

Oil Pump Screen and Pickup Tube



Removal

NOTICE: During engine repair procedures, cleanliness is extremely important. Any foreign material, including any material created while cleaning gasket surfaces that enters the oil passages, coolant passages or the oil pan, can cause engine failure.

1. With the vehicle in NEUTRAL, position it on a hoist. For additional information, refer to Section 100-02.
2. Remove the oil pan. For additional information, refer to Engine Lubrication Components — Exploded View and Oil Pan in this section.
3. Remove the 3 bolts and the oil pump screen and pickup tube assembly.
 - Discard the O-ring seal.

Installation

1. **NOTE:** *The 2 oil pump screen and pickup tube-to-oil pump bolts must be tightened prior to tightening the oil pump screen and pickup tube-to-spacer bolt.*

Using a new O-ring seal, install the oil pump screen and pickup tube and the 3 bolts. Tighten the 2 oil pump screen and pickup tube-to-oil pump bolts in 2 stages.

- Stage 1: Tighten to 10 Nm (89 lb-in).
 - Stage 2: Tighten an additional 45 degrees.
2. Tighten the oil pump screen and pickup tube-to-spacer bolt to 25 Nm (18 lb-ft).
 3. Install the oil pan. For additional information, refer to Engine Lubrication Components — Exploded View and Oil Pan in this section.