

Alphabetical Index

NOTE: This alphabetical index only lists procedure and section titles. For a full text search of this entire Workshop Manual, please use Search box above.

- Acceleration Control (Section 310-02)
- Acceleration Control (Description and Operation, 310-02 Acceleration Control)
- Acceleration Control (Diagnosis and Testing, 310-02 Acceleration Control)
- Acceleration Control (Specifications, 310-02 Acceleration Control)
- Accelerator Pedal — Adjustable (Removal and Installation, 310-02 Acceleration Control)
- Accelerator Pedal — Fixed (Removal and Installation, 310-02 Acceleration Control)
- Accessory Drive (Section 303-05)
- Accessory Drive (Description and Operation, 303-05 Accessory Drive)
- Accessory Drive (Diagnosis and Testing, 303-05 Accessory Drive)
- Accessory Drive (Specifications, 303-05 Accessory Drive)
- Accessory Protocol Interface Module (APIM) Custom Programming (General Procedures, 415-00D Information and Entertainment Systems — 8-Inch (203 mm) Touchscreen)
- Accessory Protocol Interface Module (APIM) Custom Programming (General Procedures, 415-00E Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen)
- Accessory Protocol Interface Module (APIM) Module Replacement Programming (General Procedures, 415-00D Information and Entertainment Systems — 8-Inch (203 mm) Touchscreen)
- Accessory Protocol Interface Module (APIM) Module Replacement Programming (General Procedures, 415-00E Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen)
- Accessory Protocol Interface Module (APIM) Programming (General Procedures, 415-00B Information and Entertainment Systems — AM/FM/CD)
- Accessory Protocol Interface Module (APIM) Programming (General Procedures, 415-00C Information and Entertainment Systems — 4.2-Inch (107 mm) Display)
- Accessory Protocol Interface Module (APIM) Reset (General Procedures, 415-00B Information and Entertainment Systems — AM/FM/CD)
- Accessory Protocol Interface Module (APIM) Reset (General Procedures, 415-00C Information and Entertainment Systems — 4.2-Inch (107 mm) Display)
- Accessory Protocol Interface Module (APIM) Reset (General Procedures, 415-00D Information and Entertainment Systems — 8-Inch (203 mm) Touchscreen)
- Accessory Protocol Interface Module (APIM) Reset (General Procedures, 415-00E Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen)
- Accessory Protocol Interface Module (APIM) Standard Programming (General Procedures, 415-00D Information and Entertainment Systems — 8-Inch (203 mm) Touchscreen)
- Accessory Protocol Interface Module (APIM) Standard Programming (General Procedures, 415-00E Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen)
- Accessory Protocol Interface Module (APIM) (Removal and Installation, 415-00B Information and Entertainment Systems — AM/FM/CD)
- Accessory Protocol Interface Module (APIM) (Removal and Installation, 415-00C Information and Entertainment Systems — 4.2-Inch (107 mm) Display)
- Accessory Protocol Interface Module (APIM) (Removal and Installation, 415-00D Information and Entertainment Systems — 8-Inch (203 mm) Touchscreen)
- Accessory Protocol Interface Module (APIM) (Removal and Installation, 415-00E Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen)
- Adhesives (Description and Operation, 501-35 Body Repairs)
- Adjustable Pedal Indexing (General Procedures, 206-06 Hydraulic Brake Actuation)
- Air Cleaner — 3.5L GTDI (Removal and Installation, 303-12 Intake Air Distribution and Filtering)
- Air Cleaner Outlet Pipe — 3.5L GTDI (Removal and Installation, 303-12 Intake Air Distribution and Filtering)
- Air Conditioning — Exploded View (Removal and Installation, 412-01 Climate Control)
- Air Conditioning (A/C) Clutch Air Gap Adjustment (General Procedures, 412-00 Climate Control System — General Information and Diagnostics)

Air Conditioning (A/C) Compressor Belt — 3.5L GTDI, 3.7L, 5.0L (Removal and Installation, 303-05 Accessory Drive)
 Air Conditioning (A/C) Compressor (Removal and Installation, 412-01 Climate Control)
 Air Conditioning (A/C) Odor Treatment (General Procedures, 412-00 Climate Control System — General Information and Diagnostics)
 Air Conditioning (A/C) System Flushing (General Procedures, 412-00 Climate Control System — General Information and Diagnostics)
 Air Conditioning (A/C) System Recovery, Evacuation and Charging (General Procedures, 412-00 Climate Control System — General Information and Diagnostics)
 Air Conditioning (Description and Operation, 412-01 Climate Control)
 Air Deflector (Removal and Installation, 501-17 Roof Opening Panel)
 Air Distribution and Filtering (Description and Operation, 412-01 Climate Control)
 Airbag and Safety Belt Pretensioner Supplemental Restraint System (SRS) (Description and Operation, 501-20B Supplemental Restraint System)
 Airbag and Safety Belt Pretensioner Supplemental Restraint System (SRS) (Diagnosis and Testing, 501-20B Supplemental Restraint System)
 Airbag Trim Cover — Passenger (Removal and Installation, 501-20B Supplemental Restraint System)
 Alternating Current (AC) Power Point (Removal and Installation, 414-05 High Voltage Converter/Power Point Inverter)
 Ambient Lighting Switch (Removal and Installation, 417-02 Interior Lighting)
 Anchoring and Pulling Guidelines (General Procedures, 501-35 Body Repairs)
 Antenna — AM/FM (Removal and Installation, 415-00A Information and Entertainment Systems — AM/FM)
 Antenna — AM/FM (Removal and Installation, 415-00B Information and Entertainment Systems — AM/FM/CD)
 Antenna — AM/FM (Removal and Installation, 415-00C Information and Entertainment Systems — 4.2-Inch (107 mm) Display)
 Antenna — AM/FM (Removal and Installation, 415-00D Information and Entertainment Systems — 8-Inch (203 mm) Touchscreen)
 Antenna — AM/FM (Removal and Installation, 415-00E Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen)
 Antenna — Satellite Radio (Removal and Installation, 415-00B Information and Entertainment Systems — AM/FM/CD)
 Antenna — Satellite Radio (Removal and Installation, 415-00C Information and Entertainment Systems — 4.2-Inch (107 mm) Display)
 Antenna — Satellite Radio (Removal and Installation, 415-00D Information and Entertainment Systems — 8-Inch (203 mm) Touchscreen)
 Antenna — Satellite Radio (Removal and Installation, 415-00E Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen)
 Antenna Cable — AM/FM (Removal and Installation, 415-00A Information and Entertainment Systems — AM/FM)
 Antenna Cable — AM/FM (Removal and Installation, 415-00B Information and Entertainment Systems — AM/FM/CD)
 Antenna Cable — AM/FM (Removal and Installation, 415-00C Information and Entertainment Systems — 4.2-Inch (107 mm) Display)
 Antenna Cable — AM/FM (Removal and Installation, 415-00D Information and Entertainment Systems — 8-Inch (203 mm) Touchscreen)
 Antenna Cable — AM/FM (Removal and Installation, 415-00E Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen)
 Antenna Cable — Satellite Radio (Removal and Installation, 415-00B Information and Entertainment Systems — AM/FM/CD)
 Antenna Cable — Satellite Radio (Removal and Installation, 415-00C Information and Entertainment Systems — 4.2-Inch (107 mm) Display)
 Antenna Cable — Satellite Radio (Removal and Installation, 415-00D Information and Entertainment Systems — 8-Inch (203 mm) Touchscreen)
 Antenna Cable — Satellite Radio (Removal and Installation, 415-00E Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen)
 Anti-Lock Brake System (ABS) and Stability Control (Section 206-09)
 Anti-Lock Brake System (ABS) and Stability Control (Description and Operation, 206-09 Anti-Lock Brake System (ABS) and Stability Control)
 Anti-Lock Brake System (ABS) and Stability Control (Diagnosis and Testing, 206-09 Anti-Lock Brake System (ABS) and Stability Control)
 Anti-Lock Brake System (ABS) and Stability Control (Specifications, 206-09 Anti-Lock Brake System (ABS) and Stability Control)
 Anti-Lock Brake System (ABS) Module (Removal and Installation, 206-09 Anti-Lock Brake System (ABS) and Stability

Control)

Anti-Theft — Passive Anti-Theft System (PATS) (Section 419-01B)

Anti-Theft — Perimeter (Section 419-01A)

Anti-Theft (Description and Operation, 419-01A Anti-Theft — Perimeter)

Anti-Theft (Description and Operation, 419-01B Anti-Theft — Passive Anti-Theft System (PATS))

Anti-Theft (Diagnosis and Testing, 419-01A Anti-Theft — Perimeter)

Anti-Theft (Diagnosis and Testing, 419-01B Anti-Theft — Passive Anti-Theft System (PATS))

A-Pillar Trim Panel (Removal and Installation, 501-05 Interior Trim and Ornamentation)

Appique — Rear (Removal and Installation, 501-08 Exterior Trim and Ornamentation)

Audio Control Module (ACM) Self-Diagnostic Mode (General Procedures, 415-00A Information and Entertainment Systems — AM/FM)

Audio Control Module (ACM) Self-Diagnostic Mode (General Procedures, 415-00B Information and Entertainment Systems — AM/FM/CD)

Audio Control Module (ACM) (Removal and Installation, 415-00A Information and Entertainment Systems — AM/FM)

Audio Control Module (ACM) (Removal and Installation, 415-00B Information and Entertainment Systems — AM/FM/CD)

Audio Control Module (ACM) (Removal and Installation, 415-00C Information and Entertainment Systems — 4.2-Inch (107 mm) Display)

Audio Control Module (ACM) (Removal and Installation, 415-00D Information and Entertainment Systems — 8-Inch (203 mm) Touchscreen)

Audio Control Module (ACM) (Removal and Installation, 415-00E Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen)

Audio Digital Signal Processing (DSP) Module — Front Captain's Chair (Removal and Installation, 415-00E Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen)

Audio Digital Signal Processing (DSP) Module — Split Bench (Removal and Installation, 415-00E Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen)

Audio Input Jack (Removal and Installation, 415-00B Information and Entertainment Systems — AM/FM/CD)

Audio Input Jack (Removal and Installation, 415-00C Information and Entertainment Systems — 4.2-Inch (107 mm) Display)

Autolamps Time Delay Adjustment (General Procedures, 417-01 Exterior Lighting)

Autolamps (Diagnosis and Testing, 417-01 Exterior Lighting)

Autolock and Auto-Unlock Programming (General Procedures, 501-14 Handles, Locks, Latches and Entry Systems)

Automatic Transaxle/Transmission — 6R80 (Section 307-01)

Automatic Transaxle/Transmission — 6R80 (Specifications, 307-01 Automatic Transaxle/Transmission — 6R80)

Automatic Transaxle/Transmission External Controls (Section 307-05)

Automatic Transaxle/Transmission External Controls (Specifications, 307-05 Automatic Transaxle/Transmission External Controls)

Auxiliary Brake System — Trailer Brake Control (TBC) Module (Description and Operation, 206-10 Auxiliary Brake System)

Auxiliary Brake System — Trailer Brake Control (TBC) Module (Diagnosis and Testing, 206-10 Auxiliary Brake System)

Auxiliary Brake System (Section 206-10)

Axle Assembly (Removal and Installation, 205-02A Rear Drive Axle/Differential — Ford 8.8-Inch Ring Gear)

Axle Assembly (Removal and Installation, 205-02B Rear Drive Axle/Differential — Ford 9.75-Inch Ring Gear)

Axle Assembly (Removal and Installation, 205-03 Front Drive Axle/Differential)

Axle Carrier Bushing (Removal and Installation, 205-03 Front Drive Axle/Differential)

Axle Shaft (In-vehicle Repair, 205-02A Rear Drive Axle/Differential — Ford 8.8-Inch Ring Gear)

Axle Shaft (In-vehicle Repair, 205-02B Rear Drive Axle/Differential — Ford 9.75-Inch Ring Gear)

Axle (Disassembly and Assembly, 205-03 Front Drive Axle/Differential)

Azimuth System Check (General Procedures, 413-13 Parking Aid)

Ball Joint — Lower (Removal and Installation, 204-01A Front Suspension — Rear Wheel Drive (RWD))

Ball Joint — Lower (Removal and Installation, 204-01B Front Suspension — Four Wheel Drive (4WD))

Ballast (Removal and Installation, 417-01 Exterior Lighting)

Battery and Battery Tray — Exploded View (Removal and Installation, 414-01 Battery, Mounting and Cables)

Battery and Cables (Description and Operation, 414-01 Battery, Mounting and Cables)

Battery Cables — 3.5L GTDI, 3.7L (Removal and Installation, 414-01 Battery, Mounting and Cables)

Battery Cables — 5.0L (Removal and Installation, 414-01 Battery, Mounting and Cables)

Battery Cables — 6.2L (Removal and Installation, 414-01 Battery, Mounting and Cables)

Battery Charging (General Procedures, 414-01 Battery, Mounting and Cables)

Battery Current Sensor (Removal and Installation, 414-01 Battery, Mounting and Cables)
Battery Disconnect (General Procedures, 414-01 Battery, Mounting and Cables)
Battery Drain Test (General Procedures, 414-01 Battery, Mounting and Cables)
Battery Tray (Removal and Installation, 414-01 Battery, Mounting and Cables)
Battery, Mounting and Cables (Section 414-01)
Battery, Mounting and Cables (Specifications, 414-01 Battery, Mounting and Cables)
Bearing Inspection (General Procedures, 303-00 Engine System — General Information)
Belt-Minder® Deactivating/Activating (General Procedures, 413-01 Instrumentation, Message Center, and Warning Chimes)
Bezel Diagnostics (General Procedures, 415-00C Information and Entertainment Systems — 4.2-Inch (107 mm) Display)
Bezel Diagnostics (General Procedures, 415-00D Information and Entertainment Systems — 8-Inch (203 mm) Touchscreen)
Bezel Diagnostics (General Procedures, 415-00E Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen)
Block Heater (Removal and Installation, 303-03 Engine Cooling)
Blower Motor Resistor (Removal and Installation, 412-01 Climate Control)
Blower Motor Speed Control (Removal and Installation, 412-01 Climate Control)
Blower Motor (Removal and Installation, 412-01 Climate Control)
Body Closures (Section 501-03)
Body Closures (Specifications, 501-03 Body Closures)
Body Control Module (BCM) (Diagnosis and Testing, 419-10 Multifunction Electronic Modules)
Body Control Module (BCM) (Removal and Installation, 419-10 Multifunction Electronic Modules)
Body Repairs (Section 501-35)
Body Repairs (Specifications, 501-35 Body Repairs)
Body Retainer Cage Nuts (General Procedures, 502-02 Full Frame and Body Mounting)
Body Sealer Types And Applications (Description and Operation, 501-00 Body System — General Information)
Body System — General Information (Section 501-00)
Body System — General Information (Specifications, 501-00 Body System — General Information)
Body System (Diagnosis and Testing, 501-00 Body System — General Information)
Body (Description and Operation, 501-35 Body Repairs)
B-Pillar Trim Panel — Regular Cab (Removal and Installation, 501-05 Interior Trim and Ornamentation)
B-Pillar Trim Panel — SuperCab (Removal and Installation, 501-05 Interior Trim and Ornamentation)
B-Pillar Trim Panel — SuperCrew (Removal and Installation, 501-05 Interior Trim and Ornamentation)
Brake Booster Vacuum Sensor (Removal and Installation, 206-07 Power Brake Actuation)
Brake Booster (Description and Operation, 206-07 Power Brake Actuation)
Brake Booster (Removal and Installation, 206-07 Power Brake Actuation)
Brake Caliper Anchor Plate (Removal and Installation, 206-03 Front Disc Brake)
Brake Caliper (Removal and Installation, 206-03 Front Disc Brake)
Brake Caliper (Removal and Installation, 206-04 Rear Disc Brake)
Brake Disc Machining (General Procedures, 206-00 Brake System — General Information)
Brake Disc Shield (Removal and Installation, 206-03 Front Disc Brake)
Brake Disc Shield (Removal and Installation, 206-04 Rear Disc Brake)
Brake Disc (Removal and Installation, 206-03 Front Disc Brake)
Brake Disc (Removal and Installation, 206-04 Rear Disc Brake)
Brake Flexible Hose — Inner (Removal and Installation, 206-04 Rear Disc Brake)
Brake Flexible Hose — Outer (Removal and Installation, 206-04 Rear Disc Brake)
Brake Flexible Hose (Removal and Installation, 206-03 Front Disc Brake)
Brake Master Cylinder (Removal and Installation, 206-06 Hydraulic Brake Actuation)
Brake Pads (Removal and Installation, 206-03 Front Disc Brake)
Brake Pads (Removal and Installation, 206-04 Rear Disc Brake)
Brake Pedal and Bracket (Removal and Installation, 206-06 Hydraulic Brake Actuation)
Brake Pedal Control Switch (Removal and Installation, 206-06 Hydraulic Brake Actuation)
Brake Shift Interlock Actuator — Column Shift (Removal and Installation, 307-05 Automatic Transaxle/Transmission External Controls)
Brake Shift Interlock Actuator — Floor Shift (Removal and Installation, 307-05 Automatic Transaxle/Transmission External Controls)
Brake Shift Interlock Override — Column Shift (General Procedures, 307-05 Automatic Transaxle/Transmission External Controls)

- Brake Shift Interlock Override — Floor Shift (General Procedures, 307-05 Automatic Transaxle/Transmission External Controls)
- Brake System — General Information (Section 206-00)
- Brake System — General Information (Specifications, 206-00 Brake System — General Information)
- Brake System Bleeding (General Procedures, 206-00 Brake System — General Information)
- Brake System Inspection (General Procedures, 206-00 Brake System — General Information)
- Brake System (Description and Operation, 206-00 Brake System — General Information)
- Brake Vacuum Pump (Removal and Installation, 206-07 Power Brake Actuation)
- Bumper — Front (Removal and Installation, 501-19 Bumpers)
- Bumper — Rear (Removal and Installation, 501-19 Bumpers)
- Bumper Cover — Front (Removal and Installation, 501-19 Bumpers)
- Bumper Rust Prevention — Front, Chrome (General Procedures, 501-19 Bumpers)
- Bumpers (Section 501-19)
- Bumpers (Specifications, 501-19 Bumpers)
- Camber and Caster Adjustment (General Procedures, 204-00 Suspension System — General Information)
- Camera Switching Module (Removal and Installation, 413-13 Parking Aid)
- Camshaft — LH (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)
- Camshaft — LH (In-vehicle Repair, 303-01B Engine — 3.7L)
- Camshaft — LH (In-vehicle Repair, 303-01C Engine — 5.0L (4V))
- Camshaft — LH (In-vehicle Repair, 303-01D Engine — 6.2L (2V))
- Camshaft — RH (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)
- Camshaft — RH (In-vehicle Repair, 303-01B Engine — 3.7L)
- Camshaft — RH (In-vehicle Repair, 303-01C Engine — 5.0L (4V))
- Camshaft — RH (In-vehicle Repair, 303-01D Engine — 6.2L (2V))
- Camshaft Bearing Journal Diameter (General Procedures, 303-00 Engine System — General Information)
- Camshaft End Play — OHC Engines (General Procedures, 303-00 Engine System — General Information)
- Camshaft Journal to Bearing Clearance — OHC Engines (General Procedures, 303-00 Engine System — General Information)
- Camshaft Lobe Lift (General Procedures, 303-00 Engine System — General Information)
- Camshaft Phaser and Sprocket — LH (In-vehicle Repair, 303-01D Engine — 6.2L (2V))
- Camshaft Phaser and Sprocket — RH (In-vehicle Repair, 303-01D Engine — 6.2L (2V))
- Camshaft Position (CMP) Sensor — 3.5L GTDI (Removal and Installation, 303-14 Electronic Engine Controls)
- Camshaft Position (CMP) Sensor — 5.0L (4V) (Removal and Installation, 303-14 Electronic Engine Controls)
- Camshaft Roller Follower (In-vehicle Repair, 303-01C Engine — 5.0L (4V))
- Camshaft Runout (General Procedures, 303-00 Engine System — General Information)
- Camshaft Surface Inspection (General Procedures, 303-00 Engine System — General Information)
- Charge Air Cooler (CAC) Cleaning (General Procedures, 303-12 Intake Air Distribution and Filtering)
- Charge Air Cooler (Removal and Installation, 303-12 Intake Air Distribution and Filtering)
- Charging System (Section 414-00)
- Charging System (Description and Operation, 414-00 Charging System)
- Charging System (Specifications, 414-00 Charging System)
- Child Safety Seat Tether Anchor — LATCH, SuperCab and Crew Cab (Removal and Installation, 501-20A Safety Belt System)
- Child Safety Seat Tether Anchor (Removal and Installation, 501-20A Safety Belt System)
- Climate Control (Section 412-01)
- Climate Control System — General Information and Diagnostics (Section 412-00)
- Climate Control System — General Information and Diagnostics (Specifications, 412-00 Climate Control System — General Information and Diagnostics)
- Climate Control System (Description and Operation, 412-00 Climate Control System — General Information and Diagnostics)
- Climate Control System (Diagnosis and Testing, 412-00 Climate Control System — General Information and Diagnostics)
- Climate Control (Specifications, 412-01 Climate Control)
- Clockspring (Removal and Installation, 501-20B Supplemental Restraint System)
- Clutch and Clutch Field Coil (Removal and Installation, 412-01 Climate Control)
- Communications Network (Description and Operation, 418-00 Module Communications Network)
- Communications Network (Diagnosis and Testing, 418-00 Module Communications Network)
- Compass Calibration (General Procedures, 413-01 Instrumentation, Message Center, and Warning Chimes)
- Compass Module (Removal and Installation, 415-00B Information and Entertainment Systems — AM/FM/CD)

Compass Zone Adjustment (General Procedures, 413-01 Instrumentation, Message Center, and Warning Chimes)

Component Bleeding (General Procedures, 206-00 Brake System — General Information)

Component Tests (Diagnosis and Testing, 206-00 Brake System — General Information)

Compressor to Condenser Discharge Line (Removal and Installation, 412-01 Climate Control)

Condenser Core (Removal and Installation, 412-01 Climate Control)

Connecting Rod Bearing Journal Taper and Out-of-Round (General Procedures, 303-00 Engine System — General Information)

Connecting Rod Bearing Journal-to-Bearing Clearance (General Procedures, 303-00 Engine System — General Information)

Connecting Rod Bend (General Procedures, 303-00 Engine System — General Information)

Connecting Rod Bushing Diameter (General Procedures, 303-00 Engine System — General Information)

Connecting Rod Cleaning (General Procedures, 303-00 Engine System — General Information)

Connecting Rod Large End Bore (General Procedures, 303-00 Engine System — General Information)

Connecting Rod to Crankshaft Side Clearance (General Procedures, 303-00 Engine System — General Information)

Connecting Rod Twist (General Procedures, 303-00 Engine System — General Information)

Console — Floor (Removal and Installation, 501-12 Instrument Panel and Console)

Console — Overhead (Removal and Installation, 501-12 Instrument Panel and Console)

Control Components (Description and Operation, 412-01 Climate Control)

Coolant Crossover Manifold Assembly — 3.5L GTDI (Removal and Installation, 303-03 Engine Cooling)

Coolant Expansion Tank — 6.2L (Removal and Installation, 303-03 Engine Cooling)

Coolant Inlet Pipe — 3.5L GTDI (Removal and Installation, 303-03 Engine Cooling)

Coolant Pump — 3.5L GTDI, 3.7L (Removal and Installation, 303-03 Engine Cooling)

Coolant Pump — 5.0L (Removal and Installation, 303-03 Engine Cooling)

Coolant Pump — 6.2L (Removal and Installation, 303-03 Engine Cooling)

Cooling Fan Motor and Shroud (Removal and Installation, 303-03 Engine Cooling)

Cooling Module (Removal and Installation, 303-03 Engine Cooling)

Cooling System Draining, Filling and Bleeding (General Procedures, 303-03 Engine Cooling)

Cooling System Flushing (General Procedures, 303-03 Engine Cooling)

Core Plug Replacement (General Procedures, 303-00 Engine System — General Information)

Cowl Panel Grille (Removal and Installation, 501-02 Front End Body Panels)

Cowl Side Trim Panel (Removal and Installation, 501-05 Interior Trim and Ornamentation)

C-Pillar Trim Panel (Removal and Installation, 501-05 Interior Trim and Ornamentation)

Crankshaft End Play (General Procedures, 303-00 Engine System — General Information)

Crankshaft Front Seal (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)

Crankshaft Front Seal (In-vehicle Repair, 303-01B Engine — 3.7L)

Crankshaft Front Seal (In-vehicle Repair, 303-01C Engine — 5.0L (4V))

Crankshaft Front Seal (In-vehicle Repair, 303-01D Engine — 6.2L (2V))

Crankshaft Main Bearing Journal Diameter (General Procedures, 303-00 Engine System — General Information)

Crankshaft Main Bearing Journal Taper and Out-of-Round (General Procedures, 303-00 Engine System — General Information)

Crankshaft Main Bearing Journal-to-Bearing Clearance (General Procedures, 303-00 Engine System — General Information)

Crankshaft Position (CKP) Sensor — 5.0L (4V) (Removal and Installation, 303-14 Electronic Engine Controls)

Crankshaft Pulley and Crankshaft Front Seal — Exploded View (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)

Crankshaft Pulley and Crankshaft Front Seal — Exploded View (In-vehicle Repair, 303-01B Engine — 3.7L)

Crankshaft Pulley and Crankshaft Front Seal — Exploded View (In-vehicle Repair, 303-01C Engine — 5.0L (4V))

Crankshaft Pulley and Crankshaft Front Seal — Exploded View (In-vehicle Repair, 303-01D Engine — 6.2L (2V))

Crankshaft Pulley (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)

Crankshaft Pulley (In-vehicle Repair, 303-01B Engine — 3.7L)

Crankshaft Pulley (In-vehicle Repair, 303-01C Engine — 5.0L (4V))

Crankshaft Pulley (In-vehicle Repair, 303-01D Engine — 6.2L (2V))

Crankshaft Rear Seal with Retainer Plate (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)

Crankshaft Rear Seal with Retainer Plate (In-vehicle Repair, 303-01B Engine — 3.7L)

Crankshaft Rear Seal with Retainer Plate (In-vehicle Repair, 303-01C Engine — 5.0L (4V))

Crankshaft Rear Seal with Retainer Plate (In-vehicle Repair, 303-01D Engine — 6.2L (2V))

Crankshaft Rear Seal (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)

Crankshaft Rear Seal (In-vehicle Repair, 303-01B Engine — 3.7L)

Crankshaft Rear Seal (In-vehicle Repair, 303-01C Engine — 5.0L (4V))

Crankshaft Seal (In-vehicle Repair, 303-01D Engine — 6.2L (2V))

Cruise Control (Section 419-03)

Cruise Control (Description and Operation, 419-03 Cruise Control)

Cruise Control (Diagnosis and Testing, 419-03 Cruise Control)

Cylinder Block Distortion (General Procedures, 303-00 Engine System — General Information)

Cylinder Bore Cleaning (General Procedures, 303-00 Engine System — General Information)

Cylinder Bore Out-of-Round (General Procedures, 303-00 Engine System — General Information)

Cylinder Bore Taper (General Procedures, 303-00 Engine System — General Information)

Cylinder Head — LH (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)

Cylinder Head — LH (In-vehicle Repair, 303-01B Engine — 3.7L)

Cylinder Head — LH (In-vehicle Repair, 303-01C Engine — 5.0L (4V))

Cylinder Head — RH (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)

Cylinder Head — RH (In-vehicle Repair, 303-01B Engine — 3.7L)

Cylinder Head — RH (In-vehicle Repair, 303-01C Engine — 5.0L (4V))

Cylinder Head Distortion (General Procedures, 303-00 Engine System — General Information)

Cylinder Head (Disassembly and Assembly of Subassemblies, 303-01A Engine — 3.5L GTDI)

Cylinder Head (Disassembly and Assembly of Subassemblies, 303-01B Engine — 3.7L)

Cylinder Head (Disassembly and Assembly of Subassemblies, 303-01C Engine — 5.0L (4V))

Cylinder Head (Disassembly and Assembly of Subassemblies, 303-01D Engine — 6.2L (2V))

Cylinder Head (Installation, 303-01D Engine — 6.2L (2V))

Cylinder Head (Removal, 303-01D Engine — 6.2L (2V))

Daytime Running Lamps (DRL) (Diagnosis and Testing, 417-01 Exterior Lighting)

Degas Bottle — 3.5L GTDI, 3.7L, 5.0L (Removal and Installation, 303-03 Engine Cooling)

Diagnosis By Symptom (Diagnosis and Testing, 307-01 Automatic Transaxle/Transmission — 6R80)

Diagnostic Methods (Description and Operation, 100-00 Service Information)

Diagnostic Parameters Identification (PID) Chart (Diagnosis and Testing, 307-01 Automatic Transaxle/Transmission — 6R80)

Diagnostic Strategy (Diagnosis and Testing, 307-01 Automatic Transaxle/Transmission — 6R80)

Diagnostic Trouble Code (DTC) Chart (Diagnosis and Testing, 414-00 Charging System)

Diagnostic Trouble Code (DTC) Chart (Diagnosis and Testing, 417-01 Exterior Lighting)

Diagnostic Trouble Code (DTC) Chart (Diagnosis and Testing, 419-10 Multifunction Electronic Modules)

Diagnostic Trouble Code (DTC) Charts (Diagnosis and Testing, 206-06 Hydraulic Brake Actuation)

Diagnostic Trouble Code (DTC) Charts (Diagnosis and Testing, 307-01 Automatic Transaxle/Transmission — 6R80)

Diagnostics (Diagnosis and Testing, 307-01 Automatic Transaxle/Transmission — 6R80)

Differential Bearings (In-vehicle Repair, 205-02A Rear Drive Axle/Differential — Ford 8.8-Inch Ring Gear)

Differential Bearings (In-vehicle Repair, 205-02B Rear Drive Axle/Differential — Ford 9.75-Inch Ring Gear)

Differential Bearings (Removal and Installation, 205-03 Front Drive Axle/Differential)

Differential Carrier (Removal and Installation, 205-02A Rear Drive Axle/Differential — Ford 8.8-Inch Ring Gear)

Differential Carrier (Removal and Installation, 205-02B Rear Drive Axle/Differential — Ford 9.75-Inch Ring Gear)

Differential Carrier (Removal and Installation, 205-03 Front Drive Axle/Differential)

Differential Case and Ring Gear — Conventional (Disassembly and Assembly, 205-02A Rear Drive Axle/Differential — Ford 8.8-Inch Ring Gear)

Differential Case and Ring Gear — Conventional (Disassembly and Assembly, 205-02B Rear Drive Axle/Differential — Ford 9.75-Inch Ring Gear)

Differential Case and Ring Gear — Electronic Locking Differential (ELD) (Disassembly and Assembly, 205-02B Rear Drive Axle/Differential — Ford 9.75-Inch Ring Gear)

Differential Case and Ring Gear — Traction-Lok (Disassembly and Assembly, 205-02A Rear Drive Axle/Differential — Ford 8.8-Inch Ring Gear)

Differential Case and Ring Gear — Traction-Lok (Disassembly and Assembly, 205-02B Rear Drive Axle/Differential — Ford 9.75-Inch Ring Gear)

Differential Case Runout Check (General Procedures, 205-03 Front Drive Axle/Differential)

Differential Case (Disassembly and Assembly, 205-03 Front Drive Axle/Differential)

Differential Housing Cover (In-vehicle Repair, 205-02A Rear Drive Axle/Differential — Ford 8.8-Inch Ring Gear)

Differential Housing Cover (In-vehicle Repair, 205-02B Rear Drive Axle/Differential — Ford 9.75-Inch Ring Gear)

Differential Ring And Pinion (In-vehicle Repair, 205-02A Rear Drive Axle/Differential — Ford 8.8-Inch Ring Gear)

Differential Ring And Pinion (In-vehicle Repair, 205-02B Rear Drive Axle/Differential — Ford 9.75-Inch Ring Gear)

Differential Ring And Pinion (Removal and Installation, 205-03 Front Drive Axle/Differential)

Direct Clutch Assembly (Disassembly and Assembly of Subassemblies, 307-01 Automatic Transaxle/Transmission —

6R80)
Direct Current/Alternating Current (DC/AC) Inverter (Removal and Installation, 414-05 High Voltage Converter/Power Point Inverter)
Disabling Transport or Factory Mode (General Procedures, 419-10 Multifunction Electronic Modules)
Door — Front (Removal and Installation, 501-03 Body Closures)
Door — Rear, SuperCab (Removal and Installation, 501-03 Body Closures)
Door — Rear, SuperCrew (Removal and Installation, 501-03 Body Closures)
Door Ajar Switch — Rear, SuperCab (Removal and Installation, 501-14 Handles, Locks, Latches and Entry Systems)
Door Alignment — Front (General Procedures, 501-03 Body Closures)
Door Alignment — Rear, SuperCab (General Procedures, 501-03 Body Closures)
Door Alignment — Rear, SuperCrew (General Procedures, 501-03 Body Closures)
Door Check Arm — Front (Removal and Installation, 501-03 Body Closures)
Door Check Arm — Rear, SuperCab and SuperCrew (Removal and Installation, 501-03 Body Closures)
Door Glass Top Run — Front (Removal and Installation, 501-11 Glass, Frames and Mechanisms)
Door Glass Top Run — Rear, SuperCab (Removal and Installation, 501-11 Glass, Frames and Mechanisms)
Door Glass Top Run — Rear, SuperCrew (Removal and Installation, 501-11 Glass, Frames and Mechanisms)
Door Handle to Latch Rod Adjustment (General Procedures, 501-14 Handles, Locks, Latches and Entry Systems)
Door Lock Control Switch (Removal and Installation, 501-14 Handles, Locks, Latches and Entry Systems)
Door Lock Cylinder (Removal and Installation, 501-14 Handles, Locks, Latches and Entry Systems)
Door Outer Panel (Removal and Installation, 501-35 Body Repairs)
Door Trim Panel — Front (Removal and Installation, 501-05 Interior Trim and Ornamentation)
Door Trim Panel — Rear, SuperCab (Removal and Installation, 501-05 Interior Trim and Ornamentation)
Door Trim Panel — Rear, SuperCrew (Removal and Installation, 501-05 Interior Trim and Ornamentation)
Drive Pinion Flange and Drive Pinion Seal (In-vehicle Repair, 205-02A Rear Drive Axle/Differential — Ford 8.8-Inch Ring Gear)
Drive Pinion Flange and Drive Pinion Seal (In-vehicle Repair, 205-02B Rear Drive Axle/Differential — Ford 9.75-Inch Ring Gear)
Drive Pinion Flange and Seal (In-vehicle Repair, 205-03 Front Drive Axle/Differential)
Driveline Angle Adjustment (General Procedures, 205-00 Driveline System — General Information)
Driveline Angle Measurement (General Procedures, 205-00 Driveline System — General Information)
Driveline System — General Information (Section 205-00)
Driveline System — General Information (Specifications, 205-00 Driveline System — General Information)
Driveline System (Description and Operation, 205-00 Driveline System — General Information)
Driveline System (Diagnosis and Testing, 205-00 Driveline System — General Information)
Driver Airbag (Removal and Installation, 501-20B Supplemental Restraint System)
Driver Seat Module (DSM) (Removal and Installation, 501-10 Seating)
Driveshaft — Front (Removal and Installation, 205-01 Driveshaft)
Driveshaft — Rear, One-Piece (Removal and Installation, 205-01 Driveshaft)
Driveshaft — Rear, Two-Piece (Removal and Installation, 205-01 Driveshaft)
Driveshaft (Section 205-01)
Driveshaft Runout and Balancing (General Procedures, 205-00 Driveline System — General Information)
Driveshaft Slip Yoke Boot (Removal and Installation, 205-01 Driveshaft)
Driveshaft Universal Joint — Snap Ring Type (Disassembly and Assembly, 205-01 Driveshaft)
Driveshaft (Description and Operation, 205-01 Driveshaft)
Driveshaft (Diagnosis and Testing, 205-01 Driveshaft)
Driveshaft (Specifications, 205-01 Driveshaft)
Dual Climate Controlled Seat Module (DCSM) (Removal and Installation, 501-10 Seating)
Dust Separator (Removal and Installation, 303-13 Evaporative Emissions)
Electronic Engine Controls (Section 303-14)
Electronic Engine Controls (Description and Operation, 303-14 Electronic Engine Controls)
Electronic Engine Controls (Diagnosis and Testing, 303-14 Electronic Engine Controls)
Electronic Engine Controls (Specifications, 303-14 Electronic Engine Controls)
Electronic Leak Detection (General Procedures, 412-00 Climate Control System — General Information and Diagnostics)
Electronic Locking Differential (ELD) Field Coil (In-vehicle Repair, 205-02B Rear Drive Axle/Differential — Ford 9.75-Inch Ring Gear)
Electronic Locking Differential (ELD) System (Diagnosis and Testing, 308-07A Four Wheel Drive (4WD) Systems)
Elevation System Check (General Procedures, 413-13 Parking Aid)
Engine — 3.5L GTDI (Section 303-01A)

Engine — 3.5L GTDI (Specifications, 303-01A Engine — 3.5L GTDI)
Engine — 3.7L (Section 303-01B)
Engine — 3.7L (Specifications, 303-01B Engine — 3.7L)
Engine — 5.0L (4V) (Section 303-01C)
Engine — 5.0L (4V) (Specifications, 303-01C Engine — 5.0L (4V))
Engine — 6.2L (2V) (Section 303-01D)
Engine — 6.2L (2V) (Specifications, 303-01D Engine — 6.2L (2V))
Engine Control Components — Exploded View, 3.5L GTDI (Removal and Installation, 303-14 Electronic Engine Controls)
Engine Control Components — Exploded View, 3.7L (Removal and Installation, 303-14 Electronic Engine Controls)
Engine Control Components — Exploded View, 5.0L (4V) (Removal and Installation, 303-14 Electronic Engine Controls)
Engine Control Components — Exploded View, 6.2L (2V) (Removal and Installation, 303-14 Electronic Engine Controls)
Engine Cooling (Section 303-03)
Engine Cooling (Description and Operation, 303-03 Engine Cooling)
Engine Cooling (Diagnosis and Testing, 303-03 Engine Cooling)
Engine Cooling (Specifications, 303-03 Engine Cooling)
Engine Emission Control (Section 303-08)
Engine Emission Control (Description and Operation, 303-08 Engine Emission Control)
Engine Emission Control (Diagnosis and Testing, 303-08 Engine Emission Control)
Engine Front Cover (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)
Engine Front Cover (In-vehicle Repair, 303-01B Engine — 3.7L)
Engine Front Cover (In-vehicle Repair, 303-01C Engine — 5.0L (4V))
Engine Front Cover (In-vehicle Repair, 303-01D Engine — 6.2L (2V))
Engine Ignition — 3.5L GTDI (Section 303-07A)
Engine Ignition — 3.5L GTDI (Specifications, 303-07A Engine Ignition — 3.5L GTDI)
Engine Ignition — 3.7L (Section 303-07B)
Engine Ignition — 3.7L (Specifications, 303-07B Engine Ignition — 3.7L)
Engine Ignition — 5.0L (4V) (Section 303-07C)
Engine Ignition — 5.0L (4V) (Specifications, 303-07C Engine Ignition — 5.0L (4V))
Engine Ignition — 6.2L (2V) (Section 303-07D)
Engine Ignition — 6.2L (2V) (Specifications, 303-07D Engine Ignition — 6.2L (2V))
Engine Ignition Components — Exploded View (Removal and Installation, 303-07A Engine Ignition — 3.5L GTDI)
Engine Ignition Components — Exploded View (Removal and Installation, 303-07B Engine Ignition — 3.7L)
Engine Ignition Components — Exploded View (Removal and Installation, 303-07C Engine Ignition — 5.0L (4V))
Engine Ignition Components — Exploded View (Removal and Installation, 303-07D Engine Ignition — 6.2L (2V))
Engine Ignition (Description and Operation, 303-07A Engine Ignition — 3.5L GTDI)
Engine Ignition (Description and Operation, 303-07B Engine Ignition — 3.7L)
Engine Ignition (Description and Operation, 303-07C Engine Ignition — 5.0L (4V))
Engine Ignition (Description and Operation, 303-07D Engine Ignition — 6.2L (2V))
Engine Ignition (Diagnosis and Testing, 303-07A Engine Ignition — 3.5L GTDI)
Engine Ignition (Diagnosis and Testing, 303-07B Engine Ignition — 3.7L)
Engine Ignition (Diagnosis and Testing, 303-07C Engine Ignition — 5.0L (4V))
Engine Ignition (Diagnosis and Testing, 303-07D Engine Ignition — 6.2L (2V))
Engine Lubrication Components — Exploded View (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)
Engine Lubrication Components — Exploded View (In-vehicle Repair, 303-01B Engine — 3.7L)
Engine Lubrication Components — Exploded View (In-vehicle Repair, 303-01C Engine — 5.0L (4V))
Engine Lubrication Components — Exploded View (In-vehicle Repair, 303-01D Engine — 6.2L (2V))
Engine Oil Pressure (EOP) Switch (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)
Engine Oil Pressure (EOP) Switch (In-vehicle Repair, 303-01B Engine — 3.7L)
Engine Oil Pressure (EOP) Switch (In-vehicle Repair, 303-01C Engine — 5.0L (4V))
Engine Oil Pressure (EOP) Switch (In-vehicle Repair, 303-01D Engine — 6.2L (2V))
Engine Support Insulators — LH (In-vehicle Repair, 303-01C Engine — 5.0L (4V))
Engine Support Insulators — RH (In-vehicle Repair, 303-01C Engine — 5.0L (4V))
Engine Support Insulators (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)
Engine Support Insulators (In-vehicle Repair, 303-01B Engine — 3.7L)
Engine Support Insulators (In-vehicle Repair, 303-01D Engine — 6.2L (2V))
Engine System — General Information (Section 303-00)
Engine System — General Information (Specifications, 303-00 Engine System — General Information)
Engine (Assembly, 303-01A Engine — 3.5L GTDI)

Engine (Assembly, 303-01B Engine — 3.7L)
Engine (Assembly, 303-01C Engine — 5.0L (4V))
Engine (Assembly, 303-01D Engine — 6.2L (2V))
Engine (Description and Operation, 303-00 Engine System — General Information)
Engine (Description and Operation, 303-01A Engine — 3.5L GTDI)
Engine (Description and Operation, 303-01B Engine — 3.7L)
Engine (Description and Operation, 303-01C Engine — 5.0L (4V))
Engine (Description and Operation, 303-01D Engine — 6.2L (2V))
Engine (Diagnosis and Testing, 303-00 Engine System — General Information)
Engine (Diagnosis and Testing, 303-01A Engine — 3.5L GTDI)
Engine (Diagnosis and Testing, 303-01B Engine — 3.7L)
Engine (Diagnosis and Testing, 303-01C Engine — 5.0L (4V))
Engine (Diagnosis and Testing, 303-01D Engine — 6.2L (2V))
Engine (Disassembly, 303-01A Engine — 3.5L GTDI)
Engine (Disassembly, 303-01B Engine — 3.7L)
Engine (Disassembly, 303-01C Engine — 5.0L (4V))
Engine (Disassembly, 303-01D Engine — 6.2L (2V))
Engine (Installation, 303-01A Engine — 3.5L GTDI)
Engine (Installation, 303-01B Engine — 3.7L)
Engine (Installation, 303-01C Engine — 5.0L (4V))
Engine (Installation, 303-01D Engine — 6.2L (2V))
Engine (Removal, 303-01A Engine — 3.5L GTDI)
Engine (Removal, 303-01B Engine — 3.7L)
Engine (Removal, 303-01C Engine — 5.0L (4V))
Engine (Removal, 303-01D Engine — 6.2L (2V))
Evaporative Emission (EVAP) System Components — Exploded View (Removal and Installation, 303-13 Evaporative Emissions)
Evaporative Emission (EVAP) Vapor Ejector (Removal and Installation, 303-13 Evaporative Emissions)
Evaporative Emission Canister Purge Valve (Removal and Installation, 303-13 Evaporative Emissions)
Evaporative Emission Canister Vent Solenoid (Removal and Installation, 303-13 Evaporative Emissions)
Evaporative Emission Canister (Removal and Installation, 303-13 Evaporative Emissions)
Evaporative Emission System Leak Test (General Procedures, 303-13 Evaporative Emissions)
Evaporative Emissions (Section 303-13)
Evaporative Emissions (Description and Operation, 303-13 Evaporative Emissions)
Evaporative Emissions (Diagnosis and Testing, 303-13 Evaporative Emissions)
Evaporative Emissions (Specifications, 303-13 Evaporative Emissions)
Evaporator Core (Removal and Installation, 412-01 Climate Control)
Exhaust Intermediate Pipe (Removal and Installation, 309-00 Exhaust System)
Exhaust Manifold — LH (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)
Exhaust Manifold — LH (In-vehicle Repair, 303-01B Engine — 3.7L)
Exhaust Manifold — LH (In-vehicle Repair, 303-01C Engine — 5.0L (4V))
Exhaust Manifold — LH (In-vehicle Repair, 303-01D Engine — 6.2L (2V))
Exhaust Manifold — RH (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)
Exhaust Manifold — RH (In-vehicle Repair, 303-01B Engine — 3.7L)
Exhaust Manifold — RH (In-vehicle Repair, 303-01C Engine — 5.0L (4V))
Exhaust Manifold — RH (In-vehicle Repair, 303-01D Engine — 6.2L (2V))
Exhaust Manifold Cleaning and Inspection (General Procedures, 303-00 Engine System — General Information)
Exhaust System — Exploded View (Removal and Installation, 309-00 Exhaust System)
Exhaust System (Section 309-00)
Exhaust System Alignment (General Procedures, 309-00 Exhaust System)
Exhaust System (Description and Operation, 309-00 Exhaust System)
Exhaust System (Diagnosis and Testing, 309-00 Exhaust System)
Exhaust System (Specifications, 309-00 Exhaust System)
Exhaust Y-Pipe — Dual Catalytic Converter (Removal and Installation, 309-00 Exhaust System)
Exterior Door Handle — SuperCrew (Removal and Installation, 501-14 Handles, Locks, Latches and Entry Systems)
Exterior Front Door Handle (Removal and Installation, 501-14 Handles, Locks, Latches and Entry Systems)
Exterior Lighting (Section 417-01)
Exterior Lighting (Description and Operation, 417-01 Exterior Lighting)

Exterior Lighting (Specifications, 417-01 Exterior Lighting)

Exterior Mirror Control Switch — Aero (Removal and Installation, 501-09 Rear View Mirrors)

Exterior Mirror Control Switch — Trailer Tow (Removal and Installation, 501-09 Rear View Mirrors)

Exterior Mirror Cover — Aero (Removal and Installation, 501-09 Rear View Mirrors)

Exterior Mirror Cover — Trailer Tow (Removal and Installation, 501-09 Rear View Mirrors)

Exterior Mirror Glass — Aero (Removal and Installation, 501-09 Rear View Mirrors)

Exterior Mirror Glass — Spotter, Trailer Tow (Removal and Installation, 501-09 Rear View Mirrors)

Exterior Mirror Glass — Trailer Tow (Removal and Installation, 501-09 Rear View Mirrors)

Exterior Mirror Motor Synchronization — Power Folding (General Procedures, 501-09 Rear View Mirrors)

Exterior Mirror Motor (Removal and Installation, 501-09 Rear View Mirrors)

Exterior Mirror (Removal and Installation, 501-09 Rear View Mirrors)

Exterior Trim — Exploded View (Removal and Installation, 501-08 Exterior Trim and Ornamentation)

Exterior Trim and Ornamentation (Section 501-08)

Exterior Trim and Ornamentation (Specifications, 501-08 Exterior Trim and Ornamentation)

Exterior Trim (Description and Operation, 501-08 Exterior Trim and Ornamentation)

External Controls — Column Shift (Diagnosis and Testing, 307-05 Automatic Transaxle/Transmission External Controls)

External Controls — Floor Shift (Diagnosis and Testing, 307-05 Automatic Transaxle/Transmission External Controls)

External Controls (Description and Operation, 307-05 Automatic Transaxle/Transmission External Controls)

Fender Moulding — Front (Removal and Installation, 501-08 Exterior Trim and Ornamentation)

Fender Moulding — Rear (Removal and Installation, 501-08 Exterior Trim and Ornamentation)

Fender Splash Shield (Removal and Installation, 501-02 Front End Body Panels)

Fender (Removal and Installation, 501-02 Front End Body Panels)

Flexplate Inspection (General Procedures, 303-00 Engine System — General Information)

Flexplate or Flywheel and Crankshaft Rear Seal — Exploded View (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)

Flexplate or Flywheel and Crankshaft Rear Seal — Exploded View (In-vehicle Repair, 303-01B Engine — 3.7L)

Flexplate or Flywheel and Crankshaft Rear Seal — Exploded View (In-vehicle Repair, 303-01C Engine — 5.0L (4V))

Flexplate or Flywheel and Crankshaft Rear Seal — Exploded View (In-vehicle Repair, 303-01D Engine — 6.2L (2V))

Flexplate (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)

Flexplate (In-vehicle Repair, 303-01B Engine — 3.7L)

Flexplate (In-vehicle Repair, 303-01C Engine — 5.0L (4V))

Flexplate (In-vehicle Repair, 303-01D Engine — 6.2L (2V))

Fluid Pan, Gasket and Filter (In-vehicle Repair, 307-01 Automatic Transaxle/Transmission — 6R80)

Fluorescent Dye Leak Detection (General Procedures, 412-00 Climate Control System — General Information and Diagnostics)

Flywheel Inspection (General Procedures, 303-00 Engine System — General Information)

Fog Lamp Bulb (Removal and Installation, 417-01 Exterior Lighting)

Fog Lamp (Removal and Installation, 417-01 Exterior Lighting)

Fog Lamps (Diagnosis and Testing, 417-01 Exterior Lighting)

Forward Clutch Assembly (Disassembly and Assembly of Subassemblies, 307-01 Automatic Transaxle/Transmission — 6R80)

Forward/Overdrive Clutch Assembly — Assembly (Disassembly and Assembly of Subassemblies, 307-01 Automatic Transaxle/Transmission — 6R80)

Forward/Overdrive Clutch Assembly — Disassembly (Disassembly and Assembly of Subassemblies, 307-01 Automatic Transaxle/Transmission — 6R80)

Four Wheel Drive (4WD) Systems — 2-Speed Torque-On-Demand (Diagnosis and Testing, 308-07A Four Wheel Drive (4WD) Systems)

Four Wheel Drive (4WD) Systems — Electronic Shift (Diagnosis and Testing, 308-07A Four Wheel Drive (4WD) Systems)

Four Wheel Drive (4WD) Systems (Section 308-07A)

Four Wheel Drive (4WD) Systems (Description and Operation, 308-07A Four Wheel Drive (4WD) Systems)

Four Wheel Drive (4WD) Systems (Specifications, 308-07A Four Wheel Drive (4WD) Systems)

Frame and Body Mounting (Description and Operation, 502-02 Full Frame and Body Mounting)

Frame Drilling (General Procedures, 502-02 Full Frame and Body Mounting)

Frame Members — Bed Attachment Bracket (Removal and Installation, 501-35 Body Repairs)

Frame Members — Front Frame Horn (Removal and Installation, 501-35 Body Repairs)

Frame Members — Front Frame Section (Removal and Installation, 501-35 Body Repairs)

Frame Members — Rear Frame Section (Removal and Installation, 501-35 Body Repairs)

Front Controls Interface Module (FCIM) (Removal and Installation, 415-00B Information and Entertainment Systems — AM/FM/CD)

- Front Controls Interface Module (FCIM) (Removal and Installation, 415-00C Information and Entertainment Systems — 4.2-Inch (107 mm) Display)
- Front Controls Interface Module (FCIM) (Removal and Installation, 415-00D Information and Entertainment Systems — 8-Inch (203 mm) Touchscreen)
- Front Controls Interface Module (FCIM) (Removal and Installation, 415-00E Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen)
- Front Controls/Display Interface Module (FCDIM) (Removal and Installation, 415-00C Information and Entertainment Systems — 4.2-Inch (107 mm) Display)
- Front Cover Radial Seal (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)
- Front Cover Radial Seal (In-vehicle Repair, 303-01B Engine — 3.7L)
- Front Disc Brake (Section 206-03)
- Front Disc Brake (Description and Operation, 206-03 Front Disc Brake)
- Front Disc Brake (Diagnosis and Testing, 206-03 Front Disc Brake)
- Front Disc Brake (Specifications, 206-03 Front Disc Brake)
- Front Display Interface Module (FDIM) (Removal and Installation, 415-00B Information and Entertainment Systems — AM/FM/CD)
- Front Display Interface Module (FDIM) (Removal and Installation, 415-00D Information and Entertainment Systems — 8-Inch (203 mm) Touchscreen)
- Front Display Interface Module (FDIM) (Removal and Installation, 415-00E Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen)
- Front Door Handles, Locks and Latches — Exploded View (Removal and Installation, 501-14 Handles, Locks, Latches and Entry Systems)
- Front Door Latch (Removal and Installation, 501-14 Handles, Locks, Latches and Entry Systems)
- Front Drive Axle and Differential (Description and Operation, 205-03 Front Drive Axle/Differential)
- Front Drive Axle/Differential (Section 205-03)
- Front Drive Axle/Differential (Specifications, 205-03 Front Drive Axle/Differential)
- Front Drive Axle (Diagnosis and Testing, 205-03 Front Drive Axle/Differential)
- Front Drive Halfshafts (Section 205-04)
- Front Drive Halfshafts (Description and Operation, 205-04 Front Drive Halfshafts)
- Front Drive Halfshafts (Diagnosis and Testing, 205-04 Front Drive Halfshafts)
- Front Drive Halfshafts (Specifications, 205-04 Front Drive Halfshafts)
- Front End Accessory Drive (FEAD) — Exploded View (Removal and Installation, 303-05 Accessory Drive)
- Front End Body Panels — Exploded View (Removal and Installation, 501-02 Front End Body Panels)
- Front End Body Panels (Section 501-02)
- Front End Body Panels (Specifications, 501-02 Front End Body Panels)
- Front Fog Lamp Adjustment (General Procedures, 417-01 Exterior Lighting)
- Front Impact Severity Sensor (Removal and Installation, 501-20B Supplemental Restraint System)
- Front Seat Motor Cable (Removal and Installation, 501-10 Seating)
- Front Suspension — Four Wheel Drive (4WD) (Section 204-01B)
- Front Suspension — Four Wheel Drive (4WD) (Specifications, 204-01B Front Suspension — Four Wheel Drive (4WD))
- Front Suspension — Rear Wheel Drive (RWD) (Section 204-01A)
- Front Suspension — Rear Wheel Drive (RWD) (Specifications, 204-01A Front Suspension — Rear Wheel Drive (RWD))
- Front Suspension (Description and Operation, 204-01A Front Suspension — Rear Wheel Drive (RWD))
- Front Suspension (Description and Operation, 204-01B Front Suspension — Four Wheel Drive (4WD))
- Front Suspension (Diagnosis and Testing, 204-01A Front Suspension — Rear Wheel Drive (RWD))
- Front Suspension (Diagnosis and Testing, 204-01B Front Suspension — Four Wheel Drive (4WD))
- Fuel Charging and Controls — 3.5L GTDI (Section 303-04A)
- Fuel Charging and Controls — 3.5L GTDI (Specifications, 303-04A Fuel Charging and Controls — 3.5L GTDI)
- Fuel Charging and Controls — 3.7L (Section 303-04B)
- Fuel Charging and Controls — 3.7L (Specifications, 303-04B Fuel Charging and Controls — 3.7L)
- Fuel Charging and Controls — 5.0L (4V) (Section 303-04C)
- Fuel Charging and Controls — 5.0L (4V) (Specifications, 303-04C Fuel Charging and Controls — 5.0L (4V))
- Fuel Charging and Controls — 6.2L (2V) (Section 303-04D)
- Fuel Charging and Controls — 6.2L (2V) (Specifications, 303-04D Fuel Charging and Controls — 6.2L (2V))
- Fuel Charging and Controls — Turbocharger (Section 303-04E)
- Fuel Charging and Controls — Turbocharger (Specifications, 303-04E Fuel Charging and Controls — Turbocharger)
- Fuel Charging and Controls (Description and Operation, 303-04A Fuel Charging and Controls — 3.5L GTDI)
- Fuel Charging and Controls (Description and Operation, 303-04B Fuel Charging and Controls — 3.7L)

Fuel Charging and Controls (Description and Operation, 303-04C Fuel Charging and Controls — 5.0L (4V))
 Fuel Charging and Controls (Description and Operation, 303-04D Fuel Charging and Controls — 6.2L (2V))
 Fuel Charging and Controls (Diagnosis and Testing, 303-04A Fuel Charging and Controls — 3.5L GTDI)
 Fuel Charging and Controls (Diagnosis and Testing, 303-04B Fuel Charging and Controls — 3.7L)
 Fuel Charging and Controls (Diagnosis and Testing, 303-04C Fuel Charging and Controls — 5.0L (4V))
 Fuel Charging and Controls (Diagnosis and Testing, 303-04D Fuel Charging and Controls — 6.2L (2V))
 Fuel Injection Pump Roller Tappet Inspection (General Procedures, 303-04A Fuel Charging and Controls — 3.5L GTDI)
 Fuel Injection Pump (Removal and Installation, 303-04A Fuel Charging and Controls — 3.5L GTDI)
 Fuel Injector (Removal and Installation, 303-04D Fuel Charging and Controls — 6.2L (2V))
 Fuel Injectors (Removal and Installation, 303-04A Fuel Charging and Controls — 3.5L GTDI)
 Fuel Injectors (Removal and Installation, 303-04B Fuel Charging and Controls — 3.7L)
 Fuel Injectors (Removal and Installation, 303-04C Fuel Charging and Controls — 5.0L (4V))
 Fuel Level Sender (Removal and Installation, 310-01 Fuel Tank and Lines)
 Fuel Lines — Exploded View (Removal and Installation, 310-01 Fuel Tank and Lines)
 Fuel Lines (Removal and Installation, 310-01 Fuel Tank and Lines)
 Fuel Pump Control Module (Removal and Installation, 303-04A Fuel Charging and Controls — 3.5L GTDI)
 Fuel Pump Control Module (Removal and Installation, 303-04B Fuel Charging and Controls — 3.7L)
 Fuel Pump Control Module (Removal and Installation, 303-04C Fuel Charging and Controls — 5.0L (4V))
 Fuel Pump Control Module (Removal and Installation, 303-04D Fuel Charging and Controls — 6.2L (2V))
 Fuel Pump Module — Exploded View (Removal and Installation, 310-01 Fuel Tank and Lines)
 Fuel Pump Module (Removal and Installation, 310-01 Fuel Tank and Lines)
 Fuel Rail and Fuel Injector — Exploded View (Removal and Installation, 303-04A Fuel Charging and Controls — 3.5L GTDI)
 Fuel Rail and Fuel Injector — Exploded View (Removal and Installation, 303-04B Fuel Charging and Controls — 3.7L)
 Fuel Rail and Fuel Injector — Exploded View (Removal and Installation, 303-04C Fuel Charging and Controls — 5.0L (4V))
 Fuel Rail and Fuel Injector — Exploded View (Removal and Installation, 303-04D Fuel Charging and Controls — 6.2L (2V))
 Fuel Rail Pressure (FRP) Sensor — 3.5L GTDI (Removal and Installation, 303-14 Electronic Engine Controls)
 Fuel Rail (Removal and Installation, 303-04A Fuel Charging and Controls — 3.5L GTDI)
 Fuel Rail (Removal and Installation, 303-04B Fuel Charging and Controls — 3.7L)
 Fuel Rail (Removal and Installation, 303-04C Fuel Charging and Controls — 5.0L (4V))
 Fuel Rail (Removal and Installation, 303-04D Fuel Charging and Controls — 6.2L (2V))
 Fuel System — General Information (Section 310-00)
 Fuel System — General Information (Specifications, 310-00 Fuel System — General Information)
 Fuel System Pressure Release (General Procedures, 310-00 Fuel System — General Information)
 Fuel System Pressure Test (General Procedures, 310-00 Fuel System — General Information)
 Fuel System (Description and Operation, 310-00 Fuel System — General Information)
 Fuel System (Diagnosis and Testing, 310-00 Fuel System — General Information)
 Fuel Tank and Filler Pipe — Exploded View (Removal and Installation, 310-01 Fuel Tank and Lines)
 Fuel Tank and Lines (Section 310-01)
 Fuel Tank and Lines (Description and Operation, 310-01 Fuel Tank and Lines)
 Fuel Tank and Lines (Diagnosis and Testing, 310-01 Fuel Tank and Lines)
 Fuel Tank and Lines (Specifications, 310-01 Fuel Tank and Lines)
 Fuel Tank Draining (General Procedures, 310-00 Fuel System — General Information)
 Fuel Tank Filler Pipe (Removal and Installation, 310-01 Fuel Tank and Lines)
 Fuel Tank Pressure Sensor (Removal and Installation, 303-13 Evaporative Emissions)
 Fuel Tank (Removal and Installation, 310-01 Fuel Tank and Lines)
 Full Frame and Body Mounting (Section 502-02)
 Full Frame and Body Mounting (Specifications, 502-02 Full Frame and Body Mounting)
 Gear Ratios (Description and Operation, 307-01 Automatic Transaxle/Transmission — 6R80)
 Generator — 3.5L GTDI (Removal and Installation, 414-00 Charging System)
 Generator — 3.7L (Removal and Installation, 414-00 Charging System)
 Generator — 5.0L (Removal and Installation, 414-00 Charging System)
 Generator — 6.2L (Removal and Installation, 414-00 Charging System)
 Generator Current Sensor (Removal and Installation, 414-01 Battery, Mounting and Cables)
 Glass Reseal — Windshield (General Procedures, 501-11 Glass, Frames and Mechanisms)
 Glass, Frames and Mechanisms — Exploded View, Front Door (Removal and Installation, 501-11 Glass, Frames and

Mechanisms)

Glass, Frames and Mechanisms — Exploded View, Rear Door (Removal and Installation, 501-11 Glass, Frames and Mechanisms)

Glass, Frames and Mechanisms — Exploded View, Rear (Removal and Installation, 501-11 Glass, Frames and Mechanisms)

Glass, Frames and Mechanisms (Section 501-11)

Glass, Frames and Mechanisms (Description and Operation, 501-11 Glass, Frames and Mechanisms)

Glass, Frames and Mechanisms (Diagnosis and Testing, 501-11 Glass, Frames and Mechanisms)

Glass, Frames and Mechanisms (Specifications, 501-11 Glass, Frames and Mechanisms)

Global Positioning System Module (GPSM) (Removal and Installation, 415-00B Information and Entertainment Systems — AM/FM/CD)

Global Positioning System Module (GPSM) (Removal and Installation, 415-00C Information and Entertainment Systems — 4.2-Inch (107 mm) Display)

Global Positioning System Module (GPSM) (Removal and Installation, 415-00D Information and Entertainment Systems — 8-Inch (203 mm) Touchscreen)

Global Positioning System Module (GPSM) (Removal and Installation, 415-00E Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen)

Halfshaft (Disassembly and Assembly, 205-04 Front Drive Halfshafts)

Halfshaft (Removal and Installation, 205-04 Front Drive Halfshafts)

Handles, Locks, Latches and Entry Systems (Section 501-14)

Handles, Locks, Latches and Entry Systems (Description and Operation, 501-14 Handles, Locks, Latches and Entry Systems)

Handles, Locks, Latches and Entry Systems (Diagnosis and Testing, 501-14 Handles, Locks, Latches and Entry Systems)

Handles, Locks, Latches and Entry Systems (Specifications, 501-14 Handles, Locks, Latches and Entry Systems)

Head Restraint Guide Sleeve (Removal and Installation, 501-10 Seating)

Headlamp Adjustment (General Procedures, 417-01 Exterior Lighting)

Headlamp Assembly (Removal and Installation, 417-01 Exterior Lighting)

Headlamp Bulb — Halogen (Removal and Installation, 417-01 Exterior Lighting)

Headlamp Bulb — HID (Removal and Installation, 417-01 Exterior Lighting)

Headlamp Switch (Removal and Installation, 417-01 Exterior Lighting)

Headlamps (Diagnosis and Testing, 417-01 Exterior Lighting)

Headliner — Regular Cab (Removal and Installation, 501-05 Interior Trim and Ornamentation)

Headliner — SuperCab (Removal and Installation, 501-05 Interior Trim and Ornamentation)

Headliner — SuperCrew (Removal and Installation, 501-05 Interior Trim and Ornamentation)

Heated Seat Module — Rear (Removal and Installation, 501-10 Seating)

Heated Seat Switch — Rear (Removal and Installation, 501-10 Seating)

Heater Core And Evaporator Core Housing (Removal and Installation, 412-01 Climate Control)

Heater Core (Removal and Installation, 412-01 Climate Control)

Heating and Ventilation (Description and Operation, 412-01 Climate Control)

Heating Ventilation Air Conditioning (HVAC) Module (Removal and Installation, 412-01 Climate Control)

High Mounted Stoplamp (Removal and Installation, 417-01 Exterior Lighting)

High Voltage Converter/Power Point Inverter (Section 414-05)

High Voltage Converter/Power Point Inverter (Specifications, 414-05 High Voltage Converter/Power Point Inverter)

High-Voltage Converter/Inverter (Description and Operation, 414-05 High Voltage Converter/Power Point Inverter)

High-Voltage Converter/Inverter (Diagnosis and Testing, 414-05 High Voltage Converter/Power Point Inverter)

Hood Alignment (General Procedures, 501-02 Front End Body Panels)

Hood Latch and Components — Exploded View (Removal and Installation, 501-14 Handles, Locks, Latches and Entry Systems)

Hood Latch Release Handle — Primary (Removal and Installation, 501-14 Handles, Locks, Latches and Entry Systems)

Hood Latch Release Handle — Secondary (Removal and Installation, 501-14 Handles, Locks, Latches and Entry Systems)

Hood Latch (Removal and Installation, 501-14 Handles, Locks, Latches and Entry Systems)

Horn (Section 413-06)

Horn (Description and Operation, 413-06 Horn)

Horn (Diagnosis and Testing, 413-06 Horn)

Horn (Removal and Installation, 413-06 Horn)

Horn (Specifications, 413-06 Horn)

Hydraulic Brake Actuation (Section 206-06)

Hydraulic Brake Actuation (Description and Operation, 206-06 Hydraulic Brake Actuation)

Hydraulic Brake Actuation (Specifications, 206-06 Hydraulic Brake Actuation)

Hydraulic Circuits (Description and Operation, 307-01 Automatic Transaxle/Transmission — 6R80)

Hydraulic Control Unit (HCU) (Removal and Installation, 206-09 Anti-Lock Brake System (ABS) and Stability Control)

Hydraulic Lash Adjuster Inspection (General Procedures, 303-00 Engine System — General Information)

Hydraulic Lash Adjuster (In-vehicle Repair, 303-01C Engine — 5.0L (4V))

Hydraulic System (Description and Operation, 307-01 Automatic Transaxle/Transmission — 6R80)

Identification Codes (Section 100-01)

Identification Codes (Description and Operation, 100-01 Identification Codes)

Identification Tags (Description and Operation, 307-01 Automatic Transaxle/Transmission — 6R80)

Ignition Coil-On-Plug (Removal and Installation, 303-07A Engine Ignition — 3.5L GTDI)

Ignition Coil-On-Plug (Removal and Installation, 303-07B Engine Ignition — 3.7L)

Ignition Coil-On-Plug (Removal and Installation, 303-07C Engine Ignition — 5.0L (4V))

Ignition Coil-On-Plug (Removal and Installation, 303-07D Engine Ignition — 6.2L (2V))

Ignition Lock Cylinder — Functional (Removal and Installation, 501-14 Handles, Locks, Latches and Entry Systems)

Ignition Lock Cylinder — Non Functional (Removal and Installation, 501-14 Handles, Locks, Latches and Entry Systems)

Ignition Switch (Removal and Installation, 211-05 Steering Column Switches)

Information and Entertainment System (Description and Operation, 415-00A Information and Entertainment Systems — AM/FM)

Information and Entertainment System (Description and Operation, 415-00B Information and Entertainment Systems — AM/FM/CD)

Information and Entertainment System (Description and Operation, 415-00C Information and Entertainment Systems — 4.2-Inch (107 mm) Display)

Information and Entertainment System (Description and Operation, 415-00D Information and Entertainment Systems — 8-Inch (203 mm) Touchscreen)

Information and Entertainment System (Description and Operation, 415-00E Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen)

Information and Entertainment System (Description and Operation, 415-00F Information and Entertainment Systems — Ford Work Solutions)

Information and Entertainment System (Diagnosis and Testing, 415-00A Information and Entertainment Systems — AM/FM)

Information and Entertainment System (Diagnosis and Testing, 415-00B Information and Entertainment Systems — AM/FM/CD)

Information and Entertainment System (Diagnosis and Testing, 415-00C Information and Entertainment Systems — 4.2-Inch (107 mm) Display)

Information and Entertainment System (Diagnosis and Testing, 415-00D Information and Entertainment Systems — 8-Inch (203 mm) Touchscreen)

Information and Entertainment System (Diagnosis and Testing, 415-00E Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen)

Information and Entertainment System (Diagnosis and Testing, 415-00F Information and Entertainment Systems — Ford Work Solutions)

Information and Entertainment Systems — 4.2-Inch (107 mm) Display (Section 415-00C)

Information and Entertainment Systems — 4.2-Inch (107 mm) Display (Specifications, 415-00C Information and Entertainment Systems — 4.2-Inch (107 mm) Display)

Information and Entertainment Systems — 8-Inch (203 mm) Touchscreen (Section 415-00D)

Information and Entertainment Systems — 8-Inch (203 mm) Touchscreen (Specifications, 415-00D Information and Entertainment Systems — 8-Inch (203 mm) Touchscreen)

Information and Entertainment Systems — AM/FM (Section 415-00A)

Information and Entertainment Systems — AM/FM/CD (Section 415-00B)

Information and Entertainment Systems — AM/FM/CD (Specifications, 415-00B Information and Entertainment Systems — AM/FM/CD)

Information and Entertainment Systems — AM/FM (Specifications, 415-00A Information and Entertainment Systems — AM/FM)

Information and Entertainment Systems — Ford Work Solutions (Section 415-00F)

Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen (Section 415-00E)

Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen (Specifications, 415-00E Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen)

Information And Message Center (Description and Operation, 413-01 Instrumentation, Message Center, and Warning Chimes)

Inner Body Reinforcing Panels (Removal and Installation, 501-35 Body Repairs)

Inner Tie Rod (Removal and Installation, 211-02 Power Steering)

Inspection and Repair After a Supplemental Restraint System (SRS) Deployment (General Procedures, 501-20B Supplemental Restraint System)

Inspection And Verification (Diagnosis and Testing, 206-00 Brake System — General Information)

Inspection And Verification (Diagnosis and Testing, 206-06 Hydraulic Brake Actuation)

Inspection And Verification (Diagnosis and Testing, 414-00 Charging System)

Inspection And Verification (Diagnosis and Testing, 414-01 Battery, Mounting and Cables)

Instrument Cluster and Panel Illumination (Description and Operation, 413-00 Instrument Panel and Interior Switches Illumination)

Instrument Cluster and Panel Illumination (Diagnosis and Testing, 413-00 Instrument Panel and Interior Switches Illumination)

Instrument Cluster Finish Panel (Removal and Installation, 501-12 Instrument Panel and Console)

Instrument Panel — Exploded View (Removal and Installation, 501-12 Instrument Panel and Console)

Instrument Panel and Console (Section 501-12)

Instrument Panel and Console (Specifications, 501-12 Instrument Panel and Console)

Instrument Panel and Interior Switches Illumination (Section 413-00)

Instrument Panel Cluster (IPC) Lens (Removal and Installation, 413-01 Instrumentation, Message Center, and Warning Chimes)

Instrument Panel Cluster (IPC) (Description and Operation, 413-01 Instrumentation, Message Center, and Warning Chimes)

Instrument Panel Cluster (IPC) (Removal and Installation, 413-01 Instrumentation, Message Center, and Warning Chimes)

Instrument Panel Dimmer Switch (Removal and Installation, 413-00 Instrument Panel and Interior Switches Illumination)

Instrument Panel Finish Panel — Center, LH (Removal and Installation, 501-12 Instrument Panel and Console)

Instrument Panel Finish Panel — Center, Lower (Removal and Installation, 501-12 Instrument Panel and Console)

Instrument Panel Finish Panel — Center, RH (Removal and Installation, 501-12 Instrument Panel and Console)

Instrument Panel Finish Panel — Center, Upper (Removal and Installation, 501-12 Instrument Panel and Console)

Instrument Panel Finish Panel — LH (Removal and Installation, 501-12 Instrument Panel and Console)

Instrument Panel Finish Panel — RH (Removal and Installation, 501-12 Instrument Panel and Console)

Instrument Panel (Removal and Installation, 501-12 Instrument Panel and Console)

Instrumentation, Message Center and Warning Chimes (Diagnosis and Testing, 413-01 Instrumentation, Message Center, and Warning Chimes)

Instrumentation, Message Center, and Warning Chimes (Section 413-01)

Insulation (Description and Operation, 501-00 Body System — General Information)

Intake Air Distribution and Filtering (Section 303-12)

Intake Air Distribution and Filtering (Description and Operation, 303-12 Intake Air Distribution and Filtering)

Intake Air Distribution and Filtering (Diagnosis and Testing, 303-12 Intake Air Distribution and Filtering)

Intake Air Distribution and Filtering (Specifications, 303-12 Intake Air Distribution and Filtering)

Intake Air System Components — Exploded View (Removal and Installation, 303-12 Intake Air Distribution and Filtering)

Intake Manifold (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)

Intake Manifold (In-vehicle Repair, 303-01C Engine — 5.0L (4V))

Intake Manifold (In-vehicle Repair, 303-01D Engine — 6.2L (2V))

Integrated Wheel End (IWE) (Removal and Installation, 308-07A Four Wheel Drive (4WD) Systems)

Interior Door Handle — Front (Removal and Installation, 501-14 Handles, Locks, Latches and Entry Systems)

Interior Door Handle — SuperCab (Removal and Installation, 501-14 Handles, Locks, Latches and Entry Systems)

Interior Door Handle — SuperCrew (Removal and Installation, 501-14 Handles, Locks, Latches and Entry Systems)

Interior Lamp (Removal and Installation, 417-02 Interior Lighting)

Interior Lighting (Section 417-02)

Interior Lighting (Description and Operation, 417-02 Interior Lighting)

Interior Lighting (Diagnosis and Testing, 417-02 Interior Lighting)

Interior Rear View Mirror (Removal and Installation, 501-09 Rear View Mirrors)

Interior Trim — Exploded View (Removal and Installation, 501-05 Interior Trim and Ornamentation)

Interior Trim and Ornamentation (Section 501-05)

Interior Trim and Ornamentation (Specifications, 501-05 Interior Trim and Ornamentation)

Intermediate Clutch Assembly (Disassembly and Assembly of Subassemblies, 307-01 Automatic Transaxle/Transmission — 6R80)

In-Vehicle Temperature and Humidity Sensor (Removal and Installation, 412-01 Climate Control)

Jacking and Lifting (Section 100-02)

Jacking and Lifting (Description and Operation, 100-02 Jacking and Lifting)

Key Programming — Enable/Disable Spare Key Programming (General Procedures, 419-01B Anti-Theft — Passive Anti-Theft System (PATS))

Key Programming — Program a Key Using Two Programmed Keys (General Procedures, 419-01B Anti-Theft — Passive Anti-Theft System (PATS))

Key Programming — Unlimited Key Mode (General Procedures, 419-01B Anti-Theft — Passive Anti-Theft System (PATS))

Key Programming Using Diagnostic Equipment (General Procedures, 419-01B Anti-Theft — Passive Anti-Theft System (PATS))

Keyless Entry Keypad Code Programming (General Procedures, 501-14 Handles, Locks, Latches and Entry Systems)

Keyless Entry Keypad (Removal and Installation, 501-14 Handles, Locks, Latches and Entry Systems)

Latch Lubrication (General Procedures, 501-14 Handles, Locks, Latches and Entry Systems)

Lead Terminal Repair (General Procedures, 501-11 Glass, Frames and Mechanisms)

Leaf Spring Tip Isolator (Removal and Installation, 204-02 Rear Suspension)

Leakage Inspection (Diagnosis and Testing, 307-01 Automatic Transaxle/Transmission — 6R80)

Light Sensor (Removal and Installation, 417-01 Exterior Lighting)

Locked Safety Belt Retractor Releasing (General Procedures, 501-20A Safety Belt System)

Low/Reverse Clutch Assembly (Disassembly and Assembly of Subassemblies, 307-01 Automatic Transaxle/Transmission — 6R80)

Lower Arm (Removal and Installation, 204-01A Front Suspension — Rear Wheel Drive (RWD))

Lower Arm (Removal and Installation, 204-01B Front Suspension — Four Wheel Drive (4WD))

Lower Intake Manifold (In-vehicle Repair, 303-01B Engine — 3.7L)

Lumbar Assembly — Manual (Removal and Installation, 501-10 Seating)

Lumbar Assembly — Power (Removal and Installation, 501-10 Seating)

Main Control (Disassembly and Assembly of Subassemblies, 307-01 Automatic Transaxle/Transmission — 6R80)

Main Control (In-vehicle Repair, 307-01 Automatic Transaxle/Transmission — 6R80)

Maintenance Schedule (Section 100-03)

Maintenance Schedules — Gasoline Engines (Description and Operation, 100-03 Maintenance Schedule)

Maintenance Schedules — SVT Raptor (Description and Operation, 100-03 Maintenance Schedule)

Major Components (Description and Operation, 307-01 Automatic Transaxle/Transmission — 6R80)

Manifold Absolute Pressure (MAP) / Intake Air Temperature 2 (IAT2) Sensor — 3.5L GTDI (Removal and Installation, 303-14 Electronic Engine Controls)

Manual Control Lever Shaft and Seal (In-vehicle Repair, 307-01 Automatic Transaxle/Transmission — 6R80)

Mass Air Flow (MAF) Sensor — 3.7L, 5.0L (4V), 6.2L (2V) (Removal and Installation, 303-14 Electronic Engine Controls)

Mechanical Components and Functions (Description and Operation, 307-01 Automatic Transaxle/Transmission — 6R80)

Media Hub (Removal and Installation, 415-00D Information and Entertainment Systems — 8-Inch (203 mm) Touchscreen)

Media Hub (Removal and Installation, 415-00E Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen)

Memory Position Programming (General Procedures, 501-10 Seating)

Memory Set Switch (Removal and Installation, 501-10 Seating)

Message Center Configuration (General Procedures, 413-01 Instrumentation, Message Center, and Warning Chimes)

Microphone (Removal and Installation, 415-00B Information and Entertainment Systems — AM/FM/CD)

Microphone (Removal and Installation, 415-00C Information and Entertainment Systems — 4.2-Inch (107 mm) Display)

Microphone (Removal and Installation, 415-00D Information and Entertainment Systems — 8-Inch (203 mm) Touchscreen)

Microphone (Removal and Installation, 415-00E Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen)

Mode Door Actuator — Air Inlet Door (Removal and Installation, 412-01 Climate Control)

Mode Door Actuator — Defrost/Panel/Floor Door (Removal and Installation, 412-01 Climate Control)

Mode Select Switch (MSS) (Removal and Installation, 308-07A Four Wheel Drive (4WD) Systems)

Modem — Antenna (Removal and Installation, 415-00F Information and Entertainment Systems — Ford Work Solutions)

Module Communications Network (Section 418-00)

Module Configuration (Section 418-01)

Module Configuration (Diagnosis and Testing, 418-01 Module Configuration)

Module Controlled Functions (Description and Operation, 419-10 Multifunction Electronic Modules)

Muffler and Tailpipe (Removal and Installation, 309-00 Exhaust System)

Multifunction Electronic Modules (Section 419-10)

Multifunction Electronic Modules (Specifications, 419-10 Multifunction Electronic Modules)

MyKey® Programming (General Procedures, 419-01B Anti-Theft — Passive Anti-Theft System (PATS))

MyKey® Restrictions on Vehicle Operation (Diagnosis and Testing, 419-01B Anti-Theft — Passive Anti-Theft System)

(PATSS))

Neutral Flat Tow Activation and Deactivation (General Procedures, 308-07A Four Wheel Drive (4WD) Systems)

Noise, Vibration and Harshness (NVH) (Description and Operation, 100-04 Noise, Vibration and Harshness)

Noise, Vibration and Harshness (NVH) (Diagnosis and Testing, 100-04 Noise, Vibration and Harshness)

Noise, Vibration and Harshness (Section 100-04)

Occupant Classification Sensor (OCS) System Reset (General Procedures, 501-20B Supplemental Restraint System)

Occupant Classification Sensor (OCS) System Zero Seat Weight Test (General Procedures, 501-20B Supplemental Restraint System)

Occupant Classification Sensor (Removal and Installation, 501-20B Supplemental Restraint System)

Occupant Classification System Module (OCSM) (Removal and Installation, 501-20B Supplemental Restraint System)

Oil Cooler (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)

Oil Cooler (In-vehicle Repair, 303-01B Engine — 3.7L)

Oil Cooler (In-vehicle Repair, 303-01C Engine — 5.0L (4V))

Oil Cooler (In-vehicle Repair, 303-01D Engine — 6.2L (2V))

Oil Filter Adapter (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)

Oil Filter Adapter (In-vehicle Repair, 303-01B Engine — 3.7L)

Oil Filter Adapter (In-vehicle Repair, 303-01C Engine — 5.0L (4V))

Oil Filter Adapter (In-vehicle Repair, 303-01D Engine — 6.2L (2V))

Oil Level Indicator and Tube (In-vehicle Repair, 303-01C Engine — 5.0L (4V))

Oil Level Indicator and Tube (In-vehicle Repair, 303-01D Engine — 6.2L (2V))

Oil Pan (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)

Oil Pan (In-vehicle Repair, 303-01B Engine — 3.7L)

Oil Pan (In-vehicle Repair, 303-01C Engine — 5.0L (4V))

Oil Pan (In-vehicle Repair, 303-01D Engine — 6.2L (2V))

Oil Pump Screen and Pickup Tube (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)

Oil Pump Screen and Pickup Tube (In-vehicle Repair, 303-01B Engine — 3.7L)

Oil Pump Screen and Pickup Tube (In-vehicle Repair, 303-01C Engine — 5.0L (4V))

Oil Pump Screen and Pickup Tube (In-vehicle Repair, 303-01D Engine — 6.2L (2V))

Oil Pump (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)

Oil Pump (In-vehicle Repair, 303-01B Engine — 3.7L)

Oil Pump (In-vehicle Repair, 303-01C Engine — 5.0L (4V))

Oil Pump (In-vehicle Repair, 303-01D Engine — 6.2L (2V))

Output Shaft Seal (In-vehicle Repair, 307-01 Automatic Transaxle/Transmission — 6R80)

Output State Control (OSC) Mode (Diagnosis and Testing, 307-01 Automatic Transaxle/Transmission — 6R80)

Overdrive Clutch Assembly (Disassembly and Assembly of Subassemblies, 307-01 Automatic Transaxle/Transmission — 6R80)

Parking Aid — Video (Diagnosis and Testing, 413-13 Parking Aid)

Parking Aid (Section 413-13)

Parking Aid Module (PAM) (Removal and Installation, 413-13 Parking Aid)

Parking Aid Sensor (Removal and Installation, 413-13 Parking Aid)

Parking Aid (Description and Operation, 413-13 Parking Aid)

Parking Aid (Diagnosis and Testing, 413-13 Parking Aid)

Parking Aid (Specifications, 413-13 Parking Aid)

Parking Brake and Actuation (Section 206-05)

Parking Brake and Actuation (Specifications, 206-05 Parking Brake and Actuation)

Parking Brake Cable — Front (Removal and Installation, 206-05 Parking Brake and Actuation)

Parking Brake Cable — Rear, LH (Removal and Installation, 206-05 Parking Brake and Actuation)

Parking Brake Cable — Rear, RH (Removal and Installation, 206-05 Parking Brake and Actuation)

Parking Brake Cable Tension Release (General Procedures, 206-05 Parking Brake and Actuation)

Parking Brake Control (Removal and Installation, 206-05 Parking Brake and Actuation)

Parking Brake Shoe Adjustment (General Procedures, 206-05 Parking Brake and Actuation)

Parking Brake Shoes (Removal and Installation, 206-05 Parking Brake and Actuation)

Parking Brake Warning Indicator Switch (Removal and Installation, 206-05 Parking Brake and Actuation)

Parking Brake (Description and Operation, 206-05 Parking Brake and Actuation)

Parking Brake (Diagnosis and Testing, 206-05 Parking Brake and Actuation)

Parking, Rear and License Plate Lamps (Diagnosis and Testing, 417-01 Exterior Lighting)

Passenger Airbag Deactivation (PAD) Indicator (Removal and Installation, 501-20B Supplemental Restraint System)

Passenger Airbag (Removal and Installation, 501-20B Supplemental Restraint System)

Passive Anti-Theft System (PATS) Parameter Reset (General Procedures, 419-01B Anti-Theft — Passive Anti-Theft System (PATS))

Passive Anti-Theft System (PATS) Transceiver (Removal and Installation, 419-01B Anti-Theft — Passive Anti-Theft System (PATS))

Pickup Bed and Platform Body (Section 501-04)

Pickup Bed and Platform Body (Specifications, 501-04 Pickup Bed and Platform Body)

Pickup Bed Side Panel — Styleside (Removal and Installation, 501-35 Body Repairs)

Pickup Bed Side Step Latch (Removal and Installation, 501-14 Handles, Locks, Latches and Entry Systems)

Pickup Bed Side Step (Removal and Installation, 501-08 Exterior Trim and Ornamentation)

Pickup Bed (Description and Operation, 501-04 Pickup Bed and Platform Body)

Pickup Bed (Removal and Installation, 501-04 Pickup Bed and Platform Body)

Pinpoint Test (Diagnosis and Testing, 414-00 Charging System)

Pinpoint Test (Diagnosis and Testing, 414-01 Battery, Mounting and Cables)

Pinpoint Tests — OSC Equipped Vehicle (Diagnosis and Testing, 307-01 Automatic Transaxle/Transmission — 6R80)

Pinpoint Tests (Diagnosis and Testing, 206-00 Brake System — General Information)

Pinpoint Tests (Diagnosis and Testing, 206-06 Hydraulic Brake Actuation)

Piston Diameter (General Procedures, 303-00 Engine System — General Information)

Piston Inspection (General Procedures, 303-00 Engine System — General Information)

Piston Pin Bore Diameter (General Procedures, 303-00 Engine System — General Information)

Piston Pin Diameter (General Procedures, 303-00 Engine System — General Information)

Piston Ring End Gap (General Procedures, 303-00 Engine System — General Information)

Piston Ring-to-Groove Clearance (General Procedures, 303-00 Engine System — General Information)

Piston Selection (General Procedures, 303-00 Engine System — General Information)

Piston To Cylinder Bore Clearance (General Procedures, 303-00 Engine System — General Information)

Piston (Disassembly and Assembly of Subassemblies, 303-01A Engine — 3.5L GTDI)

Piston (Disassembly and Assembly of Subassemblies, 303-01B Engine — 3.7L)

Piston (Disassembly and Assembly of Subassemblies, 303-01C Engine — 5.0L (4V))

Piston (Disassembly and Assembly of Subassemblies, 303-01D Engine — 6.2L (2V))

Plastic Components (Description and Operation, 501-35 Body Repairs)

Plastics Identification (General Procedures, 501-35 Body Repairs)

Plastics Refinishing (General Procedures, 501-35 Body Repairs)

Plastics Repair (General Procedures, 501-35 Body Repairs)

Plenum Chamber (Removal and Installation, 412-01 Climate Control)

Positive Crankcase Ventilation (PCV) Valve (Removal and Installation, 303-08 Engine Emission Control)

Power Brake Actuation (Section 206-07)

Power Brake Actuation (Specifications, 206-07 Power Brake Actuation)

Power Brake System (Diagnosis and Testing, 206-07 Power Brake Actuation)

Power Point (Removal and Installation, 501-12 Instrument Panel and Console)

Power Running Board (PRB) Module (Removal and Installation, 501-08 Exterior Trim and Ornamentation)

Power Running Board (PRB) Motor (Removal and Installation, 501-08 Exterior Trim and Ornamentation)

Power Running Board (PRB) Step (Removal and Installation, 501-08 Exterior Trim and Ornamentation)

Power Running Board (PRB) (Diagnosis and Testing, 501-08 Exterior Trim and Ornamentation)

Power Running Board (PRB) (Removal and Installation, 501-08 Exterior Trim and Ornamentation)

Power Steering (Section 211-02)

Power Steering Fluid Cooler (Removal and Installation, 211-02 Power Steering)

Power Steering Fluid Reservoir (Removal and Installation, 211-02 Power Steering)

Power Steering Pump to Steering Gear Pressure Line (Removal and Installation, 211-02 Power Steering)

Power Steering Pump (Removal and Installation, 211-02 Power Steering)

Power Steering System Filling (General Procedures, 211-00B Steering System — Hydraulic Power Assist Steering (HPAS))

Power Steering System Flushing (General Procedures, 211-00B Steering System — Hydraulic Power Assist Steering (HPAS))

Power Steering System Purging (General Procedures, 211-00B Steering System — Hydraulic Power Assist Steering (HPAS))

Power Steering (Description and Operation, 211-02 Power Steering)

Power Steering (Diagnosis and Testing, 211-02 Power Steering)

Power Steering (Specifications, 211-02 Power Steering)

Powertrain Control Module (PCM) (Removal and Installation, 303-14 Electronic Engine Controls)

Powertrain/Drivetrain Mount Neutralizing (General Procedures, 303-00 Engine System — General Information)

Preliminary Inspection (Diagnosis and Testing, 307-01 Automatic Transaxle/Transmission — 6R80)
Principles of Operation (Diagnosis and Testing, 206-00 Brake System — General Information)
Principles of Operation (Diagnosis and Testing, 206-06 Hydraulic Brake Actuation)
Principles of Operation (Diagnosis and Testing, 414-00 Charging System)
Principles of Operation (Diagnosis and Testing, 414-01 Battery, Mounting and Cables)
Programmable Module Installation (PMI) (General Procedures, 418-01 Module Configuration)
Puddle Lamp (Removal and Installation, 417-01 Exterior Lighting)
Pump Assembly (Disassembly and Assembly of Subassemblies, 307-01 Automatic Transaxle/Transmission — 6R80)
Pyrotechnic Device Disposal (General Procedures, 501-20B Supplemental Restraint System)
Quick Connect Coupling (General Procedures, 310-00 Fuel System — General Information)
Radiator Grille Support (Removal and Installation, 501-02 Front End Body Panels)
Radiator Hose (Removal and Installation, 303-03 Engine Cooling)
Radiator (Removal and Installation, 303-03 Engine Cooling)
Rain Sensor Bracket (Removal and Installation, 501-16 Wipers and Washers)
Rain Sensor (Removal and Installation, 501-16 Wipers and Washers)
Range Selection (Description and Operation, 307-01 Automatic Transaxle/Transmission — 6R80)
Rear Disc Brake (Section 206-04)
Rear Disc Brake (Description and Operation, 206-04 Rear Disc Brake)
Rear Disc Brake (Diagnosis and Testing, 206-04 Rear Disc Brake)
Rear Disc Brake (Specifications, 206-04 Rear Disc Brake)
Rear Door Handles, Locks and Latches — Exploded View, Super Crew (Removal and Installation, 501-14 Handles, Locks, Latches and Entry Systems)
Rear Door Handles, Locks and Latches — Exploded View, SuperCab (Removal and Installation, 501-14 Handles, Locks, Latches and Entry Systems)
Rear Door Latch — Lower, SuperCab (Removal and Installation, 501-14 Handles, Locks, Latches and Entry Systems)
Rear Door Latch — SuperCrew (Removal and Installation, 501-14 Handles, Locks, Latches and Entry Systems)
Rear Door Latch — Upper, SuperCab (Removal and Installation, 501-14 Handles, Locks, Latches and Entry Systems)
Rear Drive Axle and Differential (Description and Operation, 205-02A Rear Drive Axle/Differential — Ford 8.8-Inch Ring Gear)
Rear Drive Axle and Differential (Description and Operation, 205-02B Rear Drive Axle/Differential — Ford 9.75-Inch Ring Gear)
Rear Drive Axle and Differential (Diagnosis and Testing, 205-02A Rear Drive Axle/Differential — Ford 8.8-Inch Ring Gear)
Rear Drive Axle and Differential (Diagnosis and Testing, 205-02B Rear Drive Axle/Differential — Ford 9.75-Inch Ring Gear)
Rear Drive Axle/Differential — Ford 8.8-Inch Ring Gear (Section 205-02A)
Rear Drive Axle/Differential — Ford 8.8-Inch Ring Gear (Specifications, 205-02A Rear Drive Axle/Differential — Ford 8.8-Inch Ring Gear)
Rear Drive Axle/Differential — Ford 9.75-Inch Ring Gear (Section 205-02B)
Rear Drive Axle/Differential — Ford 9.75-Inch Ring Gear (Specifications, 205-02B Rear Drive Axle/Differential — Ford 9.75-Inch Ring Gear)
Rear Lamp Assembly (Removal and Installation, 417-01 Exterior Lighting)
Rear Suspension (Section 204-02)
Rear Suspension (Description and Operation, 204-02 Rear Suspension)
Rear Suspension (Diagnosis and Testing, 204-02 Rear Suspension)
Rear Suspension (Specifications, 204-02 Rear Suspension)
Rear View Mirrors — Exterior (Diagnosis and Testing, 501-09 Rear View Mirrors)
Rear View Mirrors — Interior (Diagnosis and Testing, 501-09 Rear View Mirrors)
Rear View Mirrors (Section 501-09)
Rear View Mirrors (Description and Operation, 501-09 Rear View Mirrors)
Rear View Mirrors (Specifications, 501-09 Rear View Mirrors)
Rear Wheel Bearing and Axle Shaft Seal (In-vehicle Repair, 205-02A Rear Drive Axle/Differential — Ford 8.8-Inch Ring Gear)
Rear Wheel Bearing and Axle Shaft Seal (In-vehicle Repair, 205-02B Rear Drive Axle/Differential — Ford 9.75-Inch Ring Gear)
Receiver Drier Cartridge (Removal and Installation, 412-01 Climate Control)
Refinishing — Environmental Damage (General Procedures, 501-35 Body Repairs)
Refinishing — Manufacturing Damage (General Procedures, 501-35 Body Repairs)

- Refrigerant Identification Testing (General Procedures, 412-00 Climate Control System — General Information and Diagnostics)
- Refrigerant Oil Adding (General Procedures, 412-00 Climate Control System — General Information and Diagnostics)
- Refrigerant System Tests (General Procedures, 412-00 Climate Control System — General Information and Diagnostics)
- Register (Removal and Installation, 412-01 Climate Control)
- Remote Convenience (Section 419-02)
- Remote Keyless Entry (RKE) Transmitter Programming (General Procedures, 501-14 Handles, Locks, Latches and Entry Systems)
- Remote Memory Activation (General Procedures, 501-14 Handles, Locks, Latches and Entry Systems)
- Remote Memory Deactivation (General Procedures, 501-14 Handles, Locks, Latches and Entry Systems)
- Restoring Corrosion Protection Following Repair (General Procedures, 501-35 Body Repairs)
- Restraints Control Module (RCM) (Removal and Installation, 501-20B Supplemental Restraint System)
- Reversing Lamps (Diagnosis and Testing, 417-01 Exterior Lighting)
- Ride Height Measurement (General Procedures, 204-00 Suspension System — General Information)
- Ring Gear Backlash Adjustment (General Procedures, 205-02A Rear Drive Axle/Differential — Ford 8.8-Inch Ring Gear)
- Ring Gear Backlash Adjustment (General Procedures, 205-02B Rear Drive Axle/Differential — Ford 9.75-Inch Ring Gear)
- Rocker Arm (In-vehicle Repair, 303-01D Engine — 6.2L (2V))
- Roller Follower Inspection (General Procedures, 303-00 Engine System — General Information)
- Roof Opening Panel — Exploded View (Removal and Installation, 501-17 Roof Opening Panel)
- Roof Opening Panel (Section 501-17)
- Roof Opening Panel Alignment (General Procedures, 501-17 Roof Opening Panel)
- Roof Opening Panel Control Switch (Removal and Installation, 501-17 Roof Opening Panel)
- Roof Opening Panel Frame (Removal and Installation, 501-17 Roof Opening Panel)
- Roof Opening Panel Glass (Removal and Installation, 501-17 Roof Opening Panel)
- Roof Opening Panel Motor Initialization (General Procedures, 501-17 Roof Opening Panel)
- Roof Opening Panel Motor (Removal and Installation, 501-17 Roof Opening Panel)
- Roof Opening Panel Rear Trough Guide (Removal and Installation, 501-17 Roof Opening Panel)
- Roof Opening Panel Shield (Removal and Installation, 501-17 Roof Opening Panel)
- Roof Opening Panel (Description and Operation, 501-17 Roof Opening Panel)
- Roof Opening Panel (Diagnosis and Testing, 501-17 Roof Opening Panel)
- Roof Opening Panel (Specifications, 501-17 Roof Opening Panel)
- Roof Panel (Removal and Installation, 501-35 Body Repairs)
- RTV Sealing Surface Cleaning and Preparation (General Procedures, 303-00 Engine System — General Information)
- Safety Belt Buckle — Front, Center (Removal and Installation, 501-20A Safety Belt System)
- Safety Belt Buckle — Front (Removal and Installation, 501-20A Safety Belt System)
- Safety Belt Buckle — Rear (Removal and Installation, 501-20A Safety Belt System)
- Safety Belt Cleaning (General Procedures, 501-20A Safety Belt System)
- Safety Belt Inspection and Repair After a Collision (General Procedures, 501-20A Safety Belt System)
- Safety Belt Maintenance (General Procedures, 501-20A Safety Belt System)
- Safety Belt Retractor — Front, Center (Removal and Installation, 501-20A Safety Belt System)
- Safety Belt Retractor — Rear, Center (Removal and Installation, 501-20A Safety Belt System)
- Safety Belt Retractor — Rear (Removal and Installation, 501-20A Safety Belt System)
- Safety Belt Retractor and Pretensioner — Regular Cab and Crew Cab (Removal and Installation, 501-20A Safety Belt System)
- Safety Belt Retractor and Pretensioner — SuperCab (Removal and Installation, 501-20A Safety Belt System)
- Safety Belt Shoulder Height Adjuster — Regular Cab and Crew Cab (Removal and Installation, 501-20A Safety Belt System)
- Safety Belt Shoulder Height Adjuster — SuperCab (Removal and Installation, 501-20A Safety Belt System)
- Safety Belt System (Section 501-20A)
- Safety Belt System (Description and Operation, 501-20A Safety Belt System)
- Safety Belt System (Diagnosis and Testing, 501-20A Safety Belt System)
- Safety Belt System (Specifications, 501-20A Safety Belt System)
- Safety Belt Tongue Rotated on Belt (General Procedures, 501-20A Safety Belt System)
- Safety Belt Twisted at the Safety Belt Guide (General Procedures, 501-20A Safety Belt System)
- Safety Canopy Module (Removal and Installation, 501-20B Supplemental Restraint System)
- Safety Warnings (Description and Operation, 100-00 Service Information)
- Satellite Radio Electronic Serial Number (ESN) Retrieval (General Procedures, 415-00B Information and Entertainment Systems — AM/FM/CD)

Sealers (Description and Operation, 501-35 Body Repairs)

Seat — Exploded View, Front, Center (Removal and Installation, 501-10 Seating)

Seat — Exploded View, Front (Removal and Installation, 501-10 Seating)

Seat — Exploded View, Rear, Crew Cab (Removal and Installation, 501-10 Seating)

Seat — Exploded View, Rear, SuperCab (Removal and Installation, 501-10 Seating)

Seat — Front, Center (Removal and Installation, 501-10 Seating)

Seat — Front (Removal and Installation, 501-10 Seating)

Seat — Rear, Crew Cab, 40 Percent (Removal and Installation, 501-10 Seating)

Seat — Rear, Crew Cab, 60 Percent (Removal and Installation, 501-10 Seating)

Seat — Rear, SuperCab (Removal and Installation, 501-10 Seating)

Seat Armrest — Rear, Crew Cab (Disassembly and Assembly, 501-10 Seating)

Seat Armrest — Rear, Crew Cab (Removal and Installation, 501-10 Seating)

Seat Backrest — Front, Center (Removal and Installation, 501-10 Seating)

Seat Backrest — Front (Disassembly and Assembly, 501-10 Seating)

Seat Backrest — Front (Removal and Installation, 501-10 Seating)

Seat Backrest — Rear, Crew Cab (Disassembly and Assembly, 501-10 Seating)

Seat Backrest — Rear, Crew Cab (Removal and Installation, 501-10 Seating)

Seat Backrest — Rear, SuperCab (Disassembly and Assembly, 501-10 Seating)

Seat Backrest Cover — Front, Center (Removal and Installation, 501-10 Seating)

Seat Backrest Cover — Front (Removal and Installation, 501-10 Seating)

Seat Backrest Cover — Rear, Crew Cab (Removal and Installation, 501-10 Seating)

Seat Backrest Cover — Rear, SuperCab (Removal and Installation, 501-10 Seating)

Seat Backrest Heater Mat — Front (Removal and Installation, 501-10 Seating)

Seat Backrest Heater Mat — Rear (Removal and Installation, 501-10 Seating)

Seat Backrest Latch — Rear, Crew Cab (Removal and Installation, 501-10 Seating)

Seat Backrest Thermo-Electric Device (Removal and Installation, 501-10 Seating)

Seat Control Switch (Removal and Installation, 501-10 Seating)

Seat Cushion — Front (Disassembly and Assembly, 501-10 Seating)

Seat Cushion — Rear, CrewCab (Disassembly and Assembly, 501-10 Seating)

Seat Cushion — Rear, SuperCab (Disassembly and Assembly, 501-10 Seating)

Seat Cushion Cover — Front, Center (Removal and Installation, 501-10 Seating)

Seat Cushion Cover — Front (Removal and Installation, 501-10 Seating)

Seat Cushion Cover — Rear, Crew Cab (Removal and Installation, 501-10 Seating)

Seat Cushion Cover — Rear, SuperCab (Removal and Installation, 501-10 Seating)

Seat Cushion Heater Mat — Front (Removal and Installation, 501-10 Seating)

Seat Cushion Heater Mat — Rear (Removal and Installation, 501-10 Seating)

Seat Cushion Thermo-Electric Device (Removal and Installation, 501-10 Seating)

Seat Latch — Front, Center (Removal and Installation, 501-10 Seating)

Seat Latch — Rear, Crew Cab (Removal and Installation, 501-10 Seating)

Seat Latch — Rear, SuperCab (Removal and Installation, 501-10 Seating)

Seat Latch Striker — Rear, Crew Cab (Removal and Installation, 501-10 Seating)

Seat Position Sensor (Removal and Installation, 501-20B Supplemental Restraint System)

Seat Recliner Motor (Removal and Installation, 501-10 Seating)

Seat Track Motor — Front (Removal and Installation, 501-10 Seating)

Seat Track (Removal and Installation, 501-10 Seating)

Seat Wire Harness Routing (General Procedures, 501-10 Seating)

Seating (Section 501-10)

Seating (Description and Operation, 501-10 Seating)

Seating (Diagnosis and Testing, 501-10 Seating)

Seating (Specifications, 501-10 Seating)

Sectioning Guidelines (General Procedures, 501-35 Body Repairs)

Selector Lever — Column Shift (Removal and Installation, 307-05 Automatic Transaxle/Transmission External Controls)

Selector Lever — Floor Shift (Removal and Installation, 307-05 Automatic Transaxle/Transmission External Controls)

Selector Lever Bezel (Removal and Installation, 307-05 Automatic Transaxle/Transmission External Controls)

Selector Lever Button (Removal and Installation, 307-05 Automatic Transaxle/Transmission External Controls)

Selector Lever Cable — Column Shift (Removal and Installation, 307-05 Automatic Transaxle/Transmission External Controls)

Selector Lever Cable — Floor Shift (Removal and Installation, 307-05 Automatic Transaxle/Transmission External

Controls)

Selector Lever Cable Adjustment — Column Shift (General Procedures, 307-05 Automatic Transaxle/Transmission External Controls)

Selector Lever Cable Adjustment — Floor Shift (General Procedures, 307-05 Automatic Transaxle/Transmission External Controls)

Selector Lever Knob (Removal and Installation, 307-05 Automatic Transaxle/Transmission External Controls)

Selector Lever Mechanism — Column Shift (Removal and Installation, 307-05 Automatic Transaxle/Transmission External Controls)

SelectShift™ Switch — Column Shift (Removal and Installation, 307-05 Automatic Transaxle/Transmission External Controls)

SelectShift™ Switch — Floor Shift (Removal and Installation, 307-05 Automatic Transaxle/Transmission External Controls)

Service Information (Section 100-00)

Shift Patterns (Description and Operation, 307-01 Automatic Transaxle/Transmission — 6R80)

Shift Point Road Test (Diagnosis and Testing, 307-01 Automatic Transaxle/Transmission — 6R80)

Shift Solenoids (SS) (In-vehicle Repair, 307-01 Automatic Transaxle/Transmission — 6R80)

Shock Absorber and Spring Assembly (Disassembly and Assembly, 204-01B Front Suspension — Four Wheel Drive (4WD))

Shock Absorber and Spring Assembly (Removal and Installation, 204-01A Front Suspension — Rear Wheel Drive (RWD))

Shock Absorber and Spring Assembly (Removal and Installation, 204-01B Front Suspension — Four Wheel Drive (4WD))

Shock Absorber (Removal and Installation, 204-02 Rear Suspension)

Side Airbag (Removal and Installation, 501-20B Supplemental Restraint System)

Side Impact Sensor — Front Door (Removal and Installation, 501-20B Supplemental Restraint System)

Side Impact Sensor — Second Row (Removal and Installation, 501-20B Supplemental Restraint System)

Side Lamp Assembly — Outside Rear View Mirror, Aero (Removal and Installation, 417-01 Exterior Lighting)

Side Lamp Assembly — Outside Rear View Mirror, Trailer Tow (Removal and Installation, 417-01 Exterior Lighting)

Side Lamp/Front Turn Signal Lamp Bulb (Removal and Installation, 417-01 Exterior Lighting)

Side Marker Lamp — Front (Removal and Installation, 417-01 Exterior Lighting)

Side Marker Lamp — Rear (Removal and Installation, 417-01 Exterior Lighting)

Solenoid Body Strategy (Diagnosis and Testing, 307-01 Automatic Transaxle/Transmission — 6R80)

Sound Deadeners and Insulators (Description and Operation, 501-35 Body Repairs)

Spark Plug Inspection (General Procedures, 303-00 Engine System — General Information)

Spark Plugs (Removal and Installation, 303-07A Engine Ignition — 3.5L GTDI)

Spark Plugs (Removal and Installation, 303-07B Engine Ignition — 3.7L)

Spark Plugs (Removal and Installation, 303-07C Engine Ignition — 5.0L (4V))

Spark Plugs (Removal and Installation, 303-07D Engine Ignition — 6.2L (2V))

Speaker — A-Pillar (Removal and Installation, 415-00B Information and Entertainment Systems — AM/FM/CD)

Speaker — A-Pillar (Removal and Installation, 415-00C Information and Entertainment Systems — 4.2-Inch (107 mm) Display)

Speaker — A-Pillar (Removal and Installation, 415-00D Information and Entertainment Systems — 8-Inch (203 mm) Touchscreen)

Speaker — A-Pillar (Removal and Installation, 415-00E Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen)

Speaker — Door (Removal and Installation, 415-00A Information and Entertainment Systems — AM/FM)

Speaker — Door (Removal and Installation, 415-00B Information and Entertainment Systems — AM/FM/CD)

Speaker — Door (Removal and Installation, 415-00C Information and Entertainment Systems — 4.2-Inch (107 mm) Display)

Speaker — Door (Removal and Installation, 415-00D Information and Entertainment Systems — 8-Inch (203 mm) Touchscreen)

Speaker — Door (Removal and Installation, 415-00E Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen)

Speaker — Instrument Panel (Removal and Installation, 415-00E Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen)

Speaker Audio Test (General Procedures, 415-00B Information and Entertainment Systems — AM/FM/CD)

Speaker Audio Test (General Procedures, 415-00C Information and Entertainment Systems — 4.2-Inch (107 mm) Display)

Speaker Audio Test (General Procedures, 415-00D Information and Entertainment Systems — 8-Inch (203 mm) Touchscreen)

Speaker Audio Test (General Procedures, 415-00E Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen)

- Touchscreen)
- Speaker Enclosure (Removal and Installation, 415-00E Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen)
- Special Testing Procedures (Diagnosis and Testing, 307-01 Automatic Transaxle/Transmission — 6R80)
- Spring (Removal and Installation, 204-02 Rear Suspension)
- Sprockets (General Procedures, 303-00 Engine System — General Information)
- Stability/Traction Control Switch (Removal and Installation, 206-09 Anti-Lock Brake System (ABS) and Stability Control)
- Stabilizer Bar and Link (Removal and Installation, 204-01A Front Suspension — Rear Wheel Drive (RWD))
- Stabilizer Bar and Link (Removal and Installation, 204-01B Front Suspension — Four Wheel Drive (4WD))
- Starter Motor — 3.5L GTDI, 3.7L (Removal and Installation, 303-06 Starting System)
- Starter Motor — 5.0L (4V), 6.2L (2V) (Removal and Installation, 303-06 Starting System)
- Starter Motor Drive Gear and Flywheel Ring Gear Inspection (General Procedures, 303-06 Starting System)
- Starting System (Section 303-06)
- Starting System (Description and Operation, 303-06 Starting System)
- Starting System (Diagnosis and Testing, 303-06 Starting System)
- Starting System (Specifications, 303-06 Starting System)
- Steering Column (Section 211-04)
- Steering Column Control Module (SCCM) (Removal and Installation, 211-05 Steering Column Switches)
- Steering Column Control Switch (Removal and Installation, 211-05 Steering Column Switches)
- Steering Column Motor — Telescopic (Removal and Installation, 211-04 Steering Column)
- Steering Column Motor — Tilt (Removal and Installation, 211-04 Steering Column)
- Steering Column Multifunction Switch (Removal and Installation, 211-05 Steering Column Switches)
- Steering Column Shaft (Removal and Installation, 211-04 Steering Column)
- Steering Column Shroud — Floor Shift (Removal and Installation, 211-04 Steering Column)
- Steering Column Shroud (Removal and Installation, 211-04 Steering Column)
- Steering Column Switches (Section 211-05)
- Steering Column Switches (Description and Operation, 211-05 Steering Column Switches)
- Steering Column Switches (Diagnosis and Testing, 211-05 Steering Column Switches)
- Steering Column Switches (Specifications, 211-05 Steering Column Switches)
- Steering Column (Description and Operation, 211-04 Steering Column)
- Steering Column (Diagnosis and Testing, 211-04 Steering Column)
- Steering Column (Removal and Installation, 211-04 Steering Column)
- Steering Column (Specifications, 211-04 Steering Column)
- Steering Gear — Electronic Power Assist Steering (EPAS) (Removal and Installation, 211-02 Power Steering)
- Steering Gear — Hydraulic Power Assist Steering (HPAS) (Removal and Installation, 211-02 Power Steering)
- Steering Gear to Fluid Cooler Return Hose — From Gear (Removal and Installation, 211-02 Power Steering)
- Steering Gear to Fluid Cooler Return Hose — To Cooler (Removal and Installation, 211-02 Power Steering)
- Steering Gear Turn Tubes (Removal and Installation, 211-02 Power Steering)
- Steering System — Electronic Power Assist Steering (EPAS) (Section 211-00A)
- Steering System — Hydraulic Power Assist Steering (HPAS) (Section 211-00B)
- Steering System — Hydraulic Power Assist Steering (HPAS) (Specifications, 211-00B Steering System — Hydraulic Power Assist Steering (HPAS))
- Steering System (Description and Operation, 211-00A Steering System — Electronic Power Assist Steering (EPAS))
- Steering System (Description and Operation, 211-00B Steering System — Hydraulic Power Assist Steering (HPAS))
- Steering System (Diagnosis and Testing, 211-00A Steering System — Electronic Power Assist Steering (EPAS))
- Steering System (Diagnosis and Testing, 211-00B Steering System — Hydraulic Power Assist Steering (HPAS))
- Steering Wheel Rotation Sensor (Removal and Installation, 206-09 Anti-Lock Brake System (ABS) and Stability Control)
- Steering Wheel Switch (Removal and Installation, 211-05 Steering Column Switches)
- Steering Wheel Wrap Bonding (General Procedures, 211-04 Steering Column)
- Steering Wheel (Removal and Installation, 211-04 Steering Column)
- Stepped Unlock Programming (General Procedures, 501-14 Handles, Locks, Latches and Entry Systems)
- Stoplamp Switch (Removal and Installation, 417-01 Exterior Lighting)
- Stoplamps (Diagnosis and Testing, 417-01 Exterior Lighting)
- Storage Compartment — Lower (Removal and Installation, 501-12 Instrument Panel and Console)
- Storage Compartment — Upper (Removal and Installation, 501-12 Instrument Panel and Console)
- Stub Shaft Pilot Bearing and Seal (In-vehicle Repair, 205-03 Front Drive Axle/Differential)
- Supplemental Restraint System (Section 501-20B)
- Supplemental Restraint System (SRS) Deactivation and Reactivation (General Procedures, 501-20B Supplemental Restraint

System)

Supplemental Restraint System (SRS) Depowering and Repowering (General Procedures, 501-20B Supplemental Restraint System)

Supplemental Restraint System (Specifications, 501-20B Supplemental Restraint System)

Suspension System — General Information (Section 204-00)

Suspension System — General Information (Specifications, 204-00 Suspension System — General Information)

Suspension System (Diagnosis and Testing, 204-00 Suspension System — General Information)

Symbols Glossary (Description and Operation, 100-00 Service Information)

Symptom Chart (Diagnosis and Testing, 206-00 Brake System — General Information)

Symptom Chart (Diagnosis and Testing, 414-00 Charging System)

Symptom Charts (Diagnosis and Testing, 206-06 Hydraulic Brake Actuation)

Tailgate Handle, Lock and Latches — Exploded View (Removal and Installation, 501-14 Handles, Locks, Latches and Entry Systems)

Tailgate Latch Remote Control (Removal and Installation, 501-14 Handles, Locks, Latches and Entry Systems)

Tailgate Latch (Removal and Installation, 501-14 Handles, Locks, Latches and Entry Systems)

Tailgate Lift Assist Torsion Rod (Removal and Installation, 501-04 Pickup Bed and Platform Body)

Tailgate Lock Cylinder (Removal and Installation, 501-14 Handles, Locks, Latches and Entry Systems)

Tailgate Release Handle (Removal and Installation, 501-14 Handles, Locks, Latches and Entry Systems)

Tailgate Step Adjustment (General Procedures, 501-04 Pickup Bed and Platform Body)

Tailgate Step Assist Handle (Removal and Installation, 501-04 Pickup Bed and Platform Body)

Tailgate Step (Removal and Installation, 501-04 Pickup Bed and Platform Body)

Telematics Module (Removal and Installation, 415-00F Information and Entertainment Systems — Ford Work Solutions)

Temperature Blend Door Actuator — Driver Side (Removal and Installation, 412-01 Climate Control)

Temperature Blend Door Actuator — Passenger Side (Removal and Installation, 412-01 Climate Control)

Thermostat — 3.5L GTDI (Removal and Installation, 303-03 Engine Cooling)

Thermostat — 3.7L (Removal and Installation, 303-03 Engine Cooling)

Thermostat — 5.0L (Removal and Installation, 303-03 Engine Cooling)

Thermostat — 6.2L (Removal and Installation, 303-03 Engine Cooling)

Thermostat Housing — 3.5L GTDI (Removal and Installation, 303-03 Engine Cooling)

Thermostat Housing — 3.7L (Removal and Installation, 303-03 Engine Cooling)

Thermostat Housing — 5.0L (Removal and Installation, 303-03 Engine Cooling)

Thermostatic Expansion Valve Manifold and Tube Assembly (Removal and Installation, 412-01 Climate Control)

Thermostatic Expansion Valve (Removal and Installation, 412-01 Climate Control)

Throttle Body (Removal and Installation, 303-04A Fuel Charging and Controls — 3.5L GTDI)

Throttle Body (Removal and Installation, 303-04B Fuel Charging and Controls — 3.7L)

Throttle Body (Removal and Installation, 303-04C Fuel Charging and Controls — 5.0L (4V))

Throttle Body (Removal and Installation, 303-04D Fuel Charging and Controls — 6.2L (2V))

Timing Drive Components (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)

Timing Drive Components (In-vehicle Repair, 303-01B Engine — 3.7L)

Timing Drive Components (In-vehicle Repair, 303-01C Engine — 5.0L (4V))

Timing Drive Components (In-vehicle Repair, 303-01D Engine — 6.2L (2V))

Tire Pressure Monitor (TPM) Module (Removal and Installation, 204-04 Wheels and Tires)

Tire Pressure Monitoring System (TPMS) Sensor Activation (General Procedures, 204-04 Wheels and Tires)

Tire Pressure Monitoring System (TPMS) Sensor Training (General Procedures, 204-04 Wheels and Tires)

Tire Pressure Monitoring System (TPMS) Sensor (Disassembly and Assembly of Subassemblies, 204-04 Wheels and Tires)

Tire Pressure Monitoring System (TPMS) (Diagnosis and Testing, 204-04 Wheels and Tires)

Toe Adjustment — Front (General Procedures, 204-00 Suspension System — General Information)

Torca® Clamp (General Procedures, 309-00 Exhaust System)

Torque Converter Contamination Inspection (General Procedures, 307-01 Automatic Transaxle/Transmission — 6R80)

Torque Converter Diagnosis (Diagnosis and Testing, 307-01 Automatic Transaxle/Transmission — 6R80)

Torque Converter (Description and Operation, 307-01 Automatic Transaxle/Transmission — 6R80)

Touchscreen Calibration (General Procedures, 415-00D Information and Entertainment Systems — 8-Inch (203 mm) Touchscreen)

Touchscreen Calibration (General Procedures, 415-00E Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen)

Tow/Haul Switch — Column Shift (Removal and Installation, 307-05 Automatic Transaxle/Transmission External Controls)

Tow/Haul Switch — Floor Shift (Removal and Installation, 307-05 Automatic Transaxle/Transmission External Controls)

Traction-Lock Clutch Packs (Removal and Installation, 205-02B Rear Drive Axle/Differential — Ford 9.75-Inch Ring Gear)

Trailer Brake Control (TBC) Module (Removal and Installation, 206-10 Auxiliary Brake System)

Trailer Hitch (Removal and Installation, 502-02 Full Frame and Body Mounting)

Trailer Lamps (Diagnosis and Testing, 417-01 Exterior Lighting)

Transaxle/Transmission Cooling (Section 307-02)

Transaxle/Transmission Cooling (Specifications, 307-02 Transaxle/Transmission Cooling)

Transfer Case — 2-Speed Torque-On-Demand (Disassembly and Assembly, 308-07B Transfer Case)

Transfer Case — Electronic Shift (Disassembly and Assembly, 308-07B Transfer Case)

Transfer Case (Section 308-07B)

Transfer Case Control Module (TCCM) (Removal and Installation, 308-07A Four Wheel Drive (4WD) Systems)

Transfer Case Draining and Filling (General Procedures, 308-07B Transfer Case)

Transfer Case Rear Output Shaft Seal (In-vehicle Repair, 308-07B Transfer Case)

Transfer Case Shift Motor (Removal and Installation, 308-07A Four Wheel Drive (4WD) Systems)

Transfer Case (Description and Operation, 308-07B Transfer Case)

Transfer Case (Diagnosis and Testing, 308-07B Transfer Case)

Transfer Case (Installation, 308-07B Transfer Case)

Transfer Case (Removal, 308-07B Transfer Case)

Transfer Case (Specifications, 308-07B Transfer Case)

Transmission — Four Wheel Drive (4WD) (Installation, 307-01 Automatic Transaxle/Transmission — 6R80)

Transmission — Four Wheel Drive (4WD) (Removal, 307-01 Automatic Transaxle/Transmission — 6R80)

Transmission — Rear Wheel Drive (RWD) (Installation, 307-01 Automatic Transaxle/Transmission — 6R80)

Transmission — Rear Wheel Drive (RWD) (Removal, 307-01 Automatic Transaxle/Transmission — 6R80)

Transmission Connector Layouts (Diagnosis and Testing, 307-01 Automatic Transaxle/Transmission — 6R80)

Transmission Cooling (Description and Operation, 307-02 Transaxle/Transmission Cooling)

Transmission Cooling (Diagnosis and Testing, 307-02 Transaxle/Transmission Cooling)

Transmission Description (Description and Operation, 307-01 Automatic Transaxle/Transmission — 6R80)

Transmission Drive Cycle Test (Diagnosis and Testing, 307-01 Automatic Transaxle/Transmission — 6R80)

Transmission Electronic Control System (Description and Operation, 307-01 Automatic Transaxle/Transmission — 6R80)

Transmission Fluid Cooler Backflushing and Cleaning (General Procedures, 307-01 Automatic Transaxle/Transmission — 6R80)

Transmission Fluid Cooler Backflushing and Cleaning (General Procedures, 307-02 Transaxle/Transmission Cooling)

Transmission Fluid Cooler Tubes — 3.5L GTDI, 3.7L (Removal and Installation, 307-02 Transaxle/Transmission Cooling)

Transmission Fluid Cooler Tubes — 5.0L (4V), 6.2L (2V) (Removal and Installation, 307-02 Transaxle/Transmission Cooling)

Transmission Fluid Cooler (Removal and Installation, 307-02 Transaxle/Transmission Cooling)

Transmission Fluid Drain and Refill (General Procedures, 307-01 Automatic Transaxle/Transmission — 6R80)

Transmission Fluid Exchange (General Procedures, 307-01 Automatic Transaxle/Transmission — 6R80)

Transmission Fluid Level Check (General Procedures, 307-01 Automatic Transaxle/Transmission — 6R80)

Transmission Insulator and Retainer (In-vehicle Repair, 307-01 Automatic Transaxle/Transmission — 6R80)

Transmission Operation (Description and Operation, 307-01 Automatic Transaxle/Transmission — 6R80)

Transmission Support Crossmember (Removal and Installation, 502-02 Full Frame and Body Mounting)

Transmission (Assembly, 307-01 Automatic Transaxle/Transmission — 6R80)

Transmission (Disassembly, 307-01 Automatic Transaxle/Transmission — 6R80)

Trough Assembly (Removal and Installation, 501-17 Roof Opening Panel)

Turbocharger — LH (Removal and Installation, 303-04E Fuel Charging and Controls — Turbocharger)

Turbocharger — RH (Removal and Installation, 303-04E Fuel Charging and Controls — Turbocharger)

Turbocharger Boost Pressure (TCBP) / Charge Air Cooler Temperature (CACT) Sensor — 3.5L GTDI (Removal and Installation, 303-14 Electronic Engine Controls)

Turbocharger Bypass Valve (Removal and Installation, 303-14 Electronic Engine Controls)

Turbocharger Coolant Return Tube — LH (Removal and Installation, 303-04E Fuel Charging and Controls — Turbocharger)

Turbocharger Coolant Return Tube — RH (Removal and Installation, 303-04E Fuel Charging and Controls — Turbocharger)

Turbocharger Coolant Supply Tube — LH (Removal and Installation, 303-04E Fuel Charging and Controls — Turbocharger)

Turbocharger Coolant Supply Tube — RH (Removal and Installation, 303-04E Fuel Charging and Controls — Turbocharger)

Turbocharger Intake Pressure and Temperature Sensor (TCIPT) — 3.5L GTDI (Removal and Installation, 303-14 Electronic

Engine Controls)

Turbocharger Oil Return Tube — LH (Removal and Installation, 303-04E Fuel Charging and Controls — Turbocharger)

Turbocharger Oil Return Tube — RH (Removal and Installation, 303-04E Fuel Charging and Controls — Turbocharger)

Turbocharger Oil Supply Tube — LH (Removal and Installation, 303-04E Fuel Charging and Controls — Turbocharger)

Turbocharger Oil Supply Tube — RH (Removal and Installation, 303-04E Fuel Charging and Controls — Turbocharger)

Turbocharger (Description and Operation, 303-04E Fuel Charging and Controls — Turbocharger)

Turbocharger (Diagnosis and Testing, 303-04E Fuel Charging and Controls — Turbocharger)

Turn Signal and Hazard Lamps (Diagnosis and Testing, 417-01 Exterior Lighting)

Universal Joints (Description and Operation, 205-01 Driveshaft)

Universal Serial Bus (USB) Cable and Port (Removal and Installation, 415-00B Information and Entertainment Systems — AM/FM/CD)

Universal Serial Bus (USB) Cable and Port (Removal and Installation, 415-00C Information and Entertainment Systems — 4.2-Inch (107 mm) Display)

Universal Serial Bus (USB) Cable and Port (Removal and Installation, 415-00D Information and Entertainment Systems — 8-Inch (203 mm) Touchscreen)

Universal Serial Bus (USB) Cable and Port (Removal and Installation, 415-00E Information and Entertainment Systems — Sony® 8-Inch (203 mm) Touchscreen)

Universal Transmitter Programming (General Procedures, 419-02 Remote Convenience)

Universal Transmitter (Description and Operation, 419-02 Remote Convenience)

Universal Transmitter (Diagnosis and Testing, 419-02 Remote Convenience)

Upfitter Relay Box (Diagnosis and Testing, 419-10 Multifunction Electronic Modules)

Upfitter Switch (Removal and Installation, 419-10 Multifunction Electronic Modules)

Upper Arm (Removal and Installation, 204-01A Front Suspension — Rear Wheel Drive (RWD))

Upper Arm (Removal and Installation, 204-01B Front Suspension — Four Wheel Drive (4WD))

Upper Intake Manifold (In-vehicle Repair, 303-01B Engine — 3.7L)

Using This Manual (Description and Operation, 100-00 Service Information)

Valve Clearance Check (General Procedures, 303-01A Engine — 3.5L GTDI)

Valve Clearance Check (General Procedures, 303-01B Engine — 3.7L)

Valve Cover — LH (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)

Valve Cover — LH (In-vehicle Repair, 303-01B Engine — 3.7L)

Valve Cover — LH (In-vehicle Repair, 303-01C Engine — 5.0L (4V))

Valve Cover — LH (In-vehicle Repair, 303-01D Engine — 6.2L (2V))

Valve Cover — RH (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)

Valve Cover — RH (In-vehicle Repair, 303-01B Engine — 3.7L)

Valve Cover — RH (In-vehicle Repair, 303-01C Engine — 5.0L (4V))

Valve Cover — RH (In-vehicle Repair, 303-01D Engine — 6.2L (2V))

Valve Guide Inner Diameter (General Procedures, 303-00 Engine System — General Information)

Valve Inspection (General Procedures, 303-00 Engine System — General Information)

Valve Seals (In-vehicle Repair, 303-01C Engine — 5.0L (4V))

Valve Seals (In-vehicle Repair, 303-01D Engine — 6.2L (2V))

Valve Seat Inspection (General Procedures, 303-00 Engine System — General Information)

Valve Seat Runout (General Procedures, 303-00 Engine System — General Information)

Valve Seat Width (General Procedures, 303-00 Engine System — General Information)

Valve Spring Free Length (General Procedures, 303-00 Engine System — General Information)

Valve Spring Installed Length (General Procedures, 303-00 Engine System — General Information)

Valve Spring Squareness (General Procedures, 303-00 Engine System — General Information)

Valve Spring Strength (General Procedures, 303-00 Engine System — General Information)

Valve Spring, Retainer and Seal (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)

Valve Spring, Retainer and Seal (In-vehicle Repair, 303-01B Engine — 3.7L)

Valve Springs (In-vehicle Repair, 303-01C Engine — 5.0L (4V))

Valve Springs (In-vehicle Repair, 303-01D Engine — 6.2L (2V))

Valve Stem Diameter (General Procedures, 303-00 Engine System — General Information)

Valve Stem to Valve Guide Clearance (General Procedures, 303-00 Engine System — General Information)

Valve Tappet Inspection (General Procedures, 303-00 Engine System — General Information)

Valve Tappets (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)

Valve Tappets (In-vehicle Repair, 303-01B Engine — 3.7L)

Valve Train Components — Exploded View (In-vehicle Repair, 303-01A Engine — 3.5L GTDI)

Valve Train Components — Exploded View (In-vehicle Repair, 303-01B Engine — 3.7L)

- Valve Train Components — Exploded View (In-vehicle Repair, 303-01C Engine — 5.0L (4V))
- Valve Train Components — Exploded View (In-vehicle Repair, 303-01D Engine — 6.2L (2V))
- Variable Camshaft Timing (VCT) System Oil Filter (In-vehicle Repair, 303-01D Engine — 6.2L (2V))
- Video Camera — Front (Removal and Installation, 413-13 Parking Aid)
- Video Camera — Rear (Removal and Installation, 413-13 Parking Aid)
- Visual Inspection (Diagnosis and Testing, 307-01 Automatic Transaxle/Transmission — 6R80)
- Warning Chimes (Description and Operation, 413-01 Instrumentation, Message Center, and Warning Chimes)
- Washer Pump (Removal and Installation, 501-16 Wipers and Washers)
- Weld-Bonding (General Procedures, 501-35 Body Repairs)
- Welding Precautions — Steel (Description and Operation, 501-35 Body Repairs)
- Wheel Alignment Angles (Description and Operation, 204-00 Suspension System — General Information)
- Wheel and Tire Rotation (General Procedures, 204-04 Wheels and Tires)
- Wheel and Tire (Disassembly and Assembly, 204-04 Wheels and Tires)
- Wheel and Tire (Removal and Installation, 204-04 Wheels and Tires)
- Wheel Bearing and Wheel Hub (Removal and Installation, 204-01A Front Suspension — Rear Wheel Drive (RWD))
- Wheel Bearing and Wheel Hub (Removal and Installation, 204-01B Front Suspension — Four Wheel Drive (4WD))
- Wheel Knuckle (Removal and Installation, 204-01A Front Suspension — Rear Wheel Drive (RWD))
- Wheel Knuckle (Removal and Installation, 204-01B Front Suspension — Four Wheel Drive (4WD))
- Wheel Speed Sensor — Front (Removal and Installation, 206-09 Anti-Lock Brake System (ABS) and Stability Control)
- Wheel Speed Sensor — Rear (Removal and Installation, 206-09 Anti-Lock Brake System (ABS) and Stability Control)
- Wheel Speed Sensor Ring — Rear (Removal and Installation, 206-09 Anti-Lock Brake System (ABS) and Stability Control)
- Wheel Studs (Removal and Installation, 204-01A Front Suspension — Rear Wheel Drive (RWD))
- Wheel Studs (Removal and Installation, 204-01B Front Suspension — Four Wheel Drive (4WD))
- Wheels and Tires (Section 204-04)
- Wheels And Tires (Description and Operation, 204-04 Wheels and Tires)
- Wheels And Tires (Diagnosis and Testing, 204-04 Wheels and Tires)
- Wheels and Tires (Specifications, 204-04 Wheels and Tires)
- Window Control Switch — Front (Removal and Installation, 501-11 Glass, Frames and Mechanisms)
- Window Control Switch — Rear (Removal and Installation, 501-11 Glass, Frames and Mechanisms)
- Window Glass — Front Door (Removal and Installation, 501-11 Glass, Frames and Mechanisms)
- Window Glass — Rear Door, SuperCab (Removal and Installation, 501-11 Glass, Frames and Mechanisms)
- Window Glass — Rear Door, SuperCrew (Removal and Installation, 501-11 Glass, Frames and Mechanisms)
- Window Glass — Rear, Manual Sliding Panel (Removal and Installation, 501-11 Glass, Frames and Mechanisms)
- Window Glass — Rear, Power Sliding Panel (Removal and Installation, 501-11 Glass, Frames and Mechanisms)
- Window Glass — Rear (Removal and Installation, 501-11 Glass, Frames and Mechanisms)
- Window Glass Adjustment — Front Door (General Procedures, 501-11 Glass, Frames and Mechanisms)
- Window Grid Wire Repair (General Procedures, 501-11 Glass, Frames and Mechanisms)
- Window Motor Initialization (General Procedures, 501-11 Glass, Frames and Mechanisms)
- Window Moulding (Removal and Installation, 501-08 Exterior Trim and Ornamentation)
- Window Regulator and Motor — Front Door (Removal and Installation, 501-11 Glass, Frames and Mechanisms)
- Window Regulator and Motor — Rear Door, SuperCab (Removal and Installation, 501-11 Glass, Frames and Mechanisms)
- Window Regulator and Motor — Rear Door, SuperCrew (Removal and Installation, 501-11 Glass, Frames and Mechanisms)
- Window Regulator and Motor — Rear (Removal and Installation, 501-11 Glass, Frames and Mechanisms)
- Window Regulator Motor — Rear (Removal and Installation, 501-11 Glass, Frames and Mechanisms)
- Window Regulator Motor (Removal and Installation, 501-11 Glass, Frames and Mechanisms)
- Windshield Glass (Removal and Installation, 501-11 Glass, Frames and Mechanisms)
- Wiper and Washer System — Exploded View (Removal and Installation, 501-16 Wipers and Washers)
- Wiper Blade and Pivot Arm Adjustment (General Procedures, 501-16 Wipers and Washers)
- Wiper Motor (Removal and Installation, 501-16 Wipers and Washers)
- Wiper Mounting Arm and Pivot Shaft (Removal and Installation, 501-16 Wipers and Washers)
- Wiper Pivot Arm (Removal and Installation, 501-16 Wipers and Washers)
- Wipers and Washers (Section 501-16)
- Wipers and Washers (Description and Operation, 501-16 Wipers and Washers)
- Wipers and Washers (Diagnosis and Testing, 501-16 Wipers and Washers)
- Wipers and Washers (Specifications, 501-16 Wipers and Washers)