

Powertrain/Drivetrain Mount Neutralizing



NOTE: *Refer to the appropriate section and procedure for special instructions on loosening and tightening mount fasteners.*

1. With the vehicle in NEUTRAL, position it on a hoist. For additional information, refer to Section 100-02.
2. Loosen, but do not remove, the powertrain/drivetrain mount fasteners.
3. Lower the vehicle.
4. **NOTICE: Do not twist or strain the powertrain/drivetrain mounts or damage to the mounts may occur.**
Start the vehicle and move it in forward 0.6-1.2 m (2-4 ft). Then move the vehicle in reverse the same distance.
5. Raise and support the vehicle.
6. Tighten the powertrain/drivetrain mount fasteners.
7. Lower the vehicle.
8. Test the system for normal operation.