

Valve Spring Free Length



NOTE: Refer to the appropriate Section 303-01 for the specification.

- 1. Measure the free length of each valve spring.

