

Variable Camshaft Timing (VCT) System Oil Filter



Removal and Installation

1. Remove the camshaft phaser and sprocket. For additional information, refer to Camshaft Phaser and Sprocket — LH or Camshaft Phaser and Sprocket — RH in this section.
2. Remove and discard the Variable Camshaft Timing (VCT) system oil filter.

Installation

1. Install the new VCT system oil filter with the open end facing the front of the engine.
2. Install the camshaft phaser and sprocket. For additional information, refer to Camshaft Phaser and Sprocket — LH or Camshaft Phaser and Sprocket — RH in this section.