

Fuel Injectors



Removal and Installation

1. The fuel injectors are serviced with the fuel rail. For additional information, refer to Fuel Rail and Fuel Injector — Exploded View and Fuel Rail in this section.