

# Turbocharger Coolant Supply Tube — LH



## Removal and Installation

1. Remove the LH turbocharger to access the LH turbocharger coolant supply tube for service, refer to Turbocharger — LH.