

Turbocharger Coolant Supply Tube — RH



Removal and Installation

1. Remove the RH turbocharger to access the RH turbocharger coolant supply tube for service, refer to Turbocharger — RH.