

Turbocharger Oil Return Tube — LH



Removal

1. The turbocharger oil return tube is serviced with the turbocharger oil supply tube.
Remove the Turbocharger Oil Supply Tube - LH, refer to Turbocharger Oil Supply Tube — LH.

Installation

1. Install the Turbocharger Oil Supply Tube - LH, refer to Turbocharger Oil Supply Tube — LH.