

Turbocharger Oil Return Tube — RH



Removal

1. The turbocharger oil return tube is serviced with the turbocharger oil supply tube.
Remove the Turbocharger Oil Supply Tube - RH, refer to Turbocharger Oil Supply Tube — RH.

Installation

1. Install the Turbocharger Oil Supply Tube - RH, refer to Turbocharger Oil Supply Tube — RH.