

Spark Plugs



Removal and Installation

1. Remove the ignition coil-on-plugs. For additional information, refer to Ignition Coil-On-Plug in this section.
2. **NOTICE:** Only use hand tools when removing or installing the spark plugs, or damage may occur to the cylinder head or spark plug.


NOTE: Use compressed air to remove any foreign material from the spark plug well before removing the spark plugs.

NOTE: If an original spark plug is used, make sure it is installed in the same cylinder from which it was taken. New spark plugs can be used in any cylinder.

Remove the 6 spark plugs.

- To install, tighten to 15 Nm (133 lb-in).

3. Inspect the spark plugs. Install new spark plugs as necessary. For additional information, refer to Section 303-00.
4. Adjust the spark plug gap as necessary.



5. To install, reverse the removal procedure.