

Ignition Coil-On-Plug



Material	
Item	Specification
Motorcraft® Silicone Brake Caliper Grease and Dielectric Compound XG-3-A	ESE-M1C171-A

Removal and Installation

1. Remove the Air Cleaner (ACL) outlet pipe. For additional information, refer to Section 303-12.
2. Remove the intake air resonator. For additional information, refer to Section 303-12.
3. Disconnect the 8 ignition wires.
4. Disconnect the 8 ignition coil-on-plug electrical connectors.
5. Remove the 8 ignition coil-on-plug bolts.
 - To install, tighten to 10 Nm (89 lb-in).
6. **NOTE:** *When removing the ignition coil-on-plugs, a slight twisting motion will break the seal and ease removal.*

Remove the 8 ignition coil-on-plugs.
7. **NOTE:** *Verify that the coil-on-plug spring is correctly located inside the ignition coil-on-plug boot and that there is no damage to the tip of the boot.*

To install, reverse the removal procedure.
 - Apply a light coat of dielectric compound to the inside of the coil-on-plug boots.