

Spark Plugs



Removal

NOTICE: The spark plug procedure must be followed exactly or damage to the cylinder head and spark plug will result.

NOTICE: Do not remove the spark plugs when the engine is hot or cold soaked. Spark plug thread or cylinder head damage can occur. Make sure the engine is warm (hand touch after cooling down) prior to spark plug removal.

Upper spark plugs

1. Remove the ignition coil-on-plug. For additional information, refer to Ignition Coil-On-Plug in this section.

Lower spark plugs

2. Disconnect the ignition wire from the lower spark plug.

All spark plugs

3. **NOTICE:** Only use hand tools when removing or installing the spark plugs or damage can occur to the cylinder head or spark plug.

NOTE: Use compressed air to remove any foreign material from the spark plug well before removing the spark plugs.


Remove the spark plug.

4. Inspect the spark plug. For additional information, refer to Section 303-00.

Installation

All spark plugs

1. Adjust the spark plug gap as necessary. For the correct spark plug gap specification, refer to Specifications in this section.



2. **NOTICE:** Only use hand tools when removing or installing the spark plugs or damage can occur to the cylinder head or spark plug.

Install the spark plug.

- Tighten to 18 Nm (159 lb-in).

Lower spark plugs

3. Connect the ignition wire from the lower spark plug.

Upper spark plugs

4. Install the ignition coil-on-plug. For additional information, refer to Ignition Coil-On-Plug in this section.