

Crankshaft Position (CKP) Sensor — 5.0L (4V)



Removal

1. Remove the intake manifold. For additional information, refer to Section 303-01C.
2. Disconnect the Cylinder Head Temperature (CHT) sensor electrical connector.
3. Disconnect the Crankshaft Position (CKP) sensor electrical connector.
4. **NOTE:** *The Crankshaft Position (CKP) sensor bolt is part of the CKP sensor and cannot be removed.*

Loosen the bolt and remove the CKP sensor.

Installation

1. **NOTE:** *The Crankshaft Position (CKP) sensor bolt is part of the CKP sensor and cannot be removed.*

Position the CKP sensor and tighten the bolt.

- Tighten to 10 Nm (89 lb-in).

2. Connect the CKP sensor electrical connector.
3. Connect the CHT sensor electrical connector.
4. Install the intake manifold. For additional information, refer to Section 303-01C.
5. After completing the repairs, use a diagnostic scan tool to perform the Misfire Monitor Neutral Profile Correction procedure.