

Tire Pressure Monitoring System (TPMS) Sensor



Disassembly

1. **NOTE:** *The Tire Pressure Monitoring System (TPMS) sensor cannot be removed without disassembly of the wheel and tire.*

Disassemble the wheel and tire. For additional information, refer to Wheel and Tire in this section.