

Symptom Charts

 [Ford Ecat Electronic Parts Catalog](#)

Symptom Chart

Condition	Possible Causes	Action
No communication with the Steering Column Control Module (SCCM)	- Fuse - Wiring, terminals or connectors - SCCM	REFER to Section 418-00.
Adjustable pedals are inoperative/does not operate correctly — using the brake pedal control switch	- Foreign objects or material - Fuse - Wiring, terminals or connectors - Brake pedal control switch - Adjustable accelerator pedal and motor with attached cable - Adjustable brake pedal and bracket - SCCM	GO to Pinpoint Test A.
Adjustable pedals are inoperative/does not operate correctly — using the memory SET switch buttons	- Foreign objects or material - Fuse - Wiring, terminals or connectors - Memory SET switch - Adjustable accelerator pedal and motor with attached cable - Adjustable brake pedal and bracket - Incorrect SCCM configuration - Driver Seat Module (DSM) - SCCM	GO to Pinpoint Test B.

	• Body Control Module (BCM)	
• Adjustable pedals are inoperative/does not operate correctly — using the Remote Keyless Entry (RKE) transmitter	• Foreign objects or material • Wiring, terminals or connectors • Adjustable accelerator pedal and motor with attached cable • Adjustable brake pedal and bracket • RKE transmitter • DSM • SCCM • BCM	• GO to Pinpoint Test B.
• The adjustable pedals only move in 1 second intervals	• Wiring, terminals or connectors • Adjustable accelerator pedal and motor with attached cable • Incorrect SCCM configuration • SCCM	• GO to Pinpoint Test C.