


Brake Booster

 [Ford Ecat Electronic Parts Catalog](#)




Item	Part Number	Description
1	2L523 2L523	Clevis pin
2	W520212 W520212	Brake booster nut (4 required)
3	2005 2005	Brake booster
4	2365A 2365A	Vacuum sensor assembly
5	W520212 W520212	Brake master cylinder nut (2 required)
6	2140 2140	Brake master cylinder assembly
7	2152 2152	Brake master cylinder-to-booster seal

8	—	Gasket (part of 2B022)
9	—	Spacer
10	—	Gasket (part of 2B022)
11	—	Vacuum sensor electrical connector (part of 12A581)
12	3B4763B476	Front axle vent hose

Removal and Installation

1. Relieve the vacuum in the brake booster by pressing and releasing the brake pedal a minimum of 5 times with the engine not running.
2. Remove the Air Cleaner (ACL) element. For additional information, refer to Air Cleaner Element in Section 303-12.
3. Remove the 2 bolts and position the coolant expansion tank/lower ACL housing assembly aside.
 - To install, tighten bolts to 15 Nm (133 lb-in).



4. Disconnect the brake fluid level switch.
5. If equipped, position the vacuum sensor wiring harness and front axle vent hose aside.
6. **NOTICE: When the master cylinder is removed, the piston will be exposed. Do not damage the piston or piston surface or a fluid leak may occur.**

Remove the 2 brake master cylinder nuts and position the master cylinder aside.

- Support the master cylinder with mechanic's wire.
- To install, tighten the nuts to 25 Nm (18 lb-ft).

7. **NOTE:** *To allow proper drainage of any moisture, the vacuum sensor must be installed in the same position and orientation as removed.*

Disconnect the vacuum sensor assembly from the brake booster.

8. **NOTICE: Do not service the brake pedal or brake booster without first removing the stoplamp switch. This switch must be removed with the brake pedal in the at-rest position. The switch plunger must be compressed for the switch to rotate in the bracket. Attempting to remove the switch when the plunger is extended (during pedal apply) will result in damage to the switch.**

Remove the stoplamp switch. For additional information, refer to Section 417-01.

9. **NOTE:** *The clevis pin is a one-time use only part. Any time the clevis pin is removed, a new clevis pin should be used.*

NOTE: *Use an 11 mm, 12-point socket or wrench to compress the 2 tabs on the clevis pin.*

Remove the clevis pin and disconnect the brake booster push rod from the brake pedal arm. Discard the clevis pin.

10. Remove the 4 brake booster nuts and remove the brake booster.
 - To access the nuts, fold back the sound insulation.

- To install, tighten the nuts to 25 Nm (18 lb-ft) following a clockwise pattern starting with the upper left nut.

11. NOTICE: Do not press, pull or otherwise move the brake pedal while installing the stoplamp switch. This switch must be installed with the booster push rod attached to the brake pedal and with the brake pedal in the at-rest position. Installing this switch with the brake pedal in any other position will result in incorrect adjustment and may damage the switch.

To install, reverse the removal procedure.