

Power Steering System Filling


 [Ford Ecat Electronic Parts Catalog](#)

Special Tool(s)

 ST2670-A	Evacuation Cap, Power Steering 211-265
 ST2826-A	Fill Adapter Manifold, Power Steering 211-327
 ST1176-A	Vacuum Pump Kit 416-D002 (D95L-7559-A) or equivalent

Material

Item	Specification
Motorcraft® MERCON® LV Automatic Transmission Fluid XT-10-QLVC (US); CXT-10-LV12 (Canada)	MERCON® LV



Item	Description
1	Power steering fluid reservoir
2	Control valve (vacuum side)
3	Control valve (fluid container side)
4	Fluid container

1. **NOTICE:** If the air is not purged from the power steering system correctly, premature power steering pump failure may result. The condition can occur on pre-delivery vehicles with evidence of aerated fluid or on vehicles that have had steering component repairs.

Remove the power steering fluid reservoir cap.

2. Install the Power Steering Evacuation Cap, Power Steering Fill Adapter Manifold and Vacuum Pump Kit as shown in the illustration.

3. **NOTE:** The Power Steering Fill Adapter Manifold control valves are in the OPEN position when the points of the handles face the center of the Power Steering Fill Adapter Manifold.

Close the Power Steering Fill Adapter Manifold control valve (fluid side).

4. Open the Power Steering Fill Adapter Manifold control valve (vacuum side).

5. Using the Vacuum Pump Kit, apply 68-85 kPa (20-25 in-Hg) of vacuum to the power steering system.

6. Observe the Vacuum Pump Kit gauge for 30 seconds.

7. If the Vacuum Pump Kit gauge reading drops more than 3 kPa (0.88 in-Hg), correct any leaks in the power steering system or the Power Steering Evacuation Cap, Power Steering Fill Adapter Manifold and Vacuum Pump Kit before proceeding.

8. **NOTE:** The Vacuum Pump Kit gauge reading will drop slightly during this step.

Slowly open the Power Steering Fill Adapter Manifold control valve (fluid side) until power steering fluid completely fills the hose and then close the control valve.

9. Using the Vacuum Pump Kit, apply 68-85 kPa (20-25 in-Hg) of vacuum to the power steering system.
10. Close the Power Steering Fill Adapter Manifold control valve (vacuum side).
11. Slowly open the Power Steering Fill Adapter Manifold control valve (fluid side).
12. Once power steering fluid enters the fluid reservoir and reaches the minimum fluid level indicator line on the reservoir, close the Power Steering Fill Adapter Manifold control valve (fluid side).
13. Remove the Power Steering Evacuation Cap, Power Steering Fill Adapter Manifold and Vacuum Pump Kit.
14. Install the reservoir cap.
15. **NOTICE: Do not hold the steering wheel against the stops for an extended amount of time. Damage to the power steering pump may occur.**

NOTE: *There will be a slight drop in the power steering fluid level in the reservoir when the engine is started.*

Start the engine and turn the steering wheel from stop-to-stop.

16. Turn the ignition switch to the OFF position.
17. **NOTE:** *Do not overfill the reservoir.*

Remove the reservoir cap and fill the reservoir with the specified fluid.

18. Install the reservoir cap.