

Steering Column Switches



The steering column switches consist of the following components:

- Steering Column Control Module (SCCM)
- Ignition switch
- Hazard flasher switch
- Multifunction switch
- Brake pedal control switch (if equipped)
- Steering column control switch (if equipped)
- Steering wheel switches (if equipped)
- Steering wheel rotation sensor (if equipped)

Steering Column Control Module (SCCM)

The **SCCM** acts as a central hub for the steering column switches and circuits. The hazard flasher switch, multifunction switch, brake pedal control switch and steering column control switch are mounted directly to the **SCCM** and can be serviced separately from the **SCCM**.