

WITHOUT SONY ® SOUND

AUDIO
CONTROL
MODULE (ACM)
151-16

Premium,
Premium Plus,

LF SPKR+

LF SPKR-

RF SPKR+

RF SPKR-

except base audio

except base audio

if equipped

if equipped

if optioned with base audio

VME07 WH C230

RME07 WH-BN 1

2

TWEETER,
LEFT FRONT
151-18

C290A C240A VME07 WH

8 22 RME07 WH-BN

21 10 S201

C248

51

52

VME07 WH

RME07 WH-BN

C219

1

2

VME07 WH

RME07 WH-BN

C523

1

2

SPEAKER,
LEFT FRONT
151-42

VME10 WH-VT

RME10 WH-OG

S205

S206

C238

1

2

VME10 WH-VT

RME10 WH-OG

C237

1

2

VME10 WH-VT

RME10 WH-OG

C612

1

2

SPEAKER,
RIGHT FRONT
151-43

VME10 WH-VT C231

RME10 WH-OG 1

2

TWEETER,
RIGHT FRONT
151-15
151-16

LR SPKR+

LR SPKR-

VME09 WH-GN

RME09 BN-YE

C248

14

13

VME09 WH-GN

RME09 BN-YE

C327

8

7

VME09 WH-GN

RME09 BN-YE

C702

1

2

SPEAKER,
LEFT REAR
151-26
151-44
151-45

VME12 BN-WH

RME12 BN-BU

C238

4

3

VME12 BN-WH

RME12 BN-BU

C316

8

7

VME12 BN-WH

RME12 BN-BU

C802

1

2

SPEAKER,
RIGHT REAR
151-29
151-44
151-45

