

BATTERY JUNCTION BOX (BJB)

Fuse	Amps	Circuits protected
F11	30	Power Running Board (PRB) module
F12	40, *50	Low Fan Control (LFC) relay
F13	30	Starter relay
F14	30	Seat control switch, passenger side front
F15	40, *50	High Fan Control (HFC) relay
F16	20	Headlamp, Right (HID)
F17	30	Trailer Brake Control (TBC) module, Telematics module
F18	30	Upfitter relay 1
F19	30	Upfitter relay 2
F20	20	Transfer Case Control Module (TCCM) - with 4x4
F21	30	Trailer tow battery charge relay
F22	20	Cigar lighter, front
F26	10	PCM power relay, Evaporative emission (EVAP) canister vent solenoid, Powertrain Control Module (PCM)
F27	20	Fuel pump relay
F28	10	Upfitter relay 4
F29	10	Constant Vacuum Hublock (CVH) solenoid
F30	10	A/C clutch relay
F31	15	Run/start relay
F32	40	Rear window defrost relay
F33	40	DC/AC inverter module
F34	40, **50	PCM power relay
F35	20	Headlamp, left (HID)
F36	30	Anti-lock Brake System (ABS) module
F41	15	Front camera washer relay
F42	5	Run/start relay
F43	15	Reversing lamp relay
F44	15	Upfitter relay 3
F45	10	Generator
F46	10	Brake Pedal Position (BPP) switch
F47	60	Anti-lock Brake System (ABS) module
F48	20	Roof opening panel module
F49	30	Wiper relay
F50	-	Not used
F51	40	Blower motor relay
F52	5	Power steering control module (PSCM), Blower motor relay

Fuse	Amps	Circuits protected
F53	5	Powertrain Control Module (PCM)
F54	5	Anti-lock Brake System (ABS) module, Transfer Case Control Module (TCCM), Rear window defrost relay, Trailer tow battery charge relay, Front camera washer relay
F55	-	Not used
F56	15	Exterior rear view mirrors
F57	-	Not used
F58	-	Not used
F59	-	Not used
F60	-	Not used
F61	-	Not used
F62	-	Not used
F63	25	Fan Control (FC) relay
F64	40	Not used
F65	20	Power point, instrument panel
F66	20	Power point, console 1 - with floor shifter
F67	20	Trailer tow relay, parking lamp
F68	25	Transfer Case Control Module (TCCM) - with 4x4 Electronic Locking Differential (ELD) Module - with 4x2
F69	30	Dual Climate Controlled Seat Module (DCSM), Heated seat module
F70	-	Not used
F71	20	Heated seat module, left rear
F72	20	Power point, console 2
F73	20	Trailer tow relay, left turn, Trailer tow relay, right turn
F74	30	Seat control switch, driver side front - without memory Driver Seat Module (DSM) - with memory
F75	15, **25	Powertrain Control Module (PCM)
F76	20	Mass Air Flow / Intake Air Temperature (MAF/IAT) sensor, Variable Camshaft Timing (VCT) solenoids, Heated oxygen sensors (HO2Ss), Universal heated oxygen sensors (HO2Ss), Evaporative emission (EVAP) canister purge valve, Evaporative emission (EVAP) canister vent solenoid
F77	10	Cooling fan relays, A/C clutch relay
F78	15, *20	Coil on Plugs (COPs), Ignition transformer capacitors
F79	5	Rain sensor module
F80	-	Not used
F81	-	Not used
F82	-	Not used

*6.2L

**3.5L

