

POWER DISTRIBUTION / BCM
Hot in Start or Run

13-4



CE608 VT-GN

6.2L

C1010 -9

C146 -9

CBK01 BU

S137

CBK01 BU

5.0L/6.2L

C181

C1181

2

2

FUEL
INJECTOR 1
23-2 24-2 26-2

CBK01 BU

C182

C1182

2

2

FUEL
INJECTOR 2
23-2 24-2 26-2

CBK01 BU

C183

C1183

2

2

FUEL
INJECTOR 3
23-2 24-2 26-2

CBK01 BU

C184

C1184

2

2

FUEL
INJECTOR 4
23-2 24-2 26-2

CBK01
BU

CBK01 BU

C1185

2

FUEL
INJECTOR 5
26-2

CBK01 BU

C1186

2

FUEL
INJECTOR 6
26-2

3.7L

S134

CBK01 BU

C185

2

FUEL
INJECTOR 5
23-2 24-2

CBK01 BU

C186

2

FUEL
INJECTOR 6
23-2 24-2

CBK01 BU

C187

2

FUEL
INJECTOR 7
23-2 24-2

CBK01 BU

C188

2

FUEL
INJECTOR 8
23-2 24-2

5.0L/6.2L

