



Warning
Do not attempt to diagnose or troubleshoot Supplemental Restraint System circuitry without consulting the Workshop Manual. Improper troubleshooting could cause the supplemental restraints to deploy inadvertently, causing injury.

RESTRAINTS
CONTROL
MODULE (RCM)
151-26
151-27
151-28

SAFETY BELT
RETRACTOR
PRETENSIONER,
PASSENGER
151-29
151-31
151-44

Regular Cab,
Super Crew

Super Cab

if equipped
Super Cab

PASS_LOAD_LIMITER_FEED
PASS_LOAD_LIMITER_RTN

SAFETY BELT
BUCKLE SWITCH,
PASSENGER
151-39

CR122 WH-OG

RR122 BN

CR203 GY-VT

Not used

Not used

PASS_BUCKLE_SW

4 C3066

GD901
BK

S351

GD901
BK

5 C312

Super Cab

S321

GD174
BK-WH

G300
10-17

C3202

1

2

C830

1

2

CR147

GN-OG

RR147

YE-VT

C316

6

5

CR147

GN-OG

RR147

YE-VT

C310B

12

11

C312

3

4

10

33

