

Diagnostic Parameters Identification (PID) Chart



The following is a list of output state control parameters and their corresponding PIDs:

Diagnostic PID Chart

PID Name	PID Description	Units
AXLE	Axle Ratio	Ratio
BOO1	Brake ON/OFF Switch	On/Off
BOO2	Brake ON/OFF Switch	On/Off
CHT	Cylinder Head Temperature	Temperature
DTCCNT	Continuous Codes	Number
GEAR	Gear Commanded by Module	Mode
GEAR_OSC#	Gear Commanded by Output State Control	Mode
GEAR_RAT	Gear Ratio Commanded	Ratio
HRSH_SHFT#	Firm Shift	On/Off
IN_GEAR	In Gear-Transmission is Applying a Load to Engine	In Gear
ISS_F	Input Shaft Speed Sensor Fault	No Fault/Yes Fault
ISS_SRC	Input Shaft Speed Sensor	rpm
LINEDSD#	Line Pressure Control Desired	Pressure
LOAD	Engine Load	Percentage
OSS_F	Output Shaft Speed Reliable	No Fault/Yes Fault
OSS_SRC	Unfiltered Output Shaft Speed	rpm
PARK_BRK	Park Brake Switch	On/Off
LPC	Line Pressure Control (LPC) solenoid	Pressure
LPC_AMP#	LPC solenoid current	Current
LPC_F	LPC solenoid fault status	No Fault/Yes Fault
RLC_F	Reverse Control Lamp Status	No Fault/Yes Fault
RPM#	Engine Revolutions Per Minute	rpm
SHIFT_DROP	Shift rpm Drop in Input Shaft Speed Below Expected	rpm
SHIFT_FLRE	Shift rpm Rise in Input Shaft Speed Above Expected	rpm
SHIFT_ID	Shift Identification of Shift PIDs Lag, Time, Flair and Drop	rpm
SHIFT_LAG	Shift Time Elapsed From 1% to 9% Complete	Time
SHIFT_TIME	Shift Time From Commanded to 10% Complete	Time

PID Name	PID Description	Units
SHIFT_TYPE	Shift Type	Type
SSA_AMP#	Shift Solenoid Pressure Control A (SSPCA)	Current
SSB_AMP#	Shift Solenoid Pressure Control B (SSPCB)	Current
SSC_AMP#	Shift Solenoid Pressure Control C (SSPCC)	Current
SSD_AMP#	Shift Solenoid Pressure Control D (SSPCD)	Current
SSE_AMP#	Shift Solenoid Pressure Control E (SSPCE)	Current
SSPCA	SSPCA	Pressure
SSPCA_F	SSPCA Status	No Fault/Yes Fault
SSPCB	SSPCB	Pressure
SSPCB_F	SSPCB Status	No Fault/Yes Fault
SSPCC	SSPCC	Pressure
SSPCC_F	SSPCC Status	No Fault/Yes Fault
SSPCD	SSPCD	Pressure
SSPCD_F	SSPCD Status	No Fault/Yes Fault
SSPCE_F	SSPCE Status	No Fault/Yes Fault
TCC	Torque Converter Clutch (TCC) Solenoid	Pressure
TCC AMP#	Converter Pressure Control	Current
TCC_F	TCC Fault	No Fault/Yes Fault
TCC_OSC#	Output State Control of Torque Converter	Locked/Unlocked
TCC_RAT	Transmission Slip Ratio	Ratio
TCIL	Transmission Control Indicator Lamp (TCIL)	On/Off
TCS_DEPRES	Transmission Control Switch (TCS) Pressed	Yes/No
TCS_STATE	TCS Requested State	On/Off
TC_SLIPACT	Torque Converter Slip Actual	rpm
TC_SLIPDSD	Torque Converter Slip Desired	rpm
TFT	Transmission Fluid Temperature (TFT)	Temperature
TFTV	TFT Volts	Volts
TFT_F	TFT Status	No Fault/Yes Fault
TIRESIZE	Tire Size	Rev Per Mile
TP	Throttle Position (TP) Sensor	Percentage
TP1	TP Sensor 1	Volts
TP2	TP Sensor 2	Volts
TR	Transmission Range (TR)	Mode
TRANS_VOLT_A	Transmission Supply Voltage Control State	On/Off
TRAN_RAT	Transmission Gear ratio	Ratio
TRN_N_F	Neutral Output Status	On/Off
TRN_P_F	Park Output Status	On/Off
TR_CRANK	TR Input Allowing Input Start	Yes/No
TR_DC	TR Duty Cycle	Percentage

PID Name	PID Description	Units
TR_F	TR Status	No Fault/Yes Fault
TR_FREQ	TR Frequency	Frequency
TSS_F	Turbine Shaft Speed (TSS) Reliable	No Fault/Yes Fault
TSS_SRC	Unfiltered Turbine Shaft Speed	rpm
VPWR	Module Supply Voltage	Volts
VREF	Reference Voltage	Volts
VSOUT_F	Vehicle Speed Output Status	No Fault/Yes Fault
VSS	Vehicle Speed Sensor (VSS)	Speed