

Brake Shift Interlock Override — Column Shift



NOTE: *If it is necessary to use the override procedure to move the selector lever out of the PARK position, it is possible that a fuse has blown. GO to Pinpoint Test A.*


This vehicle is equipped with a brake shift interlock feature that prevents the selector lever from being moved out of PARK when the ignition is in the ON position until the brake pedal is applied.

If the selector lever cannot be moved out of the PARK position when the ignition is in the ON position and the brake pedal is applied:

1. Apply the parking brake. Turn the ignition key to the off position and remove the key.
2. Tilt and telescope the steering column to the full downward and rearward position.
3. **NOTICE: Make sure to use extra care when detaching the selector lever boot clips from steering column shrouds or damage to the selector lever boot may occur causing replacement of the selector lever assembly. The selector lever boot is not serviceable separately.**


Position the selector lever boot aside.

1. Push forward on the selector lever boot at the area indicated and remove the boot from the upper and lower steering column shrouds.



4. **NOTE:** *The BSIA spindle can be accessed through the selector lever boot opening.*


Move the BSIA spindle outward, apply the brake pedal and position the selector lever into NEUTRAL.



5. **NOTICE:** Make sure to use extra care and follow the installation sequence when installing the selector lever boot to the steering column shrouds or damage to the boot may occur causing replacement of the selector lever assembly. the selector lever boot is not serviceable separately.

Install the selector lever boot in the sequence shown.

1. Install the front of the selector lever boot.
2. Install the bottom of the selector lever boot.
3. Install the top of the selector lever boot.
4. Install the back of the selector lever boot.



6. Start the vehicle.