

Tow/Haul Switch — Column Shift



Removal and Installation

NOTE: *The Tow/Haul switch is part of the selector lever.*

1. To install a new Tow/Haul switch, a new selector lever must be installed. For additional information, refer to Selector Lever — Column Shift in this section.