



Fuel System Pressure Test

 [Ford Ecat Electronic Parts Catalog](#)

Special Tool(s)	
	Fuel Pressure Test Kit 310-D009 (D95L-7211-A) or equivalent
	Fuel Pressure T-Adapter 3/8" 310-D252 or equivalent

WARNING: Do not smoke, carry lighted tobacco or have an open flame of any type when working on or near any fuel-related component. Highly flammable mixtures are always present and may be ignited. Failure to follow these instructions may result in serious personal injury.

WARNING: Before working on or disconnecting any of the fuel tubes or fuel system components, relieve the fuel system pressure to prevent accidental spraying of fuel. Fuel in the fuel system remains under high pressure, even when the engine is not running. Failure to follow this instruction may result in serious personal injury.

WARNING: Do not carry personal electronic devices such as cell phones, pagers or audio equipment of any type when working on or near any fuel-related component. Highly flammable mixtures are always present and may be ignited. Failure to follow these instructions may result in serious personal injury.


WARNING: When handling fuel, always observe fuel handling precautions and be prepared in the event of fuel spillage. Spilled fuel may be ignited by hot vehicle components or other ignition sources. Failure to follow these instructions may result in serious personal injury.

All vehicles

1. Release the fuel system pressure. For additional information, refer to Fuel System Pressure Release in this section.
2. Disconnect the battery ground cable. For additional information, refer to Section 414-01.

3.5L Gasoline Turbocharged Direct Injection (GTDI)

3. Remove the fuel injection pump noise insulator shield.
4. Disconnect the front fuel supply tube-to-fuel injection pump quick connect coupling. For additional information, refer to Quick Connect Coupling in this section.
5. Install the Fuel Pressure T-Adapter 3/8" and Fuel Pressure Test Kit between the fuel tube and the fuel injection pump.



3.7L, 5.0L (4V), 6.2L (2V) engines

- 6. Disconnect the front fuel supply tube-to-fuel rail quick connect coupling. For additional information, refer to Quick Connect Coupling in this section.
- 7. Install the Fuel Pressure T-Adapter 3/8" and Fuel Pressure Test Kit in line between the fuel supply line and fuel rail.

All vehicles

- 8. **NOTE:** *The Fuel Pump (FP) control module electrical connector was previously disconnected to release the fuel system pressure and must be reconnected to test the fuel system pressure.*

Connect the FP control module electrical connector.

- 9. Connect the battery ground cable. For additional information, refer to Section 414-01.

- 10. **NOTE:** *It may take more than one key cycle to pressurize the fuel system.*

Cycle the ignition key and wait 3 seconds to pressurize the fuel system. Check for leaks before starting the engine.

- 11. **NOTE:** *After completing the fuel system pressure test, open the drain valve on the Fuel Pressure Test Kit and release any residual fuel into a suitable container prior to removing the tool.*

Test the fuel system pressure to make sure it is within the specified range. For additional information, refer to Specifications in this section.