

Fuel Tank and Lines



3.5L Gasoline Turbocharged Direct Injection (GTDI)

The fuel system contains the following:

- Fuel tank assembly
- Easy Fill™ (capless) fuel tank filler pipe assembly (which cannot be modified in any way)
- Lifetime fuel filter (serviced as part of the Fuel Pump (FP) module)
- Fuel tube(s)
- Fuel vapor tubes
- Fresh air tube (located on top of the transmission)
- FP module containing:
 - the electric FP, which provides pressurized fuel to the high pressure FP.
 - the fuel level sensor.
 - an inlet filter.
 - a check valve which maintains system pressure after the pump is shut off.
 - a pressure regulator.

The FP is controlled by the PCM which energizes the FP control module. Electrical power to the pump is provided through the FP control module.

3.7L, 5.0L (4V), 6.2L (2V)

The fuel system contains the following:

- Fuel tank assembly
- Easy Fill™ (capless) fuel tank filler pipe assembly (which cannot be modified in any way)
- Lifetime fuel filter (serviced as part of the Fuel Pump (FP) module)
- Fuel tube(s)
- Fuel vapor tubes
- Fresh air tube (located on top of the transmission)
- FP module containing:
 - the electric FP, which provides pressurized fuel to the engine.
 - the fuel level sensor.
 - an inlet filter.
 - a check valve which maintains system pressure after the pump is shut off.
 - a pressure regulator.

The FP is controlled by the PCM which energizes the FP control module. Electrical power to the pump is provided through the FP control module.