

Rocket Elevators

ELEVATE SAFETY, SERVICE AND VALUE

INTERNAL DOCUMENT

Safety Code Quick Reference

Internal document. Last updated April 2026. Contact: Compliance and Regulatory Affairs, Rocket Elevators Ontario Division.

Purpose of This Document

This is a quick-reference guide for the most commonly referenced sections of CSA B44 (Safety Code for Elevators and Escalators) and Ontario Regulation 209/01 under the Technical Standards and Safety Act, 2000. It does not replace the full standard. For specific clause references on compliance orders, contact the Compliance and Regulatory Affairs team, who maintain a clause-by-clause plain-language translation database.

Current edition in force: B44-19 (2019), with periodic amendments incorporated through TSSA directives. When this document references "the code," it means CSA B44-19 as adopted under Ontario Regulation 209/01.

For what inspectors examine against these requirements, see the Inspection Types and What They Check document.

Pit Requirements

The elevator pit is the portion of the hoistway below the lowest landing. It houses buffers, compensating equipment, and provides working clearance for maintenance. Pit conditions are among the most frequently cited areas during TSSA inspections.

Minimum Depth

Pit depth varies by elevator speed and configuration. The code specifies minimum distances to ensure clearance between the car platform and the pit floor when the car rests on fully compressed buffers. For our fleet, most passenger elevators at standard speeds (200 fpm or less) require a minimum pit depth of approximately 4 feet. Higher-speed installations require proportionally deeper pits.

Required Equipment

Every elevator pit must have the following:

1. **Pit stop switch:** A clearly marked, red, single-action switch accessible from the pit access door. When activated, it removes power from the elevator drive and prevents car movement. The switch must be within reach of someone entering the pit, before they step off the ladder.

2. **Pit lighting:** A permanent light fixture with a switch located near the pit access point. Minimum illumination must be sufficient to inspect all pit equipment. Battery-operated or temporary lighting does not satisfy the code requirement.
3. **Pit ladder or steps:** A permanently installed means of entering and exiting the pit. Portable ladders are not acceptable. The ladder must extend from the lowest landing sill to the pit floor.
4. **Sump pump or drain:** If the pit floor is below the water table, or if the building is in an area prone to water infiltration, a sump pump or floor drain connected to the building drainage system is required. Standing water in the pit is a code violation regardless of depth.
5. **Buffers:** Energy-absorbing devices mounted on the pit floor directly below the car and counterweight. Spring buffers are permitted for elevators with rated speeds of 200 fpm or less. Oil buffers are required for speeds exceeding 200 fpm. Buffer type, stroke, and capacity must match the elevator's rated speed and load.

Clearance Requirements

The code requires minimum clearance between the underside of the car platform and any pit equipment when the car is at the lowest point of travel (resting on fully compressed buffers). This ensures a technician in the pit has survivable space if the car descends unexpectedly. The counterweight must also have adequate clearance from pit equipment at its lowest point of travel.

Drainage

Pit floors must prevent water accumulation through a connection to the building drainage system or a sump with an automatic pump. Water in the pit creates electrical hazards, accelerates corrosion, and can compromise buffer function.

Common Violations

- **Standing water:** The most common pit violation across our fleet. Even a small amount triggers a compliance order.
- **Stored materials:** Pits are not storage areas. Any materials, tools, or debris will be cited.
- **Missing or non-functional pit light:** Cited regardless of whether portable lighting is available.
- **Non-functional stop switch:** A high-severity finding.
- **Inadequate clearance:** Modified equipment or debris reducing required clearance under the car.

Machine Room Requirements

The machine room houses the driving machine, controller, governor, and electrical supply. Proper conditions are essential for equipment longevity and safe maintenance access.

Access and Security

The machine room must be a dedicated, enclosed space accessible only to authorized personnel. The door must be self-closing and self-locking, openable from the inside without a key. The room must not serve as a passageway to other building areas.

Ventilation and Temperature

Machine room temperature must not exceed **40°C (104°F)** for standard equipment. Elevated temperatures degrade lubricants, shorten component life, and cause controller malfunctions. Buildings must provide adequate ventilation (natural or mechanical) year-round. In Ontario, summer heat in poorly ventilated rooftop machine rooms is a recurring issue.

Lighting and Fire Rating

Permanent lighting is required with a switch located near the entrance. The machine room enclosure (walls, floor, ceiling, door) must meet fire-resistance rating requirements per the Ontario Building Code. The door must be a listed fire door.

Equipment Clearances

The code specifies minimum working clearances around the controller, driving machine, and other equipment. Controllers require sufficient front clearance for panel access; driving machines require clearance for component removal.

Electrical Disconnect

A **mainline disconnect switch** must be installed in the machine room, in sight of the controller, clearly marked to identify which elevator it serves. In multi-elevator machine rooms, each elevator must have its own labeled disconnect. The disconnect must support lockout/tagout.

Machine-Room-Less (MRL) Installations

For MRL elevators, the controller and driving machine are located in the hoistway rather than a separate room. The code requires:

- Controller cabinets accessible from the landing side without entering the hoistway
- Rescue operation equipment and instructions permanently mounted near the controller
- A means to move the car to a landing for passenger release, accessible from outside the hoistway
- Adequate ventilation for equipment in the hoistway space

Common Violations

- **Machine room used for storage:** The single most frequent machine room violation.
- **Inadequate ventilation:** Particularly in rooftop machine rooms during summer.
- **Blocked access:** Equipment or locked doors preventing timely access.
- **Unmarked or inaccessible disconnect:** Switches not labeled or unreachable.

Hoistway Requirements

The **hoistway** (also called the shaft) is the vertical enclosure in which the elevator car and counterweight travel. Hoistway integrity is fundamental to fire safety, smoke containment, and protection from moving equipment.

Enclosure

The hoistway must be fully enclosed with fire-rated construction from pit floor to top. The fire-resistance rating is determined by the Ontario Building Code based on building height and occupancy. All openings (other than landing doors) must be sealed, and any penetration for wiring, piping, or ventilation must maintain the fire rating. The enclosure must also be **smoke-proof** to prevent smoke passage between floors.

Hoistway Venting

A vent is required at the top of the hoistway to relieve smoke and heat during a fire. The vent must have a minimum area based on the hoistway cross-section. In Ontario, these vents are typically equipped with an automatic opening mechanism tied to the fire alarm system.

Clearances

- **Car to hoistway wall:** Minimum clearance between the car sill/platform and the wall on the non-door side, preventing passengers or objects from being caught.
- **Car top clearance:** Distance between the top of the car and the overhead structure at the highest point of travel. Must accommodate running clearance plus counterweight buffer stroke.
- **Counterweight clearance:** Adequate clearance between counterweight and hoistway walls throughout full travel range.
- **Between adjacent cars:** In multi-elevator hoistways, minimum clearance between cars and adjacent counterweights.

Guarding and Wiring

All moving parts in the hoistway (counterweight sheaves, deflector sheaves, rope change-of-direction points) must be guarded to prevent contact during car-top maintenance. All wiring must be flame-retardant, secured to prevent contact with moving equipment, and routed so junction boxes remain accessible.

Common Violations

- **Openings in hoistway enclosure:** Holes or unsealed penetrations from renovations, utility work, or deterioration.
- **Missing or non-functional vents:** Painted shut, blocked, or automatic mechanism disabled.
- **Inadequate clearances:** Typically found after modifications to car top equipment or hoistway structure.
- **Unauthorized items in hoistway:** Building system pipes or conduits routed through the hoistway without authorization.

Car Requirements

The elevator car is the enclosure that carries passengers or freight. Requirements cover dimensions, ventilation, emergency systems, and accessibility.

Dimensions and Ventilation

Car dimensions must meet minimum requirements based on rated capacity and use. Passenger elevator cars typically require minimum interior heights of 7 feet (2.13 m) with floor areas calculated from rated load. Every

car must have ventilation openings (car top, car walls, or both) with a minimum area based on the car's floor area. Openings must prevent objects from being inserted into the hoistway.

Emergency Lighting

All passenger elevator cars must have **emergency lighting** that activates automatically when normal power is lost:

- Battery backup sufficient to illuminate the car for a minimum of 4 hours
- Minimum illumination of approximately 0.2 foot-candles at floor level
- Automatic activation with no perceptible delay
- Regular testing to verify battery condition and transfer

Car-Top Access and Guardrails

The car top must be accessible for maintenance with the following equipment:

- **Car-top guardrails** around the perimeter, minimum height 42 inches (1,067 mm)
- Car-top stop switch that removes power from the drive
- Inspection station with run/stop and up/down controls at inspection speed
- Adequate car-top lighting

Load Weighing

Load-weighing devices monitor the weight on the car platform. The code requires the elevator to prevent operation when load exceeds rated capacity. These systems also support dispatching logic (bypass floors when nearly full) and leveling accuracy.

Car Operating Panel

The car operating panel must meet requirements for button placement, markings, and accessibility: floor buttons in ascending order, visual registration indicators, emergency controls grouped at the bottom of the panel, tactile markings (raised characters and Braille) on all buttons, and panel height accessible to wheelchair users.

Common Violations

- **Non-functional emergency lighting:** Dead batteries or lights that fail to activate during power loss.
- **Missing car-top guardrails:** Especially on older installations.
- **Blocked ventilation:** Decorative panels or signage covering ventilation openings.
- **Worn or illegible button markings:** Particularly raised characters and Braille on high-traffic panels.

Door and Gate Requirements

Doors are the most common source of violations in our fleet and across the industry. They are the primary barrier preventing falls into the hoistway, and door-related issues account for a disproportionate share of our compliance orders.

Landing Door Requirements

- **Fire rating:** Landing doors must match the fire-protection rating of the hoistway enclosure. Damage to door surfaces, gaps between panels, or missing smoke seals compromise the rating.
- **Minimum opening width:** Passenger elevators typically require a minimum of 36 inches (914 mm) for accessibility.
- **Door panels:** Must be metal or fire-rated material. Glass vision panels must use fire-rated glass in listed frames.

Door Interlocks

The **door interlock** is the single most critical safety device on an elevator. Every landing door has an interlock that provides both electrical and mechanical verification:

1. **Mechanical locking:** The interlock physically locks the landing door closed. The door cannot be opened by hand from the landing side when the car is not at that floor (except with a specialized emergency key).
2. **Electrical verification:** The interlock includes an electrical contact that confirms to the elevator controller that the door is fully closed and locked. The elevator cannot move unless all landing door interlocks in the hoistway report "closed and locked."

If any single interlock in the entire hoistway is not fully engaged, the elevator must not run. This is a non-negotiable safety requirement. Bypassing or jumping out an interlock, even temporarily, is one of the most serious violations possible and will result in an immediate shutdown order from TSSA.

Our compliance team treats interlock-related findings as high-priority regardless of the risk score assigned. Any report of an interlock issue should be escalated immediately.

Closing Force

Power-operated doors must not close with excessive force. The practical limit is approximately **30 lbf** (133 N). Doors that slam shut or close too quickly likely exceed the code limit. Closing force must be re-verified any time door speed has been adjusted.

Reopening Devices

Power-operated doors must have a **reopening device** (door detector or safety edge) that detects obstructions and causes the door to reopen. Common types: mechanical safety edges, infrared light curtains, and electronic proximity sensors. The device must detect objects and people of various sizes, including children and wheelchair users. Nudging operation (slow closing with warning buzzer after a timeout) is permitted, but force during nudging must still be limited.

Door Restrictor

A **door restrictor** prevents the landing door from being opened when the car is not at or near the landing. It limits door opening to a maximum of 4 inches when the car is not in the landing zone. Door restrictors are required on all new installations and are often retrofitted on older elevators as part of compliance upgrades.

Freight Elevator Doors and Gates

Freight elevators commonly use vertical biparting doors, manual swing doors, or gates (mesh or bar-type). All types must have interlocks. Power-operated freight doors have different closing force allowances due to their larger size. All freight elevator doors and gates must display **restricted use signage** and capacity markings.

Common Violations

- **Worn interlocks:** Interlock contacts that do not make reliable electrical contact, or mechanical locking that has worn to the point where the door can be pulled open. This is our highest-priority door violation.
- **Excessive closing force:** Doors adjusted to close too fast or too forcefully. Often the result of adjustments made to address slow door complaints.
- **Non-functional reopening device:** Infrared curtains with blocked or dirty emitters, mechanical edges that stick or do not trigger reliably.
- **Damaged fire rating:** Dented, punctured, or corroded door panels that compromise the fire-protection rating.
- **Missing or damaged smoke seals:** Gaps between door panels or between the door and frame that allow smoke passage.
- **Worn door gibbs and guides:** Causing doors to hang, drag, or not close completely, which prevents the interlock from engaging.

Safety Devices

Safety devices prevent or mitigate free-fall and overspeed conditions. They must function reliably even after years without activation.

Governor

The **overspeed governor** monitors car speed continuously via a governor rope connected to the car. If the car exceeds preset thresholds (typically 115% of rated speed), it activates in two stages:

1. **First stage (overspeed switch):** Triggers an electrical switch that cuts power to the drive motor and applies the machine brake.
2. **Second stage (safety application):** If the car continues to accelerate (indicating mechanical failure such as broken ropes), the governor mechanically applies the car safety device through the governor rope.

Governor settings are specific to each elevator's rated speed and must not be adjusted in the field without engineering authorization. The governor rope is a continuous loop running from the governor (typically in the machine room) down to a tensioning sheave in the pit and back up to the car.

Car Safety Device

The **car safety device** (commonly called "the safeties") is mounted on the car frame beneath the platform. When activated by the governor, it grips the guide rails and stops the car. Two types:

- **Instantaneous safeties:** For elevators at 150 fpm or less. Abrupt stop appropriate for low-speed deceleration forces.
- **Progressive safeties:** Required above 150 fpm. Controlled, increasing pressure on the rails limits forces on passengers and the building.

After a safety application, the car cannot return to service until a qualified technician inspects the safeties, guide rails, and governor. The safeties must be manually reset and the elevator must pass a full safety test.

Buffers

Buffers are energy-absorbing devices in the pit below the car and counterweight, the last line of defense if either travels past normal limits.

- **Spring buffers:** For speeds of 200 fpm or less. Absorb energy through compression; the spring returns the car to its pre-buffer position.
- **Oil buffers:** Required above 200 fpm. Force oil through an orifice for controlled deceleration. Must be checked for proper oil level; after full compression, they must return to fully extended position within approximately 90 seconds.

Testing Requirements

Safety devices must be tested periodically:

- **Governor:** The overspeed governor must be tested **annually** to verify that it trips at the correct speed. This is typically done using a governor testing machine that spins the governor to the tripping speed.
- **Car safety device:** A full-load safety test (where the car is loaded to rated capacity and the safeties are applied) is required at intervals specified by the code. Progressive safeties may be tested at reduced speed under specific conditions.
- **Buffers:** Oil buffer oil level and return time must be checked during periodic inspections. Spring buffers are visually inspected for damage or corrosion.

Rope and Chain Compensation

For taller buildings where the weight of the traveling ropes and cables varies significantly between top and bottom floors, **compensating ropes or chains** are used to maintain consistent loading on the driving machine throughout the range of travel. These are required above certain rise heights and must be properly tensioned and guided in the pit.

Common Violations

- **Governor not tested annually:** One of the most frequently cited safety device violations. If the governor testing tag is missing or outdated, the inspector will note it.
- **Buffer oil low:** Oil buffers that do not have adequate oil to function properly. This is checked visually (oil level gauge) and functionally (return time after compression).
- **Safety device not exercised:** Car safeties that have not been tested or exercised during periodic testing, as documented in the maintenance log.
- **Governor rope wear:** Rope showing signs of excessive wear, broken strands, or improper tension.

Emergency Communication

Every passenger elevator car must have two-way communication to summon help during entrapment or emergency.

Requirements

- **Two-way communication:** A telephone or intercom allowing passengers to speak with and hear a response from a person at a monitored location. One-way alarm bells alone do not satisfy the requirement.
- **24/7 monitoring:** Must connect to a location staffed around the clock. For our fleet, this is our central monitoring service.
- **Power failure operation:** Must function during power failure via dedicated **battery backup** with minimum duration specified by the code.
- **Hands-free operation:** Must be usable without holding a handset (typically a push-to-call button with speaker/microphone).

Accessibility

- Controls mounted at wheelchair-reachable height
- Tactile identification (raised characters or Braille) on controls
- Visual indicator confirming the call was received and help is coming
- Accommodation for passengers who are deaf or hard of hearing (visual display or text-based communication in newer installations)

Testing

Emergency communication testing is part of every periodic maintenance visit. Tests must confirm: the call connects to the monitoring service, two-way voice is clear, battery backup works, and the call-received indicator functions. See the Hydraulic Elevator Maintenance Procedures and Traction Elevator Troubleshooting Guide for testing procedures.

Common Violations

- **Non-functional phone or intercom:** The device does not connect, produces no dial tone, or has no audio
- **Phone not connecting to monitoring service:** The device works but dials a disconnected number, an unstaffed desk, or a general building line that is not monitored 24/7
- **No battery backup:** The communication device loses power when the building power is interrupted
- **Missing tactile identification:** No Braille or raised characters on the emergency communication controls

Fire Service Operations

Fire service operations allow firefighters to use elevators safely during a fire emergency. Every elevator in our fleet (with very limited exceptions) must have fire service operation capability.

Phase I: Fire Recall

Phase I fire recall is automatic. When a smoke detector in the elevator lobby, machine room, or hoistway activates, all elevators in the affected group recall to the **designated landing** (typically the ground floor):

1. Smoke detector activates and sends a signal to the elevator controller
2. All elevators in the group cancel registered car calls

3. Cars travel non-stop to the designated landing (they do not stop for hall calls or car calls)
4. Cars that have their doors open close them immediately and begin recall travel
5. Upon arrival at the designated landing, the doors open and remain open
6. The elevator remains at the designated landing with doors open, out of normal service

If the fire is at the designated landing (ground floor), elevators recall to an **alternate landing** (typically the second floor) to avoid the fire floor. Phase I recall can also be triggered manually from a keyed switch at the designated landing.

Phase II: Firefighter Operation

Phase II firefighter operation gives a firefighter direct manual control of an individual car via a keyed switch inside the car. When activated:

- The car responds only to the car operating panel (not hall calls)
- Doors do not open automatically; the firefighter must hold the door-open button. This prevents doors from opening onto a fire floor unexpectedly.
- The reopening device is disabled
- Call cancel is available
- The car operates in **independent service**, removed from group dispatching

The Phase II key is a standardized key held by fire departments. The key switch must be functional and clearly marked.

Shunt Trip

The **shunt trip** disconnects electrical power to the elevator when a sprinkler head activates in the hoistway or machine room, preventing water from energizing equipment. The timing must be coordinated so the elevator completes Phase I recall before power is cut.

Testing Requirements

- **Phase I recall:** Must be tested **monthly** by building maintenance or our team. The test involves activating the smoke detector (or using a test function) and verifying that the elevator recalls correctly.
- **Phase II operation:** Must be tested during periodic inspections. The test verifies all Phase II functions (manual door control, call cancel, independent operation).
- **Shunt trip:** Must be tested during periodic inspections to verify that the breaker opens when the sprinkler system activates.

Common Violations

- **Phase I recall not tested monthly:** Missing or incomplete monthly test records are a frequent finding. Building staff may not realize they share responsibility for this testing.
- **Phase II key missing:** The key switch in the car is present but the key is missing. While firefighters carry their own keys, the switch mechanism must be functional.
- **Shunt trip not tested:** Shunt trip testing requires coordination between the elevator and fire protection contractors, so it is often deferred and then missed entirely.

- **Incorrect recall floor programming:** The designated and alternate recall floors are not correctly programmed, or the alternate recall logic does not activate when the fire is at the designated floor.

For detailed emergency response procedures involving fire service operations and entrapment, see the Emergency Response Protocols document.

Accessibility Requirements

Accessibility requirements come from both CSA B44 and the Accessibility for Ontarians with Disabilities Act (AODA). Our fleet must comply with both.

Car Operating Panel

- **Height and reach:** Highest button no more than **48 inches** (1,219 mm) above floor for front approach, 54 inches for side approach. Emergency controls grouped at the bottom, below 35 inches.
- **Tactile markings:** All buttons must have raised characters (minimum 0.8 mm raised) and Braille markings on the jamb plate or adjacent to the button (not on the button itself).

Audible and Visual Signals

- **Floor announcements:** Verbal announcements required in buildings with more than two floors. Tone systems (one tone for up, two for down) are permitted for simpler installations.
- **Visual floor indicators:** Display inside the car showing current floor, visible from the rear.
- **Hall lanterns:** Visual and audible signal at each landing indicating car arrival and direction. Must sound early enough for a person with a visual impairment to position themselves.

Door Timing

The code specifies a **minimum door hold time** based on the distance from the hall call button to the door opening center, assuming 1.5 feet per second walking speed. For standard installations, this results in approximately 5 seconds minimum. A "door hold" button extends the time further.

Hall Buttons

Hall call buttons must be mounted between 35 and 48 inches above the floor, with visual registration indicators and tactile/Braille markings.

LULA Elevator Requirements

Limited Use/Limited Application (LULA) elevators are smaller, slower elevators for buildings where a full-size elevator is not practical:

- Maximum rated speed of 30 fpm
- Minimum car dimensions of 36 by 48 inches for wheelchair accommodation
- Simplified safety devices appropriate for lower speed
- Maximum of two or three landings served
- Must still meet all accessibility requirements for controls, markings, and communication

Common Violations

- **Missing or worn Braille markings:** Especially on older installations.
- **Audible announcements not functioning:** Speakers disconnected or disabled due to occupant complaints.
- **Insufficient door hold time:** Doors programmed to close too quickly.
- **Hall lantern not visible or audible:** Burned out, obscured, or at incorrect heights.

Key Differences by Device Type

Several device types in our fleet have code requirements that differ from standard passenger elevators.

REQUIREMENT AREA	PASSENGER ELEVATOR	FREIGHT ELEVATOR	LULA ELEVATOR	OBSERVATION ELEVATOR	SIDEWALK ELEVATOR
Door/gate type	Power-operated sliding	May use vertical biparting doors; gates permitted	Power-operated or manual	Power-operated sliding	Hatch operated cover
Capacity marking	Posted in car	Posted in car; restricted use signage required on every landing door	Posted in car	Posted in car	Posted in car
Speed limits	Per design (up to 700+ fpm)	Per design	30 fpm maximum	Per design	Per design (low)
Safety devices	Full governor, safeties, buffers	Full governor, safeties, buffers	Simplified; may use plunger gripper for hydraulic	Full governor, safeties, buffers	Varies by configuration
Car enclosure	Fully enclosed	May have open sides with gates	Fully enclosed	Glass panels permitted (must meet impact requirements)	Typical passenger only
Fire service	Phase I and Phase II required	Phase I and Phase II required	Phase I required; Phase II may not be required	Phase I and Phase II required	May be dependent on installation
Accessibility	Full requirements	Limited (freight elevators are not intended for public passenger use)	Full requirements (accessibility is their primary purpose)	Full requirements	Typical passenger
Public access	Yes	Restricted to authorized operators	Yes (limited traffic)	Yes	Public exposure, barricade, warning during

Freight Elevator Specifics

Freight elevators (including Freight Elevator-E and Freight Elevator-P variants) require restricted use signage on every landing door, capacity markings showing both rated load and class of loading (Class A, B, C1, C2, or C3), interlocks on all gates identical to passenger door interlocks, and platform guards where gates are used instead of solid doors.

Observation Elevator Specifics

Glass panels must meet **impact resistance** requirements (laminated or tempered safety glass) and be retained in frames that prevent dislodging. If the hoistway is exposed to the exterior, weather protection requirements apply to all electrical components.

Sidewalk Elevator Specifics

Sidewalk elevators open at street level through a hatch. The hatch must be flush with the sidewalk, slip-resistant, and capable of supporting pedestrian and vehicular traffic. Barricades and warning signs are required when the hatch is open. All exposed components must be weather-rated, and the pit requires robust drainage against water infiltration.

How to Read a Compliance Order

When TSSA issues a compliance order following an inspection, it references specific code clauses and assigns a risk score. A typical order includes:

- **Device ID:** The specific elevator the order applies to
- **Inspection type:** The inspection that generated the finding (e.g., ED-Periodic Inspection, ED-Followup Inspection)
- **Clause reference:** A specific CSA B44 clause (e.g., "CSA B44-19 Clause 2.26.1.3"). This identifies the exact code requirement that is not being met.
- **Description:** A brief description of the violation, sometimes in technical language
- **Risk score:** A numerical score from 1 to 10 indicating the severity of the finding
- **Compliance deadline:** The date by which the violation must be corrected

Risk Score Interpretation

SCORE RANGE	SEVERITY	TYPICAL RESPONSE
1-3	Low	Schedule correction during next planned maintenance visit. These are typically minor issues (missing signage, cosmetic damage to non-safety components, record-keeping gaps).
4-6	Medium	Prioritize correction within the compliance deadline. These are functional issues that do not present an immediate danger but must be addressed (worn door components, accessibility deficiencies, ventilation concerns).
7-9	High	Expedite correction. Assign a technician promptly. These are significant safety concerns (non-functional safety devices, interlock issues, fire service operation failures). A score of 7 or above typically means the device is at elevated risk of a shutdown if not corrected.
10	Critical	Almost always accompanied by an immediate shutdown order . The elevator is taken out of service until the violation is corrected and re-inspected. These are conditions presenting an imminent hazard (bypassed interlocks, non-functional safeties, structural failures).

Looking Up a Clause Reference

1. Note the clause number (e.g., "CSA B44-19 Clause 2.26.1.3")
2. Check our internal **Compliance Clause Database** (maintained by Compliance and Regulatory Affairs). It contains plain-language translations, photos of typical violations, and recommended corrective actions.
3. If the clause is not in the database, contact the Compliance team directly for a plain-language explanation.
4. Do not interpret unfamiliar clauses on your own. The full standard is dense and highly cross-referenced; a single clause often depends on other clauses, exceptions, and appendix notes. The Compliance team's translations capture the operational intent so field teams can act correctly.

For the full compliance order handling process, including response timelines and escalation procedures, refer to the Operations Handbook.