

Rocket Elevators

ELEVATE SAFETY, SERVICE AND VALUE

INTERNAL DOCUMENT

Emergency Response Protocols

Internal document. Last updated April 2026. Contact: Field Operations Manager, Rocket Elevators Ontario Division.

This document provides detailed emergency response procedures for field technicians and operations managers across our Ontario fleet. It covers the most common emergency scenarios, step-by-step response actions, and the communication and documentation obligations that follow.

Our operations handbook defines the high-level incident response procedure (9 steps) and the TSSA Shutdown Response Procedure. This document goes deeper into specific scenarios with detailed procedures that the handbook does not cover. See the operations handbook for the full TSSA Shutdown Response Procedure and incident reporting requirements. This document assumes familiarity with those processes.

These procedures apply to the approximately 40,000 elevating devices we manage across Ontario. Our 14 field technicians across 6 zones, with rotating on-call duty, are the first responders. On-call response time is 90 minutes for safety-critical issues and 4 hours for non-critical after-hours calls. Standard hours are 7:00 AM to 6:00 PM, Monday through Friday; emergency calls outside those hours route to the zone on-call technician.

General Emergency Principles

The principles below apply to every emergency scenario. Internalize them before reading the scenario-specific procedures.

Priority Order

Safety of people comes first, the device second, property third. If protecting equipment or property conflicts with protecting people, protect people. A damaged elevator can be repaired.

Know Your Limits

Never attempt a rescue you are not trained and authorized to perform. Our technicians are trained for specific rescue procedures (passenger entrapment in traction and hydraulic elevators). Anything beyond that training (confined space rescue, working near exposed high voltage, structural collapse) requires specialized emergency services. Calling 911 is never the wrong call when safety is in doubt.

Documentation

Document everything. From the moment you arrive, record the time, actions taken, people involved, and conditions observed. Write it down, take photos, note names and contact information. Your documentation may be reviewed by TSSA investigators, insurance adjusters, or legal counsel. Incomplete records create liability.

Communication

Communicate clearly and to the right people. During an emergency, you are communicating with building staff, passengers (if trapped), your operations manager, and potentially emergency services. Building staff need to know what is happening and what to do (usually: keep people away, provide access, wait). Passengers need reassurance and clear instructions. Your operations manager needs facts: what happened, what you have done, what you need.

Post-Emergency Inspection

After any emergency, the device must be inspected before returning to service. No exceptions. A qualified technician or contractor must inspect and confirm safety before passengers use the device again. At minimum this includes a full ride test, door operation check, and safety device verification.

Emergency Reference Card

Every machine room should have our emergency reference card posted. The card summarizes key emergency contacts, basic procedures, and device-specific information (device type, contractor, rated capacity). If you visit a machine room and the card is missing or outdated, replace it. Blank cards are available from the zone office.

Passenger Entrapment

Passenger entrapment is the most common elevator emergency we respond to. A car stops between floors or at a floor with the doors unable to open, trapping passengers inside. Most entrapments are not physically dangerous, but they are frightening, and our response directly shapes the building's perception of our service.

Assessment

When you receive an entrapment call, gather information before arriving:

1. **Are passengers injured?** If anyone reports an injury or medical condition, call 911 immediately.
2. **How many passengers are trapped?**
3. **Does anyone have a medical condition?** Claustrophobia, heart conditions, diabetic episodes, pregnancy, or mobility limitations increase urgency.
4. **Is the car between floors or at a floor?** This determines the rescue approach.
5. **What type of elevator?** Traction, hydraulic, or MRL? Check the device record if needed.

Communicating with Trapped Passengers

Once you are on site (or via the emergency phone), communicate with the passengers directly:

- **Stay calm.** Your tone sets their expectations.
- **Identify yourself.** Tell them your name, that you are from Rocket Elevators, and that you are there to get them out safely.
- **Tell them help is on the way and the elevator is safe.** The car is designed to stop safely. The brakes are holding.

- **Do NOT tell passengers to try to force the doors open.** Forced doors create fall hazards if the car is between floors. Passengers have been seriously injured attempting to climb out of a car not at a landing.
- **Do NOT tell passengers to try to climb out through the ceiling hatch.** The ceiling hatch is for firefighter access only. Passengers on top of the car are exposed to the hoistway, counterweight, and moving equipment.
- **Give them a realistic timeline.** If rescue will take 20 minutes, say 20 minutes. Do not underestimate; broken expectations increase anxiety.

Rescue Procedure for Traction Elevators

Traction elevators use steel ropes and a drive machine (motor, brake, and sheave) to move the car. The rescue procedure depends on the machine type: geared, gearless, or machine-room-less (MRL).

Before starting any rescue procedure:

1. Go to the machine room. Confirm power is off by opening the main disconnect switch and locking it in the off position.
2. Determine car position using the floor indicator in the machine room, hoistway markings, or the building's security camera.

If the car is within the landing zone (near a floor):

1. Release the landing door using the emergency release key (hoistway door key) at the floor nearest to the car.
2. Once the landing door is released, the car door will also release (they are mechanically coupled when the car is in the landing zone).
3. Open both doors carefully. Confirm the car floor is approximately level with the landing (within 150 mm or about 6 inches).
4. Assist passengers out. Warn them of any step-up or step-down.

If the car is between floors (manual lowering required):

This procedure requires training. Do not attempt it if you have not been trained on the specific drive type.

1. **For geared traction machines:** Release the brake using the brake release lever. Use the handwheel to lower the car slowly to the nearest floor. The counterweight is heavier than an empty car, so the car will want to rise; control descent with the handwheel. If the car is loaded, it may descend on its own; control the speed. Lower in small increments. Once at a landing, re-engage the brake and release doors as described above.
2. **For gearless traction machines:** Manual lowering requires specialized equipment or the building's emergency power system. Our technicians are not equipped to manually lower gearless machines. Contact ThyssenKrupp for emergency rescue assistance.
3. **For MRL (machine-room-less) elevators:** Locate the rescue device at the controller cabinet (typically on the top floor or an adjacent room). The rescue device allows manual lowering via a hand crank or battery-powered drive. Follow the manufacturer-specific instructions posted at the controller cabinet; these vary by manufacturer and model.

After rescue:

1. Secure the device: leave the main disconnect off, place an "Out of Service" tag on the car operating panel and at each landing.
2. Update device status in our system and report to your zone operations manager.
3. Arrange for diagnosis of the cause before the device returns to service.

Rescue Procedure for Hydraulic Elevators

Hydraulic elevators can be lowered to the lowest floor using the manual lowering valve, making rescue simpler than traction systems.

1. Go to the machine room. Confirm you have identified the correct elevator's equipment (in multi-elevator buildings, machine rooms may serve more than one unit).
2. Locate the **manual lowering valve** on the hydraulic control manifold (typically painted red or labeled). This valve allows fluid to drain from the cylinder back to the reservoir, lowering the car under gravity.
3. **Open the valve slowly.** Control the descent speed by adjusting how far the valve is open. Do not open fully; rapid descent is disorienting and can damage the system.
4. Once the car reaches the lowest floor and is level with the landing, release the doors using the emergency release key.
5. Assist passengers out.
6. **Close the lowering valve** fully. Secure the device, update status, and report as described above.

Important notes: - Hydraulic elevators can only be lowered, not raised, without power. If the car is at the lowest floor with doors stuck, the issue is likely door-related. Investigate the door interlock. - If the valve does not work (car does not move when opened), the issue may be a blocked valve or empty cylinder. Do not force the valve. Call KONE.

When to Call the Fire Department

In most entrapments, we perform the rescue ourselves. Call the fire department (911) if:

- **A passenger reports a medical emergency** (chest pain, difficulty breathing, diabetic episode, panic attack with hyperventilation, or any condition requiring medical attention).
- **The car position makes manual rescue unsafe** (severe misalignment, structural damage, or signs of fire/smoke in the hoistway).
- **You cannot communicate with the passengers.** If the emergency phone is not working and you cannot establish contact through the doors, treat this as a potential medical emergency.
- **A freight elevator with a heavy load is involved.** Heavy loads change the dynamics of manual lowering.
- **The situation is beyond your training or equipment.**

Working with fire departments: Fire departments are trained in elevator rescue but their methods can damage equipment. If you arrive before or with them, brief them on the device type, car position, and machine room location to prevent unnecessary damage.

Entrapment Prevention

Most entrapments are preventable. The three most common causes are:

- **Power failure.** Buildings with emergency generators should have elevator recall programmed so elevators return to the lobby when generator power activates. Verify this programming during annual checks. For buildings without generators, battery lowering systems serve the same function where installed.
- **Door interlock issues.** A faulty door interlock prevents doors from closing or opening, stopping the elevator. Regular maintenance of door contacts, rollers, gibbs, and interlocks (part of our monthly checks) reduces interlock-related entrapments significantly.
- **Controller faults.** Software glitches, failed relays, or communication errors can stop the elevator mid-travel. Regular controller diagnostics by the contractor help identify failing components.

Always document the cause of an entrapment so we can track patterns across the fleet. If a building or device type shows a pattern, escalate to the Field Operations Manager.

Flooding Response

Flooding is a recurring problem across our fleet, particularly in older buildings and during Ontario's spring thaw and heavy summer storms. Water in an elevator pit, hoistway, or machine room creates immediate electrical hazards and can cause extensive long-term damage.

Pit Flooding

Pit flooding is the most common type. Water enters from broken pipes, failed sump pumps, rising water tables, or external surface water.

Immediate risk assessment:

1. **Do NOT enter a flooded pit.** Assume the water is electrically energized until confirmed safe. Elevator pits contain electrical components (pit stop switch, buffer contacts, traveling cable terminations) that can energize the water if insulation is compromised.
2. **Assess the water level from above.** If water is at or above the buffer springs, shut down the device immediately.
3. **Shut down from the main disconnect** in the machine room. Do not rely on the pit stop switch; it may be submerged and compromised.

Identifying and stopping the water source:

1. Contact the building owner or manager immediately. Common sources: broken domestic water pipes, failed fire suppression piping, blocked floor drains, rising groundwater, and external water from construction or landscaping.
2. Stopping the source is the building owner's responsibility, but communicate the urgency clearly.

Water removal and assessment:

1. Once the source is stopped, activate the pit sump pump or arrange for a portable pump.
2. Allow the pit to dry (24 to 72 hours depending on volume and ventilation).
3. **Post-flood inspection is mandatory.** The device must not return to service until a technician has inspected:

4. All electrical components in the pit for water damage, corrosion, or short circuits
5. The buffer assembly for rust, seized components, or misalignment
6. The traveling cable and connections at the pit termination
7. The pit structure for erosion, cracking, or settling
8. For hydraulic elevators: the cylinder base and visible jack portions for water intrusion
9. Document everything with photographs. Record estimated water level at peak, the source (if identified), and all damage observed.

Hoistway Flooding

Hoistway flooding from above is less common than pit flooding but more dangerous because water can reach the machine room, controller, and car-top equipment. Common causes include broken sprinkler heads, burst pipes in adjacent floors, roof leaks channeling water down the hoistway, and external intrusion at the hoistway top.

Response:

1. **Shunt trip** should activate automatically if sprinklers in the hoistway or machine room fire, cutting power to the elevator. Verify activation by checking the main disconnect status.
2. **If shunt trip did not activate** (or the building lacks one), shut down immediately from the main disconnect. Do not ride or operate the elevator while water is entering the hoistway.
3. Contact the building owner/manager to stop the water source.
4. **Water running through the hoistway can damage:** traveling cables (shorts from insulation penetration), door operators and contacts at every floor, car-top equipment (door operator, inspection station, light fixtures), the controller and drive, and guide rail brackets (long-term corrosion).
5. Significant drying and comprehensive inspection are required before return to service. KONE and ThyssenKrupp have water damage assessment protocols; contact the appropriate contractor.
6. **Shunt trip reset** (if activated): verify the machine room and hoistway are dry before resetting. Resetting into a wet environment can cause immediate electrical failure.

Fire Emergency

Our role during a building fire is limited and specific. We do not fight fires, and we do not operate elevators during fire conditions. We provide information and, after the building is cleared, we inspect and restore elevator service. See the Safety Code Quick Reference for fire service operation requirements (Phase I and Phase II).

Fire Service Operation

Modern elevators in Ontario are required to have fire service operation, a two-phase system mandated by CSA B44 and the Ontario Building Code.

Phase I (Fire Recall):

Phase I is activated by a smoke detector in the elevator lobby or machine room:

1. All elevators recall to the designated floor (usually ground floor).

2. Cars traveling away from the recall floor reverse direction.
3. Cars stop at the recall floor without opening at intermediate floors; doors open and remain open.
4. The elevator does not respond to hall or car calls.

If the fire is on the ground floor, elevators recall to an alternate designated floor (determined during commissioning, posted in the machine room).

Phase II (Firefighter Operation):

A firefighter inserts a key into the Phase II switch on the car operating panel:

1. The firefighter has full manual control. Doors do not open automatically.
2. The car responds only to car calls, not hall calls.
3. The firefighter controls all movement and door operation.

Our role during a fire:

- **We do NOT operate the elevator.** Fire service operations are controlled by the fire department exclusively.
- **We provide information if asked:** device type, number of elevators, machine room location, whether the building has shunt trip, and any known device issues.
- **We do NOT enter the building** during an active fire unless directed by the fire department.
- If on site when a fire alarm activates, evacuate using stairs and make yourself available to the fire department outside.

Post-Fire Assessment

After the fire department clears the building, a thorough inspection is required before any elevator returns to service.

Inspection checklist:

1. **Smoke damage.** Check electrical components in the machine room, controller, and car-top for soot deposits. Soot is conductive and can cause short circuits. Significant accumulation requires professional cleaning or component replacement.
2. **Heat damage.** Check wiring insulation, plastic components, and rubber seals for melting, discoloration, or brittleness. Check traveling cables for insulation breakdown.
3. **Water damage.** Firefighting introduces significant water. Check the machine room, controller cabinet, car-top, and pit for standing water or water exposure evidence. See the Hoistway Flooding section for details.
4. **Structural damage.** Check guide rails, brackets, and car frame for heat-related warping. Check landing doors and sills.
5. **Shunt trip reset.** Verify the machine room and hoistway are completely dry before resetting. Test the shunt trip after reset.
6. **Phase I recall test.** Test the recall system by activating the test mode on the smoke detector (coordinate with building fire safety). Confirm all elevators recall correctly.
7. **Document all findings** with photographs and written notes. File with insurance if applicable.

Engage the appropriate contractor (ThyssenKrupp for traction/MRL, KONE for hydraulic, Schindler for specialty/observation) for any damage beyond surface-level soot or minor water exposure.

Power Failure Response

Power failures affect our fleet regularly, from localized transformer failures to area-wide grid events. The primary concern is always: are passengers trapped?

Immediate Response

1. **Determine scope.** Single elevator (likely device-specific), single building (building electrical or utility issue), or area-wide outage (may affect multiple buildings in your zone simultaneously).
2. **Check for entrapments.** Contact building staff at each affected building. If passengers are trapped, prioritize rescues using the Entrapment procedures in this document.
3. **Verify emergency systems.** Battery-powered emergency lighting should activate in the car (4-hour minimum per CSA B44). The emergency phone should remain functional on battery backup. Non-functional emergency systems indicate battery maintenance issues; note for follow-up.
4. **Assess building backup power.** Generator-connected elevators should recall to the lobby automatically when generator power activates. Not all buildings connect their elevators to the generator, and not all generators are sized to run all elevators.

Battery Lowering Systems

Some modern elevators have battery lowering systems that automatically detect power loss, lower the car to the nearest floor, and open the doors. During annual inspections, verify the system functions by simulating a power loss (coordinate with the building owner; car must be empty).

Older installations and hydraulic elevators (which use gravity descent via the manual lowering valve) typically lack this feature. Elevators without battery lowering or generator backup require manual rescue if passengers are trapped.

After Power Restoration

Power restoration surges can damage controllers, drive systems, and safety circuits.

1. **Elevators may not resume automatically.** Many controllers require a manual reset from the machine room. The reset sequence varies by controller type and manufacturer.
2. **Check each elevator individually** before releasing to the public. Verify: smooth travel to all floors, correct door operation at every landing, accurate floor indicators, proper response to hall and car calls, and functioning safety devices (door reversal, overload detection).
3. **Inspect for surge damage.** If a controller does not respond to reset, displays errors, or behaves erratically, take the device out of service and contact the appropriate contractor.
4. **Document the outage:** time of power loss, time of restoration, which elevators were affected, any entrapments, and any damage discovered.

Seismic Event Response

Ontario has low seismic risk compared to western Canada, but it is not zero. The Ottawa and St. Lawrence River regions experience occasional minor earthquakes, and CSA B44 includes seismic provisions for elevator installations.

Automatic Response

Elevators with seismic sensors automatically shut down when shaking exceeds a calibrated threshold: the car stops at the nearest floor, doors open, and the elevator goes out of service. Manual reset in the machine room is required before return to service. Older installations and low-rise buildings may not have seismic sensors.

Manual Response

After any earthquake felt in a building with our elevators, regardless of sensor activation:

1. **Shut down all elevators in the affected area.** Do not wait for damage reports; earthquakes cause hidden damage.
2. **Check for entrapments.** Elevators in motion during the earthquake may have trapped passengers.
3. **Do not operate any elevator until it has been inspected.**

Post-Seismic Inspection

The primary risk is **counterweight derailment**: the counterweight oscillates during shaking and can jump off its guide rails, jamming in the hoistway, damaging the car, or falling.

Post-seismic inspection must check:

1. **Counterweight position and rail engagement.** Confirm the counterweight is seated on both guide rails with no lateral displacement.
2. **Guide rail alignment.** Check car and counterweight rails for bending, bracket loosening, or misalignment.
3. **Rope condition.** Inspect hoist ropes and governor ropes for displacement from sheave grooves, kinking, or contact damage. Ropes that have jumped off sheaves require contractor re-seating.
4. **Car frame alignment.** Check for twisting, hoistway contact, or displaced components.
5. **Machine room equipment.** Check the drive machine, controller, and governor for displacement or damage.

Contact the appropriate contractor for a formal post-seismic inspection on any device where damage is suspected. The elevator must not return to service until the contractor confirms it is safe.

Equipment Failure Scenarios

This section covers the most serious equipment failure scenarios and the correct response for each. See the Traction Elevator Troubleshooting Guide for diagnostic procedures and Common Failure Modes by Elevator Type for failure patterns and fleet trends.

Broken or Damaged Hoist Rope

Most traction elevators use multiple steel ropes (typically 3 to 8) in parallel, so a single rope failure does not cause the car to fall. However, any rope failure is a critical safety event.

If a hoist rope breaks during operation:

1. The governor should activate the car safety device, gripping the guide rails and stopping the car.
2. Treat this as an entrapment with a critical safety failure. Rescue passengers, then secure the device.

3. **The device must not operate again until all ropes have been inspected and damaged ropes replaced.** All rope replacement is contractor work (ThyssenKrupp for traction systems).
4. Report to TSSA within 24 hours. A broken hoist rope is reportable regardless of injury.

If rope damage is discovered during inspection:

1. **Shut down the device immediately**, regardless of how many ropes remain intact. Broken wires, corrosion, or deformation in one rope indicates conditions that may affect others.
2. Contact ThyssenKrupp for a full rope inspection and replacement assessment.
3. Update the device status to "Out of Service" with the reason documented.

Never operate an elevator with a known damaged rope, even if "most ropes are fine." Safety margins assume all ropes are in good condition. Operating with damaged ropes invalidates those margins.

Hydraulic System Failure

Hydraulic failures range from minor leaks to catastrophic events. The most serious is **rapid oil loss (blowout)**, where the car descends uncontrollably. Safety devices (check valves, restrictor valves) should limit descent speed, but effectiveness depends on the specific devices installed.

Response to a hydraulic failure:

1. **Approach with caution.** Oil may be on the floor (slip hazard). Oil under pressure can spray from failed fittings (burn and injection hazard; high-pressure oil can penetrate skin).
2. **Shut off the pump motor** if still running. A running pump with a failed line continues pumping fluid onto the floor and can overheat.
3. **Check for entrapments.** Passengers may be trapped, potentially at the lowest floor or in the pit area.
4. **Contain the oil spill.** Hydraulic oil is a regulated waste and environmental contamination risk. Use absorbent materials. Prevent oil from reaching floor drains (may connect to the storm sewer).
5. Contact KONE immediately. KONE handles all hydraulic system repairs.
6. Report to TSSA if the failure caused injury or uncontrolled descent.
7. Document everything: photographs of the failure point, oil spread, damage, and conditions observed.

See the Hydraulic Elevator Maintenance Procedures for hydraulic system details.

Governor Activation

The overspeed governor monitors car speed. If the car exceeds a preset speed (typically 115% of rated speed), the governor activates the car safety, which clamps onto the guide rails and stops the car.

When the governor activates:

1. The car is stopped on the rails. The safety device will not release without manual intervention.
2. Perform passenger rescue as needed.
3. **Do NOT attempt to reset the safety device.** The overspeed cause must be determined first; resetting without addressing the cause could allow the dangerous condition to recur.
4. Common causes: brake failure (car accelerates under gravity), drive malfunction (controller or motor drives car too fast), governor rope tangled or caught (false activation).
5. Contact ThyssenKrupp (traction systems) or the appropriate contractor.

6. Report to TSSA. An overspeed event is reportable regardless of whether passengers were present.

Unintended Car Movement

Unintended car movement (car moves with doors open, or moves without a registered call) is among the most dangerous conditions in elevator safety. This failure mode has been involved in fatal incidents.

Response:

1. **Immediately remove the device from service.** Open the main disconnect in the machine room.
2. **Do NOT attempt to diagnose the cause.** This almost always indicates a critical failure in the door interlock circuit, controller, or drive system. Misdiagnosis could lead to recurrence.
3. Contact the appropriate contractor immediately. This is a priority-one service call.
4. **Report to TSSA within 24 hours.** Unintended car movement is reportable even without injury.
5. The device must not return to service until the contractor has identified and remediated the root cause.
6. Document thoroughly: what the car did, door position, passengers present, witness accounts, and conditions observed.

Communication During Emergencies

Clear communication during emergencies protects people, preserves information, and limits our liability.

Internal Notification Chain

1. **Field technician** responds and manages the on-site situation.
2. **Zone operations manager** is notified once the technician has assessed the situation. Coordinates resources and building owner communication.
3. **Compliance** is notified if the incident is TSSA-reportable (injury, uncontrolled movement, safety device activation, equipment failure affecting safety). Manages reporting timeline and documentation.
4. **Operations Director** is notified for serious incidents: injury, potential media attention, multiple devices or buildings affected, or 911 response.

Building Communication

The building owner or manager is our primary site contact. Keep them informed of: what has happened (factual, no speculation), what we are doing, what we need from them (access, keys, keeping people away), and what to expect next (timeline, out-of-service duration, contractor involvement). Coordinate with building security staff as needed.

External Communication

- **911:** Fire, medical emergencies, or immediate danger to life.
- **TSSA:** Incident reporting per the operations handbook (24 hours for injury, 72 hours for other reportable incidents).
- **Media:** **Do NOT communicate with media.** Refer all inquiries to the Operations Director. A single unplanned statement can create significant legal and reputational problems.

Documentation During Emergencies

Start a written record as soon as the emergency is under control. Notes must be accurate and timestamped:

- Time of the initial call and your arrival
- Conditions observed on arrival
- Actions taken, in chronological order
- People involved: passengers, building staff, emergency personnel, other technicians
- Witness or passenger statements
- Photographs and their timestamps
- Time the situation was resolved
- Current device status

These notes form the basis of the formal incident report due within 48 hours.

Post-Emergency Requirements

Every emergency involving device malfunction triggers a defined set of post-emergency actions. These are not optional. Incomplete follow-through has been flagged in TSSA audits.

Device Securing and Assessment

1. **Secure the device out of service:** main disconnect off, device tagged out, car operating panel and landing indicators showing out of service.
2. **Technician or contractor assessment** before any discussion of return to service.
3. **Cause must be remediated.** Identifying the cause is not sufficient; repair must be completed.
4. **Return-to-service inspection** must confirm safe operation: full ride test, door operation at all floors, and safety device verification.

TSSA Reporting

See the operations handbook for full TSSA incident reporting requirements. Summary:

- **24 hours** for any incident involving injury
- **72 hours** for other reportable incidents (uncontrolled movement, safety device activation, equipment failure affecting safety, entrapment exceeding 1 hour)

Compliance manages the reporting process; the field technician provides the factual basis from on-scene documentation.

Internal Incident Report

Complete within **48 hours**. Include: event timeline, actions by our technician and others, root cause (if known; note if investigation is ongoing), photographs, witness statements, current device status, and recommended follow-up actions.

System Updates and Fleet Review

1. **Update the device record.** The emergency, cause, and remediation must all be documented in the device history.
2. **Review whether similar devices are at risk.** If the failure was caused by a component defect, age-related wear, or environmental condition, other devices of the same type, age, or location may face similar risk. Consult with the contractor and Field Operations Manager on whether a broader inspection is warranted.

This review feeds into our risk prediction models. A hydraulic blowout from cylinder corrosion should prompt review of all in-ground cylinders of similar age and soil conditions.

Emergency Contact Information

Actual phone numbers are posted in each zone office and in each machine room. If you find emergency contact information missing from a machine room, report it and post a current copy before leaving.

CONTACT	PURPOSE	NUMBER
Zone on-call technician	First response for all after-hours calls	[Zone on-call number]
ThyssenKrupp emergency service	Traction and MRL elevator emergencies, 24/7	[ThyssenKrupp 24/7 line]
KONE emergency service	Hydraulic elevator and modernization emergencies, 24/7	[KONE 24/7 line]
Schindler emergency service	Specialty and observation elevator emergencies, 24/7	[Schindler 24/7 line]
Zone Operations Manager	Escalation, coordination, building owner communication	[Zone manager number]
Operations Director	Serious incidents, media inquiries, multi-site events	[Operations Director number]
Compliance (TSSA reporting)	Incident reporting within regulatory timelines	[Compliance number]
TSSA incident reporting	Regulatory incident reports (injury: 24 hrs; other: 72 hrs)	[TSSA reporting number]
911	Fire, medical emergency, entrapment with medical emergency	911

When in doubt, start with your zone operations manager. The only exception is 911: if there is an immediate threat to life, call 911 first.

This document should be reviewed annually and updated whenever procedures change, new equipment types enter the fleet, or TSSA requirements are updated. Suggested changes should be submitted to the Field Operations Manager.