

XeloBridge Firmware Requirements

Controller Display:

1. Network Mode
2. GSM Network Strength
3. Power Mode
4. Battery Charge Level
5. Time Stamp
6. Connected Dispenser
7. Online/offline Dispenser
8. GSM Data Expire Limit alert
9. Show all kinds of error code.

Firmware Controller webpage:

1. Admin Login
2. Add new dispenser.
3. Show the total number of dispensers
4. Show total sales per dispenser.
5. Live Reading per dispenser.
6. Dispenser live status.
7. Controller status.
8. Power mode status
9. Data alert status
10. Data in queue.
11. Individual Transaction Records per dispenser.

Controller Requirements:

1. Get sales data from the dispenser (amount, liter)
2. Send the fetched data to the server. Data format: timestamp,amount,liter,nozzleNumber}.
3. Set and get unit price
4. Get nozzle lifetime reading
5. Individual Transaction Records (maybe 2000 data can be stored in the dispenser. Command: 4.11, 4.12)
6. Store sales data on network issues.
7. Upload sales data automatically when network restored.
8. Upto 16 dispensers can be controlled with one single controller.