

when power on

1. check status of nozzles

send: A5 01 03 00 01 35

reply: A5 01 03 01 06 72

//06 stand for nozzle offline, it need do as below:

2. check the filling data when offline

send: A5 01 03 80 0E 5B

reply: A5 01 03 0E 00 00 00 00 00 00 00 00 00 00 00 00 04 8C

//00 04 stand for 4 filling records when offline

3. POS check filling data (filling record =0, then neglect and follow item 4)

//check the 4th filling record when offline

send: A5 01 0C 00 04 08 26

reply: A5 01 03 08 00 04 87 80 00 00 02 43 A6

//check the 3rd filling record when offline

send: A5 01 0C 00 03 08 48 //nozzle 1

reply: A5 01 03 08 00 12 00 00 00 00 06 00 E8

//check the 2nd filling record when offline

send: A5 01 0C 00 02 08 8C //nozzle 1

reply: A5 01 03 08 00 01 49 90 00 00 00 74 33

//check the 1st filling record when offline

send: A5 01 0C 00 01 08 D9 //nozzle 1

reply: A5 01 03 08 00 03 59 10 00 00 01 79 E0

4. check status of nozzles

send: A5 01 03 00 01 35

reply: A5 01 03 01 00 AF

//00 stand for nozzle idle

remark: POS need check status of nozzles with interval 100ms

上电流程

1. 查询加油状态

send: A5 01 03 00 01 35

respond: A5 01 03 01 06 72

//06 表示加油机是离线状态，需要重新和 POS 系统握手联机。

//加油机和 POS 系统握手联机步骤如下：

2. 查询离线时加油数据次数

send: A5 01 03 80 0E 5B

respond: A5 01 03 0E 00 00 00 00 00 00 00 00 00 00 00 00 04 8C

//00 04 表示有 4 条离线时加油数据

3. POS 查询加油数据（当查询离线时加油数据次数为 0 时，则跳过）

//查询第 4 条离线加油数据

send: A5 01 0C 00 04 08 26
respond: A5 01 03 08 00 04 87 80 00 00 02 43 A6
//查询第 3 条离线加油数据
send: A5 01 0C 00 03 08 48 //nozzle 1
respond: A5 01 03 08 00 12 00 00 00 00 06 00 E8
//查询第 2 条离线加油数据
send: A5 01 0C 00 02 08 8C //nozzle 1
respond: A5 01 03 08 00 01 49 90 00 00 00 74 33
//查询第 1 条离线加油数据
send: A5 01 0C 00 01 08 D9 //nozzle 1
respond: A5 01 03 08 00 03 59 10 00 00 01 79 E0

4.查询加油状态

send: A5 01 03 00 01 35
respond: A5 01 03 01 00 AF
//00 表示加油机是空闲状态。

备注: POS 系统每隔 100MS 定时查询加油状态