Install guide

Signal Explorer | Windows source installation
Version 0.1.0 - File Viewer and scripting release
Document revision 1.2 - October 29, 2026

This guide installs the current Python desktop application on another PC. A standalone installer will be addressed later. You need internet access for the initial Python package downloads and any required driver downloads.

1. Prepare the PC and project files

Install **64-bit Python 3.12** and its Python launcher. This is the version used on the development PC. The project declares Python 3.11 or later, but other versions have not been validated here.

Copy or clone the project into a writable folder, for example **C:\Tools\Signal Explorer**. Include **pyproject.toml**, **README.md**, and the complete **src** folder. Copy **examples** for the demo DBC and **tests** if you want to run checks. Do not copy the old **.venv**; create one on the new PC. Git is optional if you copy the files.

Keep the complete src/signal_explorer/assets and scripting folders: the package includes the SE window icon, startup splash and built-in demo script. Copy examples/scripts/mcu for the companion scripting tutorials. No additional runtime package is required for File Viewer or the Python runner.

2. Install the application

Open PowerShell in the project root - the folder containing pyproject.toml - and run:

```
cd "C:\Tools\Signal Explorer"
py -3.12 -m venv .venv
.\.venv\Scripts\python.exe -m pip install .
```

Using the virtual environment executable directly avoids the need to activate it or change PowerShell script-execution settings.

3. Launch Signal Explorer

```
.\.venv\Scripts\python.exe -m signal_explorer
```

Run this command from the project root whenever you want to start the application. The existing SignalExplorer.bat contains the development PC's absolute path; update that path before using it elsewhere.

Packages installed automatically

PySide6-Essentials - desktop UI; **python-can** - CAN interfaces; **pyserial** - serial adapters; **cantools** - DBC decoding; **ldfparser** - LIN descriptions; **uptime** - timestamp support; **asammdf** via python-can[mf4] - ASAM MDF4 recording and playback. pip also installs dependencies such as NumPy and pandas. Build tooling includes setuptools. These are application dependencies, separate from vendor hardware drivers.

Adapter requirements

Install only the software needed for the adapters you plan to use.

Install vendor-supplied drivers/APIs matching this 64-bit installation before connecting hardware, unless the installer requests USB connection. Keep bus wiring disconnected during setup. Driver installers may need administrator approval. Vendor DLLs are not included in the source.

Virtual CAN, LIN and Ethernet - no hardware

No vendor software is required for the simulators. Choose a virtual adapter in the relevant tab; demo traffic/peers let you test monitoring, sending and logging without physical bus traffic.

CANable - SLCAN firmware

Windows must recognize the adapter as a serial COM port. Install its appropriate USB serial driver if Windows does not configure it automatically. No additional Python packages are required. Choose CANable (SLCAN serial), select its actual COM port, and match the CAN bus bitrate. The new PC may assign a port other than COM3.

CANable - candleLight / gs_usb firmware

This is a different USB connection path from SLCAN. Install the additional backend:

```
.\.venv\Scripts\python.exe -m pip install "python-can[gs-usb]"
```

A compatible USB driver and libusb backend may also be needed on Windows. Configure those for the device's firmware, then choose CANable / candleLight (gs_usb). This path has not been physically validated in this project; the tested CANable connection is SLCAN.

Vector - VN16xx / CANXL adapter option

Install Vector hardware drivers **and the 64-bit XL Driver Library**. The USB driver alone is insufficient. Signal Explorer checks PATH and the standard Public Documents/Vector/XL Driver Library*/bin folder. If detection fails, use **Vector DLL** to select the installed **vxlapi64.dll**, then restart. Select the detected serial number and physical CAN channel; no application assignment in Vector Hardware Config is required.

Vector XL Driver Library

Kvaser - including U100-C

Install Kvaser Windows drivers with the CANlib runtime. Select Kvaser (U100 / CANlib), then Refresh devices. Channel indices start at zero. A listed Kvaser virtual channel is not a physical U100-C.

PEAK - including PCAN-USB Pro FD

Install PEAK hardware drivers and the 64-bit **PCAN-Basic API** (PCANBasic.dll). Select the PEAK option and a detected CAN channel. Manual names include PCAN_USBBUS1 and PCAN_USBBUS2; use detected names when several adapters are attached.

For **LIN**, separately install PEAK LIN drivers, **PLIN Manager** and 64-bit **PLIN-API** (PLinApi.dll). PCAN-Basic alone does not supply LIN. Select LIN > PEAK PLIN / PCAN-USB Pro FD, Refresh, then a detected LIN channel. PCAN-USB Pro/Pro FD and PLIN-USB families use this API; a CAN-only PCAN-USB cannot supply LIN. Native PEAK LIN is experimental and awaits a physical bench test.

Intrepid - ValueCAN / neoVI

Install Intrepid hardware drivers and its native 64-bit **icsneo40.dll**, then install the optional Python dependencies:

```
.\.venv\Scripts\python.exe -m pip install ".[intrepid]"
```

This adds python-ics and filelock. Select the Intrepid adapter by serial number, not its COM port. For ValueCAN4-2, HSCAN is CAN1 and HSCAN2 is CAN2.

Verify and troubleshoot

A short check before connecting to a live CAN bus.

1. Verify the software without hardware

Launch Signal Explorer, select **Virtual**, enable **Inject demo traffic**, and click **Connect**. The trace should show ID 100 with changing data. Load **examples/demo.dbc** to display the demo message name and decoded signals.

Auto-scroll (all messages) is checked by default and shows timestamped history. Uncheck it for the latest data per channel and ID. History retains the most recent 10,000 frames. **Pause Exploring** freezes trace updates while staying connected; **Start Exploring** resumes. Frames received while paused are not replayed.

2. Verify hardware reception

Connect the adapter by USB, choose its backend and channel, set the correct bus bitrate, and click Connect. Use a powered, correctly wired and terminated CAN bus with a device that is transmitting. Check the RX count. Click Clear filter if frames might be hidden. Merely connecting USB does not generate CAN traffic.

Common issues

Python or py is not recognized: verify Python 3.12 is installed and reopen PowerShell. Check with **py -3.12 --version**.

No module named signal_explorer: run the install command from the project root and launch using the same .venv Python executable.

COM port access denied: disconnect that port in other Signal Explorer windows and close other programs using it. Only one process can hold the CANable serial port.

Connected, RX stays at zero: confirm the bus has traffic, the bitrate matches, CAN-H/CAN-L wiring is correct, and the required termination is present. A quiet bus can connect successfully without producing trace rows.

RX increases but the trace appears empty: click Clear filter and ensure exploring is running. While paused, trace counters and rows stay frozen.

Missing DLL or no detected channels: install the vendor's 64-bit API as well as its USB driver. Reconnect USB, use Refresh devices, or restart after changing DLL settings. No attached device can legitimately produce an empty channel list.

Optional automated checks

If the tests folder was copied, run the following from the project root. The complete suite also expects the Intrepid optional dependencies to be installed.

```
.\.venv\Scripts\python.exe -m unittest discover -s tests -v
```

The release has 145 passing checks using simulated/virtual traffic and native API mocks. Passive PC Ethernet capture was also checked separately; physical Ethernet TX and powered ValueCAN Ethernet/LIN bench tests remain pending.

Logging and playback

Click **Start Logging** to record RX and TX; **Stop Logging** finalizes the MDF4 file and opens a save dialog. Cancelling retains it for **Save Log...**. Logging continues while the trace is paused or filtered. **Playback Log as TX** replays a selected recorded bus/direction at best-effort 1x timing through the connected adapter; **Stop Playback** stops it. Physical timing and third-party interoperability are not yet qualified.

Current scope

CAN supports Classic/FD. LIN offers simulated Monitor/Master/Slave and experimental native Intrepid, Vector XL and PEAK PLIN. Ethernet now offers an isolated simulator, Windows PC Ethernet through Npcap, and ValueCAN4-2EL Ethernet. Sending, repeat, filters and MF4/replay are available. Ethernet setup is on pages 5-6. SENT, CAN XL and a packaged installer remain future work.

DBC files are optional; copy the files you intend to use separately. No compiler is normally needed when compatible prebuilt Python wheels are available. Record working package versions for reproducible deployments; the current project uses minimum version constraints rather than a pinned dependency lock.

LIN adapter setup

Monitor, Master and Slave | native drivers are experimental until bench validation.

Intrepid ValueCAN4-2EL

Install the Intrepid drivers, 64-bit **icsneo40.dll**, and the optional Python dependencies shown on page 2. In the LIN tab select **Intrepid ValueCAN4-2EL**, Refresh, then its serial number and LIN 1. The app checks the actual device type: ValueCAN4-2 and ValueCAN3 are CAN-only and will not appear here. The development unit VE0245 was detected and its settings read over USB; physical LIN traffic has not been tested.

Baud rate and the master resistor are configured for the selected role through temporary settings, with no EEPROM writes. Disconnect restores the saved settings and closes the native handle, leaving LIN communication off until a new session enables it. **Wake is disabled for Intrepid** because its legacy Python binding has no verified dedicated wake-pulse operation; use the external master to wake a sleeping bus.

Vector VN1640 with LIN piggies

Use the installed Vector hardware drivers and XL Driver Library from page 2. In LIN select **Vector VN16xx / XL LIN** and Refresh. Select the serial, physical LIN channel and piggy shown by the driver. The VN1640 requires LIN piggies installed and configured. A VN1610 with CAN transceivers is not a LIN interface. Release initialization access in CANalyzer or other XL applications before connecting this channel.

PEAK PLIN

Install PEAK LIN drivers, PLIN Manager and the matching 64-bit PLIN-API as described on page 2. Select **PEAK PLIN / PCAN-USB Pro FD** and Refresh. PCAN-Basic is the separate CAN API; it does not provide LIN. Close other PLIN clients on the selected LIN channel.

Choose a role and transmit

Monitor: no local responses or header requests. **Master:** Send Header requests one defined ID; Start Schedule cycles the configured slots. Selected local response data can be transmitted with the header. **Slave:** select local publishers and Apply Responses; the adapter waits for the external master header before responding. Response updates are buffered in hardware, not generated from a GUI callback.

Load the matching LDF, baud rate, frame lengths and checksum model on both nodes. Pause Exploring freezes only the trace; stop the schedule or playback separately. Start Logging records RX/TX independently of trace filters. Master playback replays headers with current response configuration; Slave playback updates the selected response buffers at recorded times.

Device ownership and powered bench check

Signal Explorer prevents concurrent CAN/LIN on the same Vector and CAN/LIN/Ethernet on the **same Intrepid device**. Disconnect that device's existing session first. Different devices may remain connected in separate tabs; shared native multi-protocol sessions are future work.

USB alone is sufficient for detection, not a powered LIN bus test. Follow the vendor connector pinout, supply requirements and common-ground wiring, with exactly one master and the proper LIN master pull-up. LIN does not use CAN termination. Verify responder removal, RX/TX direction, checksum/error reporting, timing, sleep/wake and MF4 import on the real bench. Mock tests cannot qualify these physical behaviors.

Ethernet adapter setup

PC Ethernet through Npcap | Intrepid ValueCAN4-2EL | simulation stays available

1. Install PC Ethernet capture support

Install current **Npcap** from its official installer. This is a separate Windows driver/runtime, not a Python package and not bundled with Signal Explorer. The app loads **%SystemRoot%\System32\Npcap\wpcap.dll**; it does not use a DLL copied into the project. No Scapy or additional Python capture package is required.

Npcap download and installation instructions

Follow your Npcap capture-permissions policy. If installed with administrator-only access, opening an adapter may require an elevated app session. Normal capture permissions otherwise suffice. Raw Wi-Fi/monitor-mode support is not needed for this release: Wi-Fi and loopback are not offered. The app does not change PC IP addresses, link speeds or duplex.

2. Install ValueCAN4-2EL support

Use the same Intrepid Windows driver, matching 64-bit **icsneo40.dll**, and optional packages as CAN/LIN. On the new PC run:

```
.\.venv\Scripts\python.exe -m pip install ".[intrepid]"
```

Use current python-ics with the vendor's Ethernet buffer fixes (1!26.3.9+ recommended; this build used 1!26.3.17). Copying the project does not copy installed native drivers. Select the actual ValueCAN4-2EL serial; CAN-only ValueCAN4-2 and ValueCAN3 are not Ethernet adapters.

Provide the vendor-specified **external 12 V** and matching Ethernet breakout cable. USB detection alone is insufficient for Ethernet. The 2EL has a 10/100 PHY; preserve/configure its speed/duplex in neoVI Explorer, then release that tool before app connection. Signal Explorer enables Ethernet temporarily in RAM, restores settings on close and never writes EEPROM.

ValueCAN4-2EL power and Ethernet specifications

3. Discover and select

Open **Ethernet**: first display scans adapters. **Refresh adapters** rescans while disconnected. The list always keeps **Simulated Ethernet**, plus detected PC Ethernet interfaces and 2EL units. PC entries show name, MAC and up/down state; virtual Ethernet interfaces are included. Interfaces can remain listed but disabled when Npcap/capture access is unavailable.

Select the intended port and Connect Ethernet to start capture. Discovery itself never opens a session or transmits. Optional **Promiscuous capture** applies only to PC ports; a switch mirror/TAP is needed to observe other switch ports. Disconnect CAN/LIN sessions on the same ValueCAN before opening its Ethernet session.

4. Check setup without transmission

Use a known transmitting peer to confirm passive RX and link state. Clear filters and Start Exploring if needed. Simulation needs no driver: select it, enable demo traffic/peer, connect and inspect test frames. Demo traffic and synthetic ACK replies stay inside the simulator; they never run on hardware.

Ethernet verification & recovery

Confirm the selected interface and expected traffic before sending or replaying.

Simulation acceptance check

Choose Simulated Ethernet and Connect Ethernet with demo traffic and peer enabled. Expect UDP telemetry, ARP, VLAN UDP and raw 88B5 test frames. Select VLAN UDP, Load Test Frame and Send once: expect local TX and a synthetic ACK RX. Enter 100 in Interval (ms) to repeat; Send becomes Stop. Inject Test RX is simulation-only.

Hardware capture and controlled transmit check

Choose the exact PC port or externally powered 2EL and Connect Ethernet. A session-open status is not proof of physical link. Verify peer traffic first. Load/edit a suitable test frame, including destination MAC and payload for the bench, then Send once and confirm bytes at the independent peer before repeat/playback. Physical TX acceptance remains pending for this build.

PC test presets use the selected NIC source MAC; their IP/destination values remain example addresses. ValueCAN raw frames use the editor source MAC. No automatic ARP resolution, TCP session, DoIP activation line, DoIP/XCP stack or PC IP configuration is provided. Hardware Send/repeat/playback cause real transmission on the selected port.

Logging and playback

Start Logging records RX/TX before display filters/pause; Stop Logging prompts for an .mf4 name. Cancel retains it for Save Log.... Playback Log as TX, or Playback Log as Simulated TX on the virtual adapter, selects recorded bus/direction and replays at best-effort 1x timing. Playback stops repeated sending. Old Ethernet simulation logs still work; unrelated CAN/LIN logs do not.

Ethernet stores raw frames in an MDF 4.10 container using custom **SignalExplorer_EthernetFrame** records. It is not standardized ASAM Ethernet bus-event interchange or independent conformance certification. TX means driver/API acceptance, not peer receipt. FCS is excluded, while NIC-provided padding may be absent and is added when replay requires minimum TX length.

Common Ethernet issues

Capture unavailable: install/check Npcap and permissions; Refresh adapters. **No ports:** check Windows device enumeration; Wi-Fi/loopback are intentionally excluded. **ValueCAN in use:** release other CAN/LIN/Vehicle Spy/neoVI sessions on that serial.

No RX: verify cable/link and peer traffic; 2EL also needs 12 V. An ordinary switched port does not see every other port. **Checksum warning:** raw packet edits or NIC checksum offload can be responsible; verify at a peer before blaming the bus.

Driver drops: Npcap capture/interface loss; Intrepid shows n/a. **Display drops:** UI queue overflow, separately from recorder overflow. **Unsupported/error frames:** rejected captures, not logged; includes jumbo/truncated/stacked-VLAN/802.3 length frames or native CRC/length faults. Standard MTU 1500 and one VLAN tag are supported.

No sustained line-rate or lossless capture guarantee is claimed. Native RX/API failures close the session and stop/finalize active operations. Use the full users guide for column definitions, controls, recovery and cable-specific CAN/LIN/Ethernet pinouts.

October 29 update & File Viewer

Revision 1.2 | Python scripting, log viewing and timestamp correction

1. Update an existing source installation

Close Signal Explorer and its editor/viewer windows, preserving any unsaved scripts and logs. Replace/update the project files. From the project root, reinstall into the same environment:

```
.\.venv\Scripts\python.exe -m pip install .
# Intrepid users instead use:
.\.venv\Scripts\python.exe -m pip install ".[intrepid]"
```

For an editable development installation use -e . or -e ".[intrepid]". Launch with the same .venv interpreter. Do not run a new GUI alongside an older process holding the adapter. The Python worker uses the application's interpreter; there is no separate scripting executable to install.

2. Confirm startup branding and the menu

The black SE icon has a red S and white E. A separate splash adds white SIGNAL above the mark and EXPLORER below it. It appears during imports/window construction and closes when the main application opens. File Viewer replaces the former Scripts menu; the title-bar icon remains the SE mark.

3. Verify scripting without hardware

Connect Virtual CAN with Inject demo traffic checked. Choose File Viewer > Open CAN Simulation Example and Run. The script sends ID 321 hex with eight bytes; the virtual peer replies on 221 hex with the same bytes. Each verified exchange increments every byte, wraps FF to 00 and repeats until Stop. Pause/Resume/Stop and Script Output are in the separate editor. CAN FD mode also supports the eight-byte echo.

Use File Viewer > Open Python Script... for examples/scripts/mcu/*.py. Five examples use the built-in simulator. The other four require matching MCU firmware and default to a configuration guard before TX. Read SIGNAL EXPLORER Scripting User's Guide.pdf before adapting them. The se context is injected by the app; it is not a pip package.

4. Verify log viewing and replay

Use File Viewer > Open Logfile for a single-protocol CAN/CAN FD, LIN or Signal Explorer Ethernet MF4. Logs open read-only, even offline. Connect the corresponding destination, select Recorded bus and RX only/TX only/RX and TX, then Replay. Pause/Resume/Stop, highlighted rows, Follow execution and Replay Output remain in the viewer. Log line delay changes display refresh only, preserving 1x transmission timing; Python line delay slows actual script execution.

5. Make fresh Intrepid recordings after this update

The app now anchors Intrepid CAN/LIN/Ethernet RX hardware intervals to host time per connection, aligning them with local TX. Earlier recordings could mix a 2007 device-clock epoch with the PC clock and flatten subsequent timestamps. Their original timing cannot be recovered. Restart, reconnect and record a new file. Replay detects selected gaps over 24 hours before any TX and bounds platform waits to prevent timeout overflow. No Skip gaps control is provided.

Runtime versus documentation tooling

The tutorials use only Python's standard library and the existing app CAN API. No CAPL compiler, external editor, UDS library or CAN transport package is added. Full UDS/ISO-TP, LIN/Ethernet scripting and a standalone installer remain future work. reportlab and pypdf are needed only to regenerate the manuals, not to run Signal Explorer.