Important Safety Precautions

Read these instructions. Breaking the rules may be dangerous or illegal. Further detailed information is given in this user guide.

WARNING! Violation of the instructions may cause serious injury or death.



 Never use an unapproved battery since this could damage the phone and/or battery and could cause the battery to explode.



- Never place your phone in a microwave oven as it will cause the battery to explode.
- Never store your phone in temperatures less than
 - -4°F or greater than 122°F.
- 4. Do not dispose of your battery by fire or with hazardous or flammable materials.



 When riding in a car, do not leave your phone or set up the hands-free kit near to the air bag. If wireless equipment is improperly installed and the air bag is deployed, you may be seriously injured.



- 6. Do not use a hand-held phone while driving.
- Do not use the phone in areas where its use is prohibited. (For example: aircraft)

Important Safety Precautions



 Do not expose the battery charger or adapter to direct sunlight or use it in places with high humidity, such as a bathroom.



Do not use harsh chemicals (such as alcohol, benzene, thinners, etc.) or detergents to clean your phone. This could cause a fire.



Do not drop, strike, or shake your phone severely. It may harm the internal circuit boards of the phone.

4. Do not use your phone in high explosive areas as the phone may generate sparks.



 Do not damage the power cord by bending, twisting, pulling, or heating. Do not use the plug if it is loose as it may cause a fire or electric shock.



Do not place any heavy items on the power cord.Do not allow the power cord to be crimped as it may cause electric shock or fire.

7.Do not handle the phone with wet hands while it is being charged. It may cause an electric shock or seriously damage your phone.



8. Do not disassemble the phone.



- Do not place or answer calls while charging the phone as it may short-circuit the phone and/or cause electric shock or fire.
- Do not hold or let the antenna come in contact with your body during a call.



- Make sure that no sharp-edged items such as animal's teeth or nails, come into contact with the battery. This could cause a fire.
- 4. Store the battery out of reach of children.



Be careful that children do not swallow any parts (such as rubber plugs, earphone, connection parts of the phone, etc.) This could cause asphyxiation or suffocation resulting in serious injury or death.



- Unplug the power cord and charger during lightning storms to avoid electric shock or fire.
- Only use the batteries and chargers provided by LG. The warranty will not be applied to products provided by other suppliers.



Only authorized personnel should service the phone and its accessories. Faulty installation or service may result in accidents and consequently invalidate the warranty.



9. Your service provider programs one or more emergency phone numbers, such as 911, that you can call under any circumstances, even when your phone is locked. Your phone's preprogrammed emergency number(s) may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental, or interference issues.

Table of Contents

mportant Safety		Redialing Calls	23
Precautions	1	Receiving Calls	23
Table of Contents	4	Quick Access to Convenient Features	24
Welcome	8	Mute Function	24
Technical Details	9	Quick Volume Adjustment Call Waiting	24 24
Phone Overview	15	Caller ID	24
Menus Overview	17	Speed Dialing	25
vierius Overview		Entering and Editing	
Getting Started with		Information	26
Your Phone	20	Text Input	26
The Battery	20	Contacts in Your Phor	ne's
Charging the Battery	20	Memory	27
Battery Charge Level Turning the Phone On and Signal Strength	21 d Off 21 22	The Basics of Storing Contac Entries	27
Screen Icons	22	Phone Numbers With Pauses	
Making Calls	22	Searching Your Phone's Men 29	югу
Correcting Dialing	22	Making a Call From Your Pho	one's

30	4. Drafts	41
32	5. Voicemail	42
	6. Templates	42
	7. Settings	43
52	7.1 Text Message	43
32	o o	44
32		44
32		44
32		
33	2. Received Calls	45
	Dialed Calls	45
	4. All Calls	45
33	5. Call Timer	45
33	Multimedia	46
34		48
35		48
35		48
36		
36		51
	1.1 Start Command	51
	1.2 Command Mode	52
39	1.3 Announce Alert	52
40	1.5 Best Match	53
	32 32 32 32 32 32 32 33 33 33 34 35 36 36 36 39	32 5. Voicemail 6. Templates 7. Settings 7.1 Text Message 8. Delete All Recent Calls 1. Missed Calls 2. Received Calls 3. Dialed Calls 3. Dialed Calls 3. All Calls 3. All Calls 3. Record Voice Browser 3. Start Browser 4. Start Browser 4. Start Command 4. Start Command 4. Command Mode 4. All Calls 4. All Calls 5. Call Timer 4. Start Browser 4. Start Browser 4. Start Browser 4. Start Command 4. S

Table of Contents

1. Alarm Clock	53	2.2 Backlight	60
2. Calendar	53	2.3 Menu Style	60
3. Notepad	54	2.4 Languages	60
Tools	54	2. Use to select English or	
1. Calculator	54	Spanish, then press .	60
2. Ez Tip Calc	55	2.5 Clocks & Calendar	61
3. World Clock	55	2.6 Font Settings	61
4. Stopwatch	56	2.7 Word Prediction	62
5. Unit Converter	56	2.8 Name Match for Dialing	62
Settings	56	3. Security	62
1. Sound	56	3.1 Lock Phone	62
		3.2 Change Lock Code	63
1.1 Ringers	56	3.3 Reset Default	63
1.2 Volume	57	4. Call Settings	64
1.3 Message Alerts	57	4.1 Answer Options	64
1.4 Alert Type	57	4.3 One-Touch Dial	64
1.5 Service Alerts	58	4.4 Airplane Mode	65
1.6 Power On/Off Tone	58	4.5 TTY Mode	65
1.7 Flip Tone	59		65
1.8 Emergency Tone	59	5. System	
2. Display	59	5.1 Network	66
2.1 Wallpaper	59	5.2 Location	66

6. Memory	66	
7. Phone Info	67	
Bluetooth	67	
1. Paired Devices	68	
2. Power	69	
3. My Visibility	69	
4. My Bluetooth Name	69	
5. My Bluetooth Info	69	
Safety	70	
or Your Safety	75	
Safety Information	75	
Warning! Important safety		
information	81	
FDA Consumer Update	83	
10 Driver Safety Tips	94	
Consumer Information on		
SAR	98	
FCC Hearing-Aid Compatibility (HAC) Regulations for Wireless Devices 101		
Devices	101	

Accessories	105
Limited Warranty 106	Statement
Index	111

Welcome

Thank you for choosing the LG221C cellular phone; designed to operate with the latest digital mobile communication technology, Code Division Multiple Access (CDMA). Along with the many advanced features of the CDMA system, such as greatly enhanced voice clarity, this compact phone offers:

- Significantly enhanced voice clarity.
- Slim and sleek design with internal antenna (Internal antenna described as antenna throughout this user guide).
- Large, easy-to-read, backlit LCD with status icons.
- Paging, messaging, voice mail, and caller ID capabilities.
- 23-key keypad.

- Speakerphone feature.
- Menu-driven interface with prompts for easy operation and configuration.
- Any key answer, auto answer, auto retry, one-touch and speed dialing with 99 memory locations.
- Bilingual (English and Spanish) capabilities.
- Bluetooth® wireless technology.

Note

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by LG Electronics is under license. Other trademarks and trade names are those of their respective owners.

Technical Details

Important Information

This user's guide provides important information on the use and operation of your phone. Please read all the information carefully prior to using the phone for the best performance and to prevent any damage to or misuse of the phone. Any unapproved changes or modifications will void your warranty.

FCC Part 15 Class B Compliance

This device and its accessories comply with part 15 of FCC rules. Operation is subject to the following two conditions:
(1) This device and its accessories may not cause harmful interference, and (2) this device and its accessories

must accept any interference received, including interference that causes undesired operation.

Technical Details

The LG221 C is a trimode phone that operates on among (Code Division Multiple Access CDMA) frequencies: cellular services at 800 MHz, (Personal Communication Services PCS) at 1.9 GHz

CDMA technology uses a feature called DSSS (Direct Sequence Spread Spectrum) that enables the phone to keep communication from being crossed and to use one frequency channel by multiple users in the same specific area. This results in a 10-fold capacity increase when compared with analog mode. In addition, features such as soft

Technical Details

/ softer handoff, hard handoff, and dynamic RF power control technologies combine to reduce call interruptions.

The Cellular and PCS CDMA

CDMA Standard	Designator	Description
Basic Air Interface	TIA/EIA-95A TSB-74 ANSI J-STD-008 TIA/EIA-IS2000 ANSI TIA/EIA 553A	CDMA Dual Mode Air Interface 14.4kbps radio link protocol and inter-band operations IS-95 adapted for PCS frequency band cdma2000 1xRTT AirInterface
Network	TIA/EIA/IS-634 TIA/EIA/IS/651 TIA/EIA/IS-41-C TIA/EIA/IS-124	MAS-BS PCSC-RS Intersystem operations Non-signaling data comm.
Service	TIA/EIA/IS-96-B TIA/EIA/IS-637 TIA/EIA/IS-657 IS-801 TIA/EIA/IS-707-A	Speech CODEC Short message service Packet Data Position Determination Service (gpsOne) High Speed Packet Data
Performance	TIA/EIA/IS-97 TIA/EIA/IS-98 ANSI J-STD-018 ANSI J-STD-019 TIA/EIA/IS-125	Cellular base station Cellular mobile station PCS personal station PCS base station Speech CODEC

networks consist of MSO (Mobile Switching Office), BSC (Base Station Controller), BTS (Base Station Transmission System), , MS (Mobile Station).

* TSB-74: Protocol between an IS-95A system and ANSI J-STD-008

1xRTT system receives twice as many subscribers in the wireless section as IS-95. Its battery life is twice as long as IS-95. High-speed data transmission is also possible.

The following table lists some major CDMA standards.

FCC RF Exposure Information

WARNING! Read this information before operating the phone.

In August 1996, the Federal Communications Commission

(FCC) of the United States, with its action in Report and Order FCC 96-326, adopted an updated safety standard for human exposure to Radio Frequency (RF) electromagnetic energy emitted by FCC regulated transmitters. Those guidelines are consistent with the safety standard previously set by both U.S. and international standards bodies. The design of this phone complies with the FCC guidelines and these international standards.

Bodily Contact During Operation

This device was tested for typical use with the back of the phone kept 0.79 inches (2.0 cm) from the body. To comply with FCC RF exposure requirements, a minimum separation distance

Technical Details

of 0.79 inches (2.0 cm) must he maintained between the user's body and the back of the phone, including the antenna, whether extended or retracted. Third-party beltclips, holsters, and similar accessories containing metallic components should not be used. Avoid the use of accessories that cannot maintain 0.79 inches (2.0 cm) distance between the user's body and the back of the phone and have not been tested for compliance with FCC RF exposure limits.

Vehicle-Mounted the External Antenna

(Optional, if available.)

To satisfy FCC RF exposure requirements, keep 8 inches (20 cm) between the user /

bystander and vehicle-mounted the external antenna. For more information about RF exposure, visit the FCC website at www.fcc.gov.

FCC Notice and Cautions

This device and its accessories comply with part 15 of FCC rules. Operation is subject to the following two conditions: (1) This device and its accessories may not cause harmful interference, and (2) this device and its accessories must accept any interference received, including interference that causes undesired operation.

Any changes or modifications not expressly approved in this user guide could void your warranty for this equipment. Use only the supplied antenna. Use of unauthorized antennas (or modifications to the antenna) could impair call quality, damage the phone, void your warranty and/or violate FCC regulations.

Don't use the phone with a damaged antenna. A damaged antenna could cause a minor skin burn. Contact your local dealer for a replacement antenna.

Caution

Use only the supplied and approved antenna. Use of unauthorized antennas or modifications could impair call quality, damage the phone, void your warranty and/or result in violation of FCC regulations. Do not use the phone with a damaged antenna. If a damaged antenna comes into contact with the skin a minor burn may result. Contact your local dealer

for a replacement antenna.

Part 15.19 statement

This device and its accessories comply with part 15 of FCC rules. Operation is subject to the following two conditions:

- This device & its accessories may not cause harmful interference.
- (2) This device & its accessories must accept any interference received, including interference that may cause undesired operation.

Part 15.21 statement

Change or Modifications that are not expressly approved by the manufacturer could void the user's authority to operate the equipment.

Technical Details

Part 15.105 statement

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules, These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation, if this equipment does cause harmful interference or television reception, which can be determined by turning the

equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Phone Overview



- 1. Earpiece Lets you hear the caller.
- 2. LCD Screen Displays messages and indicator icons. When the phone is turned on, Power Save mode automatically dims the screen and then darkens it if no keys are pressed.
- Left Soft Key Use to access the Messaging menu from the standby screen, or the function immediately above it.
- 4. Speakerphone Key Use to turn Speaker On or Off.
- 5. SEND Key Use to place or answer calls.
- Alphanumeric Keypad Use to enter numbers and characters and select menu items.
- Vibrate Mode Key Use to set the vibration mode from standby mode, press and hold for about 2 seconds.
- Navigation Key Use to navigate through menus and options. When on the Standby screen, use for quick access to Favorites ,easyedge,Calendar and My Menu.
- Right Soft Key Use to access the Contacts menu from the standby screen, or the function immediately above it.
- Menu/OK Key Lets you access the phone's main Menu and also selects the highlighted choice when navigating through a menu or function.
- 11. CLR Key Deletes single spaces or characters with a quick press, but press and hold to delete the text entered in a text field. Will also back you out of menus, one level at a time. Also you are allowed to access Voice command by pressing CLR key from home screen.
- 12. PWR/END Key Use to turn the power on/off and to end a call. Also, use to exit from any function and return to the standby menu.
- Lock Mode Key Use to lock the phone from standby mode, press and hold for about 2 seconds.

Phone Overview





- Earphone Jack Allows the use of a headset to hear caller's voice.
- Side Volume Keys Use to adjust the ringer volume in standby mode and the earpiece volume during a call.
- Charger/Accessory Port Connects the phone to the battery charger or other available accessories.
- Camera Key Use for quick access to Camera function.

Charging with PC USB

You can use your computer to charge your phone. Connect one end of a USB cable to the charging accessory port on your phone and the other end to a high-power USB port on your PC (commonly located on the front panel of the computer).

Camera Lens Lets you take pictures and videos.

Menus Overview

Menu Access

While in standby mode, press
Menu to access twelve phone menus. There are two methods of accessing menus and submenus:

- Use the navigation key to highlight a menu/option and
 o
 to select it.
- Press the number key on the keypad that to activate the corresponding menu/option.

Duamaid	Massaging	Decemb Calle
Prepaid	Messaging	Recent Calls
1. Add Airtime	 New Message 	 Missed Calls
2. Buy Airtime	2. Inbox	2. Received Calls
3. My Phone	3. Outbox	3. Dialed Calls
Number	4. Drafts	4. All Calls
4. Aurtime Info	5. Voicemail	5. Call Timer
Airtime Display	6. Templates	6. Data Counter
6. Serial Number	7. Settings	o. Data Counter
Contacts		
1. New Contact	1. Entry Mode	Game
	2. Signature	
2. Contact List	8. Delete All	
3. Groups	1. Delete Inbox	Browser
4. My vCard	2. Delete Outbox	
5. Speed Dials	3. Delete Drafts	
		Multimedia
	4. Delete All Messages	1. Record Voice

Menus Overview

2. Images	1. Disable	4. My Bluetooth Info
1. My Images	2. Announce	
2. Default	3. Announce + Ring	Tools
3. Buy Graphics	4. Train Word	1. Calculator
3. Sounds	1. Voice Command	2. Ez Tip Calculator
1. My Sounds	2. Answer	3. World Clock
2. Default	3. Digit Dial	4. Stopwatch
3. Buy Ringtones	5. Best Match	5. Unit Converter
		1. Currency
Voice Command	1. Match	2. Area
1. Start Command	2. Matches	3. Length
1. Call <name> or</name>		4. Mass
<number></number>	My Schedule	5. Temperature
2. Voicemail	1. Alarm Clock	6. Volume
3. Missed Calls	2. Calendar	7. Velocity
4. Messages	3. Notepad	
5. Time&Date		Settings
6. Help		1. Sound
2. Command Mode	Bluetooth	1. Ringtones
1. Normal	1. Paired Devices	1. All Calls
	2. Power	2. Caller ID
2. Speed	3. My Visibility	3. No Caller ID
3. Announce Alert	3. my risibility	4. Buy

Ringtones	1. Wallpaper	3. Reset
2. Volume	1. My Images	Default
1. Master	2. Default	4. Call Settings
Volume	3. Buy Graphics	1. Answer Options
2. Keypad	2. Backlight	2. Auto Retry
Earpiece	1. Display	One Touch Dial
4. Speaker	2. Keypad	4. Airplane Mode
3. Message Alerts	3. Brightness	5. TTY Mode
1. Message	3. Menu Style	5. System
2. Voicemail		1. Network
3. Message	4. Languages (Idiomas)	1. System
Reminder	5. Clocks &	Select
4. Alert Type	Calendar	2. Serving
Service Alerts	Font Settings	System
1. Minute Beep	1. Font Type	2. Location
2. Call Connect	2. Dial Font	6. Memory
3. Back to Top	Style	1. Reserved Memory
4. Low Battery	3. Dial Font Size	2. Multimedia
5. Roam Alert	Word Prediction	
6. Power On/Off	8. Name Match for Dialing	7. Phone Info
Tone		1. My Number
7. Flip Tone	3. Security	ESN/MEID
8. Emergency	1. Lock Phone	3. Icon Glossary
Tone	2. Change	4. Version
2. Display	Lock Code	

Getting Started with Your Phone

The Battery

Note

It is important to fully charge the battery before initial use of the phone.

The phone comes with a rechargeable battery. The battery charge level is shown at the top of the LCD screen.

Installing the Battery

Remove the battery cover by pressing down below the LG logo and sliding the cover up. Align the battery with the terminals near the top of the phone, then snap the rest of the battery into place. Align the battery cover then slide it upward until it clicks into place.





Removing the Battery

Turn the phone off. Slide the battery cover upward to remove it. Use the opening near the bottom of the battery to lift the battery out.



Charging the Battery

Use the charger provided with your phone:

Warning! Use only the charger provided with the phone. Using any charger other than the one included with the LG221 C may damage your phone or battery.



Notice

Please make sure that the 'B' Side faces up before inserting a charger or data cable into the charger port of your phone.

- Plug the end of the adapter into the phone's charger port and the other end into an electrical outlet.
- The charge time varies
 depending upon the battery
 level.

Battery Charge Level

The battery charge level is shown at the top right of the LCD screen. When the battery charge level becomes low, the low battery sensor alerts you in up to three ways: sounding an audible tone, blinking the battery icon, and displaying a warning message. If the battery charge level becomes exceedingly low, the phone automatically switches off and any function in progress is not saved.

Turning the Phone On and Off

Turning the Phone On

- Install a charged battery or connect the phone to an external power source.
- 2. Press for about 3 seconds until the LCD screen lights up.

Turning the Phone Off

1. Press and hold until the display turns off.

Getting Started with Your Phone

Signal Strength

Call quality depends on the signal strength in your area. The signal strength is indicated on the screen as the number of bars next to the signal strength icon the more bars, the better the signal strength. If the signal quality is poor, move to an open area. If you are in a building, the reception may be better near a window.

Note

The call quality may also be affected by the places where you are and weather/ambient conditions.

Screen Icons

To see the icon glossary, go to

Menu -> #= Settings ->

Phone Info -> = Icon

Glossary on your phone.

Making Calls

- 1. Make sure the phone is turned on. If not, press for about 3 seconds to turn it on.
- Enter the phone number (include the area code if needed).
- 3. Press SEND .
- 4. Press to end the call.

Correcting Dialing

If you make a mistake while dialing a number, press nonce to erase the last digit entered, or hold down for at least 2 seconds to go to the standby mode.

Redialing Calls

1. Press some twice to redial the last number you dialed. The last 150 numbers (50 missed, 50 received and 50 dialed) are stored in the call history list and you can also select any of these to redial.

Tip

To choose answer options:

Menu -> # Settings ->

Gall Settings ->

1.8 Answer Options. Choose from the following options:

Any Key/ Send Key Only/ Flip Open/ Auto with Handsfree

Receiving Calls

Note

If you press or () (the side keys), while the phone is ringing, the ringing or vibration is muted for that call.

2. Press to end the call.

Quick Access to Convenient Features

Mute Function

The Mute Function is used during a phone call. To quickly activate Mute press Left Soft Key

Mute, then to cancel press
Left Soft Key

Unmute.

Quick Volume Adjustment

Quickly adjust ringer and earpiece volumes by pressing the upper side volume key to increase and lower side key to decrease.

Note

Keypad Volume is adjusted through the Sound Volume menu:



Call Waiting

Your cellular service may offer call waiting. While a call is in progress one beep indicates an incoming call. When call waiting is enabled, you may put the active call on hold while you answer the other incoming call. Check with your cellular service provider for information about this function.

- Press seno to receive a waiting call.
- 2. Press again to switch between calls.

Caller ID

Caller ID displays the phone number or name of the incoming call. If the caller's identity is stored in Contacts, the name will appear along with the phone number. Check with your service provider to ensure they offer this feature.

Speed Dialing

Speed dialing is a convenient feature that allows you to make phone calls quickly. A number key can be assigned to a specific phone number. By pressing and holding down a number key, your phone will recall the phone number associated from the Contact List and display it briefly while simultaneously dialing that phone number for you. Speed Dial Number 1 is set to Voice Mailbox by default and is unchangeable.

Dialing Single Digit Speed Dials (from 2 to 9)

Press and hold the Speed Dial number.

OR

Enter the Speed Dial number and press seno.

Dialing Double Digit Speed Dials (from 10 to 99)

Press the first digit and then press and hold the key of the second digit.

OR

Enter the first and second digits and press ...

Entering and Editing Information

Text Input

You can input and edit your Banner, Calendar, Contacts, Alarm Clock, Notepad, and Messages plus much more. When Entering Text Without the OWERTY

Key Functions



Left Soft Key: Press to scroll through the following text input modes: T9Word (T9WORD/T9Word/ T9word) -> Abc (ABC/Abc/abc) -> 123 -> Symbols

★%.

Shift: Press to change case.

T9 text : T9Word -> T9WORD -> T9word Abc text : Abc -> ABC -

> abc

Next: In T9 mode, press to display other matching words.

#- Space: Press to complete a word if text is in T9 mode or insert a space.

Clear: Press to delete a single space or character. Hold to delete the whole message.

Punctuation: Press to insert punctuation in a word and complete a sentence.

Contacts in Your Phone's Memory

The Basics of Storing Contacts Entries

- From standby mode enter the phone number you want to save (up to 48 digits).
- 2. Press Left Soft Key Save.
- Select either Save New or Update Existing.

Note

Use **Update Existing** to add another phone number to a contact already stored in memory.

- Use to highlight a Label and press .
 Mobile 1/ Home/ Work/
 Mobile 2/ Fax

Phone Numbers With Pauses

When you call automated systems, such as voice mail or credit billing numbers, you often have to enter a series of numbers to navigate through the system. Instead of entering these numbers by hand, you can store the numbers in your Contacts separated by special pause characters (W, P). There are two different types of pauses you can use when storing a number:

Wait (W)

The phone stops dialing until you press Left Soft Key Release to advance to the next number.

Pause (P)

The phone waits 2 seconds before sending the next string of digits.

Contacts in Your Phone's Memory

Storing a Number with Pauses

- 1. Press Menu.
- 2. Press Contacts.
- 3. Press 1.8 New Contact.
- 4. Enter a name (up to 22 characters).
- Enter the number in any of the text fields presented (Mobile 1/ Email 1/ Home/ Work/ Work).
- While entering, press the Right Soft Key — Options.
- 7. Press 3 B Wait or 4 G Pause.
- 8. Enter additional number(s) then press ok .

Adding a Pause to an Existing Number

- While in Standby Mode, press Navigation Down Key
 Contacts to display your Contacts alphabetically.
- Use to highlight the Contact entry to edit, then press view.
- 3. Press Left Soft Key Fdit.
- 4. Use 🗘 to highlight the
- 5. Press Right Soft Key Options.
- 6. Press Sur Wait or 4 and Pause.
- 7. Enter additional number(s), then press ox .

Searching Your Phone's Memory

The LG221C phone is able to perform a dynamic search of the contents in your phone's memory. A dynamic search compares entered letters or numbers against the entries in your Contacts. A matching list is displayed in descending order. You can then select a number from the list to call or edit.

Scrolling Through Your Contacts

- Press Navigation Down Key

 Contacts to display your Contacts alphabetically.
- 2. Use 🐧 to scroll through the list.

Searching by Letter

 While in Standby Mode, press Navigation Down Key

- Contacts to display your Contacts alphabetically.
- Press (or press repeatedly)
 the key on the keypad that
 corresponds with the search
 letter.

Contact List Options

- While in Standby Mode, press Navigation Down Key
 - Contacts and highlight a Contact Entry.
- Press Right Soft Key Options.

Contacts in Your Phone's Memory

- 1.8 Send Message: Send a text message to the selected contact.
- Delete: Delete the selected entry in your Contacts.
- **Edit**: Edit the selected contact information.
- 4es Delete Multiple: Choose from Selective/ All to delete multiple entries at one time.
- Set Speed Dial/ Remove Speed Dial: Set a speed dial or remove the speed dial.

Making a Call From Your Phone's Memory

Once you have stored phone numbers in your Contacts, you can place calls to those numbers quickly and easily.

- By pressing SEND Key
 after searching for a phone
 number in Contacts or Call
 History and highlighting it.
- By using Speed Dialing.

From Contacts

- While in Standby Mode, press Navigation Down Key
 Contacts to display your Contacts.
- 2. Use 🛟 to highlight the Contact entry, then press 💌

- 3. Use 🛟 to highlight the phone number.
- 4. Press (SEND) to place the call.

From Call History

- 1. Press Menu.
- 2. Press 4 Recent Calls.
- 3. Use to highlight the type of recent call, then press .

Missed Calls/ Received Calls/ Dialed Calls/ All Calls

- Use to highlight the phone number.
- 5. Press (see) to place the call.

Speed Dialing

For a single-digit Speed Dial, press and hold the digit or press the digit, then press

. For a double-digit Speed Dial, press the first digit and hold the second digit or press the first and second digits, then press

Using Phone Menus

Prepaid

The Prepaid Menu provides shortcuts to access useful account information.

1. Add Airtime

Add Airtime allows you to start an over-the-air request for additional airtime.

- 1. Press 🖃 , 💵 , 🝱 .
- 2. Enter Airtime PIN Number press —.

2. Buy Airtime

Buy Airtime allows you to start an over-the-air request for purchase additional airtime.

- 1. Press 🖃 , 📵 , 🚉 .
- 2. Use to highlight an option and press .

60 mins./ 120 mins./ 200 mins./ 450 mins.

3. My Phone Number

My Phone Number displays the phone's phone number.

4. Airtime Info

Airtime Info displays the amount of airtime by the unit and due date information.

1. Press —, 18, 4^{cm}.

5. Airtime Display

Airtime Display allows you to disable/enable the display of idle screen, prepaid-related information.

1. Press —, 18, 5^m.

2. Use to highlight an Balance/ Due Date and press .

On/Off

6. Serial Number

Serial Number simply displays the information of your phone's MEID.

1. Press 🖅, 📵, 🖼.

7. Code Entry Mode

Code Entry Mode will allow the phone to accept Tracfone-related codes in order to add units, modify specific data and troubleshoot the phone. In using the Code Entry Mode, you can't receive incoming calls or use events alert.

Contacts

The Contacts Menu allows you to store names, phone numbers and other information in your phone's memory.

Note

When you access your Contacts, the number in parentheses represents the number of entries you have stored (up to 1000).

New Contact

Allows you to add a new contact to your Contact List.

Note

Using this submenu, the number is saved as a new Contact. To save the number into an existing Contact, edit the Contact entry through the Contact List.

Using Phone Menus

- 1. Press —, 2^{**}, 1^{*}.
- 2. Enter the name, then press .
- Highlight the field you wish to store the contact information.
- 4. Enter the phone number or e-mail address.
- Continue adding the desired contact information to the entry.
- When you are finished entering the desired contact information, press Save to save the entry into your Contact List.

2. Contact List

Allows you to view your Contact List.

- 1. Press —, [2ABC], [2ABC].
- 2. Choose from the following options:
 - Press to scroll through your Contacts alphabetically.
 - Press Right Soft Key
 Options to select one of the following:
 - Send Message/ Delete/ Edit/ Delete Multiple/ Set(Remove) Speed Dial
 - Press View to view the contact's information.
 - Press Left Soft Key —
 New to store new contact information.

3. Groups

Allows you to view your grouped Contacts, add a new group, change the name of a group, or delete a whole group.

- Press , Eac, Bost.
 Choose from the following
- options:

 Use 🗘 to highlight a
 - Use to highlight a group, then press View to view the contacts in the selected group.
 - Press Left Soft Key
 New to add a new group.
 - Use to highlight a group, then press Right Soft Key Options to choose from the following options:
 Delete/ Send Message/ Rename Group/ Group Ringtone/ Delete All

My vCard

Allows you to edit and view your personal Contact information including name and phone numbers.

- 1. Press OK, 18, 5x.
- Use to highlight the feature you wish to edit, and press Left Soft Key
 Edit.
- 3. Edit the information as desired and press (iii).

Note

You cannot edit phone number Mobile 1, but you can add additional phone numbers.

Using Phone Menus

5. Speed Dials

Allows you to view your Speed Dials list, designate new Speed Dials, or remove Speed Dial designations entered in your Contacts.

- 1. Press OK , 18, 4^{aa}.
- 2. Use to highlight the desired Speed Dial location (or enter the Speed Dial digit), and press Assign.
- 3. Use \bigcirc to highlight the Contact then press \bigcirc \bigcirc \bigcirc

A confirmation message is displayed.

Messages

The LG221 C can store a total of up to 515 (Inbox 500 + Drafts 15) incoming messages and drafts. The information stored in the messages is determined by phone mode and service capability. Other limits such as available characters per message may exist, please check with your service provider for system features and capabilities.

1. New Message

Allows you to send text messages and e-mail transmissions. Each message will be formatted and sent according to the destination address.

The Basics of Sending a Text Message

- 1. Press **-**, **3**DEF, **1**.
- Enter the recipient's address.
- 3. Press to access the text field.
- Type your message (text or e-mail).
- 5. Press Send.

A confirmation message is displayed.

Select Recipient(s) Using Options

- 1. Press —, 🖃, 🝱.
- Press the Right Soft KeyOptions while in the To: field.

3. Use to highlight an option and press . ■.

Contacts To select a recipient from your Contact List.

Call History To select a recipient from your Recent Calls.

Recent Messages Choose Inbox/ Sent to select a recipient from your Recent Messages.

Groups Select a recipient from your Groups.

Cancel Cancels your message.

Complete your message and send or save it.

Customize Your Text Message Using Options

You have various options to customize the text while you are composing a message.

- 1. Press **—**, **∃**[∞], **1**. .
- 2. Enter the recipient's address.
- 3. Press (w) to access the text field.
- Press the Right Soft KeyOptions.
- Select from the following options:

Add Insert Templates / Signature / Name & Number

Save As Save As Draft / Templates

Priority Level Priority Level High / Normal

Callback # On/ Off
Delivery Notice On/ Off

Cancel Cancels your message.

Complete your message and send or save it.

Message Icon Reference

Inbox



🛭 🖨 Opened/Read Text

New/Unread Notification Message

Opened/Read Notification Message

High Priority

New/Read High Priority MMS

Sent

Failed Text

Multiple Failed Text

Sent Text

Multiple Sent Text

Drafts

Draft Text Message

Inbox

The phone alerts you in 2 ways when you receive a new message by:

- Displaying a notification message on the screen.
- Displaying the message icon
 (It blinks when the message is urgent).

Received messages are displayed from newest to oldest.

Viewing Your Inbox

Up to 500 received messages (500 SMS) can be stored in the Inbox.

- 1. Press —, [3DEF], [3DEF].
- 2. Use to highlight an inbox message.
- 3. Press Left Soft Key Reply to reply, Key View.

For text messages the options are:
Delete/Forward/Save
Contact/Lock/Delete
Multiple

When viewing a particular text message and the View Type is set to Detail View, the Right Soft Key Options menu will contain the following options:

Delete Deletes the selected message.

Forward Forwards a received message to other destination address(es).

Save Contact Stores the callback number, e-mail address, and numbers in the received message into your Contacts.

Save as Templates Stores the message as a template for future messages.

Call Back Calls the number in the received message.

Go To URL Accesses the website by starting Browser. (Only for messages containing a URL.)

Lock/Unlock Locks or unlocks the selected message.

Message Info Shows the message type priority and status.

3. Sent

Up to 50 sent text messages can be stored in the Sent folder. Access the Sent message list to view contents of sent messages and verify whether the transmission was successful or not.

- 1. Press —, 3DEF, 4GHI.
- Use to highlight a sent message. Press Left Soft Key
 Resend to resend the
 - message to the recipient,
 - ok View to view the message, or Right Soft Key
 - Options to access additional options (below):

Delete/ Forward/ Save Contact/ Lock(Unlock)/ Message Info/ Delete Multiple While viewing the selected sent message, press Left SoftKey Resend to resend the message to the recipient, or Right Soft Key

Options to access additional options (below):

Delete Deletes the selected message.

Forward Forwards a received message to other destination address(es).

Save Contact Stores the callback number, e-mail address, and numbers in the received message into your Contacts.

Save as Templates Stores the message as a template for future messages.

Lock/Unlock Locks or unlocks the selected message. Message Info Shows the message type priority and status.

4. Drafts

Displays saved messages and draft messages.

- 1. Press **—** , **∃**□EF , **5** . . .
- 2. Use to highlight a Saved message.
 - Press OK to Edit.
 - Or press the Right Soft
 Key Options to view
 the options available
 (below):

Delete Deletes the selected message from the Drafts.

Save Contact Select Save New/ Update Existing to store the callback number, e-mail address, and numbers in the received message into your Contacts or update an existing contact already stored in memory.

Lock/Unlock Locks a message so that it is not erased if the Erase Saved or Erase All feature is used.

Delete Multiple

5. Voicemail

Allows you to hear new voice messages recorded in your voice mail box. Your phone will alert you when you receive a new voice message.

Checking Your Voicemail Box

1. Press —, [3DEF], [6MNO].

- 2. Choose from the following options:
- Press Left Soft Key Clear to clear the voicemail counter.
- Press to listen to the message(s).
- Press Right Soft Key
 Exit to return to the
 Messaging menu.

6. Templates

Allows you to display, edit, and add text phrases.

These text strings allow you to reduce manual text input into messages.

- 1. Press —, 3^{DEF}, 7^{PQKS}.
- Press Left Soft Key New to create a new template.

Enter text and press Save to save the template.

3. Use to highlight a template and press Right Soft Key Dotions, then highlight an option and press to select:

7. Settings

Allows you to configure settings for Messaging:

- 1. Press —, 3DEF, 8TW.
- 2. Use to hlight All Message/ Text Message then press .
- 3. Use to highlight one of the settings and press or to select it.

Messaging Settings Sub-Menu Descriptions

1. Entry Mode

Allows you to select the default input method between T9Word, Abc and 123.

Signature (On/ Off/ Edit)
 Allows you to make/edit a signature to automatically send with your messages.

7.1 Text Message

1. Callback # (On/ Off/ Edit)

With this feature on, you can input the callback number that will be automatically included when you send a message.

2. Delivery Notice (On/ Off)

8. Delete All

Allows you to erase the messages stored in your Inbox, Sent, or Drafts message folders. You can also erase all messages at the same time.

- 1. Press —, [3DEF], [8TUW].
- 2. Use to highlight an option: Inbox/ Sent/
 Drafts/ All Messages then press .

Recent Calls

The Recent Calls Menu is a list of the last phone numbers or Contacts entries for calls you placed, accepted, or missed. It is continually updated as new numbers are added to the beginning of the list and the oldest entries are removed from the bottom of the list.

1. Missed Calls

Allows you to view the list of missed calls; up to 40 entries.

- 1. Press —, 4st, 1^a.
- Use to highlight an entry, and press Right Soft Key Doptions for the following options:

Save/ Delete/ Delete All/ Call Timer 3. Press to return to standby mode.

2. Received Calls

Allows you to view the list of incoming calls; up to 50 entries.

- 1. Press —, [4_{GH}], [2_{ABC}].
- 2. Use to highlight an entry.

3. Dialed Calls

Allows you to view the list of outgoing calls; up to 50 entries.

- 1. Press —, 4^{GH}, 3^{DEF}.
- Use to highlight an entry.

4. All Calls

Allows you to view the list of missed, received and dialed calls; up to 120 entries.

- 1. Press —, 4_{GHI}, 4_{GHI}.
- 2. The history of all calls are displayed.

5. Call Timer

Allows you to view the duration of selected calls.

- 1. Press —, 4^{GH}, 5^{KL}.
- 2. Use to highlight a call type (below).

Last Call/ Home Calls/ Roam Calls/ All Calls

Multimedia 1. Image

Allows you to browse through the images saved on your handset.

- 1. Press OK , 4^{GH} , 4^{GH} .
- Select My Images or Default.

To review your stored pictures:

- Use your navigation key to view and scroll through the pictures.
- 4. Press the Right Soft Key

 Options for the following options:

Set as/ File Filter/ Slide Show/ Take Photo/ Delete/ Rename/ Move/Copy/ Lock/ List View/ Information/ Delete Multiple/ Sort by/ Send via Bluetooth

2. Sounds

Allows you to choose audio clips.

- 1. Press OK, 4^{GHI}, 6^{MNO}.
- Press Left Soft Key Voice to record an audio clip.
- Press Left Soft Key Sound to access My Sounds or press Record to begin recording.
 - While recording, press
 Left Soft Key Pause
 to pause, or Stop to
 stop recording.

- 4. When you are finished recording, press Left Soft Key Save to save the audio clip, Send to send the audio clip to somebody else, or Right Soft Key Options to access additional options. Use to highlight Set As/ Rename/ Delete and press S.
- Or -
- 2. Use to highlight My Sounds or Default and press .
- 3. Use to highlight the audio clip.
 - Press Left Soft Key
 Send to send the
 selected audio clip to
 somebody else (not
 available for Default
 sounds).

- Press Play to play the selected audio clip.
- Press Right Soft Key
 Options to access the following options:

For My Sounds: Set as/ File Filter/ Record Voice/ Delete/ Rename/ Move/Copy/ Lock/ Information/ Delete Multiple/ Sort by/ Send Via Bluetooth

For Default: Set as/Information

3. Record Voice

Record Voice allows you to record short verbal/voice messages.

- 1. Press —, 5^{xx}, 2^{xx}.
- 2. Press Record to record a new voice memo.
- Talk into the microphone, then press Stop. The default memo title is the date and time of recording.
- Once recording has stopped, press Right Soft Key Options to access the following:

Rename/ Delete

Browser

The Web feature allows you to view Internet content.
Accessibility and selections within this feature are dependent upon your service provider. For specific information on Web contact your service provider.

1. Start Browser

Allows you to initiate an Web session.

- 1. Press —, 6^{MNO}, 1⁸.
- An air time charges prompt can appear if the setting is enabled.
- 3. After a few seconds, you will see the home page.

Ending an Web Session

End an Web session by pressing .

Navigating Through the Browser

On-screen items may be presented in one of the following ways:

Numbered options

You can use your numeric keypad or you can select the items by moving the cursor and pressing the appropriate Soft Key(s).

Links embedded in content

You can act on the options or the links by using the Soft Keys at the bottom of the display screen.

Text or numbers

You can select the items by moving the cursor and pressing the appropriate Soft Keys.

Scrolling

Use to scroll through the content if the current page does not fit on one screen. The currently selected item is indicated by a cursor on the screen.

Fast Scrolling

Press and hold to quickly move the cursor up and down on the current screen.

Soft Keys

The Left Soft Key — is used primarily for first options or selecting an item, but its

function may change depending on the content displayed.

The Right Soft Key is used primarily for secondary options or a menu of secondary options.

Entering Text, Numbers, or Symbols

When prompted to enter text, the current text entry method appears above the Right Soft Key as abc, Sym, 123, etc. To change the input mode, press the Right Soft Key change to upper case, press

Clearing Out Text/Numbers Entered

When entering text or numbers, press to clear the

last number, letter, or symbol. Press and hold a to clear the input field completely.

Initiating a Phone Call From Web

You can make a phone call from Web if the site you are using supports the feature. The browser connection is terminated when you initiate the call. After you end the call, your phone returns to the screen from which you initiated the call.

Voice Command

Allows you to make phone calls quickly and easily by voice. Your phone recalls the number from your Contacts, displays it briefly, and then dials it. This menu also includes features that are useful for those who are driving or blind. It delivers time information by voice and allows you to check missed calls, messages and voicemails.

1.1 Start Command

1.1.1 Call <Name> or <Number>

1. Press —, 8^{nw}, 1^a, 1^a.

Say the name as it is saved in your Contact List or say the number.

1.1.2 Voicemail

- 1. Press —, 8^{tuv}, 1.8, 1.8, 2^{ABC}.
- 2. The phone will announce any new Voicemail(s).

1.1.3 Missed Calls

You can hear details about missed calls.

1.1.4 Messages

This voice command feature will read out information from messages received.

1.1.5 Time & Date

This voice command feature will read out the current time & date.

1. Press —, 8^{TUV}, 1.8, 1.8, 5.41.

1.1.6 Help

Allows you to view more information about the features in Voice Control.

1.2 Command Mode

Allows you to choose between Normal or Speed settings. The Speed setting allows you to access the Voice Command functions more quickly with a non-verbal prompt.

1. Press —, 8^{nw}, 13,

2. Select options.

Normal/Speed

1.3 Announce Alert

Allows you to customize the Announce Alert function. Alert Announce allows you to hear more information about an incoming call in addition to, or instead of, the Ring/Ringtone.

- 1. Press —, [8^{TW}], [1[®], [3^{DBF}].
- 2. between the options: Disable/ Announce/ Announce + Ring

1.4 Train Word

Allows you to train the voice recognition for improved results.

1. Press , [8tw], [1&], [404].

 Select options.
 Voice Command/ Answer/ Digit Dial

1.5 Best Match

Allows you to customize Best Match settings.

- 1. Press —, 8^{TW}, 1.8, 5^{ML}.
- Select options.
 Match/ 4 Matches

1. Alarm Clock

Allows you to set up to five alarms. At the alarm time, any set alarm will sound the tone of your choice, and an alarm message will be displayed on the LCD screen.

- 1. Press —, 9¹⁰⁰⁷, 1.8.
- 2. Use 🗘 to highlight the alarm you wish to set, then

- press or to select it.
- 3. Press Left Soft Key Set to set the alarm time.
- 4. Use 🗘 to highlight Repeat (recurrence setting).
- Press to select one of the following.
 Once/ Daily/ Mon - Fri/ Weekends
- 6. Use to highlightRingtones, press Left Soft KeySet and select a ringtone.
- 7. Press OK Save.

2. Calendar

Allows you to store and access your agenda(s). Simply enter your appointments in the Calendar, and your phone will

alert you with a reminder.

- 1. Press —, 9¹⁰⁰⁰, 2²⁰⁰.
- 2. Use to highlight the scheduled day.
 - Moves cursor to the previous day.
 - Moves cursor to the next day.
 - Moves to the previous week.
 - Moves to the next week.
- 3. Press Left Soft Key 🕝 New.
- Use to highlight the field you wish to edit, then press Left Soft Key Set to edit your schedule information:

3. Notepad

Allows you to add, read, edit, and erase notes to yourself.

- 1. Press —, 9^{wooz}, 3^{DEF}.
- Press Left Soft Key New to write a new note.
- 3. Type the note, then press Save.

A confirmation message displays briefly, then displays your list of notes.

Tools

Your phone is equipped with helpful tools, including: Voice Voice Command, Ez Tip Calc, Calculator, World Clock, Stopwatch, Unti Converter.

1. Calculator

Allows you to perform simple mathematical calculations. You can enter numbers up to the eighth decimal place.

1. Press **—** , □[∞] , □[∞] .

Enter data.

- Use keypad to enter numbers.
- Use ** to enter decimals.
- Use # to set as negative or positive.
- Press Left Soft Key
 Clear to the entry.
- Press Right Soft Key
 Operator for additional calculating options.
- Use Navigation Keys to enter functions.
- Press ok to complete equation.

2. Ez Tip Calc

Allows you to quickly and easily estimate the tip and total amount of a bill by inputting the bill amount before tip, the tip percentage, and dividing it by the number of people paying.

- 1. Press —, ONEST, ZARK.
- Enter the variable fields (Bill, Tip(%), Split).
- Access Notepad and highlight the entry.
- 4. Press Left Soft Key Reset for another.

3. World Clock

Allows you to determine the current time in another time zone or country.

- 1. Press , ONECT, BEEF.
- Press Right Soft Key ☐
 Cities to select a specific
 city and display the
 date/time in that location,
 then press ☒ .

- 3. Use to scroll through all available cities on the map.
- Press ok to select the highlighted city.
- Press Left Soft Key Set DST to set daylight saving time.

4. Stopwatch

Allows you to use the Stopwatch function of the phone.

- 1. Press —, Oscol, 4gel.
- Press ok Start to start, and press ok Stop to stop.
 - You can use the Lap function by pressing Right Soft Key Lap to record up to 99 laps and lap times.

5. Unit Converter

Allows you to convert units of Area, Length, Temperature, Mass, Volume and Velocity.

- 1. Press —, ONET, 5.KL.
- 2. Press the unit of measurement you want to convert:

Area/ Length/ Temperature/ Mass/ Volume/ Velocity

Settings

1. Sound

Options to customize your phone's sounds:

1.1 Ringers

Allows you to assign ringtones for incoming calls.

1. Press —, #=, 1&, 1&,

- Select All Calls/ Caller ID/ No Caller ID/ Restricted Calls/ Buy Ringtones.
- The My Audios/ Default/ Buy Ringtones folders will be displayed. Press to open the desired folder.
- 4. Use 🐧 to highlight the ringtone.
- Press Play to play the ringtone, and Left Soft Key
 Set to set the ringtone to your phone.

1.2 Volume

Allows you to set various volume settings.

- 1. Press , #==, 1 &, 2 &,
- Select Master Volume/ Keypad/ Earpiece/ Speaker.

3. Use to adjust the volume of the function, then press to save the setting.

1.3 Message Alerts

Allows you to select the alert tone for a new message.

- 1. Press —, #****, 1 &,
- Select Text Message/ Voicemail/ Message Reminder.
- 3. Use to select a setting, then press .

1.4 Alert Type

Allows you to select the alert types.

1. Press —, [#^{****}, [1[®]],

- Use to highlight the alert you wish to edit.
 Call Alert/ Message Alert/ Schedule Alert/ Alarm Alert
- 3. Use •• to scroll through the alert types.
 Ring Only/ Vibrate Only/
 Ring & Vib
- 4. Press ok to save.

1.5 Service Alerts

Allows you to set any of the 4 Alert options to On or Off.

- 1. Press —, #*****, 1.\$,
- 2. Select an alert option.

1.5.1 Minute Beep

Alerts you 10 seconds before the end of every minute during a call.

1.5.2 Call Connect

Alerts you when the call is connected.

1.5.3 Back to Top

Alerts you when you scroll through the end of a menu list.

1.5.4 Low Battery

Alerts you when the battery charge level is low.

3. Use to On/ Off, then press old. (Options for Low Battery are: Announce/

1.6 Power On/Off Tone

Allows you to set the phone to sound a tone when the phone is powered on and off.

1. Press —, #***, 1 &, 6****.

2. Use 🐧 to set On/ Off, then press 🕟 .

1.7 Flip Tone

Allows you to set a Flip tone that will play when you Flip your phone.

- 2. Use 🗘 to set to On/ Off, then press 🕟 .

1.8 Emergency Tone

Allows you to set the phone to sound a tone when the phone is powered on and off.

- 1. Press —, #***, 1 &,
 81w .
- 2. Use to set Alert/ Vibrate/ Off, then press

2. Display

Options to customize your phone's display screen.

2.1 Wallpaper

Allows you to choose the kind of background to be displayed on the phone.

- 1. Press —, #****, ZABC, 1. #*****
- 2. My Images, Default, Buy Graphics, then press 🐼 .

2.1.1 Main Screen

Select an image or video from My Images/ Default/ Buy Wallpaper, and press Left Soft Key Set to set it as the main screen wallpaper.

2.1.2 Front Screen

Select an image or video from My Images/ Default/ Buy Wallpaper, and press Left Soft Key Set to set it as the main screen wallpaper.

2.1.3 Buy Wallpaper

Set Shuffle to On or Off, and set the repeat frequency. To add images to your Shuffle list, see page 51 for instructions.

2.2 Backlight

Allows you to set the duration for illuminating the backlight.

- 1. Press —, #****, ZAR, ZAR,
- 2. Choose a submenu (options below), then press $\bigcirc \mathbb{K}$.

Display / Keypad / Brightness 3. Use to select a setting, then press ok.

2.3 Menu Style

Allows you to view the main Menu items as icons or on a list.

- 1. Press —, #***, ZARC,
- 2. Select **Icon** or **List** and press

2.4 Languages

Allows you to use the bilingual feature according to your preference. Choose between English and Spanish.

- 1. Press —, #**co, ZARC, 4 cre .
- 2. Use to select **English** or **Spanish**, then press ok

2.5 Clocks & Calendar

Allows you to select the type of clocks displayed on the main LCD.

- 1. Press —, [#»«, [2»«, 5»«,
- 2. Select Main Screen/ Front Screen, then press OK.

2.5.1 Main Screen

Use 🐧 to highlight an option, then press 🐼 .

Normal Clock/ Analog Clock/ Digital Clock/ Dual Clock/ Calendar/

2.5.2 Front Screen

Use 🛟 to highlight an option, then press 🐼 .

Minimize/ Digital Clock

2.6 Font Settings

Allows you to select the type of font displayed on LCD.

- 1. Press —, ###ACE, 2ABC, 6MNO.
- 2. Choose a sub-menu and press ok .

Font Type / Dial Font Style / Dial Font Size

3. Use to highlight an option, then press ok.

Options for Font Type

LG Gothhic / LG GreenTea / LG Mint / LG Round / LG Secret

Options for Dial Font Size Normal/ Large

2.7 Word Prediction

Allows you to activate word prediction, a function that uses your past text entries to predict what your next word will be.

- 1. Press OK , 9wx, 2xx, 8xx,

2.8 Name Match for Dialing

Allows you to turn Name Match for Dialing On or Off.

1. Press —, #=, 2*,

8TUV .

2. Use \(\bigcirc\) to highlight a setting, then press \(\omega\) .

3. Security

The Security menu allows you to secure the phone electronically.

3.1 Lock Phone

Keeps your phone from unauthorized use. Once the phone is locked, it is in restricted mode until the lock code is entered. You can still receive phone calls and make emergency calls. You can modify the lock code by setting a New Lock code within the Security menu.

- 1. Press **-** , **#**∞∞, **∃**□EF.
- 2. Enter the four-digit lock code and press ok.

The default lock code is commonly the last 4 digits of your phone number.

3. Press 18 Lock Phone.

4. Use to select an option, then press .

Unlock The phone will remain unlocked.

Lock The phone is locked until it is unlocked again. When locked, you can receive incoming calls and make only emergency calls.

On Power Up The phone is locked when it is turned on.

3.2 Change Lock Code

Allows you to enter a new fourdigit lock code.

- 1. Press **-** , **#**∞, **∃**□∈ .
- 2. Enter the four-digit lock code and press .
- Press Esc Change Lock Code and select Phone Only.

- 4. Enter a new 4-digit lock code and press ok.
- For confirmation, it will ask you to enter the new lock code again.

3.3 Reset Default

Allows you to reset your phone to the factory default settings.

- 1. Press **-** , **#** → , **∃** DEF .
- 2. Enter the four-digit lock code and press .
- 3. Press **∃**ost **Reset Default.**
- A message will pop up that says "Preference settings will be set to factory defaults. Press <OK> to continue." Press
 .

5. Use to highlight an option (below) and press

Revert/ Cancel.

4. Call Settings

The Call Settings menu allows you to designate how the phone handles both incoming and outgoing calls.

4.1 Answer Options

Allows you to determine how to answer an incoming call.

- 1. Press —, #****, 4***, 1.8.
- Use to select a setting (from below), then press
 .

Flip Open/ Any Key/ Send Key Only/ Flip Open/ Auto with Handsfree

4.2 Auto Retry

Allows you to set the length of time the phone waits before automatically redialing a number when the attempted call fails.

- 1. Press —, #***, 4**, 2**.
- 2. Use to select a setting, then press .

Off/ Every 10 Seconds/ Every 30 Seconds/ Every 60 Seconds

4.3 One-Touch Dial

Allows you to initiate a speed dial call by pressing and holding the speed dial digit. If set to Off, Speed Dial numbers designated in your Contacts will not function.

1. Press —, #==, 4==, 3==. 2. Use 🛟 to select a setting, then press 🐼 .

On/Off

4.4 Airplane Mode

Allows you to use features on your phone that do not require wireless communications.

- 1. Press —, #****, 464,
- 2. Read the displayed message and press on to continue.
- 3. Use to select a setting, then press k.

On/Off

4.5 TTY Mode

Allows you to attach a TTY (Teletype writer) device, enabling you to communicate with parties also using a TTY device. A phone with TTY support is able to translate

typed characters to voice. Voice can also be translated into characters and then displayed on the TTY.

- 1. Press —, #****, 4***, 5**.
- 2. Read the displayed message and press to continue.
- 3. Use to select a setting, then press ok.

TTY Full/ TTY + Talk/ TTY + Hear/ TTY Off

5. System

The System menu allows you to designate specific system network settings.

5.1 Network

5.1.1 System Select

Allows you to set up the phone producer's management environment. Leave this setting as the default unless you want to alter system selection as instructed by your service provider.

- 1. Press —, #==, 5=, 1 &, 1 &.
- 2. Use 🛟 to highlight

 Home Only / Automatic

 then press 🐼 .

6.1.2 Serving System

Identifies the channel number of a system that is served as an SID Number. This information should only be used for technical support.

5.2 Location

Menu for GPS (Global Positioning System: Satellite assisted location information system) mode.

- 1. Press -, #***, 5***, 2***.
- 2. Use 🗘 to highlight a setting, then press 🗽 .

Location On/ E911 Only

6. Memory

Allows you to check out the memory status of your phone and change Save options.

- 1. Press 🗖 , 🗯 , 🗗 .
- 2. Use 🐧 to highlight
 Reserved Memory/
 Multimedia, and press 🎯 .

7. Phone Info

The Phone Info menu provides you with specific information pertaining to your phone model.

- 2. Use to highlight an option and press or press the corresponding number key.

My Number/ ESN/MEID/ Icon Glossary/ Version

Bluetooth

The Force is compatible with devices that support the Bluetooth® headset, handsfree profiles, object push and phonebook access. You may create and store several pairings within the Force and connect to one device at a time. The approximate

communication range for Bluetooth® wireless technology is up to 30 feet (10 meters).

Bluetooth QD ID B015101

Note

Read user guide of each Bluetooth® accessory that you are trying to pair with your phone because the instructions may be different.

Note

The Bluetooth® features of this handset may not be compatible with all devices which are Bluetooth® enabled; your service provider or handset manufacturer cannot be responsible for compatibility with devices not sold by the service provider or handset manufacturer.

1. Paired Devices

Pairing is the process that allows the handset to locate, establish and register 1-to-1 connection with the target device.

For pairing new Bluetooth® device

- 1. Press 🖃 , 🔀 , 🗓 .
- Follow the Bluetooth®
 accessory instructions to set
 the device to pairing mode.
- Press Left Soft Key Search to search for devices to pair. If Bluetooth® power is set to off, you will be prompted to turn power on.
 Select Yes and press X.

- The device will appear in the Add New Device menu once it has been located. Highlight the device and press .
- 5. The handset may prompt you for the passkey. Consult the Bluetooth® accessory instructions for the appropriate passkey (typically "0000" 4 zeroes). Enter the passkey and press ® .
- Once pairing is successful, select a connection preference (Always Ask/ Always Connect).
- Once connected, you will see the device listed in the Paired Devices menu.

Power

Allows you to set the power On/Off.

- 1. Press **-** , **★***, **2**∞.
- Use to select a setting, then press .
 On/ Off

Note

By default, your device's Bluetooth® functionality is turned off.

3. My Visibility

Allows you to set the visibility of your Bluetooth® function.

- 1. Press **-** , **★***, **∃**□EF.
- 2. Use to select a setting, then press or .
 Options are:

Visible/ Hidden

Note

If you turn on My Visibility, your device is able to be searched by other in-range Bluetooth® devices.

4. My Bluetooth Name

Allows you to edit the name of the Bluetooth® device.

- 1. Press —, **, 4 ···., 4 ···.
- 2. Hold down to clear the existing name.
- 3. Use the alphanumeric keypad to enter a new alias.
- 4. Press ok to save and exit.

5. My Bluetooth Info

Allows you to view the Bluetooth® information on your device.

1. Press —, ***, 46H.

Safety

TIA Safety Information

The following is the complete TIA Safety Information for wireless handheld phones.

Exposure to Radio Frequency Signal

Your wireless handheld portable phone is a low power radio transmitter and receiver. When ON, it receives and sends out Radio Frequency (RF) signals.

In August, 1996, the Federal Communications Commissions (FCC) adopted RF exposure guidelines with safety levels for handheld wireless phones. Those guidelines are consistent with the safety standards previously set by both U.S. and international standards bodies:

ANSI C95.1 (1992) *
NCRP Report 86 (1986)

ICNIRP (1996)

* American National Standards Institute; National Council on Radiation Protection and Measurements; International Commission on Non-lonizing Radiation Protection.

Those standards were based on comprehensive and periodic evaluations of the relevant scientific literature. For example, over 120 scientists, engineers, and physicians from universities, government health agencies, and industry reviewed the available body of research to develop the ANSI Standard (C95.1).

The design of your phone complies with the FCC guidelines (and those standards).

Antenna Care

Use only the supplied or an

approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the phone and may violate FCC regulations.

Phone Operation

NORMAL POSITION: Hold the phone as you would any other telephone with the antenna pointed up and over your shoulder.

Tips on Efficient Operation

For your phone to operate most efficiently:

Don't touch the antenna unnecessarily when the phone is in use. Contact with the antenna affects call quality and may cause the phone to operate at a higher power level than otherwise needed.

Driving

Check the laws and regulations on the use of wireless phones in the areas where you drive and always obey them. Also, if using your phone while driving, please observe the following:

- Give full attention to driving

 driving safely is your first
 responsibility;
- Use hands-free operation, if available;
- Pull off the road and park before making or answering a call if driving conditions or the law require it.

Electronic Devices

Most modern electronic equipment is shielded from RF signals. However, certain electronic equipment may not be shielded against the RF signals from your wireless phone.

Safety

Pacemakers

The Health Industry
Manufacturers Association
recommends that a minimum
separation of six (6) inches be
maintained between a handheld
wireless phone and a pacemaker
to avoid potential interference
with the pacemaker. These
recommendations are consistent
with the independent research
by and recommendations of
Wireless Technology Research.

Persons with pacemakers:

- Should ALWAYS keep the phone more than six (6) inches from their pacemaker when the phone is turned ON;
- Should not carry the phone in a breast pocket;

- Should use the ear opposite the pacemaker to minimize the potential for interference;
- Should turn the phone OFF immediately if there is any reason to suspect that interference is taking place.

Hearing Aids

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may want to consult your service provider (or call the customer service line to discuss alternatives).

Other Medical Devices

If you use any other personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information.

Health Care Facilities

Turn your phone OFF in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may use equipment that could be sensitive to external RF energy.

Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer or its representative regarding your vehicle. You should also

consult the manufacturer of any equipment that has been added to your vehicle.

Posted Facilities

Turn your phone OFF in any facility where posted notices so require.

Aircraft

FCC regulations prohibit using your phone while in the air. Switch OFF your phone before boarding an aircraft.

Blasting Areas

To avoid interfering with blasting operations, turn your phone OFF when in a "blasting area" or in areas posted: "Turn off two-way radio". Obey all signs and instructions.

Safety

Potentially Explosive Atmosphere

Turn your phone OFF when in any area with a potentially explosive atmosphere and obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death. Areas with a potentially explosive atmosphere are often, but not always marked clearly. Potential areas may include: fueling areas (such as gasoline stations); below deck on boats: fuel or chemical transfer or storage facilities; vehicles using liquefied petroleum gas (such as propane or butane); areas where the air contains chemicals or particles (such as grain, dust, or metal powders); and any other area where you would normally be advised to turn off your vehicle engine.

For Vehicles Equipped with an Air Bag

An air bag inflates with great force. DO NOT place objects, including either installed or portable wireless equipment, in the area over the air bag or in the air bag deployment area. If in-vehicle wireless equipment is improperly installed and the air bag inflates, serious injury could result.

Safety Information

Please read and observe the following information for safe and proper use of your phone and to prevent damage. Also, keep the user guide in an accessible place at all times after reading it.

Caution! Violation of the instructions may cause minor or serious damage to the product.

- Do not disassemble or open crush, bend or deform, puncture or shred.
- Do not modify or remanufacture, attempt to insert foreign objects into the battery, immerse or expose to water or other liquids, expose to fire, explosion or other hazard.

- Only use the battery for the system for which it is specified.
- Only use the battery with a charging system that has been qualified with the system per IEEE-Std-1725-2006. Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazard.
- Do not short circuit a battery or allow metallic conductive objects to contact battery terminals.
- Replace the battery only with another battery that has been qualified with the system per this standard, IEEE-Std-1725-2006. Use of an unqualified battery may present a risk of fire, explosion, leakage or other hazard.

- Promptly dispose of used batteries in accordance with local regulations.
- Battery usage by children should be supervised.
- Avoid dropping the phone or battery. If the phone or battery is dropped, especially on a hard surface, and the user suspects damage, take it to a service center for inspection.
- Improper battery use may result in a fire, explosion or other hazard.
- The phone shall only be connected to USB products that bear the USB-IF logo or have completed the USB-IF compliance program.

Charger and Adapter Safety

 The charger and adapter are intended for indoor use only.

- Insert the battery pack charger vertically into the wall power socket.
- Use the correct adapter for your phone when using the battery pack charger abroad.
- Only use the approved battery charger. Otherwise, you may cause serious damage to your phone.

Battery Information and Care

- Please dispose of your battery properly or take it to your local wireless carrier for recycling.
- The battery doesn't need to be empty before recharging.
- Use only LG-approved chargers specific to your phone model since they are designed to maximize battery life.
- Do not disassemble or shortcircuit the battery.

- Keep the battery's metal contacts clean.
- Replace the battery when it no longer provides acceptable performance. The battery can be recharged several hundred times before replacement.
- Recharge the battery after long periods of non-use to maximize battery life.
- Battery life will vary due to usage patterns and environmental conditions.
- Use of extended backlighting, Browser, and data connectivity kits affect battery life and talk/standby times.
- The self-protection function of the battery cuts the power of the phone when its operation is in an abnormal state. In this case, remove the battery from the phone, reinstall it, and turn the phone on.

Explosion, Shock, and Fire Hazards

- Do not put your phone in a place subject to excessive dust and keep the minimum required distance between the power cord and heat sources.
- Unplug the power cord prior to cleaning your phone, and clean the power plug pin when it's dirty.
- When using the power plug, ensure that it's firmly connected. If not, it may cause excessive heat or fire.
- If you put your phone in a pocket or bag without covering the receptacle of the phone (power plug pin), metallic articles (such as a coin, paperclip or pen) may short-circuit the phone.
 Always cover the receptacle when not in use.

- Don't short-circuit the battery. Metallic articles such as a coin, paperclip or pen in your pocket or bag may short-circuit the + and - terminals of the battery (metal strips on the battery) upon moving. Short-circuit of the terminal may damage the battery and cause an explosion.
- Do not disassemble or crush the battery. It may cause a fire.

General Notice

- Using a damaged battery or placing a battery in your mouth may cause serious injury.
- Do not place items containing magnetic components such as a credit card, phone card, bank book, or subway ticket near

- your phone. The magnetism of the phone may damage the data stored in the magnetic strip.
- Talking on your phone for a long period of time may reduce call quality due to heat generated during use.
- When the phone is not used for a long period time, store it in a safe place with the power cord unplugged.
- Using the phone in proximity to receiving equipment (i.e., TV or radio) may cause interference to the phone.
- Do not use the phone if the antenna is damaged. If a damaged antenna contacts skin, it may cause a slight burn. Please contact an LG Authorized Service Center to replace the damaged antenna.

- Do not immerse your phone in water. If this happens, turn it off immediately and remove the battery. If the phone does not work, take it to an LG Authorized Service Center.
- Do not paint your phone.
- The data saved in your phone might be deleted due to careless use, repair of the phone, or upgrade of the software. Please backup your important phone numbers. (Ring tones, text messages, voice messages, pictures, and videos could also be deleted.) The manufacturer is not liable for damage due to the loss of data.
- When you use the phone in public places, set the ringtone to vibration so you don't disturb others.

- Do not turn your phone on or off when putting it to your ear.
- Use accessories, such as earphones and headsets, with caution. Ensure that cables are tucked away safely and do not touch the antenna unnecessarily.
 - Don't short-circuit the battery. Metallic articles such as a coin, paperclip or pen in your pocket or bag may short-circuit the + and - terminals of the battery (metal strips on the battery) upon moving. Short-circuit of the terminal may damage the battery and cause an explosion.
- Do not disassemble or crush the battery. It may cause a fire.

General Notice

- Using a damaged battery or placing a battery in your mouth may cause serious injury.
- Do not place items containing magnetic components such as a credit card, phone card, bank book, or subway ticket near your phone. The magnetism of the phone may damage the data stored in the magnetic strip.
- Talking on your phone for a long period of time may reduce call quality due to heat generated during use.
- When the phone is not used for a long period time, store it in a safe place with the power cord unplugged.

- Using the phone in proximity to receiving equipment (i.e., TV or radio) may cause interference to the phone.
- Do not use the phone if the antenna is damaged. If a damaged antenna contacts skin, it may cause a slight burn. Please contact an LG Authorized Service Center to replace the damaged antenna.
- Do not immerse your phone in water. If this happens, turn it off immediately and remove the battery. If the phone does not work, take it to an LG Authorized Service Center.
- Do not paint your phone.
- The data saved in your phone might be deleted due to careless use, repair of the phone, or upgrade of the

software. Please backup your important phone numbers. (Ring tones, text messages, voice messages, pictures, and videos could also be deleted.) The manufacturer is not liable for damage due to the loss of data.

- When you use the phone in public places, set the ringtone to vibration so you don't disturb others.
- Do not turn your phone on or off when putting it to your ear.
- Use accessories, such as earphones and headsets, with caution. Ensure that cables are tucked away safely and do not touch the antenna unnecessarily.

Warning! Important safety information

Avoiding hearing damage

Permanent hearing loss may occur if you use your phone and/or headset at a high volume. Set the volume to a safe level. You can adapt over time to a higher volume of sound that may sound normal but can be damaging to your hearing. If you experience ringing in your ears or muffled speech, stop listening and have your hearing checked. The louder the volume, the less time is required before your hearing could be affected. Hearing experts suggest that to protect your hearing:

 Limit the amount of time you use your phone and/or headset at high volume.

- Avoid turning up the volume to block out noisy surroundings.
- Turn the volume down if you can't hear people speaking near you.

For information about how to set a maximum volume limit on your phone, see the features guide for your phone.

Using your phone safely

Use of your phone while operating a vehicle is not recommended and is illegal in some areas. Be careful and attentive while driving. Stop using your phone if you find it disruptive or distracting while operating any type of vehicle or performing any other activity that requires your full attention.

Avoiding hearing damage

Permanent hearing loss may occur if you use your headset at a high volume. Set the volume to a safe level. You can adapt over time to a higher volume of sound that may sound normal but can be damaging to your hearing. If you experience ringing in your ears or muffled speech, stop listening and have your hearing checked. The louder the volume, the less time is required before your hearing could be affected. Hearing experts suggest that to protect your hearing:

- Limit the amount of time you use headset at high volume.
- Avoid turning up the volume to block out noisy surroundings.

 Turn the volume down if you can't hear people speaking near yo

For information about how to set a maximum volume limit on your handset, please refer to the features guide for your handset.

Using headsets safely

Use of headsets to listen to music while operating a vehicle is not recommended and is illegal in some areas. Be careful and attentive while driving. Stop using this device if you find it disruptive or distracting while operating any type of vehicle or performing any other activity that requires your full attention.u.



FDA Consumer Update

The U.S. Food and Drug Administration's Center for Devices and Radiological Health Consumer Update on Mobile Phones:

1. Do wireless phones pose a health hazard?

The available scientific evidence does not show that any health problems are associated with using wireless phones. There is no proof, however, that wireless phones are absolutely safe. Wireless phones emit low levels of Radio Frequency (RF) energy in the microwave range while being used. They also emit very low levels of RF when in standby mode. Whereas high levels of RF can produce health effects (by heating tissue), exposure

to low level RF that does not produce heating effects causes no known adverse health effects. Many studies of low level RF exposures have not found any biological effects. Some studies have suggested that some biological effects may occur, but such findings have not been confirmed by additional research. In some cases, other researchers have had difficulty in reproducing those studies, or in determining the reasons for inconsistent results.

2. What is the FDA's role concerning the safety of wireless phones?

Under the law, the FDA does not review the safety of radiation-emitting consumer products such as wireless phones before they can be sold, as it does with new drugs or medical devices. However, the agency has authority to take action if wireless phones are shown to emit Radio Frequency (RF) energy at a level that is hazardous to the user. In such a case, the FDA could require the manufacturers of wireless phones to notify users of the health hazard and to repair, replace, or recall the phones so that the hazard no longer exists.

Although the existing scientific data do not justify FDA regulatory actions, the FDA has urged the wireless phone industry to take a number of steps, including the following:

 Support needed research into possible biological effects of RF of the type emitted by wireless phones;

- Design wireless phones in a way that minimizes any RF exposure to the user that is not necessary for device function; and
- Cooperate in providing users of wireless phones with the best possible information on possible effects of wireless phone use on human health.

The FDA belongs to an interagency working group of the federal agencies that have responsibility for different aspects of RF safety to ensure coordinated efforts at the federal level. The following agencies belong to this working group:

- National Institute for Occupational Safety and Health
- Environmental Protection Agency

- Occupational Safety and Health Administration
- National Telecommunications and Information Administration

The National Institutes of Health participates in some interagency working group activities, as well.

The FDA shares regulatory responsibilities for wireless phones with the Federal Communications Commission (FCC). All phones that are sold in the United States must comply with FCC safety guidelines that limit RF exposure. The FCC relies on the FDA and other health agencies for safety questions about wireless phones.

The FCC also regulates the base stations that the wireless phone networks rely upon.

While these base stations operate at higher power than do the wireless phones themselves, the RF exposures that people get from these base stations are typically thousands of times lower than those they can get from wireless phones. Base stations are thus not the subject of the safety questions discussed in this document.

3. What kinds of phones are the subject of this update?

The term "wireless phone" refers here to handheld wireless phones with built-in antennas, often

called "cell", "mobile", or "PCS" phones. These types of wireless phones can expose the user to measurable Radio Frequency (RF) energy because of the short distance between the phone and the user's head.

These RF exposures are limited by FCC safety guidelines that were developed with the advice of the FDA and other federal health and safety agencies. When the phone is located at greater distances from the user, the exposure to RF is drastically lower because a person's RF exposure decreases rapidly with increasing distance from the source. The so-called "cordless phones," which have a base unit connected to the telephone wiring in a house, typically operate at far lower power levels, and thus produce RF exposures far below the FCC safety limits.

4. What are the results of the research done already?

The research done thus far has produced conflicting results, and many studies have suffered

from flaws in their research methods. Animal experiments investigating the effects of Radio Frequency (RF) energy exposures characteristic of wireless phones have vielded conflicting results that often cannot be repeated in other laboratories. A few animal studies, however, have suggested that low levels of RF could accelerate the development of cancer in laboratory animals. However, many of the studies that showed increased tumor development used animals that had been genetically engineered or treated with cancer-causing chemicals so as to be pre-disposed to develop cancer in the absence of RF exposure. Other studies exposed the animals to RF for up to 22 hours per day. These conditions are not similar to

the conditions under which people use wireless phones, so we do not know with certainty what the results of such studies mean for human health. Three large epidemiology studies have been published since December 2000. Between them, the studies investigated any possible association between the use of wireless phones and primary brain cancer, glioma, meningioma, or acoustic neuroma, tumors of the brain or salivary gland, leukemia, or other cancers. None of the studies demonstrated the existence of any harmful health effects from wireless phone RF exposures. However, none of the studies can answer questions about long-term exposures, since the average period of phone use in these studies was around three years.

5. What research is needed to decide whether RF exposure from wireless phones poses a health risk?

A combination of laboratory studies and epidemiological studies of people actually using wireless phones would provide some of the data that are needed Lifetime animal exposure studies could be completed in a few years. However, very large numbers of animals would be needed to provide reliable proof of a cancer promoting effect if one exists. Epidemiological studies can provide data that is directly applicable to human populations, but ten or more years follow-up may be needed to provide answers about some health effects, such as cancer. This is because the interval between the time of exposure

to a cancer-causing agent and the time tumors develop — if they do — may be many, many years. The interpretation of epidemiological studies is hampered by difficulties in measuring actual RF exposure during day-to-day use of wireless phones. Many factors affect this measurement, such as the angle at which the phone is held, or which model of phone is used.

6. What is the FDA doing to find out more about the possible health effects of wireless phone RF?

The FDA is working with the U.S. National Toxicology Program and with groups of investigators around the world to ensure that high priority animal studies are conducted to address important questions

about the effects of exposure to Radio Frequency (RF) energy.

The FDA has been a leading participant in the World Health Organization International Electro Magnetic Fields (EMF) Project since its inception in 1996. An influential result of this work has been the development of a detailed agenda of research needs that has driven the establishment of new research programs around the world. The project has also helped develop a series of public information documents on EMF issues.

The FDA and the Cellular Telecommunications & Internet Association (CTIA) have a formal Cooperative Research And Development Agreement (CRADA) to do research on wireless phone safety. The FDA

provides the scientific oversight, obtaining input from experts in government, industry, and academic organizations. CTIA-funded research is conducted through contracts with independent investigators. The initial research will include both laboratory studies and studies of wireless phone users. The CRADA will also include a broad assessment of additional research needs in the context of the latest research developments around the world.

7. How can I find out how much Radio Frequency energy exposure I can get by using my wireless phone?

All phones sold in the United States must comply with Federal Communications

Commission (FCC) guidelines that limit Radio Frequency (RF) energy exposures. The FCC established these guidelines in consultation with the FDA and the other federal health and safety agencies. The FCC limit for RF exposure from wireless phones is set at a Specific Absorption Rate (SAR) of 1.6 watts per kilogram (1.6 W/kg). The FCC limit is consistent with the safety standards developed by the Institute of Electrical and Electronic Engineering (IEEE) and the National Council on Radiation Protection and Measurement. The exposure limit takes into consideration the body's ability to remove heat from the tissues that absorb energy from the wireless phone and is set well below levels known to have effects. Manufacturers of wireless phones must report the RF

exposure level for each model of phone to the FCC. The FCC website

(http://www.fcc.gov/oet/rfsafety) gives directions for locating the FCC identification number on your phone so you can find your phone's RF exposure level in the online listing.

8. What has the FDA done to measure the Radio Frequency energy coming from wireless phones?

The Institute of Electrical and Electronic Engineers (IEEE) is developing a technical standard for measuring the Radio Frequency (RF) energy exposure from wireless phones and other wireless handsets with the participation and leadership of FDA scientists and engineers. The standard, "Recommended Practice for

Determining the Spatial-Peak Specific Absorption Rate (SAR) in the Human Body Due to Wireless Communications Devices: Experimental Techniques", sets forth the first consistent test methodology for measuring the rate at which RF is deposited in the heads of wireless phone users. The test method uses a tissuesimulating model of the human head. Standardized SAR test methodology is expected to greatly improve the consistency of measurements made at different laboratories on the same phone. SAR is the measurement of the amount of energy absorbed in tissue, either by the whole body or a small part of the body. It is measured in watts/kg (or milliwatts/g) of matter. This measurement is used to

determine whether a wireless phone complies with safety guidelines.

9. What steps can I take to reduce my exposure to Radio Frequency energy from my wireless phone?

If there is a risk from these products — and at this point we do not know that there is — it is probably very small. But if you are concerned about avoiding even potential risks, you can take a few simple steps to minimize your exposure to Radio Frequency (RF) energy. Since time is a key factor in how much exposure a person receives, reducing the amount of time spent using a wireless phone will reduce RF exposure. If you must conduct extended conversations by wireless phone every day, you could place more distance between

your body and the source of the RF, since the exposure level drops off dramatically with distance. For example, you could use a headset and carry the wireless phone away from your body or use a wireless phone connected to a remote antenna. Again, the scientific data do not demonstrate that wireless phones are harmful. But if you are concerned about the RF exposure from these products, you can use measures like those described above to reduce your RF exposure from wireless phone use.

10. What about children using wireless phones?

The scientific evidence does not show a danger to users of wireless phones, including children and teenagers. If you want to take steps to lower exposure to Radio Frequency (RF) energy, the measures described above would apply to children and teenagers using wireless phones. Reducing the time of wireless phone use and increasing the distance between the user and the RF source will reduce RF exposure.

Some groups sponsored by other national governments have advised that children be discouraged from using wireless phones at all. For example, the government in the United Kingdom distributed leaflets containing such a recommendation in December 2000. They noted that no evidence exists that using a wireless phone causes brain tumors or other ill effects. Their recommendation to limit wireless phone use by children was strictly precautionary; it was not based on scientific

evidence that any health hazard exists.

11. What about wireless phone interference with medical equipment?

Radio Frequency (RF) energy from wireless phones can interact with some electronic devices. For this reason, the FDA helped develop a detailed test method to measure Flectro Magnetic Interference (EMI) of implanted cardiac pacemakers and defibrillators from wireless telephones. This test method is now part of a standard sponsored by the Association for the Advancement of Medical Instrumentation (AAMI). The final draft, a joint effort by the FDA, medical device manufacturers, and many other groups, was completed in late 2000. This

standard will allow manufacturers to ensure that cardiac pacemakers and defibrillators are safe from wireless phone EMI.

The FDA has tested hearing aids for interference from handheld wireless phones and helped develop a voluntary standard sponsored by the Institute of Flectrical and Electronic Engineers (IEEE). This standard specifies test methods and performance requirements for hearing aids and wireless phones so that no interference occurs when a person uses a "compatible" phone and a "compatible" hearing aid at the same time. This standard was approved by the IFFF in 2000.

The FDA continues to monitor the use of wireless phones for possible interactions with other

medical devices. Should harmful interference be found to occur, the FDA will conduct testing to assess the interference and work to resolve the problem.

12. Where can I find additional information? For additional information,

please refer to the following resources:

FDA web page on wireless phones (http://www.fda.gov/cellphones/)
Federal Communications
Commission (FCC) RF Safety
Program
(http://www.fcc.gov/oet/rfsafety)
International Commission on
Non-lonizing Radiation
Protection
(http://www.icnirp.de)

World Health Organization (WHO) International EMF Project (http://www.who.int/emf)

National Radiological Protection Board (UK) (http://www.hpa.org.uk/radiation/)

10 Driver Safety Tips

Your wireless phone gives you the powerful ability to communicate by voice almost anywhere, anytime. An important responsibility accompanies the benefits of wireless phones, one that every user must uphold.

When operating a car, driving is your first responsibility. When using your wireless phone behind the wheel of a car, practice good common sense and remember the following tips:

- 1. Get to know your wireless phone and its features such as speed dial and redial. Carefully read your instruction manual and learn to take advantage of valuable features most phones offer, including automatic redial and memory. Also, work to memorize the phone keypad so you can use the speed dial function without taking your attention off the road.
- When available, use a handsfree device. A number of hands-free wireless phone accessories are readily available today. Whether you choose an installed mounted device for your wireless phone or a speaker phone accessory, take advantage of these devices if available to you.

- Make sure you place your wireless phone within easy reach and where you can reach it without removing your eyes from the road. If you get an incoming call at an inconvenient time, if possible, let your voicemail answer it for you.
- 4. Suspend conversations during hazardous driving conditions or situations. Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions. Rain, sleet, snow, and ice can be hazardous, but so is heavy traffic. As a driver, your first responsibility is to pay attention to the road.

- 5. Don't take notes or look up phone numbers while driving. If you are reading an address book or business card, or writing a "to-do" list while driving a car, you are not watching where you are going. It is common sense. Do not get caught in a dangerous situation because you are reading or writing and not paying attention to the road or nearby vehicles.
- 6. Dial sensibly and assess the traffic; if possible, place calls when you are not moving or before pulling into traffic. Try to plan your calls before you begin your trip or attempt to coincide your calls with times you may be stopped at a stop sign, red light, or otherwise stationary. But if you need

- to dial while driving, follow this simple tip -- dial only a few numbers, check the road and your mirrors, then continue.
- 7. Do not engage in stressful or emotional conversations that may be distracting. Stressful or emotional conversations and driving do not mix; they are distracting and even dangerous when you are behind the wheel of a car. Make people you are talking with aware you are driving and if necessary, suspend conversations which have the potential to divert your attention from the road.
- Use your wireless phone to call for help. Your wireless phone is one of the greatest tools you can own to protect yourself and your family in

- dangerous situations -- with your phone at your side, help is only three numbers away. Dial 911 or other local emergency number in the case of fire, traffic accident, road hazard, or medical emergency. Remember, it's a free call on your wireless phone!
- 9. Use your wireless phone to help others in emergencies. Your wireless phone provides you a perfect opportunity to be a "Good Samaritan" in your community. If you see an auto accident, crime in progress or other serious emergency where lives are in danger, call 911 or other local emergency number, as you would want others to do for you.
- 10. Call roadside assistance or a special wireless nonemergency assistance number when necessary. Certain situations you encounter while driving may require attention, but are not urgent enough to merit a call for emergency services. But you can still use your wireless phone to lend a hand. If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless number.

The above tips are meant as general guidelines. Before deciding to use your mobile

device while operating a vehicle, it is recommended that you consult your applicable jurisdiction's local laws or other regulations regarding such use. Such laws or other regulations may prohibit or otherwise restrict the manner in which a driver may use his or her phone while operating a vehicle

Consumer Information on SAR

(Specific Absorption Rate)

This Model Phone Meets the Government's Requirements for Exposure to Radio Waves. Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radiofrequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. Government, These FCC exposure limits are derived from the recommendations of two expert organizations, the National Counsel on Radiation Protection and Measurement (NCRP) and the Institute of **Electrical and Electronics** Engineers (IEEE). In both cases, the recommendations were developed by scientific and engineering experts drawn from industry, government, and academia after extensive reviews of the scientific literature related to the biological effects of RF energy.

The exposure Limit for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR is a measure of the rate of absorption of RF energy by the human body expressed in units of watts per kilogram (W/kg). The FCC requires wireless phones to comply with a safety limit of 1.6 watts per kilogram (1.6 W/kg). The FCC exposure limit incorporates a substantial margin of safety to give additional protection to the public and to account for any variations in measurements.

Tests for SAR are conducted using standard operating positions specified by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. Because the phone is designed to operate at multiple

power levels to use only the power required to reach the network, in general, the closer you are to a wireless base station antenna, the lower the power output.

Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government-adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model.

This device was tested for typical body-worn operations with the back of the phone kept 0.79 inches (2.0 cm) between the user's body and the back of the phone. To comply with FCC RF exposure

requirements, a minimum separation distance of 0.79 inches (2.0 cm) must be maintained between the user s body and the back of the phone. Third-party belt-clips, holsters, and similar accessories containing metallic components should not be used. Body-worn accessories that cannot maintain 0.79 inches (2.0 cm) separation distance between the user's body and the back of the phone, and have not been tested for typical body-worn operations may not comply with FCC RFexposure limits and should be avoided.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF emission guidelines.

The highest SAR value for this model phone when tested for use at the ear is 1.24 W/kg and when worn on the body, as described in this user's manual, is 0.7 W/kg. While there may be differences between SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure.

SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of http://www.fcc.gov/oet/fccidaf ter searching on FCC ID.

To find information that pertains to a particular model phone, this site uses the phone FCC ID number which is usually printed somewhere on the case of the phone. Sometimes it may be necessary to remove the battery pack to find the

number. Once you have the FCC ID number for a particular phone, follow the instructions on the website and it should provide values for typical or maximum SAR for a particular phone.

Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications Industry Association (CTIA) website at http://www.ctia.org/

*In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6

watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

FCC Hearing-Aid Compatibility (HAC) Regulations for Wireless Devices

On July 10, 2003, the U.S. Federal Communications Commission (FCC) Report and Order in WT Docket 01-309 modified the exception of wireless phones under the Hearing Aid Compatibility Act of 1988 (HAC Act) to require digital wireless phones be compatible with hearing-aids. The intent of the HAC Act is to ensure reasonable access to telecommunications services for persons with hearing disabilities.

While some wireless phones are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing

devices are more immune than others to this interference noise, and phones also vary in the amount of interference they generate.

The wireless telephone industry has developed a rating system for wireless phones, to assist hearing device users find phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that are rated have the rating on their box or a label located on the box.

The ratings are not guarantees. Results will vary depending on the user's hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing

device is the best way to evaluate it for your personal needs.


M-Ratings: Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. M4 is the better/higher of the two ratings.

T-Ratings: Phones rated T3 or T4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. T4 is the better/higher of the two ratings.

Hearing devices may also be rated. Your hearing device manufacturer or hearing health professional may help you find this rating. Higher ratings mean that the hearing device is relatively immune to interference noise. The hearing aid and wireless phone rating values are then added together. A sum of 5 is considered acceptable for normal use. A sum of 6 is considered for best use.

In the above example, if a hearing aid meets the M2 level rating and the wireless phone meets the M3 level rating, the sum of the two values equal M5. This is synonymous for T ratings. This should provide the hearing aid user with "normal usage" while using their hearing aid with the particular wireless phone. "Normal usage" in this context is defined as a signal quality that is acceptable for normal operation.

The M mark is intended to be synonymous with the U mark. The T mark is intended to be synonymous with the UT mark. The M and T marks are recommended by the Alliance for Telecommunications Industries Solutions (ATIS). The U and UT marks are referenced in Section 20.19 of the FCC Rules. The HAC rating and measurement procedure are described in the American National



Standards Institute (ANSI) C63.19 standard.

To enter that the Hearing Aid Compatibility rating for your phone is maintained, secondary transmitters such as Bluetooth and WIAN components must be disabled during a call. See Page 52 for instructions to disable these components.

For information about hearing aids and digital wireless phones

FCC Hearing Aid Compatibility and Volume Control

http://www.fcc.gov/cgb/dro/hearing.html

Gallaudet University, RERC

http://tap.Gallaudet.edu/DigWireless.KS/DigWireless.htm

Hearing Loss Association of America [HLAA]

http://www.hearingloss.org/learn/cellphonetech.asp

The Hearing Aid Compatibility FCC Order

http://hraunfoss.fcc.gov/edocs_public/attachmatch/FCC-03-168A1.pdf

Accessories

There are a variety of accessories available for your mobile phone. Consult your local dealer for availability. Optional items are sold separately.

Battery Charger

The battery charger allows you to charge your phone battery.



Battery

Standard battery is available.



Vehicle Power Charger

The vehicle power charger allows you to operate the phone and charge the phone's battery from your vehicle.



USB Cable



Ear-mic

Limited Warranty Statement

1. WHAT THIS WARRANTY COVERS:

LG offers you a limited warranty that the enclosed subscriber unit and its enclosed accessories will be free from defects in material and workmanship, according to the following terms and conditions:

(1) The limited warranty for the product extends for TWELVE (12) MONTHS beginning on the date of purchase of the product with valid proof of purchase, or absent valid proof of purchase, FIFTEEN (15) MONTHS from date of manufacture as determined by the unit's manufacture date code.

- (2) The limited warranty extends only to the original purchaser of the product and is not assignable or transferable to any subsequent purchaser/end user.
- (3) This warranty is good only to the original purchaser of the product during the warranty period as long as it is in the U.S, including Alaska, Hawaii, U.S. Territories and Canada.
- (4) The external housing and cosmetic parts shall be free of defects at the time of shipment and, therefore, shall not be covered under these limited warranty terms.

- (5) Upon request from LG, the consumer must provide information to reasonably prove the date of purchase.
- (6) The customer shall bear the cost of shipping the product to the Customer Service Department of LG. LG shall bear the cost of shipping the product back to the consumer after the completion of service under this limited warranty.

2. WHAT THIS WARRANTY DOES NOT COVER:

 Defects or damages resulting from use of the product in other than its normal and customary manner.

- (2) Defects or damages from abnormal use, abnormal conditions, improper storage, exposure to moisture or dampness, unauthorized modifications. unauthorized connections. unauthorized repair, misuse, neglect, abuse, accident, alteration. improper installation, or other acts which are not the fault of LG, including damage caused by shipping, blown fuses, spills of food or liquid.
- (3) Breakage or damage to antennas unless caused directly by defects in material or workmanship.

Limited Warranty Statement

- (4) That the Customer Service Department at LG was not notified by consumer of the alleged defect or malfunction of the product during the applicable limited warranty period.
- (5) Products which have had the serial number removed or made illegible.
- (6) This limited warranty is in lieu of all other warranties, express or implied either in fact or by operations of law, statutory or otherwise, including, but not limited to any implied warranty of marketability or fitness for a particular use.
- (7) Damage resulting from use of non-LG approved accessories.

- (8) All plastic surfaces and all other externally exposed parts that are scratched or damaged due to normal customer use.
- Products operated outside published maximum ratings.
- (10) Products used or obtained in a rental program.
- (11) Consumables (such as fuses).

3. WHAT LG WILL DO:

"LG will, at its sole option, either repair, replace or refund the purchase price of any unit that does not conform to this limited warranty. LG may choose at its option to use functionally equivalent reconditioned, refurbished or

new units or parts or any units. In addition, LG will not reinstall or back-up any data, applications or software that you have added to your phone. It is therefore recommended that you back-up any such data or information prior to sending the unit to LG to avoid the permanent loss of such information."

4. STATE LAW RIGHTS:

No other express warranty is applicable to this product. THE DURATION OF ANY IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTY OF MARKETABILITY, IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY HEREIN. LG SHALL NOT BE LIABLE FOR THE LOSS OF THE USE OF THE PRODUCT.

INCONVENIENCE. LOSS OR ANY OTHER DAMAGES. DIRFCT OR CONSEQUENTIAL, ARISING OUT OF THE USE OF, OR INABILITY TO USE, THIS PRODUCT OR FOR ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY. INCLUDING THE IMPLIED WARRANTY OF MARKETABILITY APPLICABLE TO THIS PRODUCT. Some states do not allow the exclusive limitation of incidental or consequential damages or limitations on how long an implied warranty lasts; so these limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Limited Warranty Statement

5. HOW TO GET WARRANTY SERVICE:

To obtain warranty service, please call or fax to the following telephone numbers from anywhere in the continental United States:

Tel. 1-800-793-8896 or Fax. 1-800-448-4026

Or visit http://us.lgservice.com. Correspondence may also be mailed to:

LG Electronics Service- Mobile Handsets

P.O. Box 240007, Huntsville, AL 35824

DO NOT RETURN YOUR PRODUCT TO THE ABOVE ADDRESS. Please call or write for the location of the LG authorized service center nearest you and for the procedures for obtaining warranty claims.

Index

Calendar 53 Call Settings 64 Accessories 105 Call Timer 45 Add Airtime 32 Call Waiting 24 Airplane Mode 65 Caller ID 24 Airtime Display 32 Change Lock Code Airtime Info 32 63 Alarm Clock 53 Charging the Battery Alert Type 57 20 All Calls 45 Clocks & Calendar Announce Alert 52 61 Answer Options 64 Code Entry Mode Auto Retry 64 33 Command Mode 52 В Consumer Information on SAR Backlight 60 98 Battery Charge Level Contact List 34 21 Contacts 33 Best Match 53 Contacts in Your Bluetooth 67 Phone's Memory 27 Browser 48

C

Calculator 54

Buy Airtime 32

Delete All 44

22

Correcting Dialing

Dialed Calls 45 Display 59 Drafts 41

Ε

Emergency Tone 59 Entering and Editing Information 26 Ez Tip Calc 55

F

FCC Hearing-Aid Compatibility (HAC) Regulations for Wireless Devices 101 FDA Consumer Update 83 Flip Tone 59 Font Settings 61 For Your Safety 75

G

Getting Started with Your Phone 20

Index

Groups 35

ı

Image 46 Important Safety Precautions 1 Inbox 39 Index 111

L

Languages 60 Limited Warranty Statement 106 Location 66 Lock Phone 62

M

Making a Call From Your Phone's Memory 30 Making Calls 22 Memory 66 Menu Style 60 Menus Overview 17 Message Alerts 57 Messages 36 Missed Calls 44 Multimedia 46 Mute Function 24 My Bluetooth Info 69 My Bluetooth Name 69 My Phone Number

My vCard 35 My Visibility 69

N

32

Name Match for Dialing 62 Network 66 New Contact 33 New Message 36 Notepad 54

0

One-Touch Dial 64

Р

Paired Devices 68 Phone Info 67 Phone Numbers With Pauses 27 Phone Overview 15 Power 69 Power On/Off Tone 58 Prepaid 32

Q

Quick Access to Convenient Features 24 Quick Volume Adjustment 24

R

Received Calls 45 Receiving Calls 23 Recent Calls 44 Record Voice 48 Redialing Calls 23 Reset Default 63 Ringers 56

S

Safety 70 Safety Information 75 Screen Icons 22 Searching Your Phone's Memory 29 Security 62 Sent 40 Serial Number 33 Service Alerts 58 Settings 43, 56 Signal Strength 22 Sound 56 Sounds 46 Speed Dialing 25 Speed Dials 36 Start Browser 48 Start Command 51 Stopwatch 56 System 65

т

Table of Contents 4
Technical Details 9
Templates 42
Text Input 26
Text Message 43
The Basics of Storing
Contacts Entries 27
The Battery 20
TIA Safety
Information 70
Tools 54
Train Word 52
TTY Mode 65
Turning the Phone

u

Unit Converter 56 Using Phone Menus 32

On and Off 21

٧

Voice Command 51

Voicemail 42 Volume 57

W

Wallpaper 59
Warning! Important
safety information
81
Welcome 8
Word Prediction 62
World Clock 55