

These settings configure seamless roaming between multiple EKI6333AC-2GD access points.

Important: Roaming works when the access points are connected to each other via Ethernet (wired backhaul).

To configure each access point:

1. Connect a computer directly to the AP using an Ethernet cable.
2. Configure each AP individually using the settings below.

Settings	AP1	AP2 (and any other APs)
<u>Basic</u>		
• Operation Mode	Access Point	Access Point
• 2G SSID	AMR-AP-2G	AMR-AP-2G
• 5G SSID	AMR-AP-5G	AMR-AP-5G
• Channel	Any	Any (different from AP1)
<u>Advanced</u>		
• Transmission Power	Change for signal strength desired	Change for signal strength desired
<u>Security</u>		
• Security Mode	WPA-Personal	WPA-Personal
• WPA Version	WPA2	WPA2
• WPA Cipher	TKIP+AES	TKIP+AES
• Pass Phrase	Same	Same
• 802.11r	Enabled	Enabled
• NAS ID	Same	Same
• Mobility Domain	Same	Same
<u>LAN</u>		
• Network Mode	Static	Static

• LAN IP	192.168.1.2	192.168.1.3
• Subnet Mask	255.255.255.0	255.255.255.0
• Gateway	None	None
• DNS	None	None
• DHCP Server	Enabled	Disabled
• Start IP	192.168.1.100	None

Notes

- Use the same SSIDs, security settings, NAS ID, and Mobility Domain on every AP.
- Assign each AP a unique static LAN IP address.
- Configure different Wi-Fi channels on neighboring APs to reduce interference.
- Adjust transmit power as needed to provide the desired overlap between AP coverage areas for smooth roaming.
- **Do not** set network mode to DHCP. This changes the AP's IP address to that of the router it is connected to. If no router is connected, it will not receive an IP address and will need to be reset in order to access.
(no router -> no ip -> cannot access -> hard reset)