
Kirk-Rudy, Inc. Instruction and Parts Manual KR319N NetJet



Manufactured by Kirk-Rudy, Inc.

Before using this machine, all operators must study this manual to understand and follow the <u>safety warnings and instructions</u>. Keep these instructions with the machine for future reference. If you have any questions, contact your local Kirk-Rudy, Inc. Distributor.

10000-319N REV. 1 03/07/05



TABLE OF CONTENTS

<u>SECTION</u>	DESCRIPTION	PAGE
1	IMPORTANT SAFETY INSTRUCTIONS	3
2	SPECIFICATIONS	4
3	INSTALLATION	5
4	OPERATING INSTRUCTIONS 4.1 BASE ELECTRICAL OPERATION 4.1.1 OVERVIEW OPERATOR CONTROLS 4.1.2 PLUG INTERFACES 4.2 SKID BARS	6 6 7 8
5	PARTS LISTS AND DIAGRAMS	9-12
6	ELECTRICAL SCHEMATICS AND PARTS	13
7	APPENDIX	14
8	NOTES	15
9	WARRANTY AND SERVICE INFORMATION	16

NOTE: FIGURES AND DIAGRAMS ARE NOT INCLUDED IN PAGE NUMBERS.

1 Important Safety Instructions

Usage for other purposes may lead to unsafe condition.

SAVE THESE INSTRUCTIONS. Read all instructions before using this product.



WARNING

- * NEVER OPERATE THE MACHINE WITHOUT ALL GUARDS OR SAFETY DEVICES IN PLACE.
- * ALWAYS TURN POWER OFF WHEN MAKING ADJUSTMENTS.
- * ALWAYS DISCONNECT THE POWER SUPPLY BEFORE ANY MAINTENANCE OR SERVICE WORK.
- * NEVER START THE MACHINE WITHOUT FIRST CHECKING ALL PERSONNEL ARE CLEAR OF MOVING PARTS.
- * KEEP FINGERS CLEAR OF ALL MOVING PARTS.
- * NEVER REMOVE THE PRODUCT FROM THE MACHINE WHILE MACHINE IS RUNNING.
- * SHOULD MISFED PRODUCT JAM THE MACHINE AND STOP IT FROM RUNNING, ALWAYS PRESS THE STOP BUTTON BEFORE CLEARING PRODUCT. IF THE STOP BUTTON IS NOT PRESSED AND THE JAM IS CLEARED, THE MACHINE WILL BEGIN RUNNING.
- * IT IS NOT RECOMMENDED THAT LOOSE CLOTHING, JEWELRY AND LONG HAIR BE WORN WHILE OPERATING THIS MACHINERY.
- * ALWAYS USE AN EXPERIENCED ELECTRICIAN WHEN TROUBLE-SHOOTING ELECTRICAL PROBLEMS.
- * CHANGES OR MODIFICATIONS TO THIS UNIT NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

2 SPECIFICATIONS

ELECTRICAL

110 VAC, 50/60Hz, Single Phase, 15 amp

PHYSICAL SIZE	ENGLISH	METRIC
Length:	32.25"	82 cm
Width:	29.44"	75 cm
Height: (TABLETOP)	33.5"	85 cm
W/aialata		

Weight:

Shipping:

PRODUCTS

Minimum Size: 3"W X 5"L Maximum Size 15" W X 9" L

^{*}Limited print area

3 INSTALLATION

3.1 UNCRATING AND UNPACKING



WARNING

Read and follow all Safety Instructions in Section 1, Page 3 before proceeding.

The machinery is crated. Remove machines and all packaging from crates. <u>Note:</u> Some boxes are located inside the base cabinet.

Note: A forklift should be used to lift machine form pallet.

The Base is mounted on rollers.

3.2 ACCESSORIES AND SPARE PARTS

The accessories and spare parts are packaged and located inside the base cabinet. The box should be opened and checked against the enclosed packing list.

3.3 ASSEMBLY OF BASE

NOTE: Read all Safety and Operating Instructions contained in this manual before beginning operation and assembly.

1. Locate machine in final location and mount the (4) 4" leveling screws and pads on the corners of the machine.

4 OPERATING INSTRUCTIONS

4.1 BASE – ELECTRICAL OPERATION

4.1.1 OVERVIEW OPERATOR CONTROLS



WARNING

Read and follow all Safety Instructions in Section 1, Page 3 before proceeding.

The following controls are located on the operator side of the feeder base. (FIG. 1 & 2)

Main Power Off Button (red, white circle, yellow plate): Pressing this button cuts the power to the entire machine. Twist to unlatch.

<u>Main Power On Button:</u> When this two-position switch is depressed, source voltage is supplied to the electrical panel and button will light up. This will make all of the switches on the electrical control panel active.

<u>Stop Button (red plate)</u>: Machine operation can be manually stopped by depressing the stop button on the operator panel. Twist to unlatch.

<u>Jog Button (black)</u>: The machine can be inched or jogged by depressing and releasing this button. The machine will continue to cycle if this button is held depressed.

<u>Start Button (green):</u> Continuous machine operation is achieved by depressing this button momentarily and releasing.

<u>Speed Control, Table Conveyor:</u> The knob controls the speed of the belts on the table. This speed should be set slightly greater than the feeder speed. Turn knob clockwise to increase belt speed, counterclockwise to decrease.

<u>Feeder Stop Switch:</u> When this two-position switch is depressed the feeder portion of the machine will turn off. The feeder that is controlled is dependent on the position of the 319N mode switch. The rest of the machine past the feeder will continue to operate.

Printer Switch: On/Off switch for NetJet Printer.

4.1.2 PLUG INTERFACES

Plug Description	Plug Type
NetJet controller interface Plugs (see figure #1)	
NetJet/319N	8-Pin
Encoder	9-Pin
Product Beamswitch	4-pin
Stop In	2-pin Turck
Power Supply Plugs:	
120 Vac, 8 Amp	Standard 120VAC Outlet
Stop Plug:	
Conveyor Stop: Contact Closure	Male 3-Pin Twist Stop Out Socket

Netjet Controller Output Signals

<u>Conveyor Speed Up:</u> The conveyor speed up/stacker cycle output signal is used for two different functions depending on which machine is placed inline with the 319N. The conveyor speed up is used to control speed up on a shingle conveyor for address breaks. The NetJet controller determines the amount of time for the speed up.

Feeder Stop: The feeder stop function is used to stop the shuttle motor at the end of a run.


Side Guides:

Position side guides to within 1/8" of mailing piece as it is propelled across entire tabletop. Rotate the two knurled hand knobs at each end of the side guides and rotate ½ turn counterclockwise to allow movement of guides--to lock, rotate knobs clockwise while twisting with slight pressure. Each side guide can be pivoted left to right by loosening the allen screws in side guide mounting blocks-when pivoted the guide will raise and allow clearance between table belts and label head pressure rollers. (Caution: Do not position guides directly over table belt(s) or label head pressure roller(s). The guide mounting screws can be left slightly loose for faster set-up when guide movement is required.

4.2 SKID BAR

The skid bar rides on top of the product to help transport the mailing piece across the tabletop. The skid bar should be placed over one of the tabletop belts for best results. To move the skid bars locate and loosen the 1/8" hex head set screws in the lock collars on the right-hand side of the machine. The left-hand side of the machine has a lock collar and a skid bar block that is held in place with a 5/32" hex head screw. The KR215B is furnished with one skid bar, and is not needed when running small pieces such as cards or envelopes but can be installed when running large or heavy product.

Attached to one end of the skid bars is a "jam detector switch" on certain machines. This switch, when properly set, will stop the machine when a jam or double feed occurs.



To set the skid bar, rotate the machine until a mailing piece is under the skid bar. Loosen the 5/32" hex head screw on the skid bar block. Adjust until the skid bar is resting on the mailing piece and the skid bar rollers rotate as the product is transported. Lock in place with the 5/32" hex head screw.

The jam switch is adjusted by loosening the lock nut, moving the adjustment knob in or out and tightening the lock nut. The microswitch should disengage and stop the machine when a jam or double feed occurs.

NOTE: The machine will not run if the jam switch is not set properly (see Section 4.2).

5 PARTS LISTS AND DIAGRAMS

This section contains the entire mechanical bill of materials and assembly drawings.


Item #	Qtv	Part #	Description
1	4	100133	BUSHING, SL.500ID.625OD.375LG
2	2	100162	BUSHING, SL.500ID.625OD.625LG
3	2	100306	BUSHING, FL.375ID.500OD.500LG
4	2	100338	BUSHING, FL1.000ID1.2500D1.500LG
5	1	102112	KNOB
6	1	102114	KNOB
7	2	102132	KNOB, 10-32 CAP SCREW
8	1	102205	COLLAR .500
9	2	102210	COLLAR .188
10	2	102306	SHIM, .375X.625X.031
11	4	102792	SPRING, EXTENSION
12	2	102906	BEARING, LINEAR SLEEVE OPEN
13	2	103107	BEARING, FLAT .312
14	4	103804	BEARING, HUB .625
15	2	104100	SNAPRING, .375
16	1	105201	PIN, ROLL .125X 1.000
17	8	105419	DOWEL, PIN .188X1.000
18	1	105602	SHAFT, THREADED 10-32
19	1	109319	PULLEY, TIMING 32L050 .625B .188K
20	1	109847	PULLEY, 28XL037 .625B NK
21	1	109848	PULLEY, 26XL037 .375B NK
22	1	109953	TIMING PULLEY, 12L050, NO HUB
23	2	110163	SPRKT, 25B11 .375B NK
24	1	190101	MICROSWITCH, LEVER
25	1	190203	COVER, MICROSWITCH
26	1	190234	LIGHT INDICATOR
27	4	190634	FOOT, MOUNTING
28	2	190669	CASTER, 3.500 RIGID
29	2	190670	CASTER, 3.500 SWIVEL
30	2	190771	SCALE, CENTER ZERO
31	4	191002	ANGLE, LEVELING LEG SUPPORT
32	4	191004	LEG, BASE ASSEMBLY
33	4	191214	BOARD, INTERFACE TERMINAL
34	1	191227	ETHERNET HUB SWITCH
35	1	200129	BLOWER, FAN
36	1	200501	RECEPTACLE, AMPHENOL 4 PIN
37	1	201121	BUTTON, START
38	1	201122	BUTTON, STOP
39	1	201123	BUTTON, JOG
40	1	201145	SELECTOR, 2 POSITIONS
41	1	202492	ENCODER, ACCU-CODER 1000PPR
42	1	202531	POWER SUPPLY
43	1	202532	BOARD I/O 110V
44	4	208517	SPACER, .17ID .37OD .63LG


45	2	209016	KNOB, POT
46	2	209286	RELAY, ODC15
47	4	500791	POST, SIDEGUIDE
48	2	500792	POST, SIDE GUIDE
49	1	500800	LINK-SKID-FRONT
50	1	500801	LINK-SKID-REAR
51	1	500802	HOLDER-SKID SWITCH
52	1	500823	SHAFT,IDLER ROLLER
53	2	500834	SHAFT, SKID ROLLER
54	1	500835	ROLLER, BELT IDLER
55	2	500836	HUB
56	2	500839	HUB-BELT DRIVE
57	4	501629	CLAMP, GUIDE STRIP
58	1	503794	CLAMP
59	1	508593	CLAMP
60	4	102131-5	KNOB
61	4	105901-19	BELT, GREEN 3/4 X 68.75
62	1	108988-1	BELT, TIMING 540L050
63	1	109006-1	BELT, TIMING 150XL037
64	1	110021-17	CHAIN, NO. 25 X 47.5 IN.
65	1	190619-1	PLATE, NAME
66	1	190689-1	DOOR LATCH
67	1	191029-1	PUMP, MOVOTEC PB4612FC
68	4	191029-2	CYLINDER, LIFT CB415
69	4	191029-3	GLIDE, SUSPA
70	2	191195-1	HEAD, NETJET 1.5IN
71	2	191195-2	HEAD, NETJET 1.5IN
72	2	191195-3	HEAD, NETJET 1.5IN
73	2	191195-4	HEAD, NETJET 1.5IN
74	1	200170-2	MOTOR, 1/8HP DC GEAR
75	5	200503-3	RECEPTACLE, 8 PIN MALE
76	1	200512-1	RECEPTACLE, 9 PIN MALE
77	1	201124-1	BUTTON, POWER
78	1	201125-2	BUTTON, MUSHROOM STOP
79	1	201563-1	SWITCH, POWER
80	1	202734-1	BASE FLKM-2I/O
81	1	208503-5	FAN, CONTROL BOX 115V 3.1" SQUARE
82	1	208504-2	GUARD, FINGER
83	1	208505-1	FAN GUARD, 3.125"
84	1	500341-1	SHAFT, LIFT
85	1	500341-1	SHAFT, LIFT
86	1	500722-24	L RAIL, GUIDE LH
87	1	500722-24	R RAIL, GUIDE RH
88	1	500722-24	CHANNEL, SKID
89	2	500725-0	GUIDE, BELT 3/4
90	1	500725-13	GUIDE, BELT
91	1	500723-17	ROLLER, TUBE BELT DRIVE
92	2	500742-4	SHAFT, SIDE GUIDE ADJ
93	1	500787-0	SHAFT-BELT GUIDE
93	_ <u>'</u> 4	500824-7	LEG, LEVELING
34	4	001012-1	LLO, LLVLLING


95	1	508995-7	SHAFT, BEAMSWITCH MOUNT
96	1	508996-2	PHOTOCELL BRACKET
97	1	528247-2	BOX, CONTROL
98	1	530441-01	BOX, ELECTRICAL INLET 20A
99	1	531024-03	PANEL, INFEED END
100	1	531025-03	PANEL, OUTFEED END
101	2	531026-03	ANGLE, CROSS SUPPORT
102	1	531027-02	BASE, CABINET
103	1	531028-11	PANEL, ELECTRICAL
104	1	531028-13	PNL, BACK R/H
105	1	531033-07	TABLETOP, VACUUM CONVEYOR
106	1	531034-04	SHAFT, ROLLER DRIVE
107	1	531678-02	BAR, SCALE SUPPORT
108	1	531987-02	PNL, ELECT. OUTLET CVR.
109	1	532115-04	UP-RIGHT, CENTER
110	1	532128-02	TRAY, KEYBOARD
111	1	532153-01	TUBING, VERTICAL
112	1	532154-01	HOUSING, PIVOT
113	1	532157-01	SPACER, PIVOT
114	2	532163-01	STAND, BELT GUIDE
115	1	532164-01	BRACKET, INTERFACE
116	1	532467-01	SHAFT, DRYER PIVOT
117	1	532475-01	MOUNT, MOTOR
118	4	537371-01	BRACKET, SPRING RETURN MOUNT
119	4	537596-01	BLOCK, HYDRAULIC LIFT LH
120	4	537596-02	BLOCK, HYDRAULIC LIFT RH
121	2	537597-01	BRACKET, HYDRAULIC LIFT SPRING
122	2	537597-02	BRACKET, HYDRAULIC LIFT SPRING
123	4	538146-01	SHAFT, BRACKET SUPPORT
124	2	538147-01	SHAFT , VERTICAL SUPPORT
125	2	538149-01	HOUSING, LINEAR BEARING
126	2	538150-01	PLATE, VERTICAL MOUNT
127	1	538151-01	PLATE, SCREW SUPPORT
128	2	538152-04	PLATE, INKJET STAND MOUNT
129	2	538154-01	COVER, LINEAR SLIDE RH
130	2	538154-02	COVER, LINEAR SLIDE LH
131	1	538155-01	COVER, CHAIN
132	2	538167-01	PLATE, SHAFT SUPPORT
133	4	538168-01	SHAFT, HEAD SUPPORT
134	2	538178-01	STRAP, RIBBON CLAMP
135	2	538270-01	PLATE, VERTICAL INKJET MNT.
136	4	538271-01	BLOCK, BUSHING MOUNT
137	2	538273-01	CAM, INKJET LEVEL
138	2	538280-01	BLOCK, SLIDE LOCK
139	2	538300-01	COLLAR, SLED LOCK
140	2	538305-01	INDICATOR, SCALE RH
141	2	538305-02	INDICATOR, SCALE LH
142	1	538343-01	TRAY, MOUSE PAD
143	1	538502-01	BOX, COMPUTER TOWER
144	1	538502-02	FLAT PANEL, COMPUTER TOWER


145	4	540185-01	PLATE, NETJET HEAD MOUNT
146	1	541023-01	PLATE, ENCODER MOUNT
147	1	541024-01	BRACKET, ENCODER MOUNT
148	1	542188-01	PANEL, BLOWER BOX MOUNT
149	1	542190-01	BRACKET, BLOWER MOUNT
150	1	542191-01	DOOR, BLOWER BOX
151	2	542192-01	BRACKET, L DOOR STOP
152	2	542194-01	FRAME, 319W
153	1	542195-01	TRAY, VACUUM
154	1	542196-01	COVER, BELTS OUTFEED
155	1	542198-04	BRACKET, NETJET BOX
156	2	542871-01	STRAP, 319B 3/8 X 29 IN.
157	2	544426-01	BAR, INFEED SKIDPLATE MOUNT
158	8	544431-01	RAISER, PIN
159	4	544432-01	RAISER, CLIP
160	2	544433-02	SKIDPLATE, WIDE
161	1	546002-01	BOX, ELECTRICAL
162	1	546003-01	DOOR, HINGED ELECTRICAL BOX
163	1	546004-01	PANEL, WIRING
164	1	546005-01	HINGE, 11IN LG
165	2	546006-01	PANEL, FLANGE
166	2	546009-01	MOUNT, I/O BOARDS
167	1	546010-01	SHAFT, .25 DIA
168	1	546012-01	PLATE, CONNECTORS
169	1	546013-01	PLATE, POWER SUPPLY
170	1	COMPUTER_	CPUCOMPUTER, CPU TOWER
171	1	DINRAIL-0	1 DIN RAIL, 2.5" LG
172	1	KEYBOARD	KEYBOARD
173	1	MONITOR	15 IN. MONITOR
174	2	SP37359	SHAFT, SKID BAR SPACER


319N	ECM BY XXX XXX XXXX	NC. -RG1
KR	DESCRIPTION A	KIRK - RUDY KENNESAW, C 319N
DRAWING B	BO THE TOTAL PROPERTY OF THE P	KEN KEN 31.9
	202	WIT DENTIAL S DRAWING REPRODUCED INTERPRETATION I 44 USA
		PROPRIETARY AND CC NO PORTION OF THI NAY BE JUDICED OF IN ANY ESS WRITTER IOF OF KIRK-RUDI NENNESAW, GA 31 1111E:
		19N
		141 RD 1
		N / N / N / N / N / N / N / N / N / N /
	BOX VERS MOD W/AB	MITERIAL: OF ES HEAT TREAT: HEAT TREAT: S S TIMISH: S TREAT: TREAT:
	CONTROL INKJET (ET & COV T PRINT BAR/SENS	UNLESS OTHERWISE NOTED TX TXX ANG. OI .005 .5 REMOVE ALL BURRS AND SHARP EDGES UNITES OTHERWISE NOTED ALL BURRS AND SHARP EDGES UNITES OTHERWISE NOTED ALL BURRS OND TO STALE - WORK TO DIMENSIONS ONLY
	DESCRIPTION ASSY, 324M ASSY, 319 W ASSY, CABIN ASSY, NETJE ASSY, SKID	SCALE O O O O O O O O O O O O O O O O O O O
	533132-01 533195-04 533196-07 538169-21 538188-04	SCALE O, (DATE O 7 - M (
	7 E M OTY P P P P P P P P P P P P P P P P P P P	CHECKED BY:












DRAWING 1 53802 - 0		NO N						91)													\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \		-	KR21	AND CONCIDENT	MAY BE QUOTED OR REPRODUCED WAY BE QUOTED OR REPRODUCED K F NNF S AW GF OR S C C C C C C C C C C C C C C C C C C		MASSY, SKID BAR	538021-01	
			- 1			00	32	6					VER			(4)		SING N	(18) (5)	(12))					MATERIAL -	N/A	HEAT TREAT:	SSS N/A WORD: 9 J	N/A SHETTINGS N/A	
	PART # DFSCRIPTION	ALOOS IS SWIHSIIB CS	KNOB		BEARING,	1 =	105602 SHAFT, THREADED 10-32	MICROS		500802 HOLDER-SKID-KEAK		503794 CLAMP	ASSY-SWIT	500723-8 CHANNEL, SKID	500800-A ASSY, LINK	500801A ASSY, LINK	ASSY, CLAMP	ASSY, STUD WITH	SP37359 SHAFT, SKID BAR SPACER		2				SCALE 0.500	SCALE) 750 DINENSIONAL TOLER UNLESS OTHERWISE	500. 10.	B B - NON -	MASTER ALL DIMENSIONS ARE FINISHED DIMENSIONS ON TO DIMENSIONS ON TO DIMENSIONS ON TO DIMENSIONS ON TO	
	ITEMIOTY	6	7 1	3	4 2	5	1 9	1 1		 0 =	12 2		4	15 -	1 91	1 71	- 8-		20 2	 	12	<i>)</i>		Marie Morrison	-	DRAWN BY:	AYB	CHECKED BT:		TRACED BT:	

										****			····									т	· · · · · · · · · · · · · · · · · · ·			1
18-691	ECN BY																					I KR319N	INC. SEORGI		W/AB	8169-21
DRAWING 11 538	DESCRIPTION							/	(25	8	•	9 43	$\langle \mathbb{N}$. ~\^{	4			\				KIRK - RUD ENNESAW,		INT MOD	53
DRAW	DATE						<	/ \							9/			2)						JET PR	
	RE V NO								\			3) 	(x)					AND CONFIDENTIAL OF THIS DRAWING D OR REPRODUCED NM WITHOUT THE TTEN PERMISSION	30	SY, NET	
										\									9				ION PROPRIETARY AND NO PORTION OF THE NATION	KENNESAW,	AS	DRAWING B
																5 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		X		(m)		THIRD ANGLE PROJECTION	MODEL:	3 9 N	SHEET NO. : 5
													`			WE THE				\(\sqrt{\chi}\)			×	×	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	×
																			~			\	WATERIAL:	HEAT TREAT:		XXX
		ZERO	I.51N	PORT	ADJ. RH		UPPORT	CLAMP	MOUNT												7	<i>)</i>	DIMENSIONAL TOLERANCES UNLESS OTHERWISE NOTED .xx xxx AMG.			FILITIONS ARE FINISHED DIMENSIONS DO NOT SCALE - WORK TO DIMENSIONS ONLY
	DESCRIPTION	LE, CENTER	NETJET	, SCALE SUPPORT	Y, VERTICAL	Ι.			_											<i>)</i>						FINISHE DO NOT TO DIM
	#	71 SCALE		531678-02 BAR,	538153-06 ASSY			1	1														scale 0.250	07 - Mar - 05	The state of the s	2
	TY PART	190771	191195	5316	5381	5381	53810																C M C			
	I TEM OTY	1 2	2 2	3	4	5	6 4		8 2														DRAWN BY:	CHECKED BY:	TRACED BY:	



6 ELECTRICAL SCHEMATICS AND PARTS

6.1 WIRING DIAGRAMS LIST # 200-178-03-04

6.2 PARTS LIST

Parts lists are shown in order as indicated below. Sub-assemblies are indented under the main assembly.

DRAWING #	DESCRIPTION
KR319N	ASSY, 319N
533196-07	ASSY, CABINET & COVERS
531023-05	WLDMNT, 319B BASE CABINET
532152-20	ASSY, MONITOR STAND NETJET
536586-02	WLDMT, MONITOR STAND
532155-02	ASSY, MONITOR PIVOT
546008-01	PRINT CONTROL MODULE NETJET 110V
546007-01	ASSY,WELDMENT BOX
538502-03	WLDMT, COMPUTER BOX
539424-01	ASSY, RH HYDRALIFT LEG
539425-01	ASSY, LH HYDRALIFT LEG
533195-04	ASSY, 319 WINKJET CONVEYOR
530676-06	ASSY, DRIVE ROLLER
SP45241-10	PLATE, ENCODER MOUNT
500835-A	ASSY, TUBE ROLLER
542189-01	WLDMT, BLOWER BOX W/DOOR
538169-21	ASSY, NETJET PRINT MOD W/AB
538153-06	ASSY, VERTICAL ADJ. RH
538153-07	ASSY, VERTICAL ADJ. LH
538269-11	ASSY, NETJET MOUNT
191195	HEAD, NETJET 1.5IN
538188-04	ASSY, SKIDBAR/SENSOR
538021-01	ASSY, SKID BAR
500801A	ASSY, LINK
500800-A	ASSY, LINK
500802A	ASSY, CLAMP
190101A	ASSY-SWITCH WITH COVER
500834A	ASSY, STUD WITH BEARING
501629-A	ASSY, CLAMP WITH KNOB
102131-5A	KNOB ASY
533132-01	ASSY, 324M CONTROL BOX

7 APPENDIX

8	NOTES	·
and deliberation of the second		
		7,000
1		

-		

,		

9 WARRANTY AND SERVICE

WARRANTY

Warranty: Kirk-Rudy, Inc., warrants to the original retail purchaser that this product is free from defects in the material and workmanship, and agrees to repair or replace, at Kirk-Rudy's option, any defective product within (90) days from the date of purchase. This warranty is not transferable. It covers damage resulting from defects in material or workmanship, and it does not cover conditions or malfunctions resulting from normal wear, neglect, abuse or accident.

THIS WARRANTY IS IN LIEU OF ALL OTHER EXPRESSED WARRANTIES ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR ANY IMPLIED WARRANTY ARISING OUT OF A COURSE OF DEALING, CUSTOM, OR USAGE OF TRADE.

Limitation of Remedies: If product is proven to be defective within the warranty period stated above, THE EXCLUSIVE REMEDY, AT KIRK-RUDY'S OPTION, SHALL BE TO REFUND THE PURCHASE PRICE OF OR TO REPAIR OR REPLACE THE DEFECTIVE PRODUCT, provided that the defective product is, at Kirk-Rudy's choice, returned immediately to Kirk-Rudy or authorized service representative designated by Kirk-Rudy, or made available at user's premises in a location suitable for servicing.

Limitation of Liability: Kirk-Rudy shall not otherwise be liable for any losses or damages, whether direct, indirect, special, incidental, or consequential, regardless of the legal or equitable theory asserted, including contract, negligence, warranty, or strict liability.

To obtain replacement parts and service, contact an Authorized Kirk-Rudy Dealer. Use Kirk-Rudy part numbers when ordering.

USE ONLY GENUINE KIRK-RUDY REPLACEMENT PARTS

KIRK-RUDY, INC 125 LORRAINE PARKWAY WOODSTOCK, GEORGIA 30188 PH 770-427-4203 FX 770-427-4036 www.kirkrudy.com