
Kirk-Rudy, Inc. Instruction and Parts Manual 203P Pick-n-Place



Manufactured by Kirk-Rudy, Inc.

Before using this machine, all operators must study this manual to understand and follow the <u>safety warnings and instructions</u>. Keep these instructions with the machine for future reference. If you have any questions, contact your local Kirk-Rudy, Inc. Distributor.

TABLE OF CONTENTS

SECTION	DESCRIPTION	<u>PAGE</u>
1	IMPORTANT SAFETY INSTRUCTIONS	3
2	SPECIFICATIONS	4
3	INSTALLATION 3.1 UNCRATING 3.2 INSTALLING 203P TO BASE	5 5 5
4	OPERATING INSTRUCTIONS 4.1 HOPPER ADJUSTMENTS 4.2 VACUUM ADJUSTMENTS	6 6 6
5	MAINTENANCE 5.1 LUBRICATION	7 7
6	MECHANICAL PARTS AND DIAGRAMS 6.1 DIAGRAMS 6.2 PARTS LIST	8 8 9
7	ELECTRICAL SCHEMATICS AND PARTS 7.1 WIRING DIAGRAMS LISTS 7.2 PARTS LIST – STANDARD SHAFT 7.3 PARTS LIST – MOTOR DRIVE	17 17 17 17
8	APPENDIX 8.1 SUCTION CUP OPTIONS 8.2 DUAL HOPPER OPTION 8.3 MOTOR DRIVE OPTION	18 18 18 18
9	NOTES	19
10	WARRANTY AND SERVICE INFORMATION	20

NOTE: FIGURES AND DIAGRAMS ARE NOT INCLUDED IN PAGE NUMBERS.

1 Important Safety Instructions

Intended Use Statement: The Kirk-Rudy, Inc. 203P Pick-n-Place machine is designed to feed pieces that are normally difficult to gate through a typical shuttle or friction feeder. It can handle irregular shaped pieces such as sachets for cosmetic or medical samples. This machine can also handle product that varies in thickness in the hopper. It can be built to feed inline or 90 degrees to material flow. It can be shaft driven with standard Kirk-Rudy Inc. Head Drive Systems or Free Standing with its own motor drive and engaged with a single revolution clutch powered on demand from an external signal. The 203P is available in right and left hand models.

SAVE THESE INSTRUCTIONS. Read all instructions before using this product.



WARNING

- * NEVER OPERATE THE MACHINE WITHOUT ALL GUARDS OR SAFETY DEVICES IN PLACE.
- * ALWAYS TURN POWER OFF WHEN MAKING ADJUSTMENTS.
- * ALWAYS DISCONNECT THE POWER SUPPLY BEFORE ANY MAINTENANCE OR SERVICE WORK.
- * NEVER START THE MACHINE WITHOUT FIRST CHECKING ALL PERSONNEL ARE CLEAR OF MOVING PARTS.
- * KEEP FINGERS CLEAR OF ALL MOVING PARTS.
- * NEVER REMOVE THE PRODUCT FROM THE MACHINE WHILE MACHINE IS RUNNING.
- * SHOULD MISFED PRODUCT JAM THE MACHINE AND STOP IT FROM RUNNING, ALWAYS PRESS THE STOP BUTTON BEFORE CLEARING PRODUCT. IF THE STOP BUTTON IS NOT PRESSED AND THE JAM IS CLEARED, THE MACHINE WILL BEGIN RUNNING.
- * IT IS NOT RECOMMENDED THAT LOOSE CLOTHING, JEWELRY AND LONG HAIR BE WORN WHILE OPERATING THIS MACHINERY.
- * ALWAYS USE AN EXPERIENCED ELECTRICIAN WHEN TROUBLE-SHOOTING ELECTRICAL PROBLEMS.
- * CHANGES OR MODIFICATIONS TO THIS UNIT NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

2 SPECIFICATIONS

PRODUCT SIZE RANGE English Metric

Minimum Size: 2.75" W x 1" L 70mm W x 25mm L

Maximum Size: 7.75" W x 5" L 197mm W x 127mm L

Minimum Thickness: Card Stock (.007") Card Stock (.18mm)

Maximum Thickness: 1/4" 6.4mm

*Note: Minimum Width w/ filler plates 1.5".

PHYSICAL SIZE

 Length:
 38"
 97cm

 Width:
 19.5"
 50cm

 Height:
 22"
 56cm

 Weight:
 70lb.
 31.8 kg

Shipping: 90lb. 40.8 kg

SPEED

Maximum: 6000-8000/hr.

Varies on product size.


Some material can be fed 2 wide (side by side) in dual hopper.

ELECTRICAL

Base Main Power Input: 220 VAC

Vacuum: 20-25 in. Hg.

Minimun Air Pressure: 80 lb.



KR203P MAJOR COMPONENTS FIGURE 1.0

R/H SHOWN, L/H OPPOSITE
NOTE: GUARDS PHANTOMED FOR CLARITY

3 INSTALLATION



WARNING


Read and follow all Safety Instructions in Section 1, Page 5 before proceeding

3.1 UNCRATING

Remove your Kirk Rudy 203P and all packaging from crate. Inspect for damage. The accessories and spare parts are boxed and located inside the crate. The box should be opened and checked against the packing list. Please check the enclosed checklist to insure all items have been received.

3.2 INSTALLING 203P TO BASE

- 1. Locate head drive clamp on standard Kirk Rudy head drive shaft (located opposite of operator side). Loosen clamp with 3/16" allen wrench.
- 2. Remove 7/16" x 14 flange bolts from bearing on operator's side of base.
- 3. Remove head shaft.
- 4. Lightly oil head drive shaft to resist contaminates. Insert shaft through 203P.
- 5. Tighten 3/16" allen screw in 203P clamp to secure shaft in 203P.
- 6. Insert shaft (w/ 203P) into operator side head bracket and then into opposite side head bracket.
- 7. Tighten 7/16" x 14 flange bolts in bearing.
- 8. Tighten both 3/16" allen screws in head drive clamp.
- 9. Attach electrical wires:
 - a) One 3 prong twist plug
 - b) One 2 prong twist plug
 - c) One beam switch
 - d) One stop circuit



4 OPERATING INSTRUCTIONS

Except for the material hopper, all adjustments are preset at the factory.



WARNING

Read and follow all Safety Instructions in Section 1, Page 5 before proceeding.

4.1 HOPPER ADJUSTMENT


To adjust the hopper to handle your material, spread the hopper side guides SP18702 & SP18702-1 apart, lay the material in the bottom of the hopper and center it using the Jogger bar SP47905 as a guide. Bring the two sideguides to within 1/16" of material width allowing .030 on each side. Sideguides can be slightly wider on the upper end to allow for easier loading. On the lower end and at the bottom of each sideguide, there is an 8-32 screw used to hold back the stack of material. The proper setting will vary depending on the type of material. For plastic cards adjust the screw about 1/16" above the bottom of the side guide. For softer pieces like sachets it may be necessary to adjust this screw as much as ½" above the bottom of the hopper. To support and hold back the upper portion of the material, locate bracket 530447-02 RH and 530447-01 LH. These brackets should be adjusted up or down. To set rod 532139-01, the top of the material should split the middle of these rods. See Figure 4.0. Adjust the height of the hopper by loosening the two 5/16" x 18 hex bolts on bracket SP47902 and moving the hopper up or down to position the suction cup 1/16" from the bottom of the material. Before tightening bolts make sure the hopper bracket SP47902 fits squarely against plate SP26590. This will insure proper alignment of suction cup to material.


On the bracket SP47902 there are two 5/16" x 18 allen head screws which when loosened allows the hopper to slide toward or away from the suction cup. With vacuum off and the suction cup fully extended toward hopper, slide the hopper assembly toward or away from the suction cup as necessary. For most pieces set the hopper so that the material comes in contact with the suction cup.

Spring Steel assembly 531556-01 should be set approximately .030 from the top of the material. Do not rest spring steel on top of material. The jogger is not used on all types of materials. For plastic cards and other pieces that will slide down the hopper unassisted do not use jogger. It may be necessary to use it with sachets and other lightweight materials.

4.2 VACUUM ADJUSTMENTS

Vacuum is preset at the factory. The head drive is to be turned clockwise as viewed from the hopper side. Vacuum will shut off as the pulley box 532987-02 is in the vertical position and the suction cup is parallel to the tabletop. A service technician should only make these adjustments.





5 MAINTENANCE



WARNING

Read and follow all Safety Instructions in Section 1, Page 5 before proceeding.

5.1 LUBRICATION

Periodic greasing is required for gears inside 203P. Before sliding 203P along head drive shaft, lightly oil shaft to insure proper maintenance.

Lubrication should be checked weekly.

- 1. Check gearbox, pendulum gear and 1648 gears on the head weekly for proper lubrication. Use JT-6 Multi-Purpose Grease.
- 2. Keep vacuum airway clear.
- 3. Before repositioning head or removing from head shaft, clean head shaft and inspect shaft for any blemishes. Lubricate the shaft before moving head along the shaft. Failure to do this can cause the shaft to seize inside the sleeve.

Caution: Do not operate the base if the sleeve clamp on the head is not tightened down.

- 4. Mac air valve requires air pressure min. 30 psi and not to exceed 150 psi. Recommended pressure of 40psi.
- 5. Check sprocket chain for proper lubrication. Lightly lubricate chain with grease.
- 6. Suction Cup Replacement

Single Blue suction cup replacement is a VC57-A Suction Cup Triple Black Bellow cup replacement is a 95McCain KR# 190699

Triple Blue Bellow cup is replacement VCB3 KR# 190699-1

6 PARTS LISTS AND DIAGRAMS

6.1 DIAGRAMS

Drawing #	Description
KR203PRH	203P R/H Pick-n-Place
532104-01	EG, Assy 203P Hopper
532446-01	Assy, Hub Bearing
532447-01	Assy, Hub Bearing
532570-02	Assy, Crank Arm
532570-01	Assy, Crank Arm
532670-01	Assy, Dbl Air Reg Brckt
532685-03	Assy, Vacuum Arm RH
532577-01	Assy, Pulley Box 203P
534007-01	Assy, Crank Adjust
535048-01	Assy, Vac. Valve & Fittings

Drawing #	Description
KR203PLH	203P L/H Pick-n-Place
532104-02	EG, Assy 203P L/H Hopper
532446-01	Assy, Hub Bearing
532447-01	Assy, Hub Bearing
532570-02	Assy, Crank Arm
532570-01	Assy, Crank Arm
532670-02	Assy, Dbl Air Reg Brckt
532685-04	Assy, Vacuum Arm LH
532577-01	Assy, Pulley Box 203P
534007-01	Assy, Crank Adjust
535048-01	Assy, Vac. Valve & Fittings

6.2 PARTS LIST

203P R/H Pick-n-Place

Item	Qty	Part #	Description
1	4	100623	WASHER, FLAT .250
2	4	102131	KNOB
3	1	102528	GEAR, 1648
4	1	102531	GEAR, 1648 .750B .188K
5	8	103106	BEARING, FLAT .375
6	6	103108	BEARING, FLAT .500
7	6	103116	BEARING, FLAT 1.000
8	2	103120	BEARING, FLAT 1.250
9	1	103500	BEARING, ROD END
10	1	104106	SNAPRING, .500
11	2	104108	SNAPRING, 1.250
12	5	104113	SNAPRING, 1.000
13	1	105630	ROD, THD 3/8-24 X 1.75
14	1	108721	PULLEY, 18XL037 .375B .125K
15	2	108785	PULLEY, 16XL037 .375B NK
16	1	109019	BELT, TIMING 60XL037
17	1	109529	CONNECTOR, PIPE
18	1	109533	ELBOW
19	1	109543	BRANCH, T
20	1	109544	NIPPLE, 1/4 NPT AIR GUN
21	4	109545	BUSHING, HEX 1/4 TO 3/8
22	4	109546	PLUG, 1/4 NPT
23	2	109549	PLUG, 1/8 NPT
24	1	109669	VALVE, MAC PID-121BAAA 220V
25	1	109818	PULLEY, 18XL037 .314B NK
26	1	109822	PULLEY, 14XL037 .500B .188K
27	1	109823	PULLEY, 21XL037 .375B NK
28	2	190100	MICROSWITCH, ROLLER
29	2	190605	NIPPLE, VACUUM LINE
30	5	190606	FITTING, 90 DEG 1/4 NPT
31	1	190773	CUP, VACUUM VC57A
32	1	201142	BRACKET, MICROSWITCH
33	1	201158	SWITCH, COVER
34	1	201159	KEY, INTERLOCK SWITCH
35	1	500975	SHOE, HEAD DRIVE CLAMP

Item	Qty	Part #	Description
36	1	501629	CLAMP, GUIDE STRIP
37	1	109013-2	BELT, TIMING 260XL037
38	1	109017-5	BELT, TIMING 80XL037
39	- 2	190695-1	GAUGE, AIR REGULATOR
40	2	190695-2	REGULATOR, AIR
41	1	200600-1	MOTOR, 41RPM 220V
42	1	500976-1	CLAMP, HEAD DRIVE
43	1	530208-01	ARM, HEAD SUPPORT
44	1	530445-01	CAM, PICK & PLACE
45	1	530447-01	BRACKET, GUIDE MOUNT
46	1	530447-02	BRACKET, GUIDE MOUNT
47	2	530693-01	BAR, MICROSWITCH MOUNT
48	1	530977-01	BLOCK, HOPPER
49	1	530987-02	BLOCK, BEARING
50	1	531556-01	BRACKET
51	1	532021-01	BRACKET, DBL AIR REGULATOR
52	1	532024-01	COVER, JOGGER PULLEY
53	1	532,050-01	WELDMENT, HOPPER MTR CVR
54	1	536851-01	COVER, HOPPER PULLEY
55	1	536854-01	COVER, 203P DRIVE
56	1	532053-01	COVER, 203P DRIVE
57	1	532054-02	BLOCK, VACUUM MANIFOLD RH
58	1	532104-01	EG, ASSY 203P HOPPER
59	2	532138-01	SHAFT, C-CLAMP
60	2	532139-01	ROD, HOPPER FEED
61	1	532257-01	COVER, INLINE PICK-N-PLACE
62	1	532369-01	COVER, HOPPER ADJ
63	1	532370-01	PLATE, HOPPER COVER MOUNT
64	2	532446-01	ASSY, HUB BEARING
65	1	532447-01	ASSY, HUB BEARING
66	1	532570-01	ASSY, CRANK ARM
67	1	532570-02	ASSY, CRANK ARM
68	1	532577-01	ASSY, PULLEY BOX 203P
69	1	532670-01	ASSY, DBL AIR REG BRACKET RH
70	1	532684-01	COVER, BEARING BLOCK PULLEY

Till	Item	Qty	Part #	Description
73 1 532731-01 CAM, MICROSWITCH 74 1 534006-01 STUD, CRANK ADJUST 75 1 534007-01 ASSY, CRANK ADJUST 76 1 535048-01 ASSY, VAC VALVE & FITTINGS 77 1 CSDD269 78 4 CSDD298 79 1 HJN011 80 2 HJN012 81 1 S18702 HOPPER 82 1 S18705 HOUSING, BEARING 83 2 S18706 HOUSING, BEARING 84 1 S18707 SHAFT 85 1 S18709 GEAR, DRIVING 86 1 S18710 STOP, ARM 87 1 S18711 SHAFT, IDLER 89 1 S18712 SHAFT, IDLER 89 1 S18713 GEAR, CRANK 90 1 S18717 CRANK 91 1 S18732 HOPPER, MOUNT <t< td=""><td>71</td><td>1</td><td>532685-03</td><td>ASSY, VACUUM ARM RH</td></t<>	71	1	532685-03	ASSY, VACUUM ARM RH
74 1 534006-01 STUD, CRANK ADJUST 75 1 534007-01 ASSY, CRANK ADJUST 76 1 535048-01 ASSY, VAC VALVE & FITTINGS 77 1 CSDD269 78 4 CSDD298 79 1 HJN011 80 2 HJN012 81 1 S18702 HOPPER 82 1 S18705 HOUSING, BEARING 84 1 S18707 SHAFT 85 1 S18709 GEAR, DRIVING 86 1 S18710 STOP, ARM 87 1 S18711 SHAFT, STOP 88 1 S18712 SHAFT, IDLER 89 1 S18713 GEAR, CRANK 90 1 S18717 CRANK 91 1 S18721 HOLDER, V.C. 92 4 S18732 HOPPER, MOUNT 93 4 S18737 WASHER, GUIDE	72	1	532730-01	BRACKET, MICROSWITCH
75 1 534007-01 ASSY, CRANK ADJUST 76 1 535048-01 ASSY, VAC VALVE & FITTINGS 77 1 CSDD269 78 4 CSDD298 79 1 HJN011 80 2 HJN012 81 1 S18702 HOPPER 82 1 S18705 HOUSING, BEARING 83 2 S18706 HOUSING, BEARING 84 1 S18707 SHAFT 85 1 S18709 GEAR, DRIVING 86 1 S18710 STOP, ARM 87 1 S18711 SHAFT, STOP 88 1 S18712 SHAFT, IDLER 89 1 S18713 GEAR, CRANK 90 1 S18717 CRANK 91 1 S18721 HOLDER, V.C. 92 4 S18732 HOPPER, MOUNT 93 4 S18744 PLATE, SPACER 9	73	1	532731-01	CAM, MICROSWITCH
76 1 535048-01 ASSY, VAC VALVE & FITTINGS 77 1 CSDD269 78 4 CSDD298 79 1 HJN011 80 2 HJN012 81 1 S18702 HOPPER 82 1 S18705 HOUSING, BEARING 83 2 S18706 HOUSING, BEARING 84 1 S18707 SHAFT 85 1 S18709 GEAR, DRIVING 86 1 S18710 STOP, ARM 87 1 S18711 SHAFT, STOP 88 1 S18712 SHAFT, IDLER 89 1 S18713 GEAR, CRANK 90 1 S18717 CRANK 91 1 S18721 HOLDER, V.C. 92 4 S18732 HOPPER, MOUNT 93 4 S18749 PLATE, SPACER 96 1 S18748 PLATE, SPACER 96	74	1	534006-01	STUD, CRANK ADJUST
77 1 CSDD269 78 4 CSDD298 79 1 HJN011 80 2 HJN012 81 1 S18702 HOPPER 82 1 S18705 HOUSING, BEARING 83 2 S18706 HOUSING, BEARING 84 1 S18707 SHAFT 85 1 S18709 GEAR, DRIVING 86 1 S18710 STOP, ARM 87 1 S18711 SHAFT, STOP 88 1 S18712 SHAFT, IDLER 89 1 S18713 GEAR, CRANK 90 1 S18717 CRANK 91 1 S18721 HOLDER, V.C. 92 4 S18732 HOPPER, MOUNT 93 4 S18737 WASHER, GUIDE 94 1 S18747 PLATE, SPACER 96 1 S18748 PLATE, SPACER 96 1 S18749 PLATE, SPACER 97 2 S18750 HOPPER, SPACER 98 1 S18751 HOPPER, SPACER 99 1 S26556 SHAFT, DRIVE 100 1 S26590 END, PLATE FRAME 101 2 S47901 BAR, HOPPER MOUNT 103 1 S47905 BAR, LIFTER 104 1 S47905 BAR, LIFTER	75	1	534007-01	ASSY, CRANK ADJUST
78 4 CSDD298 79 1 HJN011 80 2 HJN012 81 1 S18702 HOPPER 82 1 S18705 HOUSING, BEARING 83 2 S18706 HOUSING, BEARING 84 1 S18707 SHAFT 85 1 S18709 GEAR, DRIVING 86 1 S18710 STOP, ARM 87 1 S18711 SHAFT, STOP 88 1 S18712 SHAFT, IDLER 89 1 S18713 GEAR, CRANK 90 1 S18717 CRANK 91 1 S18721 HOLDER, V.C. 92 4 S18732 HOPPER, MOUNT 93 4 S18737 WASHER, GUIDE 94 1 S18748 PLATE, SPACER 96 1 S18749 PLATE, SPACER 97 2 S18750 HOPPER, SPACER	76	1	535048-01	ASSY, VAC VALVE & FITTINGS
79 1 HJN012 80 2 HJN012 81 1 S18702 HOPPER 82 1 S18705 HOUSING, BEARING 83 2 S18706 HOUSING, BEARING 84 1 S18707 SHAFT 85 1 S18709 GEAR, DRIVING 86 1 S18710 STOP, ARM 87 1 S18711 SHAFT, STOP 88 1 S18712 SHAFT, IDLER 89 1 S18713 GEAR, CRANK 90 1 S18713 GEAR, CRANK 90 1 S18717 CRANK 91 1 S18721 HOLDER, V.C. 92 4 S18732 HOPPER, MOUNT 93 4 S18737 WASHER, GUIDE 94 1 S18748 PLATE, SPACER 95 1 S18749 PLATE, SPACER 96 1 S18750 HOPPER, SPACER <td>77</td> <td>1</td> <td>CSDD269</td> <td></td>	77	1	CSDD269	
80 2 HJN012 81 1 S18702 HOPPER 82 1 S18705 HOUSING, BEARING 83 2 S18706 HOUSING, BEARING 84 1 S18707 SHAFT 85 1 S18709 GEAR, DRIVING 86 1 S18710 STOP, ARM 87 1 S18711 SHAFT, STOP 88 1 S18712 SHAFT, IDLER 89 1 S18713 GEAR, CRANK 90 1 S18713 GEAR, CRANK 90 1 S18717 CRANK 91 1 S18721 HOLDER, V.C. 92 4 S18732 HOPPER, MOUNT 93 4 S18737 WASHER, GUIDE 94 1 S18747 PLATE, SPACER 95 1 S18748 PLATE, SPACER 96 1 S18750 HOPPER, SPACER 98 1 S18751 <td>78</td> <td>4</td> <td>CSDD298</td> <td></td>	78	4	CSDD298	
81 1 \$18702 HOPPER 82 1 \$18705 HOUSING, BEARING 83 2 \$18706 HOUSING, BEARING 84 1 \$18707 SHAFT 85 1 \$18709 GEAR, DRIVING 86 1 \$18710 STOP, ARM 87 1 \$18711 SHAFT, STOP 88 1 \$18712 SHAFT, IDLER 89 1 \$18713 GEAR, CRANK 90 1 \$18717 CRANK 91 1 \$18721 HOLDER, V.C. 92 4 \$18732 HOPPER, MOUNT 93 4 \$18737 WASHER, GUIDE 94 1 \$18747 PLATE, SPACER 95 1 \$18748 PLATE, SPACER 96 1 \$18749 PLATE, SPACER 97 2 \$18750 HOPPER, SPACER 99 1 \$26556 SHAFT, DRIVE 100	79	1	HJN011	
82 1 \$18705 HOUSING, BEARING 83 2 \$18706 HOUSING, BEARING 84 1 \$18707 \$HAFT 85 1 \$18709 GEAR, DRIVING 86 1 \$18710 \$TOP, ARM 87 1 \$18711 \$HAFT, STOP 88 1 \$18712 \$HAFT, IDLER 89 1 \$18713 GEAR, CRANK 90 1 \$18717 CRANK 90 1 \$18717 CRANK 91 1 \$18721 HOLDER, V.C. 92 4 \$18732 HOPPER, MOUNT 93 4 \$18737 WASHER, GUIDE 94 1 \$18747 PLATE, SPACER 95 1 \$18748 PLATE, SPACER 96 1 \$18749 PLATE, SPACER 97 2 \$18750 HOPPER, SPACER 99 1 \$26556 SHAFT, DRIVE 100	80	2	HJN012	
83 2 \$18706 HOUSING, BEARING 84 1 \$18707 SHAFT 85 1 \$18709 GEAR, DRIVING 86 1 \$18710 STOP, ARM 87 1 \$18711 SHAFT, STOP 88 1 \$18712 SHAFT, IDLER 89 1 \$18713 GEAR, CRANK 90 1 \$18717 CRANK 91 1 \$18721 HOLDER, V.C. 92 4 \$18732 HOPPER, MOUNT 93 4 \$18737 WASHER, GUIDE 94 1 \$18747 PLATE, SPACER 95 1 \$18748 PLATE, SPACER 96 1 \$18749 PLATE, SPACER 97 2 \$18750 HOPPER, SPACER 98 1 \$18751 HOPPER, SPACER 99 1 \$26556 SHAFT, DRIVE 100 1 \$26590 END, PLATE FRAME 101 <td>81</td> <td>1</td> <td>S18702</td> <td>HOPPER</td>	81	1	S18702	HOPPER
84 1 \$18707 \$HAFT 85 1 \$18709 \$GEAR, DRIVING 86 1 \$18710 \$TOP, ARM 87 1 \$18711 \$HAFT, STOP 88 1 \$18712 \$HAFT, IDLER 89 1 \$18713 \$GEAR, CRANK 90 1 \$18717 \$CRANK 90 1 \$18717 \$CRANK 91 1 \$18721 \$HOLDER, V.C. 92 4 \$18732 \$HOPPER, MOUNT 93 4 \$18737 \$WASHER, GUIDE 94 1 \$18747 \$PLATE, \$PACER 95 1 \$18748 \$PLATE, \$PACER 96 1 \$18749 \$PLATE, \$PACER 97 2 \$18750 \$HOPPER, \$PACER 98 1 \$18751 \$HOPPER, \$PACER 99 1 \$26556 \$HAFT, DRIVE 100 1 \$26590 \$END, PLATE FRAME 101 2 \$47901 \$BAR, HOPPER SUPPORT 102 1	82	1	S18705	HOUSING, BEARING
85 1 \$18709 GEAR, DRIVING 86 1 \$18710 \$TOP, ARM 87 1 \$18711 \$HAFT, STOP 88 1 \$18712 \$HAFT, IDLER 89 1 \$18713 GEAR, CRANK 90 1 \$18717 CRANK 91 1 \$18721 HOLDER, V.C. 92 4 \$18732 HOPPER, MOUNT 93 4 \$18737 WASHER, GUIDE 94 1 \$18747 PLATE, SPACER 95 1 \$18748 PLATE, SPACER 96 1 \$18749 PLATE, SPACER 97 2 \$18750 HOPPER, SPACER 98 1 \$18751 HOPPER, SPACER 99 1 \$26556 SHAFT, DRIVE 100 1 \$26590 END, PLATE FRAME 101 2 \$47901 BAR, HOPPER SUPPORT 102 1 \$47902 PLATE, HOPPER MOUNT 103 1 \$47905 BAR, LIFTER 104 1	83	2	S18706	HOUSING, BEARING
86 1 \$18710 \$TOP, ARM 87 1 \$18711 \$HAFT, STOP 88 1 \$18712 \$HAFT, IDLER 89 1 \$18713 \$GEAR, CRANK 90 1 \$18717 \$CRANK 91 1 \$18721 \$HOLDER, V.C. 92 4 \$18732 \$HOPPER, MOUNT 93 4 \$18737 \$WASHER, GUIDE 94 1 \$18747 \$PLATE, \$PACER 95 1 \$18748 \$PLATE, \$PACER 96 1 \$18749 \$PLATE, \$PACER 97 2 \$18750 \$HOPPER, \$PACER 98 1 \$18751 \$HOPPER, \$PACER 99 1 \$26556 \$SHAFT, DRIVE 100 1 \$26590 \$END, \$PLATE FRAME 101 2 \$47901 \$BAR, HOPPER SUPPORT 102 1 \$47902 \$PLATE, HOPPER MOUNT 103 1 \$47905 \$BAR, LIFTER 104 1 \$47906 \$SHAFT, LIFTER DRIVE <td>84</td> <td>1</td> <td>S18707</td> <td>SHAFT</td>	84	1	S18707	SHAFT
87 1 \$18711 \$SHAFT, STOP 88 1 \$18712 \$SHAFT, IDLER 89 1 \$18713 \$GEAR, CRANK 90 1 \$18717 \$CRANK 91 1 \$18721 \$HOLDER, V.C. 92 4 \$18732 \$HOPPER, MOUNT 93 4 \$18737 \$WASHER, GUIDE 94 1 \$18747 \$PLATE, SPACER 95 1 \$18748 \$PLATE, SPACER 96 1 \$18749 \$PLATE, SPACER 97 2 \$18750 \$HOPPER, SPACER 98 1 \$18751 \$HOPPER, SPACER 99 1 \$26556 \$SHAFT, DRIVE 100 1 \$26590 \$END, PLATE FRAME 101 2 \$47901 \$BAR, HOPPER SUPPORT 102 1 \$47902 \$PLATE, HOPPER MOUNT 103 1 \$47905 \$BAR, LIFTER 104 1 \$47906 \$SHAFT, LIFTER DRIVE	85	1	S18709	GEAR, DRIVING
88 1 \$18712 \$SHAFT, IDLER 89 1 \$18713 \$GEAR, CRANK 90 1 \$18717 \$CRANK 91 1 \$18721 \$HOLDER, V.C. 92 4 \$18732 \$HOPPER, MOUNT 93 4 \$18737 \$WASHER, GUIDE 94 1 \$18747 \$PLATE, \$PACER 95 1 \$18748 \$PLATE, \$PACER 96 1 \$18749 \$PLATE, \$PACER 97 2 \$18750 \$HOPPER, \$PACER 98 1 \$18751 \$HOPPER, \$PACER 99 1 \$26556 \$SHAFT, DRIVE 100 1 \$26590 \$END, \$PLATE FRAME 101 2 \$47901 \$BAR, HOPPER SUPPORT 102 1 \$47902 \$PLATE, HOPPER MOUNT 103 1 \$47905 \$BAR, LIFTER 104 1 \$47906 \$SHAFT, LIFTER DRIVE	86	1	S18710	STOP, ARM
89 1 S18713 GEAR, CRANK 90 1 S18717 CRANK 91 1 S18721 HOLDER, V.C. 92 4 S18732 HOPPER, MOUNT 93 4 S18737 WASHER, GUIDE 94 1 S18747 PLATE, SPACER 95 1 S18748 PLATE, SPACER 96 1 S18749 PLATE, SPACER 97 2 S18750 HOPPER, SPACER 98 1 S18751 HOPPER, SPACER 99 1 S26556 SHAFT, DRIVE 100 1 S26590 END, PLATE FRAME 101 2 S47901 BAR, HOPPER SUPPORT 102 1 S47902 PLATE, HOPPER MOUNT 103 1 S47905 BAR, LIFTER 104 1 S47906 SHAFT, LIFTER DRIVE	87	1	S18711	SHAFT, STOP
90 1 S18717 CRANK 91 1 S18721 HOLDER, V.C. 92 4 S18732 HOPPER, MOUNT 93 4 S18737 WASHER, GUIDE 94 1 S18747 PLATE, SPACER 95 1 S18748 PLATE, SPACER 96 1 S18749 PLATE, SPACER 97 2 S18750 HOPPER, SPACER 98 1 S18751 HOPPER, SPACER 99 1 S26556 SHAFT, DRIVE 100 1 S26590 END, PLATE FRAME 101 2 S47901 BAR, HOPPER SUPPORT 102 1 S47902 PLATE, HOPPER MOUNT 103 1 S47905 BAR, LIFTER 104 1 S47906 SHAFT, LIFTER DRIVE	88	1	S18712	SHAFT, IDLER
91 1 S18721 HOLDER, V.C. 92 4 S18732 HOPPER, MOUNT 93 4 S18737 WASHER, GUIDE 94 1 S18747 PLATE, SPACER 95 1 S18748 PLATE, SPACER 96 1 S18749 PLATE, SPACER 97 2 S18750 HOPPER, SPACER 98 1 S18751 HOPPER, SPACER 99 1 S26556 SHAFT, DRIVE 100 1 S26590 END, PLATE FRAME 101 2 S47901 BAR, HOPPER SUPPORT 102 1 S47902 PLATE, HOPPER MOUNT 103 1 S47905 BAR, LIFTER 104 1 S47906 SHAFT, LIFTER DRIVE	89	1	S18713	GEAR, CRANK
92 4 \$18732 HOPPER, MOUNT 93 4 \$18737 WASHER, GUIDE 94 1 \$18747 PLATE, SPACER 95 1 \$18748 PLATE, SPACER 96 1 \$18749 PLATE, SPACER 97 2 \$18750 HOPPER, SPACER 98 1 \$18751 HOPPER, SPACER 99 1 \$26556 SHAFT, DRIVE 100 1 \$26590 END, PLATE FRAME 101 2 \$47901 BAR, HOPPER SUPPORT 102 1 \$47902 PLATE, HOPPER MOUNT 103 1 \$47905 BAR, LIFTER 104 1 \$47906 SHAFT, LIFTER DRIVE	90	1	S18717	CRANK
93 4 \$18737 WASHER, GUIDE 94 1 \$18747 PLATE, SPACER 95 1 \$18748 PLATE, SPACER 96 1 \$18749 PLATE, SPACER 97 2 \$18750 HOPPER, SPACER 98 1 \$18751 HOPPER, SPACER 99 1 \$26556 SHAFT, DRIVE 100 1 \$26590 END, PLATE FRAME 101 2 \$47901 BAR, HOPPER SUPPORT 102 1 \$47902 PLATE, HOPPER MOUNT 103 1 \$47905 BAR, LIFTER 104 1 \$47906 SHAFT, LIFTER DRIVE	91	1	S18721	HOLDER, V.C.
94 1 \$18747 PLATE, \$PACER 95 1 \$18748 PLATE, \$PACER 96 1 \$18749 PLATE, \$PACER 97 2 \$18750 HOPPER, \$PACER 98 1 \$18751 HOPPER, \$PACER 99 1 \$26556 \$HAFT, DRIVE 100 1 \$26590 END, PLATE FRAME 101 2 \$47901 BAR, HOPPER SUPPORT 102 1 \$47902 PLATE, HOPPER MOUNT 103 1 \$47905 BAR, LIFTER 104 1 \$47906 \$HAFT, LIFTER DRIVE	92	4	S18732	HOPPER, MOUNT
95 1 S18748 PLATE, SPACER 96 1 S18749 PLATE, SPACER 97 2 S18750 HOPPER, SPACER 98 1 S18751 HOPPER, SPACER 99 1 S26556 SHAFT, DRIVE 100 1 S26590 END, PLATE FRAME 101 2 S47901 BAR, HOPPER SUPPORT 102 1 S47902 PLATE, HOPPER MOUNT 103 1 S47905 BAR, LIFTER 104 1 S47906 SHAFT, LIFTER DRIVE	93	4	S18737	WASHER, GUIDE
96 1 S18749 PLATE, SPACER 97 2 S18750 HOPPER, SPACER 98 1 S18751 HOPPER, SPACER 99 1 S26556 SHAFT, DRIVE 100 1 S26590 END, PLATE FRAME 101 2 S47901 BAR, HOPPER SUPPORT 102 1 S47902 PLATE, HOPPER MOUNT 103 1 S47905 BAR, LIFTER 104 1 S47906 SHAFT, LIFTER DRIVE	94	1	S18747	PLATE, SPACER
97 2 \$18750 HOPPER, \$PACER 98 1 \$18751 HOPPER, \$PACER 99 1 \$26556 \$HAFT, DRIVE 100 1 \$26590 END, PLATE FRAME 101 2 \$47901 BAR, HOPPER SUPPORT 102 1 \$47902 PLATE, HOPPER MOUNT 103 1 \$47905 BAR, LIFTER 104 1 \$47906 \$HAFT, LIFTER DRIVE	95	1	S18748	PLATE, SPACER
98 1 S18751 HOPPER, SPACER 99 1 S26556 SHAFT, DRIVE 100 1 S26590 END, PLATE FRAME 101 2 S47901 BAR, HOPPER SUPPORT 102 1 S47902 PLATE, HOPPER MOUNT 103 1 S47905 BAR, LIFTER 104 1 S47906 SHAFT, LIFTER DRIVE	96	1	S18749	PLATE, SPACER
99 1 \$26556 \$SHAFT, DRIVE 100 1 \$26590 \$END, PLATE FRAME 101 2 \$47901 \$BAR, HOPPER SUPPORT 102 1 \$47902 \$PLATE, HOPPER MOUNT 103 1 \$47905 \$BAR, LIFTER 104 1 \$47906 \$SHAFT, LIFTER DRIVE	97	2	S18750	HOPPER, SPACER
100 1 S26590 END, PLATE FRAME 101 2 S47901 BAR, HOPPER SUPPORT 102 1 S47902 PLATE, HOPPER MOUNT 103 1 S47905 BAR, LIFTER 104 1 S47906 SHAFT, LIFTER DRIVE	98	1	S18751	HOPPER, SPACER
101 2 S47901 BAR, HOPPER SUPPORT 102 1 S47902 PLATE, HOPPER MOUNT 103 1 S47905 BAR, LIFTER 104 1 S47906 SHAFT, LIFTER DRIVE	99	1	S26556	SHAFT, DRIVE
102 1 S47902 PLATE, HOPPER MOUNT 103 1 S47905 BAR, LIFTER 104 1 S47906 SHAFT, LIFTER DRIVE	100	1	S26590	END, PLATE FRAME
103 1 S47905 BAR, LIFTER 104 1 S47906 SHAFT, LIFTER DRIVE	101	2	S47901	BAR, HOPPER SUPPORT
104 1 S47906 SHAFT, LIFTER DRIVE	102	1	S47902	PLATE, HOPPER MOUNT
	103	1	S47905	
	104	1	S47906	
105 1 S47907 SHAFT, LIFTER DRIVE	105	1	S47907	SHAFT, LIFTER DRIVE

Item	Qty	Part #	Description
106	4	S47908	COLLAR, LIFTER LOCATE
107	1	S47918	BAR, TIE
108	1	S18702-1	HOPPER
109	1	S18708-1	SLEEVE
110	1	S18715-1	SHAFT, CRANK
111	1	S18716-3	STOP, ARM
112	1	S18722-3	MOUNT, V.C.
113	1	S18723-5	SHAFT, VACUUM
114	1	S26557-1	FRAME, INLINE PICK-N-PLACE
115	1	S47903-R	BAR, LIFTER MOUNT
116	1	S47913-R	BAR, MOTOR MOUNT
117	1	WA011	WASHER


203P L/H Pick-n-Place


Item	Qty	Part #	Description
1	4	100623	WASHER, FLAT .250
2	4	102131	KNOB
3	1	102528	GEAR, 1648
4	1	102531	GEAR, 1648 .750B .188K
5	8	103106	BEARING, FLAT .375
6	6	103108	BEARING, FLAT .500
7	6	103116	BEARING, FLAT 1.000
8	2	103120	BEARING, FLAT 1.250
9	1	103500	BEARING, ROD END
10	1	104106	SNAPRING, .500
11	2	104108	SNAPRING, 1.250
12	5	104113	SNAPRING, 1.000
13	1	105630	ROD, THD 3/8-24 X 1.75
14	1	108721	PULLEY, 18XL037 .375B .125K
15	2	108785	PULLEY, 16XL037 .375B NK
16	1	109019	BELT, TIMING 60XL037
17	1	109529	CONNECTOR, PIPE
18	1	109533	ELBOW
19	1	109543	BRANCH, T
20	1	109544	NIPPLE, 1/4 NPT AIR GUN
21	4	109545	BUSHING, HEX 1/4 TO 3/8
22	4	109546	PLUG, 1/4 NPT
23	2	109549	PLUG, 1/8 NPT
24	1	109669	VALVE, MAC PID-121BAAA 220V
25	1	109818	PULLEY, 18XL037 .314B NK
26	1	109822	PULLEY, 14XL037 .500B .188K
27	1	109823	PULLEY, 21XL037 .375B NK
28	2	190100	MICROSWITCH, ROLLER
29	2	190605	NIPPLE, VACUUM LINE
30	5	190606	FITTING, 90 DEG 1/4 NPT
31	1	190773	CUP, VACUUM VC57A
32	1	201142	BRACKET, MICROSWITCH
33	1	201158	SWITCH, COVER
34	1	201159	KEY, INTERLOCK SWITCH
35	1	500975	SHOE, HEAD DRIVE CLAMP


Item	Qty	Part #	Description
36	1	501629	CLAMP, GUIDE STRIP
37	1	109013-2	BELT, TIMING 260XL037
38	1	109017-5	BELT, TIMING 80XL037
39	2	190695-1	GAUGE, AIR REGULATOR
40	2	190695-2	REGULATOR, AIR
41	1	200600-1	MOTOR, 41RPM 220V
42	1	500976-1	CLAMP, HEAD DRIVE
43	1	530208-01	ARM, HEAD SUPPORT
44	1	530445-01	CAM, PICK & PLACE
45	1	530447-01	BRACKET, GUIDE MOUNT
46	1	530447-02	BRACKET, GUIDE MOUNT
47	2	530693-01	BAR, MICROSWITCH MOUNT
48	1	530977-01	BLOCK, HOPPER
49	1	530987-02	BLOCK, BEARING
50	1	531556-01	BRACKET
51	1	532021-01	BRACKET, DBL AIR REGULATOR
52	1	532024-01	COVER, JOGGER PULLEY
53	1	532050-01	WELDMENT, HOPPER MTR CVR
54	1	536851-01	COVER, HOPPER PULLEY
55	1	532052-02	COVER, LH 203P DRIVE
56	1	532053-02	COVER, 203P DRIVE
57	1	532054-01	BLOCK, VACUUM MANIFOLD LH
58	1	532104-02	EG, ASSY 203P LH HOPPER
59	2	532138-01	SHAFT, C-CLAMP
60	2	532139-01	ROD, HOPPER FEED
61	1	532257-02	COVER, INLINE PICK-N-PLACE
62	. 1	532369-02	COVER, HOPPER ADJ
63	1	532370-01	PLATE, HOPPER COVER MOUNT
64	2	532446-01	ASSY, HUB BEARING
65	1	532447-01	ASSY, HUB BEARING
66	1	532570-01	ASSY, CRANK ARM
67	1	532570-02	ASSY, CRANK ARM
68	1	532577-01	ASSY, PULLEY BOX 203P
69	1	532670-02	ASSY, DBL AIR REG BRACKET LH
70	1	532684-01	COVER, BEARING BLOCK PULLEY


71 1 532685-04 ASSY, VACUUM ARM LH 72 1 532730-01 BRACKET, MICROSWITCH 73 1 532731-01 CAM, MICROSWITCH 74 1 534006-01 STUD, CRANK ADJUST 75 1 535048-01 ASSY, CRANK ADJUST 76 1 535048-01 ASSY, VAC VALVE & FITTINGS 77 1 CSDD269 78 4 CSDD298 79 1 HJN011 80 2 HJN012 81 1 S18702 HOPPER 82 1 S18705 HOUSING, BEARING 83 2 G19706 HOUSING, DEARING	Item	Qty	Part #	Description
73 1 532731-01 CAM, MICROSWITCH 74 1 534006-01 STUD, CRANK ADJUST 75 1 534007-01 ASSY, CRANK ADJUST 76 1 535048-01 ASSY, VAC VALVE & FITTINGS 77 1 CSDD269 78 4 CSDD298 79 1 HJN011 80 2 HJN012 81 1 S18702 HOPPER 82 1 S18705 HOUSING, BEARING	71	1	532685-04	ASSY, VACUUM ARM LH
74 1 534006-01 STUD, CRANK ADJUST 75 1 534007-01 ASSY, CRANK ADJUST 76 1 535048-01 ASSY, VAC VALVE & FITTINGS 77 1 CSDD269 78 4 CSDD298 79 1 HJN011 80 2 HJN012 81 1 S18702 HOPPER 82 1 S18705 HOUSING, BEARING	72	1	532730-01	BRACKET, MICROSWITCH
75 1 534007-01 ASSY, CRANK ADJUST 76 1 535048-01 ASSY, VAC VALVE & FITTINGS 77 1 CSDD269 78 4 CSDD298 79 1 HJN011 80 2 HJN012 81 1 S18702 HOPPER 82 1 S18705 HOUSING, BEARING	73	1	532731-01	CAM, MICROSWITCH
76 1 535048-01 ASSY, VAC VALVE & FITTINGS 77 1 CSDD269 78 4 CSDD298 79 1 HJN011 80 2 HJN012 81 1 S18702 HOPPER 82 1 S18705 HOUSING, BEARING	74	1	534006-01	STUD, CRANK ADJUST
77 1 CSDD269 78 4 CSDD298 79 1 HJN011 80 2 HJN012 81 1 S18702 HOPPER 82 1 S18705 HOUSING, BEARING	75	1	534007-01	ASSY, CRANK ADJUST
78	76	1	535048-01	ASSY, VAC VALVE & FITTINGS
79 1 HJN011 80 2 HJN012 81 1 S18702 HOPPER 82 1 S18705 HOUSING, BEARING	77	1	CSDD269	
80 2 HJN012 81 1 S18702 HOPPER 82 1 S18705 HOUSING, BEARING	78	4	CSDD298	
81 1 S18702 HOPPER 82 1 S18705 HOUSING, BEARING	79	1	НЈN011	
82 1 S18705 HOUSING, BEARING	80	2	HJN012	
	81	1	S18702	HOPPER
00 0 01070C HOLIONIC DEADNIC	82	1	S18705	HOUSING, BEARING
83 2 S18/06 HOUSING, BEARING	83	2	S18706	HOUSING, BEARING
84 1 S18707 SHAFT	84	1	S18707	SHAFT
85 1 S18709 GEAR, DRIVING	85	1	S18709	GEAR, DRIVING
86 1 S18710 STOP, ARM	86	1	S18710	STOP, ARM
87 1 S18711 SHAFT, STOP	87	1	S18711	SHAFT, STOP
88 1 S18712 SHAFT, IDLER	88	1	S18712	SHAFT, IDLER
89 1 S18713 GEAR, CRANK	89	1	S18713	GEAR, CRANK
90 1 S18717 CRANK	90	1	S18717	CRANK
91 1 S18721 HOLDER, V.C.	91	1	S18721	HOLDER, V.C.
92 4 S18732 HOPPER, MOUNT	92	4	S18732	HOPPER, MOUNT
93 4 S18737 WASHER, GUIDE	93	4	S18737	WASHER, GUIDE
94 1 S18747 PLATE, SPACER	94	1	S18747	PLATE, SPACER
95 1 S18748 PLATE, SPACER	95	1	S18748	PLATE, SPACER
96 1 S18749 PLATE, SPACER	96	1	S18749	PLATE, SPACER
97 2 S18750 HOPPER, SPACER	97	2	S18750	HOPPER, SPACER
98 1 S18751 HOPPER, SPACER	98	1	S18751	HOPPER, SPACER
99 1 S26556 SHAFT, DRIVE	99	1	S26556	SHAFT, DRIVE
100 1 S26590 END, PLATE FRAME	100	1	S26590	END, PLATE FRAME
101 2 S47901 BAR, HOPPER SUPPORT	101	2	S47901	BAR, HOPPER SUPPORT
102 1 S47902 PLATE, HOPPER MOUNT	102	1	S47902	PLATE, HOPPER MOUNT
103 1 S47905 BAR, LIFTER	103	1	S47905	BAR, LIFTER
104 1 S47906 SHAFT, LIFTER DRIVE	104	1	S47906	SHAFT, LIFTER DRIVE
105 1 S47907 SHAFT, LIFTER DRIVE	105	1	S47907	SHAFT, LIFTER DRIVE


Item	Qty	Part #	Description
106	4	S47908	COLLAR, LIFTER LOCATE
107	1	S47918	BAR, TIE
108	1	S18702-1	HOPPER
109	1	S18708-1	SLEEVE
110	1	S18715-1	SHAFT, CRANK
111	1	S18716-3	STOP, ARM
112	1	S18722-3	MOUNT, V.C.
113	1	S18723-5	SHAFT, VACUUM
114	1	S26557-1	FRAME, INLINE PICK-N-PLACE
115	1	S47903-L	BAR, LIFTER MOUNT
116	1	S47913-L	BAR, MOTOR MOUNT
117	1	WA011	WASHER











































DRAVING 1 532570-01	DATE DESCRIPTION ECN BY NO.	KIRK - RUDY, INC. KENNESAW, GEORGIA CRANK ARM 532570-02
	NO N	HHIRD ANGLE PROJECTION PROPRIETARY AND CONFIDENTIAL NO PROPRIETARY AND CONFIDENTIAL NATIONAL CONFIDENTIAL CONFIDENTIAL CONFIDENTIAL CONFIDENTIAL CONFIDENTIAL CONFIDENTIAL CONFIDENTIAL CONFIDENTIAL CONFIDENTIAL CONFIDENTI
	PART # DESCRIPTION 103106 BEARING - FLAT SP18717 CRANK	N JG O O DINENSIONAL TOLERANCES WATERIAL: N JG O O O O O O O O O O O O O O O O

DARBING # 532670-01	NO NO NO NO NO NO NO NO	
	1 109529 CONNECTOR, PIPE 1 109529 CONNECTOR, PIPE 1 109533 ELBOW 1 1 1 1 1 1 1 1 1	NJG 0.375 UNLESS OTHERWES NOTED NATERIAL: N/A HEATTREAT: N/A HEATTREAT. N/A HEATTREAT.

/ 0 - 0 2		ļ	Y, INC. GEORGIA T LH 2670-02
5326 Description			IRK - RUD NNESAW, G BRCK
DATE		(-)	AIR RE
NO NO		2	AND COMFIDENTIAL OF THIS DRAWING OFF WILLIAM OFF WILLIAM THOUT HE THEN PEN ISSION THE OFF WILLIAM THEN PEN ISSION THE OFF WILLIAM THEN PEN ISSION THE OFF WILLIAM THE OFF WILL
			PROPRIETARY NO POSITION NAT BE UND FOUND
			MODELS O 3 P
			N/A N/A N/A
	GUN IUBE NIPPLE 1 NPT SULATOR		MATERIAL: 0. 6. HEAT TREAT: NID HEAT TREAT: S THIST.
ON 1, PIPE	4 NPT AIR 90 DEG 1/4 SSURE AIR BL AIR REC		UNLESS OTHERWISE NOTED TX TX ANG. OI 005 REMOVE ALL BURRS AND SHARP EDGIS UNLESS OTHERWISE NOTED ALL DIMENSIONS ANE FINISHED DIMENSIONS DO NOT SCALE WORK TO DIMENSIONS ONLY
DESCRIPTION CONNECTOR, ELBOW		WACHINE ONLY	. 375 Jan-98
Y PART # 109529 109533	109543 109544 109546 190606 190695-1 190695-2 532021-02	: FOR L/H MACHINE	JG SCALE 8
1 TEM 01 Y	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	NOTE:	CHECKED BT:



CHNG'D DRIVE FR ' GEARS 6298 NJG	FROM 6458	(m)		=		1 532685.03	RK - RUDY, INC. NES/ V, GEORGI,	BOX 03P 532577-01
NO NO DATE 1 3-1-98 CH	6						PROPRIETARY AND CONFIDENTIAL NO PORTION OF THIS DRAW HIG NA DE OLOTED OR REPRODUCE IN ANY FORW WITHOUT THE EXRESS WRITTEN PERMISSION OF KIRK-RUDY INC. KENNESSAW, GA 3014 USA	ASSY, PULLEY
		H N	2		8		N/A N/A	
ION FLAT	2	BELT, TIMING 60XL037 PULLEY, 14XL037 .500B .188K PULLEY, 21XL037 .375B NK BLOCK, BEARING COVER, BRG BLK PULLEY	SLEEVE SHAFT, VACUUM	(5)		6	J. 375 UNLESS OTHERWISE NOTES ALTERIAL TX XXX ANG. OI .005 .3 HEATTRE. Jan - 98 REMOVE ALL BURRS AND	ALL DIMENSIONS ARE FINISH: DIMENSIONS ON ON SCALE - WORK
TEM OTY	7	5 1 109019 6 1 109822 7 1 109823 8 530987-02 9 532684-01					NJG 0. CHECKED B7: 5CALE DATE 5 - J C	TRACED BT: MASTER



	NO BY		1 203P REO'D WHERE USED 1Y, INC. GEORGIA 1 NGS
	DE SCR I P I I ON	4	KIRK - RUDY, INC KENNESAW, GEORG VALVE & FITTINGS
7.50	REV - DATE		
			DECTION PROPRETARY AND CONFIDENTIAL NO PORTION OF THIS DRAWING. MAY BE COUCLE OF REPRODUCED FREPRODUCED FREPRODUCED FREPRODUCED FREPRODUCED FRANT FORW WITHOUT THE CAPPER STAND OF THE SAME OF 30 144 USA 1111E: ASSUME A
			MODEL: R 2 0 3
	3 / 8 TUBE N I PPLE AAA 220V 4 NPT		N A
NOTED	HING, 1/4 TO /4NPT W/. 06 MAC PID-121E VACUUM LINE - 90 DEG 1/		UNLESS OTHERWISE NOTED TX TX TXG. OIL GOST OIL GOST ARCHAULES AND SHARP EGGES UNLESS OTHERS OTHERS OF FINE FOLLOWERS OF FINE FINE FOLLOWERS OF FINE FINE FOLLOWERS OF FINE FINE FOLLOWERS OF FINE FINE FINE FINE FINE FINE FINE FIN
PART # DESCRIPTION	4 4 5 4 4 5 9 9 9 9 9 9 9 9 9 9 9 9 9 9		SCALE . 000 20 - Nov - 98
ITEM OTY PA			рвами дт. Т Ј С сиескео вт. твасео вт.

7 ELECTRICAL SCHEMATICS AND PARTS



WARNING

Read and follow all Safety Instructions in Section 1, Page 5 before proceeding.

7.1 WIRING DIAGRAMS LIST

200-174-00-110

PICK + PLACE SHAFT DRIVE

200-106-01-112


Pick & Place with Motor Drive

7.2 PARTS LIST – STANDARD SHAFT DRIVE


KR Part #	Qty	Name	Description
109666	1	Valve, Mac	558-12-PI-111CA-110VAC
190100	2	Microswitch, Roller	BZ-2RW82-A2

7.3 PARTS LIST – MOTOR DRIVE

KR Part #	Qty	Name	Description
104033	1	Warner Clutch	405-23-005
109666	1	Valve, Mac	558-12-PI-111CA-110VAC
190100	2	Microswitch, Roller	BZ-2RW82-A2
200124	1	Pump, Vacuum	823 GAST
200170-01	1	Motor, Bodine 1/8 hp	250 rpm
202277	2	Socket, Relay	RH4B-ULCD24V
202291	2	Relay, 24V AC	700-HF32A24-4
202297	1	Relay, Multi-function	TRM Strelel
202426-2	1	Board, 90V DC Motor	KBNM-225D 240 VAC
203022	1	Micron GlobalTRAN	B050-0021-GA
208015	1	Fuse	MDL 1
208031	2	Fuse	5 MDL
208043	2	Fuse	MDL/GDL 10
208045	1	Fuse	MDL/GDL 2



Kirk-Hudy, Inc.	P. M. B. T. W. L. W.
7/00 DUS WEST Drive P.O. Box 1507	*****
Kennesaw, Georgia 30144	*****
T1110	Ī
Pick & Place Feeder	-
Size Document Number	REV
A 200 174 00 110	o
Oste:	



8 APPENDIX

SPECIAL OPTIONS

8.1 SUCTION CUP OPTIONS


KR Part #	Manufacturer's #	Description	KR Holder needed
190704	VC36B	Small Round Blue	SP18721-2
190773	VC57A	Big Round Blue	SP18721
190774	B-15-2	Black Bevels	SP18721-1
190778	VC189B	Medium Rectangular Blue	SP18721-3
190811	P1AB F20	Small Round Black	SP18721-3
190818	VC189A	Large Rectangular Blue	SP18721-3
190819	VC189C	Small Rectangular Blue	SP18721-3
190820	P1AB F25	Large Round Black	SP18721-3

8.2 DUAL HOPPER OPTION

The Dual Hopper option assembly is 531989-01 and is used to feed two products side by side. See following page for 531989-01.

8.3 MOTOR DRIVE OPTION

The Motor Drive option assembly is 534945-01 and is used to drive the head instead of using the standard shaft drive. See following page for 534945-01.



534945-01	BESCRIFTON SECRIPTION	13 16 16 17 17 17 17 18 18 18 18
DADT #	1 1 1 1 1 1 1 1 1 1	SCALE 0.375 DINENSIONAL TOLERANCES 0.375 UNLESS OTHERWISE NOTED 1. TIT ANG. 0. 0. 0. 0. 0. 0. 0. 0. 0. 0. 0. 0. 0. 0

9	NOTES

10 WARRANTY AND SERVICE

WARRANTY

Warranty: Kirk-Rudy, Inc., warrants to the original retail purchaser that this product is free from defects in the material and workmanship, and agrees to repair or replace, at Kirk-Rudy's option, any defective product within (90) days from the date of purchase. This warranty is not transferable. It covers damage resulting from defects in material or workmanship, and it does not cover conditions or malfunctions resulting from normal wear, neglect, abuse or accident.

THIS WARRANTY IS IN LIEU OF ALL OTHER EXPRESSED WARRANTIES ANY IMPLIED WARRANTY OF MERCHANTABLITIY OR FITNESS FOR A PARTICULAR PURPOSE OR ANY IMPLIED WARRANTY ARISING OUT OF A COURSE OF DEALING, CUSTOM, OR USAGE OF TRADE.

Limitation of Remedies: If product is proven to be defective within the warranty period stated above, THE EXCLUSIVE REMEDY, AT KIRK-RUDY'S OPTION, SHALL BE TO REFUND THE PURCHASE PRICE OF OR TO REPAIR OR REPLACE THE DEFECTIVE PRODUCT, provided that the defective product is, at Kirk-Rudy's choice, returned immediately to Kirk-Rudy or authorized service representative designated by Kirk-Rudy, or made available at user's premises in a location suitable for servicing.

Limitation of Liability: Kirk-Rudy shall not otherwise be liable for any losses or damages, whether direct, indirect, special, incidental, or consequential, regardless of the legal or equitable theory asserted, including contract, negligence, warranty, or strict liability.

To obtain replacement parts and service, contact an Authorized Kirk-Rudy Dealer. Use Kirk-Rudy part numbers when ordering.

USE ONLY GENUINE KIRK-RUDY REPLACEMENT PARTS

KIRK-RUDY, INC 125 Lorraine Parkway Woodstock, GA 30188 770-427-4203 FX 770-427-4036 www.kirkrudy.com