

## Artserialagent User Guide


- 1. Connect USB-serial adapter between target board and Windows PC
- 2. Determine the Serial port number by using Device Manager (Wins XP), make sure the COM port number less than 3 (if it is COM41, then change it to COM2 or 3, and restart your computer)



3. Configure the corresponding COM2 (see highlight part in the above figure) in remoteIP.ini file:



4. Open hyper terminal with COM2 with UART setting as 115200, n, 8, 1:




- 5. On the Hyper terminal, if the target board brings up, the type the command as follows:
  - Insmod compat.ko
  - ➤ Insmod ath6kl\_cfg80211.ko
  - Insmod ath6kl\_sdio.ko debug\_quirks=0x10
  - cp /etc/inittab /etc/inittab\_yes

Make sure the line is not commented out in the file inittab\_yes:

S:2345:respawn:/sbin/getty 115200 ttyO0

- cp /etc/inittab /etc/inittab\_no
  Make sure the line is commented out in the file inittab\_no:
  # S:2345:respawn:/sbin/getty 115200 ttyO0
- Artserialagent /dev/ttyO0 80 &
- 6. On Windows XP PC, type the command IQrun\_Console.exe -run tony\_test.txt



7. If successfully, it will show the following figure:

