Phone: (904) 248-4308 Fax: (904) 248-4301

NSN	Nomenclature (1561)	P/N	Alternate P/N	A/C	SOR AWD
Items on the "In-	Active" capabilities list, as well as items in the sa	ame "Families" as those on the a	ctive or inactive		
list will require r	esearch; a current publication and possibly supp	port equipment provided by the	customer and up to		
•			<u>_</u>		
45 days lead time	e to re-establish capability, please contact NSI N	IRO/Logistics for further informa			
6610-00-976-3341	Accelerometer, Counting Indicator	262	MS25448-1	A4/T2	NAVICP
5826-00-168-8308	Bearing Distance Heading Indicator (BDHI)	1000	ID-663/U	A4	NAVICP
5826-00-689-9780	Bearing Distance Heading Indicator (BDHI)	10124	ID-663A/U	A4/H3/P3	NAVICP
6610-00-115-6782	Attitude Indicator	11500	ID1448A/A	A4T2	
6610-00-622-6227	Position Indicator	12050			
6610-00-133-7868	Accelerometer, Counting Indicator	24110	MIL-A-22145	A4/H3/S3/T2	NAVICP
6610-00-912-5033	Attitude Indicator	42659	ID1448/A	A4/T2	NAVICP
6610-00-937-9721	Attitude Indicator	43010	ID1448/A	A4/T2	NAVICP
6610-00-140-1719	Attitude Indicator	44615	ID-1448/A, B185	A4/T2	NAVICP
6605-00-034-2500	Horizontal Situation Indicator (HSI)	100524	AQU-2A	C141/T38/T39	USAF-Tink
6605-00-992-3096	Horizontal Situation Indicator (HSI)	101000	104500	C141/F111	USAF-Tink
5826-00-953-9465	Bearing Distance Heading Indicator (BDHI)	101200	ID-663U	A4/P3	NAVICP
5826-00-961-7185	Bearing Distance Heading Indicator (BDHI)	101580	ID-663A/U	A4	NAVICP
5826-00-912-3285	Bearing Distance Heading Indicator (BDHI)	102200	ID-663BU	A4/H3	NAVICP
6610-00-933-5951	Attitude Indicator	102300	MS17400-1	A4	NAVICP
6610-00-939-5237	Attitude Direction Indicator (ADI)	102379		Gen	USAF-Tink
6610-00-764-6627	Attitude Direction Indicator (ADI)	102630	MIL-I-27710	A4/C12/U21	NAVICP
5826-00-089-7912	Bearing Distance Heading Indicator (BDHI)	104470	ID-663C/U	A4/P3	NAVICP
6610-00-131-8817	Attitude Direction Indicator (ADI)	109090		Gen	USAF-Tink
6610-01-314-2480	Attitude Direction Indicator (ADI)	112790		Gen	USAF-Tink
6610-00-165-5827	Attitude Indicator, Remote	112940	MS17401-1	A4	NAVICP
6610-01-655-5827	Attitude Indicator	112940		A4	NAVICP
6610-00-086-1632	Attitude Indicator	113150	ID-1329A/A	A4	NAVICP
6605-01-058-0975	Horizontal Situation Indicator (HSI)	126460	AQU13/A/A	F5/F16/F117	USAF-Tink
6605-01-221-5384	Horizontal Situation Indicator (HSI)	126610		A7/A10	USAF-Tink
6610-01-132-1898	Attitude Direction Indicator (ADI)	135070		Gen	USAF-Tink
5826-00-953-9464	Bearing Distance Heading Indicator (BDHI)	182774	ID-663/U	A4/H3	NAVICP
5826-00-952-3709	Bearing Distance Heading Indicator (BDHI)	196716	ID-1103	A4	NAVICP
6610-01-180-5544	Attitude Indicator, Remote	276111	E25-8034-2	A4	NAVICP
6605-01-194-3611	Horizontal Situation Indicator (HSI)	277666	AQU-4/A	C141/F111	
6620-01-063-9054	Torquemeter Indicator	472592		P3	NAVICP
	Pressure Indicator, Oil	522082	101-384122-5		
5826-00-912-3285	Bearing Distance Heading Indicator (BDHI)	587981	2033250-01	A4/H3	NAVICP
6610-00-663-8813	Attitude Indicator	613937	NAF 1308-1	P3	NAVICP

Phone: (904) 248-4308 Fax: (904) 248-4301

6610-00-663-8812	Attitude Indicator	678901	NAF 1308-1	P3	NAVICP
6610-00-050-8808	Attitude Direction Indicator (ADI)	1510698		Gen	USAF-Tink
6605-00-775-3253	Horizontal Situation Indicator (HSI)	1783960	AQU-2/A	T-38/T-39	
6610-00-474-2286	Attitude Direction Indicator (ADI)	1784163		Gen	USAF-Tink
6610-00-405-6461	Altimeter Indicator	88415422001		Gen	NAVICP
6615-01-217-6219	Horizontal Situation Indicator (HSI)	066-3046-01	KI 525A	C12/U21	NAVTRA
6620-01-285-4685	Suction Gauge Indicator	09007-0168	101-384133-1		
6685-01-069-3964	Temperature Indicator	100004-001		P3/S3	NAVICP
6685-01-176-3649	Temperature Indicator, Turbine Inlet (TIT)	10004-001A	670785-111	P3/S3	NAVICP
XXXX	Rate of Climb Indicator (ROC, VSI, VVI)	100-384053-3			
XXXX	Position Indicator, Flap	100-384053-7			
6610-01-323-1077	Rate of Climb Indicator (ROC, VSI, VVI)	100-384054-1	7130C-44	C12/U21	NAVTRA
XXXX	Pressure Indicator, Oil	100-384058-7			
XXXX	Turn and Slip Indicator	100-384078-1	2800(6930NIL)	C12/U21	NAVTRA
01-530-3198	Tachometer Indicator, Propeller	100-384079-3	3941231-9003		
XXXX	Pressure Indicator, Oil	100-384082-5	522315		
XXXX	Indicator	100-384088-5	55035-1138		
XXXX	Rate of Climb Indicator (ROC, VSI, VVI)	100-384091-1	35060-1152		
XXXX	Pressure Indicator, Pneumatic	100-384092-3	78020-1114		
XXXX	Position Indicator, Flap	100-384093-1	8001-3003		
XXXX	Turn and Slip Indicator	100-500053-7	270-2424-010		
1660-01-030-2821	Temperature Controller	10088A200-505	673163-107	Gen	
1660-01-037-8700	Temperature Controller	10088A200-507	673163-109	Gen	
5826-00-887-1942	Converter, Navigation Set ARN-87	101217-1	616277-7		
XXXX	Temperature & Pressure Indicator, Oil	101-320255-5	521594		
XXXX	Indicator	101-380030-1	509-003-901		
XXXX	Indicator	101-380030-3	509-003-903		
XXXX	Torque Meter Indicator	101-384008-3	SR2AM		
XXXX	Voltage Indicator, AC	101-384078-1	570-518		
XXXX	Voltage Indicator, DC	101-384106-1	562-898/MD106-5		
XXXX	Voltage Indicator, DC	101-384106-3	562-898/MD106-3		
XXXX	Voltage Indicator, DC	101-384106-5	MD106-5		
XXXX	Voltage Indicator, DC	101-384106-7	563-110/MD106-7		
01-493-4880	Voltage Indicator, DC	101-384106-9	563-124/MD106-9		
01-493-4881	Voltage Indicator, AC	101-384107-3	570-531		
XXXX	Altimeter Indicator, Encoder	101-420-01223			
6610-01-359-9809	Turn and Slip Indicator	101-500053-7	270-2424-010		
6610-00-972-0869	Altimeter Ind, Counter-Drum Pointer/Servoed Ctl	10180A			
6610-00-872-0454	Altimeter Ind, Counter-Drum Pointer/Servoed Ctl	10180-A	AAU-19A/A	A4	NAVICP
XXXX	Torque Meter Indicator	104-384017-3	SR-C2AQ		

Phone: (904) 248-4308 Fax: (904) 248-4301

XXXX	Torque Meter Indicator	104-384017-5	SR-C2AS		
6610-01-091-3702	Altimeter Indicator, Pressure	10450-31327	22964	A4	USA/USAF
6610-01-296-0880	Altimeter Indicator, Pressure	10450-31875	23557	Gen	N00383
6610-01-390-6925	Attitude Direction Indicator (ADI)	109090-3		Gen	USAF-Tink
6610-00-106-7552	Altimeter Indicator, Pressure	112234-1	AAU-24A	A4	NAVICP
6610-01-167-6617	Attitude Direction Indicator (ADI)	112790-1	ARU-39A	C130/T38/F15	USAF-Tink
5826-00-952-3709	Bearing Distance Heading Indicator (BDHI)	1166-8	ID-1103/ARN	A4	NAVICP
6605-01-094-3627	Horizontal Situation Indicator (HSI)	118550M	AQU-13A/A	F5/F16/F117	USAF-Tink
6610-00-590-8270	Attitude Indicator	118769-01		A4	NAVICP
6680-00-762-0454	Liquid Quantity Indicator	118-999-20	561281	Gen	USAF
6610-00-729-6479	Position Indicator, Pitch Trim	1200A-C1A-1-A2	3571810-4001	A4	NAVICP
6610-00-778-9039	Position Indicator, Nose Trim	1201A-C2A-1-A2		A4	NAVICP
6610-00-663-8723	Air Speed Indicator	1214CX8-05			
5835-00-703-3601	Recorder Control	121AV12032-1			
6610-00-716-5240	Altimeter Monitor, C-8836	121PE15512-3			
6605-01-398-0032	Horizontal Situation Indicator (HSI)	126610-3		A7/A10	USAF-Tink
6610-00-585-0990	Attitude Direction Indicator (ADI)	127123-01	ARU-13/A	A4	NAVICP
6610-00-663-8716	Air Speed Indicator	1296U4-0202		Gen	S9
6610-00-663-8722	Air Speed Indicator	1296U40206		Gen	S9
6610-00-776-2137	Position Indicator, Flap	1300A-C1A-1A2		A4	NAVICP
6610-00-930-9158	Position Indicator, Flap	1301A-C1A-1-A2		A4	NAVICP
6610-00-580-9562	Attitude Indicator	131400-01	ARU-13/A	A4	NAVICP
6610-00-738-6203	Attitude Indicator	134799-01-02	ID-811AJB3A		
6610-00-783-5470	Attitude Direction Indicator (ADI)	136000-01-01		Gen	USAF-Tink
6610-00-855-9349	Attitude Direction Indicator (ADI)	136600-01-03	ARU-13/A	A4	NAVICP
6610-00-866-3234	Attitude Direction Indicator (ADI)	136601-01-03	ARU-14A		
6610-00-833-3315	Attitude Direction Indicator (ADI)	136910-01-01		Gen	USAF-Tink
6610-00-866-4348	Attitude Indicator	137000-01-01	4012D	A4/T2	NAVICP
6610-00-061-7882	Attitude Indicator	137521-01-02		A4	NAVICP
1660-00-870-0497	Temperature Controller	1378-1A	860-1	Н3	NAVICP
1660-00-939-0460	Temperature Controller	1378-1B		Н3	NAVICP
1660-00-019-1515	Temperature Controller	1378-1C		Н3	NAVICP
1660-00-921-8441	Temperature Controller	1378-1F		Н3	NAVICP
6610-00-954-6156	Attitude Direction Indicator (ADI)	138093-01-02	ARU-13/U	A4	NAVICP
6610-00-809-0978	Attitude Indicator	138094-01-01	4005N		
6610-00-990-9825	Attitude Indicator	138094-01-02			
6610-00-055-8535	Attitude Direction Indicator (ADI)	139001-01-01		Gen	USAF-Tink
6610-00-722-2795	Attitude Direction Indicator (ADI)	139001-01-02		Gen	USAF-Tink
6610-00-933-9262	Attitude Direction Indicator (ADI)	139001-01-03		Gen	USAF-Tink
6610-00-424-8740	Attitude Direction Indicator (ADI)	139001-01-04		Gen	USAF-Tink

Phone: (904) 248-4308 Fax: (904) 248-4301

6610-00-758-2385	Attitude Indicator	141400-01-01	4005AB	Gen	NAVTRA
6610-00-169-1526	Attitude Indicator	142000-01-01	ID-1329A	A4	NAVICP
4920-00-993-7859	Position Indicator	142550-01-01	2718A	Gen	NAVICP
6625-00-189-9607	Position Indicator	142550-02-01	2718C	Gen	USAF-Kelly
6610-00-167-9699	Attitude Indicator	144700-01-01	4003AF	A4/C12/U21	NAVICP
6610-00-641-3015	Attitude Indicator	14602-1JA1M		P3	USA
6610-00-663-8798	Attitude Indicator	14602-1JD1	MIL-I-5133B	S3	NAVICP
6610-00-663-8800	Attitude Indicator	14602-1JF1	MIL-I-5133B	S3	NAVICP
6610-00-179-9035	Attitude Indicator	148700-01-01		Gen	NAVTRA
6610-00-023-6073	Attitude Indicator	148700-03-01			
6610-01-023-6073	Attitude Indicator	148700-03-01			
6610-00-410-2866	Attitude Indicator	149250-01-01		Gen	NAVICP
6610-00-186-8229	Attitude Direction Indicator (ADI)	152560-01-01		Gen	USAF-Tink
6685-00-557-5910	Temperatue Indicator, Thermocouple	152B2	152B2A	Н3	S9
6685-00-557-5910	Temperatue Indicator, Thermocouple	152B22	157800	Н3	S9
6685-00-530-3614	Temperatue Indicator, Thermocouple	152B4	152B44	Н3	S9
6625-00-895-3980	Temperatue Indicator, Thermocouple	152B8	MJ2	Н3	S9
6685-00-557-7006	Temperature Indicator	152BL2C	MIL-I-25852		
6610-00-148-7180	Attitude Direction Indicator (ADI)	156578-01-01	4003AU	Gen	USAF-Tink
6615-00-676-0855	Controller, Roll Stabilization	15753-1-A			
6610-01-394-8294	Attitude Direction Indicator (ADI)	160C180238-1		Gen	USAF-Tink
6610-01-070-9411	Attitude Direction Indicator (ADI)	161815-01-01		Gen	USAF-Tink
6610-00-190-1414	Rate of Climb Indicator (ROC, VSI, VVI)	1636-6A-B1			
6610-00-663-4138	Rate of Climb Indicator (ROC, VSI, VVI)	1636-6H-B1			
6685-00-603-3913	Temperatue Indicator, Thermocouple	163B2	EHU18A	Н3	S9
6685-00-603-3913	Temperatue Indicator, Thermocouple	163B2C	163B2D	Н3	S9
6610-00-663-4148	Rate of Climb Indicator (ROC, VSI, VVI)	1648-6U-A6-1			
6608-00-893-7892	Liquid Quantity Indicator, Oxygen	1649602-1	29316-4L-C1	A4	NAVICP
6680-00-943-5179	Liquid Quantity Repeater Indicator, Oxygen	1649602-2	29119-6Н-А1	T2	NAVICP
6610-00-639-3615	Rate of Climb Indicator (ROC, VSI, VVI)	1652-6AJ-B6-1	1652-6AJ-BG-1	H53	NAVICP
6610-00-639-3615	Rate of Climb Indicator (ROC, VSI, VVI)	1652-6AJ-C6-1	MS28075-1	H53	NAVICP
6610-00-816-3621	Rate of Climb Indicator (ROC, VSI, VVI)	1655-6AEB6-1	MIL-I-18804	S3	NAVICP
6610-00-816-3621	Rate of Climb Indicator (ROC, VSI, VVI)	1655-6AEB6-1SD		S3	NAVICP
6610-00-886-6518	Rate of Climb Indicator (ROC, VSI, VVI)	1665-6AU-6A-1		A4	NAVICP
6610-00-970-9111	Rate of Climb Indicator (ROC, VSI, VVI)	1667-6AEA6-1	128SCAV108-1	Gen	NAVICP
6610-00-477-6691	Rate of Climb Indicator (ROC, VSI, VVI)	1675-6BD-A6-1	MS28075-2B	Gen	NAVICP
6610-00-454-0284	Rate of Climb Indicator (ROC, VSI, VVI)	1684-6BDA6-1		S3	NAVICP
6610-00-462-3879	Rate of Climb Indicator (ROC, VSI, VVI)	1685-6BDA6-1		S3	NAVICP
6625-01-513-5012	Load Meter	169P909-1LBW5			
6680-01-491-8863	Liquid Quantity Indicator, Fuel	169P910-22LBW5			

Phone: (904) 248-4308 Fax: (904) 248-4301

6620-01-513-4140	Temperature Indicator, Engine Oil	169P910-5LBW5			
6610-00-050-8806	Attitude Direction Indicator (ADI)	1784163-901		Gen	USAF-Tink
6620-00-717-1900	Pressure Indicator, Oil	18-1118	18-1118W	Gen	<b>S</b> 9
6685-00-690-8905	Pressure Indicator, Oil	18-1157	EGU-1/A	Gen	S9
6685-00-882-8127	Altimeter Indicator, Pressure	18-1169	MS 25470-7	Gen	NAVICP
6685-00-979-6257	Altimeter Indicator, Pressure	18-1199-01		Gen	x-nif-NSN
6620-00-903-5054	Altimeter Indicator, Pressure	18-1486	HE432-5005-0001	T2	NAVICP
6620-00-904-1596	Altimeter Indicator, Pressure	18-1487	HE432-5004-0001	A4/T2	NAVICP
6620-00-903-5053	Altimeter Indicator, Pressure	18-1488	HE432-5003-0001	T2	NAVICP
5826-00-032-7024	Bearing Distance Heading Indicator (BDHI)	18-1686-2	ID-663	A4/H3	NAVICP
6610-00-514-4181	Altimeter Indicator	1845LU-4-02BUE		Gen	x-nif-PN
6610-00-999-1528	Attitude Indicator	18507-1EA1	1493892	A4/T2	NAVICP
6680-00-425-1763	Liquid Quantity Indicator, Fuel	200-017-001		A4	NAVICP
6680-00-425-1823	Liquid Quantity Indicator	200-018-001	7821745-501	A4	NAVICP
6620-01-038-5801	Torquemeter Indicator	201-004-001		Gen	NAVICP
6620-01-328-2971	Altimeter Indicator, Pressure	206-075-675-001	9016-3018		
6610-01-083-1439	Accelerometer, Counting Indicator	2094-7			
6610-00-451-1155	Turn and Slip Indicator	20B380-1	91-380018-1		
6680-00-425-1762	Liquid Quantity Indicator	211-003-001	7821745-503	A4	NAVICP
XXXX	Accelerometer, Counting Indicator	2117-812		C12/T34/44	NAVTRA
6610-00-585-5929	Accelerometer, Counting Indicator	2119-001	Type MA1	T2	NAVICP
6610-00-585-1355	Accelerometer, Counting Indicator	2119-001-2		T2	NAVICP
6610-00-684-1666	Accelerometer, Counting Indicator	2119-001-3	MIL-A-25719	T2	NAVICP
6680-00-294-6291	Liquid Quantity Indicator	215-002-002	694966-101	S3	NAVICP
6680-00-294-6289	Liquid Quantity Indicator	219-004-002	694965-101	S3	NAVICP
6680-00-554-4336	Liquid Quantity Indicator	219-004-003	694965-103	S3	NAVICP
6610-00-732-0037	Accelerometer, Counting Indicator	2231B1	262	A4/T2	NAVICP
6610-00-732-0037	Accelerometer, Counting Indicator	2231B2	MS 25448-1	A4/T2	NAVICP
6610-00-530-3953	Altimeter Indicator, Pressure	2240LU-4-02	5760L4U	Gen	NAVICP
6610-00-181-1746	Accelerometer, Counting Transducer	24108-1		A4	NAVICP
6610-00-181-1750	Accelerometer, Counting Transducer	24108-4	MIL-A-22145	A4	NAVICP
6610-00-841-6509	Accelerometer, Counting Transducer	24108-6		A4	NAVICP
6610-00-841-6505	Accelerometer, Counting Transducer	24108-7	261-7	A4	NAVICP
6610-00-903-1047	Accelerometer, Counting Transducer	24108-9		A4	NAVICP
6610-00-732-0035	Accelerometer, Counting Transducer	24523T1		A4	NAVICP
6610-00-976-3340	Accelerometer, Counting Transducer	24523T1	261-1	A4	NAVICP
6610-00-732-0036	Accelerometer, Counting Transducer	24523T4		A4	NAVICP
6610-00-903-1046	Accelerometer, Counting Transducer	24523T7	261-7	A4	NAVICP
6680-00-597-8859	Flow Indicator, Fuel	25104-B16C-3A1			
6685-00-663-8832	Altimeter Indicator, Pressure	254BK8-045		Gen	x-nif-NSN

Phone: (904) 248-4308 Fax: (904) 248-4301

1660-00-719-6885	Temperature Controller	25730028-03		A4	NAVICP
1660-00-562-3898	Temperature Controller	25730028-04	7667750-523	A4	NAVICP
6610-00-976-3337	Accelerometer, Counting Transducer	261-4		A4	NAVICP
6610-00-761-2330	Accelerometer, Counting Transducer	261-7	24108-7	A4	NAVICP
6610-00-558-0399	Turn and Slip Indicator	266-004-001	A51A9055-1	F14	
5826-01-029-8005	Bearing Distance Heading Indicator (BDHI)	276000	ID-663	A4	NAVICP
5826-01-135-1943	Bearing Distance Heading Indicator (BDHI)	276200-001	ID-663D/U		
6680-00-684-2236	Liquid Quantity Indicator, Oxygen	29316-4C-H1		A4	NAVICP
6680-00-723-1934	Liquid Quantity Indicator, Oxygen	29316-4FA1		A4	NAVICP
XXXX	Rate of Climb Indicator (ROC, VSI, VVI)	30030-1137	100-384075-1		
6685-00-234-7118	Temperatue Indicator, Thermocouple	309-001-001	670785-109	P3	NAVICP
6680-01-382-9162	Tachometer Indicator, Turbine	30B367-3	50-380034-3	C34/44	NAVTRA
6610-00-121-4679	Altitude Encoding Altitude Computer	31103-A1	1620644-1	Gen	NAVICP
6610-00-167-9800	Altitude Encoding Altitude Computer	31103-A22		A4	NAVICP
6610-01-242-9674	Airspeed Indicator	3250002-0201	3250002-201	F4	NAVICP
6610-00-086-3840	Altimeter Ind, Counter-Drum Pointer/Servoed Ctl	3252001-0101	AAU-19/A	A4	NAVICP
6610-00-134-1824	Altimeter Indicator, Pressure	3252010-0101	AAU-31/A	A4	NAVICP
6610-01-286-0880	Altimeter Indicator, Pressure	3252010-1100-01	lite mod	Gen	
6610-01-406-4985	Altimeter Indicator, Pressure	3252010-1101-01		Gen	N00383
6610-01-055-0468	Altimeter Indicator, Encoder	3252011-0101	C44202-10-002	C12/T34/44	NAVICP
6610-01-282-3207	Altimeter Indicator, Encoder	3252011-0301		Gen	USA/USAF
6610-01-084-9562	Altimeter Indicator, Encoder	3252011-1101		Gen	NAVICP
6610-01-005-9151	Altimeter Indicator, Encoder	3252013-0101	AAU-31/A	C12/U21	NAVTRA
5826-00-679-3205	Bearing Distance Heading Indicator (BDHI)	331C4A	ID-663U	A4/H3	NAVICP
5841-01-014-1674	Altimeter Indicator, Radar	339Н4	622-1204-003	C12/T34/44	NAVTRA
6620-00-553-8862	Tachometer, Electric Indicator	34101-C1E-7-1C1	MIL-I-25863	A4	NAVICP
6620-00-860-1626	Tachometer Indicator	34101C2C7-2E1	1496049	P3	NAVICP
6620-00-543-2534	Tachometer Indicator	34102C2B3-2D1	MS 21971-1	Gen	NAVICP
6610-00-597-3095	Accelerometer, Counting Indicator	3422-5C-A1		A4	NAVICP
6610-00-445-1033	Altimeter Indicator, Pressure (Cabin Pressure Indicator)	34500-C1-A1A1	A27397-10-004	A4	NAVICP
6610-00-887-2068	Altimeter Ind, Counter-Drum Pointer/Servoed Ctl	34500-C1A-1A1	AAU-19/A	A4	NAVICP
6610-00-147-4225	Amplifier, Electronic Control (ECA)	352-020-001	7821745-515	A4	NAVICP
6685-00-161-8995	Temperatue Indicator, Thermocouple	354-012-001	354-012-004	Gen	NAVICP
6685-00-148-7296	Temperatue Indicator, Thermocouple	354-012-006	354-012-006	Gen	NAVICP
6620-00-181-2605	Tachometer, Electric Indicator	3571260-4002	ERU-5A	A4	NAVICP
6620-00-182-7569	Tachometer, Electric Indicator	3571261-7001	ERU-5A/A	A4	NAVICP
6620-01-025-8503	Tachometer, Electric Indicator	3571280-4002	ERU-5/A	A4	NAVICP
6620-01-060-5430	Tachometer, Electric Indicator	3571281-7001	ERU-5A/A	A4	x-nif-PN
6620-00-946-2677	Torque Meter Indicator, Percent	3571320-0007	6300C38A155B1	НЗ	NAVICP
6610-00-169-1594	Attitude Indicator	3571442-3001	ID-1329A	A4	NAVICP

Phone: (904) 248-4308 Fax: (904) 248-4301

6610-00-244-2816	Attitude Indicator	3571540-9003	DSA309	A4	NAVICP
6610-00-353-9990	Position Indicator, Roll Trim	3571812-4001	673146-101	H3/S3	NAVICP
6610-01-012-0517	Position Indicator, Pitch Trim	3571812-5005	673148-109	S3	NAVICP
6610-00-522-7669	Position Indicator, Flap	3571820-4001	673152-101	S3	NAVICP
6680-00-159-0815	Fluid Quantity Indicator, Hydraulic	358-002-001	65450-01426-101	H3/H53	NAVICP
6680-01-020-8149	Fluid Quantity Indicator, Hydraulic	358-002-002	65450-01426-102	H3/H53	NAVICP
6340-00-672-5700	Stall Warning Shaker	35A509	C35102-3		
6605-01-183-2220	Horizontal Situation Indicator (HSI)	3809283-2		B1	USAF-Tink
6680-00-703-6812	Liquid Quantity Indicator, Fuel	393004-01648	S6145-61391-1	Н3	NAVICP
6680-00-868-9810	Liquid Quantity Indicator, Fuel	393004-01699		НЗ	NAVICP
6680-00-733-8432	Liquid Quantity Indicator, Fuel	393004-01970		НЗ	NAVICP
6680-00-815-7282	Liquid Quantity Indicator, Fuel	393007-07869	624407-1	P3	NAVICP
6680-00-815-7285	Liquid Quantity Indicator, Fuel	393007-07870		P3	NAVICP
6620-00-612-7743	Torquemeter Indicator	393059-01897	21C1596-46	НЗ	NAVICP
6680-00-815-7284	Liquid Quantity Indicator, Fuel	393065-01858	624408-1	P3	NAVICP
6680-00-728-8765	Liquid Quantity Indicator	3B90018-275		C141	USAF
6610-00-629-1883	Attitude Indicator	4003G	131941-01	A4	NAVICP
6610-00-866-3234	Attitude Direction Indicator (ADI)	4005F	MM-4A		
6610-00-068-3464	Attitude Direction Indicator (ADI)	4055K	139602-01-01	Gen	USAF-Tink
6620-00-987-9242	Tachometer, Electric Indicator	408981-2	ERU-5A/A	A4	NAVICP
6680-01-103-3419	Fuel Quantity Indicator	472964-001	68-580104-235	Gen	USAF-Kelly
6685-01-047-8368	Temperatue Indicator, Thermocouple	4SE01104-1		P3/S3	NAVICP
6610-00-089-4358	Attitude Indicator	501-1022-01	ID-1481A	A4T2	x-nif-NSN
6610-00-787-7652	Attitude Indicator	501-1032-01	ID-1481A	Gen	USAF
6610-00-179-2655	Attitude Indicator	501-1049-01	ID-1481A	A4/S3/T2	NAVICP
6610-00-165-5838	Attitude Indicator	501-1059-51	ID-1481A/A	A4T2	NAVICP
6610-00-150-6785	Attitude Direction Indicator (ADI)	501-1086-01		Gen	USAF-Tink
6610-00-719-8446	Attitude Direction Indicator (ADI)	501-1096-01		Gen	USAF-Tink
6610-00-160-0905	Attitude Direction Indicator (ADI)	501-1098-01		Gen	USAF-Tink
6610-00-115-6800	Attitude Indicator	501-1099-01	ID-1791A	A4T2	NAVICP
6610-01-034-5226	Attitude Indicator	501-1099-02	ID-1791A	A4T2	NAVICP
6610-00-200-8832	Attitude Direction Indicator (ADI)	501-1131-01		Gen	USAF-Tink
6610-00-200-8742	Attitude Direction Indicator (ADI)	501-1131-02		Gen	USAF-Tink
6610-00-365-4194	Attitude Direction Indicator (ADI)	501-1153-01		Gen	USAF-Tink
6610-01-045-6372	Attitude Direction Indicator (ADI)	501-1190-02		Gen	USAF-Tink
6610-01-152-2821	Attitude Indicator	501-1197-08		T34/44	NAVTRA
6610-01-182-9481	Attitude Direction Indicator (ADI)	501-1230-01		Gen	USAF-Tink
6610-01-192-2467	Attitude Indicator	501-1239-51	ARU-55A		
6610-01-088-2352	Attitude Indicator	501-1277-01	ID-1791A/A	A4/S3/T2	NAVICP
6610-01-123-2204	Attitude Indicator	501-1278-01	ARU-48/A	A6/F18	NAVICP

Phone: (904) 248-4308 Fax: (904) 248-4301

6610-01-358-1161	Attitude Indicator	501-1492-01	ARU-65/A	A6/F18	NAVICP
6610-01-357-4345	Attitude Indicator	501-1492-02	ARU-69/A	A6/F18	NAVICP
6610-01-341-6041	Attitude Indicator	501-1664-01	ARU-70/A	A6/F18	NAVICP
6610-01-343-2609	Attitude Indicator	501-1665-01	ARU-71/A	A6/F18	NAVICP
6685-00-455-9941	Temperatue Indicator, Thermocouple	502B29	ST4325014HE0001	T2	NAVICP
6610-01-323-1076	Turn and Slip Indicator	50-380023-1			
6685-01-097-9188	Temperature Indicator, Cabin	50-380026-1	562-806		
6620-01-359-9363	Tachometer Indicator, Propeller	50-380035-1	5610-01		
6610-00-089-4358	Attitude Indicator	507-1009	AI-803A	A4T2	x-nif-NSN
6610-01-259-0251	Altimeter Indicator, Encoder	518-28007-204	28007-204	Gen	NAVICP
6610-00-159-1119	Attitude Indicator	520 1045 001		A4	NAVICP
5826-00-812-8606	Bearing Distance Heading Indicator (BDHI)	520-1046-001	C45-9813-02	A4/H3	NAVICP
5826-00-679-3205	Bearing Distance Heading Indicator (BDHI)	522-0974-003	ID663/U	A4/H3	NAVICP
6610-00-633-4260	Horizontal Situation Indicator (HSI)	522-1393-003	Type AFA24J1	S3	NAVICP
5826-00-953-9298	Bearing Distance Heading Indicator (BDHI)	522-2377-003	331C4F	A4/H3	NAVICP
6610-00-799-8315	Horizontal Situation Indicator (HSI)	522-2411-003	331D2	S3	NAVICP
6610-00-975-1699	Horizontal Situation Indicator (HSI)	522-4706-001		Gen	NAVICP
6610-01-294-5633	Altimeter Indicator, Encoder	570-23932-414		C12/U21	NAVTRA
XXXX	Voltage Indicator, AC	570-524	100-384095-1		
5998-01-027-8667	ALC/Control 1A6 p/o RT-1194/ARC-159	601-3718-001		Gen	
6680-00-887-6763	Accelerometer, Counting Indicator	602110-5	CN-793/ASN-42	Gen	NAVICP
5821-01-023-9318	Guard receiver, 1A4 p/o ARC-159	608-9419-003		Gen	
5996-01-025-8697	Circuit Card, ARC-159	608-9420-003		Gen	
5821-01-023-9813	Guard Receiver 1A4	608-9613-003		Gen	
1280-00-475-6858	Control Monitor	60A95D1	DCU-77/A	Н3	NAVICP
5821-00-180-8264	Translator-Modulator, 1A2 p/o ARC-159	617-9621-002	AN/ARC-159	Gen	
5821-00-566-2980	Translator-Modulator, 1A2 p/o ARC-159	617-9621-004	617-9621-006	Gen	NAVICP CNRT
5895-01-017-5383	Control 1A6 p/o ARC-159	618-7241-004		Gen	
5821-00-100-7931	Radio, UHF Communication ARC-159	622-0356-001	AN/ARC-159	Gen	
5821-01-020-3970	Radio, UHF Communication ARC-159	622-0356-002	AN/ARC159	Gen	
5821-00-140-1824	Radio, UHF Communication ARC-159	622-0356-003	AN/ARC-159	Gen	
5821-01-018-4240	Radio, UHF Communication ARC-159	622-1365-001	RT-1150/ARC-159	Gen	
5821-01-020-8384	Radio, UHF Communication ARC-159	622-1366-001	RT-1124/ARC-159	Gen	
5895-00-567-4548	ARC-159	622-1391-003		Gen	
5895-00-567-4549	Amplifier RF, ARC-159	622-1394-002		Gen	
5821-00-567-4544	Chassis 1A7 p/o ARC-159	622-1495-002		Gen	
5821-01-349-7085	Radio, UHF Communication ARC-159	622-1524-001	AN/ARC-159	Gen	
5821-00-140-1775	Radio, UHF Communication ARC-159	622-1524-021	AN/ARC-159	Gen	NAVICP
5821-00-140-1776	Radio, UHF ARC-159	622-1524-022	AN/ARC-159(V)1	Gen	
5821-00-140-1817	Indicator, Frequency Channel p/o ARC-159	622-1624-002	ID-1972/ARC-159V	Gen	

Phone: (904) 248-4308 Fax: (904) 248-4301

6610-01-101-1927	Attitude Indicator	622-3374-002	ADI-55A	Gen	NAVICP
6610-01-101-1883	Horizontal Situation Indicator (HSI)	622-4298-001		Gen	NAVICP
5821-01-029-4786	Connector Board 1A6A1A2 p/o C-9815/ARC-159	628-2137-001		Gen	
5821-01-029-5098	Front Plate 1A6A1 p/o C-9815/ARC-159	628-2138-001		Gen	
6610-00-799-8315	Horizontal Situation Indicator (HSI)	629318-5		S3	NAVICP
5998-01-236-4916	Memory Circuit 1A6A3 p/o ARC-159	637-2576-001	637-2576-002	Gen	
6685-00-919-2188	Temperatue Indicator, Thermocouple	670785-101	BH183R58	P3/S3	NAVICP
6685-01-047-8368	Temperatue Indicator, Thermocouple	670785-105	BH183R58A	S3	NAVICP
5826-00-117-4629	Bearing Indicator	671353-101		P3	NAVICP
6610-00-530-3955	Altimeter Indicator, Pressure	671BK010	C-12	Gen	NAVICP
6610-00-232-9485	Altimeter Indicator, Pressure	671BK011	C-16	Gen	x-nif-NSN
6610-00-232-9472	Altimeter Indicator, Pressure	671CK010	AN5760L4B	Gen	NAVICP
6610-00-301-6365	Altimeter Indicator, Pressure	671CK-010		Gen	x-nif-NSN
6610-00-232-9473	Altimeter Indicator, Pressure	671CKL010	AN5760L4B	Gen	NAVICP
6610-00-663-8815	Attitude Indicator	673191		P3	NAVICP
XXXX	Turn and Slip Indicator	6930N1L			
1680-01-164-4123	Temperature Control Panel	70450-21801-101	783235-1	H60	S9
1680-01-279-8193	Controller Grip Assembly	70450-21905-102	707-3407	H3/H53	S9
6610-01-175-9045	Position Indicator	70450-21953-101	3809487-1	H3/H60	NAVICP
6610-01-164-4329	Rate of Climb Indicator (ROC, VSI, VVI)	70450-21988-101	30260-1164	H60	NAVICP
6605-01-327-0253	Control Panel	70450-81012-041		H3/H53	S9
1680-01-347-4628	Control Panel	70450-81012-043		H3/H53	S9
1680-01-353-9292	Fault Function Indicator Panel	70550-82605-042		H60	TCore/OEM
5895-01-313-6476	Recording Set Control	70600-81815-101	2010566-001	H60	TCore/OEM
1680-01-274-7060	Rescue Hoist Control Panel Assy	70850-22111-113	EC-10000-30	H60	TCore/OEM
1680-01-346-8299	Rescue Hoist Control Panel Assy	70850-22111-121	EC-10000-60	H60	TCore/OEM
1680-01-164-4126	Blade Deice Control Panel	70902-01099-043		H60	S9
1680-01-240-5509	Blade Deice Control Panel	70902-01099-044		H60	S9
1680-01-347-4626	Blade Deice Control Panel	70902-01099-046		H60	S9
6610-00-526-7967	Rate of Climb Indicator (ROC, VSI, VVI)	716BU4-052			
6610-00-663-4156	Rate of Climb Indicator (ROC, VSI, VVI)	716-BU8-036			
XXXX	Rate of Climb Indicator (ROC, VSI, VVI)	7200C57	104-384019-1		
5826-00-505-2218	Course Indicator	7202-1A4B1	ID-249A/ARN52	Н3	
6610-00-038-3423	Air Speed Indicator	724DU4-016			
6610-00-663-8706	Air Speed Indicator	739CU-4-034		Gen	NAVICP
6620-00-030-1867	Tachometer, Electric Indicator	751CU-4-02	AN5530-3A-12		
6620-00-244-8020	Tachometer, Electric Indicator	751CU-4-02	AN5530-3A-12		
6620-00-662-4211	Tachometer, Electric Indicator	751CU-4-02	AN5530-3A-12		
6605-01-018-2184	Horizontal Situation Indicator (HSI)	75500000-1		F5/F16/F117	USAF-Tink
6610-01-192-2467	Attitude Indicator	75J808000-101			

Phone: (904) 248-4308 Fax: (904) 248-4301

6610-01-044-1860	Attitude Direction Indicator (ADI)	77600000-3		Gen	USAF-Tink
6610-01-092-9846	Attitude Direction Indicator (ADI)	77600000-4		Gen	USAF-Tink
6685-00-585-4133	Temperature Indicator	77B203B	AN5792-2		
6620-01-230-0197	Tachometer Indicator	78035-01118		Gen	NAVICP
6620-01-228-1571	Tachometer Indicator	78035-11119		Gen	NAVICP
XXXX	Position Indicator, Flap	8001-3003	100-384093-1		
1680-01-346-8274	Temperature Control Panel	801676-1	70450-21801-102	H60	S9
1680-00-424-6612	Fault Function Indicator Panel	837171-5	673134-111	S3	NAVICP
1680-01-378-3339	Fault Function Indicator Panel	837171-8	673134-117	S3	NAVICP
6610-00-168-0564	Rate of Climb Indicator (ROC, VSI, VVI)	843-67-1		S3	NAVICP
6610-00-179-5175	Rate of Climb Indicator (ROC, VSI, VVI)	843-67-2	MS28075-2B	S3	NAVICP
1680-01-434-1979	Caution Advisory Panel	844182-14	70550-21900-115	H60	TCore/OEM
1680-01-361-1051	Caution Advisory Panel	844182-15	70550-21900-113	H60	TCore/OEM
1680-01-393-6859	Caution Advisory Panel	844182-16	70550-21900-118	H60	TCore/OEM
1680-01-175-8968	Caution Advisory Panel	844182-2	70550-21900-102	H60	TCore/OEM
1680-01-330-6729	Caution Advisory Panel	844182-3	70550-21900-104	H60	TCore/OEM
1680-01-317-4563	Caution Advisory Panel	844182-4	70550-21900-105	H60	TCore/OEM
1680-01-348-5144	Caution Advisory Panel	844182-8	70550-21900-109	H60	TCore/OEM
6620-00-809-4480	Tachometer, Electric Indicator	8831522-0001	C31527-10008	Н3	NAVICP
6610-00-780-3065	Air Speed Transmitter	892495-00-000	A24950-00-001	A4/H3/T2	NAVICP
6610-00-703-0781	Position Indicator, Wheele/Flap	8DJ26AA51			
6610-00-514-6156	Position Indicator	8DJ48CAD1	EA323-1	Gen	S9
6610-00-817-8769	Position Indicator	8DJ48LAA2		Gen	NAVICP
6610-00-817-8771	Position Indicator	8DJ49LAM2		F14	NAVICP
6610-00-817-8772	Position Indicator	8DJ49LAN2		F14	NAVICP
6610-00-084-1129	Position Indicator	8DJ49LAR2	4062044	Gen	S9
6610-00-084-1128	Position Indicator	8DJ49LAS2	7000043	Gen	S9
6610-00-087-6303	Position Indicator	8DJ49LAV2		Gen	NAVICP
6620-01-151-9590	Flowmeter Indicator	8DJ88LAB1, -2, -3		Gen	USAF
XXXX	Volt Ammeter Indicator	90-384023-1	621915		
6610-00-405-0513	Turn and Slip Indicator	91-380019-1			
6210-00-676-7874	Advisory Panel	965-9015-008	S6155-61551-018	Н3	NAVICP
6620-00-345-1474	Flow Indicator	9807-27		T2	x-nif-PN
5826-00-812-8606	Bearing Distance Heading Indicator (BDHI)	9813-02		A4/H3	NAVICP
5826-00-829-9045	Bearing Distance Heading Indicator (BDHI)	9813-06	ID-663U	A4/H3	NAVICP
6610-00-058-9527	Attitude Direction Indicator (ADI)	9819-08		Gen	USAF-Tink
5998-00-836-3633	Modulator Assembly	99971EE207-1		S2/Grum	
6680-00-358-1306	Liquid Oxygen Quantity Indicator	9A1021	MIL-I-81387A Type II	Gen	NAVICP
6680-00-358-1306	Liquid Oxygen Quantity Indicator	9A860		Gen	NAVICP
6610-00-986-0031	Rate of Climb Indicator (ROC, VSI, VVI)	A10352-1	A10352-2	Н3	NAVICP

Phone: (904) 248-4308 Fax: (904) 248-4301

6610-00-625-6035	Turn and Slip Indicator	A1605	MD-1B	Gen	NAVICP
6610-01-105-7880	Turn and Slip Indicator	A1605	MD-1B	Gen	x-nif-PN
6610-00-620-3802	Turn and Slip Indicator	A1620	MD-4A	Gen	NAVICP
6685-00-887-9302	Rate of Climb Indicator (ROC, VSI, VVI)	A26877-10-001	620536-1	P3	NAVICP
6610-00-703-3519	Altimeter Indicator, Pressure (Cabin Pressure Indicator)	A27397-10-004	34500-C1-A1A1	A4	NAVICP
6610-00-605-8296	Rate of Climb Indicator (ROC, VSI, VVI)	A27407-10-004		A4	NAVICP
6610-00-531-2345	Altimeter Indicator, Counter Pointer Pressure	A29534-04-001	A29534-10-004	A4/T2	NAVICP
6610-00-887-2068	Altimeter Ind, Counter-Drum Pointer/Servoed Ctl	A41322-10-002	AAU19A	A4	NAVICP
6610-00-179-5086	Altimeter Ind, Counter-Drum Pointer/Servoed Ctl	A413222-10-003	AAU-19/A	A4	NAVICP
6685-00-148-7296	Temperatue Indicator, Thermocouple	A51A9011-15		Gen	NAVICP
6610-00-150-6897	Altimeter Indicator, Pressure	AAU-24A	B41552-10-002	A4	NAVICP
1680-01-361-1051	Caution Advisory Panel	ABU-26B/A		H60	TCore/OEM
1680-01-330-6729	Caution Advisory Panel	ABU-35A		H60	TCore/OEM
6610-00-787-7652	Attitude Indicator	AI-803B		Gen	USAF
6610-00-179-2655	Attitude Indicator	AI-803D		A4T2	NAVICP
6610-01-012-0517	Position Indicator, Pitch Trim	ALU-11/A		<b>S</b> 3	NAVICP
6610-00-224-1284	Altimeter Indicator, Pressure	AN5760-2	671CK010	Gen	x-nif-NSN
6610-00-301-6365	Altimeter Indicator, Pressure	AN5760-2	C63110ISSUEA	Gen	x-nif-NSN
6610-00-224-1278	Altimeter Indicator, Pressure	AN5760-2A	671K03	Gen	USAF
6610-00-663-7749	Altimeter Indicator, Pressure	AN5760-2A	671CP19-017	Gen	x-nif-NSN
6610-00-224-1843	Altimeter Indicator, Pressure	AN5760L2	671CKL010	Gen	x-nif-NSN
6610-00-514-5651	Altimeter Indicator, Pressure	AN5760L2A	671BU010	Gen	x-nif-NSN
6610-00-232-9470	Altimeter Indicator, Pressure	AN5760L4B	671CKL018	Gen	NAVICP
6610-00-232-9479	Altimeter Indicator, Pressure	AN5760L4B	671BU010	Gen	NAVICP
6610-00-514-4175	Altimeter Indicator, Pressure	AN5760L4B	671BK03	Gen	Pending
6610-00-251-0366	Altimeter Indicator, Pressure	AN5760T2A	671CPU19-015	Gen	x-nif-NSN
6605-01-119-0832	Horizontal Situation Indicator (HSI)	AQU13/A/A	126460		
6605-00-034-2500	Horizontal Situation Indicator (HSI)	AQU-2/A	MIL-I-26889	C141/T38/T39	USAF-Tink
6605-00-797-0134	Horizontal Situation Indicator (HSI)	AQU-2A	522-1785-003	C130/T38/T39	USAF-Tink
6605-00-992-3096	Horizontal Situation Indicator (HSI)	AQU-4/A	MIL-I-27848	C141/F111	USAF-Tink
6605-01-221-5384	Horizontal Situation Indicator (HSI)	AQU-6A/A	MIL-I-83034	A7/A10	USAF-Tink
6610-00-854-9166	Attitude Indicator	ARU-14A	MM-4		
6610-00-821-2635	Attitude Direction Indicator (ADI)	ARU-2B/A		Gen	USAF-Tink
6610-00-686-1554	Altimeter Indicator, Counter Pointer Pressure	B003124101	MC2	T2	x-nif-PN
6610-00-736-4376	Altimeter Indicator, Counter Pointer Pressure	B29534-04-001	B29534-10-004	A4/T2	NAVICP
6620-00-761-9290	Tachometer Indicator	B31521-10-007	107E2982-1	P3	NAVICP
6620-00-895-9774	Tachometer, Electric Indicator	B31521-10-008		Н3	NAVICP
6620-01-018-7440	Tachometer Indicator	B31521-10-015	107E2982-8	P3	NAVICP
6680-00-944-5784	Liquid Quantity Indicator	B353-20		A4	NAVICP
6680-00-966-6423	Liquid Quantity Indicator	B353-32	HE432-9002-001	T2	NAVICP

Phone: (904) 248-4308 Fax: (904) 248-4301

6680-00-623-6016	Liquid Quantity Repeater Indicator, Fuel	B353-6	353-999-6	T2	NAVICP
6610-00-168-0797	Altimeter Indicator, Encoder	B4154210003		Gen	NAVICP
6610-01-091-3701	Altimeter Indicator, Pressure	B4420210002	B44202-10-002	Gen	NAVICP
6610-01-406-4983	Altimeter Indicator, Pressure	B44202-10-042	lite mod	Gen	
6610-00-134-5625	Altimeter Indicator, Encoder	B45152-10-002	AAU-32/A	C12/T34/44	NAVICP
6610-01-134-5625	Altimeter Indicator, Encoder	B451521002		Gen	NAVICP
6680-00-950-9619	Amplifier, Electronic Control (ECA)	B478-32		A4	NAVICP
6620-00-928-0216	Torquemeter Indicator	B709-4	620865-103	Gen	NAVICP
6620-00-151-5363	Torque Meter Indicator	B-709-7		P3	NAVICP
6620-00-151-5363	Torque Meter Indicator	B-709-7A	MS 90323-6	P3	NAVICP
6620-00-148-7313	Torque Meter Indicator	В-709-7Ј	620865-107	P3	NAVICP
6615-00-717-6094	Common & Yaw Axis Amplifier	BG102D2			
6620-00-738-5996	Temperature Indicator	BH183R16	622273-103	S3	NAVICP
6610-00-937-0527	Altimeter Indicator, Counter Pointer Pressure	C003124101	MC2	A4/T2	NAVICP
1680-01-174-1962	SASP Control Panel	C-11104/A	969063-101	P3	NAVICP
6610-00-963-5783	Altimeter Indicator, Pressure	C28934-101007	671BU10	Gen	
5821-01-021-3503	Control Panel	C-9815/ARC-159(V)	622-2287-001	Gen	
5821-01-018-4238	Control Panel	C-9816/ARC-159(V)	622-2287-002	Gen	
5821-01-025-5020	Control Panel	C-9817/ARC-159(V)	622-2287-003	Gen	
5821-01-022-9499	Control Panel	C-9818/ARC-159(V)	622-2287-004	Gen	
6615-00-787-3770	Wheel Control (Pilot)	CG79C1			
6615-00-787-3771	Wheel Control (CoPilot)	CG79D1			
6615-00-717-6157	Control Panel	CG80A2			
5826-00-887-1942	Converter, Navigation Set ARN-87	CV-2059/ARN-87(V)	2086412-1		
6610-00-530-1363	Rate of Climb Indicator (ROC, VSI, VVI)	D07163-04-052			
6620-00-450-3952	Tachometer Indicator	D31527-10-008	107E2982-7	CH46/P3	NAVICP
6620-01-029-4777	Tachometer Indicator	D31527-10-015	107E2982-9	CH46/P3	NAVICP
6615-00-676-2675	Compass Interconnection Box	DR45A1			
6610-00-169-1594	Attitude Indicator	DSA335		A4	NAVICP
6610-00-180-5544	Attitude Indicator	DSA335-1	ID-1329A		
6610-00-933-8790	Attitude Indicator	DSA335-1	ID-1329A		
5826-00-081-8325	Bearing Distance Heading Indicator (BDHI)	DSB357	ID-663	A4	NAVICP
6610-00-134-1322	Attitude Indicator	E25-8034-1	ID-1329A		
6610-00-134-1323	Attitude Indicator	E25-8034-2	ID-1329A	A4	NAVICP
4920-00-867-1424	Temperature Indicator, Turbine Inlet (TIT)	H153B		P3	S9
4920-01-166-5020	Temperature Indicator, Turbine Inlet (TIT)	H153C		P3	S9
6620-00-908-7497	Flow Indicator, Fuel	HE432-5002-0001		T2	NAVICP
5821-00-140-1785	Frequency Indicator	ID-1972	622-1624-001	Gen	
5826-00-505-3091	Course Deviation Indicator	ID-249/ARN	11200		
5826-00-505-3141	Course Indicator	ID-351/ARN	140313	НЗ	

Phone: (904) 248-4308 Fax: (904) 248-4301

5826-00-882-1203	Bearing Distance Heading Indicator (BDHI)	ID-663/U	37604-1E5A1	A4/H3/P3	NAVICP
5826-00-953-9298	Bearing Distance Heading Indicator (BDHI)	ID-663/U	QB400434	A4/H3/P3	NAVICP
5826-00-788-5273	Bearing Distance Heading Indicator (BDHI)	ID-663BV	37612-1H5A1	A4/P3	NAVICP
5826-01-147-3098	Bearing Distance Heading Indicator (BDHI)	ID-663C/U	276200	A4/H3/P3	NAVICP
5826-01-188-4128	Bearing Distance Heading Indicator (BDHI)	ID-663D/U	276200-001		
6610-00-601-2313	Attitude Indicator	ID-811/AJB-3A	471764-1		
5831-00-675-8786	Intercommunication Junction Box	J-1013/AIC14			
6680-00-684-5927	Liquid Quantity Indicator, Fuel	JG130A63			
6685-00-319-1685	Temperature Indicator, Electrical	JG165A2	626175-1	P3	
6680-00-580-1248	Liquid Quantity Indicator	JG402A4	695797-5	C130	
6680-01-056-1779	Liquid Quantity Indicator	JG402A52		C130	
6680-01-060-5228	Liquid Quantity Indicator	JG402A-53	695797-25	C130	
6680-00-585-5859	Liquid Quantity Indicator	JG412A2		C130	
6680-00-585-5444	Liquid Quantity Indicator	JG412A3	675797-11	C130	
6680-01-137-3784	Fuel Quantity Indicator	JG4C1		Gen	USAF
6615-00-796-7343	Actuator, Servo	MG70A13			
6610-01-158-6540	Accelerometer, Counting Indicator	MIL-A-22145	MS25448	A4	x-nif-NSN
6620-00-165-5777	Tachometer Indicator, Triple	MIL-I-23832	2274655	Н3	x-nif-PN
6610-00-954-6156	Attitude Indicator	MIL-I-25592	MM3A	A4	x-nif-PN
6610-00-078-9002	Attitude Direction Indicator (ADI)	MIL-I-27710	ARU-13/A	Gen	USAF-Tink
6610-00-087-2434	Attitude Direction Indicator (ADI)	MIL-I-27710	ARU-13/A	Gen	USAF-Tink
6685-00-530-3614	Temperatue Indicator, Thermocouple	MJ1		Н3	S9
6130-00-913-4114	Power Supply	MS 18103-1	28VS50Y	A4	NAVICP
6610-00-181-1750	Accelerometer, Counting Transducer	MS 25447-4		A4	NAVICP
6610-00-620-3802	Turn and Slip Indicator	MS 28041-2A	M3500-9	Gen	NAVICP
6610-00-531-2345	Altimeter Indicator, Counter Pointer Pressure	MS 28074-2		A4/T2	NAVICP
6610-00-514-5651	Altimeter Indicator, Pressure	MS280441	8000	Gen	x-nif-NSN
5826-00-887-1942	Converter, Navigation Set ARN-87	NVA-22A	101-000-217		
6615-00-659-5201	Altitude Control	PG10D1			
6615-00-794-7239	Air Speed Compensator	PG7007B24			
	Marker Beacon Receiver	R-666C/ARN-32			
6610-00-012-4624	Turn and Slip Indicator	RC30V			
6610-01-125-0726	Rate of Climb Indicator (ROC, VSI, VVI)	RC30V10			
6610-00-530-0028	Rate of Climb Indicator (ROC, VSI, VVI)	RC-60			
6610-00-435-8932	Rate of Climb Indicator (ROC, VSI, VVI)	RC-60-V1L	41304-2	A4/T2	NAVICP
6615-00-628-6363	Link Force Assembly	RG79A1		Gen/Grum	
6615-00-717-5267	Force Link Actuator	RG79A2			
5826-01-370-9328	Compass Indicator, Radio Magnetic (RMI)	RMI-30	622-4938-007	C12/U21	NAVTRA
5825-01-328-0196	Compass Indicator, Radio Magnetic (RMI)	RMI-36	622-2506-003	C12/T34/44	NAVTRA
6610-00-864-9759	Rate of Climb Indicator (ROC, VSI, VVI)	SLZ9066			

Phone: (904) 248-4308 Fax: (904) 248-4301

tcrane@n-s-i.us

Repair Capability List by NSN

6620-00-557-0362	Pressure Indicator, Pneumatic	SR-3A	18-1104	Gen	S9
6620-00-557-0350	Pressure Indicator, Pneumatic	SR-4A	18-1102	Gen	S9
6620-00-557-0363	Pressure Indicator, Pneumatic	SR-4B/D	18-1103	Gen	S9
6685-00-557-0215	Pressure Indicator, Pneumatic	SR-7A	18-1105	Gen	<b>S</b> 9
6620-00-557-0816	Pressure Indicator, Pneumatic	SR-8B/P	18-1112	Gen	<b>S</b> 9
6620-00-716-0001	Pressure Indicator, Oil	SR94F			
6685-00-887-9303	Altimeter Indicator, Pressure	SRD9B	626150-1	P3	NAVICP
6610-00-719-5228	Position Indicator	SRL92B		T2	NAVICP
6610-00-805-8011	Accelerometer, Counting Indicator	TRU-3/A	MIL-T-27330		
6610-00-845-4674	Accelerometer, Counting Indicator	TRU-3/A	18-1151		
6610-01-264-2663	Turn and Bank Standard AIRD	TS300-1A			
00-061-7882	Attitude Indicator	137521-01-02			
00-131-8817	Attitude Indicator	109090			
01-390-6925	Attitude Indicator	109090-3			
00-148-7180	Attitude Indicator	156578-01-01			
01-390-6925	Attitude Indicator	MIL-I-27710			
XXXX	Attitude Indicator	12750			
XXXX	Attitude Indicator	119890			
00-764-6627	Attitude Indicator	102630			
XXXX	Attitude Indicator	104384022-3			
00-167-9699	Attitude Indicator	144700-01-01			
XXXX	Attitude Indicator	148100-01-01			
6220-01-115-9237	Power Supply, Strobe Light	70553-05002-107	60-2977-3	H60	NAVICP
6220-01-211-6790	Power Supply, Strobe Light	70553-05002-110	60-2977-5	H60	NAVICP
XXXX	Tail Strobe	30-1125-1			
XXXX	Strobe Assembly	30-1331-3		T34/44	NAVTRA
00-545-5093	Strobe Assembly	30-1467-1		T34/44	NAVTRA
XXXX	Strobe Assembly	30-1467-5		T34/44	NAVTRA
6220-01-004-1643	Anti-Collision Oscillating Light (Navigation Light Assembly)	41775A-121	41775A-121-7079-24	T2	NAVICP
6620-00-716-3305	Anti-Collision Oscillating Light (Navigation Light Assembly)	41775A-21	41775A-21-7079-24	T2	NAVICP
6130-01-123-2274	Inverter, Power Static	501-1243-01		C130/FA18	
XXXX	Power Supply, Strobe Light	60-1750-1		T34/44	NAVTRA
6130-01-124-9886	Power Supply, Strobe Light	60-1750-3		T34/44	NAVTRA
6130-01-083-1520	Power Supply, Strobe Light	60-2667-1			
5945-00-475-9117	Strobe Light Power Supply	60-2693-1	1680EG035-7	UH-1	USA/USAF
6130-01-069-2087	Power Supply, Strobe Light	60-2694-1	1680EG035-5	UH-1	NAVICP