EXAMPLE ELECTRIC MULTIPLE UNIT

Driver's Manual

Document EMU-100-DM-001 · Revision A

Example manual for the TFLS standard. Not actual operator data.

Contents

1 Introduction **3**

1.1 About this example 3

1.2 Page numbers 3

2 Cab Controls **4**

2.1 Driver's desk 4

2.2 Fault indications 4

3 Traction **5**

3.1 Traction overview 5

4 Brake System **6**

4.1 Brake system overview 6

4.2 Brake Pressure Sensor Faults 7

4.3 Brake tests 8

5 Passenger Doors **9**

5.1 Door Control Unit Faults 9

6 Fault Reporting **10**

6.1 Recording faults 10

1 Introduction

1.1 About this example

This manual accompanies example-train.tfls in the Train Fault Library Standard repository. It shows how a TFLS package bundles a manual with a fault library, and how faults reference pages of it.

1.2 Page numbers

TFLS manual references use the physical page of the PDF, counting the cover as page 1. The page numbers in this example's footer match that numbering.

2 Cab Controls

2.1 Driver's desk

Placeholder content describing the layout of the driver's desk.

2.2 Fault indications

Placeholder content describing how faults are shown on the train management display.

3 Traction

3.1 Traction overview

Placeholder content describing the traction system.

4 Brake System

4.1 Brake system overview

Placeholder content describing the brake system and its pressure sensors.

4 Brake System (continued)

4.2 Brake Pressure Sensor Faults

Fault code EXO-BRK-001. The brake pressure sensor fails to register the correct air pressure in the brake line.

1. Isolate the brake circuit as per safety procedures.
2. Test the sensor with diagnostic equipment.
3. Replace the pressure sensor unit if readings are outside tolerance.
4. Recalibrate the brake system using the appropriate test equipment.

WARNING Example content only. Follow your operator's procedures.

4 Brake System (continued)

4.3 Brake tests

Placeholder content describing static and running brake tests.

5 Passenger Doors

5.1 Door Control Unit Faults

The door control unit fails, so doors may not respond to commands or obstruction detection may not work.

1. Isolate the affected door system.
2. Download error logs from the door control system.
3. Attempt a software reset using the maintenance terminal.
4. Replace the door control unit if the reset is unsuccessful.
5. Upload the correct software version and test functionality.

WARNING Trains must not operate in passenger service with faulty door control units.

6 Fault Reporting

6.1 Recording faults

Placeholder content describing how faults are recorded and reported.