cadence™

Allegro® X User Guide: SKILL Reference

Product Version 23.1
September 2023

© 2023 Cadence Design Systems, Inc. All rights reserved.
Portions © Apache Software Foundation, Sun Microsystems, Free Software Foundation, Inc., Regents of the University of California, Massachusetts Institute of Technology, University of Florida. Used by permission. Printed in the United States of America.

Cadence Design Systems, Inc. (Cadence), 2655 Seely Ave., San Jose, CA 95134, USA.

Allegro Platform Products contain technology licensed from, and copyrighted by: Apache Software Foundation, 1901 Munsey Drive Forest Hill, MD 21050, USA © 2000-2005, Apache Software Foundation. Sun Microsystems, 4150 Network Circle, Santa Clara, CA 95054 USA © 1994-2007, Sun Microsystems, Inc. Free Software Foundation, 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA © 1989, 1991, Free Software Foundation, Inc. Regents of the University of California, Sun Microsystems, Inc., Scriptics Corporation, © 2001, Regents of the University of California. Daniel Stenberg, © 1996 - 2006, Daniel Stenberg. UMFPACK © 2005, Timothy A. Davis, University of Florida, (davis@cise.ulf.edu). Ken Martin, Will Schroeder, Bill Lorensen © 1993-2002, Ken Martin, Will Schroeder, Bill Lorensen. Massachusetts Institute of Technology, 77 Massachusetts Avenue, Cambridge, Massachusetts, USA © 2003, the Board of Trustees of Massachusetts Institute of Technology. All rights reserved.

Trademarks: Trademarks and service marks of Cadence Design Systems, Inc. contained in this document are attributed to Cadence with the appropriate symbol. For queries regarding Cadence's trademarks, contact the corporate legal department at the address shown above or call 800.862.4522.

Open SystemC, Open SystemC Initiative, OSCI, SystemC, and SystemC Initiative are trademarks or registered trademarks of Open SystemC Initiative, Inc. in the United States and other countries and are used with permission.

All other trademarks are the property of their respective holders.

Restricted Permission: This publication is protected by copyright law and international treaties and contains trade secrets and proprietary information owned by Cadence. Unauthorized reproduction or distribution of this publication, or any portion of it, may result in civil and criminal penalties. Except as specified in this permission statement, this publication may not be copied, reproduced, modified, published, uploaded, posted, transmitted, or distributed in any way, without prior written permission from Cadence. Unless otherwise agreed to by Cadence in writing, this statement grants Cadence customers permission to print one (1) hard copy of this publication subject to the following conditions:

1. The publication may be used only in accordance with a written agreement between Cadence and its customer.
2. The publication may not be modified in any way.
3. Any authorized copy of the publication or portion thereof must include all original copyright, trademark, and other proprietary notices and this permission statement.
4. The information contained in this document cannot be used in the development of like products or software, whether for internal or external use, and shall not be used for the benefit of any other party, whether or not for consideration.

Disclaimer: Information in this publication is subject to change without notice and does not represent a commitment on the part of Cadence. Except as may be explicitly set forth in such agreement, Cadence does not make, and expressly disclaims, any representations or warranties as to the completeness, accuracy or usefulness of the information contained in this document. Cadence does not warrant that use of such information will not infringe any third party rights, nor does Cadence assume any liability for damages or costs of any kind that may result from use of such information. Cadence is committed to using respectful language in our code and communications. We are also active in the removal and/or replacement of inappropriate language from existing content. This product documentation may however contain material that is no longer considered appropriate but still reflects long-standing industry terminology. Such content will be addressed at a time when the related software can be updated without end-user impact.

Restricted Rights: Use, duplication, or disclosure by the Government is subject to restrictions as set forth

in FAR52.227-14 and DFAR252.227-7013 et seq. or its successor.

Contents

Before You Start 59

About This Manual 59
Prerequisites 60
Command Syntax Conventions 60
Referencing Objects by Name 61
Finding Information in This Manual 62
Other Sources of Information 68

1 Introduction to Allegro PCB Editor SKILL Functions 71

Overview 71
AXL-SKILL in Allegro PCB Editor 71
AXL-SKILL Database 74

2 The Allegro PCB Editor Database User Model 83

Overview 83
Description of Database Objects 84
Figure Database Types 89
Logical Database Types 112
Property Dictionary Database Types 120
Parameter Database Types 123

3 Parameter Management Functions 133

axlcreate – Obsolete 134
axlDBGetTextBlockCount 135
axlDBGridGet 136
axlDBGridSet 138
axlDBTextBlockCreate 140

©2023 All Rights Reserved.

axlDBTextBlockFindName 142
axlDBTextBlockGetName 143
axlDBTextBlockSetName 144
axlExportXmlDBRecords 145
axlFilmCreate 146
axlImportXmlDBRecords 149
axlMiniStatusReset 151
axlPadSuppressGet 152
axlPadSuppressOkLayer 154
axlPadSuppressSet 155
axlParamFilletDoc 158
axlParamShapeDoc 162
axlGetParam 170
axlParamDesignDoc 175
axlSetParam 177
axlIsParamType 179
axltdfIsEnabled 180
axltdfLoad 181
axltdfSave 182
Color Access 183
axlColorDoc 183
axlColorGet 186
axlColorShadowGet 188
axlColorShadowSet 190
axlColorLoad 192
axlColorOnGet – Obsolete 194
axlColorOnSet – Obsolete 195
axlColorPriorityGet – Obsolete 196
axlColorPrioritySet – Obsolete 197
axlColorSave 198
axlColorSet 199
axlCVFColorChooserDlg 202
axlClearObjectCustomColor 203
axlCustomColorObject 205
axlLayerPriorityClearAll 207
axlLayerPriorityGet 208

©2023 All Rights Reserved.

axlLayerPriorityRestoreAll . . . 210
axlLayerPrioritySaveAll . . . 211
axlLayerPrioritySet . . . 212
axlIsCustomColored . . . 214
Database Layer Management . . . 215
axlClasses . . . 215
axlCompareLayers . . . 216
axlDBGetLayerType . . . 218
axlGetExternalLayers . . . 219
axlGetXSection – Obsolete . . . 220
axlIsEtchLayer . . . 222
axlIsLayer . . . 223
axlIsVisibleLayer . . . 224
axlLayerCreateCrossSection – Obsolete . . . 225
axlLayerCreateNonConductor . . . 226
axlLayerDelete . . . 227
axlLayerExternal . . . 229
axlLayerGet . . . 230
axlLayerRenameNonConductor . . . 232
axlLayerViaLabel . . . 233
axlMaterialGet . . . 234
axlVisibleDesign . . . 237
axlVisibleGet . . . 239
axlVisibleLayer . . . 241
axlVisibleSet . . . 242
axlConductorBottomLayer . . . 243
axlConductorTopLayer . . . 244
axlDBCreateFilmRec – Obsolete . . . 245
axlSetPlaneType . . . 246
axlSubclasses . . . 247
axlSubclassRoute . . . 249
axlXSectionAssign . . . 251
axlXSectionCopy . . . 252
axlXSectionCreate . . . 253
axlXSectionCreateStackup . . . 258
axlXSectionDelete . . . 259

©2023 All Rights Reserved.

axlXSectionDeleteStackup 260
axlXSectionGet 261
axlXSectionLayerFunctions 268
axlXSectionLayerTypes 269
axlXSectionModify 270
axlXSectionRemove 271
axlXSectionRename 273
axlXSectionSet 274

4
Selection and Find Functions 277

Overview 277
Select Set Highlighting 278
Select Modes 278
Finding Objects by Name 278
Point Selection 279
Area Selection 279
Miscellaneous Select Functions 280
axlSelect–The General Select Function 280
Select Set Management 280
Find Filter Control 280
Selection and Find Functions 282
axlSingleSelectPoint 282
axlAddSelectPoint 285
axlSubSelectPoint 287
axlSingleSelectBox 289
axlAddSelectBox 291
axlSubSelectBox 292
axlAddSelectAll 293
axlSubSelectAll 294
axlSingleSelectName 296
axlAddSelectName 298
axlSubSelectName 300
axlSingleSelectObject 302
axlAddSelectObject 303

©2023 All Rights Reserved.

axlSubSelectObject 304
axlSelect 305
axlGetSelSet 308
axlGetSelSetCount 310
axlClearSelSet 311
axlGetFindFilter 312
axlSetFindFilter 314
axlAutoOpenFindFilter 324
axlOpenFindFilter 325
axlCloseFindFilter 326
axlDBFindByName 327
axlFindFilterIsOpen 329
axlSelectByName 330
axlSelectByProperty 335
axlSnapDisableAtRMB 337
axlSnapEnableAtRMB 338
axlSnapToObject 339
axlLastPickIsSnapped 341

5
Interactive Edit Functions 343

Overview 343
AXL/SKILL Interactive Edit Functions 344
axlAllShapesMerge 344
axlBondFingerDelete 345
axlBondWireDelete 346
axlChangeLine2Cline 347
axlChangeLineFont 348
axlChangeWidth 349
axlCopyProperties 351
axlCopyObject 353
axlDBAltOrigin 355
axlDBChangeText 357
axlDBConnectItem 360
axlDeleteObject 362

©2023 All Rights Reserved.

axlDeleteByRectangle 365
axlDeleteTaper 367
axlDBDeleteProp 368
axlDBDeletePropAll 371
axlDBDeletePropDictEntry 372
axlDBOpenShape 373
axlDeleteFillet 375
axlFillet 376
axlFilletConvert 377
axlFixFillet 378
axlGetLastEnterPoint 379
axlLastPick 380
axlWindowBoxGet 381
axlWindowBoxSet 382
axlReplacePadstack 383
axlPurgePadstacks 384
axlPurge3DModelMapDataInDesign 386
axlShapeAutoVoid 387
axlShapeChangeDynamicType 389
axlShapeDeleteVoids 391
axlShapeDynamicUpdate 393
axlShapeRaisePriority 394
axlShapeMerge 396
axlShapeUpdateDegas 398
axlShoveItems 399
axlShoveSetParams 400
axlSmoothDesign 403
axlSmoothItems 404
axlSmoothSetParams 405
axlStepDelete 408
axlStepSet 409
axlSymbolAttach 411
axlSymbolDetach 413
axlAddTaper 415
axlTextOrientationCopy 416
axlTransformObject 417

©2023 All Rights Reserved.

axlUnfixFillet 421
axlZoneDelete 422
axlZoneSet 423
Padstack Access Functions 425
axlDBCreatePadStack 425
axlPadFigureTypes 433
axlPadstackEdit 434
axlPadstackSetType 444
axlPadstackUsageTypes 446
axlPadUserMaskLayers 447

6
Database Read Functions 449

AXL-SKILL Database Read Functions 449
axlAltSymbolList 450
axlAltSymbolOK 451
axlAltSymbolReplace 452
axlBackdrillGet 454
axlDBGetDesign 457
axlDBGetDrillPlating 459
axlIsDBIDType 460
axlDBGetAttachedText 462
axlDBGetPad 464
axlDBGetPropDict 467
axlDBGetPropDictEntry 468
axlDBGetProperties 470
axlDBGetDesignUnits 472
axlDBRefreshId 473
axlDBGetLonelyBranches 475
axlDBGetConnect 476
axlDBIsBondpad 478
axlDBIsBondwire 479
axlDBIsFixed 480
axlDBIsPackagePin 482
axlDBViaStack 483

©2023 All Rights Reserved.

axlGetModuleInstanceDefinition 484
axlGetModuleInstanceLocation 485
axlGetModuleInstanceLogicMethod 486
axlGetModuleInstanceNetExceptions 487
axlIsDummyNet 488
axlIsLayerNegative 489
axlIsPinUnused 490
axlIsitFill 491
axlOK2Void 492
axlDBDynamicShapes 493
axlDBGetShapes 494
axlDBTextBlockCompact 495
axlShapeArea 496
axlShapeExistDegasOutOfDate 497
axlShapeGetDegasOutOfDateCount 498
axlShapeIsDegasOutOfDate 499
axlShapeIsDegasOutOfDateCheckDisabled 500
axlStepGet 501
axlStepMappedInstance 504
axlZoneAccess 505

7
Allegro PCB Editor Interface Functions 507

Overview 507
AXL-SKILL Interface Function Examples 507
Allegro PCB Editor Interface Functions 514
axlClearDynamics 514
axlAddSimpleRbandDynamics 515
axlAddSimpleMoveDynamics 518
axlDesignFlip 520
axlEnterPoint 521
axlEnterString 522
axlEnterAngle 523
axlCancelEnterFun 524
axlFinishEnterFun 525

©2023 All Rights Reserved.

axlGetDynamicsSegs 526
axlGetLineLock 527
axlEnterBox 529
axlEnterPath 531
axlHighlightObject 532
axlDehighlightObject 534
axlMiniStatusLoad 535
axlMiniStatusClose 538
axlDrawObject 539
axlDynamicsObject 540
axlEraseObject 541
axlControlRaise 542
axlEnterEvent 543
axlEventSetStartPopup 547
axlGetTrapBox 549
axlRatsnestBlank 550
axlRatsnestDisplay 551
axlSetDynamicsMirror 552
axlSetDynamicsRotation 553
axlShowObjectToFile 554
axlUICmdPopupSet 555
axlWindowFit 556
axlZoomBbox 557
axlZoomCenter 558
axlZoomControl 559
axlZoomFit 561
axlZoomInOut 562
axlZoomPoints 563
axlZoomToDbid 564
axlZoomWorld 566
axlMakeDynamicsPath 567

8
Allegro PCB Editor Command Shell Functions 571
Command Shell Functions 571

©2023 All Rights Reserved.

axlGetAlias 572
axlGetFunckey 573
axlGetVariable 574
axlGetVariableList 576
axlJournal 578
axlProtectAlias 580
axlIsProtectAlias 581
axlReadOnlyVariable 582
axlSetAlias 584
axlSetAlias 586
axlSetFunckey 588
axlSetVariable 590
axlSetVariableFile 592
axlShell 593
axlShellPost 594
axlUnsetVariable 596
axlUnsetVariableFile 597

9
IC Packaging Commands 599

axlBGATextIn 600
axlChangeLayer 603
axlCNSAssemblyModeGet 605
axlCNSAssemblyModeSet 607
axlCNSGetAssembly 609
axlCNSSetAssembly 612
axlCreateDeviceFileTemplate 615
axlCompAddPin 616
axlCompDeletePin 619
axlCompMovePin 620
axlComponentChangeClass 622
axlCompSetPinAttributes 624
axlDBGetDesignStats 626
axlDBIsBondingWireLayer – Obsolete 628
axlDBIsDiePad 629

©2023 All Rights Reserved.

axlDBIsPlatingbarPin 630
axlDieTextIn 631
axlGetBondWireToBondWireDist 634
axlGetDieType 635
axlGetMetalUsageForLayer 636
axlGetWireProfileDefinition 638
axlAddAutoAssignNetAlgorithm 639
axlGetWireProfileDirection 640
axlGetAllVisibleProfiles 641
axlSetAllProfilesVisible 642
axlGetBondWireLength 643
axlLoadViaStructure 644
axlNetlistTextIn 645
axlPushConnectivity 647
axlSetBondWireProfile 649
axlImportWireProfileDefinitions 650
axlSetBondWireProfile 651
axlSetDieStackData 652
axlDBIsDieStackLayer 653
axlGetDieData 654
axlGetDieStackData 657
axlGetDieStackMemberSet 659
axlGetDieStackNames 661
axlGetIposerData 662
axlGetSpacerData 664
axlGetWireProfileColor 666
axlGetWireProfileVisible 667
axlPackageDesignCheckAddCategory 668
axlPackageDesignCheckAddCheck 670
axlPackageDesignCheckDrcError 673
axlPackageDesignCheckLogError 674
axlSetDieData 676
axlSetDieType 678
axlSetIposerData 679
axlSetSpacerData 680
axlSetWireProfileColor 681

©2023 All Rights Reserved.

axlSetWireProfileVisible 682
axlShapeEraseDegassingHole 683
axlCDLNetlistSetValue 684

10
User Interface Functions 687

Window Placement 687
Using Menu Files 688
Dynamically Loading Menus 690
Understanding the Menu File Format 691
AXL-SKILL User Interface Functions 697
axlCancelOff 697
axlCancelOn 698
axlCancelTest 700
axlCancelClearFormClosable 701
axlCancelSetFormClosable 702
axlClipboardGetText 704
axlClipboardSetText 705
axlCursorGet 706
axlCursorWarp 707
axlMeterCreate 708
axlMeterDestroy 710
axlMeterIsCancelled 711
axlMeterUpdate 712
axlUIAppMode 713
axlUIMenuLoad 715
axlUIMenuDump 716
axlUIColorDialog 717
axlUIConfirm 718
axlUIConfirmEx 719
axlUIControl 721
axlUIMenuChange 723
axlUIMenuDebug 725
axlUIMenuDelete 726
axlUIMenuFind 727

©2023 All Rights Reserved.

axlUIMenuInsert 730
axlUIMenuRegister 733
axlUIPopupDump 735
axlUIPrompt 736
axlUIWCloseAll 738
axlUIWIconify 739
axlUIWIsIconic 740
axlUIWIsWindow 741
axlUIWMove 742
axlUIWRedraw 743
axlUIWSize 744
axlIsViewFileType 745
axlUIViewFileCreate 746
axlUIViewFileReuse 748
axlUIYesNo 750
axlUIWExpose 752
axlUIWClose 753
axlUIWHelpRegister 755
axlUIWPrint 757
axlUIWRedraw 758
axlUIWBlock 759
axlUIEditFile 760
axlUIMultipleChoice 762
axlUIViewFileScrollTo 763
axlUIWBeep 764
axlUIWDisableQuit 765
axlUIWExposeByName 766
axlUIWPerm 767
axlUIWSetHelpTag 769
axlUIWSetParent 770
axlUIWShow 771
axlUIWTimerAdd 772
axlUIWTimerRemove 775
axlUIWUpdate 776
axlUIYesNoCancel 777
axlUIDataBrowse 778

©2023 All Rights Reserved.

11
Form Interface Functions . . . 781

Overview . . . 781
- Programming . . . 781
- Field / Control . . . 782

Using Forms Specification Language . . . 791
Moving and Sizing Form Controls During Form Resizing . . . 800
Using Grids . . . 805
AXL-SKILL Form Interface Functions . . . 822
- axlFormBNFDoc . . . 822
- axlFormCallback . . . 838
- axlFormCreate . . . 843
- axlFormClearMouseActive . . . 846
- axlFormClose . . . 847
- axlFormDisplay . . . 848
- axlFormBuildPopup . . . 849
- axlFormGetField . . . 853
- axlFormGetFieldRange . . . 855
- axlFormGetOptionValue . . . 856
- axlFormGridGetSize . . . 857
- axlFormListGetCount . . . 858
- axlFormGridSelected . . . 859
- axlFormGridSelectedCnt . . . 860
- axlFormGridSetSelectRows . . . 861
- axlFormListDeleteAll . . . 863
- axlFormListSelect . . . 866
- axlFormSetEventAction . . . 867
- axlFormSetField . . . 869
- axlFormSetFieldHelpTip . . . 872
- axlFormSetInfo . . . 873
- axlFormSetMouseActive . . . 874
- axlFormTest . . . 875
- axlFormRestoreField . . . 876
- axlFormTitle . . . 878
- axlIsFormType . . . 879

©2023 All Rights Reserved.

axlFormSetFieldVisible 880
axlFormIsFieldVisible 881
Callback Procedure: formCallback 882
axlFormAutoResize 887
axlFormColorize 888
axlFormGetActiveField 891
axlFormGridBatch 892
axlFormGridCancelPopup 893
axlFormGridDeleteRows 894
axlFormGridEvents 895
axlFormGridGetCell 898
axlFormGridInsertCol 900
axlIsGridCellType 903
axlFormGridInsertRows 904
axlFormGridNewCell 905
axlFormGridReset 906
axlFormGridSetBatch 907
axlFormGridUpdate 910
axlFormInvalidateField 911
axlFormIsFieldEditable 912
axlFormListAddItem 913
axlFormListDeleteItem 915
axlFormListGetItem 917
axlFormListGetSelCount 918
axlFormListGetSelItems 919
axlFormListOptions 920
axlFormListSelAll 922
axlFormMsg 923
axlFormGetFieldRange 925
axlFormGetFieldType 926
axlFormDefaultButton 927
axlFormGridOptions 929
axlFormSetActiveField 931
axlFormSetDecimal 932
axlFormSetFieldEditable 933
axlFormSetFieldLimits 934

©2023 All Rights Reserved.

axlFormTreeViewAddItem 935
axlFormTreeViewChangeImages 938
axlFormTreeViewChangeLabel 940
axlFormTreeViewGetImages 941
axlFormTreeViewGetLabel 942
axlFormTreeViewGetParents 943
axlFormTreeViewGetSelectState 944
axlFormTreeViewLoadBitmaps 945
axlFormTreeViewSet 947
axlFormTreeViewSetSelectState 950

12
Simple Graphics Drawing Functions 953

Functions 957
axlGRPDrwBitmap 957
axlGRPDrwCircle 958
axlGRPDrwInit 959
axlGRPDrwLine 960
axlGRPDrwMapWindow 961
axlGRPDrwPoly 962
axlGRPDrwRectangle 963
axlGRPDrwText 964
axlGRPDrwUpdate 965

13
Message Handler Functions 967

Overview 967
Message Handler Functions 970
axlMsgPut 970
axlMsgContextPrint 971
axlMsgContextGetString 972
axlMsgContextGet 973
axlMsgContextTest 974
axlMsgContextInBuf 975
axlMsgContextRemove 976

©2023 All Rights Reserved.

axlMsgContextStart 977
axlMsgContextFinish 978
axlMsgContextClear 979
axlMsgCancelPrint 980
axlMsgCancelSeen 981
axlMsgClear 982
axlMsgSet 983
axlMsgTest 984

14
Design Control Functions 985

AXL-SKILL Design Control Functions 985
axlAppendDBDiary 986
axlCurrentDesign 987
axlDesignType 988
axlCompileSymbol 990
axlSetSymbolType 991
axlDBControl 992
axlDBGetExtents 999
axlDBIgnoreFixed 1000
axlDBIsReadOnly 1002
axlDBSectorSize - Obsolete 1003
axlGetDrawingName 1004
axlIgnoreFixed 1005
axlInTrigger 1006
axlInTriggerFunc 1007
axlIsSymbolEditor 1008
axlKillDesign 1009
axlOpenDesign 1010
axlOpenDesignForBatch 1012
axlRenameDesign 1014
axlSaveDesign 1015
axlSaveEnable 1017
axlDBChangeDesignExtents 1018
axlDBChangeDesignOrigin 1019

©2023 All Rights Reserved.

axlDBChangeDesignUnits 1020
axlDBCheck 1023
axlDBCopyPadstack 1025
axlDBDelLock 1027
axlDBGetLock 1028
axlDBMemoryReclaim 1029
axlDBSetLock 1031
axlDBTuneSectorSize 1034
axlTechnologyType 1035
axlTriggerClear 1036
axlTriggerPrint 1037
axlTriggerSet 1038
axlGetActiveLayer – Obsolete 1043
axlGetActiveTextBlock – Obsolete 1044
axlSetActiveLayer – Obsolete 1045
axlWFMAnyExported 1046
axlDBDisplayControl 1047
AXL-SKILL Pulse Functions 1054
axlPulseCopyAs 1056
axlPulseDownloadAttachment 1057
axlPulseEnabled 1058
axlPulseGetAttachmentNames 1059
axlPulseGetDesignStatus 1060
axlPulseGetRevision 1061
axlPulseGetStatus 1062
axlPulseLock 1063
axlPulseOpenDesign 1064
axlPulseShowDesigns 1065
axlPulseShowShare 1066
axlPulseUnlock 1067
axlPulseUploadAttachment 1068
axlPulseVersionControl 1069

©2023 All Rights Reserved.

15
Database Create Functions 1071

Overview 1071
Path Functions 1072
- axlPathStart 1074
- axlPathArcRadius 1075
- axlPathArcAngle 1075
- axlPathArcCenter 1075
- axlPathLine 1079
- axlPathGetWidth 1080
- axlPathSegGetWidth 1081
- axlPathGetPathSegs 1082
- axlPathGetLastPathSeg 1083
- axlPathSegGetEndPoint 1084
- axlPathSegGetArcCenter 1085
- axlPathSegGetArcClockwise 1086
- axlPathStartCircle 1087
- axlPathOffset 1088
- axlDB2Path 1089
- axlDBCreatePath 1090
- axlDBCreateLine 1093
- axlDBCreateCircle 1095

Create Shape Interface 1096
- axlDBComposeShapesFromLines 1098
- axlDBCreateBoundingShape 1101
- axlDBCreateOpenShape 1104
- axlDBCreateCloseShape 1108
- axlDBActiveShape 1109
- axlDBCreateVoidCircle 1110
- axlDBCreateVoid 1111
- axlDBCreateShape 1113
- axlDBCreateRectangle 1115
- axlDBCreateVectorizedEllipse 1117

Nonpath DBCreate Functions 1120
- axlCreateBondFinger 1120

©2023 All Rights Reserved.

axlCreateBondWire 1122
axlDBCreateExternalDRC 1124
axlDBCreateFillet 1128
axlDBCreatePin 1130
axlDBCreateSymbol 1134
axlDBCreateSymbolSkeleton 1138
axlDBCreateText 1143
axlDBCreateVia 1146
axlDBCreateSymbolAutosilk 1149
axlDBCreateViaStructure 1150
axlCreateWirebondGuide 1152
axlZoneCreate 1153
Property Functions 1155
axlDBCreatePropDictEntry 1155
axlDBAddProp 1159
Load and Save Functions 1164
axlLoadPadstack 1164
axlLoadSymbol 1165
axlPadstackToDisk 1167
axlRefreshSymbol 1168

16
Database Group Functions 1171

Overview 1171
axlDBAddGroupObjects 1172
axlDBCreateGroup 1173
axlDBDisbandGroup 1177
axlDBGetGroupFromItem 1178
axlDBGroupRename 1180
axlDBRemoveGroupObjects 1181
axlNetClassAdd 1182
axlNetClassCreate 1184
axlNetClassDelete 1186
axlNetClassGet 1187
axlNetClassRemove 1189

©2023 All Rights Reserved.

axlRegionAdd 1190
axlRegionCreate 1192
axlRegionDelete 1193
axlRegionRemove 1194

17
Database Attachment Functions 1197

Overview 1197
axlCreateAttachment 1198
axlDeleteAttachment 1201
axlGetAllAttachmentNames 1202
axlGetAttachment 1203
axlIsAttachment 1205
axlSetAttachment 1206

18
Database Transaction Functions 1209

axlDBCloak 1209
axlDBTransactionCommit 1213
axlDBTransactionMark 1214
axlDBTransactionOops 1215
axlDBTransactionRollback 1216
axlDBTransactionStart 1217

19
Constraint Management Functions 1221

Overview 1221
axlCnsAddVia 1222
axlCnsAssignPurge – Obsolete 1223
axlCnsClassTableChange 1224
axlCnsClassTableCreate 1226
axlCnsClassTableDelete 1228
axlCnsClassTableFind 1229
axlCnsClassTableSeek 1231

©2023 All Rights Reserved.

axlCNSCreate 1233
axlCNSCsetLock 1235
axlCNSDelete 1237
axlCnsDeleteClassClassObjects 1238
axlCnsDeleteRegionClassClassObjects 1239
axlCnsDeleteRegionClassObjects 1240
axlCnsDeleteVia 1241
axlCNSDesignModeGet 1243
axlCNSDesignModeSet 1246
axlCNSDesignValueCheck 1249
axlCNSDesignValueGet 1250
axlCNSDesignValueSet 1253
axlCNSDFAExport 1255
axlCNSDFAImport 1256
axlCNSDFAMode 1257
axlCNSEcsetCreate 1259
axlCNSEcsetDelete 1261
axlCNSEcsetGet 1262
axlCNSEcsetModeGet 1263
axlCNSEcsetModeSet 1265
axlCNSEcsetValueCheck 1268
axlCNSEcsetValueGet 1269
axlCNSGetDefaultMinLineWidth 1272
axlCNSGetPhysical 1273
axlCNSGetPinDelayEnabled 1276
axlCNSGetPinDelayPVF 1277
axlCNSGetSameNet 1278
axlCNSGetSameNetXtalkEnabled 1281
axlCNSGetSpacing 1282
axlCNSGetViaZEnabled 1285
axlCNSGetViaZPVF 1286
axlCNSPhysicalModeGet 1287
axlCNSIsCsetLocked 1289
axlCNSIsLockedDomain 1290
axlCNSLockDomain 1292
axlCNSOptions 1293

©2023 All Rights Reserved.

axlCNSPhysicalModeSet 1295
axlCNSSameNetModeGet 1297
axlCNSSameNetModeSet 1299
axlCNSSetPhysical 1301
axlCNSSetSpacing 1304
axlCNSSetPinDelayEnabled 1308
axlCNSSetPinDelayPVF 1309
axlCNSSetSameNet 1310
axlCNSSetSameNetXtalkEnabled 1312
axlCNSSetViaZEnabled 1313
axlCNSSetViaZPVF 1314
axlCNSSpacingMax 1315
axlCNSSpacingMin 1316
axlCNSSpacingModeGet 1318
axlCNSSpacingModeSet 1320
axlCnsPurgeAll() 1322
axlCnsPurgeCsets 1323
axlCnsPurgeObjects 1324
axlViaZLength 1325
axlNetEcsetValueGet 1327
axlCNSEcsetValueSet 1329
axlCnsGetViaList 1331
axlGetAllViaList 1333
axlGetMaxSpacingCNS 1334
axlGetSNSTolerance 1336
axlGetSPCTolerance 1337
axlDRCUpdate 1338
axlDRCWaive 1339
axlDRCGetCount 1341
axlDRCItem 1342
axlDRCWaiveGetCount 1344
axlLayerSet 1345
axlCnsList 1346
axlCNSMapClear 1348
axlCNSMapUpdate 1349
axlCnsNetFlattened 1351

©2023 All Rights Reserved.

axlSetSNSTolerance 1353
axlSetSPCTolerance 1354
DFM DRC Modes Functions 1355
axlCNSModeSet 1355
axlCNSModeGet 1358

20
Command Control Functions 1361

AXL-SKILL Command Control Functions 1361
axlCmdGetAppMode 1362
axlCmdIsRegistered 1363
axlCmdRegister 1364
axlCmdUnregister 1370
axlEndSkillMode 1371
axlFlushDisplay 1372
axlOKToProceed 1374
axlSetLineLock 1375
axlSetRotateIncrement 1377
axlUIGetUserData 1378
axlUIPopupDefine 1379
axlUIPopupSet 1381
axlBuildClassPopup 1383
axlBuildSubclassPopup 1384
axlSubclassFormPopup 1386
axlVisibleUpdate 1389

21
Polygon Operation Functions 1391

About Polygon Operations 1391
AXL-SKILL Polygon Operation Attributes 1394
AXL-SKILL Polygon Operation Functions 1396
axlPolyFromDB 1396
axlPolyFromHole 1401
axlPolyMemUse 1402
axlPolyOffset 1404

©2023 All Rights Reserved.

axlPolyOperation 1405
axlPolyExpand 1407
axlIsPolyType 1413
axlPolyFromDrillHole 1414
axlPolyErrorGet 1416
axlPolyRotate 1418
axlPolyTrim 1419
Use Models 1421

22
Allegro PCB Editor File Access Functions 1423

AXL-SKILL File Access Functions 1423
axlDMFileError 1424
axlDMFindFile 1425
axlDMGetFile 1427
axlDMOpenFile 1429
axlDMOpenLog 1432
axlDMClose 1433
axlDMBrowsePath 1434
axlDMDirectoryBrowse 1435
axlDMFileBrowse 1436
axlDMFileParts 1439
axlOSFileCopy 1440
axlOSFileMove 1441
axlOSSlash 1442
axlRecursiveDelete 1443
axlTempDirectory 1445
axlTempFile 1446
axlTempFileRemove 1447

23
Reports and Extract Functions 1449

AXL-SKILL Data Extract Functions 1449
axlExtractToFile 1449
axlExtractMap 1451

©2023 All Rights Reserved.

axlReportGenerate 1453
axlReportList 1455
axlReportRegister 1456

24
Utility Functions 1461

axlCheckString 1462
axlCmdList 1464
axlDebug 1465
axlDetailLoad 1466
axlDetailSave 1468
axlEmail 1469
axlHistory 1470
axlHttp 1472
axlIsDebug 1474
axlIsProductLineActive 1475
axlISProductStarted 1476
axlLicDefaultVersion 1477
axlLicFeatureExists 1478
axlLicIsProductEnabled 1479
axlLogHeader 1480
axlMKS2UU 1481
axlMKSAlias 1483
axlMKSConvert 1484
axlMKSStr2UU 1487
axlMapClassName 1488
axlMemSize 1490
axlOSBackSlash 1491
axlOSControl 1492
axlOSNtp 1494
axlOSExit 1496
axlPPrint 1497
axlPdfView 1498
axlPrintDbid 1499
axlRegexpIs 1501

©2023 All Rights Reserved.

axlRunBatchDBProgram 1502
axlShowObject 1507
axlSleep 1508
axlSort 1509
axlStrcmpAlpNum 1513
axlStringCSVParse 1514
axlStringRemoveSpaces 1516
axlVersion 1517
axlVersionIdGet 1521
axlVersionIdPrint 1522

25
Math Utility Functions 1525

Overview 1525
axlDegToRad 1525
axlDistance 1526
axlGeo2Str 1527
axlGeoAngleBetweenLines 1529
axlGeoArcCenterAngle 1530
axlGeoArcCenterRadius 1533
axlGeoArcMidpoint 1538
axlGeoCircleCircleInt 1539
axlGeoCircleLineInt 1540
axlGeoCircleLineInt2 1541
axlGeoEqual 1542
axlGeoFindAngle 1544
axlGeoGetBBox 1545
axlGeoIsBoxOverlap 1546
axlGeoLineMidpoint 1547
axlGeoRotatePt 1548
axlGeoPointsEqual 1550
axlGeoPickShorterArc 1551
axlGeoIsShorterArcClockwise 1552
axlGeoUnrotatePt 1553
axlMathSolveQuadratic 1554

©2023 All Rights Reserved.

axlIsBetween 1555
axlIsPointInsideBox 1556
axlIsPointOnLine 1557
axlLineSlope 1558
axlLineXLine – Obsolete 1559
axlMathConstants 1560
axlMathDotProduct 1561
axlMidPointArc 1562
axlMidPointLine 1563
axlMPythag 1564
axlMUniVector 1565
axlMXYAdd 1567
axlMXYMult 1568
axlMXYSub 1569
axlRadToDeg 1570
axl_ol_ol2 1571
bBoxAdd 1573

26
Database Miscellaneous Functions 1575

Overview 1575
axlAirGap 1576
axlBackDrill – Obsolete 1581
axlDBGetLength 1582
axlDBGetManhattan 1583
axlDBGetSymbolBodyExtent 1584
axlDBPinPairLength 1585
axlDeleteByLayer 1586
axlExtentDB 1588
axlExtentLayout – Obsolete 1589
axlExtentSymbol – Obsolete 1590
axlFindPath 1591
axlGeoClosestPointOnArc 1593
axlGeoClosestPointOnCircle 1594
axlGeoPointInShape 1595

©2023 All Rights Reserved.

axlGeoPointShapeInfo 1596
axlGetImpedance 1597
axlGeoMirrorLayer 1598
axlImpdedanceGetLayerBroadsideDPImp 1599
axlImpdedanceGetLayerBroadsideDPWidth 1600
axlImpdedanceGetLayerEdgeDPImp 1601
axlImpdedanceGetLayerEdgeDPSpacing 1602
axlImpdedanceGetLayerEdgeDPWidth 1603
axlImpedance2Width 1604
axlPadOnLayer 1605
axlPinExport 1607
axlPinImport 1608
axlReratNet 1610
axlText2Lines 1611
axlUnfixAll 1613
axlWidth2Impedance 1614
axlIsHighlighted 1615
axlTestPoint 1616
axlChangeNet 1619
axlSegDelayAndZ0 1621
axlSetDefaultDieInformation 1622

27
Microsoft Excel Integration Functions 1623

axlSpreadsheetClose 1623
axlSpreadsheetDefineCell 1625
axlSpreadsheetDoc 1626
axlSpreadsheetGetCell 1628
axlSpreadsheetGetRGBColorString 1630
axlSpreadsheetGetRGBForNamedColor 1631
axlSpreadsheetGetStyles 1632
axlSpreadsheetGetWorksheets 1633
axlSpreadsheetGetWorksheetSize 1634
axlSpreadsheetInit 1635
axlSpreadsheetRead 1637

©2023 All Rights Reserved.

axlSpreadsheetReadDelimited 1639
axlSpreadsheetSetCell 1640
axlSpreadsheetSetCellProp 1642
axlSpreadsheetSetColumnProp 1644
axlSpreadsheetSetDocProp 1646
axlSpreadsheetSetRowProp 1647
axlSpreadsheetSetStyle 1649
axlSpreadsheetSetStyleBorder 1650
axlSpreadsheetSetStyleParent 1652
axlSpreadsheetSetStyleProp 1653
axlSpreadsheetSetWorksheet 1657
axlSpreadsheetWrite 1658

28
Plugin Functions 1661

Overview 1661
SKILL Programming 1661
DLL Programming 1662
Input/Output Data Primitives 1664
Programming Restrictions, Cautions and Hints 1665
Performance Considerations 1666
Cadence Customer Support 1666
Examples 1666
axlDllCall 1668
axlDllCallList 1670
axlDllClose 1671
axlDllDump 1672
axlDllOpen 1673
axlDllSym 1675

29
Skill Language Extensions 1677

axldo 1677
copyDeep 1679
isBoxp 1680

©2023 All Rights Reserved.

lastelem 1681
letStar 1682
listnindex 1683
movedown 1684
moveup 1685
parseFile 1686
parseQuotedString 1688
pprintln 1689
propNames 1690

30
Logic Access Functions 1691

Overview 1691
axlDBAssignNet 1692
axlDBCreateConceptComponent 1695
axlDBCreateComponent 1697
axlDBCreateManyModuleInstances 1699
axlDBCreateModuleDef 1702
axlDBCreateModuleInstance 1703
axlDBCreateNet 1705
axlDBCreateSymDefSkeleton 1706
axlDBDummyNet 1708
axlDbidName 1710
axlDiffPair 1712
axlDiffPairAuto 1714
axlDiffPairDBID 1716
axlMatchGroupAdd 1717
axlMatchGroupCreate 1719
axlMatchGroupDelete 1722
axlMatchGroupProp 1723
axlMatchGroupRemove 1725
axlNetSched 1727
axlPinPair 1728
axlPinPairSeek 1731
axlPinsOfNet 1732

©2023 All Rights Reserved.

axlRemoveNet 1733
axlRenameNet 1734
axlRenameRefdes 1736
axlSchedule 1738
axlScheduleNet 1740
axlWriteDeviceFile 1741
axlWritePackageFile 1743

31
DFM SKILL APIs 1745

Component Lead Functions 1745
axlCreateLeadContact 1745
axlDeleteLeadContact 1748
axlGetSupportedLeadTypes 1749
DFM CSet Operations 1750
axlCreateDfmAssignment 1753
axlDFMIsCsetLocked 1756
axlDFMCsetLock 1757
axlDeleteDfmAssignment 1758
axlGetDFMAssignedCsets 1759
axlGetDFMCsetAssignmentStatus 1763
axlRenameDFFCset 1766
axlCreateDFMCset 1767
axlDeleteDFMCset 1769
axlGetDFMCsets 1770
axlGetDFMCset 1771

©2023 All Rights Reserved.

axlAddAutoAssignNetAlgorithm 639
axlAddSelectAll 293
axlAddSelectBox 291
axlAddSelectName 298
axlAddSelectObject 303
axlAddSelectPoint 285
axlAddSimpleMoveDynamics 518
axlAddSimpleRbandDynamics 515
axlAddTaper 415
axlAirGap 1576
axlAllShapesMerge 344
axlAltSymbolList 450
axlAltSymbolOK 451
axlAltSymbolReplace 452
axlAppendDBDiary 986
axlAutoOpenFindFilter 324
axlBackDrill – Obsolete 1581
axlBackdrillGet 454
axlBGATextIn 600
axlBondFingerDelete 345
axlBondWireDelete 346
axlBuildClassPopup 1383
axlBuildSubclassPopup 1384
axlCancelClearFormClosable 701
axlCancelEnterFun 524
axlCancelOff 697
axlCancelOn 698
axlCancelSetFormClosable 702
axlCancelTest 700
axlCDLNetlistSetValue 684
axlChangeLayer 603
axlChangeLine2Cline 347
axlChangeLineFont 348
axlChangeNet 1619
axlChangeWidth 349
axlCheckString 1462
axlClasses 215
axlClearDynamics 514
axlClearObjectCustomColor 203
axlClearSelSet 311
axlClipboardGetText 704
axlClipboardSetText 705
axlCloseFindFilter 326
axlCmdGetAppMode 1362
axlCmdIsRegistered 1363

axlCmdList 1464
axlCmdRegister 1364
axlCmdUnregister 1370
axlCnsAddVia 1222
axlCNSAssemblyModeGet 605
axlCNSAssemblyModeSet 607
axlCnsAssignPurge – Obsolete 1223
axlCnsClassTableChange 1224
axlCnsClassTableCreate 1226
axlCnsClassTableDelete 1228
axlCnsClassTableFind 1229
axlCnsClassTableSeek 1231
axlCNSCreate 1233
axlCNSCsetLock 1235
axlCNSDelete 1237
axlCnsDeleteClassClassObjects 1238
axlCnsDeleteRegionClassClassObjects 1239
axlCnsDeleteRegionClassObjects 1240
axlCnsDeleteVia 1241
axlCNSDesignModeGet 1243
axlCNSDesignModeSet 1246
axlCNSDesignValueCheck 1249
axlCNSDesignValueGet 1250
axlCNSDesignValueSet 1253
axlCNSDFAExport 1255
axlCNSDFAImport 1256
axlCNSDFAMode 1257
axlCNSEcsetCreate 1259
axlCNSEcsetDelete 1261
axlCNSEcsetGet 1262
axlCNSEcsetModeGet 1263
axlCNSEcsetModeSet 1265
axlCNSEcsetValueCheck 1268
axlCNSEcsetValueGet 1269
axlCNSEcsetValueSet 1329
axlCNSGetAssembly 609
axlCNSGetDefaultMinLineWidth 1272
axlCNSGetPhysical 1273
axlCNSGetPinDelayEnabled 1276
axlCNSGetPinDelayPVF 1277
axlCNSGetSameNet 1278
axlCNSGetSameNetXtalkEnabled 1281
axlCNSGetSpacing 1282
axlCnsGetViaList 1331
axlCNSGetViaZEnabled 1285
axlCNSGetViaZPVF 1286

axlCNSIsCsetLocked 1289
axlCNSIsLockedDomain 1290
axlCnsList 1346
axlCNSLockDomain 1292
axlCNSMapClear 1348
axlCNSMapUpdate 1349
axlCNSModeGet 1358
axlCNSModeSet 1355
axlCnsNetFlattened 1351
axlCNSOptions 1293
axlCNSPhysicalModeGet 1287
axlCNSPhysicalModeSet 1295
axlCnsPurgeAll() 1322
axlCnsPurgeCsets 1323
axlCnsPurgeObjects 1324
axlCNSSameNetModeGet 1297
axlCNSSameNetModeSet 1299
axlCNSSetAssembly 612
axlCNSSetPhysical 1301
axlCNSSetPinDelayEnabled 1308
axlCNSSetPinDelayPVF 1309
axlCNSSetSameNet 1310
axlCNSSetSameNetXtalkEnabled 1312
axlCNSSetSpacing 1304
axlCNSSetViaZEnabled 1313
axlCNSSetViaZPVF 1314
axlCNSSpacingMax 1315
axlCNSSpacingMin 1316
axlCNSSpacingModeGet 1318
axlCNSSpacingModeSet 1320
axlColorDoc 183
axlColorGet 186
axlColorLoad 192
axlColorOnGet – Obsolete 194
axlColorOnSet – Obsolete 195
axlColorPriorityGet – Obsolete 196
axlColorPrioritySet – Obsolete 197
axlColorSave 198
axlColorSet 199
axlColorShadowGet 188
axlColorShadowSet 190
axlCompAddPin 616
axlCompareLayers 216
axlCompDeletePin 619
axlCompileSymbol 990

axlCompMovePin 620
axlComponentChangeClass 622
axlCompSetPinAttributes 624
axlConductorBottomLayer 243
axlConductorTopLayer 244
axlControlRaise 542
axlCopyObject 353
axlCopyProperties 351
axlcreate – Obsolete 134
axlCreateAttachment 1198
axlCreateBondFinger 1120
axlCreateBondWire 1122
axlCreateDeviceFileTemplate 615
axlCreateDfmAssignment 1753
axlCreateDFMCset 1767
axlCreateLeadContact 1745
axlCreateWirebondGuide 1152
axlCurrentDesign 987
axlCursorGet 706
axlCursorWarp 707
axlCustomColorObject 205
axlCVFColorChooserDlg 202
axlDB2Path 1089
axlDBActiveShape 1109
axlDBAddGroupObjects 1172
axlDBAddProp 1159
axlDBAltOrigin 355
axlDBAssignNet 1692
axlDBChangeDesignExtents 1018
axlDBChangeDesignOrigin 1019
axlDBChangeDesignUnits 1020
axlDBChangeText 357
axlDBCheck 1023
axlDBCloak 1209
axlDBComposeShapesFromLines 1098
axlDBConnectItem 360
axlDBControl 992
axlDBCopyPadstack 1025
axlDBCreateBoundingShape 1101
axlDBCreateCircle 1095
axlDBCreateCloseShape 1108
axlDBCreateComponent 1697
axlDBCreateConceptComponent 1695
axlDBCreateExternalDRC 1124
axlDBCreateFillet 1128
axlDBCreateFilmRec – Obsolete 245

axlDBCreateGroup 1173
axlDBCreateLine 1093
axlDBCreateManyModuleInstances 1699
axlDBCreateModuleDef 1702
axlDBCreateModuleInstance 1703
axlDBCreateNet 1705
axlDBCreateOpenShape 1104
axlDBCreatePadStack 425
axlDBCreatePath 1090
axlDBCreatePin 1130
axlDBCreatePropDictEntry 1155
axlDBCreateRectangle 1115
axlDBCreateShape 1113
axlDBCreateSymbol 1134
axlDBCreateSymbolAutosilk 1149
axlDBCreateSymbolSkeleton 1138
axlDBCreateSymDefSkeleton 1706
axlDBCreateText 1143
axlDBCreateVectorizedEllipse 1117
axlDBCreateVia 1146
axlDBCreateViaStructure 1150
axlDBCreateVoid 1111
axlDBCreateVoidCircle 1110
axlDBDeleteProp 368
axlDBDeletePropAll 371
axlDBDeletePropDictEntry 372
axlDBDelLock 1027
axlDBDisbandGroup 1177
axlDBDisplayControl 1047
axlDBDummyNet 1708
axlDBDynamicShapes 493
axlDBFindByName 327
axlDBGetAttachedText 462
axlDBGetConnect 476
axlDBGetDesign 457
axlDBGetDesignStats 626
axlDBGetDesignUnits 472
axlDBGetDrillPlating 459
axlDBGetExtents 999
axlDBGetGroupFromItem 1178
axlDBGetLayerType 218
axlDBGetLength 1582
axlDBGetLock 1028
axlDBGetLonelyBranches 475
axlDBGetManhattan 1583

axlDBGetPad 464
axlDBGetPropDict 467
axlDBGetPropDictEntry 468
axlDBGetProperties 470
axlDBGetShapes 494
axlDBGetSymbolBodyExtent 1584
axlDBGetTextBlockCount 135
axlDBGridGet 136
axlDBGridSet 138
axlDBGroupRename 1180
axlDbidName 1710
axlDBIgnoreFixed 1000
axlDBIsBondingWireLayer – Obsolete 628
axlDBIsBondpad 478
axlDBIsBondwire 479
axlDBIsDiePad 629
axlDBIsDieStackLayer 653
axlDBIsFixed 480
axlDBIsPackagePin 482
axlDBIsPlatingbarPin 630
axlDBIsReadOnly 1002
axlDBMemoryReclaim 1029
axlDBOpenShape 373
axlDBPinPairLength 1585
axlDBRefreshId 473
axlDBRemoveGroupObjects 1181
axlDBSectorSize - Obsolete 1003
axlDBSetLock 1031
axlDBTextBlockCompact 495
axlDBTextBlockCreate 140
axlDBTextBlockFindName 142
axlDBTextBlockGetName 143
axlDBTextBlockSetName 144
axlDBTransactionCommit 1213
axlDBTransactionMark 1214
axlDBTransactionOops 1215
axlDBTransactionRollback 1216
axlDBTransactionStart 1217
axlDBTuneSectorSize 1034
axlDBViaStack 483
axlDebug 1465
axlDegToRad 1525
axlDehighlightObject 534
axlDeleteAttachment 1201
axlDeleteByLayer 1586
axlDeleteByRectangle 365

axlDeleteDfmAssignment 1758
axlDeleteDFMCset 1769
axlDeleteFillet 375
axlDeleteLeadContact 1748
axlDeleteObject 362
axlDeleteTaper 367
axlDesignFlip 520
axlDesignType 988
axlDetailLoad 1466
axlDetailSave 1468
axlDFMCsetLock 1757
axlDFMIsCsetLocked 1756
axlDieTextIn 631
axlDiffPair 1712
axlDiffPairAuto 1714
axlDiffPairDBID 1716
axlDistance 1526
axlDllCall 1668
axlDllCallList 1670
axlDllClose 1671
axlDllDump 1672
axlDllOpen 1673
axlDllSym 1675
axlDMBrowsePath 1434
axlDMClose 1433
axlDMDirectoryBrowse 1435
axlDMFileBrowse 1436
axlDMFileError 1424
axlDMFileParts 1439
axlDMFindFile 1425
axlDMGetFile 1427
axlDMOpenFile 1429
axlDMOpenLog 1432
axldo 1677
axlDrawObject 539
axlDRCGetCount 1341
axlDRCItem 1342
axlDRCUpdate 1338
axlDRCWaive 1339
axlDRCWaiveGetCount 1344
axlDynamicsObject 540
axlEmail 1469
axlEndSkillMode 1371
axlEnterAngle 523
axlEnterBox 529

axlEnterEvent 543
axlEnterPath 531
axlEnterPoint 521
axlEnterString 522
axlEraseObject 541
axlEventSetStartPopup 547
axlExportXmlDBRecords 145
axlExtentDB 1588
axlExtentLayout – Obsolete 1589
axlExtentSymbol – Obsolete 1590
axlExtractMap 1451
axlExtractToFile 1449
axlFillet 376
axlFilletConvert 377
axlFilmCreate 146
axlFindFilterIsOpen 329
axlFindPath 1591
axlFinishEnterFun 525
axlFixFillet 378
axlFlushDisplay 1372
axlFormAutoResize 887
axlFormBNFDoc 822
axlFormBuildPopup 849
axlFormCallback 838
axlFormClearMouseActive 846
axlFormClose 847
axlFormColorize 888
axlFormCreate 843
axlFormDefaultButton 927
axlFormDisplay 848
axlFormGetActiveField 891
axlFormGetField 853
axlFormGetFieldRange 855
axlFormGetFieldRange 925
axlFormGetFieldType 926
axlFormGetOptionValue 856
axlFormGridBatch 892
axlFormGridCancelPopup 893
axlFormGridDeleteRows 894
axlFormGridEvents 895
axlFormGridGetCell 898
axlFormGridGetSize 857
axlFormGridInsertCol 900
axlFormGridInsertRows 904
axlFormGridNewCell 905
axlFormGridOptions 929

axlFormGridReset 906
axlFormGridSelected 859
axlFormGridSelectedCnt 860
axlFormGridSetBatch 907
axlFormGridSetSelectRows 861
axlFormGridUpdate 910
axlFormInvalidateField 911
axlFormIsFieldEditable 912
axlFormIsFieldVisible 881
axlFormListAddItem 913
axlFormListDeleteAll 863
axlFormListDeleteItem 915
axlFormListGetCount 858
axlFormListGetItem 917
axlFormListGetSelCount 918
axlFormListGetSelItems 919
axlFormListOptions 920
axlFormListSelAll 922
axlFormListSelect 866
axlFormMsg 923
axlFormRestoreField 876
axlFormSetActiveField 931
axlFormSetDecimal 932
axlFormSetEventAction 867
axlFormSetField 869
axlFormSetFieldEditable 933
axlFormSetFieldHelpTip 872
axlFormSetFieldLimits 934
axlFormSetFieldVisible 880
axlFormSetInfo 873
axlFormSetMouseActive 874
axlFormTest 875
axlFormTitle 878
axlFormTreeViewAddItem 935
axlFormTreeViewChangeImages 938
axlFormTreeViewChangeLabel 940
axlFormTreeViewGetImages 941
axlFormTreeViewGetLabel 942
axlFormTreeViewGetParents 943
axlFormTreeViewGetSelectState 944
axlFormTreeViewLoadBitmaps 945
axlFormTreeViewSet 947
axlFormTreeViewSetSelectState 950
axlGeo2Str 1527
axlGeoAngleBetweenLines 1529

axlGeoArcCenterAngle 1530
axlGeoArcCenterRadius 1533
axlGeoArcMidpoint 1538
axlGeoCircleCircleInt 1539
axlGeoCircleLineInt 1540
axlGeoCircleLineInt2 1541
axlGeoClosestPointOnArc 1593
axlGeoClosestPointOnCircle 1594
axlGeoEqual 1542
axlGeoFindAngle 1544
axlGeoGetBBox 1545
axlGeoIsBoxOverlap 1546
axlGeoIsShorterArcClockwise 1552
axlGeoLineMidpoint 1547
axlGeoMirrorLayer 1598
axlGeoPickShorterArc 1551
axlGeoPointInShape 1595
axlGeoPointsEqual 1550
axlGeoPointShapeInfo 1596
axlGeoRotatePt 1548
axlGeoUnrotatePt 1553
axlGetActiveLayer – Obsolete 1043
axlGetActiveTextBlock – Obsolete 1044
axlGetAlias 572
axlGetAllAttachmentNames 1202
axlGetAllViaList 1333
axlGetAllVisibleProfiles 641
axlGetAttachment 1203
axlGetBondWireLength 643
axlGetBondWireToBondWireDist 634
axlGetDFMAssignedCsets 1759
axlGetDFMCset 1771
axlGetDFMCsetAssignmentStatus 1763
axlGetDFMCsets 1770
axlGetDieData 654
axlGetDieStackData 657
axlGetDieStackMemberSet 659
axlGetDieStackNames 661
axlGetDieType 635
axlGetDrawingName 1004
axlGetDynamicsSegs 526
axlGetExternalLayers 219
axlGetFindFilter 312
axlGetFunckey 573
axlGetImpedance 1597
axlGetIposerData 662

axlGetLastEnterPoint 379
axlGetLineLock 527
axlGetMaxSpacingCNS 1334
axlGetMetalUsageForLayer 636
axlGetModuleInstanceDefinition 484
axlGetModuleInstanceLocation 485
axlGetModuleInstanceLogicMethod 486
axlGetModuleInstanceNetExceptions 487
axlGetParam 170
axlGetSelSet 308
axlGetSelSetCount 310
axlGetSNSTolerance 1336
axlGetSpacerData 664
axlGetSPCTolerance 1337
axlGetSupportedLeadTypes 1749
axlGetTrapBox 549
axlGetVariable 574
axlGetVariableList 576
axlGetWireProfileColor 666
axlGetWireProfileDefinition 638
axlGetWireProfileDirection 640
axlGetWireProfileVisible 667
axlGetXSection – Obsolete 220
axlGRPDrwBitmap 957
axlGRPDrwCircle 958
axlGRPDrwInit 959
axlGRPDrwLine 960
axlGRPDrwMapWindow 961
axlGRPDrwPoly 962
axlGRPDrwRectangle 963
axlGRPDrwText 964
axlGRPDrwUpdate 965
axlHighlightObject 532
axlHistory 1470
axlHttp 1472
axlIgnoreFixed 1005
axlImpdedanceGetLayerBroadsideDPImp 1599
axlImpdedanceGetLayerBroadsideDPWidth 1600
axlImpdedanceGetLayerEdgeDPImp 1601
axlImpdedanceGetLayerEdgeDPSpacing 1602
axlImpdedanceGetLayerEdgeDPWidth 1603
axlImpedance2Width 1604
axlImportWireProfileDefinitions 650
axlImportXmlDBRecords 149
axlInTrigger 1006

axlInTriggerFunc 1007
axlIsAttachment 1205
axlIsBetween 1555
axlIsCustomColored 214
axlIsDBIDType 460
axlIsDebug 1474
axlIsDummyNet 488
axlIsEtchLayer 222
axlIsFormType 879
axlIsGridCellType 903
axlIsHighlighted 1615
axlIsitFill 491
axlIsLayer 223
axlIsLayerNegative 489
axlIsParamType 179
axlIsPinUnused 490
axlIsPointInsideBox 1556
axlIsPointOnLine 1557
axlIsPolyType 1413
axlIsProductLineActive 1475
axlISProductStarted 1476
axlIsProtectAlias 581
axlIsSymbolEditor 1008
axlIsViewFileType 745
axlIsVisibleLayer 224
axlJournal 578
axlKillDesign 1009
axlLastPick 380
axlLastPickIsSnapped 341
axlLayerCreateCrossSection – Obsolete 225
axlLayerCreateNonConductor 226
axlLayerDelete 227
axlLayerExternal 229
axlLayerGet 230
axlLayerPriorityClearAll 207
axlLayerPriorityGet 208
axlLayerPriorityRestoreAll 210
axlLayerPrioritySaveAll 211
axlLayerPrioritySet 212
axlLayerRenameNonConductor 232
axlLayerSet 1345
axlLayerViaLabel 233
axlLicDefaultVersion 1477
axlLicFeatureExists 1478
axlLicIsProductEnabled 1479
axlLineSlope 1558

axlLineXLine – Obsolete 1559
axlLoadPadstack 1164
axlLoadSymbol 1165
axlLoadViaStructure 644
axlLogHeader 1480
axlMakeDynamicsPath 567
axlMapClassName 1488
axlMatchGroupAdd 1717
axlMatchGroupCreate 1719
axlMatchGroupDelete 1722
axlMatchGroupProp 1723
axlMatchGroupRemove 1725
axlMaterialGet 234
axlMathConstants 1560
axlMathDotProduct 1561
axlMathSolveQuadratic 1554
axlMemSize 1490
axlMeterCreate 708
axlMeterDestroy 710
axlMeterIsCancelled 711
axlMeterUpdate 712
axlMidPointArc 1562
axlMidPointLine 1563
axlMiniStatusClose 538
axlMiniStatusLoad 535
axlMiniStatusReset 151
axlMKS2UU 1481
axlMKSAlias 1483
axlMKSConvert 1484
axlMKSStr2UU 1487
axlMPythag 1564
axlMsgCancelPrint 980
axlMsgCancelSeen 981
axlMsgClear 982
axlMsgContextClear 979
axlMsgContextFinish 978
axlMsgContextGet 973
axlMsgContextGetString 972
axlMsgContextInBuf 975
axlMsgContextPrint 971
axlMsgContextRemove 976
axlMsgContextStart 977
axlMsgContextTest 974
axlMsgPut 970
axlMsgSet 983

axlMsgTest 984
axlMUniVector 1565
axlMXYAdd 1567
axlMXYMult 1568
axlMXYSub 1569
axlNetClassAdd 1182
axlNetClassCreate 1184
axlNetClassDelete 1186
axlNetClassGet 1187
axlNetClassRemove 1189
axlNetEcsetValueGet 1327
axlNetlistTextIn 645
axlNetSched 1727
axlOK2Void 492
axlOKToProceed 1374
axl_ol_ol2 1571
axlOpenDesign 1010
axlOpenDesignForBatch 1012
axlOpenFindFilter 325
axlOSBackSlash 1491
axlOSControl 1492
axlOSExit 1496
axlOSFileCopy 1440
axlOSFileMove 1441
axlOSNtp 1494
axlOSSlash 1442
axlPackageDesignCheckAddCategory 668
axlPackageDesignCheckAddCheck 670
axlPackageDesignCheckDrcError 673
axlPackageDesignCheckLogError 674
axlPadFigureTypes 433
axlPadOnLayer 1605
axlPadstackEdit 434
axlPadstackSetType 444
axlPadstackToDisk 1167
axlPadstackUsageTypes 446
axlPadSuppressGet 152
axlPadSuppressOkLayer 154
axlPadSuppressSet 155
axlPadUserMaskLayers 447
axlParamDesignDoc 175
axlParamFilletDoc 158
axlParamShapeDoc 162
axlPathArcAngle 1075
axlPathArcCenter 1075
axlPathArcRadius 1075

axlPathGetLastPathSeg 1083
axlPathGetPathSegs 1082
axlPathGetWidth 1080
axlPathLine 1079
axlPathOffset 1088
axlPathSegGetArcCenter 1085
axlPathSegGetArcClockwise 1086
axlPathSegGetEndPoint 1084
axlPathSegGetWidth 1081
axlPathStart 1074
axlPathStartCircle 1087
axlPdfView 1498
axlPinExport 1607
axlPinImport 1608
axlPinPair 1728
axlPinPairSeek 1731
axlPinsOfNet 1732
axlPolyErrorGet 1416
axlPolyExpand 1407
axlPolyFromDB 1396
axlPolyFromDrillHole 1414
axlPolyFromHole 1401
axlPolyMemUse 1402
axlPolyOffset 1404
axlPolyOperation 1405
axlPolyRotate 1418
axlPolyTrim 1419
axlPPrint 1497
axlPrintDbid 1499
axlProtectAlias 580
axlPulseCopyAs 1056
axlPulseDownloadAttachment 1057
axlPulseEnabled 1058
axlPulseGetAttachmentNames 1059
axlPulseGetDesignStatus 1060
axlPulseGetRevision 1061
axlPulseGetStatus 1062
axlPulseLock 1063
axlPulseOpenDesign 1064
axlPulseShowDesigns 1065
axlPulseShowShare 1066
axlPulseUnlock 1067
axlPulseUploadAttachment 1068
axlPulseVersionControl 1069
axlPurge3DModelMapDataInDesign 386

axlPurgePadstacks 384
axlPushConnectivity 647
axlRadToDeg 1570
axlRatsnestBlank 550
axlRatsnestDisplay 551
axlReadOnlyVariable 582
axlRecursiveDelete 1443
axlRefreshSymbol 1168
axlRegexpIs 1501
axlRegionAdd 1190
axlRegionCreate 1192
axlRegionDelete 1193
axlRegionRemove 1194
axlRemoveNet 1733
axlRenameDesign 1014
axlRenameDFFCset 1766
axlRenameNet 1734
axlRenameRefdes 1736
axlReplacePadstack 383
axlReportGenerate 1453
axlReportList 1455
axlReportRegister 1456
axlReratNet 1610
axlRunBatchDBProgram 1502
axlSaveDesign 1015
axlSaveEnable 1017
axlSchedule 1738
axlScheduleNet 1740
axlSegDelayAndZ0 1621
axlSelect 305
axlSelectByName 330
axlSelectByProperty 335
axlSetActiveLayer – Obsolete 1045
axlSetAlias 584
axlSetAlias 586
axlSetAllProfilesVisible 642
axlSetAttachment 1206
axlSetBondWireProfile 649
axlSetBondWireProfile 651
axlSetDefaultDieInformation 1622
axlSetDieData 676
axlSetDieStackData 652
axlSetDieType 678
axlSetDynamicsMirror 552
axlSetDynamicsRotation 553
axlSetFindFilter 314

axlSetFunckey 588
axlSetIposerData 679
axlSetLineLock 1375
axlSetParam 177
axlSetPlaneType 246
axlSetRotateIncrement 1377
axlSetSNSTolerance 1353
axlSetSpacerData 680
axlSetSPCTolerance 1354
axlSetSymbolType 991
axlSetVariable 590
axlSetVariableFile 592
axlSetWireProfileColor 681
axlSetWireProfileVisible 682
axlShapeArea 496
axlShapeAutoVoid 387
axlShapeChangeDynamicType 389
axlShapeDeleteVoids 391
axlShapeDynamicUpdate 393
axlShapeEraseDegassingHole 683
axlShapeExistDegasOutOfDate 497
axlShapeGetDegasOutOfDateCount 498
axlShapeIsDegasOutOfDate 499
axlShapeIsDegasOutOfDateCheckDisabled 500
axlShapeMerge 396
axlShapeRaisePriority 394
axlShapeUpdateDegas 398
axlShell 593
axlShellPost 594
axlShoveItems 399
axlShoveSetParams 400
axlShowObject 1507
axlShowObjectToFile 554
axlSingleSelectBox 289
axlSingleSelectName 296
axlSingleSelectObject 302
axlSingleSelectPoint 282
axlSleep 1508
axlSmoothDesign 403
axlSmoothItems 404
axlSmoothSetParams 405
axlSnapDisableAtRMB 337
axlSnapEnableAtRMB 338
axlSnapToObject 339
axlSort 1509

axlSpreadsheetClose 1623
axlSpreadsheetDefineCell 1625
axlSpreadsheetDoc 1626
axlSpreadsheetGetCell 1628
axlSpreadsheetGetRGBColorString 1630
axlSpreadsheetGetRGBForNamedColor 1631
axlSpreadsheetGetStyles 1632
axlSpreadsheetGetWorksheets 1633
axlSpreadsheetGetWorksheetSize 1634
axlSpreadsheetInit 1635
axlSpreadsheetRead 1637
axlSpreadsheetReadDelimited 1639
axlSpreadsheetSetCell 1640
axlSpreadsheetSetCellProp 1642
axlSpreadsheetSetColumnProp 1644
axlSpreadsheetSetDocProp 1646
axlSpreadsheetSetRowProp 1647
axlSpreadsheetSetStyle 1649
axlSpreadsheetSetStyleBorder 1650
axlSpreadsheetSetStyleParent 1652
axlSpreadsheetSetStyleProp 1653
axlSpreadsheetSetWorksheet 1657
axlSpreadsheetWrite 1658
axlStepDelete 408
axlStepGet 501
axlStepMappedInstance 504
axlStepSet 409
axlStrcmpAlpNum 1513
axlStringCSVParse 1514
axlStringRemoveSpaces 1516
axlSubclasses 247
axlSubclassFormPopup 1386
axlSubclassRoute 249
axlSubSelectAll 294
axlSubSelectBox 292
axlSubSelectName 300
axlSubSelectObject 304
axlSubSelectPoint 287
axlSymbolAttach 411
axlSymbolDetach 413
axltdfIsEnabled 180
axltdfLoad 181
axltdfSave 182
axlTechnologyType 1035
axlTempDirectory 1445
axlTempFile 1446

axlTempFileRemove 1447
axlTestPoint 1616
axlText2Lines 1611
axlTextOrientationCopy 416
axlTransformObject 417
axlTriggerClear 1036
axlTriggerPrint 1037
axlTriggerSet 1038
axlUIAppMode 713
axlUICmdPopupSet 555
axlUIColorDialog 717
axlUIConfirm 718
axlUIConfirmEx 719
axlUIControl 721
axlUIDataBrowse 778
axlUIEditFile 760
axlUIGetUserData 1378
axlUIMenuChange 723
axlUIMenuDebug 725
axlUIMenuDelete 726
axlUIMenuDump 716
axlUIMenuFind 727
axlUIMenuInsert 730
axlUIMenuLoad 715
axlUIMenuRegister 733
axlUIMultipleChoice 762
axlUIPopupDefine 1379
axlUIPopupDump 735
axlUIPopupSet 1381
axlUIPrompt 736
axlUIViewFileCreate 746
axlUIViewFileReuse 748
axlUIViewFileScrollTo 763
axlUIWBeep 764
axlUIWBlock 759
axlUIWClose 753
axlUIWCloseAll 738
axlUIWDisableQuit 765
axlUIWExpose 752
axlUIWExposeByName 766
axlUIWHelpRegister 755
axlUIWIconify 739
axlUIWIsIconic 740
axlUIWIsWindow 741
axlUIWMove 742

axlUIWPerm 767
axlUIWPrint 757
axlUIWRedraw 743
axlUIWRedraw 758
axlUIWSetHelpTag 769
axlUIWSetParent 770
axlUIWShow 771
axlUIWSize 744
axlUIWTimerAdd 772
axlUIWTimerRemove 775
axlUIWUpdate 776
axlUIYesNo 750
axlUIYesNoCancel 777
axlUnfixAll 1613
axlUnfixFillet 421
axlUnsetVariable 596
axlUnsetVariableFile 597
axlVersion 1517
axlVersionIdGet 1521
axlVersionIdPrint 1522
axlViaZLength 1325
axlVisibleDesign 237
axlVisibleGet 239
axlVisibleLayer 241
axlVisibleSet 242
axlVisibleUpdate 1389
axlWFMAnyExported 1046
axlWidth2Impedance 1614
axlWindowBoxGet 381
axlWindowBoxSet 382
axlWindowFit 556
axlWriteDeviceFile 1741
axlWritePackageFile 1743
axlXSectionAssign 251
axlXSectionCopy 252
axlXSectionCreate 253
axlXSectionCreateStackup 258
axlXSectionDelete 259
axlXSectionDeleteStackup 260
axlXSectionGet 261
axlXSectionLayerFunctions 268
axlXSectionLayerTypes 269
axlXSectionModify 270
axlXSectionRemove 271
axlXSectionRename 273
axlXSectionSet 274

axlZoneAccess 505
axlZoneCreate 1153
axlZoneDelete 422
axlZoneSet 423
axlZoomBbox 557
axlZoomCenter 558
axlZoomControl 559
axlZoomFit 561
axlZoomInOut 562
axlZoomPoints 563
axlZoomToDbid 564
axlZoomWorld 566
bBoxAdd 1573
Cadence Customer Support 1666
Callback Procedure: formCallback 882
copyDeep 1679
DLL Programming 1662
Examples 1666
Field / Control 782
Input/Output Data Primitives 1664
isBoxp 1680
lastelem 1681
letStar 1682
listnindex 1683
movedown 1684
moveup 1685
parseFile 1686
parseQuotedString 1688
Performance Considerations 1666
pprintln 1689
Programming 781
Programming Restrictions, Cautions and Hints 1665
propNames 1690
SKILL Programming 1661

Before You Start

About This Manual

This manual is for designers and engineers who use the Allegro PCB Editor SKILL functions to customize existing Allegro PCB Editor interactive commands or create new ones. It describes the AXL (Allegro eXtension Language) user model, how to start AXL, and how to use each AXL function.

This manual assumes that you are familiar with the development and design of printed circuit boards (PCBs). It also assumes you are familiar with Allegro PCB Editor for the physical design of PCBs and analysis of reliability, testability, and restructurability.

If you are reading this manual for a general understanding of AXL capabilities, but do not actually intend to program in AXL, read Chapter 1, “Introduction to Allegro PCB Editor SKILL Functions.”

You should also be familiar with the Cadence SKILL language. The following manuals describe SKILL:

- *SKILL Language User Guide*
- *SKILL Language Reference*
- *Cadence SKILL Functions Quick Reference*

©2023 All Rights Reserved.

Prerequisites

Before you begin using Allegro PCB Editor to design boards, you should be familiar with the Allegro PCB Editor environment.

The *Allegro PCB Editor User Guide: Getting Started with Physical Design* explains how to:

- Start Allegro PCB Editor
- Navigate in the Allegro PCB Editor software
- Get help on a command
- Use the mouse, menus and forms
- Start a design session

Command Syntax Conventions

AXL–SKILL descriptions adhere to the conventions described in the *SKILL Language Basics*. In addition, this manual uses the conventions described below.

italics	Data type name.
nil	Standard SKILL for empty list; as a return value, may indicate failure.
t	Standard SKILL for “true;” return value for success.
[name]	Optional argument “name.”
<name>	Argument of type “name” required.
dbid	Instance of an Allegro PCB Editor database object (means “database id”)
figure	Geometric Allegro PCB Editor database object—for example, line, shape, or symbol are all Allegro PCB Editor figures. This is not to be confused with the Allegro PCB Editor’s database object “figure”, a special graphic denoting DRC markers and drill holes. To ensure clear distinction in this manual, “Allegro PCB Editor figure” denotes this special object.
l_bBox	A list of the coordinates of a bounding box. Coordinate pairs are lower left and upper right. For example, `(list( 100:100 200:200 ))`

©2023 All Rights Reserved.

t_layer	A pair of names separated by a slash "/" denoting the name of an Allegro PCB Editor class-subclass. For example, "PACKAGE GEOMETRY/ SILKSCREEN_TOP."
lo_dbid	Function that takes or returns a dbid or list of dbids.
o_dbid	Function that takes or returns a single dbid.

Referencing Objects by Name

When programming AXL, you can select or refer to a named object by using the unique name of that object. The table shows Allegro PCB Editor object types and their associated names:

Table 4-1 Allegro PCB Editor Object Types and Names

Allegro PCB Editor Object Type	Name
NET	netname
COMPONENT	refdes
SYMBOL	refdes or symbol pin: <refdes>.<pin number>
FUNCTION	function designator
DEVTYPE	device type
SYMTYPE	symbol type, for example, "DIP 14"
PROPERTY	property name, for example, "MAX_OVERSHOOT"

You can select objects using the `axlName` functions in Chapter 4, "Selection and Find Functions".

©2023 All Rights Reserved.

Finding Information in This Manual

The following table summarizes the topics described in this manual.

For Information About . . .	Read . . .
AXL operation and the relation between Allegro PCB Editor database and AXL functions: ■ AXL functions ■ AXL initialization, environment ■ Starting and stopping AXL ■ Debugging AXL programs ■ *dbids* and object persistence ■ Selecting Allegro PCB Editor database objects ■ AXL–SKILL database object types	Chapter 1, “Introduction to Allegro PCB Editor SKILL Functions”
The structure of Allegro PCB Editor AXL database objects, and how they are related to each other. Lists attributes of each object type. ■ Database rules ■ Attribute types ■ Figure (geometric) database types ■ Logical database types ■ Property database types ■ Full attribute listing for all Allegro PCB Editor database objects	Chapter 2, “The Allegro PCB Editor Database User Model”

©2023 All Rights Reserved.

For Information About . . .	Read . . .
Path structures and AXL functions that add path objects and other figure objects to the Allegro PCB Editor database. ■ Path create functions ■ Create shape and rectangle functions ■ Create functions for line, pin, symbol, text, and via	Chapter 15, “Database Create Functions”
Read/Write access to Allegro PCB Editor database parameter objects.	Chapter 3, “Parameter Management Functions”
The select set and AXL functions for managing the select set and selecting single and multiple database objects. ■ Point selection ■ Box selection ■ Selection by name and object *dbid* ■ Find filter management ■ Selection set management	Chapter 4, “Selection and Find Functions”
AXL functions that operate on database objects in the same way as interactive Allegro PCB Editor commands, including functions to: ■ Delete objects ■ Show objects	Chapter 5, “Interactive Edit Functions”
Reading database objects: ■ Opening an Allegro PCB Editor design ■ Accessing standalone branch figures, properties, pads, and text	Chapter 6, “Database Read Functions”

©2023 All Rights Reserved.

For Information About . . .	Read . . .
AXL functions for ■ Highlighting and displaying database objects ■ Loading the cursor buffer and dynamic rubberband displays for interactive commands ■ Accepting single and multiple user coordinate picks ■ Callback functions for completing and cancelling commands	Chapter 7, “Allegro PCB Editor Interface Functions”
AXL functions for ■ Setting Allegro PCB Editor shell variables ■ Sending a command string to the Allegro PCB Editor shell.	Chapter 8, “Allegro PCB Editor Command Shell Functions”
AXL functions for ■ Prompting and getting confirmation from the user, displaying text files ■ Displaying and printing ASCII files	Chapter 10, “User Interface Functions”
AXL forms and functions for ■ Creating forms, including the various types of form fields ■ Setting up callbacks for response to input to individual fields	Chapter 11, “Form Interface Functions”
AXL functions related to Simple Graphics Drawing	Chapter 12, “Simple Graphics Drawing Functions”
Writing AXL functions for ■ Setting up for user messages ■ Displaying messages to users	Chapter 13, “Message Handler Functions”

©2023 All Rights Reserved.

For Information About . . .	Read . . .
AXL functions for ■ Opening a design ■ Compiling, running edit check, and saving the current (symbol) design ■ Getting the type of the active design ■ Setting the Allegro PCB Editor symbol type ■ Getting or setting the value for a specified database control, sector, and obstacle ■ Changing the extents, origin, units and accuracy of the design ■ Setting, deleting, and getting information about locks on the database ■ Setting, clearing, and printing information about triggers, which register interest in events that occur in Allegro PCB Editor ■ Getting the active class and subclass, active text block, type of design technology in use, and the full path of the drawing ■ Saving the design ■ Saving a board padstack out to a library ■ Creating a new padstack by copying from an existing padstack ■ Running dbdoctor on the current database	Chapter 14, “Design Control Functions”

©2023 All Rights Reserved.

For Information About . . .	Read . . .
AXL functions for ■ Creating and removing database groups. ■ Adding and removing database objects from database groups.	Chapter 16, “Database Group Functions”
AXL functions for ■ Creating, changing, and deleting database attachments ■ Checking whether an object is a database attachment ■ Getting the ids of all database attachments ■ Getting a database attachment	Chapter 17, “Database Attachment Functions”
AXL functions for ■ Improving the performance and program memory use while updating many etch or package symbols in batch mode ■ Marking the start of a database transaction and returning the mark to the calling function ■ Writing a mark in the database to allow future rollback or commitment ■ Committing and undoing a database transaction	Chapter 18, “Database Transaction Functions”

©2023 All Rights Reserved.

For Information About . . .	Read . . .
AXL functions for ■ Getting and setting current DRC modes and values for design constraints and ECset members ■ Creating, deleting, and getting the dbid of an ECset ■ Checking the syntax of a given value against the allowed syntax for a given constraint ■ Batching and tuning DRC updates from constraint changes made using axlCNS<xxx> functions	Chapter 19, “Constraint Management Functions”
AXL functions for ■ Registering and unregistering SKILL commands with the command interpreter ■ Getting and setting the controls for line lock, active layer ■ Defining popups ■ Getting user data	Chapter 20, “Command Control Functions”
Polygon operation functions, attributes, and use models.	Chapter 21, “Polygon Operation Functions”
Getting Allegro PCB Editor file names, and opening and closing files	Chapter 22, “Allegro PCB Editor File Access Functions”
AXL functions for ■ SKILL access to the extract command ■ Selecting sets of database objects as members of a view and applying an AXL function to each	Chapter 23, “AXL-SKILL Data Extract Functions”

©2023 All Rights Reserved.

For Information About . . .	Read . . .
AXL functions for	Chapter 24, “Utility Functions”
■ Calculating an arc center given various data	
■ Converting quantities to various units	
Using math utility functions.	Chapter 25, “Math Utility Functions”
Odds and ends.	Chapter 26, “Database Miscellaneous Functions”
Using logic access functions.	Chapter 30, “Logic Access Functions”

Other Sources of Information

For more information about Allegro PCB Editor and other related products, consult the sources listed below.

Product Installation

The *Cadence Installation Guide* tells you how to install Cadence products.

Related Manuals

The following manuals comprise the Allegro PCB Editor documentation set for your workbench of PCB design tools:

For Information About...	Read...
The Allegro PCB Editor user interface. An overview of the design process using Allegro PCB Editor, starting and exiting, controlling the graphic display, graphic and text elements, design information, and system information.	*Allegro PCB Editor User Guide: Getting Started with Physical Design*
Building and managing libraries, including defining padstacks, custom pads, packages, electrical attributes, and formats.	*Allegro PCB Editor User Guide: Defining and Developing Libraries*

©2023 All Rights Reserved.

For Information About...	Read...
Loading logical design data and converting third-party mechanical data, including loading data from Concept™, netlists, and board mechanical data.	*Allegro PCB Editor User Guide: Transferring Logic Design Data*
Setting up the design and specifying design rules and controls, including instructions for specifying properties and constraints.	*Allegro PCB Editor User Guide:Preparing the Layout*
Placing components using Allegro PCB Editor, including automatic and interactive placement.	*Allegro PCB Editor User Guide: Placing the Elements*
Routing using Allegro PCB Editor, including interactive and automatic routing.	*Allegro PCB Editor User Guide: Routing the Design*
Design output, including renaming reference designators, creating drill and silkscreen data, and generating penplots.	*Allegro PCB Editor User Guide: Preparing Manufacturing Data*
Optional Allegro PCB Editor interfaces, including Cadnetix-E, CBDS, Racal Visula, IGES, Greenfield, Computervision CADDS, SDRC I-DEAS, AutoCAD DXF, PTC, CATIA, IPC-D_350C, GDSII, Fluke Defect Analyzer, and HP3070 Tester.	*Converting Third Party Designs and Mechanical Data*
Allegro PCB Editor commands, listed alphabetically.	*Allegro PCB and Package Physical Layout Command Reference*
Allegro PCB Editor properties, extracts (examples), and reports.	*Allegro PCB Editor User Guide: Design Rules, Extract Data Dictionary*, and *Viewing Reports On Screen in HTML Format*
A comprehensive glossary for the Allegro PCB Editor user guides and reference manuals.	*Allegro PCB Editor User Guide Glossary*

©2023 All Rights Reserved.

Customer Support

Cadence offers many customer education services. Ask your sales representative for more information.

Cadence Online Support (COS) is available for customers who have a maintenance agreement with Cadence.

Here, you can also find technical information, including SKILL documentation and shareware code, online. COS provides the latest in Quarterly Incremental Releases (QIRs), case and product change release (CCR) information, technical documentation, solutions, software updates and more.

Allegro PCB Editor Users Mailing List Subscription

You can use electronic mail (email) to subscribe to the Allegro PCB Editor users mailing list. You will receive periodic newsletters containing up-to-date information on the Allegro PCB Editor product family.

To subscribe to the Allegro PCB Editor mailing list

➤ Send an email message to *majordomo@cadence.com*, and include the phrase “subscribe allegro_users” in the body of the message.

You will receive an acceptance notification.

AXL-SKILL Example Files

You can find AXL-SKILL example files in this location:

`<install_dir>/share/pcb/examples/skill`

User Discussion Forums

You can find discussion groups for users of Cadence products at Cadence Community site.

©2023 All Rights Reserved.

1

Introduction to Allegro PCB Editor SKILL Functions

Overview

This chapter is a brief overview of the following:

- Allegro PCB Editor AXL-SKILL
- AXL-SKILL functions
- How to initialize and run AXL-SKILL
- The AXL Allegro PCB Editor database

Later chapters describe in detail the AXL database objects and all AXL-SKILL functions.

AXL-SKILL in Allegro PCB Editor

AXL-SKILL is a language processor contained in Allegro PCB Editor, as shown in the following figure.

AXL-SKILL contains and is an extension of the core Cadence SKILL language. You use AXL-SKILL functions to access the Allegro PCB Editor database and its display and user interfaces. Once you have accessed the Allegro PCB Editor database, you can process the

©2023 All Rights Reserved.

data using the core SKILL functions. The *SKILL Language Functions Reference* describes core SKILL and its available functions.

You access AXL-SKILL by entering the command `skill` on the Allegro PCB Editor command line.

AXL-SKILL initializes automatically when you start Allegro PCB Editor. As Allegro PCB Editor starts, it reads the Allegro PCB Editor `env` file, then the AXL `ilinit` file (as described below) then any script you may have specified with the `-s` option in the UNIX command starting Allegro PCB Editor.

Allegro PCB Editor looks for the `ilinit` file in the following way:

➤ For the locations specified below, Allegro PCB Editor reads one of the following files:

`<program_name>.ilinit`

`allegro.ilinit`

From the locations:

`<cdsroot>/share/pcb/etc/skill`

`<cdssite>/pcb/skill`

©2023 All Rights Reserved.

Note: *<cdssite>* defaults to *<cdsroot>*/share/local/pcb/skill, otherwise you can set the CDS_SITE variable to point to another location, the directory where your program started: $HOME/pcbenv

If you have multiple ilinit files in the locations listed above, *each* of the ilinit files will be read. If you wish only the *first* found ilinit file to be read (the methodology employed in pre-14.2 releases), set the environment variable skill_old_ilinit.

Note: You cannot insert SKILL commands in the env file.

Running AXL-SKILL from the Command Line

You run AXL-SKILL by typing skill on the Allegro PCB Editor command line. The AXL-SKILL interpreter appears with the *skill>* prompt in place of the Allegro PCB Editor command line.

You can also run AXL-SKILL functions from the Allegro PCB Editor command line with the following syntax:

```
skill (<function> <arguments>)
```

Type exit to close the AXL-SKILL interpreter and return to the Allegro PCB Editor command line.

Running AXL-SKILL in Batch Mode

You can run AXL-SKILL in batch mode using an X terminal window without displaying Allegro PCB Editor, by typing the following command:

```
.allegro -nographic
```

If your system is not running the X window system, verify that it has its DISPLAY environment variable set to a system running an X-server.

Note: The -nographic switch is valid for all Allegro PCB Editor graphic executables, such as allegro_layout, allegro_engineer, allegro_prep, allegro_interactive, and allegro_layout.

You can also program the Allegro PCB Editor and AXL-SKILL startup and command entry in a shell script, allowing full batch capability.

Debugging AXL-SKILL Programs

If you have a SKILL ACCESS development license, you can debug AXL-SKILL programs in Allegro PCB Editor using the same tools offered by other Cadence SKILL programs. See

©2023 All Rights Reserved.

SKILL Language Functions Reference for a description of those tools, which are primarily available on Unix.

AXL-SKILL Grammar

AXL-SKILL functions follow SKILL grammar rules. In addition, the following characteristics apply to most AXL-SKILL functions:

- All Allegro PCB Editor AXL function names begin with `axl`.
- AXL functions are classified into families that typically have similar calling sequences and share a common part of their names, for example the `axlDBCreate` family, with members such as `axlDBCreateShape` and `axlDBCreateSymbol`.

SKILL Development Window

You can get a larger SKILL-only window by setting the Allegro PCB Editor environment variable, `TELSKILL`.

Note: All Allegro PCB Editor console output is directed to the SKILL window when the `TELSKILL` variable is set.

AXL-SKILL Database

Allegro PCB Editor stores design data as various types of objects in a proprietary database format. These object types can create a complete representation of an electronic layout. You can create, operate on, and extract information from this database using AXL-SKILL programs.

The AXL-SKILL database stores both physical and logical information about your design. Physical information is objects such as geometrical shapes (connecting etch, for example). Logical information is objects such as nets and logical components.

Object dbids (database identifiers)

Every Allegro PCB Editor database object has a unique *`dbid`* (database identifier) associated with it. When you call a function to operate on a database object, you identify the object to the function by giving the object's *`dbid`* as an argument.

Only AXL routines can create *`dbids`*. You cannot alter *`dbids`* directly, except for parameter record ids.

©2023 All Rights Reserved.

Out of Scope dbids

When a dbid is separated from its object, the dbid is considered out-of-scope. A dbid can become separated from its object for any of the following reasons:

- You delete an object.
- You add a connect line that touches an existing connect line. This causes the existing line to break in to two objects, each with a separate dbid, so the original dbid of the line no longer denotes the same object.
- You return to Allegro PCB Editor from AXL.
- You run an Allegro PCB Editor command while in SKILL, using the AXL shell function. To minimize out-of-scope issues with AXL shell, isolate AXL shell functions and if necessary refresh dbids after AXL shell calls with the function axlDBRefreshID.
- You open a new layout.

Out of scope *`dbids`* have no attributes, so they have no object type. If you try to evaluate a *`dbid`* that is out of scope, SKILL displays the message:

```
dbid: removed
```

Using an out of scope *`dbid`* in a function causes unexpected results.

Object Types

Each Allegro PCB Editor object has an associated *type* and a set of *attributes* that describe the object. For example, all `symbol` objects are of type `symbol`. All `symbols` have the `isMirrored` attribute, among others, and this attribute has the value `t` if the symbol is mirrored or `nil` if it is not. You can use an AXL-SKILL function with `"->"` (the access operator) to access any object attribute. If the attribute does not exist for that object the function returns `nil`.

You use the SKILL special attributes `?` (question mark) and `??` to see all attributes and all attribute/value pairs of an object. See Chapter 2, “The Allegro PCB Editor Database User Model,” for more information about object types.

Object Classes

An *object class* is a data-type abstraction used to group related object types. When a number of distinct object types share enough attributes, you can discuss them as a single class. The start of each section describing a class of object types lists all attributes common to that class.

©2023 All Rights Reserved.

The different types and classes of objects form a class hierarchy. At the top of the hierarchy is a class containing all types. At the bottom of the hierarchy, each leaf (terminal node) represents an object type that you can create, delete, and save on disk. Each intermediate node in the hierarchy has attributes that are common to all of its children. AXL-SKILL figures, for example, have common attributes of `layer` and `bBox` (bounding box). These higher level classes do not exist as objects.

Select Sets and Find Functions

AXL-SKILL edit functions obtain the identities of the objects on which they operate from a list of *`dbids`* called the *select set.* You accumulate *`dbids`* in the select set by selecting one or several objects using AXL select functions. You then apply edit functions to the objects by passing the select set as an argument to the functions.

AXL-SKILL has functions to do the following:

- Set the Find Filter to control the types of objects selected and select options
- Select objects at a single point, over an area, or by name
- Select parts of objects (for example, pins, which are parts of symbols)
- Add or remove objects from the select set (the set of selected objects)
- Get *`dbids`* and return the count of *`dbids`* in the select set
- Add *`dbids`* to and remove them from the select set before using it.

See Chapter 4, “Selection and Find Functions,” for information about select set functions.

Note: Allegro PCB Editor highlights selected objects whenever it refreshes the display.

Design Files

Design files are containers for Allegro PCB Editor database objects. AXL-SKILL has two major design file types:

`Layout`	Contains printed circuit or MCM layout data.
`Symbol`	Contains the definition drawing of a symbol. The compiled output of a symbol file can be added to layouts. Symbol files can define any of package, mechanical, format, and shape symbols.

©2023 All Rights Reserved.

Logical Objects

Logical objects are the objects in the netlist that Allegro PCB Editor loads from a schematic or third-party netlist file:

`Component`	Contains the electrical functions, such as nand gates, and pins that define the electrical behavior of an object. A component's reference designator is its name.
`Net`	Is the set of all the etch objects—ppins, etch paths, shapes, and vias—associated with a particular signal name. Every net has a name which is its signal name. A net contains one or more branches. Each branch is a list of the etch objects that are physically connected among themselves. A branch can include ppins, etch paths, shapes, and vias. The number of branches in a net varies as Allegro PCB Editor connects or disconnects parts of the net. A completely connected net consists of one and only one branch.

Layer Attributes

Each Allegro PCB Editor figure exists on a class/subclass in the database. For example, a c-line might be on class ETCH, subclass TOP. AXL-SKILL represents this class/subclass combination with a layer attribute. Each AXL-SKILL layer is in one-to-one correspondence with an Allegro PCB Editor class/subclass combination. A later section describes this structure in detail.

Allegro PCB Editor Properties

Although they are a class of Allegro PCB Editor objects, you do not create or access Allegro PCB Editor properties directly. Rather, you use AXL-SKILL commands to attach, delete, and read the values of properties on Allegro PCB Editor database objects. You can also use AXL-SKILL commands to read, create and delete definitions of your own properties.

Property Definitions

AXL-SKILL stores each property definition for an object indirectly associated with that object. You can access any property definition on an object to find its value and you can create new, user-defined properties using AXL-SKILL functions.

You can use an AXL-SKILL function to attach a property to an object if the object accepts that property type. The property must be defined in the property dictionary of that database. A

©2023 All Rights Reserved.

property definition is an object that contains the property name, value type, and a list specifying to what object types it can be attached.

Figures

The following AXL-SKILL figures are Allegro PCB Editor geometry types.

`Arc`	Is a figure that is either an arc or a circle. You can specify arcs to AXL-SKILL with start and end points, and either radius or center point. (Allegro PCB Editor figure: `arc segment`).
`Branch`	Is a collection of etch figures that make up one physically connected part of a net. Nets are made up of branches, and branches are made up of pins, vias, tees and etch figures, as described later in this chapter.
`DRC`	Is a design rule violation marker with one or more object identities and a violation type and location.
`Line`	An object defined by the coordinates of its center line and a width (Allegro PCB Editor figure: `line segment`).
`Path`	Is a sequence of end-to-end lines and arcs on the same layer. Each segment can have a different width (Allegro PCB Editor figures: `lines and clines`).
`PPin`	Is a physical instance of a pin with associated padstack.
`Polygon`	Is an unfilled, closed path (Allegro PCB Editor figure: `unfilled shape`).
`Shape`	Is a filled shape. It can optionally contain voids.
`Pad`	Is a geometric shape (circle, oblong, rectangle) defining the shape of one type of pad on one layer. Pads are always owned by padstacks.
`Symbol`	Is a collection of geometries and text with a type name, location, rotation and mirroring.
`Tee`	Is the single point where the endpoints of three or more etch paths connect.
`Text`	Is a string of characters with associated size, mirror, rotation, and location.
`Via`	Is a connecting drill path between layers with associated padstack.

©2023 All Rights Reserved.

The following types are not figures but contain geometry that defines figure instances:

`Padstack`	(Pin/Via Definition) Contains the definition data for all ppins or vias of a named type.
`Symdef`	Contains the definition data for all symbols of a named type.

Accessing Allegro PCB Editor Colors with AXL-SKILL

You can access predefined colors and Allegro PCB Editor database colors using AXL-SKILL. Only graphics editors support access to Allegro PCB Editor database colors.

Forms

You set and access pre-defined colors by their symbols. The pre-defined colors include the following:

- ‘black
- ‘white
- ‘red
- ‘green
- ‘yellow
- ‘blue
- ‘button

Button means grey, the color of buttons in the application.

Note: You can use only pre-defined colors in Allegro PCB Editor forms.

Design Object

Graphics editors support access to the colors used for Allegro PCB Editor layers. These are represented by integers.

AXL API calls, including `axlLayerGet` (“class/subclass”) or its primitive form `axlGetParm`(`paramLayerGroup`:<*`class/paramLayer:`*<*`subclass`*>), return the current color setting of a layer via the color attribute call, as shown.

```
p = axlLayerGet("etch/top")
p->color->2
```


©2023 All Rights Reserved.

These color settings range between 1 and 24 with 0 reserved for the background color.

Form based interfaces supporting color include the following:

- axlFormDoc
- axlFormColorize
- axlFormGridDoc
- axlGRPDoc

Notes:

- AXL does not allow you to change the red/green/blue (RGB) of Allegro PCB Editor database colors.
- Pre-defined colors are restricted to minimize problems with 8 bit color graphics on UNIX.

Database Objects

A design is made of various database objects that you can combine to make other database objects. This section describes the relationships among database objects.

Parts of a Design

A design can include any of the following database objects:

- Property Dictionary
- Lines
- Text
- Polygons
- Shapes
- Property Definitions
- DRCs
- Vias that are Padstack object types
- Symbols that are Symdef object types
- Components
- Nets

©2023 All Rights Reserved.

Parts of a Symbol

Symbols that are Symdef objects types can include any of the following database objects:

- PPins that are Padstack object types
- Vias that are Padstack object types
- Lines
- Arcs
- Text
- Polygons
- Shapes

Parts of a Branch

Branches can include any of the following database objects:

- Tees
- Vias that are Padstack object types
- PPins that are Padstack object types
- Paths
- Shapes

Parts of a Path

A path can include any of the following database objects:

- Lines
- Arcs

Parts of a Symdef

A symdef can include any of the following database objects:

- PPins that are Padstack object types
- Vias that are Padstack object types
- Lines
- Arcs

©2023 All Rights Reserved.

- Text
- Polygons
- Shapes

Types of Parameters

Allegro PCB Editor parameters store feature or board level options to the Allegro PCB Editor database. You can modify parameters using a SKILL program. The parameter types include the following:

- Design
- Display
- Layer Group
- Textblock Group

Table 1-1 Other Database Object Relationships

Object Name	Object Parts
Property Dictionary	Property Entries
Net	Branches
Padstack	Pads
Polygon	Paths
Shape	Paths
Void	Polygons
Polygon	Paths
PPin	Pin Number Text
Layer Group	Layers
Textblock Group	Textblocks

©2023 All Rights Reserved.

2

The Allegro PCB Editor Database User Model

Overview

This chapter describes each AXL database object type, listing each type's attributes and relationships to other object types.

Object Types

- Figure objects
  - Arcs (Table 2-3 on page 90)
  - Branches (Table 2-4 on page 90)
  - Design Files (Table 2-5 on page 91)
  - DRCs (Table 2-6 on page 92)
  - Lines (Table 2-12 on page 95)
  - Paths (Table 2-15 on page 102)
  - Polygons (Table 2-17 on page 104)
  - Pins (Table 2-16 on page 103)
  - Shapes (Table 2-19 on page 105)
  - Symbols (Table 2-20 on page 108)
  - Tees (Table 2-22 on page 109)
  - Vias (Table 2-24 on page 110)
  - Pads (Table 2-13 on page 97)
  - Padstacks (Table 2-14 on page 98)

©2023 All Rights Reserved.

- Symdefs (Table 2-21 on page 109)

- Logical objects
  - Components (Table 2-27 on page 112)
  - Functions (Table 2-29 on page 113)
  - Function Pins (Table 2-30 on page 114)
  - Nets (Table 2-32 on page 115)
- Property dictionary objects (Table 2-42 on page 123)
- Parameter objects
  - Design (Table 2-45 on page 126)
  - Display (Table 2-46 on page 127)
  - Layer Group (Table 2-48 on page 128)
  - Layer (Table 2-49 on page 129)
  - Textblock Group (Table 2-50 on page 130)
  - Textblock (Table 2-51 on page 130)

Description of Database Objects

Although a database object type can have dozens of attributes, you need only learn the semantics of a few attributes to get useful information from the Allegro PCB Editor database. Requesting an attribute not applicable to an object, or a property not existing on the object, causes the access function to return `nil`.

AXL Database Rules

The Allegro PCB Editor database interacts with AXL functions as specified in the following rules. Changes to the Allegro PCB Editor database made using AXL functions can affect both the database references (*`dbids`*) and the attributes of the Allegro PCB Editor database objects that the AXL program has already accessed.

- Invoking the `axlShell` function or editing a new Allegro PCB Editor database invalidates all *`dbids`*.

  Accessing the object's attributes with an out-of-scope *`dbid`* yields unreliable values. The `axlDBRefreshId` function returns `nil` for any out-of-scope *`dbid`*.

©2023 All Rights Reserved.

- An AXL function that modifies one attribute of an object may cause a related attribute of that object to become out-of-date.

  A parent's attribute may become out-of-date when you modify one of its children's attributes. For example, changing path width might affect the bounding box attribute of both a child and its parent.

- Operations you perform on an object affect the attributes of other objects if they refer to the changed object either directly or indirectly.

  An example of direct reference is deleting a segment from a path. An example of indirect reference is changing the width of a single segment in a path. These can cause `isSameWidth` to be incorrect.

- Accessing an out-of-date *`dbid`* does not cause the AXL program to crash or corrupt the Allegro PCB Editor database.

- The AXL function, `axlDBRefreshId`, updates an object.

  AXL does not update objects asynchronously.

- Allegro PCB Editor maintains properties across operations for all objects that support properties.

- DRC objects are volatile.

  By changing Allegro PCB Editor database objects, you can create or destroy DRCs.

  You cannot *directly* change a DRC object.

The following Allegro PCB Editor rule for treating non-etch figures applies only to paths or path segments:

- Path *`dbids`* on non-etch layers are more stable than those on etch layers.

  Deleting a segment from a path breaks the segment into two paths with separate *`dbids`*. Non-etch paths never merge, even if they touch.

The Allegro PCB Editor database treats etch figures differently from non-etch figures. The following are the etch figure rules. Figure 2-1 on page 86 shows the connectivity model used by Allegro PCB Editor.

- Path, line and arc *`dbids`* are volatile on etch layers.

  Allegro PCB Editor merges and breaks these objects to maintain connectivity.

- Deleting a segment from a path so it detaches from a pin, via, tee, or shape causes the etch to be classed as *floating*.

©2023 All Rights Reserved.

That means the etch is not a member of any net. A floating etch has a `nil` netname.

- Tees and branches are volatile.

  Changes in paths or path segments can cause tees to disappear or branches to combine or break into multiple branches.

Figure 2-1 Allegro PCB Editor Connectivity Model

Connection of three or more paths, added and removed as needed

Can be deleted by ripup or glossing operations

The net attribute on paths, vias and tees changes due to connectivity to pins and shapes.

Paths, lines and arcs can be broken, merged, or can change parent with the modification (add, delete or modify) of any etch object.

* The “net” attribute is an empty string ""for all figures that are on a dummy net.

©2023 All Rights Reserved.

Data Types

AXL database objects can have the following data types:

Type	Meaning
bbox	Boundary box (list of two points, lower left and upper right of a rectangular area that encloses the object)
integer	Signed integer number
float	Floating-point number
string	A string. For attributes with a list of possible string values, the attribute description lists the allowed values.
t/nil	Either true (`t`) or false (`nil`)
dbid	Allegro PCB Editor object identifier
l_dbid	List of *`dbids`*
point	A point—a list of two floats denoting a coordinate pair
l_propid	A list of properties accessed by `axlDbGetProperties`
l_fill	`t` = solid; `nil` = polygon; *`r_fill`* = crosshatch type

©2023 All Rights Reserved.

Generic Allegro PCB Editor Object Attributes

The following attributes are generic to all Allegro PCB Editor database objects. All Allegro PCB Editor database objects have at least these attributes.

Table 2-1 Generic Object Attributes

Attribute Name	Type	Description
objType	string	Name of the object type
prop	propid	Attached properties
parentGroups	l_dbid	List of groups to which the object belongs
readOnly	`t`/`nil`	`t` = can modify object directly **Note:** Except for parameter dbids all other objects are readOnly=nil. This means they cannot be modified via "dbid->object = value".

`propid` refers to properties attached to the object. When a *`dbid`* is returned to an AXL program, the properties attached to that object are not immediately returned. You access the property value by referencing the property name via the prop attribute. The `axlDBGetProperties` function returns the property names/value pairs as an “assoc” list to allow easier processing by applications.

©2023 All Rights Reserved.

Figure Database Types

Figures, in Allegro PCB Editor, also share a common set of attributes. However, “figure” is not actually an attribute of any object. Table 2-2 on page 89 lists the common figure attributes. In Allegro PCB Editor, figures are sometimes called geometries.

Among other attributes, figures have a bounding box called *bBox*. *bBox* is an orthogonal rectangle that defines the geometrical extents of the figure.

Table 2-2 Common Figure Attributes

Attribute Name	Type	Description
bBox	bbox	Figure’s bounding box
branch	dbid	For etch, the figure’s branch parent
layer	t_layer	Layer of figure, `nil` if object is multi-layer
parent	dbid	Nonconnective owner
net	dbid	Net object if figure is associated with a net

Note: The *"net"* attribute is an empty string `""` for all figures that are on a dummy net.

©2023 All Rights Reserved.

Attributes for Each Figure Type

The following tables list the attributes specific to each Allegro PCB Editor object type. The Common Figure attributes (see Table 2-2 on page 89) and the Generic Allegro PCB Editor Object attributes (see Table 2-1 on page 88) also apply to these figure types.

The tables are in alphabetical order by figure type name. The attributes in each table are in alphabetical order by attribute name.

Table 2-3 Arc Attributes Single arc cline or line in Allegro

Attribute Name	Type	Description
Also includes generic object and figure attributes		
isCircle	t/nil	`t` = circle; `nil` = unclosed arc
isClockwise	t/nil	`t` = clockwise; `nil` = counterclockwise
isEtch	t/nil	`t` = a CLINE; `nil` = a LINE
objType	string	Type of object, in this case `"arc"`.
parent	dbid	Path, polygon or shape
startEnd	l_point	Start and end points of arc
width	float	Width of line
font	symbol/nil	Line font, etch and solid is `nil`.
		Other types are `'HIDDEN 'PHANTOM 'DOTTED 'CENTER`
xy	point	Location of arc center

Table 2-4 Branch Attributes

Attribute Name	Type	Description
Also includes generic object and figure attributes		
children	l_dbid	List of *`dbids`* of the objects that make up branch: paths, tees, vias, pins and shapes
objType	string	Type of object, in this case `"branch"`
parent	dbid	Always `nil`

©2023 All Rights Reserved.

Table 2-5 Design Attributes Represents the design root, axlDBGetDesign()

Attribute Name	Type	Description
Also includes generic object and figure attributes		
bus	l_dbid	List of busses
compdefs	l_dbid	List of component definitions
components	l_dbid	List of components
designOutline	dbid	Design outline shape/rect, `nil` if none (layer BOARD GEOMETRY/DESIGN_OUTLINE)
diffpair	l_dbid	List of differential pairs
drcs	l_dbid	List of non-waived DRCs
drcState	symbol	State of DRC `t` = up to date `nil` = out-of-date `batch` = batch out-of-date
ecsets	l_dbid	List of Electrical Csets
groups	l_dbid	List of groups
keepinPlace	dbid	Place shape/rect keepin, `nil` if none (layer PACKAGE KEEPIN/ALL)
keepinRoute	dbid	Route shape/rect keepin, `nil` if none (layer ROUTE KEEPIN/ALL)
matchgroup	l_dbid	List of match groups in the design
module	l_dbid	List of module instances in the design
nets	l_dbid/nil	List of nets
netclass	l_dbid	List of netclass constraints group
netgroup	l_dbid	List of netgroups in the design
objType	string	Type of object, in this case `"design"`
region	l_dbid	List of regions
padstacks	l_dbid	List of padstacks
pins	l_dbid	If a `.dra`, list of pins, else `nil`
symbols	l_dbid	List of symbol instances

©2023 All Rights Reserved.

Table 2-5 Design Attributes, *continued* **Represents the design root, axlDBGetDesign()**

Attribute Name	Type	Description
symdefs	l_dbid	List of symbol definitions
text	l_dbid	List of unattached text in design. These are not associated with any other object.
waived	l_dbid	List of waived DRCs
xnet	l_dbid	List of Xnets (no nets with VOLTAGE property)
zone	l_dbid	List of zones (only for Rigid-Flex designs)

Table 2-6 DRC Attributes

Attribute Name	Type	Description
Also includes generic object and figure attributes		
actual	string	Actual value (user units)
expected	string	Expected value (user units)
fixed	t/nil	`t` = Allegro PCB Editor generated DRC `nil` = user defined DRC
name	string	Name of constraint that was violated
objType	string	Type of object, in this case `"drc"`
parent	dbid	Design *`dbid`*
source	string	DRC source (property or constraint set name)
type	string	Domain of DRC, values can be: ■ "NET SPACING CONSTRAINTS" ■ "PHYSICAL CONSTRAINTS" ■ "DESIGN" ■ "NET ELECTRICAL CONSTRAINTS" ■ "SAME NET CONSTRAINTS" ■ "EXTERNAL REFERENCE"

©2023 All Rights Reserved.

Table 2-6 DRC Attributes

Attribute Name	Type	Description
violations	l_dbid	List of figures causing error (2 max)
waived	t/nil	`t` = waived DRC `nil` = regular
xy	point	Location of DRC marker

Table 2-7 FUNCDEF Attributes: Function definition (logic element) Component definition has a list of funcdef (functions)

Attribute Name	Type	Description
Also includes generic object attributes		
objType	string	"funcdef"
parent	dbid	compdef (Component Definition)
pins	l_dbid	list of funcdefPin (Function definition pins)
slot	string	Name of Slot (function def name)
type	string	Type of function

Table 2-8 FUNCDEFPIN Attributes: Function definition pin (logic element)

Attribute Name	Type	Description
Function definition has a list of these pins each with point has a link to the component def pin		
Also includes generic object attributes		
objType	string	`"funcdefPin"`
parent	dbid	pin (component pin definition)
name	string	Name of the pin
swapCode	integer	The swap code (pins with common codes can be swapped)
use	string	Use of pin (for example, UNSPEC)

©2023 All Rights Reserved.

Table 2-9 FIGURE Attributes

Attribute Name	Type	Description
Also includes generic and figure object attributes		
corners	string	Rnd Rect and Rect pad only: corners chamfered, dash separated: ■ UR – upper right ■ UL – upper left ■ LR – lower right ■ LL – lower left ■ `nil` if pad type does not support
drillChar	string	drill characters (max 3)
figureName	string	figure type
fill	t/nil	is figure filled (usually `t`)
inside	float	Donut pad only: inside diameter, 0 otherwise **Note:** Outside diameter needs to be obtained form the bBox attribute (maxX - minX);
height	float	height of figure
objType	string	"figure"
radius	float	Rnd Rect and Rect pad only: corner radius, 0 otherwise
rotation	float	rotation absolute
width	float	width of figure
xy	point	Figure placement location

©2023 All Rights Reserved.

Table 2-10 Group Attributes Groupings of Allegro Objects

Attribute Name	Type	Description
Also includes generic object attributes		
groupMembers	l_dbid	List of members of the group
name	string	Name of the group
objType	string	Type of object, in this case `"group"`
type	string	Predefined group type. **Note:** This cannot be defined in SKILL. User-defined groups are considered “GENERIC.”

Table 2-11 Module Attributes Module instance in design

Attribute Name	Type	Description
Also includes generic object attributes		
bBox	bBox	Bounding box of all physical members of group
groupMembers	l_dbid	List of members of the module
name	string	Name of the module
objType	string	Type of object, in this case `"group"`
placeReplicate	t/nil	`t` if module is from Place Replicate, `nil` if a basic module
type	string	“`MODULE`”

Table 2-12 Line Attributes Cline and line of Allegro objects

Attribute Name	Type	Description
Also includes generic and figure object attributes		
isEtch	t/nil	t = a CLINE; `nil` = a LINE
lineType	s_type	a symbol: horizontal, vertical, odd
objType	string	Type of object, in this case `"line"`

©2023 All Rights Reserved.

Table 2-12 Line Attributes, *continued* **Cline and line of Allegro objects**

Attribute Name	Type	Description
parent	dbid	Path, polygon, or shape
startEnd	l_point	Start and end points
thermal	t/nil	Cline is a thermal relief.
width	float	Width of line
font	symbol/nil	Line font, etch and solid is nil.
		Other types are 'HIDDEN 'PHANTOM 'DOTTED 'CENTER

©2023 All Rights Reserved.

Table 2-13 Pad Attributes

Attribute Name	Type	Description
Also includes generic object and figure attributes		
bBox	bBox	Bounding box. Coordinates are always relative.
figure	lr_path	List of *r_paths* defining pad's boundary *lr_path* always contains at most one *r_path* `nil` denotes a null pad
figureName	string	Type of pad figure. Examples are "CIRCLE", "SQUARE", "SHAPE", "NULL". May be nil if drill. Use axlPadFigureTypes() to obtain list of figures
flash	string	If of type `FLASH`, name of flash symbol otherwise an empty string "" (Obsolete; use name attribute)
layer	string/ symbol	Pad layer For regular layers and mask layers this is a string. For composite, internal, adjacent, backdrill layers this is a symbol
name	string	If type is a `SHAPE` or `FLASH`, name of symbol.
objType	string	Type of object, in this case `"pad"`
offset	l_point	Offset of pad (relative to pin/via origin)
parent	dbid	Padstack *dbid*
readOnly	t	Cannot be modified.
type	string	Pad type is one of: `REGULAR`, `ANTI`, `THERMAL`, `or KEEPOUT`
sides	int	Octagon pad only: Number of sides, 0 otherwise Ranges between 6 and 64 as an even integer.
inside	float	Donut pad only: inside diameter, 0 otherwise **Note:** Outside diameter needs to be obtained form the bBox attribute (maxX - minX);

©2023 All Rights Reserved.

Table 2-13 Pad Attributes

Attribute Name	Type	Description
radius	float	Rnd Rect and Rect pad only: corner radius, 0 otherwise
corners	string	Rnd Rect and Rect pad only: corners chamfered, dash separated: ■ UR - upper right ■ UL - upper left ■ LR - lower right ■ LL - lower left nil if pad type does not support

Table 2-14 Padstack (PPin/Via Definition) Attributes

Attribute Name	Type	Description
Also includes generic object and figure attributes		
definition	o_dbid	(see isPadRef) Points to padstack definition if this is padReference otherwise `nil`
derived	string	if a derived padstack name of original padstack, else `nil`
drillChar	string	drill characters (max 3)
drillDiameter	float	Drill hole diameter (0 if slot)
drillSizeWidth	float	width of slot, diameter if hole and extents of multidrill
drillSizeHeight	float	height of slot, diameter if hole and extents of multidrill
drillSize	string	Name of drill to use (optional)
drillOffset	point	offset of drill hole
drillFigureName	string	type of drill symbol (circle, square, and so on.
drillFigureWidth	float	Width of drill symbol (for slots same as drillSizeWidth)

©2023 All Rights Reserved.

Table 2-14 Padstack (PPin/Via Definition) Attributes, *continued*

Attribute Name	Type	Description
drillFigureHeight	float	Height of drill symbol (for slots same as drillSizeHeight)
drillNonStandard	string	Type of drill (`nil` is standard) (*not supported by slots*)
drillToolSize	string	Description of actual drill. This field was introduced in 17.0 to describe the drill used. It should NOT be treated as a number. Is optional and may be an empty string.
holeCounterAngle	integer	If counter sink reports angle of sink with range 0 to 90.
holeCounterDepth	float	If counter bore report depth of sink in user units. This is maintained with an accuracy greater than the design
holeCounterDiameter	float	Diameter of counter bore/sink in user units
holeCounterTolerance	l_float	If counter bore/sink a list of two design units reporting the + and - tolerance of bore/sink
holeCounterType	string	If counter bore reports "bore" If counter sink reports "sink" else is nil
holeTolerance	l_float	A list of two deign units reporting the + and - drill hole tolerance. If a slot this is the 'X' or NC routing distance tolerance.
holeToleranceY	l_float	If slot is list of two design units reporting the + and - 'Y' drill hole tolerance. This is the routing drill tolerance.
multiDrillData	l_values	If not multidrill then `nil` otherwise list of: (`rows columns clearanceX clearanceY staggered`) Both clearances are in `dbreps` and staggered is `t/nil`
holeType	string	Type of hole (circle_drill, oval_slot, and so on.)

©2023 All Rights Reserved.

Table 2-14 Padstack (PPin/Via Definition) Attributes, *continued*

Attribute Name	Type	Description
keepout	nil	This is obsolete for 17.0. Use routekeep layer for padstacks
isPadRef	t/nil	`t` = padstack is a padstack reference. This means that the actual padstack is a template and the start and end layers of the padstack are dynamically mapped, depending upon its use with a pin or a via.
isThrough	t/nil	`t` = through padstack
name	string	Padstack name
objType	string	Type of object, in this case `"padstack"`
pads	l_dbid	List of pads
parent	dbid	Design
padSuppresion	t/nil	Does padstack have Pad Suppression enabled. This is for the legacy artwork based pad suppression. The dynamic pad suppression ignores this option.
plating	string	One of "Plated" or "Non-Plated". In 17.0 "Plating-Optional" is obsolete.
pluralVia	t/nil	is padstack marked as a plural (multi-net) compatible padstack
prop	l_dbid	Padstack's properties
spanLockCount	integer	Reports non-zero if padstack will not expand, if new layers are added or deleted. 0 if padstack will expand (this is the default). In the future, this may report the number of layers the padstack covers in lock layer span mode.
startEnd	lt_layer	Start and end layer of padstack

©2023 All Rights Reserved.

Table 2-14 Padstack (PPin/Via Definition) Attributes, *continued*

Attribute Name	Type	Description
type	string	Type of padstack; valid values are: ■ through ■ smd ■ bbvia ■ uvia **Note:** Kept for backward compatibility; you should migrate to usage field
usage	usage	Usage of pad. Superset of type. Valid values are: ■ through ■ smd ■ bbvia ■ uvia ■ die_pad_legacy ■ through_pin ■ surface_pin ■ through_via ■ die_pad ■ bond_finger ■ fiducial ■ slot ■ mechanical_hole ■ tooling_hole ■ mounting_hole
uvia	t/nil	A sub-type of bbvias, to differentiate in constraint system.

©2023 All Rights Reserved.

Table 2-14 Padstack (PPin/Via Definition) Attributes, *continued*

Attribute Name	Type	Description
Backdrill Data: These attributes are nil, until set		
backdrillDiameter	float	Diameter of backdrill
backdrillFigureName	string	type of drill symbol (circle, square, and so on.)
backdrillFigureChar	string	Backdrill characters (max of 3)
backdrillFigureHeight	float	Height of backdrill figure
backdrillFigureWidth	float	Width of backdrill figure
Note: axlDBGetPad can be utilize to more easily query pad layer data.		

Table 2-15 Path Attributes Path clines or lines in Allegro

Attribute Name	Type	Description
Also includes generic object and figure attributes		
branch	dbid/nil	Branch owner
hasArcs	t/nil	`t` = path has one or more arcs
isSameWidth	t/nil	`t` = all segments in path have the same width
isEtch	t/nil	t = a CLINE; nil = a LINE
nSegs	integer	Number of segments in path
objType	string	Type of object, in this case `"path"`
parent	dbid	owner (Branch, symbol, shape)
segments	l_dbid	List of arc and line figures in this path
symbolEtch	dbid	Symbol owner if etch.
startEnd	lt_layer	If bond-wire start and end layers; `nil` if not bondwire. If bondwire has a disconnected end, then the start and/or end will be `nil`

©2023 All Rights Reserved.

Table 2-16 Pin Attributes Pin (board and symbol editors) (generic and figure elements)

Attribute Name	Type	Description
Also includes generic object and figure attributes		
bondpad	class/ subclass	name of pad if pin is a bond pad (for example, "ETCH/BOND_TOP"), otherwise `nil`
branch	dbid/nil	Branch owner
component	dbid/nil	Component owner of pin `nil` if unassigned symbol pin
definition	dbid/nil	Padstack definition `nil` if unplaced component pin
fixedByTestPoint	t/nil	OBSOLETE - kept for backwards compatibility. Use `axlDBIsFixed(<dbid>)` or `axlDBControl(?testPointFixed)` instead.
functionPins	l_dbid/nil	List of function pins `nil` if unassigned symbol pin
isExploded	t/nil	`t` = pin is instance edited
isMech	t/nil	`t` = pin is mechanical
isMirrored	t/nil	`t` = pin is mirrored
isThrough	t/nil	`t` = pin is a throughhole
mirrorType	string	Type of mirror.
name	string	Padstack name of this pin `nil` if unplaced component pin
number	string	Pin number
objType	string	Type of object, in this case `"pin"`
pads	l_dbid	Unordered list of pads.[1] To access a particular pad, use `axlDBGetPad()`.

©2023 All Rights Reserved.

Table 2-16 Pin Attributes, *continued*Pin (board and symbol editors) (generic and figure elements)

Attribute Name	Type	Description
parent	dbid	`dbid` of symbol owning this pin[2] `nil` if pin is standalone (as it is in a symbol drawing)
relRotation	float	Pin rotation (relative to symbol)
relxy	point	Location (relative to symbol)
rotation	float	Pin rotation (absolute)
startEnd	lt_layer	Range of layers spanned by pin[2]
testPoint	t_layer/nil	`t_layer`, denotes layer of testpoint `nil` = pin is not a testpoint
use	string	Pin use as shown by show element
xy	point	Location of pin in absolute coordinates

May be `nil` if component is unplaced.
Will say etch/(unknown) if unplaced component.

Note: Ppins straddle the line between physical and logical elements. They have attributes that are conditional on their owners. If the padstack definition is `nil`, then the pin is purely logical. If the component attribute is `nil`, then the pin is purely physical. If both are non-`nil`, then the pin is fully instantiated.

Table 2-17 Polygon Attributes

Attribute Name	Type	Description
Also includes generic object and figure attributes		
area	float	Area of the polygon in drawing units.
bBox	bBox	Bounding box.
holes	list	List of `o_polygons`.
isHole	t/nil	`t` = polygon is a hole
isRect	t/nil	`t` = polygon is a rectangle
nSegs	integer	Number of segments in polygon

©2023 All Rights Reserved.

Table 2-17 Polygon Attributes, *continued*

Attribute Name	Type	Description
objType	string	Type of object, in this case `"polygon"`
parent	dbid	Symbol, shape (for voids), or `nil`
segments	l_dbid	Path describing boundary of shape. Boundary consists of line and arc segments.
symbolEtch	dbid	Symbol owner if etch
vertices	list	Outer boundary available as a list containing a point, which is the vertex of a polygon, and a floating point number, which is the radius of the edge from the previous to the present vertex.

Table 2-18 Rat_T Attributes Rat_T (figure element)

Attribute Name	Type	Description
Also includes generic object and figure attributes		
name	string	Name of T to T-<n>
net	dbid	Net of Rat-T
objType	string	Type of object, in this case `"rat_t"`
parent	dbid	Net
xy	point	Location of T

Table 2-19 Shape Attributes Shapes or rectangles in Allegro

Attribute Name	Type	Description
Also includes generic object and figure attributes		
autoKeepoutType	string	If shape is a route keepout and derived from a padstack. This indicates type (adjacent_rko, backdrill_rko or same_layer_rko)
autoObject	dbid	If this a an auto-generated route keepout this shows the pin or via that generated it.
bBox	bBox	Bounding box

©2023 All Rights Reserved.

Table 2-19 Shape Attributes, *continued*Shapes or rectangles in Allegro

Attribute Name	Type	Description
cavity	t/nil	If a boundary shape is for cavity generation (embedded design). Cavity shapes are generated automatically based on the rki.
children	l_dbid	Used when a Boundary Shape points to a list of dynamic shapes
fill	g_fill	
		`t` = filled; `nil` = unfilled
		(axlFillType axlFillType) - xhatch
		Each `axlFillType` has spacing width, origin, and angle.
fillet	t/nil	shape is a fillet (teardrop)
fillOOD	t/nil	Dynamic fill is out of date.
		`t` = shape needs fill updating (Only dynamic shapes can be `t`)
		`nil` = shape does not refill
voids	list	List of o_polygons
isHole	t/nil	`t` = polygon is a hole
isRect	t/nil	`t` = polygon is a rectangle
nSegs	integer	Number of segments in polygon
objType	string	Type of object, in this case `"shape"`
parent	dbid	Branch (if etch shape), Symbol, shape (for voids)
		`nil` = no parent

©2023 All Rights Reserved.

Table 2-19 Shape Attributes, *continued***Shapes or rectangles in Allegro**

Attribute Name	Type	Description
priority	integer/nil	If shape is a dynamic shape boundary this is an integer voiding priority. For all other shapes this is `nil`. The priority is relative to other dynamic shapes on the same layer. If two dynamic shapes are coincident, the shape with the higher priority wins in voiding. This number is re-calculated as needed, so use only for comparison purposes.
region	l_dbid/nil	Region owner if a region shape.
segments	l_dbid	Path boundary of shape
shapeAuto	l_dbid/nil	If dynamic shape list of generated shapes on the matching auto-gen ETCH or CAVITY layer
shapeBoundary	dbid/nil	If this shape is generated from a dynamic shape, this points to that shape. Boundary shapes may either be used for ETCH or CAVITY (see state of cavity attribute)
shapeIsBoundary	t/nil	This shape is a dynamic shape, for example, on BOUNDARY class.
taper	t/nil	shape is used for tapering
dynamicGroup	t/nil	If this a dynamic shape (BOUNDARY class) return its dynamic group object. This is where voiding instance overrides are stored.
symbolEtch	dbid	Symbol owner, if etch
vertices	list	outer boundary available as a list containing a point (vertex of a polygon) and a floating point number (radius of the edge from the previous to the present vertex).

Note: You cannot manipulate (move, add property, delete and more) auto-generated shapes (shapeBoundary != nil). You should modify the dynamic shape (shapeBoundary). You can use `axlSetFindFilter` to set the find filter to auto-select the boundary shape when the user selects one of the auto-generated children.

©2023 All Rights Reserved.

Table 2-20 Symbol Instance Attributes symbol

Attribute Name	Type	Description
Also includes generic object and figure attributes		
children	l_dbid	attached objects. This is non-etch data. Pins and pin escapes are pins and etchChildren respectively.
component	dbid	Component instance associated with symbol (`nil` if no component)
definition	dbid	Symbol definition
isMirrored	t/nil	`t` = symbol is mirrored
mirrorType	string	specific mirror type in use (YES, NO or GEOMETRY (APD+ only).
name	string	Symbol name
objType	string	Type of object, in this case `"symbol"`
parent	dbid	Design (no other parent possible for symbols)
pins	l_dbid	List of pins
refdes	string/nil	Reference designator nil if no associated component (for example, mechanical)
rotation	float	Symbol rotation
type	string	Symbol type is one of: `PACKAGE`, `MECHANICAL`, `FORMAT`, `SHAPE`,`FLASH or DRAFTING`
xy	point	Symbol location
embedded	t/nil	symbol placed on embedded layer
embeddedLayer	string	layer of placed symbol or `nil` if external
embeddedMethod	string	method (CHIP_UP or CHIP_DOWN)
embeddedAttach	string	attachment method (DIRECT_ATTACH or INDIRECT_ATTACH)
etchChildren	l_dbid	does symbol have attached etch (typically pin escapes or shapes)

©2023 All Rights Reserved.

Table 2-20 Symbol Instance Attributes, *continued* **symbol**

Attribute Name	Type	Description
fixedByTestPoint	t/nil	OBSOLETE - kept for backwards compatibility. Use `axlDBIsFixed(<dbid>)` or `axlDBControl(?testPointFixed)` instead.
layer	string	Placement layer (applies to zones and surface placement)
zone	dbid	placement zone (nil if no zones). Zone name is zoneDbid->name

Table 2-21 Symdef (Symbol Definition) Attributes

Attribute Name	Type	Description
Also includes generic object and figure attributes		
bBox	bBox	bounding box Because a symdef s not placed the center point of the box is 0,0
children	l_dbid	List of children making up symbol
instances	l_dbid	List of symbol instances using this symbol
name	string	Name of symbol definition
objType	string	Type of object, in this case `"symdef"`
parent	dbid	Design root
pins	l_dbid	List of pins
type	string	Symbol type is one of the following: `PACKAGE`, `MECHANICAL`, `FORMAT`, `SHAPE, or FLASH`

Table 2-22 Tee Attributes

Attribute Name	Type	Description
Also includes generic object and figure attributes		
branch	dbid	Branch owner

©2023 All Rights Reserved.

Table 2-22 Tee Attributes, *continued*

Attribute Name	Type	Description
objType	string	Type of object, in this case `"tee"`
parent	dbid	Branch
readOnly	t	User cannot directly modify
xy	point	Location

Table 2-23 Text Attributes Text in Allegro

Attribute Name	Type	Description
Also includes generic object and figure attributes		
isMirrored	t/nil	`t` = text mirrored
justify	string	`"left"`, `"right"` or `"center"`
mirrorType	string	Type of mirror.
objType	string	Type of object, in this case `"text"`
parent	dbid	Symbol or `nil`
rotation	float	Rotation angle
text	string	The text itself
textBlock	string	Text block type
xy	point	Location of text origin

Table 2-24 Via Attributes Via (board and symbol editors) (figure element)

Attribute Name	Type	Description
Also includes generic object and figure attributes		
branch	dbid/nil	Branch owner
definition	dbid	Padstack definition
fixedByTestPoint	t/nil	OBSOLETE- kept for backwards compatibility. Use `axlDBIsFixed(<dbid>)` or `axlDBControl(?testPointFixed)` instead.

©2023 All Rights Reserved.

Table 2-24 Via Attributes, *continued* **Via (board and symbol editors) (figure element)**

Attribute Name	Type	Description
isMirrored	t/nil	`t` = via mirrored
isThrough	t/nil	`t` = via is a through hole padstack
mirrorType	string	specific mirror type in use ("YES" "NO" "GEOMETRY"). Geometry indicates via is mirrored on same layer. Applies only APD+.
net	dbid/nil	net dbid

relations	list	List of relations of via
		Currently supports return path capability
		Format is one of the following:
		`nil`
		`('ground l_dbidVia)`
		`('signal l_dbidVia)`

name	string	"VIA"
objType	string	Type of object, in this case `"via"`
pads	l_dbid	Unordered list of pads. To access a specific pad, use `axlDBGetPad`.
pluralVia	t/nil	is via a plural via (Multi-net)
pluralViaConnect	t/nil	is via a plural connect via (Multi-net)
parent	dbid	Typically the branch
rotation	float	Via rotation
symbolEtch	dbid/nil	If part of a symbol the symbol dbid
testPoint	t_layer/nil	t_layer denotes layer of testpoint
xy	point	Location of via

©2023 All Rights Reserved.

Logical Database Types

Allegro PCB Editor logical database objects have these generic attributes (see Description of Database Objects on page 84): objType, prop, and readOnly. Logical database objects do not have other attributes in common. The tables below list the attributes for each Allegro PCB Editor logical type.

Table 2-25 Bus Attributes (logic element)

Attribute Name	Type	Description
Also includes generic object attributes		
groupMembers	l_dbid	List of xnets of the bus
name	string	Name of the bus
objType	string	“`group`”
type	string	“`BUS`”
lock	t/nil	Is membership locked for editing (vector buses)

Table 2-26 Compdef Attributes Component Definitions (logic element)

Attribute Name	Type	Description
Also includes generic object attributes		
class	string	Component classification
components	l_dbid	List of component instances of this definition.
deviceType	string	Device type of the component
functions	l_dbid	List of functions.
objType	string	Type of object, in this case `"compdef"`
pins	l_dbid	List of pins comprising the component.

Table 2-27 Component Attributes Component instances (logic element)

Attribute Name	Type	Description
Also includes generic object attributes		

©2023 All Rights Reserved.

Table 2-27 Component Attributes, *continued*Component instances (logic element)

Attribute Name	Type	Description
class	string	Component classification
compdef	dbid	dbid of component definition (`COMPDEF`)
deviceType	string	Device type of component (see `COMPDEF`)
functions	l_dbid	List of functions
name	string	Reference designator
objType	string	Type of object, in this case `"component"`
package	string	Package name
pins	l_dbid	List of pins comprising component
symbol	dbid/nil	*`dbid`* of the placed symbol of this component, `nil` if unplaced

Table 2-28 Diffpair Attributes (logic element)

Attribute Name	Type	Description
Also includes generic object attributes		
groupMembers	l_dbid	List of xnets of the differential pair
name	string	Name of the differential pair
objType	string	“`group`”
type	string	“`DIFF_PAIR`”
userDefined	t/nil	If you create `t`, can be modified. `Nil` indicates creation by SigNoise models and cannot be changed.

Table 2-29 Function Attributes

Attribute Name	Type	Description
Also includes generic object attributes		
name	string	Function designator

©2023 All Rights Reserved.

Table 2-29 Function Attributes, *continued*

Attribute Name	Type	Description
objType	string	Type of object, in this case `"function"`
parent	dbid	*`dbid`* of component owning this function
pins	l_dbid	List of function pins composing function
slot	string	Slot name
type	string	Function type

Table 2-30 Function Pin Attributes

Attribute Name	Type	Description
Also includes generic object attributes		
name	string	Function pin name
objType	string	Type of object, in this case `"functionPin"`
parent	dbid	*`dbid`* of function owning this pin
pin	dbid	Pin owner of function pin
swap code	integer	Swap code of function pin
use	string	Pin usage description, one of `UNSPECIFIED`, `POWER`, `GROUND`, `NC`, `LOADIN`, `LOADOUT`, `BI`, `TRU`, `OCA`, `OCL`

Table 2-31 MATCH_GROUP Attributes (logic element)

Attribute Name	Type	Description
Also includes generic object attributes		
groupMembers	l_dbid	List of xnets, nets and pinpairs making up this group.
name	string	Name of the match group.
objType	string	“`group`”
pinpair	l_dbid	List of pinpairs associated with xnet

©2023 All Rights Reserved.

Table 2-31 MATCH_GROUP Attributes (logic element)

Attribute Name	Type	Description
type	string	"`MATCH_GROUP`"

Note: For more information, see `axlMatchGroupCreate`.

Table 2-32 Net Attributes Net Definitions (logic element)

Attribute Name	Type	Description
Also includes generic object attributes		
branches	l_dbid	List of branches
name	string	Net name
bus	dbid	Bus dbid if part of a bus
nBranches	integer	Number of branches (when exactly one, net is fully connected) **Note:** Island shapes causes the count to be not one, even if all pins are connected.
objType	string	Type of object, in this case `"net"`
pinpair	l_dbid	List of pinpairs associated with net (`1`) **Note:** If a net is a member of an xnet, all pinpairs appear on the xnet.
ratsnest	l_dbid	List of ratsnest for net.
ratsnest On	t/nil	State of ratsnest display for the net.
ratT	l_dbid	List of rat_T's. If none exist, this is NULL.
rpd	l_rpd	List of lists for each member net of a match group (`mg_dbid t_relatePropDelay`). For more information, see `axlMatchGroupCreate`
isBundled	t/nil	`t` = net contains at least one bundled ratsnest.
scheduleLocked	t/nil	`t` = net schedule cannot be changed
unconnected	integer	Number of remaining connections. This does not include connections to unplaced symbols.

©2023 All Rights Reserved.

Table 2-32 Net Attributes, *continued* Net Definitions (logic element)

Attribute Name	Type	Description
unplaced	integer	Number of unplaced pins.

Note: If net is a member of an xnet then all pinpairs will appear on the xnet.

For more information on the rpd attribute see `axlMatchGroupCreate`.

Table 2-33 NETCLASS Attributes: NetClass objects for constraint grouping

Attribute Name	Type	Description
Also includes generic object attributes		
groupMembers	l_dbid	List of nets, xnets, buses or differential pairs.
name	string	Name of the net class
objType	string	"group"
type	string	"NETCLASS"
electrical	t/nil	If part of the electrical and same net domain
physical	t/nil	If part of the physical and same net domain
spacing	t/nil	If part of the spacing and same net domain

Note: A NetClass can be a member of one or more domains but its name must be unique across all domains.

Note: Constraint overrides can be added to netclass via properties.

Table 2-34 REGION Attribute: Region objects for constraint grouping

Attribute Name	Type	Description
Also includes generic object attributes		
groupMembers	l_dbid	List of constraint area shapes.
name	string	Name of the region
objType	string	"group"
type	string	"REGION"

©2023 All Rights Reserved.

Table 2-35 CLASS Table Attribute

Attribute Name	Type	Description
name	string	Name of ecset
netclass1	dbid	net class entry
netclass2	dbid	second net class entry (may be nil)
region	dbid	region class for table entry (may be nil)
physical	dbid	physical cset associated with entry or nil
spacing	string	spacing cset associated with entry or nil
sameNet	string	sameNet cset associated with entry or nil
assembly	string	physical assembly cset associated with entry (APD+ only)
objType	string	"classTable"
readOnly	t/nil	Cannot be modified
prop	l_dbid	List of properties on table entry. Typically where constraint overrides on entry exist. Also duplicates the cset names.

Note: These are the class-class, class-class-region and class-region constraint table entries. See `axlCnsClassTableCreate`.

Table 2-36 Pinpair Attributes (logic element)

Attribute Name	Type	Description
Also includes generic object attributes		
ecsetDerived	t/nil	If `t`, pinpair was created from an ECset. `Nil` indicates pinpair created due to net override property.
groupMembers	l_dbid	List of two pins making up pinpair.
name	string	Name of the pinpair (`<refdes>.<pin#>:<refdes>.<pin#>`)
objType	string	“`group`”
parent	l_dbid	Net or xnet owning the pinpair.

©2023 All Rights Reserved.

Table 2-36 Pinpair Attributes, *continued*(logic element)

Attribute Name	Type	Description
parentGroups	l_dbid	Lists match groups that have this pinpair. May also list other parent groups.
rpd	l_rpd	For each match group that has this pinpair as a member, will list as a list of lists. (`mg_dbid t_relatePropDelay`)
type	string	“`PIN_PAIR`”

Note: For nets that are part of an xnet, the pinpair always has the xnet as the pinpair owner. For more information on the rpd attribute, see `axlMatchGroupCreate`.

Table 2-37 NET_GROUP Attributes A net group

Attribute Name	Type	Description
Also includes generic object attributes		
groupMembers	l_dbid	members of the group (net_groups, nets, xnets, diff pairs, buses)
name	string	Name of group
objType	string	"group"
type	string	"NET_GROUP"
isInterfaceTop	t/nil	If `t`, group is the top of a definition-driven interface instance.

Note: Use `axlDBCreateGroup` family of commands to add, delete and modify these groups.

Table 2-38 PORT_GROUP Attributes Groupings of Allegro pin objects

Attribute Name	Type	Description
Also includes generic object attributes		
groupMembers	l_dbid	members of the group (port_groups, pins, function pins)
name	string	Name of group

©2023 All Rights Reserved.

Table 2-38 PORT_GROUP Attributes, *continued***Groupings of Allegro pin objects**

Attribute Name	Type	Description
objType	string	"group"
type	string	"PORT_GROUP"
isInterfaceTop	t/nil	If `t`, group is the top of a definition-driven interface instance.

Note: PORT_GROUPs are groupings of Allegro pin objects.

Table 2-39 ZONE Attributes Groupings of Allegro zone groups

Attribute Name	Type	Description
Also includes generic object attributes		
groupMembers	l_dbid	members of the group (shapes for region, keepout rooms). may have additional members in the future.
name	string	Name of zone
objType	string	"group"
type	string	"ZONE_GROUP"
region	string	name of region associated with zone (may be nil)
room	string	name of room associated with zone (may be nil)
shapeBoundary	l_dbid	boundary of zone (PRIMARY group is typically nil) Only one boundary dbid is supported.
stackup	string	name of stackup associated with zone (see axlXSectionGet)

Table 2-40 RATSNEST Attributes Ratsnest definitions (logic element)

Attribute Name	Type	Description
Also includes generic object attributes		
bus	t/nil	Currently being shown with bus routes option
objType	string	Type of object, in this case "ratsnest"
pinsConnected	t/nil	Ratsnest not displayed (both pins on the same branch)

©2023 All Rights Reserved.

Table 2-40 RATSNEST Attributes, *continued*Ratsnest definitions (logic element)

Attribute Name	Type	Description
pins	l_dbid	The two pins (or ratTs) that the rats connect
pwrAndGnd	t/nil	Net is power and ground scheduled
ratnest	l_dbid	Two dbids of the next ratsnest for dbid's of the pins attribute.
ratsPlaced	t/nil	User-defined rats only, one or more pins unplaced
userDefined	t/nil	Ratsnest is user-defined

Table 2-41 XNET Attributes eXtended Net (logic element)

Attribute Name	Type	Description
Also includes generic object attributes		
bus	dbid	Bus dbid if part of a bus.
diffpair	dbid	differential pair dbid if part of a differential pair.
groupMembers	l_dbid	List of nets of the xnet.
name	string	Name of the xnet.
objType	string	"`group`"
pinpair	l_dbid	List of pinpairs associated with xnet.
rpd	l_rpd	For each match group that has this xnet as a member, lists as a list of lists (`mg_dbid t_relatePropDelay`).
type	string	"`XNET`".

Note: This attribute can only be defined indirectly from the SigNoise model assignment.

For more information on rpd, see `axlMatchGroupCreate`.

Property Dictionary Database Types

The following section contains tables listing the attributes of Allegro PCB Editor property dictionary objects. You must enter a dictionary object with a particular name in the property dictionary before you attach properties by that name to Allegro PCB Editor objects.

©2023 All Rights Reserved.

Object Types Allowing Attachment of Properties

You can attach properties to the database object types listed here. Each property type has a list of the objects types to which it can be attached. Attempting to attach a non-qualified property to an object returns `nil`.

NETS	COMPONENTS	FUNCTIONS	PINS
VIAS	SHAPES	SYMBOLS	CLINES
LINES	DRCS	FIGURES	DESIGNS
COMPDEFS	PINDEFS	FUNCDEFS	

©2023 All Rights Reserved.

Allowed Property Data Types

An Allegro PCB Editor property value can be one of the data types listed. The right column shows the checks you can optionally apply to user input for that data type. Pre-defined properties have pre-defined range checks. You define your own range checks for user-defined properties.

Note: The right column includes default units for that property data type, however, you can set the units of these standard data types in the `<tools>/text/units.dat` file.

Data Type	Data Check Available (default units)
STRING	N/A
INTEGER	range and units
REAL	range and units
DESIGN_UNITS	range (units of current design)
BOOLEAN	N/A
ALTITUDE	range (meters)
CAPACITANCE	range (pF)
DISTANCE	range (cm)
ELEC_CONDUCTIVITY	range (mho/cm)
LAYER_THICKNESS	range (mil)
IMPEDANCE	range (ohm)
INDUCTANCE	range (nH)
PROP_DELAY	range (nS)
RESISTANCE	range (ohm)
TEMPERATURE	range (degC)
THERM_CONDUCTANCE	range (w/cm-degC)
THERM_CONDUCTIVITY	range (w/cm-degC)
VOLTAGE	range (mV)
VELOCITY	range (m/sec)

©2023 All Rights Reserved.

Table 2-42 Property Dictionary Attributes

Attribute Name	Type	Description
Also includes generic object attributes		
dataType	string	Data type for property value (see Allowed Property Data Types on page 122)
name	string	Name of property
objType	string	Type of object, in this case `"propDict"`
range	lf_range	Optional limits for value
units	string	Optional value units
useCount	integer	Number of objects using property. **Note:** This attribute is valid only for user-defined properties. For pre-defined Allegro PCB Editor properties, the useCount value will always be `0`.
write	t/nil	`t` = writable or user defined `nil` = read-only or Allegro PCB Editor pre-defined

Parameter Database Types

The following Allegro PCB Editor parameter types, which are critical to the function of interactive commands, are modeled:

- `drawing`
- `layer`
- `text block`
- `display`

Only drawing parameters support attached properties.

You can access and change parameters with `axlParamGetByName` and `axlSetParam`, respectively. See Chapter 3, "Parameter Management Functions" for functions that provide easier access to layers and other parameter objects.

©2023 All Rights Reserved.

Unlike other Allegro PCB Editor objects these attributes contain a column, `Set?`, that shows whether you can modify this field via the `axlSetParam` function.

Table 2-43 Artwork Parameter Attributes

Attribute Name	Type	Description
Includes no generic object attributes		
groupMembers	l_string	List of film names
nChildren	number	Number of films
objType	string	Type of object, in this case `"artwork"`

Table 2-44 Artwork Film Parameter Attributes

Attribute Name	Type	Description
Includes no generic object attributes		
domains	l_string	List of domains where film is visible. Supportedvaluesare`ipc2581`,`pdf`,`artwork`, and `visibility`.
drawHolesOnly	t/nil	For pins and vias draw only the holes.
drawMissingPadApertures	t/nil	Specifies the apertures you can use to draw (fillin) the shape of any pad for which there is no matching pad aperture in `art_aper.txt`. Not selecting this option means that you cannot draw such pads.
fullContact	t/nil	Applies to negative film. When `t`, a pin or via that is connected to a shape uses no flash, causing a solid mass of copper to cover the pad. When you do not select this field, a pin or via connected to a shape uses a thermal-relief flash.
groupMembers	l_string	List of layers comprising film
ipc2581	l_string	List of IPC2581 Layer mappings. Indicates where film should be used in IPC25281 output. Supported values are inner, outer, misc, doc, and soldermask.
mirrored	t/nil	Specifies whether to mirror the photoplot output.

©2023 All Rights Reserved.

Table 2-44 Artwork Film Parameter Attributes, *continued*

Attribute Name	Type	Description
name	string	Name of film
negative	t/nil	Is film positive (`nil`) or negative (`t`)
objType	string	Type of object, in this case "`artwork`"
offset	point	Specifies the x and y offset to add to each photoplot coordinate. If you enter positive x and y offsets, all photoplotted lines shift in the positive direction on the film.
rotation	integer	Rotation of the plotted film image. Choices are: `0`, `90`, `180`, and `270` degrees.
sequence	integer	Sequence number for PDF ordering. Range is 0 to 255. If two films share the same number, the database ordering determines ties.
shapeBoundingBox	float	Applies to negative film. Adds another outline around the design outline, extending the shape boundary of the filled area. This new artwork outline extends, by default, 100 mils in all directions beyond the design outline.
suppressShapeFill	t/nil	Area outside the shapes is not filled on a negative film. You must replace the filled areas with separation lines before running artwork.
suppressUnconnectPads	t/nil	Specifies that the pads of pins and vias with no connection to a connect line in a gerber data file are not plotted. This option applies only to internal layers and to pins whose padstack flags the pads as optional. Selecting this button also suppresses donut antipads in raster based negative artwork.
undefineLineWidth	float	Determines the width of any line that is 0.
useApertureRotation	t/nil	Specifies whether or not to use the aperture rotation raster. Artwork uses gerber behavior to determine which type of pad to flash.
vectorBasedPad	string	Extracts information about vector based pad behavior from the artwork control dialog box.

©2023 All Rights Reserved.

Table 2-45 Design Parameter Attributes

Attribute Name	Set?	Type	Description
Includes generic object attributes			
accuracy	no	integer	Number of decimal places of accuracy
bBox	no	bbox	The design's bounding box
height	no	float	Height in user units
objType	no	string	Type of object, in this case `"paramDesign"`
units	no	string	Type of user units (`mils`, `inch`, `micron`, `millimeter` and `centimeter`)
width	no	float	Width in user units
xy	no	point	Lower left corner of design

Notes:

- To avoid harmful side effects, such as rounding errors, do not toggle between English and metric.
- Changes to accuracy are very time consuming since all objects in the design must be changed.

  Setting drawing accuracy to a value greater than Allegro PCB Editor supports is an error. Typical range is 0 to 4.
- Change units and accuracy at the same time to avoid loss of accuracy.
- The size (width and height) may not be decreased where it will leave some objects outside of the drawing extents.

©2023 All Rights Reserved.

Table 2-46 Display Parameter Attributes

Attribute Name	Set?	Type	Description
Includes no generic object attributes			
activeLayer	yes	string	Active layer name
altLayer	yes	string	Alternative layer name which must be of group `"etch"`
objType	no	string	Type of object, in this case `"paramDisplay"`

Table 2-47 ECset Parameter Attributes Electrical Constraint Set (parameter element)

Attribute Name	Set?	Type	Description
Includes generic object attributes			
locked		t/nil	Cset locked from UI based editing
members		l_dbid	List of electrical constraints in set
name		string	Name of ECset
objType		string	Type of object, in this case `"ecset"`
prop		l_dbid	List of user-defined properties on ECset
readOnly		t/nil	Cannot be modified, always `t`
topology		t/nil	This is derived from a topology file, and may contain constraints that have restrictions on how they can be modified.

©2023 All Rights Reserved.

Figure 2-2 Allegro PCB Editor Class/Subclass to AXL Layer Model

Table 2-48 Layer Group Parameter Attributes (Allegro Classes)

Attribute Name	Set?	Type	Description
Includes no generic object attributes			
color	yes	integer	Layer color index; -1 if all child layers are not the same color
groupMember	no	l_string	List of subclasses belonging to this class
isEtch	no	t/nil	Is an etch layer
name		string	Name of this class
nChildren	no	integer	Number of subclasses in class
objType	no	string	Type of object, in this case `"paramLayerGroup"`
pattern	yes	integer	Pattern for layer; -1 if all child layers not the same pattern (see Layer Parameter Attributes (Allegro Subclasses) table on page 129)
visible	yes	t/nil	All subclasses of this class are visible

©2023 All Rights Reserved.

Table 2-49 Layer Parameter Attributes (Allegro Subclasses)

Attribute Name	Set?	Type	Description
Includes no generic object attributes			
color	yes	integer	Subclass color number
drcPhotoType	no	string	`"Positive"` or `"negative"` (applies only to etch)
isEtch	no	t/nil	Is an etch layer
material	NO	string	Layer material (etch only)
name	no	string	Name of this subclass
number	no	integer	Layer number, while this is reported for both etch and non-etch layers it is only meaningful for etch layers where it shows the stackup order.
nextLayer	no	string	Name of next layer in stackup (etch only)
objType	no	string	Type of object, in this case `"paramLayer"`
parentname	no	string	Name of owning class
pattern	yes	integer	Pattern of layer where 0 is default solid pattern. For maximum patterns, see axlColorGet('pattern). Pattern style for each pattern number can be found in the color192 dialog.
thickness	no	string	Layer thickness (etch only)
type	no	string	“Positive” or Negative (etch only)
userDefined	No	t/nil	Is layer user defined. User defined layers could have been added by the user. Note for etch layers — all are user-defined, but you typically cannot delete or rename the TOP or BOTTOM.
visible	yes	t/nil	All subclasses of this class are visible

Note: The Allegro PCB Editor class/subclass system is modeled in AXL as layers. The previous drawing figure shows how AXL layers are mapped to Allegro PCB Editor class/subclasses. The define etch form in Allegro PCB Editor does not match this model. AXL does not support access to the dielectric pseudo-layers nor does it support analysis layer attributes

©2023 All Rights Reserved.

such as material and thickness. To access these records, use Allegro PCB Editor's technology file feature.

Table 2-50 Textblock Group Parameter Attributes

Attribute Name	Set?	Type	Description
Includes no generic object attributes			
groupMembers	no	l_string	Names of members in this group
nChildren	no	integer	Number of children
objType	no	string	Type of object, in this case `"paramTextGroup"`

Table 2-51 Textblock Parameter Attributes

Attribute Name	Set?	Type	Description
Includes no generic object attributes			
charSpace	Yes	float	Spacing between characters in design units
height	Yes	float	Character height in design units (includes descender)
lineSpace	Yes	float	character line to line space in design units
name	no	string	Character block number
objType	no	string	Type of object, in this case `"paramTextBlock"`
photoWidth	Yes	float	character line width in design units
width	Yes	float	character width in design units

Table 2-52 Testprep Parameter Attributes

Attribute Name	Set?	Type	Description
Includes no generic object attributes			
allowUnderComp	yes	t/nil	Allows test pads under components.
autoInsert	yes	t/nil	Allows automatic generation of test points as needed.

©2023 All Rights Reserved.

Table 2-52 Testprep Parameter Attributes, *continued*

Attribute Name	Set?	Type	Description
bareBoard	yes	t/nil	If `nil`, you can only test component pins on non-component design side. If `t`, then you can check pins on either side of the design, as long as padstack is defined on that side.
directTest	yes	t/nil	Allows pins to be selected as test point.
executeInc	yes	t/nil	If `t`, returns in incremental mode where you can analyze only nets without test points. If `nil`, removes all test points at beginning of run.
layer	yes	symbol	Layer for test: `top`, `bottom` or `either`.
maxTestDisplacement	yes	float	Maximum distance from pin or via where you can place the test point.
minPadSize	yes	float	Minimum padstack size. Works with replaceVias to upscale padstacks.
minTestDisplacement	yes	float	Minimum distance from pin or via where you can place a test point. A value of 0 indicates DRC distance you should use.
minTestSpacing	yes	float	Minimum spacing between test points.
objectType	no	string	Type of object, in this case `"testprep"`
pinType	yes	symbol	Type of pin selectable for testing: `input`, `output`, `pin`, `via`, or `point`.
replaceVias	yes	t/nil	If `t`, replaces vias that are too small with a larger via.
testGridX	yes	float	Testprep grid.
testGridY	yes	float	Testprep grid.
testMethod	yes	symbol	Method used for test: `single`, `node`, or `flood`.
testPad	yes	nil/string	Padstack that you use for test pads on the probe side of the design. Must meet criteria specified in the *`testPadType`* attribute. If relative name is given, uses database then `PSMPATH` to find pad.

©2023 All Rights Reserved.

Table 2-52 Testprep Parameter Attributes, *continued*

Attribute Name	Set?	Type	Description
testPadDB	no	dbid	*dbid* of the testPad
testPadType	yes	symbol	Type of padstacks for probes: `smd`, `through`, or `either`.
testVia	yes	nil/string	Padstack that you use for testpads on the probe side of the design. Must be through hole. If relative name is given, uses database then `PSMPATH` to find pad.
testViaDB	no	dbid	*dbid* of testVia.
unusedPins	yes	t/nil	Allows test points on pins, not on a net.
	The following are Text Controls		
alpha	yes	t/nil	If `t`, use Alphabetic extension, `nil` use numeric extension.
displayText	yes	t/nil	Displays text for each test point.
textOffsetX	yes	float	X offset of text from pad center.
textOffsetY	yes	float	Y offset of text from pad center.
textRotation	yes	integer	Rotation of text labels: values are `0`, `90`, `180`, or `270` degrees. Other values are moduled and truncated.

Note: Specifying testVia or testPad loads them into the current database if they are not already loaded. Changing to another padstack does not delete the old padstack from the database.

Example

```
p = axlGetParam("testprep")
p->displayText = t
p->testMethod = 'flood
axlSetParam(p)
```

Turns on text display and sets test method to flood.

©2023 All Rights Reserved.

3

Parameter Management Functions

~~Overview~~This chapter describes the AXL-SKILL functions that retrieve and set Allegro database parameters. You can access certain Allegro parameters using these functions. Additional functions are built on top of `axlGetParam/axlSetParam` to make programming easier.

See Chapter 1, “Introduction to Allegro PCB Editor SKILL Functions,” for a description of available parameter attributes.

The use model follows:

- Get the parameter using `axlGetParam`.
- Modify the values using `axlSetParam`.
- Update the parameter using `axlSetParam`.

AXL-SKILL restricts you from creating new parameters or subclasses.

©2023 All Rights Reserved.

axlcreate – Obsolete

```
axlcreate
```

This interface is obsolete. It is kept to support existing SKILL code.

Use axlFilmCreate.

©2023 All Rights Reserved.

axlDBGetTextBlockCount

```
axlDBGetTextBlockCount(
     )
     => x_textBlockCount
```

Description

Returns a count of the number of text blocks defined.

Arguments

NA

Value Returns

x_textBlockCount	A count of the number of text blocks defined.

Examples

```
numTextBlocks = axlDBGetTextBlockCount()
printf("This database has %d text blocks\n" numTextBlocks)
```


©2023 All Rights Reserved.

axlDBGridGet

```
axlDBGridGet(
     nil)
     ==> lt_grids
```

```
axlDBGridGet(
     t_gridName)
     ==> og_grid
```

Description

This command returns current grid values. Function has two modes:

- if grid name is nil returns list of names
- If given a grid name return its grid characteristics (see below)

Note: Reserved grid name is "non-etch" otherwise grid names follow Allegro ETCH subclass names.

Use axlDBDisplayControl to control grid color and visibility.

Grids have the following attributes:

Name	Type	Description
`objType`	string	Name of the object - grids
readOnly	nil	can modify object
name	string	Name of grid
xOrigin	dbrep	X origin of grid
yOrigin	dbrep	Y origin of grid
xMajor	dbrep	Major X spacing of grid (read-only)
yMajor	dbrep	Major Y spacing of grid (read-only)
xGrids	l_dbrep	Spacings X of grid (always a list of dbreps)
yGrids	l_dbrep	Spacings Y of grid (always a list of dbreps)

©2023 All Rights Reserved.

Arguments

t_gridName	name of grid or `nil` to get all grid names

Value Returned

- `lt_gridds` – list of grids
- `og_grid` – disembodied property list containing grid settings

See Also

axlDBGridSet

Example

Run the following code to get all grids and print them.

```
grids = axlDBGridGet(nil)

foreach(g grids
     grd = axlDBGridGet(g)
     printf("GRID name=%s  values=%L\n", grd->name, grd))
```


©2023 All Rights Reserved.

axlDBGridSet

```
axlDBGridSet(
     og_grid)
     ==> t/nil
```

Description

This function modifies the grid settings in the design.

In addition to the grid names (see axlDBGridGet), two symbolic grid names are available:

- `'all` – sets all grid values
- `'etch` – sets all ETCH grid values

As a convenience when setting a single xGrids or yGrids attribute, you can use a float.

Both xMajor and yMajor values are automatically determined by the sum of the spacings in xGrids and yGrids, respectively.

Notes

- Non etch grids may not have multiple spacings. We only use the first grid seen.
- Setting grids is not undo-able (this may change in the future).
- Etch grids names are the same as ETCH layer names. This may change in the future.
- Origin values must be within drawing extents or 0.
- If Grid dialog is open it will not be updated when you change the grid settings using this API .

Arguments

og_grid	a grid disembodied property list from axlDBGridGet

Value Returned

`t` if the command is successful and the grid is changed, `nil` in case of failure.

©2023 All Rights Reserved.

See Also

axlDBGridGet, axlDBDisplayControl

Examples

1. Modify TOP grid settings

```
grid = axlDBGridGet("TOP") ; Retrieve existing grid settings
grid->xGrids = 1.0
grid->yGrids = 1.0
axlDBGridSet(grid)
```

2. Modify all grids (note allow xGrids and yGrids to NOT be list)

```
grid = axlDBGridGet("TOP"); Retrieve base grid settings to modify
grid->name = 'all
grid->xGrids = 5.0
grid->yGrids = 5.0
axlDBGridSet(grid)
```

3. Modify all etch grids

```
grid = axlDBGridGet("TOP"); Retrieve base grid settings to modify
grid->name = 'etch
grid->xGrids = '(5.0 7.0)
grid->yGrids = '(5.0 6.0)
axlDBGridSet(grid)
```


©2023 All Rights Reserved.

axlDBTextBlockCreate

```
axlDBTextBlockCreate(
     x_blockTemplate
     ?width  f_width
     ?height f_height
     ?lineSpace f_lineSpace
     ?charSpace f_charSpace
     ?photoWidth f_photoWidth
     ) => x_textBlock/nil
```

Description

Creates a new text block from the template block number provided. By providing optional text block characteristics, you can get available text blocks by:

```
lst = axlGetParam("paramTextBlock")
```

Arguments

x_blockTemplate	Text block number (an integer) to use as template.
	`0` (zero) can be used to start with a new empty text block
f_width	Width of an individual character in design units
f_height	Height of an individual character in design units
f_lineSpace	Spacing between lines of text in design units
f_charSpace	Spacing between consecutive characters in design units
f_photoWidth	Width in design units of the strokes used to draw characters

Value Returned

`x_textBlock`	New text block
`nil`	Returned if the command fails. Typically, this happens when you have exhausted the number block Allegro provides, or one of the parameters is not of the correct data type.

■

©2023 All Rights Reserved.

See Also

axlGetParam, axlSetParam, axlDBTextBlockCompact

Examples

- Create a new text block based upon text block 1 but change width and height

```
blockNum = axlDBTextBlockCreate(1 ?width 15.0 ?height 16.0)
```

- Create a new text block without using a template. All parameters must be specified

```
block2 = axlDBTextBlockCreate(0 ?width 25.0 ?height 35.0 ?lineSpace 40.0
?photoWidth 5.0 ?charSpace 4.0)
```


©2023 All Rights Reserved.

axlDBTextBlockFindName

```
axlDBTextBlockFindName(
     t_textBlockName
     )=> x_textBlockNumber/nil
```

Description

Finds a text block based on its name.

Arguments

t_textBlockName	The name of the text block to be found.

Value Returned

x_textBlockNumber	Number of the text block found.
nil	No text block found with the given name.

Examples

- Find the text block with the name "Refdes".

```
textBlockNumber = axlDBTextBlockFindName("Refdes")
if(textBlockNumber then
    printf("Text block Refdes is number %d\n" textBlockNumber)

else

    printf("There is no text block named Refdes\n")

)
```


©2023 All Rights Reserved.

axlDBTextBlockGetName

```
axlDBTextBlockGetName(
     x_textBlockNumber
     )=> t_name/nil
```

Description

Returns the name associated with the given text block. Same as attribute `userName` in `axlGetParam("paramTextBlock:<number>")`.

Arguments

x_textBlockNumber	The index of the text block whose name it to be returned. Text blocks use a 1-based indexing.

Value Returns

t_name	The text block name
nil	This text block has no name

Examples

```
textBlockName = axlDBTextBlockGetName(textBlockNumber)
```


©2023 All Rights Reserved.

axlDBTextBlockSetName

```
axlDBTextBlockSetName(
     x_textBlockNumber
     t_name
     )
     => t/nil
```

Description

Defines a name for a given text block.

Arguments

x_textBlockNumber	The index of the text block whose name is to be defined. Text blocks use a 1 based indexing.
t_name	The name being defined for the text block. A `nil` indicates that there is no name.

Value Returns

t	Success
nil	Error

Examples

Define a name of "Refdes" for text block #3.

```
axlDBTextBlockSetName(3 "Refdes")
```


©2023 All Rights Reserved.

axlExportXmlDBRecords

```
axlExportXmlDBRecords(
     t_fileName
     lt_parmGroups/nil
     ) -> t/nil
```

```
axlExportXmlDBRecords(
     nil
     ) -> lt_parmGroups
```

Description

This exports an Allegro Parameter file from the current design. It offers the same capability as (*File – Import – Parameter*). Side effect is creation of a `param_write.log` file.

Arguments

t_fileName	Name of parameter file. Default extension is `.prm` and if not given a path component will locate the file via PARAMPATH. If filename is `nil` report back as a list the supported parameter groups.
lt_parmGroups	List of parameter groups to export or nil to export all.

Value Returned

`t` if command is successfully executed, `nil` in case of an error

See Also

axlImportXmlDBRecords

Examples

1. In an existing dump, save all its settings and load into a new design

```
axlExportXmlDBRecords("myparam" nil)
axlOpenDesign(?design "newDesign")
axlImportXmlDBRecords("myparam")
```

2. Dump current parameter groups

```
axlExportXmlDBRecords(nil)
```


©2023 All Rights Reserved.

axlFilmCreate

```
axlFilmCreate(
     t_filmname
     ?negative               t/nil
     ?undefineLineWidth      f_width
     ?sequence               x_number
     ?rotation               x_angle
     ?xOffset                f_x
     ?yOffset                f_y
     ?shapeBoundingBox       f_value
     ?mirrored               t/nil
     ?fullContact            t/nil
     ?suppressUnconnectPads  t/nil
     ?drawMissingPadApertures t/nil
     ?useApertureRotation    t/nil
     ?suppressShapeFill      t/nil
     ?vectorBasedPad         t/nil
     ?drawHolesOnly          t/nil
     ?layers                 lt_layers
     ?domains                lt_domains
     ?ipc2581                lt_ipcDomains
     ) -> t/nil
```

Description

Creates a new artwork film or replaces an existing artwork film.

The terminology used matches the artwork dialog box. For more information on how each field is used, see the dialog box help.

- Defaults for all boolean entities is `nil`.
- Due to Valor issue suppressShapeFill is always `nil` when using Gerber 4x or 6x.
- If the value of the `drawHolesOnly` parameter is set to `t`, drill holes are drawn for all pads defined on the VIA and PIN CLASS for the film.
- Enable `axlDebug` for additional error messages.

©2023 All Rights Reserved.

Arguments

t_filmname	Film name
f_width	Undefined line width, default is 0.
x_sequence	For PDF output ordering. Default is 1, range is 1 to 255. If films have the same number, their database order will determine output.
x_angle	Film rotations, values are 0, 90, 180 or 270, Default is 0.
f_x, f_y	Film offset in design units, Default is 0,0
f_shapeBoundingBox	Shape bounding box in design units. Default is 0.
lt_layers	List of Allegro layers to apply to film. Default is none. Layer names are fully qualified (include both class and subclass) Example: "ETCH/TOP" A mode exists where if you specify the class name all subclasses of that class are listed in the film. Example: "MANUFACTURING"
lt_domains	List of domains where film should be visible. Values are ipc2581, pdf, artwork and visibility. Default is all.
lt_ipcDomains	List of domains where film should be used in IPC2581. Valid values are `inner`, `outer`, `misc`, `doc`, and `soldermask`.

Value Returned

`t` if film is created, `nil` in case of an error.

See Also

axlGetParam, axlDeleteObject, axlDebug

Examples

- Add/Change

©2023 All Rights Reserved.

To understand how to add films, right-click on the artwork dialog to save a film to film (FILM_SETUP.txt)

- Get all films:

```
p = axlGetParam("artwork")
p->groupMembers
```

- Get a single film (where format is "artwork:<film name>"):

```
s = axlGetParam("artwork:top")
s->??
```

- Delete a film (in this case top):

```
axlDeleteObject(s)
```


©2023 All Rights Reserved.

axlImportXmlDBRecords

```
axlImportXmlDBRecords(
     t_fileName
     ) -> t/nil
```

Description

This command imports an Allegro Parameter file into the current design. It offers the same capability as (*File – Import – Parameter*). A side effect is creation of `param_read.log` file.

Caution

For new releases, the `prm` ***files may require updating to support new parameter records or additions to current records.***

Tip

You can create your own custom parameter files and load them with this interface. While the export interface typically groups several Allegro parameters together, you can custom craft a `prm` file with a single parameter record or just a single parameter from one record (see the following example). The only `prm` file requirements are: prm file xml header, parameter header and trailer, and revision number per parameter (currently these are all 1)

Arguments

`t_fileName`	Name of parameter file. Default extension is `.prm`. If filename is not provided component will located the file via PARAMPATH.

Value Returned

`t` if success, `nil` an error

See Also

axlExportXmlDBRecords

©2023 All Rights Reserved.

Examples

See axlExportXmlDBRecords

Example of a parameter file with setting just the dynamic shape min area to 75.0:

```
<?xml version="1.0" encoding="UTF-8" standalone="no" ?>
         <CadenceAllegroParameter xmlns="">
           <dynfill_parm_type>
             <rev>1</rev>
             <min_area>75.0 MIL</min_area>
           </dynfill_parm_type>
         </CadenceAllegroParameter>
```


©2023 All Rights Reserved.

axlMiniStatusReset

```
axlMiniStatusReset(

     ) => t/nil
```

Description

This resets the Option panel settings and find filter settings to a new design's default.

Caution

Do not run this unless advise by Cadence.

Arguments

None

Value Returned

nil	a command is active
t	panel is reset settings

Examples

```
axlMiniStatusReset()
```


©2023 All Rights Reserved.

axlPadSuppressGet

```
axlPadSuppressGet(
     nil
     )
     ==> ll_LayerPadSuppress
```

```
axlPadSuppressGet(
     'all
     )
     ==> ll_LayerPadSuppress
```

```
axlDBGridGet(
     t_layer/x_layerNumber
     )
     ==> l_LayerPadSuppress
```

Description

Returns pad suppress layer characteristic for a layer or design. Pad suppression is not available in symbol editor.

Name dielectric layers will appear in the list unlike the pad suppress dialog.

Arguments

nil	Returns global status for dynamic pad suppression
all	Returns all layers with settings
t_layer	Get suppress characteristics of named layer
x_layerNumber	Layer number (1st layer is 0).

Value Returned

- `ll_LayerPadSuppress` - list of `l_LayerPadSuppress` for all etch layers. Layers are ordered from top to bottom.
- `l_LayerPadSuppress` - suppress characteristics of named layer. The symbols pin and via are optional and if present indicate pin and/or vias will be suppressed on that layer.

```
(<t_layer> [<s_pin>] [<s_via>])
```


©2023 All Rights Reserved.

See Also

axlPadSuppressSet, axlPadSuppressOkLayer, axlDBControl, axlSubclassRoute, axlPadOnLayer

Example

- Get the global dynamic pad suppression status

```
suppress = axlPadSuppressGet(nil)
```

- Get and print suppress state of all layers

```
suppress = axlPadSuppressGet('all)

foreach(item suppress
     printf("Layer=%s  what= %L\n", car(item) cdr(item))
```

- Get settings for layer "GND"

```
suppress = axlPadSuppressGet("GND")
```

- Get settings for layer 1

```
suppress = axlPadSuppressGet(1)
```


©2023 All Rights Reserved.

axlPadSuppressOkLayer

```
axlPadSuppressOkLayer(
     t_layer/x_layerNumber
     )
     ==> t/nil
```

Description

Indicates if layer can be set for pad suppression. Only internal conductor and shape layers that are not set for negative artwork, support pad suppression.

Argument

t_layer	name of layer (for example, "TOP")
x_layerNumber	layer number (starts at 0);

Value Returned

`t` if layer can allows pad suppress; `nil` otherwise

See Also

axlPadSuppressGet

Examples

The following are the same in the PCB tool but may not be in APD+:

```
axlPadSuppressOkLayer("TOP")
axlPadSuppressOkLayer(0)
```


©2023 All Rights Reserved.

axlPadSuppressSet

```
axlPadSuppressSet(
     g_mode
     ll_LayerPadSuppress/'all/'none/nil
     )
     ==> t/nil
```

```
axlPadSuppressSet(
     g_mode
     t_layer/x_layerNumber
     ls_options
     )
     ==> t/nil
```

Description

This modifies the pad suppression settings in the design. Allows control of both dynamic suppression setting (`g_mode`) and the individual layer options (subsequent arguments).

Notes:

- If passing a list of suppression layers then any errors in the list are ignored.
- Will mark dynamic shapes and DRC out of date.
- If enabling dynamic mode and no suppression layers are enabled the dynamic mode will be left disabled.
- Unlike the dynamic it will not automatically enable the display of padless holes.

Caution

Pad suppression dialog should not be open when using this API.

©2023 All Rights Reserved.

Argument

g_mode	The possible values are: ■ `nil` - maintain current pad suppression mode ■ `'on` - turn pad suppression on ■ `'off` - turn pad suppression off

In the first format, second argument can have one of the following values.

'all	Enable suppress on all supported layers
'none	Clear suppression on all supported layers
nil	Leave suppression layers alone (typically used to toggle global mode)
ll_LayerPadSuppress	List of layers using the same form as axlPadSuppressGet.

Alternatively, use the second format to set suppression on single layers.

t_layer	Layer name

or

x_layerNumber	Layer number when first layer is 0
ls_options	May be `nil` or a list of `'via` and/or `'pin`

Value Returned

`t` if success, `nil` a failure

See Also

axlDBGridGet, axlDRCUpdate, axlDBDynamicShapes

Examples

■ Enable dynamic suppression setting

©2023 All Rights Reserved.

```
axlPadSuppressSet('on nil)
```

- Enable all layers and dynamic mode

```
axlPadSuppressSet('on 'all)
```

- Delete suppression layer settings and turn off dynamic mode

```
axlPadSuppressSet('off 'none)
```

- Turn on via suppression on layer GND

```
axlPadSuppressSet(nil "GND" '(via))
```

- Turn on via & pin suppression on layer GND

```
axlPadSuppressSet(nil "GND" '(via pin))
```

- Turn off suppression on a layer GND

```
axlPadSuppressSet(nil "GND" nil)
```

- Turn on suppression for GND and VCC layers

```
axlPadSuppressSet(nil '(("GND" via pin) ("VCC" via pin)))
```


©2023 All Rights Reserved.

axlParamFilletDoc

```
p = axlGetParam("fillet")
axlSetParam(p)
```

Description

This function supports access to the fillet parameter record. The database is updated when axlSetParam is called.

1. This parameter is not available in certain tiers of Allegro PCB Editor.
2. If dynamic is enabled, or if a parameter is changed while dynamic fillet is in effect, when axlSetParam is called, all fillet/tapes are updated.
3. If one of the min/max attributes is changed, the opposite value may be updated to enforce the min <= max rule.

Fillet Attributes

NAME	Set?	TYPE	DESCRIPTION
objectType	No	string	“fillet”
dynamic	Yes	t/nil	enables/disables dynamic fillet or taper
allowDRC	Yes	t/nil	allows fillet or taper to cause DRC
allowCurved	Yes	t/nil	generates curves for fillet or taper
unusedNets	Yes	t/nil	generates fillet or tapers on unused nets
pin	Yes	t/nil	generates fillet on pins
via	Yes	t/nil	generates fillet on vias
ts	Yes	t/nil	generates fillet on Ts
fingers (APD+ only)	Yes	t/nil	generates fillet on fingers
padsWithoutDrills	Yes	t/nil	generates fillet on pads without drills

©2023 All Rights Reserved.

NAME	Set?	TYPE	DESCRIPTION
round	Yes	t/nil	generates fillet on round pads
square	Yes	t/nil	generates fillet on square pads
rect	Yes	t/nil	generates fillet on rectangular pads
oblong	Yes	t/nil	generates fillet on oblong pads
octagon	Yes	t/nil	generates fillet on octagon pads
padShape	Yes	t/nil	generates fillet on shape pads
sizeRound	Yes	float	minimum size of round pad to fillet
sizeSquare	Yes	float	minimum size of square pad to fillet
sizeRect	Yes	float	minimum size of rectangular pad to fillet
sizeOblong	Yes	float	minimum size of oblong pad to fillet
sizeOctagon	Yes	float	minimum size of octagon pad to fillet
pinDesiredAngle	Yes	integer	desired fillet angle for a pin (0 to 99 degrees)
viaDesiredAngle	Yes	integer	desired fillet angle for a via (0 to 99 degrees)
tDesiredAngle	Yes	integer	desired fillet angle for a T (0 to 99 degrees)
pinMaxAngle	Yes	integer	Maximum fillet angle for a pin (0 to 99 degrees)
viaMaxAngle	Yes	integer	Maximum fillet angle for a via (0 to 99 degrees)
tMaxAngle	Yes	integer	Maximum fillet angle for a T (0 to 99 degrees)
pinMaxOffset	Yes	float	Maximum offset length for a pin
viaMaxOffset	Yes	float	Maximum offset length for a via
tMaxOffset	Yes	float	Maximum offset length for a T

©2023 All Rights Reserved.

NAME	Set?	TYPE	DESCRIPTION
pinMaxArcOffset	Yes	float	Maximum arc offset length for a pin (only if curved fillets are allowed)
pinMinArcOffset	Yes	float	Minimum arc offset length for a pin (only if curved fillets are allowed)
viaMaxArcOffset	Yes	float	Maximum arc offset length for a via (only if curved fillets are allowed)
viaMinArcOffset	Yes	float	Minimum arc offset length for a via (only if curved fillets are allowed)
pinMinLineWidth	Yes	float	Minimum line width from a fillet to a pin
viaMinLineWidth	Yes	float	Minimum line width from a fillet to a via
tMinLineWidth	Yes	float	Minimum line width from a fillet to a T
pinMaxLineWidth	Yes	float	Maximum line width from a fillet to a pin
viaMaxLineWidth	Yes	float	Maximum line width from a fillet to a via
tMaxLineWidth	Yes	float	Maximum line width from a fillet to a T
taper	Yes	t/nil	enable/disable taper generation
taperAngle	Yes	integer	desired taper angle (line to line)
taperMaxOffset	Yes	float	maximum offset length for a line

Arguments

axlGetParam	Requires “fillet”
axlSetParam	Requires return of axlGetParam

Value Returned

- axlGetParam returns fillet parameter record

©2023 All Rights Reserved.

- axlSetParam returns parameter dbid if successful, nil otherwise

Examples

Enable dynamic fillet

```
p = axlGetParam("param")
p->dynamic = t
axlSetParam(p)
```

See Also

axlGetParam, axlSetParam

©2023 All Rights Reserved.

axlParamShapeDoc

```
d= axlGetParam("shapeDynamic")
l= axlGetParam("shapeDynamic:etch/shapeDynamicLayer:<name>")
s= axlGetParam("shapeStatic")
axlSetParam(d)
```

Description

Supports access to the dynamic, static, and layer parameter records. Database is updated when axlSetParam is called.

Shape Dynamic Attributes

NAME	Set?	TYPE	DESCRIPTION
objectType	No	string	"shapeDynamicLayer:<name>"
artwork	Yes	string	Target Gerber format. Values are "Gerber 4x00", "Gerber 6x00", Gerber RS274X", "Barco DPF", "MDA", or "Non-Gerber"
minAperture	Yes	float	Minimum aperture for shape fill. Value must at least 3 database units (if you have a 2 decimal-place design, this value should be greater than or equal to 0.03).
areaSuppress	Yes	float	Length of a minimum shape to suppress. This value is squared to determine the minimum area to suppress.

©2023 All Rights Reserved.

NAME	Set?	TYPE	DESCRIPTION
inlinePinVoid	Yes	float	Distance between pins to combine into a one void. If 0, the inline pin void algorithm is disabled. In the dialog this value is shown as “Individually”.
acuteAngleTrim	Yes	string	Type of trimming. Values are "Round", "Chamfered", or "Full Round".
diffpair	Yes	t/nil	Combined void for vias added with Return Path option.
fillStyle	Yes	string	"Fill style of shape". Values are "Solid" or "XHatch"
xHatchBorderWidth	Yes	float	Width of border. Must be greater than or equal to the width of the largest of the first or the second hatch line widths.
xHatchLineWidth1	Yes	float	Line width for fill pattern 1
xHatchLineSpacing1	Yes	float	Line spacing for fill pattern 1
xHatchLineAngle1	Yes	float	Line angle for fill pattern 1 (in degrees)
xHatchLineWidth2	Yes	float	Line width for fill pattern 2
xHatchLineSpacing2	Yes	float	Line spacing for fill pattern 2
xHatchOrigin	Yes	list	Origin of the cross-hatch lines. Must contain float values representing x and y coordinates
xHatchLineAngle2	Yes	float	Line angle for fill pattern 2 (in degrees)
xHatchSnapVoids	Yes	t/nil	Whether to attach voids to cross hatch lines.

©2023 All Rights Reserved.

NAME	Set?	TYPE	DESCRIPTION
xHatchFillPartial	Yes	string	Partial filling of cross- hatch cells. Values are "Off", "Low", "Medium" "High".
pinClearanceOther	Yes	t/nil	Clearance mode; uses DRC for nil and uses thermal/antipad clearance values for, t. If nil, the thermalWidthOverSize value is added to line width constraint.
pinOversize	Yes	float	Additional clearance applied to thru pin to shape clearance or thru pin to thermal/antipad clearance.
pinThermalType	Yes	string	Thermal relief type. Can be, “Diagonal”, “Orthogonal”, "Full contact”, "8 way connect” "Orthogonal", "Full contact", "8 way connect" or "None".
pinBestFit	Yes	t/nil	Generative thermals using the best contact option.
pinMinTherms	Yes	integer	Minimum thermal connections. Range is 1-4 unless 8 way connect is used when it is 1-8.
pinMaxTherms	Yes	integer	Maximum thermal connections. Range is 1-4 unless 8 way connect is used when it is 1-8.
smdClearanceOther	Yes	t/nil	Clearance mode; uses DRC for nil and uses thermal/antipad clearance values for t
smdOversize	Yes	float	Additional clearance applied to smd pin to shape clearance or smd pin to thermal/antipad clearance

©2023 All Rights Reserved.

NAME	Set?	TYPE	DESCRIPTION
smdThermalType	Yes	string	Thermal relief type. Can be, "Diagonal","Orthogonal", "Full contact", "8 way connect" or "None".
smdBestFit	Yes	t/nil	Generative thermals using the best contact option.
smdMinTherms	Yes	integer	Minimum thermal connections. Range is 1-4 unless 8 way connect is used when it is 1-8.
smdMaxTherms	Yes	integer	Maximum thermal connections. Range is 1-4 unless 8 way connect is used when it is 1-8.
viaClearanceOther	Yes	t/nil	Clearance mode; uses DRC for nil and uses thermal/antipad clearance values for t/
viaOversize	Yes	float	Additional clearance applied to via to shape clearance or via to thermal/antipad clearance
viaThermalType	Yes	string	Thermal relief type. Can be, "Diagonal", "Orthogonal", "Full contact", "8 way connect" or "None".
viaBestFit	Yes	t/nil	Generative thermals using the best contact option.
viaMinTherms	Yes	integer	Minimum thermal connections. Range is 1-4 unless 8 way connect is used when it is 1-8.
viaMaxTherms	Yes	integer	Maximum thermal connections. Range is 1-4 unless 8 way connect is used when it is 1-8.
lineOversize	Yes	float	Clearance oversize for lines and clines
textOversize	Yes	float	Clearance oversize for text
shapeOversize	Yes	float	Clearance oversize shapes and fill rectangles.

©2023 All Rights Reserved.

NAME	Set?	TYPE	DESCRIPTION
thermalWidthUseXHatch	Yes	t/nil	Use cross-hatch line widths when generating thermals (applies to only cross-hatch shapes)
thermalWidthUseFixed	Yes	t/nil	Uses thermalWidthFixed value for thermal width for t and adds the thermalWidthOverSize value to line width constraint for nil.
thermalWidthFixed	Yes	float	Fixed width of thermals.
thermalWidthOverSize	Yes	float	Thermal width oversize value added to line width constraint. It is applied when thermalWidthUseFixed is nil.

Shape Static Attributes

NAME	Set?	TYPE	DESCRIPTION
objectType	No	string	“shapeStatic”
minAperture	Yes	float	Minimum aperture for shape fill. Must be at least 3 database units (if you have a 1 decimal place design this value should be 0.3).
areaSuppress	Yes	float	Length of a minimum shape to suppress.This value is squared to determine the minimum are to suppress.
allowSplit	Yes	string	Allow a shape to split when voiding. Permitted values are "No", "Yes" or "Confirm".
inlinePinVoid	Yes	t/nil	Create single void for in-line pins (t) or individual voids (nil).

©2023 All Rights Reserved.

NAME	Set?	TYPE	DESCRIPTION
acuteAngleTrim	Yes	string	Type of trimming. Values are "Round", “Chamfered”, "Full Round".
xHatchSnapVoids	Yes	t/nil	Whether attach voids to xhatch lines.
xHatchFillPartial	Yes	string	Fill partial xhatch cells. Values are "Off", "Low", "Medium" "High". This setting is shared with dynamic shapes.
pinClearanceType	Yes	string	Clearance mode. Can be "Thrm/ Anti", "DRC Value", "Default" or "None".
pinDefault	Yes	float	Clearance value to use if clearance type is "Default".
pinThermalType	Yes	string	Thermal relief type. Can be, "Diagonal", "Orthogonal", "Full contact", "8 way connect".
viaThermalType	Yes	string	Thermal relief type. Can be, "Diagonal", "Orthogonal", "Full contact", "8 way connect".
lineClearanceType	Yes	string	Clearance mode. Can be "DRC Value", "Default" or "None".
lineDefault	Yes	float	Clearance value to use if clearance type is "Default"
clineClearanceType	Yes	string	Clearance mode. Can be "DRC Value", "Default" or "None".
clineDefault	Yes	float	Clearance value to use if clearance type is "Default"
textClearanceType	Yes	string	Clearance mode. Can be "DRC Value", "Default" or "None".
textDefault	Yes	float	Clearance value to use if clearance type is "Default"
shapeClearanceType	Yes	string	Clearance mode. Can be "DRC Value", "Default" or "None".

©2023 All Rights Reserved.

NAME	Set?	TYPE	DESCRIPTION
shapeDefault	Yes	float	Clearance value to use if clearance type is "Default"
rectClearanceType	Yes	string	Clearance mode. Can be "DRC Value", "Default" or "None".
rectDefault	Yes	float	Clearance value to use if clearance type is "Default"
thermalMax	Yes	integer	Maximum thermals to generate by connection, range is 1-8
thermalWidth	Yes	float	Thermal width to use. If 0 uses DRC line width value.

Notes

- If not specified all float units are in design units.
- The type of cross hatching is not directly controlled by these two parameter records. Instead, if the cross-hatch values are not supplied at the time of shape creation, the values stored in these parameter records are used.
- If the dynamic shape parameter record is modified any dynamic shapes are marked out of date.
- If the static shape parameter record is modified no existing static shapes are affected. These values are applied when the shape is voided next time.
- Use `axlDBControl('dynamicFillMode)` to control dynamic shape fill mode.
- Use "cdn_outer", "cdn_inner_plane", and "cdn_inner_signal" to access superlayer parameter records.

Arguments

axlGetParam	Requires "shapeStatic" or "shapeDynamic"
axlSetParam	Requires return of axlGetParam

Value Returned

- `axlGetParam` returns shape parameter record
- `axlSetParam` returns parameter dbid if successful, `nil` otherwise

©2023 All Rights Reserved.

See Also

axlGetParam, axlSetParam, axlDBControl, axlDBDynamicShapes

Examples

- Set smd thermal for dynamic

```
d = axlGetParam("shapeDynamic")
axlPrintDbid(d)         ; print dbid in a pleasing format
d->smdThermalType = "8 way connect"
d->smdBestFit = t
d->smdMinTherms = 2
d->smdMaxTherms = 7
axlSetParam(d)
```

- Set minimum aperture and allow shapes to automatically split

```
s = axlGetParam("shapeStatic")
s->minAperture = 10.2
s->allowSplit = "Yes"
axlSetParam(s)
```


©2023 All Rights Reserved.

axlGetParam

```
axlGetParam (
     t_parm_name
     )
     ⇒ o_paramDbid/nil
```

```
axlGetParam (
     nil
     ) =>lt_params
```

Description

Gets the parameter *dbid* for a named object. Supported parameter names are shown below. For descriptions of attributes of a parameter, see are Chapter 2, “The Allegro PCB Editor Database User Model.”

©2023 All Rights Reserved.

Arguments

nil	Returns list of parameters supported

©2023 All Rights Reserved.

t_parm_name Name of the parameter to seek. The legal naming conventions follow:

- `paramTextBlock:<#>` -– where # is 1-<N> (Example: `paramTextBlock:1`) where N is number of text blocks (axlDBGetTextBlockCount())
- `paramDesign`
- `paramDisplay`
- `paramLayerGroup:<name>` – where name is a legal Allegro class name

  `paramLayerGroup:ETCH` – is obsolete for getting the cross-section layers, use new `axlXSectionGet()` family of APIs. If the design does not contain multiple cross-sections, this will still return the list of ETCH layers, and if there are no mask layers, this will be the list of all layers. It will be maintained for older SKILL code to continue to work in single stackup designs with no mask layers.

  Note: In IC packaging products a pseudo class called WIRE with a single subclass called WIRE exists. This supports bondwires and is typically not displayed in the Options panel drop-down. Also, predefined ETCH subclasses BOND_TOP and BOND_BOTTOM, used for wirebond bondpads on chip-on-board components, are not included as they are not layers available for shapes, lines or routing. See switch `includeNonLayers` that controls this.
- `paramLayerGroup:<name>/paramLayer:<name>`
- `paramLayerGroup:name>/includeNonLayers` – ETCH class includes all non-mask layers of the cross-section. By default, `paramLayerGroup:ETCH` includes only those ETCH subclasses that are also cross-section layers. In order to get additional ETCH subclasses that are not layers, such as BOND_TOP and BOND_BOTTOM for chip-on-board, add switch `includeNonLayers`.
- `artwork` – List of film names
- `artwork:<filmName>` – A film given by `filmName`
- `testprep` – See `axlParamTestPrepDoc`
- `Fillet` – See `axlParamFilletDoc`
- `shapeStatic` and `shapeDynamic` – See `axlParamShapeDoc`

©2023 All Rights Reserved.

Value Returned

`o_paramDbid`	Returns a *`dbid`* for the requested parameter
`lt_params`	Returns list of parameter names supported
`nil`	Returns if parameter requested is not legal

See Also

axlSetParam, axlGetParam, axlIsParamType, axlParamDesignDoc

Example

- Return all param types supported

```
axlGetParam(nil)
```

- Get etch layer (to find all members of the etch class).

```
 etch_parm = axlGetParam("paramLayerGroup:ETCH")
param:123456

 etch_parm->??
(objType "paramLayerGroup" name "ETCH" visible
-1 nChildren 4 groupMembers
("TOP" "GND" "VCC" "BOTTOM")
color -1
)

 etch_parm->color
-1

 etch_parm->groupMembers
("TOP" "GND" "VCC" "BOTTOM")
```

- Access artwork records
  - Get list of all possible records.

```
 p = axlGetParam("artwork")
 p->??
(objType "artwork" nChildren 4 groupMembers
("TOP" "GND" "VCC" "BOTTOM")
```


©2023 All Rights Reserved.

```
)
```

- Get information on film record “VCC”.

```
r = axlGetParam("artwork:VCC")
 r->??
(objType "artwork" groupMembers
("ETCH/VCC" "PIN/VCC" "VIA CLASS/VCC") vectorBasedPad
t suppressShapeFill t useApertureRotation nil
drawMissingPadApertures nil suppressUnconnectPads t fullContact
nil mirrored nil shapeBoundingBox 100.0
offset (0.0 0.0) rotation 0 undefineLineWidth
0.0 negative t name "VCC"
)
```

- Delete a TOP parameter record.

```
axlDeleteObject(axlGetParam("artwork:TOP"))
```

- Design (`paramDesign`) modification.

```
axlDBChangeDesignOrigin: change design origin
axlDBChangeDesignExtents: change extents
axlDBChangeDesignUnits: change units and/or accuracy
```


©2023 All Rights Reserved.

axlParamDesignDoc

```
axlGetParam("paramDesign") -> o_dbid
```

Description

This function obtains the Allegro design record which controls database size and accuracy.

DESIGN Attributes

NAME	Set?	TYPE	DESCRIPTION
accuracy	no	integer	number of decimal places in design
dbuperuu	no	integer	database units per user units in design
bBox	no	bbox	the design's bounding box
height	no	float	size of design (see width)
objType	no	string	"paramDesign"
units	no	string	design units ("mils", etc.)
width	no	float	size of design (see height)
xy	no	point	lower left corner of design

Arguments

"paramDesign"	Name of parameter

Value Returned

dbid of parameter record

Example

See what current db has to offer

```
p = axlGetParam("paramDesign"
p->??
```


©2023 All Rights Reserved.

See Also

axlDBChangeDesignOrigin, axlDBChangeDesignExtents, axlDBChangeDesignUnits

©2023 All Rights Reserved.

axlSetParam

```
axlSetParam (
     od_paramDbid
     )
     ⇒ rd_paramDbid/nil
```

Description

This allows applications to modify certain aspects of Allegro parameters. After a parameter has been retrieved, attributes of it can be changed locally. Those changes can then be put back into the database using `axlSetParam`.

Arguments

od_paramDbid	Parameter id returned from axlGetParam. Modify the parameters to be changed then call axlSetParam function to update the database.

Value Returned

`rd_paramDbid`	Returns the input parameter id if successful
`nil`	Database was not modified.

Example

- Change visibility (note it is easier to use axlVisibleSet to do this)

```
(setq etch_top (axlGetParam "paramLayerGroup:ETCH/paramLayer:TOP"))
=>param:123456
```

; is layer visible?

```
etch->visible
t
```

; blank it

```
etch_top->visible = nil
t
(axlSetParam etch_top)
=>param:123456
```

; layer is now invisible

```
etch_top->visible
```


©2023 All Rights Reserved.

```
nil
```

- Change accuracy

```
p = axlGetParam("paramDesign")
p->accuracy = 3
axlSetParam(p)
```


©2023 All Rights Reserved.

axlIsParamType

```
axllsParamType(
     o_paramDbid
     ) -> t/nil
```

Description

Returns `t` if the parameter is a parameter dbid, else return `nil`.

Arguments

A parameter type from `axlGetParam`.

Value Returned

`t`	if a parameter
`nil`	otherwise

See Also

axlGetParam

Example

```
axlIsParamType( axlGetParam("shapeDynamic") )
-*/
```


©2023 All Rights Reserved.

axltdfIsEnabled

```
axltdfIsEnabled()
     ) -> t/nil
```

Description

This function checks whether a technology-dependent footprint mapping file (`.tdfx`) is attached to a design. This function also checks whether the technology-dependent footprint mapping, defined in the TDF file, contains mapping of the footprint symbols to alternative footprints.

Arguments

None.

Value Returned

`t`	if TDF information is attached
`nil`	no attachment

See Also

axltdfSave, axltdfLoad

Examples

```
if(axltdfIsEnabled()
println("TDF mapping found")
println("No TDF mapping in this drawing")
)
=> "TDF mapping found"
```


©2023 All Rights Reserved.

axltdfLoad

```
axltdfLoad
     [t_tdffile]
     ) -> t/nil
```

Description

Parses the input TDF file to get the technology-dependent footprint mapping and stores it in the database.

Arguments

`t_tdffile`	Optional name of TDF file. If no name is given then the currently attached TDF mapping is deleted and symbols are refreshed to reflect the changes.

Value Returned

`t`	If successful
`nil`	If failed

See Also

axltdfSave, axltdfIsEnabled

Examples

- Imports the TDF file `tdf_example.tdfx`

```
axltdfLoad("tdf_example")
==> t
```

- Deletes the currently attached TDF file

```
axltdfLoad()
==> t
```


©2023 All Rights Reserved.

axltdfSave

```
axltdfSave
     [t_tdffile]
     ) -> t/nil
```

Description

Saves current technology-dependent footprint mapping to the file name supplied as the argument (or to default of `tdf_attachment.tdfx` if none is provided).

Arguments

`t_tdffile`	Optional name of TDF file.

Value Returned

`t`	If successful
`nil`	If failed

See Also

axltdfLoad, axltdfIsEnabled

Examples

- Saves TDF attachment to `exported.tdfx`

```
axltdfSave("exported")
==> t
```

- Saves TDF attachment to default name (`tdf_attachment.tdfx`)

```
axltdfSave()
==>t
```


©2023 All Rights Reserved.

Color Access

axlColorDoc

`axlColorDoc`

Description

Allegro supports two color access methods: pre-defined colors and Allegro database colors. Not all Allegro-based programs support access to Allegro database colors. (This is only supported by the graphics editors.)

Pre-defined colors are set and accessed by their symbols:

- `'black`
- `'white`
- `'red`
- `'green`
- `'yellow`
- `'blue`
- `'cyan`
- `'magenta`
- `'darkred`
- `'darkgreen`
- `'darkblue`
- `'darkcyan`
- `'darkmagenta`
- `'darkyellow`
- `'multivalue` - use `dfor` fields where value is not the same
- `'button` - current color of button faces (grey)
- `'default` - default background or text color per application theme
- `'modified` - color used to denote modified fields

©2023 All Rights Reserved.

In addition, graphics editors support access to the colors used for Allegro layers. These are integer numbers.

AXL API calls such as `axlGetLayer("class/subclass")` or its primitive form

```
axlGetParm("paramLayerGroup:<class>/paramLayer:<subclass>")
```

return the current color setting of a layer via the color attribute call.

Example:

```
p = axlGetLayer("etch/top")
p->color        -> 2
```

These colors currently range between 1 and 24 with 0 reserved for the background color.

Interfaces supporting setting color are mostly form based. For there interfaces see:

- `axlFormDoc`
- `axlFormColorize`
- `axlFormGridDoc`
- `axlGRPDoc`

Notes

- No AXL method is currently supported to allow you to change the red/green/blue (RGB) of Allegro database colors
- We restrict the pre-defined colors to those defined to minimize use of colors to minimize problems with 8 bit color graphics on UNIX. When 24 (or higher) color cards become standard on UNIX, this will be relaxed.
- On Windows, Microsoft's UI theme overrides the background color. To enable background color control for ENUM controls, when specifying the control in the form file add the "OPTION color". The default Microsoft theme for this control is disabled. Also, the drop-down itself drawn with the background color.

  On UNIX, this option is ignored and background coloring just works.

Arguments

none

©2023 All Rights Reserved.

Value Returned

none

©2023 All Rights Reserved.

axlColorGet

```
axlColorGet(
     x_number/`background
     ) -> lx_rgb/nil
```

```
axlColorGet(
     'count)
     -> x_count
```

```
axlColorGet(
     'all)
     -> llx_rgb
```

```
axlColorGet(
     'pattern
     ) -> x_count
```

Description

Get color palette. Supports the following modes:

- If passed, an index less the color count returns a list containing the red, green, blue palette values for that color index. These are integer values between `0` (no color and `255` (maximum color). For example, a value of `255 255 255` is white. Or if passed, '*`background`* returns the palette for the background.
- If given *`'count`* returns the current size of the database palette (currently always 24).
- If passed 'all returns a list of list (red, green, blue) for all entire database palette EXCEPT the background.
- Returns number of patterns supported (includes default solid).

The color index is the number assigned to each layer in Allegro PCB Editor. (see `axlVisibleGet`).

©2023 All Rights Reserved.

Arguments

x_number	Color number.
'background	Get background color.
'count	Query current database color palette size.
'all	Get entire database color palette (except background).

Value Returned

x_count	Size of database palette.
nil	Error.
lx_rgb	A palette.
llx_rgb	The entire database palette.

See Also

axlColorSet, axlVisibleGet

Examples

Get red/green/blue of color 2:

```
clr = axlColorGet(2)
```

Get background color:

```
bground = axlColorGet(`background)
```

Get number of colors:

```
cnt = axlColorGet(`count)
```

Get all red/green/blue color settings except background:

```
all = axlColorGet(`all)
```

Get number of display patterns supported

```
cnt = axlColorGet(`pattern)
```


©2023 All Rights Reserved.

axlColorShadowGet

```
axlColorShadowGet(
     g_option
     ) -> t/nil/x_percent
```

Description

Provides the options of shadow mode.

Arguments

g_option	
`'mode`	Shadow mode status (`t` is on, `nil` is off).
`'activeLayer`	Active layer dimming enabled (`t`). This is called "Dim active layer in Options panel.
`'highlight`	This is called "Dim color assignments" in the Options panel
`'percent`	Current brightness percentage (0 to 100).
`'custom`	Custom colors, these are not shadowed.

Value Returned

`t/nil`	Shadow or active layer mode on or off.
x_percent	Brightness percentage.

See Also

axlColorSet, axlColorShadowSet

Examples

Is shadow mode on:

```
axlColorShadowGet('mode)
```

Is shadow mode percent:

©2023 All Rights Reserved.

```
axlColorShadowGet('percent)
```


©2023 All Rights Reserved.

axlColorShadowSet

```
axlColorShadowSet(
     g_mode
     t/nil
     ) -> t/nil
```

```
axlColorShadowSet(
     'percent
     x_percentage
     ) -> t/nil
```

Description

Sets the shadow mode options. These are equivalent to the color commands in the shadow mode box under the Display group.

The Mode Options are:

- The mode option is either `t` or `nil` to turn shadow mode on or off.
- The activeLayer option is either `t` or `nil` to automatically dim the active layer. This is called "Dim active layer in Options panel.
- The highlight can be `t` or `nil` to dim highlighted objects. This is called *Dim color assignments* in the Options panel.
- The percent option sets the dimness (`0`) to brightness (`100`) percentage.

Note: On graphics or display combinations, shadow values of less than 40 percent disappear into the background. For example, you have what appears to be black on black.

After you finish all the color changes, call `axlVisibleUpdate` to update the display.

This interface is disabled if you set the *display_noshadow* environment variable.

©2023 All Rights Reserved.

Arguments

g_mode	The possible values are: ■ `'mode` – Enable or disable shadow mode. ■ `'highlighted` – Enable or disable shadow mode for highlighted objects. ■ `'activeLayer` – Enable or disable active layer dimming. ■ `'percent` – Set shadow mode percentage (0 to 100)

Value Returned

`t`	If successful.
`nil`	An argument error.

See Also

axlColorSet, axlColorShadowSet, axlVisibleUpdate

Examples

Is shadow mode on:

```
axlColorShadowSet('mode t)
```

Is shadow mode percent:

```
axlColorShadowSet('percent 20)
```


©2023 All Rights Reserved.

axlColorLoad

```
axlColorLoad(
     t_file/nil
     ) -> t/nil
```

Description

Loads an Allegro PCB Editor color file (default `.col` file). Master color file is located at `<cdsroot>/share/pcb/text/lallegro.col`.

File format is:

```
#   Comment if in first column.

#N  Next line with a number is number of colors (currently only 24 is supported).
This should appear first in the file.

Number format

#Number

24

#B - next line with a number is background color. This should appear after color
number. Format of color line must be:

(name is currently ignored):

0 <red> <green> <blue> [<name>]

EXAMPLE of background format setting it to black

#Background Color

0      0       0       0

#I - next set of lines sets the colors. These should always appear last in the file.
We will read until the first color number that exceeds the color number (currently
hardcoded as 24) or the end of file is reached. The order the colors appear in the
file determines the initial color [priority (highest (first) to lowest (last)].

Format is:

<color number> <pen number> <red> <green> <blue> [<name>]

EXAMPLE:

1      1       255     255     255     White

2      2       14      210     255     LtBlue

<color number>: entry in color table. This is the color number referenced by the
allegro subclass (axlLayerGet)

<pen number>: Used by Allegro plot (UNIX) to control what pen to use during
plotting. Not applicable on Windows.

<red> intensity of red to blend into color 0 to 255

<green> intensity of green to blend into color 0 to 255

<blue> intensity of blue to blend into color 0 to 255

<name> (optional) name of color, currently not used by Allegro but sigxp takes
advantage of the name to auto-assign colors.
```


©2023 All Rights Reserved.

Call `axlVisibleUpdate` to update the display after you finish manipulating the colors.

In Allegro PCB Editor, you need the color file to start a new design. Opening existing databases uses the color table stored in that database. A new database created, when Allegro PCB Editor is already running, copies the color table from the previous database.

Arguments

`s_file`	Color file name to load.
`nil`	Uses `lallegro.col`. If no directory path, Allegro PCB Editor uses the LOCALPATH environment variable to find the file.

Value Returned

`t`	If loaded file.
`nil`	File not found or error in loading file.

Example

Load user-defined default color. Overriding and setting current board values:

```
axlColorLoad(nil)
axlVisibleUpdate(t)
```

See Also

axlColorSave, axlColorSet.

©2023 All Rights Reserved.

axlColorOnGet – Obsolete

This function is obsolete. Due to change in display model, switching off colors is no longer supported.

©2023 All Rights Reserved.

axlColorOnSet – Obsolete

This is an obsolete command. Due to changes in the viewing model, now you cannot turn off a color in Allegro PCB Editor.

©2023 All Rights Reserved.

axlColorPriorityGet – Obsolete

Due to the changes in color model of Allegro PCB Editor, this command is now obsolete. Instead of this command, use axlLayerPriorityGet.

©2023 All Rights Reserved.

axlColorPrioritySet – Obsolete

Due to the changes in color model of Allegro PCB Editor, this command is now obsolete. Instead of this command, use axlLayerPrioritySet.

©2023 All Rights Reserved.

axlColorSave

```
axlColorSave(
     t_file/nil
     ) -> t/nil
```

Description

Saves current design colors to specified file.

Argument

t_file	File name. If `nil`; saves to `<HOME>/pcbenv/lallegro.col`. If no extension, uses `.col` extension.

Value Returned

`t`	Successful.
`nil`	Failed to save.

EXAMPLES

Save current design color settings:

```
axlColorSave("mycolor")
```

See Also

axlColorSave,`axlColorSet`

©2023 All Rights Reserved.

axlColorSet

```
axlColorSet(
     x_number/'background
     l_rbg
     ) -> t/nil
```

```
axlColorSet(
     'all
     ll_rgb
     ) ->t/nil
```

Description

Sets red, green, blue palette for a color number or background.

Modes supported:

- Color number (*x_number*) and red/green/blue list. *x_number* must be between one and `axlColorGet('count)`, or `'background` sets red/green/blue as the background color.
- `'all` takes a list of red/green/blue values and sets colors starting at one to the end of the list. Intended to use with `axlColorGet('all)` to save or restore color values.

Red/green/blue colors are values between `0` (least intensity) to `255` (maximum intensity).

After color changes are made, call `axlVisibleUpdate` to update the display.

Color model:

A color (or colorNumber) in Allegro PCB Editor has the following attributes:

- A palette of red, green and blue values between `0` and `255`. `0` adds none of the primary color to the mixture while `255` adds the maximum. For example, `0,0,0` is black and `255,255,255` is white. The color mixture is controlled using the palette section of the color command.
- Each color number can be assigned to a layer. Multiple layers will have the same color number, because there are more layers than colors.
- Allegro PCB Editor supports setting a background palette value. Grids, ratsnest, temporary highlight can have a color number assigned via `axlDBControl`.

Color services:

`axlColorSet`	This routine.

©2023 All Rights Reserved.

`axlColorGet`	Get red, green, or blue of one or more color numbers.
`axlColorShadowGet`	Shadow mode options.
`axlColorShadowSet`	Set shadow mode options.
`axlLayerPrioritySet`	set a layer to a display priority
`axlLayerPriorityGet`	get a layer's current priority
`axlLayerPriorityClearAll`	clear all layer priorities (restore to default)
`axlLayerPrioritySaveAll`	save existing priority table
`axlLayerPriorityRestoreAll`	restore saved priority table
`axlColorSave`	Save color values to file.
`axlColorLoad`	Load color values from file.
`axlUIColorDialog`	Standard color chooser dialog box.
`axlDBControl`	Miscellaneous color number assignments (for example, highlight).
`axlLayerGet`	Get layer (class/subclass) attributes (control color) number and visibility for individual layers.
`axlLayerSet`	Set color number or visibility for a layer.
`axlVisibleLayer`	Set visibility of layer.
`axlIsVisibleLayer`	Provides the layer visibility.
`axlVisibleGet`	Get visibility set for design.
`axlVisibleSet`	Set visibility set for design.
`axlVisibleDesign`	Global design visibility control.
`axlVisibleUpdate`	Update windows with color changes.

©2023 All Rights Reserved.

Arguments

x_number	Color index.
'background	Set background color.
'all	Set colors based upon a list starting at color number one.
l_rgb	Red/green/blue lists; three integers.
ll_rgb	Lists of red/green/blue values.

Value Returned

`t`	Successful.
`nil`	An error; wrong arguments: color number is less then one or greater than maximum.

EXAMPLES

Set color number three same as color two:

```
clr = axlColorGet(2)
axlColorSet(3 clr)
axlVisibleUpdate(nil)
```

Set first three colors:

```
axlColorSet('all '((10 10 10) (40 40 40) (100 100 100)))
```


©2023 All Rights Reserved.

axlCVFColorChooserDlg

```
axlCVFColorChooserDlg(
     [x_color_index]
     [g_show_hilite]
     [x_hilite_flag]
     [x_bitmap_index]
     )
     ==> t/nil
```

Description

Displays color palette modal dialog. Color wells reflect current design colors.

Arguments

x_color_index	Color index to initialize palette dialog. Values 0 to 191.
g_show_hilite	Specifies whether or not the highlight check box is to be displayed. If the value is set to: t – displays the highlight check box. `nil/default` – highlight check box is not displayed.
x_hilite_flag	Highlight state to initialize highlight check box (if displayed). Pass 1 or 0.
x_bitmap_index	Bitmap index to initialize palette dialog. Values 0 to 15.

Value Returned

list	containing one or two int values for user color palette selection and highlight check box selection. if `g_show_hilite` is not `nil`, list contains the two values, or else list contains color index only.
nil	if user cancels the form or error occurred.

©2023 All Rights Reserved.

axlClearObjectCustomColor

```
axlClearObjectCustomColor(
     [lo_dbid]
     )
     ==> t/nil
```

Description

Clears any custom color set on the provided database ID or list of database IDs. Objects supported are groups, nets, symbol instances, function instances, pins, vias, bond fingers, and external DRCs. The color of an object (group, net, symbol, or function) and all inheriting objects are cleared. If you clear the color of an object, where part of that object, such as a pin in a net, has a different custom color, that child object will retain its different color. If you want the custom color to be cleared for the parent and all child objects of the parent, call `axlClearObjectCustomColor` on the parent object and on all child objects that have different custom colors.

Note: Segments may not be custom colored or cleared by these interfaces. Segments are colored directly and only for temporary use in specific commands like the highlight segment over via tool. They should be unhighlighted with the same command.

Custom colors must be enabled (see `axlDBDisplayControl`) to be viewed.

Arguments

`lo_dbid`	List of database IDs or a single database ID to clear custom color.

Value Returned

`t/nil`	Returns `t` if at least one object custom color was cleared. Returns `nil` otherwise.

Examples

See `axlCustomColorObject` for examples.

©2023 All Rights Reserved.

See Also

axlCustomColorObject

©2023 All Rights Reserved.

axlCustomColorObject

```
axlCustomColorObject(
     [lo_dbid]
     [g_custom_color]
     )
     ==> t/nil
```

Description

Set custom color for a single or list of database IDs. Objects supported are groups, nets, symbol instances, function instances, pins, vias, bond fingers, clines, lines, text, figures, shapes, and external DRCs. An object that is part of a group, net, symbol, or function but that does not have a specific custom color assigned, inherits the custom color assigned to the parent object. For instance, a pin on net "A" inherits the custom color assigned to net "A" if the pin does not have a different custom color assigned to it. On the other hand, if a custom color is assigned to a net but some pins on the net have a different custom color assigned, the color of these pins will not match the net color.

Note: Segments may not be custom colored or cleared by these interfaces. Segments are colored directly and only for temporary use in specific commands like the highlight segment over via tool. They should be unhighlighted with the same command.

The color index is between 1 and `axlColorGet(`count)`. The index references a RGB value in the Allegro Color table. The RGB values can be viewed or modified via `axlColorGet` or `axlColorSet`.

Custom colors need to be enabled (see axlDBDisplayControl) to be viewed.

©2023 All Rights Reserved.

Arguments

od_dbid	a single or a list of DBIDS
g_custom_color	Color index to be used to set custom color. If the value is `nil`, perm highlight will be used.

Value Returned

`t`	An object was custom colored.
`nil`	No valid DBIDS.

See Also

axlClearObjectCustomColor, axlDBDisplayControl, axlIsCustomColored, axlColorGet

Example

The example covered in this section uses `axlCustomColorObject` and `axlClearObjectCustomColor` functions respectively to set and clear custom color of database elements during interactive commands.

The following example does the following:

- Defines the function highlightLoop.
- Loops on the function axlSelect gathering user selections to set/clear custom color.
- Custom colors objects using color 4.
- Waits then clears custom color.

The command can be stopped at any time by selecting Cancel or Done from the pop-up menu.

```
(defun customColorLoop ()
     axlSetFindFilter( ?enabled '("noall" "alltypes" "nameform")
     ?onButtons "alltypes")
     while( axlSelect()
          axlCustomColorObject( axlGetSelSet() 4)
          checkColor = axlIsCustomColored( car(axlGetSelSet()) )
          axlSleep(1)
          axlClearObjectCustomColor( axlGetSelSet())
          )
     )
```


©2023 All Rights Reserved.

axlLayerPriorityClearAll

```
axlLayerPriorityClearAll(
     ) -> t/nil
```

Description

Clears all layer priority information in Allegro database. Use axlLayerPrioritySet for usage.

Arguments

None

Value Returned

t:	success

See Also

axlLayerPrioritySaveAll, axlLayerPriorityRestoreAll

©2023 All Rights Reserved.

axlLayerPriorityGet

get layer's priority

```
axlLayerPriorityGet(
     t_layer
     ) -> x_priority/t_mapClass/nil
```

Description

Obtains layer priority, where 0 is normal (not set). Priority can range from 1 (highest) to 255 (lowest).

Depending on the argument value, the function operates in two modes:

- if *t_layer* is layer name (class / subclass), returns priority of that layer as an integer
- if *t_layer* is class name then returns the mapped layer

Note: Mapped layer groupings may change from release to release (for example, future releases may choose to break up some class groupings).

Argument

t_layer	layer name (`<class>/<subclass>`) or class name (`<class>`)

Value Returned

- `x_priority` - priority of layer (0 layer draws at normal priority)
- `t_mapClass` - class name used as lead group for provided class
- `nil` - error in layer name

See Also

axlLayerPrioritySet

Examples

- Get and fetch priority

```
axlLayerPrioritySet("BOARD GEOMETRY/OUTLINE" 1)
prior = axlLayerPriorityGet("BOARD GEOMETRY/OUTLINE")
```


©2023 All Rights Reserved.

- Get group class mapping of class Ref Des

```
axlLayerPrioritySet("REF DES") -> "COMPONENT VALUE"
```


©2023 All Rights Reserved.

axlLayerPriorityRestoreAll

```
axlLayerPriorityRestoreAll(
     ) -> t/nil
```

Description

Restores previously saved layer priority information. This function only works if a call to axlLayerPrioritySaveAll has been done already.

Arguments

None

Value Returned

t:	success
nil:	nothing to restore.

See Also

axlLayerPrioritySaveAll, axlLayerPriorityClearAll

©2023 All Rights Reserved.

axlLayerPrioritySaveAll

```
axlLayerPrioritySaveAll(
     ) -> t/nil
```

Description

Saves all layer priority information to be restored later. Until a axlLayerPriorityRestoreAll is called, any subsequent calls to this function are no-op.

Arguments

None

Value Returned

t:	success
nil:	this function has been called already but axlLayerPriorityRestoreAll has not been called yet.

See Also

axlLayerPriorityClearAll, axlLayerPriorityRestoreAll

©2023 All Rights Reserved.

axlLayerPrioritySet

```
axlLayerPrioritySet(
     t_layer
     x_priority
     ) -> t/nil
```

Description

This changes the drawing priority of given layer. Priority is from 1 (highest) to 255 (lowest). Layers without priority in standard drawing order below all priority layers. The active layer is always drawn first.

Only one layer may be at a priority level, thus adding a new layer at a priority replaces the existing layer at that priority. For example, executing following line of code results in just the ASSEMBLY_TOP being drawn at priority 1 and OUTLINE returning to normal drawing order.

```
axlLayerPrioritySet( "BOARD GEOMETRY/OUTLINE" 1)
axlLayerPrioritySet( "PACKAGE GEOMETRY/ASSEMBLY_TOP" 1)
```

From priority level 1 each level must be set for lower priority levels to be enabled. For example, if you set a layer to priority level 2 but leave level 1 empty then level 2 is disabled until level 1 is assigned.

Classes may be grouped together in a class group with one class being the lead of that group. For example, all etch layers (ETCH, PIN, etc.) are mapped together into the stack-up group with class ETCH the lead. You can set the priority using class names but you cannot prioritized the different stack-up layers individually. This interface automatically maps a class name to its class group (see axlLayerPriorityGet to determine groupings).

You should do a axlVisibleUpdate after changing layer priority to have the display updated.

Note: Priority value of 0 means remove layer priority of the layer.

©2023 All Rights Reserved.

Arguments

x_layer	layer name (i.e. "ETCH/TOP")
x_priority	priority value in the range of 1-255 and 0 means remove.

Value Returned

t	success
nil	error in one of the arguments

Examples

Set priority for class BOARD GEOMETRY and subclass OUTLINE:

```
axlLayerPrioritySet("BOARD GEOMETRY/OUTLINE" 1)
```

To temporarily force a set of layers to display on top, you should take the following steps:

- save existing layer table,
- clear existing layer priorities
- set your layer priorities
- draw objects
- restore old layer priority:

```
axlLayerPrioritySaveAll()
axlLayerPriorityClearAll()
axlLayerPrioritySet() -- multiple times if needed
axlLayerPriorityRestoreAll()
```

See Also

axlLayerPriorityClearAll, axlLayerPrioritySaveAll, axlLayerPriorityRestoreAll, axlLayerPriorityGet, axlMapClassName, axlVisibleUpdate

©2023 All Rights Reserved.

axlIsCustomColored

```
axlIsCustomColored (
     o_dbid
     )
     ==> x_customColor/nil
```

Description

If object has custom color, will return the object custom color, otherwise nil.

Arguments

o_dbid	An dbid for which custom color information is desired.

Value Returned

x_customColor	custom color or nil if object has no custom color or object does not support custom color.

See Also

axlCustomColorObject

©2023 All Rights Reserved.

Database Layer Management

These functions allow easier access to layer attributes.

axlClasses

```
axlClasses(
     ) -> lt_classes
```

Description

Return list of classes.The is actually just:

```
    axlGetParam("paramLayerGroup")->groupMembers
```

Arguments

Nothing

Value Returned

list of class strings

See Also

axlSubclasses, axlGetParam, axlMapClassName

Examples

```
axlClasses()
```


©2023 All Rights Reserved.

axlCompareLayers

```
axlCompareLayers(
     l_referenceLayers
     l_compareLayers
     t_outputLayer
     ?action                ts_action
     ?clearOutputLayer      b_clearOutputLayer
     ?extents               l_extents
     ?shape                 g_shape
     ) => t/nil
```

Description

Performs a comparison between two layers or sets of layers in the active design.This SKILL function provides a direct API to generate layer compare outputs from the code instead of through the interactive and batch layer compare tools.

©2023 All Rights Reserved.

Arguments

l_referenceLayers	Source layer(s) to be compared. This may be either a single layer, such as "ETCH/TOP", or a list of layers '("ETCH/TOP" "PIN/TOP"). If multiple layers are provided, layers are first combined together (logical OR) before the comparison to the second layer set is performed.
l_compareLayers	Comparison layer(s) to be compared. This may be either a single layer, such as "ETCH/TOP", or a list of layers '("ETCH/TOP" "PIN/TOP"). If multiple layers are provided, these are first combined together (logical OR) before the comparison to the reference layer set is performed.
t_outputLayer	Target layer, where the results of the boolean operation should be generated to. If the layer does not exist, it will be created.
ts_action	Comparison action. Operations are same as those supported by the `axlPolyOperation` API: 'AND, 'OR, 'ANDNOT, and 'XOR. Default is 'OR.
b_clearOutputLayer	If `t`, remove any shapes from the output layer before populating with the results of the layer compare operation. Default is `t`.
l_extents	If set, represents the window area where the comparison is to be restricted to. Default is to compare the entire database region.
g_shape	If set, provides a DBID of a shape. The shape will be used to set the restricted comparison region. Only one of *l_extents* or *g_shape* may be used at a time.

Value Returned

`t`	Comparison successful
`nil`	An error occurred. Check arguments passed to the function and ensure that if the output layer does not exist, there is room to add it to the database.

Example

```
axlCompareLayers("ETCH/TOP" "ETCH/BOTTOM" "DRAWING FORMAT/COMPARE_LAYERS"
                 ?action 'AND ?clearOutputLayer t)
```


©2023 All Rights Reserved.

axlDBGetLayerType

```
axlDBGetLayerType
     t_layerName
     )
     ⇒ t_layertype/nil
```

Description

Retrieves the cross-section type of a given layer. This may be (Layer Type in define xsection form): `CONDUCTOR`, `DIELECTRIC`, `PLANE`, `SURFACE`, `DIESTACK` or `MASK`.

Note: See cross-section dialog for a current list.

Arguments

t_layername	Layer name is *<class>*/*<subclass>*.

Value Returned

t_layertype	Layer type string.
nil	If an error occurs

See Also

axlXSectionGet

Example

```
axlDBGetLayerType("ETCH/TOP") => "CONDUCTOR"
```


©2023 All Rights Reserved.

axlGetExternalLayers

```
axlGetExternalLayers(
     ) -> lt_layers
```

Description

Returns the names external layers.

Arguments

Nothing

Value Returned

(<top name> <bottom name>)

See Also

axlXSectionGet, axlLayerExternal

Examples

On a PCB design

```
axlGetExternalLayers()
("TOP" "BOTTOM")
```


©2023 All Rights Reserved.

axlGetXSection – Obsolete

```
axlGetXSection(
     )
     ==> ll_layers/nil
```

Description

Important

This is obsolete, use new axlXSectionGet() family of APIs. The command will be maintained for older SKILL code but it will not be enhanced to support new data. Returns a list of all layers in the cross section found in the current drawing.

Values Returned

An ordered SKILL list of layers in the board's cross section. A list of the following format defines each layer:

```
(t_name t_type t_material t_thickness t_thermalCond t_elecCond
 t_dielectricConst y_artworkNeg y_shield t_lossTangent
 t_usage t_SignalDieConstant t_SignalLossTangent g_freqDepFileName)
```

where:

t_name	Layer name.
t_type	Layer type.
t_material	Layer material.
t_thickness	Layer thickness.
t_thermalCond	Layer thermal conductivity.
t_elecCond	Layer electrical conductivity.
t_dielectricConst	Layer dielectric constant.
y_artworkNeg	Indicates whether the artwork for the layer is negative.
y_shield	Indicates whether the layer is a shield layer.
t_lossTangent	Layer loss tangent (valid for dielectrics only).
t_usage	obsolete ("")
t_SignalDieConstant	Dielectric between traces on interior signal layers (or *nil*).

©2023 All Rights Reserved.

t_SignalLossTangent	Dielectric between traces on interior signal layers (or *nil*).
g_freqDepFileName	Defines the name of the frequency-dependent data file for the file; *nil* if no file name is defined for this layer.
t_etchFactor	Defines the etch factor for this layer which is in degrees.

Note: The *t_SignalDieConstant* and *t_SignalLossTangent* are *nil* on PLANE and dielectric layers.

©2023 All Rights Reserved.

axlIsEtchLayer

```
axlIsEtchLayer(
     t_layer
     )
     => t/nil
```

Description

Determines if a layer is associated with the ETCH layers. Returns `t` if layer is associated with any of the ETCH layers — `ETCH`, `PIN`,`VIA`, `DRC`, `VIA_KEEPOUT`, `ROUTE_KEEPOUT`, `ANTI_ETCH`, `BOUNDARY`, `CONSTRAINT_REGION`, `ROUTER_PLAN`, and `CAVITY`

Arguments

t_layer	Layer name (for example, "ETCH/TOP") or just class name ("ETCH")

Value Returns

nil	Not an etch associated layer
t	Is an etch associated layer

Examples

```
axlIsEtchLayer("PIN/TOP")
```

```
axlIsEtchLayer("ETCH")
```


©2023 All Rights Reserved.

axlIsLayer

```
axlIsLayer(
     t_layer
     )
     ⇒ t/nil
```

Description

Determines if the *t_layer* exists. *t_layer* is a fully qualified layer name.

Arguments

t_layer	Name of layer in format "*<class>/<subclass>*."

Value Returned

t	Layer exists.
nil	Layer does not exist.

©2023 All Rights Reserved.

axlIsVisibleLayer

```
axlIsVisibleLayer(
     t_layer
     )
     ⇒ t/nil
```

Description

Returns the visibility (`t/nil`) of a fully qualified layer.

Arguments

t_layer	Name of layer in format "<*class*>/<*subclass*>".

Value Returned

`t`	Layer is visible.
`nil`	Layer is invisible or not present.

Example

```
axlIsVisibleLayer("pin/top") ⇒ t
```


©2023 All Rights Reserved.

axlLayerCreateCrossSection – Obsolete

This function is obsolete, use axlXSectionCreate.

©2023 All Rights Reserved.

axlLayerCreateNonConductor

```
axlLayerCreateNonConductor(
     t_layerName
     )
     ⇒ t/nil
```

Description

Creates a new subclass for non-etch subclasses. AXL-SKILL restricts you from creating etch subclasses.

Arguments

`t_layerName`	*<class>/<subclass>*

Value Returned

`t`	New subclass is created or, subclass already exists.
`nil`	New subclass is not created.

Example

```
axlLayerCreateNonConductor("BOARD GEOMETRY/MYSUBCLASS")
```

Creates a new subclass named `MYSUBCLASS`.

©2023 All Rights Reserved.

axlLayerDelete

```
axlLayerDelete(
     t_layerName/x_layerNumber
     ) => t/nil
```

Description

This command deletes a cross section layer. While axlDeleteObject can be used to delete empty named layers, this API can delete both named and unnamed cross-section layers.The cross section has both ETCH layers and unnamed dielectric layers.The order of the cross section is returned by axlGetXSection – Obsolete. The `x_layerNumber` is the order within the cross-section with the first index number (e.g AIR) starting at 0.

The command can fail in the following scenarios.

- Deleting a named layer containing geometries (excluding pins or vias)
- Deleting top or bottom dielectric or TOP or BOTTOM etch layers
- Layer name does not exist
- Layer number is less then 0 or greater or equal to `length(axlGetXSection('count))`

Arguments

ETCH layer string or cross section index

Value Returned

`t` if layer is deleted, `nil` if failure

Examples

- The command to delete a layer named empty is:

  ```
  axlLayerDelete("EMTPY")
  ```

- Delete the third cross section layer. On most designs this is an unnamed dielectric layer between TOP and the next etch layer.

  ```
  axlLayerDelete(3)
  ```


©2023 All Rights Reserved.

See Also

axlLayerCreateNonConductor, axlDeleteByLayer, axlDeleteObject, axlGetXSection – Obsolete, axlXSectionDelete

©2023 All Rights Reserved.

axlLayerExternal

```
axlLayerExternal(
     t_subclass/x_subclassNumber
     ) -> t/nil
```

Description

Returns if layer is external.

Arguments

t_subclass	Subclass name
x_subclassNumber	The subclass number (Does not mean the cross-section number)

Value Returned

`t`	External
`nil`	Not external

See Also

axlXSectionGet, axlGetExternalLayers

Examples

- On a design

  ```
  axlGetExternalLayers("TOP") -> t
  ```

- On a design

  ```
  axlGetExternalLayers(0) -> t
  ```


©2023 All Rights Reserved.

axlLayerGet

```
axlLayerGet(
     t_layer
     )
     ⇒ o_dbid/nil
```

Description

Gets the layer parameter given the shortcut notation of *<class>*/*<subclass>*. This is an ease of use function that does:

```
axlGetParam("paramLayerGroup:<class>/paramLayer:<subclass>)
```

This function does NOT allow access to the cross-section data (for example, material or thickness). It allows easier access to color and visibility of a layer.

Tip

You can use the groupMembers attribute of result — `result=axlGetParam("paramLayerGroup:<class>")` — to iterate over all subclass of a class.

Arguments

t_layer	Name of layer in format "*<class>*/*<subclass>*".

Value Returned

o_dbid	Layer parameter *dbid*.
nil	Layer is not present.

Example

Changes color of top etch layer.

```
q = axlLayerGet("ETCH/TOP")
q->color = 7
axlLayerSet(q)
axlVisibleUpdate(t)
```


©2023 All Rights Reserved.

See Also

axlGetParam

©2023 All Rights Reserved.

axlLayerRenameNonConductor

```
axlLayerRenameNonConductor (
     t_oldLayerName
     t_newLayerName
     )
     ⇒ t/nil
```

Description

Renames the old subclass to the new name. If the subclass is not found, or if the new name already exists in the design, then no changes will be made.

Arguments

t_oldLayerName	<class>/<subclass>
t_newLayerName	<subclass>

Value Returned

`t`	If subclass was renamed
`nil`	Otherwise

Example

```
axlLayerCreateNonConductor("BOARD GEOMETRY/FOO")
axlLayerRenameNonConductor("BOARD GEOMETRY/FOO" "BAR")
```

See Also

axlLayerCreateNonConductor, axlLayerGet

©2023 All Rights Reserved.

axlLayerViaLabel

```
axlLayerViaLabel(
     t_layerName/x_layerNumber
     ) => t_viaLabel/nil
```

Description

Reports via label for a layer. A via label either defaults to the layer number, or can be assigned by the user through the cross-section. You can query the cross-section for an override.

Arguments

ETCH layer string or cross-section index

Value Returned

Via label name; or `nil`, in case of an error

Examples

- To return the via label of a layer called TOP

```
axlLayerViaLabel("TOP")-> 1
```

See Also

axlXSectionGet

©2023 All Rights Reserved.

axlMaterialGet

```
axlMaterialGet(
     nil
     )
     ==> lt_materials
```

```
axlMaterialGet(
     t_materialName
     )
     ==> og_material
```

```
axlMaterialGet(
     'all
     )
     ==> log_materials
```

```
axlMaterialGet(
     'file
     )
     ==> t_file
```

```
axlMaterialGet(
     'path
     )
     ==> t_pathToFile
```

Description

Returns various information about materials file. Depending on the argument passed, command works in different modes to retrieve the following.

- List of materials
- Number of material file entries
- Name of material file being used; this differ between PCB and IC Packaging products
- Path to material file
- actual attributes of a material file entry

Material attributes as a disembodied property list:

NAME	TYPE	DESCRIPTION
`dielectric`	double	Dielectric Constant
`freqDepFile`	string	Name of frequency dependent file or ""

©2023 All Rights Reserved.

NAME	TYPE	DESCRIPTION
`electricalConductivity`	string	Electrical Conductivity in mho/cm
`lossTangent`	double	Loss Tangent
`name`	string	Name of material
`objType`	string	"material"
`readOnly`	t	Cannot modify object
`thermalConductivity`	string	Thermal Conductivity in w/cm-degC
`thickness`	string	Layer thickness with design units
`tolPlus`	string	Layer thickness tolerance plus with design units
`tolMinus`	string	Layer thickness tolerance minus with design units

Caution

On Windows, performance may be slow, when accessing individual material entries in material file is stored on the network.

©2023 All Rights Reserved.

Arguments

nil	List of material names
t_materialName	Name of material
'all	Get all material data
'filename	Get name of material file (Allegro uses 'material' and IC Packaging products uses 'mcmmat'
'path	Return location of file on disk

Value Returned

nil	An error was detected
lt_materialNames	A list of the material names
og_materials	Disembodied property list of material characteristics (see above)
log_materials	A list of disembodied property lists
t_file	Name of material file in use
t_pathToFile	Path to material file in use

Examples

- Get info about FR-4

```
mat = axlMaterialGet("FR-4")
printf("Thicknesss %L\n" mat->thickness)
```

- Get all materials defined in the materials file

```
names = axlMaterialGet(nil)
```

- Get path of file

```
path = axlMaterialGet('path)
```


©2023 All Rights Reserved.

axlVisibleDesign

```
axlVisibleDesign(
     g_makeVis
     )
     ⇒ t/nil
```

Description

Makes entire design visible or invisible. This command does not visually change the display, since it can also be used in conjunction with the `axlSelect` command family to provide additional filtering of the database objects. If you wish to visually update the display, call `axlUIWUpdate(nil)` after changing the visibility.

Note: This routine along with `axlVisibleGet` and `axlVisibleSet` allows you to temporarily change the visibility of the design to provide additional filtering capability when finding objects via the selection set. The programming model is:

```
saveVis = axlVisibleGet()
axlVisibleDesign(nil)
; set desired layers visible via one or more calls to
axlVisibleLayer(...)
; set find filter for objects to find
axlSetFindFilter(...)
; find objects by using one of the Select APIs .. example
axlAddSelectAll()
objs = axlGetSelSet()

; restore visiblility
axlVisibileSet(saveVis)
; note no need to make a call to axlVisibileUpdate because
; the visisbility changes are a wash
```


©2023 All Rights Reserved.

Arguments

g_makeVis	Either `t` or `nil`. `t` = make entire design visible `nil` = make entire design invisible

Value Returned

`t`	Design made visible or invisible as specified.
`nil`	Should never be seen.

See Also

axlVisibleUpdate and `axlIsVisibleLayer`

Note: This command does not visually change the display. To visually update the display, call `axlUIWUpdate (nil)` after changing the visibility.

©2023 All Rights Reserved.

axlVisibleGet

```
axlVisibleGet(
     )
     ⇒ l_visList/nil
```

Description

Returns the visibility of the entire design - which layers are visible/invisible.

Arguments

None.

Value Returned

l_visList List of lists. The format is for each class:

```
(nil class <t_className> visible t/nil/-1
subclassinfo <l_subclass>)
....)
l_subclass format:
((<t_subclass> t/nil) ....)
where t/nil/-1
t - visible
nil - invisible
-1 - class has both visible and invisible components.
```

Note: Any change in the structure of *l_vislist* affects `axlVisibleSet`, this function's complementary function.

Example

```
visList = axlVisibleGet()
(
(nil class "BOARD GEOMETRY" visible nil subclassinfo nil)
(nil class "COMPONENT VALUE" visible nil subclassinfo nil)
(nil class "DEVICE TYPE" visible nil subclassinfo nil)
(nil class "DRAWING FORMAT" visible nil subclassinfo nil)
(nil class "DRC ERROR CLASS" visible t subclassinfo nil)
(nil class "ETCH" visible -1
subclassinfo
(("TOP" t)
("TRACE_2" nil)
```


©2023 All Rights Reserved.

```
("TRACE_3" nil)
("BOTTOM" t)
))
(nil class "MANUFACTURING" visible nil subclassinfo nil)
(nil class "ANALYSIS" visible nil subclassinfo nil)
(nil class "PACKAGE GEOMETRY" visible nil subclassinfo nil)
(nil class "PACKAGE KEEPIN" visible t subclassinfo nil)
(nil class "PACKAGE KEEPOUT" visible nil subclassinfo nil)
(nil class "PIN" visible t subclassinfo nil)
(nil class "REF DES" visible nil subclassinfo nil)
(nil class "ROUTE KEEPIN" visible t subclassinfo nil)
(nil class "ROUTE KEEPOUT" visible nil subclassinfo nil)
(nil class "TOLERANCE" visible nil subclassinfo nil)
(nil class "USER PART NUMBER" visible nil subclassinfo nil)
(nil class "VIA CLASS" visible nil subclassinfo nil)
(nil class "VIA KEEPOUT" visible nil subclassinfo nil)
)
```

Returns the visibility of the entire design.

©2023 All Rights Reserved.

axlVisibleLayer

```
axlVisibleLayer(
     t_layer
     g_makeVis
     )
     ⇒ t/nil
```

Description

Sets a given layer to visible or invisible. If given only a class name, sets the entire layer to visible or invisible. If you want to update the display, call `axlVisibleUpdate` when finished with your layer visibility updates.

Arguments

t_layer	Name of the layer. Either a fully qualified layer name in the format *<class>*/*<subclass>* or a class name in the format *<class>*.

g_makeVis	Either `t` or `nil`.
	`t = make visible`
	`nil = make invisible.`

Value Returned

`t`	Layer set to visible or invisible as specified.
`nil`	Layer does not exist.

See Also

axlVisibleUpdate

Note: This command does not visually change the display. To visually update the display, call `axlUIWUpdate (nil)` after changing the visibility.

©2023 All Rights Reserved.

axlVisibleSet

```
axlVisibleSet(
      l_visList
     )
     ⇒ t/nil
```

Description

Sets the visibility of the entire design.

Arguments

l_visList	List with visibility attributes.

Value Returned

`t`	Set the visibility of the design as specified.
`nil`	Incorrect format for *l_visList*.

See Also

axlVisibleUpdate and axlVisibleLayer

Note: This command does not visually change the display. To visually update the display, call `axlUIWUpdate (nil)` after changing the visibility.

©2023 All Rights Reserved.

axlConductorBottomLayer

```
axlConductorBottomLayer(
     )
     ⇒ t_name
```

Description

Returns the name of the bottom conductor layer.

Arguments

none

Value Returned

`t_name`	Name of the bottom conductor layer.

Example

```
axlConductorBottomLayer()
⇒ "BOTTOM"
```


©2023 All Rights Reserved.

axlConductorTopLayer

```
axlConductorTopLayer()
     ⇒ t_name
```

Description

Returns the name of the top conductor layer.

Arguments

none

Value Returned

`t_name`	Name of the top conductor layer.

Example

```
axlConductorTopLayer()
⇒ "TOP"
```


©2023 All Rights Reserved.

axlDBCreateFilmRec – Obsolete

This interface is obsolete. It is kept to support existing SKILL code.

Instead, use axlFilmCreate

©2023 All Rights Reserved.

axlSetPlaneType

```
axlSetPlaneType(
     t_subclassName
     t_planeType
     )
     ⇒ t/nil
```

Description

This changes the photoplot type of a conductor or plane type layer between positive or negative artwork. Changing a layer already containing data will require re-voiding existing shapes and updating DRC.

Arguments

t_subclassName	Subclass name whose plane type is to be changed.
t_planeType	Plane type (“Positive”, “Negative”)

Value Returned

`t`	Plane type changed.
`nil`	Plane type is not changed.

See Also

axlGetParam, axlSetParam

©2023 All Rights Reserved.

axlSubclasses

```
axlSubclasses(
     t_class
     ?field s_name
     ?value g_value
     ) -> lt_subclasses
```

Description

Lists subclasses that make up a class. This function is supported in both, APD and Allegro name space. The field and value options provide additional filtering based upon the characteristics of the layer.

The information about the attributes and values permitted on a layer, can be obtained using the following function.

```
axlLayerGet("MANUFACTURING/PROBE_TOP")->??
```

You should map the class name via axlMapClassName if you are writing code for both PCB and APD+ as certain class names are different in these products.

The base call is actually just:

```
axlGetParam("paramLayerGroup:ETCH")->groupMembers
```

Arguments

t_class	Class name.
field	Optional field for filtering. If value option is not present filters on basis of a non-nil value.
value	Optional value of field to use for filtering. Requires field option to be passed.

Values Returned

lt_subclasses	A list of subclass strings.

See Also

axlSubclassRoute, axlGetParam, axlMapClassName, axlClasses

©2023 All Rights Reserved.

Example

- get all subclasses on class

```
axlSubclasses( axlMapClassName("MANUFACTURING"))
```

- get user defined subclasses

```
axlSubclasses("MANUFACTURING" ?field 'userDefined)
```

- all allegro defined

```
axlSubclasses("MANUFACTURING" ?field 'userDefined ?value nil)
```


©2023 All Rights Reserved.

axlSubclassRoute

```
axlSubclassRoute(
     ?field s_name
     ?value g_value
     ) -> lt_subclasses
```

Description

Lists subclasses that make up class ETCH.

If no arguments are passed to the function, it returns a list of subclasses in the ETCH class, or CONDUCTOR class, in case of non-PCB product.

The field and value options provide additional filtering based upon the characteristics of the layer. For information on layer parameters, see the section Layer Parameter Attributes (Allegro Subclasses).

The information about the attributes and values permitted on a layer can be obtained using the following command.

```
axlLayerGet("ETCH/TOP")->??
```

The base call is actually just:

```
axlGetParam("paramLayerGroup:ETCH")->groupMembers
```

Arguments

`field`	Optional field for filtering. Uses the value specified by the `value` argument to filter subclasses.
`value`	Optional value of field to use for filtering. Requires field option to be passed.

Values Returned

List of subclass as strings.

See Also

axlSubclasses, axlGetParam

©2023 All Rights Reserved.

Example

- all etch subclasses

```
axlSubclassRoute() -> ("TOP" "GND" "VCC" "BOTTOM")
```

- all subclasses that are of type etch

```
axlSubclassRoute(?field 'isEtch)
```

- all subclasses that are not etch (e.g dielectric)

```
axlSubclassRoute(?field 'isEtch ?value nil)
```

- all subclasses with material FR-4

```
axlSubclassRoute(?field 'material ?value "FR-4")
```


©2023 All Rights Reserved.

axlXSectionAssign

```
axlXSectionAssign(
     t_crossSection/nil
     g_layer/og_layer
     ) -> t/nil
```

Description

Assigns an existing layer to a cross-section. In the recommended model, it is used in building additional cross-sections from the primary cross-section.

Use axlXSectionCreate to a create a cross-section layer.

This API should be used to manage multiple cross-sections. Should not be used if you are not doing rigid-flex design. It is not supported in the symbol editor.

Arguments

t_crossSection	Name of cross-section `nil` is the primary cross-section
g_layer	Can be: ■ o_xsectionDBid - Cross-section dbid ■ t_layerName - name of etch layer ■ x_number - position of entry in "All Stackups"
og_layer	List of layers to assign

Value Returned

`t`	Layer assigned (if layer is already part stackup returns `t`)
`nil`	Failed, illegal name, editor does not support this interface or assignment not permitted

See Also

axlXSectionCreate

Examples

see `<cdsroot>/share/pcb/examples/skill/dbcreate/xsection.il`

©2023 All Rights Reserved.

axlXSectionCopy

```
axlXSectionCopy(
     o_xsectionDBID
     ) => g_xsectionDefstruct/nil
```

Description

This copies dbid xsection to an xsection SKILL defstruct. It can be used to duplicate the characteristics of an existing xsection layer to a new layer for use with axlXSectionCreate. Alternatively, it can be used to modify an existing layer via axlXSectionSet, although axlXSectionModify might be a better fit for changing a layer.

This creates a new defstruct using `make_axlXSection()`.The name attribute is never copied.

Caution

If using this to copy named layers, you need to set the name attribute in the defstruct returned by this function.

Arguments

o_xsectionDBID	a xsection dbid

Value Returned

g_xsectionDefstruct	a defstruct with its attribute data copied from dbid

Examples

- See `<cdsroot>/share/pcb/examples/skill/dbcreate/xsection.il`

See Also

axlXSectionCreate, axlXSectionModify

©2023 All Rights Reserved.

axlXSectionCreate

```
axlXSectionCreate(
     t_stackup/nil
     g_option
     [g_xsectionDefStruct]
     ) -> o_xsectionDBID/nil
```

Description

Creates a new cross-section entry.

The three critical create items in `g_xsectionDefStruct` are:

- name – a string which is a name of the layer
- layerType – a string (see `axlXSectionLayerTypes()` for supported of types) that describes the type of layer.

  Popular types are CONDUCTOR, PLANE, DIELECTRIC or MASK. If no value is specified, DIELECTRIC is used as the default value.
- material – a string that describes substance making up the cross-section layer. If no value is specified, FR-4 is used as the default value for dielectrics and COPPER for conductor or plane layers.

If no attributes are provided, an unnamed cross-section entry of type DIELECTRIC, with material FR-4 is created.

You can set other cross-section entries, see axlXSectionGet for a description of the other available attributes. If material is provided it will auto-fill additional attributes based upon the material file entry.

For named cross-section layers, it creates a class/subclass on the etch layers, it does not set the color and visibility for those layers. You need to use `axlLayerSet` for those attributes.

Allegro PCB Editor does not allow name layers above TOP or below BOTTOM layers.

CREATING AND POPULATING MULTIPLE CROSS-SECTIONS

Two models are supported for creating multiple cross-section; assign and create directly. The recommend model is assign.

©2023 All Rights Reserved.

The ASSIGN model:

- Create all the stackups (axlXSectionCreateStackup).
- Optionally, rename the Primary stackup (axlXSectionRename).
- Populate the "All Stackups" (use nil as the first argument to axlXSectionCreate) with the layers. All internal (etch and dielectric) layers are assigned to all stackups.
- Create required mask layers (axlXSectionCreate).
- Assign (axlXSectionAssign) the non-mask layers to the non-primary stackups
- Remove (axlXSectionRemove) any mask layer which is not required in the primary stackup.

By default, all layers created in this model are initially assigned to the primary stackup. The downside with this model is that unwanted layers from the primary stackup are to be removed.

The CREATE DIRECTLY mode

- Create all the stackups (axlXSectionCreateStackup).
- Optionally, rename the primary stackup (axlXSectionRename).
- Provide a stackup name to axlXSectionCreate when creating a layer. If the layer is an ETCH layer, it is also assigned to the primary stackup.
- Must assign dielectric layers to primary since only ETCH layers are automatically assigned to this stackup.
- Assign (axlXSectionAssign) layers to any additional stackups.

The downside of this model is to assign (axlXSectionAssign) mask or internal layers if required in multiple stackups. This is also true for any dielectric layers that must be in the primary stackup.

PROGRAMMING TIPS

- For populating multiple internal layers, use the `'bottom` option and build the stackup from bottom to top.
- Use `'afterBottom` option to assign MASK layers below BOTTOM.
- Ensure that there is at least one dielectric layer between each CONDUCTOR or PLANE layer type. Adjacent routing layers are allowed, but this results in incorrect signal analysis.

©2023 All Rights Reserved.

- Do not name dielectric layers unless you want to physically add and edit objects to those layers. In Allegro PCB Editor, every named layers creates an entry in the class/subclass table on ETCH related classes.
- Material names that are not contained in the materials file, can also be specified. Setting environment variable "*`xsection_material_warning`*" prints a warning. When unknown materials are specified the thickness and other associated data are not populated.
- Changing the material also updates its associated data. This is only an issue with the `axlXSectionSet` API.
- layerId defaults to the layer number.
- When creating MASK layers, you must provide the `?name` option. If you provide both, a `?name` and `?maskLayer` option, then `?maskLayer` name wins.
- MASK layers added between TOP and BOTTOM do not effect connectivity.
- Constraint Manager removes the '_' in pretty printing layerFunction.This interface requires them (see types returned by `axlXSectionLayerFunctions` API). Mask and dielectric have different allowed function types.
- Use `axlXSectionModify` or axlXSectionCopy to create the `axlXSection` defstruct. Do not directly call `make_axlXSection`.
- DRC is marked out of date with cross-section changes.

©2023 All Rights Reserved.

Arguments

nil	default stackup (primary or All stackups)	
t_stackup	in a multi-stackup design the name of the stackup	
g_option		
	'top	insert layer above TOP. For PCB designs this can only be a unnamed dielectric or MASK layers.
	'bottom	insert layer above BOTTOM
	'afterBottom	insert layer after BOTTOM. For PCB Designs this can only be unnamed dielectrics or MASK layers.
	t_etchSubclass	subclass name, insert layer above this name
	x_position	insert above cross-section position.This is the number field in the cross-section dbid. In designs with one cross-section, you can also use the position attribute. You cannot insert above 0 (Surface).
g_xsectionDefStruct or *nil*	A SKILL defstruct with all possible attributes for cross-section entry	
	make_axlXSection	creates a new entry
	copy_axlXSection	copies an existing entry
	axlXSectionCopy	copies contents of an existing cross-section dbid to a new defstruct.

Value Returns

o_xsectionDBID	if successful

©2023 All Rights Reserved.

`nil` failed.

Examples

See `<cdsroot>/share/pcb/examples/skill/dbcreate/xsection.il`

See Also

axlXSectionGet, axlXSectionSet, axlXSectionDelete, axlXSectionLayerTypes, axlXSectionCopy, axlXSectionModify, `axlXSectionLayerFunctions`, axlXSectionCreateStackup, axlXSectionDeleteStackup, axlXSectionRename, axlXSectionAssign, axlXSectionRemove, axlZoneCreate

©2023 All Rights Reserved.

axlXSectionCreateStackup

```
axlXSectionCreateStackup(
     t_crossSection
     ) -> t/nil
```

Description

This creates a new empty stackup with name, `t_name`.

Should not be used if you are not doing rigid-flex design. It is not supported in the symbol editor.

Arguments

t_crossSection	Name of stackup (case insensitive)

Value Returned

`t`	Stackup created
`nil`	Failed, stackup exists, illegal name, editor does not support this interface or exhausted the maximum number of stackups

See Also

axlXSectionCreate

Examples

See `<cdsroot>/share/pcb/examples/skill/dbcreate/xsection.il`

©2023 All Rights Reserved.

axlXSectionDelete

```
axlXSectionDelete(
     g_option
     ) => lt_types
```

Description

Deletes a cross section layer. If layer is associated with an ETCH layer, the associated layer is also deleted. Associated ETCH layers must not have objects. See axlLayerDelete for other reasons for failure.

Arguments

g_option	
o_xsectionDBID	delete layer by XSection dbid
t_etchSubclass	delete layer by this name
x_position	delete layer by position. This is the position attribute in the xsection dbid.

Value Returned

t	if successful
nil	failed.

Examples

See `<cdsroot>/share/pcb/examples/skill/dbcreate/xsection.il`

See Also

axlXSectionCreate, axlLayerCreate, axlDeleteByLayer

©2023 All Rights Reserved.

axlXSectionDeleteStackup

```
axlXSectionDeleteStackup(
     t_crossSection
     ) -> t/nil
```

Description

Deletes a stackup with name `t_name`. Cannot delete a stackup assigned to a zone.

Arguments

`t_crossSection`	Name of stackup (case insensitive)

Value Returned

`t`	Stackup is deleted
`nil`	Stackup is in use or not found

See Also

axlXSectionCreate

Examples

Delete a "flex1" created by RigidFlexCreate()

in `<cdsroot>/share/pcb/examples/skill/dbcreate/xsection.il`

see axlXSectionCreateStackup

```
axlXSectionDeleteStackup("flex1")
```


©2023 All Rights Reserved.

axlXSectionGet

```
axlXSectionGet(
     g_stackup/nil
     g_option
     )
     ==> g_data/nil
```

Description

Returns data about the cross-section entry for a design.

Supports multiple access options (see Arguments).

Allegro design color and visibility query needs are satisfied by the axlLayerGet API.

©2023 All Rights Reserved.

Arguments

g_stackup

nil	for cross-sections with a single stackup this returns the standard stackup. For Rigid-Flex designs this returns All Stackups.
str	name of stackup. From zone groups it is the name in zoneDbid -> stackup or available stackups are returned by `axlXSectionGet(nil 'stackups)`

g_option

'stackups	return a list of stacks. g_xsection is ignored and should be nil
'count	return number of cross-section entries for provided stackup. g_data is x_entries
'number	return maximum number of individual stackups database supports
'thickness	return provided stackup thickness in user units g_data is f_thickness design units, accuracy is not restricted to current design accuracy. This is the total thickness with masks.
'top	return cross-section entry for top layer of design
'bottom	return cross-section entry for bottom layer of design
x_position	return cross-section entry for given position in "All stackups". This is the number field in a cross-section dbid. (0 is the 1st layer -- air)
t_etchSubclass	name of etch subclass. g_data is a o_xsectionDBID
'all	return entire stackup. g_data must be a lo_xsectionDBID

©2023 All Rights Reserved.

`'locked`	lock status ■ nil - not locked list of lock status. This is a user interface lock only. SKILL and techfile can make changes. ■ `'value:` cannot edit values ■ '`layer`: add or delete layers

Tip

The name of the stackup can be obtained from the zone dbid by zoneDbid->stackup

Tip

If using a single stackup in a design pass `nil` as the first argument.

Tip

If a multi-stackup design, a nil returns all of the cross-section dbids (for example, "All Stackups"). If you need the main stackup, typically called “primary”, use its name.

Tip

Except for `'stackups` and `'locked` all other options take into account the stackup argument.

Tip

For `'thickness` if `g_xsection` is nil, the stackup thickness is returned, which can be overridden by the TEXT_BOARD_THICKNESS property assigned at the design level. Otherwise, if a stackup (`g_xsection`) name is provided, the calculated thickness of the indicated stackup is returned.

©2023 All Rights Reserved.

XSection Attributes:

Attributes that have Yes under Modify column can be set with APIs axlXSectionCreate and axlXSectionSet.

NAME	TYPE	Modify	DESCRIPTION
`objType`	string	No	"xsection"
`readOnly`	t	No	Cannot directly modify entry
`constraint`	string	Yes	(Optional) Techfile generic layer support (max 1023 chars).
`conductor`	t/nil	Yes	Is layer of conductor or plane?
`layerType`	string	Yes	Type of xsection layer.
`layerFunction`	string	Yes	Layer function of a layer. This is a superset of layer types for dielectric and mask layers. Conductor, plane and surface layers cannot have their layerFunction changed. When creating a layer, Allegro automatically assigns a default function based on the layer type. Can be nil (surface layers).
`layerId`	string	Yes	Override of via label id (max 3 characters)
`material`	string	Yes	Layer material (max 250 chars)
`maskLayer`	string	Yes	Mask layer associated with this cross-section entry. This is `nil` unless the layerType is type MASK. If a string is present it will have the same name as the name field.
`mfg`	string	Yes	(Optional) Stackup layer grouping for IPC2581 (max 255 chars)
`name`	string/nil	Yes	Name of xsection/etch layer (max 47 chars).

©2023 All Rights Reserved.

NAME	TYPE	Modify	DESCRIPTION
`negativeArtwork`	t/nil	Yes	Layout is a negative image.
`polyCutLayer`	t/nil	Yes	Layer is a cut layer for poly vias. Only dielectric layers between the surface layers may be cut layers. You cannot unset a cut layer that is being used by a poly via.
`position`	integer	No	Position of xsection layer in stackup. This is relative to the stackup. (starts at 0 for SURFACE).
`number`	integer	No	Absolute position which is the position in "All Stackups". In non-multi cross-section designs this has the same value as position.
`prop`	l_dbid	Yes	List of properties on object.
`thickness`	float	Yes	layer thickness in design units, stored with more accuracy then design
`tolMinus`	float	Yes	thickness tolerance - in design units, stored with more accuracy then design
`tolPlus`	float	Yes	thickness tolerance + in design units, stored with more accuracy then design
`Pad suppression:`			
`unusedPin`	t/nil	Yes	suppress unused pads of pins on this layer
`unusedVia`	t/nil	Yes	suppress unused pads of vias on this layer
`Embedded support:`			

©2023 All Rights Reserved.

NAME	TYPE	Modify	DESCRIPTION
`embedded`	string	Yes	Type of embedded layer (default NOT_EMBEDDED) Values: nil, NOT_EMBEDDED, BODY_UP, BODY_DOWN PROTRUDING_ALLOWED
`embeddedAttach`	string	Yes	Type of attachment if embedded layer. Values: nil, DIRECT_ATTACH, INDIRECT_ATTACH
`Electrical parameters:`			
`diffCouplingType`	string	Yes	Diffpair routing on layer (Values: nil or EDGE)
`diffSpacing`	float	Yes	Typical diffpair spacing on this layer in design units (only if coupling type is set)
`conductivity`	string	Yes	Layer conductivity (MKS in mho/cm)
`dielectricConst`	string	Yes	Dielectric constant
`etchFactor`	integer	Yes	Vertical geometry of etch (angle 45-135 or 225-315 degrees)
`freqDepFile`	string	Yes	(optional) Frequency dependent file for this layer (max 255 chars)
`lossTangent`	string	Yes	Loss tangent value
`shield`	t/nil	Yes	Is this a shield layer
`width`	float	Yes	Typical layer width for Impedance what-ifs in design units
`siIgnore`	t/nil	Yes	SI should ignore this layer

©2023 All Rights Reserved.

Value Returned

`nil`	an error
`g_data`	depends on g_option, see **Arguments** section

Examples

- Get design thickness

```
thick = axlXSectionGet(nil 'thickness)
```

- Fetch entire cross-section

```
stackup = axlXSectionGet(nil 'all)
```

- Fetch just the TOP layer

```
xs = axlXSectionGet(nil 'top)
```

- Fetch dielectric below top-most layer

```
xs = axlXSectionGet(nil 'top)
dielectric = axlXSectionGet(nil xs->number +1)
axlPrintDbid(dielectric)
```

- Get all stackups (even with one stackup will return PRIMARY)

```
stackups = axlXSectionGet(nil 'stackups)
```

- Get stackup called FLEX2

```
zoneStackup = axlXSectionGet("FLEX2" 'all)
```

- Get number of layers in FLEX2 (includes etc, dielectric and layers above surface)

```
zoneStackup = axlXSectionGet("FLEX2" 'count)
```

- See `<cdsroot>/share/pcb/examples/skill/dbcreate/xsection.il`

©2023 All Rights Reserved.

axlXSectionLayerFunctions

```
axlXSectionLayerFunctions(

     ) => lt_types
```

Description

Return list of supported layer function types. Layer functions are a super set of layer types.

Arguments

None

Value Returned

- List of strings of supported layer types.

Examples

Get the list of layer functions:

```
types = axlXSectionLayerFunctions()
```

See Also

axlXSectionCreate

©2023 All Rights Reserved.

axlXSectionLayerTypes

```
axlXSectionLayerTypes(

     ) => lt_types
```

Description

Return list of supported layer types. This is used with layerType attribute when adding or modifying xsection layers.

Arguments

None

Value Returned

- List of strings of supported layer types.

See Also

axlXSectionCreate

Examples

```
only use types = axlXSectionLayerTypes()
```


©2023 All Rights Reserved.

axlXSectionModify

```
axlXSectionModify(
     <list of defstruct attributes and values>
     ) => g_xsectionDefstruct/nil
```

Description

This is a wrapper for `make_axlXSection()` function to create a new defstruct. For certain fields (for example, boolean and some string fields) a `'none` symbol is used to indicate that the field should not be changed, other fields can use the default `nil` symbol.

Arguments

Same as `make_axlXSection()`.

Value Returned

`g_xsectionDefstruct`	a defstruct with its attribute data copied from provided arguments

Examples

- Modify a layer to be negative artwork assume a layer named GND exists. All other layer characteristics will remain the same

```
xs = axlXSectionGet(nil "GND")
negative = axlXSectionModify(?negativeArtwork t)
ret = axlXSectionSet(xs negative)
```

- See <cdsroot>`/share/pcb/examples/skill/dbcreate/xsection.il`

See Also

axlXSectionCreate

©2023 All Rights Reserved.

axlXSectionRemove

```
axlXSectionRemove(
     t_crossSection/nil
     g_layer/og_layer
     ) -> t/nil
```

Description

Removes a layer from indicated stackup. The layer is not deleted, it is de-assigned from a stackup. There are rules (see cross-section documentation) for layer membership in stackups. If you do something not permitted a nil is returned.

Its typical use is when building a multi-cross section design. It removes mask layers from the primary cross-section.

This is used to manage multiple cross-sections. It is not applicable to a single cross-section design. It is not supported in the symbol editor.

Use axlXSectionDelete if a layer should be deleted.

Arguments

t_name	Name of stackup (case insensitive) if `nil`, it uses the Primary stackup
g_layer	Can be: ■ o_xsectionDBid: Cross-section dbid ■ t_layerName: Name of etch layer ■ x_number: Position of entry in "All Stackups"
og_layer	List of layers to remove

Value Returned

`t`	Layer removed from stackup (if layer is already not part of the stackup it returns `t`)
`nil`	Failed, illegal name, editor does support interface, layer cannot be removed

See Also

©2023 All Rights Reserved.

axlXSectionCreate

Examples

See `<cdsroot>/share/pcb/examples/skill/dbcreate/xsection.il`

©2023 All Rights Reserved.

axlXSectionRename

```
axlXSectionRename(
     t_crossSection/nil
     t_newName
     ) -> t/nil
```

Description

Renames a stackup. If first argument is nil, renames the primary stackup.

Should not be used if you are not doing rigid-flex design.It is not supported in the symbol editor.

Arguments

t_crossSection	Existing name of stackup
t_newName	New name of stackup (case insensitive)

Value Returned

`t`	Stackup renamed
`nil`	Failed

See Also

axlXSectionCreate

Examples

Assume a multi-stackup design rename the default primary name

```
axlXSectionRename(nil "rigid")
```


©2023 All Rights Reserved.

axlXSectionSet

```
axlXSectionSet(
     g_option
     [g_xsectionDefStruct]
     ) -> t/nil


axlXSectionSet(
     'locked
     nil/l_lockType
     ) -> t/nil
```

Description

Modifies an existing cross-section entry. Use axlXSectionModify to create a xsection defstruct with the attributes you wish to modify.

See axlXSectionGet for a description of the other available attributes. If changing material, it also updates the material characteristics to values of the new material.

Allegro PCB editor does not allow name layers above top or below bottom.

PROGRAMM TIPS:

- See tips in axlXSectionCreate.
- In Allegro PCB Editor, you cannot rename TOP or BOTTOM.
- Cannot unname a layer with data on the ETCH layers.
- DRC is marked out of date.

©2023 All Rights Reserved.

Arguments

nil	first argument must always be `nil`	
g_option		
	o_xsectionDBID	delete layer by cross-section dbid
	t_etchSubclass	modify by subclass name
	x_position	modify by cross-section position. This is the number attribute in the cross-section dbid.
	'locked	update user interface layer locking
g_xsectionDefStruct	A SKILL defstruct with all possible attributes for cross-section entry	
	make_axlXSection	creates a new entry
	copy_axlXSection	copies an existing entry
	axlXSectionCopy	copies contents of an existing cross-section dbid to a new defstruct.
l_lockType	change user interface locking	

- nil - unlock
- `'layer` - prevent layer addition or deletion
- `'value` - prevent changing values
- list of both 'layer and 'value

Value Returned

t	if successful
nil	failed.

See Also

axlXSectionCreate, axlXSectionCopy

©2023 All Rights Reserved.

Examples

- See `<cdsroot>/share/pcb/examples/skill/dbcreate/xsection.il`
- lock layer values

```
axlXSectionSet('locked 'layer)
```


©2023 All Rights Reserved.

4

Selection and Find Functions

Overview

AXL edit functions such as move or delete operate on database object `dbids` contained in the *select set*. The select set is a list of one or more object `dbids` you have previously selected. You add `dbids` to the select set with the `axlSelect` functions described in this chapter. You use the select set as an argument in any edit function calls. This differs from interactive Allegro PCB Editor edit commands, where you first start a command, then select the objects to be edited. One advantage of a select set is that selected object `dbids` stay in the select set from function to function until you explicitly change it. You can perform multiple edits on the same set of objects without reselecting. Remember, however, that edit functions might cause `dbids` to go out of scope. This chapter also describes functions for managing the select set and controlling the selection filter.

AXL supports one active select set. The contents of the select set becomes invalid when you exit Allegro PCB Editor.

The interactive select functions find objects only on visible layers.

You can do the following with the selection functions:

- Set the Find Filter to control the types of objects selected
- Select objects at a single point, over an area, or by name
- Select parts of objects, such as individual pins of a package symbol
- Add or remove `dbids` from the select set

A select set can contain `dbids` of parts of a figure without containing the figure itself. For example, you can select one or more pins of a symbol or individual segments of a path figure. See Chapter 2, “The Allegro PCB Editor Database User Model,” for a list of Allegro PCB Editor figure types.

You can add figure `dbids` to the select set interactively with a mouse click on the figure (point selection) or by drawing a box that includes the figure (box selection). The **Find Filter**

©2023 All Rights Reserved.

controls filtering for specific object types. This chapter describes AXL–SKILL functions to set the filter for any object type.

All coordinates are in user units unless otherwise noted.

Select Set Highlighting

Objects in the select set are displayed as highlighted when control passes from SKILL to you for interactive input (for selection) or when SKILL returns control to the Allegro PCB Editor shell. You can select and modify objects using AXL–SKILL functions. To keep these objects from displaying as highlighted, remove them from the select set before returning SKILL control to you for interactive input or to the Allegro PCB Editor shell.

Select Modes

AXL provides two select modes:

`single`	Selects one or a group of objects that match the selection criteria. When you select an object in this mode, AXL deselects any objects previously in the select set.
`cumulated`	Adds to or subtracts from the select set one or a group of objects that match the selection criteria. Add cumulated mode never adds an object already in the set, so you do not have duplicate entries if you mistakenly select the same object twice. Subsequent selects of the same object are ignored.

Finding Objects by Name

The `axlSingleSelectName`, `axlAddSelectName`, and `axlSubSelectName` functions find objects by using their names. You can search for the following Allegro PCB Editor object types by name:

`NET`	List of net names for net selection.
`COMPONENT`	List of reference designators for component instance selection.
`SYMBOL`	List of reference designators for symbol instance selection.
`FUNCTION`	List of function designators for function instance selection.
`DEVTYPE`	List of device type for component or symbol instance selection. **

©2023 All Rights Reserved.

`SYMTYPE`	List of symbol types for symbol instance selection.
`REFDES`	List of reference designators for component or symbol instance selection. **
`DEVSYM`	List of device type for symbol instance selection.
`GROUP`	List of group names for group or group member selection.
`PROPERTY`	List of property names or property value) lists for selection of database object that have the property/value. If no value is provided, the value will be ignored for the database property comparison. The find filter enabled and onButtons control the type of elements that will be selection.

** For DEVTYPE and REFDES, a component instance is selected if COMPONENTS are in the find filter ?enabled list. Otherwise, if SYMBOLS are enabled, a symbol instance is selected.

See the descriptions of the `SelectName` functions for how to set up the arguments.

Point Selection

These functions select objects at a single geometric point. They prompt you for the point if that argument is missing from the function call.

```
axlSingleSelectPoint
axlAddSelectPoint
axlSubSelectPoint
```

Area Selection

These functions select objects over an area. They prompt you for the area (*`Bbox`*) if that argument is missing from the function call.

```
axlSingleSelectBox
axlAddSelectBox
axlSubSelectBox
```


©2023 All Rights Reserved.

Miscellaneous Select Functions

These functions select by other means as shown in each function description later in this chapter:

`axlAddSelectAll`

`axlSubSelectAll`

`axlSingleSelectName`

`axlAddSelectName`

`axlSubSelectName`

`axlSingleSelectObject`

`axlAddSelectObject`

`axlSubSelectObject`

axlSelect–The General Select Function

One function, `axlSelect`, combines the capabilities of the `axlAddSelect` functions. Use `axlSelect` as you write interactive commands to give the user the same select capabilities available in Allegro PCB Editor commands *move* or *delete*.

Select Set Management

These functions manage the select set:

`axlGetSelSet`

`axlGetSelSetCount`

`axlClearSelSet`

Find Filter Control

These functions control the selection filter:

- `axlGetFindFilter`
- `axlSetFindFilter`

©2023 All Rights Reserved.

Find Filter Options

You can restrict selection in a given window to a subset of all possible figure types by using the **Find Filter** or the `FindFilter` functions described in this chapter. `FindFilter` functions also control whether the **Find Filter** is immediately visible to you.

The permissible keywords for the *`lt_options`* list are shown. These keywords are a subset of the Allegro PCB Editor Find Filter. You can prefix any of these keywords with `NO` to reverse the effect. See the description of axlSetFindFilter on page 314 for details on how to use these keywords:

`Global`	`ALL`, `ALLTYPES`, `EQUIVLOGIC`
`Figures`	`PINS`, `VIAS`, `CLINES`, `CLINESEGS`, `LINES`, `LINESEGS`, `DRCS`, `TEXT`, `SHAPES` (includes rectangles), `SHAPESEGS`, `VOIDS`, `VOIDSEGS`, `TEXT`. **Note:** The *`xxx`*`SEG` keywords also select arc and circle segments
`Logic`	`COMPONENTS`, `SYMBOLS`, `NETS`

Except for `EQUIVLOGIC`, the *Find Filter* functions take the keywords in the order found. For example, the list `(ALL NOPIN)` results in all objects except pins being selectable.

`EQUIVLOGIC` is a global find state. It instructs *find* to select the physically equivalent parts, as specified in the filter of the found logic object. For example, if the user picks any physical part of a net, the selection returns any physical parts of the (logical) net selected by the *find filter*. Both the logical and the physical objects must be enabled. For example, to select all pins of a net, both `NETS` and `PINS` must be enabled and set with `?onButton`.

©2023 All Rights Reserved.

Selection and Find Functions

This section lists selection and find functions.

axlSingleSelectPoint

```
axlSingleSelectPoint(
     [l_point]
     [trapEnable]
     )
     ⇒ t/nil
```

Description

Finds an object that is close to the input point and meets the *Find* filter criteria and adds that object to the selection set after clearing all previous selections. If no point is provided, prompts to select a point prior to the find operation.

`axlSingleSelectPoint` selects a single object and adds it to the select set, unless `EQUIVLOGIC` is on. In that case, it may select multiple objects, for example, if it finds a qualified figure (such as a pin, connect line, or via) that is part of a net. `axlSingleSelectPoint` adds all the qualified figures that belong to the net to the select set. (See the Find Filter Options on page 281.)

This finds objects within the current trapsize (`axlGetTrapBox`), which varies based upon the zoom factor.

©2023 All Rights Reserved.

Arguments

l_point	Coordinate pair for xy location where objects are to be found.
trapEnable	By default, enables a a trap box, which is based on the zoom level of the canvas. Objects that are found can be effected based on the current zoom level. When this option is set to `nil` the trap size gets disabled.

Value Returned

`t`	One or more *dbids* put in the select set.
`nil`	No *dbids* put in the select set.

Note: An object which is currently in the selection set may be reselected if there are no unselected objects that qualify for selection at the given point and find filter.

Example

Adds a previously defined user property `MYPROP` to a pin at X6325 Y3575.

```
axlSetFindFilter(?enabled "pins" ?onButtons "pins")
     axlSingleSelectPoint( 6325:3575 )
     axlDBAddProp(axlGetSelSet() list( "MYPROP" 23.5))
     ⇒ t
```

To check

1. From Allegro PCB Editor, choose *Display – Element*.
2. Select the pin to display its properties.

©2023 All Rights Reserved.

The **Show Element** window displays *MYPROP* with value *23.500000 level*

See Also

axlAddSelectPoint

©2023 All Rights Reserved.

axlAddSelectPoint

```
axlAddSelectPoint(
     [l_point]
     [trapEnable]
     )
     ⇒ t/nil
```

Description

Finds a non-selected object that is close to the input point and meets the *Find* filter criteria and adds that object to the selection set. If no point is provided, prompts to select a point prior to the find operation.

Selects a single object and adds it to the select set, unless `EQUIVLOGIC` is on. In that case, it may select multiple objects, for example, if it finds a qualified figure (such as a pin, connect line, or via) that is part of a net. Adds all the qualified figures that belong to the net to the select set. (See the Find Filter Options on page 281.)

This function finds objects within the current trapsize (`axlGetTrapBox`), which varies based upon the zoom factor.

Arguments

l_point	Coordinate pair for xy location where objects are to be found.
trapEnable	Set to `nil` to restrict found elements to exactly matching location, instead of close to the location.

Value Returned

`t`	One or more *dbids* put in the select set.
`nil`	No *dbids* put in the select set.

Example

See axlSingleSelectPoint on page 282 for an example. `axlSingleSelectPoint` has the same behavior except that it selects only one object.

©2023 All Rights Reserved.

See Also

axlSingleSelectPoint, axlSubSelectBox, axlSingleSelectBox, axlAddSelectBox, axlSubSelectPoint

©2023 All Rights Reserved.

axlSubSelectPoint

```
axlSubSelectPoint(
     [l_point]
     [trapEnable]
     )
     ⇒ t/nil
```

Description

Finds a selected object that is close to the input point and meets the find filter criteria and removes that object from the selection set. If no point is provided, prompts to select a point prior to the find operation.

Removes a *single* object from the select set, unless `EQUIVLOGIC` is on. In that case, itmay find multiple objects, for example, if it finds a qualified figure (such as a pin, connect line, or via) that is part of a net. Deletes all the qualified figures that belong to the net from the select set. (See the Find Filter Options on page 281.)

This function finds objects within the current trapsize (`axlGetTrapBox`), which varies based upon the zoom factor.

Arguments

`l_point`	Coordinate pair for xy location where objects are to be found.
`trapEnable`	Set to `nil` to restrict found elements to exactly matching location, instead of close to the location.

Value Returned

`t`	One or more *`dbids`* removed from the select set
`nil`	No *`dbids`* removed from the select set.

Example

Adds a previously defined user property, `MYPROP`

1. Selects four pins in a box in order.
2. Before adding the property, subtracts the pin at `6325:3575` from the list, then adds as shown in the following example:

©2023 All Rights Reserved.

```
axlSetFindFilter(?enabled "pins" ?onButtons "pins")
axlSingleSelectBox( list(6200:3700 6500:3300))
axlSubSelectPoint( 6325:3575 )
axlDBAddProp(axlGetSelSet() list("MYPROP" 23.5))
⇒ t
```

To check

1. Select *Edit – Properties*.
2. Select a window around all four pins.
3. Select *MYPROP* from the Available Properties list in the Edit Property window.

   The command displays the pins that have properties in the Show Properties window. Only the three pins not subtracted from the select set have the property, *MYPROP*.

See Also

axlAddSelectPoint

©2023 All Rights Reserved.

axlSingleSelectBox

```
axlSingleSelectBox(
     [l_bBox]
     [trapEnable]
     )
     ⇒ t/nil
```

Description

Finds all objects that intersect with the input box and meet the find filter criteria and adds those objects to the selection set after clearing all previous selections. If no box (or an incomplete box) is provided, prompts to select a box (or to complete the box) prior to the find operation.

Arguments

l_bBox	List containing one or two coordinates defining the bounding box to be used to select the figures. If *l_bBox* is `nil`, requests two picks from the user. If *l_bBox* has only one point, asks for a second point from the user.
trapEnable	Set to `nil` to restrict found elements to exactly matching location, instead of close to the location.

Value Returned

`t`	One or more objects added to the select set.
`nil`	No objects added to the select set.

Example

Adds a previously defined user property `MYPROP` to four pins by selecting a box around them with corners (`6200:3700 6500:3300`).

```
axlSetFindFilter(?enabled "pins" ?onButtons "pins")
axlSingleSelectBox( list(6200:3700 6500:3300))
axlDBAddProp(axlGetSelSet() list( "MYPROP" 23.5))
⇒ t
```

To check

1. Select *Edit – Properties*.

©2023 All Rights Reserved.

2. Select the four pins.
3. Select *MYPROP* from the Available Properties list in the Edit Property window.

   The command displays the four pins in the Show Properties window as having *MYPROP* with value *23.500000 level*

See Also

axlAddSelectPoint, axlAddSelectBox

©2023 All Rights Reserved.

axlAddSelectBox

```
axlAddSelectBox(
     [l_bBox]
     [trapEnable]
     )
     ⇒ t/nil
```

Description

Finds all non-selected objects that intersect with the input box and meet the find filter criteria and adds those objects to the selection set. If no box (or an incomplete box) is provided, prompts to select a box (or to complete the box) prior to the find operation.

Arguments

l_bBox	List containing one or two coordinates defining the bounding box to be used to the select figures. If *l_bBox* is `nil`, requests two picks from the user. If *l_bBox* has only one point, asks for a second point from the user.
trapEnable	Set to `nil` to restrict found elements to exactly matching location, instead of close to the location.

Value Returned

`t`	One or more objects added to the select set.
`nil`	No objects added to the select set.

Example

See the example for axlSingleSelectBox on page 289. That function behaves exactly as `axlAddSelectBox`, except that `axlSingleSelectBox` does not clear the select set.

See Also

axlAddSelectPoint, axlSingleSelectBox

©2023 All Rights Reserved.

axlSubSelectBox

```
axlSubSelectBox(
     [l_bBox]
     [trapEnable]
     )
     ⇒ t/nil
```

Description

Finds all selected objects that intersect with the input box and meet the find filter criteria and removes those objects from the selection set. If no box (or an incomplete box) is provided, prompts to select a box (or to complete the box) prior to the find operation.

Arguments

l_bBox	List containing one or two coordinates defining the bounding box to be used to the select figures. If *l_bBox* is `nil`, requests two picks from the user. If *l_bBox* has only one point, asks for a second point from the user.
trapEnable	Set to `nil` to restrict found elements to exactly matching location, instead of close to the location.

Value Returned

`t`	One or more objects deleted from select set.
`nil`	No objects deleted from select set.

Example

See axlSubSelectPoint on page 287 for an example of subtracting from the select set, and axlAddSelectPoint on page 285 for an example of using a box for selection.

See Also

axlAddSelectPoint

©2023 All Rights Reserved.

axlAddSelectAll

```
axlAddSelectAll()
     ⇒ t/nil
```

Description

Finds all the figures in the database that pass the current Find Filter and adds their *dbids* to the select set.

Arguments

None.

Value Returned

`t`	One or more object *dbids* added to the select set.
`nil`	No object *dbids* added to the select set.

Example

```
axlSetFindFilter(?enabled list( "noall" "vias")
    ?onButtons list( "noall" "vias"))
    axlAddSelectAll()
    axlDeleteObject(axlGetSelSet())
    ⇒ t
```

Selects all vias in a layout and deletes them.

©2023 All Rights Reserved.

axlSubSelectAll

```
axlSubSelectAll()
     ⇒ t/nil
```

Description

Finds all figures in the database that pass the current Find Filter and deletes their *dbids* from the select set. Use `axlSubSelectAll` to subtract all of a given type of figure from a larger set of selected objects.

Note: Use `axlClearSelSet` to deselect all figures in the current select set, regardless of the current Find Filter.

Arguments

None.

Value Returned

`t`	One or more *dbids* deleted from select set.
`nil`	No *dbids* deleted from select set.

Note: Dependent on find filter ?enabled settings.

Example 1

The following example selects the nets GND and VCC by their names.

```
axlClearSelSet()
axlSetFindFilter(?enabled
    list( "noall" "equivlogic" "nets" "clines" "vias")
    ?onButtons list( "all"))
axlSingleSelectName( "NET" list( "GND" "VCC"))
         ==> (dbid:234436 dbid:98723)
axlSingleSelectName("PROPERTY" list( list("BUS_NAME" "MEM") "FIXED"
)⇒ t
```

Interactively selects all connect lines (clines) and vias on a net, subtracts the via *dbids* from the select set, and deletes the remaining *dbids* in the select set.

The prompt *Enter selection point*, is displayed. Only the connect lines on the net you select are deleted—not the vias of the net.

©2023 All Rights Reserved.

Example 2

The following example selects a set of nets--one set by the property name ELECTRICAL_CONSTRAINT_SET with value DEFAULT, and another set that has the name ROUTE_PRIORITY.

```
axlClearSelSet()
axlSetFindFilter( ?enabled list( "noall" "nets")
                          ?onButtons list( "all"))
axlSingleSelectName("PROPERTY"
                 list( list( "ELECTRICAL_CONSTRAINT_SET" "DEFAULT")
                 "ROUTE_PRIORITY"))
         ==> (dbid:234436 dbid:98723 dbid:234437 dbid:98727
             dbid:234438 dbid:98725 dbid:234439 dbid:98726)
```


©2023 All Rights Reserved.

axlSingleSelectName

```
axlSingleSelectName(
     t_nameType
     l_names
     [g_wildcard]
     )
     ⇒ t/nil
```

Description

Finds figures by their names. Clears the current contents of the select set and adds named figure *dbids* to the select set in single mode using the arguments as described below. The function selects any figures completely, regardless of the selection mode. If the function selects a figure already partially selected, the figure becomes fully selected.

Note: The *on* buttons are used for selecting *Properties* by name only. Both `axlSubSelectName` and `axlAddSelectName` always operate in wildcard mode. Both take the optional wildcard argument but ignore it. In the future, if passed `nil`, they may obey the argument.

Arguments

t_nameType	Indicates the type of name string being provided. Also implies the type of object to be selected. (see Finding Objects by Name on page 278).
l_names	List of item name names or for properties a name value. This varies with the nameType. Supports a single name item outside of a list. Therefore, supported values can be: – a name – a list of names – a list of name/value pairs
g_wildcard	A `t` means that `*` or `?` performs regular expression matching. Default is `nil` where `*` and `?` are treated as normal characters.

Value Returned

`t`	One or more objects added to the select set.
`nil`	No objects added to the select set.

©2023 All Rights Reserved.

Example 1

```
axlClearSelSet()
axlSetFindFilter(
    ?enabled list( "noall" "nets")
    ?onButtons list( "all"))
axlSingleSelectName ("NET" (list ("GND" "VCC"))
⇒ (dbid:234436 dbid:98723)
    axlSingleSelectName ("PROPERTY" (list (list "BUS_NAME" "MEM") "FIXED")
```

Selects the nets GND and VCC by their names.

Example 2

```
axlClearSelSet()
axlSetFindFilter(
    ?enabled list( "noall" "nets")
    ?onButtons list( "all"))
axlSingleSelectName ("PROPERTY"
    list(
    list( "ELECTRICAL_CONSTRAINT_SET" "ECL_DEFAULT")
    "ROUTE_PRIORITY"))
⇒ (dbid:234436 dbid:98723 dbid:234437 dbid:98727
    dbid:234438 dbid:98725 dbid:234439 dbid:98726)
```

Selects a set of nets—one set by the property name ELECTRICAL_CONSTRAINT_SET with value ECL_DEFAULT, and another set that has the name ROUTE_PRIORITY.

©2023 All Rights Reserved.

axlAddSelectName

```
axlAddSelectName(
     t_nameType
     l_names
     )
     ⇒ t/nil
```

Description

Adds the named figure *dbids* to the select set in cumulated mode according to the arguments described below. Adds the found figures to the select set if not already there. Selects figures completely regardless of the selection mode. If the function selects a figure already partially selected, the figure becomes fully selected.

Arguments

t_nameType	String denoting the name type to be selected (see Finding Objects by Name on page 278). Also implies the type of object to be selected.
l_names	List of item name names or for properties a name value. This varies with the nameType. Supports a single name item outside of a list. Therefore, supported values can be: – a name – a list of names – a list of name/value pairs

Value Returned

`t`	One or more objects added to the select set.
`nil`	No objects added to the select set.

The on buttons matter for select Properties by name, but don't for other name types. Both `axlSubSelectName` and `axlAddSelectName` always operate in wildcard mode. Both take the optional wildcard argument, but ignore it. In the future, if passed `nil` they may obey the argument.

©2023 All Rights Reserved.

Example

See examples for axlSingleSelectName on page 296. The only difference is that `axlSingleSelectName` clears the select set, while `axlAddSelectName` adds the selected *`dbids`* into the select set without removing any already in it. The arguments for `axlAddSelectName` are the same as for `axlSingleSelectName`.

©2023 All Rights Reserved.

axlSubSelectName

```
axlSubSelectName(
     t_nameType
     l_names
     )⇒ t/nil
```

Description

Removes *dbids* of the named figure from the select set using the arguments described. Removes figures completely regardless of the selection mode. If the function finds a figure already partially selected, it removes all of its *dbids* from the select set.

Arguments

t_nameType	String denoting name type to be selected (see Finding Objects by Name on page 278). Also implies the type of object to be selected.
l_names	List of item name names or for properties a name value. This varies with the nameType. Supports a single name item outside of a list. Therefore, supported values can be: – a name – a list of names – a list of name/value pairs

Value Returned

`t`	One or more objects deleted from select set.
`nil`	No objects deleted from select set.

Note: The on buttons matter for select Properties by name, but not for other name types. Both `axlSubSelectName` and `axlAddSelectName` always operate in wildcard mode. Both take the optional wildcard argument, but ignore it. In the future, if passed `nil`, they may obey the argument.

©2023 All Rights Reserved.

Example

See examples for axlSingleSelectName on page 296. The only difference is that `axlSingleSelectName` clears the select set and then puts the *`dbids`* it finds into the select set, while `axlSubSelectName` removes the *`dbids`* of the elements it selects from the select set. The arguments are the same as `axlSingleSelectName`.

©2023 All Rights Reserved.

axlSingleSelectObject

```
axlSingleSelectObject(
     lo_dbid
     )
     ⇒ t/nil
```

Description

Clears contents of the select set and adds the dbids in *lo_dbid* to the select set in single mode. *lo_dbid* is either a single dbid or a list of dbids. Selects figures completely regardless of the selection mode. If the dbid of any part of a figure is in *lo_dbid*, the function adds the entire figure.

Note: You need to "BOUNDARY_SHAPES" to the axlSetFindFilter "?enabled" option if you wish to select a dynamic shape. Generated shape from dynamics shapes cannot be selected via the SelectObject APIs since it cannot be edited.

Arguments

lo_dbid	dbid, or list of dbids to be added to the select set.

Value Returned

`t`	One or more objects added to the select set.
`nil`	No objects added to the select set.

Example

```
axlClearSelSet()
axlSetFindFilter(
    ?enabled list( "all" "equivlogic")
    ?onButtons list( "all"))
mysym = axlDBCreateSymbol(
    list( "dip14" "package"), 5600:4600)
axlSingleSelectObject(car(mysym))
⇒ t
```

Creates a symbol and add its dbid to the select set.

©2023 All Rights Reserved.

axlAddSelectObject

```
axlAddSelectObject(
     lo_dbid
     )
     ⇒ t/nil
```

Description

Adds the *dbids* in *lo_dbid* to the select set in cumulated mode, that is, without removing already selected objects. *lo_dbid* is either a single *dbid* or a list of *dbids*. Adds *dbids* in the select set only if they are not already there. Selects figures completely regardless of the selection mode. If the *dbid* of any part of a figure is in *lo_dbid*, adds the entire figure.

Arguments

lo_dbid	*dbid*, or list of *dbids* to be added to the select set.

Value Returned

`t`	One or more objects added to the select set.
`nil`	No objects added to the select set.

Example

```
axlSetFindFilter(
    ?enabled list( "all")
    ?onButtons list( "all"))
mysym = axlDBCreateSymbol(
    list("dip14" "package") 2600:2600 ) axlAddSelectObject(car(mysym))
⇒ t
```

Creates a symbol instance and adds its *dbid* to the select set.

©2023 All Rights Reserved.

axlSubSelectObject

```
axlSubSelectObject(
     lo_dbid
     )
     ⇒ t/nil
```

Description

Removes the *dbids* in *lo_dbid* from the select set in cumulated mode. *lo_dbid* is either a single *dbid* or a list of *dbids*. Removes figures completely regardless of the selection mode.

Arguments

lo_dbid	*dbid*, or list of *dbids* to be removed from select set.

Value Returned

t	One or more objects deleted from select set.
nil	No objects deleted from select set.

Example

```
axlClearSelSet()
axlSetFindFilter(?enabled list("noall" "vias")
    ?onButtons list( "vias"))
myvia = axlDBCreateVia( "pad1", 3025:3450)
axlAddSelectBox( list( 3000:3100 3200:3600))
axlSubSelectObject( car( myvia))
⇒ t
```

Creates a via, then selects all the vias in a surrounding region for deletion, but saves the one just created by subtracting its *dbid* from the selection set.

The resulting select set contains the *dbids* of all vias in the box except *myvia*, the one just created.

©2023 All Rights Reserved.

axlSelect

```
axlSelect(
     ?firstEventCallbacks_callback
     ?groupModet/nil
     ?promptt_prompt
     )
     ⇒ t/nil
```

Description

General tool for AXL programs to solicit interactive object selections from the user. `axlSelect` automatically sets up the pop-up to provide any of the possible Allegro PCB Editor selection methods:

- Single point select
- Window select
- Group select

You can set up the pop-up to display other options such as *Done* and *Cancel*, but the function also displays the find options. See the example.

Before `axlSelect` returns, it puts in the select set a list of the *`dbids`* of the objects the user selected.

Use `axlSelect` when you create interactive commands that allow the user to select objects in the same way as existing Allegro PCB Editor interactive commands such as *move* or *delete*. `axlSelect` allows the user to select objects using the standard methods of mouse pick, window, and group. It returns when the user has selected one or more objects or picks *Done* or *Cancel*, depending on the pop-up selections you set up. The default mode for `axlSelect` is selecting a single object by point—equivalent to `axlSingleSelectPoint`.

`axlSelect` removes any previously selected *`dbids`* in the selection set when the user first selects one or more objects.

You must set up the find filter to meet your requirements before calling `axlSelect`.

©2023 All Rights Reserved.

Arguments

firstEventCallback	Procedure to be called once the first user event occurs. The callback takes no arguments.
groupMode	Default is for `axlSelect` to return when the user makes a selection. If groupMode is `'t`, `axlSelect` won't return until you do an `axlCancelEnterFun` or `axlFinishEnterFun`. You perform all of your activity in popup callbacks instead of when `axlSelect` returns. In `groupMode`, `axlSelect` does not clear existing selections. To clear existing selections after the first event, clear them in your *firstEventCallback*.
prompt	Prompt to the user. The default prompt is: `"Enter selection point"`

Value Returned

`t`	One or more object *dbids* put into the select set during the call. The select set is a list of the *dbids* of the objects the user selected.
`nil`	No object *dbids* put into the select set.

Example

```
(defun showElement ()
mypopup = axlUIPopupDefine( nil
    (list (list "Done" 'axlFinishEnterFun)
    (list "Cancel" 'axlCancelEnterFun)))
axlUIPopupSet( mypopup)
axlSetFindFilter( ?enabled list( "NOALL" "ALLTYPES" "NAMEFORM")
    ?onButtons "ALLTYPES")
while( axlSelect()
    axlShowObject( axlGetSelSet()))
```

Function loops, performing the `Show Element` command on each object selected by the user.

©2023 All Rights Reserved.

Although you explicitly set *Done* and *Cancel* for this command, AXL also adds *Group*, *Window Select*, and *FindFilter* to the pop-up.

```
Done
Cancel
Group
Window Select
Find Filter
```


©2023 All Rights Reserved.

axlGetSelSet

```
axlGetSelSet()
     ⇒ lo_dbid/nil
```

Description

Gets the list of object *dbids* in the select set.

Arguments

None.

Value Returned

lo_dbid	List of figure *dbids*.
nil	Select set is empty.

Example

```
axlClearSelSet()
axlSetFindFilter(?enabled list("noall" "vias")
    ?onButtons list("vias"))
axlAddSelectBox(list(3000:3100 3200:3600))
axlShowObject(axlGetSelSet())
⇒ t
```

Selects all vias in a box area and shows the contents of the select set.

©2023 All Rights Reserved.

The **Show Element** window is displayed, with the via selected.

©2023 All Rights Reserved.

axlGetSelSetCount

```
axlGetSelSetCount()
     ⇒ x_selCount
```

Description

Returns the number of figure *dbids* in the select set.

Arguments

None.

Value Returned

x_selCount Number of objects selected. Returns `0` if nothing is selected.

Example

```
axlClearSelSet()
axlSetFindFilter(?enabled list("noall"))
axlSetFindFilter(?enabled list("pins")
    ?onButtons list("pins"))
axlAddSelectBox()
axlGetSelSetCount()
⇒ 14
```

Sets the Find Filter to find pins, selects a box around a 14 pin dip and prints the number of *dbids* in the select set. It is 14, as expected.

©2023 All Rights Reserved.

axlClearSelSet

```
axlClearSelSet()
     ⇒ t/nil
```

Description

Removes all *dbids* from select set.

Arguments

None.

Value Returned

`t`	One or more *dbids* removed in order to empty the select set.
`nil`	Select set already empty.

Example

```
axlClearSelSet()
axlSetFindFilter(?enabled list("noall"))
axlSetFindFilter(?enabled list("pins")
    ?onButtons list("pins"))
axlAddSelectBox()
axlGetSelSetCount()
⇒ 14
```

Ensures the select set does not have any leftover *dbids* in it, as in the example for `axlGetSelSetCount`.

©2023 All Rights Reserved.

axlGetFindFilter

```
axlGetFindFilter(
     [onEnabledF]
     )
     ⇒ lt_filters/nil
```

Description

Returns the current Find Filter settings as a list `pf` keyword strings. The return find filters settings (onButton or enabled) is controlled by the boolean `onEnabledF`.

Note that SKILL has its own local Find Filter settings. The axlGetFindFilter()/axlSetFindFilter() API is for getting and setting the local Find Filter settings. This does not get the global Find Filter settings, which can only be modified by the user. SKILL programs are not allowed to modify the global Find Filter settings.

Arguments

onEnabledF	If *onEnabledF* is `t`, returns the enabled list. If *onEnabledF* is `nil`, returns the *onButton* list. Default is nil.

Value Returned

lt_filters	List of element types in the Find Filter OR list of current onButton settings.
`nil`	If list would be empty.

Example

```
axlSetFindFilter ?enabled (list "vias" "pins" "nets" "clinesegs" "nameform")
?onButtons (list "vias" "pins" "clinesegs"))
ret =axlGetFindFilter()
```

Returns the following:

```
("NAMEFORM" "NETS" "CLINESEGS" "VIAS" "PINS"
<plus default items that may change from release to release> )
```


©2023 All Rights Reserved.

```
ret = axlGetFindFilter(t)
```

Returns:

```
("CLINESEGS" "VIAS" "PINS")
```


©2023 All Rights Reserved.

axlSetFindFilter

```
axlSetFindFilter(
     ?enabledlt_enabled
     ?onButtonslt_filterOn
     )
     t/nil
```

Description

Sets up both the object types to be displayed in the Find Filter, and which types among those are set to *on* in the **Find Filter**.

Note that SKILL has its own local Find Filter settings. The axlGetFindFilter()/axlSetFindFilter() API is for getting and setting the local Find Filter settings. This does not get the global Find Filter settings, which can only be modified by the user. SKILL programs are not allowed to modify the global Find Filter settings.

The first argument, `lt_enabled`, is a list of the object types to be displayed in the Find Filter and of the select options described. The second argument, `lt_onButons`, lists the object types whose buttons are to be *on* (and therefore selectable) when the filter displays. The table lists the keywords that can be included in the enabled and `onButtons` lists for setting up the Find Filter. The diagrams show the keywords and the buttons they cause `axlSetFindFilter` to display.

Each change is additive and processed in the order that they appear in the list. For example, you type the following to enable all object types except for pins.

```
'("ALLTYPES" "NOPINS")
```

Each of the following keywords may be preceded with a `"NO"` to disable the particular option or object type. For example, `"NOPINS"`. The initial default is `"NOALL"`.

`axlSetFindFilter` Keywords

Keyword	Description
`"PINS"`	Enable pins
`"VIAS"`	Enable vias
`"CLINES"`	Enable clines
`"CLINESEGS"`	Enable cline (arc or line) segs
`"LINES"`	Enable lines
`"LINESEGS"`	Enable line (arc or line) segs

©2023 All Rights Reserved.

`axlSetFindFilter` Keywords, *continued*

Keyword	Description
`"DRCS"`	Enable DRC errors
`"TEXT"`	Enable text
`"SHAPES"`	Enable shapes, rects and frects
`"SHAPESEGS"`	Enable shape segments
`"BOUNDARY_SHAPES"`	Enable promotion to boundary shape if auto-shape is selected (see dynamic shape discussion)
`"VOIDS"`	Enable shape voids
`"VOIDSEGS"`	Enable shape void segments
`"SYMBOLS"`	Enable symbol instances
`"FIGURES"`	Enable figures
`"COMPONENTS"`	Enable component instances
`"FUNCTIONS"`	Enable function instances
`"NETS"`	Enable nets
`"BONDWIRES"`	Enable bondwires (APD/SIP only). For more information, see Bond Objects.
`"FINGERS"`	Enable fingers (APD/SIP only). For more information, see Bond Objects.

©2023 All Rights Reserved.

`axlSetFindFilter` Keywords, *continued*

Keyword	Description
`"GROUPS"` `"GROUPMEMBERS"`	`"GROUPS"` and `"GROUPMEMBERS"` operate together to produce four possible selection states: **Keyword** / **States**: 1, 2, 3, 4 `GROUPS`: OFF, ON, OFF, ON `GROUPMEMBERS`: OFF, OFF, ON, ON ■ State 1: Legacy. This supports code that predates the group implementation. This is the same as State 3. ■ State 2: Group only. By only setting the group bitfield, any selected group is returned to the application as a group. ■ State 3: Members only. By only setting the group_members bitfield, group members are returned to the application when a group is selected. ■ State 4: Hierarchical. By setting both the group and group_members bitfields, a group is returned for any hierarchical group that is selected (such as a Module instance), and group members are returned for all other selected group types.
`"AUTOFORM"`	OBSOLETE
`"EQUIVLOGIC"`	Option - For logic object types (nets and components), causes the physical equivalent to be selected. Physical objects must be enabled in both "enabled" an "onButton" lists.
`"INVISIBLE"`	Option - Allows selection of objects that are not visible due to color class/subclass form setting.
`"NAMEFORM"`	Option - enables the find by name/property fields in the find filter form.

©2023 All Rights Reserved.

`axlSetFindFilter` Keywords, *continued*

Keyword	Description
`"DYNTHEMALS"`	Option - Enable selection of thermal reliefs generated by dynamic shapes. Only applicable to ?enabled. By default, you should not select these if you plan on modifying the objects since the dynamic shape will just re-generate them. You should only access them from read-only purposes. If in the partition editor or the design has partitions active then this option is used to selections of read-only objects. This option should also be used to select shape base fillets. The system will not allow shape based fillets to be modified it the dynamic fillet option is enabled.
`"BONDSMART"`	Option - Application has been updated to differentiate bond wires and/or fingers (APD/SIP). For more information, see Bond Objects.
`"ALLTYPES"`	Enable all object types ("PINS" ... "NETS").
`"ALL"`	Enable all object types and options.

`axlSetFindFilter` processes the keywords in each argument list in order and only makes the changes occurring in the list. Changes are incremental for each call to the function. To remove a selection, attach the string `"NO"` to the front of the keyword. For example, the list `("ALLTYPES" "NOPINS")` enables all object types except pins. The initial default setting of the Find Filter is `"NOALL"`, or, nothing enabled. Use `"NOALL"`, as shown, to clear the Find Filter before enabling particular types.

Dynamic Shapes

When writing an application and it needs to handle shapes, you need to decide how you want to handle dynamic shapes. Additional information is useful only if your SKILL program access shapes.

A shape on `ETCH` may be either static or dynamic. A static shape is similar to what existed in Allegro PCB Editor prior to SPB15.0. You add a shape to an etch layer and manually void objects that impact the shape. A dynamic shape is placed on the `BOUNDARY CLASS` and generates zero or more shapes on the `ETCH` layer based upon auto-voiding.

If you want to modify a dynamic shape, then you should set `BOUNDARY_SHAPES`. This allows the user to select the generated shape, but selection will return its dynamic shape (for

©2023 All Rights Reserved.

example, to move the shape). If you want to access information on the shape, then do not set the `BOUNDARY_SHAPES` option (for example, to do show element on the shape).

Note: If you pass `"ALL"` or `"ALLTYPES"` to *`setOptions`*, then `BOUNDARY_SHAPES` will be enabled and user's selecting a `ETCH` layer generated shape will result in the selection returning its dynamic shape on the `"BOUNDARY CLASS"`. If you wish to select the generated shape, but want to use the `all` option, use `"(ALLTYPES" "NOBOUNDARY_SHAPES"`. You need only pass `BOUNDARY_SHAPES` to the enabled list. It will be ignored if passed to the `onButtons` list.

Figure 4-1 Find Filter and Related Keywords

The differences in effects of different combinations of keywords can be subtle. Figure 4-2 on page 319 shows the relationship between the keywords.

©2023 All Rights Reserved.

Figure 4-2 Relationship Among axlSetFindFilter Keywords (*See examples also*)

Note: To select either of the “abstract” Logic types—`NETS` or `COMPONENTS`—and not one of its parts, such as its pins or clines, you must set `NOEQUIVLOGIC`. Since the keyword `ALL` sets `EQUIVLOGIC`, if you want to use that keyword and also select a net or component, use the argument: `?enabled list("all" "noequivlogic")`

Bond Objects

Bond objects (bond wires and fingers) are enabled only in APD/SIP. These options are ignored in the PCB products.

In APD/SIP, to maintain backward compatibility, an application is not considered to be "bond smart". This means if the SKILL application enables VIAs then FINGERS are enabled and if CLINES is enabled, the BOND WIRES are automatically enabled.

©2023 All Rights Reserved.

To make an application bond smart, you either set the BONDSMART option or use the BONDWIRES, NOBONDWIRES, FINGERS or NOFINGERS options. An application that is bond smart can separately control the selection of bond objects (fingers or bond wires) from their base objects (vias or clines).

Note: You only need to make you SKILL application bond smart if you wish to differentiate the disabling of one of these objects. By default, users in APD/SIP will be able to independently select: VIAS or FINGERS if the SKILL application enables VIAS or CLINES and WIRES if CLINES are enabled. Ideally most applications will not need to be updated to be bond smart.

Arguments

`lt_enabled`	List of keyword strings that describe object types that are to be selectable. Enabled object types will appear in the **Find Filter** form. Object types need the *`onButton`* set as well to fully enable selection. List may also include selection options. Also supports a single keyword string instead of a list of strings.
`lt_onButtons`	List of keyword strings that describe object types that are to be enabled for selection. Enabled types will appear with the `onButton` depressed in the Find Filter form. `onButton` settings provide the default for controls which can be modified by the user when the Find Filter form is opened. An object type must be *on* in both the enabled and the `onButton` lists to be fully enabled for selection. Options are ignored when provided in the `onButton` list. Also supports a single keyword string instead of a list of strings.

Note: `axlSetFindFilter` does not display or select any types that are not enabled. That means that `?onButtons` keywords only effect enabled types. For example, to have all enabled buttons be *on*, use `?onButtons list("alltypes")`. In general, you need only set specific buttons *on* if you want those on and others off.

Value Returned

`t`	One or more Find Filter changes were made.
`nil`	No valid keywords were provided.

©2023 All Rights Reserved.

Application Programming Note

When you use `axlSetFindFilter()` to implement an interactive command, make your AXL-SKILL program restore the user's FindFilter settings from the previous time he same command was used. Find Filter settings are incremental. Clear any previous settings as you start, then set the ones you want. Call `axlSetFindFilter` with `"noall"` as the first member of the list for both the `?enabled` and `?onButtons` arguments the first time you call it.

To maintain the user's Find Filter settings between invocations of your command

1. The first time the user invokes your program (when it loads), preset global variables to the list of `?enabled` and `?onButtons` settings you want as the initial default, as follows:

   ```
   myglobal_enabled = list("noall" "xxx" "yyy" ... "zzz")
   myglobal_onButtons = list("xxx" ..."zzz")
   ```

2. Each time the user invokes your command, call `axlSetFindFilter` with the current global values of `?enabled` and `?onButtons`.

   ```
   axlGetFindfilter( ?enabled myglobal_enabled
       ?onButtons myglobal_onButtons)
   ```

   Since users can set or clear any of the buttons on the Find Filter, you need to save the button settings as you exit the command.

3. As you end the command, save the user's Find Filter *`onButton`* settings as shown:

   ```
   myglobal_onButtons = cons( "noall" axlGetFindFilter(t))
   ```

   Note: The `cons - "noall"` ensures that when you call `axlSetFindFilter` again you clear any settings left over from any previous command, and set only the buttons set at the time you call `axlGetFindFilter`.

©2023 All Rights Reserved.

Example 1

```
(axlSetFindFilter ?enabled (list "vias" "pins" "nets")
    ?onButtons (list "vias" "pins"))
```

Displays the Find Filter with a list of Nets, Pins, and Vias. The Pins and Vias boxes are turned on as shown:

©2023 All Rights Reserved.

Example 2

```
(axlSetFindFilter ?enabled (list "noall" "vias" "pins"
    "nets" "clinesegs" "nameform")
    ?onButtons (list "vias" "pins" "clinesegs"))
```

Displays the Find Filter with Pins, Vias, and Cline segs turned on.

Example 3

```
axlSetFindFilter(
?enabled list("noall" "equivlogic" "nets" "pins" "vias")
?onButtons list("all"))
```

Sets to find all the pins and vias on a net when the user selects any part of the net.

©2023 All Rights Reserved.

axlAutoOpenFindFilter

```
axlAutoOpenFindFilter()
     ⇒ t
```

Description

This function is no longer required, but is kept for backward compatibility.

Arguments

None.

Value Returned

`t`	Returns `t` always.

©2023 All Rights Reserved.

axlOpenFindFilter

```
axlOpenFindFilter()
     ⇒ t
```

Description

This function is no longer required, but is kept for backward compatibility.

Arguments

None.

Value Returned

`t`	Returns `t` always.

©2023 All Rights Reserved.

axlCloseFindFilter

```
axlCloseFindFilter()
     ⇒ t
```

Description

This function is no longer required, but is kept for backward compatibility.

Arguments

None.

Value Returned

`t`	Returns `t` always.

©2023 All Rights Reserved.

axlDBFindByName

```
axlDBFindByName(
     s_type
     t_name
     ) ⇒ o_dbid/nil
```

Description

Finds `dbid` of an object by name without involving the selection set. This means you can run this command any time without affecting what exists in the selection set. The following object lookup types are supported:

type	t_name	return type
'net	net name	`dbid` of a net
'refdes	refdes	`dbid` of a component instance
'padstack	padstack name	`dbid` of a padstack

This is restricted to a single object. To find objects using wildcards, use `axlSelectByName`.

Arguments

s_type	Type symbol; see above.
t_name	Object's name (this is case insensitive).

Value Returned

`o_dbid`	*dbid* of object or `nil`.

See Also

axlSelectByName

Examples

```
db = axlDBFindByName('net "GND")
db = axlDBFindByName('padstack "VIA")
```


©2023 All Rights Reserved.

```
db = axlDBFindByName('refdes "U1")
```


©2023 All Rights Reserved.

axlFindFilterIsOpen

```
axlFindFilterIsOpen()
     ⇒ t
```

Description

This function is no longer required, but is kept for backward compatibility.

Arguments

None.

Value Returned

`t`	Returns `t` always.

©2023 All Rights Reserved.

axlSelectByName

```
axlSelectByName (
     t_objectType
     t_name/lt_name
     [g_wildcard]
     )
     ⇒ lo_dbid/nil
```

Description

Selects database objects by name.

Interface allows more than one name to be passed, but only one object type per call. For certain object types, a single name may return multiple objects. The supported object types and related items follow:

Object Type	Item the function finds
"NET"	net name
"COMPONENT"	component name
"FUNCTION"	function name
"DEVTYPE"	device type name
"SYMTYPE"	symbol type name
"PIN"	refdes.pinname
"REFDES"	find symbol by refdes name
"COMPREFDES"	find component by refdes name
"GROUP"	find group by name
"BUS"	find bus by name
"DIFF_PAIR"	find differential pair by name
"NETCLASS"	find netclass by name
"NET_GROUP"	find a net group by name
"REGION"	find region by name

©2023 All Rights Reserved.

Object Type	Item the function finds
`"XNET"`	find xnet by name; Will return a Net if xnet is a single net xnet. See `<cdsroot>/share/pcb/examples/skill/select/ashfindxnet.il`
`"MATCH_GROUP"`	find match group by name
`"MODULE"`	find module by name

You can use wildcards with this function:

- `"*"` matches any sequence of zero or more characters.
- `"?"` matches any single character.
- `"\"` is used to send a special character, for example, `\x`.

Provided third argument *`[g_wildcard]`* is set to `TRUE`.

Note: This saves and restores the current find filter settings, but resets the selection set.

©2023 All Rights Reserved.

Arguments

t_objectType	Type of database name.
t_name	Object to find.
lt_name	List of names to find.
[g_wildcard]	If `*` or `?` appear in name, use regular expression matching

Value Returned

`t`	List of objects found.
`nil`	No matching name or illegal *objectType* name.

Example 1

```
Skill > p = axlSelectByName("NET" '("GND" "NET1"))
(dbid:28622576 dbid:28639844)
```

Finds two nets.

Example 2

```
Skill > p = axlSelectByName("NET" '("GND" "FOO"))
(dbid:28622576)
```

Finds two nets, but board only has `GND`.

Example 3

```
Skill > p = axlSelectByName("COMPONENT" "C1")
(dbid:28590388)
Skill > car(p)->objType
"component"
```

Finds Component `C1`.

Example 4

```
Skill > p = axlSelectByName("FUNCTION" "TF-326")
(dbid:28661572)
Skill > car(p)->objType
```


©2023 All Rights Reserved.

```
"function"
```

Finds function `TF-326`.

Example 5

```
Skill > p = axlSelectByName("DEVTYPE" "CAP1")
(dbid:28591032 dbid:28590700 dbid:28590388)
Skill > car(p)->objType
"component"
```

Finds devices of type `CAP1`.

Example 6

```
Skill > p = axlSelectByName("SYMTYPE" "dip14_3")
(dbid:28688416 dbid:28686192)
Skill > car(p)->objType
"symbol"
```

Finds symbols of type `DIP14_3`.

Example 7

```
Skill > p = axlSelectByName("PIN" "U1.1")
(dbid:28630692)
Skill > car(p)->objType
"pin"
```

Finds pin `U2.1`.

Example 8

```
Skill > p = axlSelectByName("REFDES" "U3")
(dbid:28688416)
Skill > car(p)->objType
"symbol"
```

Finds symbol by refdes `U3`.

Example 9

```
Skill > p = axlSelectByName(“COMPREFDES” “U3”)
(dbid:28621208)
```


©2023 All Rights Reserved.

```
Skill > car(p)->objType
"component"
```

Finds component by refdes `U3`.

Example 10

```
Skill > p = axlSelectByName("GROUP" "BAR")
(dbid:28593776)
Skill > car(p)->objType
```

Finds a group `BAR` by name.

Example 11

```
Skill > p = axlSelectByName("PIN" "U1.*" t)
(dbid:28630856 dbid:28630784 dbid:28630692 dbid:28630572 dbid:28630400
dbid:28630228 dbid:28630076 dbid:28630004 dbid:28629912 dbid:28629800
dbid:28629728 dbid:28629656 dbid:28629484 dbid:28629372 dbid:28629280
dbid:28629208
)
```

Finds all pins on `refdes U1`.

Example 12

```
Skill > p = axlSelectByName("PIN" "U1.?" t)
(dbid:28630856 dbid:28630692 dbid:28630572 dbid:28630400 dbid:28630228
dbid:28630076 dbid:28630004 dbid:28629912 dbid:28629800
)
```

Finds pins with single digit number on `U1`.

Example 13

```
Skill >  p = axlSelectByName("NET" "N*" t)
(dbid:28630044 dbid:28634000 dbid:28638750)
```

Finds nets starting with `N`.

©2023 All Rights Reserved.

axlSelectByProperty

```
axlSelectByProperty(
     t_objectType
     t_property
     [t_value]
     [g_regularExpression]
     )
     ⇒ lo_dbid/nil
```

Description

Selects the *dbid* set of a particular Allegro PCB Editor database object with the indicated property.

Property can be a name or a name/value pair. Value may contain a regular expression (`*` or `?`), since certain select by name functions support wildcards. You can test for the presence of wildcards before you call this function.

Regular expressions used by Allegro PCB Editor differ from the SKILL regular expressions. Allegro PCB Editor handles regular expressions such that they are more compatible with the character set allowed in Allegro PCB Editor object names. Do not use this function to test patterns sent to the SKILL `regexp` family of functions.

For value, match the database formats into the value string to contain the units preference if applicable for the property. If the data type of the attribute is BOOLEAN, and if it exists on the element, the string is empty. If the data type is `INTEGER` or `REAL`, the user units string, if any, is appended to the value. If the data type is one of the `"units category"` types, for example, `ALTITUDE`, `PROP_DELAY`, the MKS package converts the value.

Properties must be upper case. The value is case insensitive if wildmatch match is `nil` while case sensitive for wildcard matching.

Note: Property names may change from release to release, or may be rendered obsolete. SKILL programs using property names may require modifications in future releases.

©2023 All Rights Reserved.

Arguments

t_objectType	String for Allegro PCB Editor database object type. Must be: `compdef`, `component`, `drc`, `net`, `symdef`, `symbol`, or `group`.
t_property	Name of property.
t_value	Optional property value.
g_regularExpression	`t` if property value is to be treated as a regular expression, or `nil`, which is the default, to treat property value as a simple match.

Value Returned

`t`	One or more *dbids* added to the select set.
`nil`	No *dbids* added to the select set.

Example 1

```
p = axlSelectByProperty("net" "ELECTRICAL_CONSTRAINT_SET")
axlAddSelectObject(p)
```

Selects all nets with an `ECset` property, then adds them to the current select set.

Example 2

```
p = axlSelectByProperty("net" "ELECTRICAL_CONSTRAINT_SET", "SPITFIRE_ADDRESS")
```

Selects all nets with ECset property of value `SPITFIRE_ADDRESS`.

Example 3

```
p = axlSelectByProperty("net" "ELECTRICAL_CONSTRAINT_SET", "SPITFIRE*" t)
```

Selects all nets with ECset property with any value matching `spitfire`.

©2023 All Rights Reserved.

axlSnapDisableAtRMB

```
axlSnapDisableAtRMB(
     )
     ⇒ t
```

Description

Disable the display of "snap to" submenu at right-click popup.

Use in conjunction with axlSnapEnableAtRMB to remove the "Snap To" from the right-click popup.

Arguments

None

See Also

axlSnapEnableAtRMB

Value Returned

`t`	Always returns `t`

©2023 All Rights Reserved.

axlSnapEnableAtRMB

```
axlSnapEnableAtRMB(
     )
     ⇒ t
```

Description

Enable the display of "snap to" submenu at right mouse button popup.

It is used to enable the display of "snap to" submenu at right-click popup. The function should be used with axlSnapDisableAtRMB to achieve "snap to" submenu which is available with all the popups of an interactive command. To enable or disable "snap to" submenu at particular steps during execution, this function can be used with axlSnapDisableAtRMB.

This is the default mode with all axlEvent APIs with a right mouse button.

Arguments

None.

Value Returned

`t`	Always returns `t`

See Also

axlSnapDisableAtRMB, axlEnterEvent

Example

See `<cdsroot>/share/pcb/examples/axlcore/enterevent.il`

©2023 All Rights Reserved.

axlSnapToObject

```
axlSnapToObject(
     g_mode
     xy
     )
     ⇒ xy/nil
```

Description

Supports snapping to a logic object's connect point. A logic object is a:

- Cline
- Clines segments (lines or arcs)
- Via
- Pin

For cline objects, the two end points are considered the connect points. For pad objects, the connect point is defined in the padstack. Snapping is based upon the trap size, which varies based upon the zoom factor (see `axlGetTrapBox`). The smaller the trap size, the higher the zoom. If no object is found within the original xy location is returned.

Note: Avoid using the grid snapping option with `axlEnterPoint` as it might move the user pick outside the trap size.

Arguments

g_mode	*nil*: Use active sel set to determine snapping.
	t: Snap based upon the visible layers in the database.
xy	Location in design units to snap (list of design units x:y).

Value Returned

`xy`	Object snapped point (list of design units x:y).
`nil`	If not object exists for snapping returns nil.

Also nil if arguments are incorrect

©2023 All Rights Reserved.

See Also

axlGetSelSet, axlGetTrapBox, axlGetLastEnterPoint

Examples

Pseudo code to move objects.

```
; select object(s); do not do a axlClearSelSet
         _clpSelect
         ; first snap to an object that is the selection list
         gridSnap = axlEnterPoint(?prompts list("Pick origin point")
                        ? gridSnap t)
; for better results use the unsnapped pick
         origin = axlSnapToObject(nil axlLastPick(nil))
         ; if no object found fallback to the grid snapped pick
         unless( origin origin = gridSnap)
; ok to do clear now
         axlClearSelSet()
; now ask user for a destination
         gridSnap = axlEnterPoint(?prompts list("Pick origin point")
                        ? gridSnap t)
; Now snap the destination point based upon what can be found at that
         ; location
         ; for better results use the unsnapped pick
         dest = axlSnapToObject(nil axlLastPick(nil))
         ; fallback to grid snapped location if nothing found
         unless( origin dest = gridSnap)
; modify coordinates  with dest location
         axlTransformObject(....)
```


©2023 All Rights Reserved.

axlLastPickIsSnapped

```
axlLastPickIsSnapped()
     -> t/nil
```

Description

Normally called after an `axlEnter` call to determine if the pick was snapped or unsnapped.

Arguments

none

Value Returned

`t` if last picked was snapped, `nil` if unsnapped

Examples

```
snappedPoint = axlEnterPoint(?prompts list("Pick origin point")
          ?gridSnap t)
state = axlLastPickIsSnapped()
```


©2023 All Rights Reserved.

©2023 All Rights Reserved.

5

Interactive Edit Functions

Overview

This chapter describes the basic database edit functions `axlDeleteObject` and `axlDBDeleteProp`. It also describes `axlShowObject`, which you can use to display the data about an object.

`axlDeleteObject` does not allow you to delete Allegro PCB Editor logical or parameter objects. Also, certain figure or property objects may be marked `readOnly`. `axlDeleteObject` ignores objects with that property. DRC markers created by Allegro PCB Editor are an example of `readOnly` Allegro PCB Editor figure objects. An AXL program cannot modify DRC objects directly.

©2023 All Rights Reserved.

AXL/SKILL Interactive Edit Functions

This section lists interactive edit functions.

axlAllShapesMerge

```
axlAllShapesMerge(
     l_mode
     l_layer
     )
     ==> nil
```

Description

Merge all shapes, modify all dynamic shapes to static before merge.

Arguments

l_mode	■ 0: merge all shapes ■ 1: merge all dynamic shapes which will be converted to static shapes before merge ■ 2: merge all static shapes
l_layer	■ -1: merge all shapes on all layers ■ n: merge all shapes on layer "n" (n >= 0)

Value Returned

l_result/l_layer: Returns nil

Example

- merge all shapes

  ```
  axlAllShapesMerge(0 nil)
  ```

- merge all dynamic shapes

  ```
  axlAllShapesMerge(1 nil)
  ```


©2023 All Rights Reserved.

axlBondFingerDelete

```
axlBondFingerDelete(
     bondFingers
     deleteWires
     )
     ==> t/nil
```

Description

Deletes the (list of) bond fingers passed in. Optionally, it will delete the connect bond wire elements as well.

Arguments

bondFingers	either a dbid or a list of dbids representing the bond fingers to be deleted.
deleteWires	t/nil to tell the system whether it should remove any bond wires connected to the fingers.

Value Returned

Value is `t` returned, if one or more objects are deleted; otherwise the return value is `nil`.

©2023 All Rights Reserved.

axlBondWireDelete

```
axlBondWireDelete(
     bondWires
     deleteFingers
     )
     ==> t/nil
```

Description

Deletes the (list of) bond wires passed in. Optionally, it will delete the connect bond finger elements as well.

Arguments

Argument...	Value...
`bondWires`	`dbid` or list of `dbid`, representing the bond wires to be deleted.
`deleteFingers`	■ `t`: Bond fingers connected to the wires are removed ■ `nil`: Connect bond fingers are not deleted

Value Returned

Value is `t` returned, if one or more objects are deleted; otherwise the return value is `nil`.

©2023 All Rights Reserved.

axlChangeLine2Cline

```
axlChangeLine2Cline(
     lo_dbid/o_dbid
     )
     ==> x_cnt/nil
```

Description

Changes provided lines to clines. Lines not on an etch layer are ignored. If a line is converted to a cline then it may be assigned to a net, otherwise it will be left on a the standalone branch.

Arguments

lo_dbid/o_dbid	A single dbid or list of line dbids

Value Returned

`t` if succeeded, `nil` if failure

FAILURES: (for debug purposes set axlDebug(t) to see additional messages)

- dbid is not a line or a line on ETCH class
- line is LOCKED or FIXED

Examples

- Convert a line

```
res = axlDBCreateLine('(0:0 100:100) 5 "ETCH/TOP")
res = car(res)
cnt = axlChangeLine2Cline(res)
```

See Also

axlTransformObject

©2023 All Rights Reserved.

axlChangeLineFont

```
axlChangeLineFont(
     o_dbid
     x_newFont
     )
     ==> lo_dbid/nil
```

Description

Changes font on a line or segment.

Arguments

o_dbid	A line dbid
x_newFont	The new font. The valid values are `'SOLID` `'HIDDEN` `'PHANTOM` `'DOTTED` `'CENTER` `nil` is same as `SOLID`

Value Returned

FAILURES:

- dbid is not a cline, line or line/arc segment of a line/cline
- illegal option types
- transformed object is outside of database extents

Examples

■ Changes the font of a line to hidden

```
; ashOne is a selection utility found at <cdsroot>/share/pcb/examples/skill/
ash-fxf/ashone.il
dbid = ashOne()
; pick a line, cline or segment (set find filter)
updatedDbid = axlChangeLineFont(dbid 'hidden)
```

See Also

axlTransformObject, axlChangeLayer

©2023 All Rights Reserved.

axlChangeWidth

```
axlChangeWidth(
     lo_dbid/o_dbid
     f_newWidth
     [g_invisible]
     [l_endPoints]
     )
     ==> lo_dbid/nil
```

Description

Changes width of lines, clines and segments (arc and line).

By default, only visible lines are changed. This allows layer filtering by temporary changing the visible layers (see example in axlVisibleUpdate). If you wish to override this behavior then set the value of the optional variable *g_invisible* to `t`.

Note: If you need to change the width of multiple lines, it is more efficient to pass them as a list of *dbids* than to call this function for each *dbid*. This function does not support change in the width of shape borders.

Arguments

lo_dbid/o_dbid	Single `dbid` or list of `dbids`.
f_newWidth	New width of line.
g_invisible	If `t` objects do not need to be visible on the display to have their width changed.
l_endPoints	The start and end point along the path of the line where the width should be changed. Only available if single `dbid` passed for first argument, allows only a portion of the line or cline to be modified.

Value Returned

List of width objects or `nil` if failed.

Failures:

- *dbid* is not a cline, line or line/arc segment of a line/cline.
- Illegal option types.

©2023 All Rights Reserved.

- Transformed object is outside of database extents.

Example

Changes the width of a cline to 20 in current database use units

```
; ashOne is a selection utility found at
;   <cdsroot>/pcb/examples/skill/ash-fxf/ashone.il
dbid = ashOne()
; pick a line, cline or segment (set find filter)
updatedDbid = axlChangeWidth(dbid, 20.0)
```

See Also

axlTransformObject, axlChangeLayer

©2023 All Rights Reserved.

axlCopyProperties

```
axlCopyProperties(
     o_destDbid
     o_srcDbid
     )==> t/nil
```

Description

This copies properties from one object to another. It filters certain properties. If you need to copy properties suggest you utilize this interface instead doing it yourself.

Side effects may happen when properties are copied.

Properties filtered are:

- IDX family
- IDF_OWNER
- CLIP_DRAWING
- FIXED
- FIXED_PRIVATE
- DYN_SHAPE_PRIORITY
- SUBNET_NAME only if shape is not on ETCH

Also properties may not be copied if they do not meet the rules for the destination element (example not legal for element type).

Existing properties are maintained on destination object but they may be overridden by source object.

Arguments

o_destDbid	Destination for properties
o_srcDbid	Source for properties

Value Returned

`t` if objects are dbids, `nil` if one or more object is not a dbid.

©2023 All Rights Reserved.

See Also

axlCopyObject

©2023 All Rights Reserved.

axlCopyObject

```
axlCopyObject(
     lo_dbid/o_dbid
     ?move           l_deltaPoint
     ?mirror         t/nil
     ?angle          f_angle
     ?origin         l_rotatePoint
     ?allOrNone      t/nil
     ?retainNet      t/nil
     )
     ==> t/nil
```

Description

Use this function to copy the database object(s). This supports the same functionality as axlTransformObject except it copies and transforms one or more objects.

One additional option supported is retainNet. This only applies to vias. If the value of this option is set to `t`, the net of the via is retained on copy, `nil` allows the via to connect to whatever it touches at the new location. In the board, pins are not supported.

Caution

Properties and text attached to the database object are also copied. Also ***see*** axlTransformObject ***cautions.***

Arguments

`lo_dbid/o_dbid`	a single dbid or list of dbids
`l_deltaPoint`	optional move distance
`mirror`	optional mirror object (see above table)
`f_angle`	optional rotation angle
`l_rotatePoint`	optional rotation point
`allOrNone`	if t and a group of objects, transform must succeed on all objects or fail
`retainNet`	t/nil (applies to vias only)

©2023 All Rights Reserved.

Value Returned

list of transformed objects or `nil` if failed.

Tip

If you need to copy a group of objects the performance is much better if you call this function with the object group instead of passing each dbid individually.

Examples

ldbid = list of database objects

dbid = one database object

Case 1: Copy a set of objects 1000 database units vertically

```
r = axlCopyObject(ldbid, ?move '1000.0:0.0)
```

Case 2: Copy and rotate an object about its origin 45 degrees

```
r = axlCopyObject(dbid, ?angle 45)
```

Case 3: Copy and rotate an object about a rotate point

```
r = axlCopyObject(dbid, ?angle 45 ?origin 100:100)
```

See Also

axlTransformObject, axlDBCloak, axlCopyProperties

©2023 All Rights Reserved.

axlDBAltOrigin

```
axlDBAltOrigin(
     g_mode
     o_dbid
     )⇒ xy/nil
```

Description

Returns alternative center for a *dbid*. This provides SKILL access to the `move` command's origin point option in the Options tab.

It is intended for symbols instances (it will convert a component instance to its symbol). Body origin rules for symbols, origin is the first rule that is met:

1. the origin of text on the PACKAGE_GEOMETRY/BODY_CENTER layer
2. the center of an extent box created by the union of all shapes on layers PACKAGE_GEOMETRY (PLACE_BOUND_TOP, PLACE_BOUND_BOTTOM, DFA_BOUND_TOP, DFA_BOUND_BOTTOM) and EMBEDDED_GEOMETRY (PLACE_BOUND and DFA_BOUND)
3. center of the symbol bbox

Other Allegro figure *dbids* can be supplied, but all options may not be supported. For example, a CLINE supports the center option, but not *'origin* or *'pin1*.

©2023 All Rights Reserved.

Arguments

g_mode	The '*center* option returns the body center of an object. The '*origin* option returns the origin of an object (normally if *dbid* has an *xy* attribute, this is the same coordinate). For Symbols, the board origin can be set by the origin of text on the PACKAGE_GEOMETRY/BODY_CENTER layer. The '*pin1* option returns pin1 as center.
o_dbid	A figure (geometric object) *dbid.*

Value Returned

`xy`	Location requested.
`nil`	Not a *dbid*, *dbid* is not a figure dbid, or mode is not supported for that object.

See Also

axlDBGetSymbolBodyExtent

Example

The `;ashOne` utility is supplied in the examples SKILL code.

```
sym = ashOne()
;  select symbol in Find filter and select a symbol
sym->xy
; prints (3503.0 1058.0)
axlDBAltOrigin('origin sym)
; prints (3503.0 1058.0) -- origin of symbol is same as xy
axlDBAltOrigin('center sym)
; prints (3250.0 1737.0)
axlDBAltOrigin('pin1 sym)
; prints (3503.0 1058.0) -- pin1 of symbol is same as its x
```


©2023 All Rights Reserved.

axlDBChangeText

```
axlDBChangeText(
     o_dbid
     t_text
     [r_textOrientation/x_textBlock]
     )
     ==> l_result/nil
```

Description

Modifies the characteristics of a text string in the layout. To keep current settings on the text, set the arguments, `t_text` and `r_textOrientation` to `nil`. To move text use the axlTransformObject object.

Note: For renaming refdes this works the same as edit text in that it checks for the HARD_LOCATION property and will not rename refdes if this property is present. If you want to ignore this property, use axlRenameRefdes.

Arguments

`o_dbid`	Database ID of text
`t_text`	Text string. If the value of this argument is set to `nil`, current settings are retained on the text
`r_textOrientation`	Orientation of text The `nil` value indicates that current settings are to be retained on the text. See Structure.
`x_textBlock`	To be specified if only the text block is to be changed

©2023 All Rights Reserved.

Structure

The `axlTextOrientation` structure is as follows.

```
defstruct axlTextOrientation
r_textOrientation ;
```

orientation of text

`textBlock;` A string specifying the text block name

`rotation;` A floatnum variable specifying rotation in degrees

`mirrored;` Possible values are:

- `t`: mirrored
- `nil`: not mirrored
- `GEOMETRY`: only geometry is mirrored.

`justify;` Supported values:

- left
- center
- right

If any of these arguments is modified, then you need to provide values for all arguments. Arguments for which the values are not changed, copy the values from the existing text dbid.

Note: As with all SKILL defstructs, use constructor function, `make_axlTextOrientation` to create instances of `axlTextOrientation`. To copy instances of `axlTextOrientation`, use the copy function, `copy_axlTextOrientation`.

Value Returned

nil	if not created
l_result	List containing:

- (car) list of DBID of the text
- (cadr) t if DRCs created or nil.

©2023 All Rights Reserved.

Caution

Do not pass text string with newlines as an argument.

See Also

axlTransformObject, axlChangeLayer, axlRenameRefdes, axlTextOrientationCopy

Example

Example is text added in axlDBCreateText

```
text = car(ret)
```

- Change text

```
cret = axlDBChangeText(text "Chamfer neither sides")
```

- Change text block

```
cret = axlDBChangeText(text nil 4)
```

- Change rotation and text

```
axlTextOrientationCopy(text myorient)
myorient->rotation = 0.0
cret = axlDBChangeText(text "New text" myorient)
```


©2023 All Rights Reserved.

axlDBConnectItem

```
axlDBconnectItem(
     o_dbid
     [x-trapSize]
     )
     ⇒ x_count/nil
```

Description

Connects an unconnected cline end (path) to close by pins or vias. It basically does a device connectivity to connect clines to vias.

By default, if trap is absent or nil use the cline width to construct a search box of 2 * width. This is normally sufficient if the cline ends on the pad or within the pad to make a connection. If there are multiple pads within the search box it will use the closest pad to the unconnect end based on the origin of the pad.

To achieve a connection it may:

- extends a segment
- adds a new segment
- shortens a segment (occurs if the segment crosses the pad's connect point and does not make a connection). This is atypical.

Notes

- Currently does not consider net. Future versions may take net into account.
- If changing many clines put the operation in `axlDBCloak`.
- It is recommend to use the default *`trapSize`*. Large values may slow performance.

Arguments

`o_dbid`	A dbid, path (cline)
`x_trapSize`	Optional size to look in design units. By default, uses the cline width to construct a box of width * 2. Trapsize is limited to 4 times the line width.

©2023 All Rights Reserved.

Value Returned

`nil`	An illegal argument
`x_count`	Number of connections made.
	Can be `0` (no additional connections) or `1` or `2` new connections

See Also

axlDBGetConnect

Examples

Uses "ash" example software in example hierarchy

```
cline = ashOne('("NOALL" "CLINES"))
ret = axlDBConnectItem(cline)
```


©2023 All Rights Reserved.

axlDeleteObject

```
axlDeleteObject(
     o_dbid/lo_dbid
     [g_mode]
     )
     ⇒ t/nil
```

Description

Deletes single or list of database objects from database.
Deletion of components deletes the symbol owner as well.
Deletion of nets is LOGIC only, and leaves the physical objects.

Command allows for rip-up of associated etch via the ripup option.

```
axlDeleteObject(lo_dbid 'ripup)
```

Except for Nets, objects will be erased before they are deleted. Only the Net's Ratsnests is erased. Other parts of a Net will not be erased because there is no ripup. If a Net is in a highlighted state, it will be dehighlighted.

Also allows deletion of the following parameter records:

- artwork (films)

  Both individual films can be deleted and all films If all films are deleted then next time the artwork dialog is opened then it will be auto-populated with the default films.

- subclasses

  subclasses must by empty and legal for deletion (cannot delete PIN subclasses).

In the case of deleting parameter records, the current restriction is to only pass that single object. Do not try to pass multiple parameter objects or to mix them with non-parameter objects.

©2023 All Rights Reserved.

Arguments

o_dbid/lo_dbid	*dbid*, or list of *dbids* to delete from layout.
g_mode	optional delete options.'ripup - enable etch ripup option (same as Allegro delete ripup command ripup option)

Value Returned

t	Deleted one or more objects from the layout.
nil	Deleted no objects from the layout.

Caution

If passed component or net dbid will delete the logic. This is different from the Allegro `delete` ***command which will delete the physical objects associated with the logic (clines/vias for nets and symbols for components). To emulate the Allegro*** `delete` ***command behavior, select and then set objects selection using*** `axlSetFindFilter` ***with the*** `equivlogic` ***parameter passed to the*** `?enabled` ***option (See example below).***

Example

The following example loops on `axlSelect` and `axlDeleteObject`, deleting objects interactively selected by user. This could be dangerous because object is deleted without allowing *oops* (left as an exercise to the reader -- required use of `axlDBStartTransaction` and popup enhancement).

```
(defun DelElement ()
          let ((mypopup)
          "Delete selected Objects"
          mypopup = axlUIPopupDefine(nil
               '(("Done" axlFinishEnterFun)
                    ("Cancel" axlCancelEnterFun)))
             axlUIPopupSet(mypopup)
          axlSetFindFilter(?enabled '("ALL" "EQUIVLOGIC") ?onButtons '("ALL"))
          while( axlSelect() axlDeleteObject(axlGetSelSet()))
```


©2023 All Rights Reserved.

```
        axlUIPopupSet( axlUIPopupDefine(nil nil))
))
```

The following deletes the TOP artwork film record

```
p = axlGetParam("artwork:TOP")
axlDeleteObject(p)
```

The following deletes all films

```
axlDeleteObject(axlGetParam("artwork"))
```


©2023 All Rights Reserved.

axlDeleteByRectangle

```
axlDeleteByRectangle
     g_windowSelect
     g_windowDelete
     g_insideOutside
     [b_ignoreFixed]
     [l_objectTypes]
     -> t/nil
```

Description

This function removes elements from a design relative to a rectangular box provided (*`g_windowDelete`*). The box is defined by a two points on opposite sides of the box and the edges of the box will be parallel to the x and y axes. *`g_windowSelect`* is another box which is used to select items for removing. It is a SKILL access to the *Manufacture – Drafting – Delete by Rectangle* command in the tool.

The interface operates by removing all objects either inside or outside of the provided rectangle. For those elements which cross the edge of the window provided, the object is cut there. This means only part of a shape over top of the rectangle will be removed, and a cline will be cut at the XY location where it meets the rectangle (the center line will be cut at the box boundary, but the end caps of the trimmed cline may still extend over the boundary).

©2023 All Rights Reserved.

Arguments

l_windowSelect	The parameter type is a list of 2 points defining a box to select items which need to be cut, for example, list(-500:-500 500:500)
l_windowDelete	Bounding box to be cut relative to. For example, list(-500:-500 500:500)
s_insideOutside	`'inside`: Deletes elements inside the box, while keeping those outside of it. `'outside`: Deletes elements outside the box, while keeping those inside of it.
[b_ignoreFixed]	`t`: Ignores fixed property on elements to allow them to be deleted. `nil`: Respects the fixed property, so fixed elements will not be deleted, even though they are in an area where non-fixed elements are deleted. If not provided, default value is nil.
[ls_objectTypes]	The argument type is a list of strings, or a single string if there is only one object type to be deleted. List may include any set of: "VIAS" "FINGERS" "CLINES" "LINES" "BONDWIRES" "SHAPES" "CLINESEGS" "OTHERSEGS". If not provided, all object types will be processed.

Value Returned

t	Operation was successful.
nil	Operation failed.

Example

```
axlDeleteByRectangle(list(-500:-500 500:500) list(-500:-500 500:500) 'inside t
'("VIAS" "CLINES"))
```

See Also

axlDeleteObject

©2023 All Rights Reserved.

axlDeleteTaper

```
axlDeleteTaper(
     o_dbid
     )
     ==> t/nil
```

Description

Deletes tapers

Arguments

o_dbid dbid of Shape or PATH.

Value Returned

- `t` – indicates success
- `nil` – command failed

©2023 All Rights Reserved.

axlDBDeleteProp

```
axlDBDeleteProp(
     lo_attach
     lt_name
     )
     ⇒ l_result/nil
```

Description

Deletes the properties listed by name, in *lt_name*, from the objects whose *dbids* are in *lo_attach*.

Arguments

lo_attach	List of *dbids* of objects from which properties are to be deleted. *lo_attach* may be a single *dbid*. If *lo_attach* is `nil`, then the property is to be deleted from the design itself.
lt_name	List of names of the properties to be deleted. *lt_name* may be a list of strings for several properties, or a single string, if only one property is to be deleted.

Value Returned

l_result	List. (`car`) list of *dbids* of members of *lo_attach* that successfully had at least one property deleted. (`cadr`) always `nil`.
`nil`	No properties deleted.

See Also

axlDBAddProp, `axlDBDeletePropAll`

©2023 All Rights Reserved.

Example

```
axlDBCreatePropDictEntry(
    "myprop", "real", list( "pins" "nets" "symbols"),
    list( -50. 100), "level")
axlClearSelSet()
axlSetFindFilter(
    ?enabled '("NOALL" "ALLTYPES" "NAMEFORM")
    ?onButtons "ALLTYPES")
axlSingleSelectName( "NET" "ENA2")
axlDBAddProp(axlGetSelSet(), list("MYPROP" 23.5))
axlShowObject(axlGetSelSet())
```

First defines the string-valued property `"myprop"`, then adds it to the net `"ena2"`, then deletes the property from the net.

The following **Show Element** form shows the net with `"MYPROP"` attached.

©2023 All Rights Reserved.

```
axlDBDeleteProp(axlGetSelSet() list("myprop"))
axlShowObject(axlGetSelSet())
```

Using `axlDBDeleteProp`, deletes the attached property.

The following Show Element form shows the net with *MYPROP* deleted.

©2023 All Rights Reserved.

axlDBDeletePropAll

```
axlDBDeletePropAll(
     t_name
     )
     ==> x_count/nil
```

Description

Deletes all instances of the property *t_name* in the database. This includes properties that exist on the symDef and compDef that cannot be access via the property edit command. If you delete a property that effects the DRC system, you may wish to wrap this call with a `axlDBCloak` for better performance.

Arguments

t_name	Name of property to have all its instances deleted.

Value Returned

x_count	Returns number of properties deleted
nil	Error, property definition doesn't exist

See Also

axlDBAddProp, `axlDBDeleteProp`, and axlDBCloak

EXAMPLE

Delete all fixed properties in database

```
axlDBDeletePropAll("FIXED")
```


©2023 All Rights Reserved.

axlDBDeletePropDictEntry

```
axlDBDeletePropDictEntry(
     t_name
     )
     ==> t/nil
```

Description

Deletes an unused user property definition. Property entry must be unused. The property definition must be a user property and its useCount (`axlDBGetPropDictEntry`) must be zero for you to delete it. Use `axlDBDeletePropAll` if property is in use.

Arguments

t_name	String specifying the name of the user property dictionary entry to be deleted.

Value Returned

t:	Deleted the property definition.
nil	Property is in use, is an Allegro property, property does not exist, or name is not legal.

See Also

axlDBAddProp, `axlDBDeleteProp`, and axlDBCreatePropDictEntry

EXAMPLE

take property, myprop, created `axlDBCreatePropDictEntry`

```
axlDBDeletePropDictEntry("myprop")
```


©2023 All Rights Reserved.

axlDBOpenShape

```
axlDBOpenShape(
     o_shapeDbid/nil
     [o_polygon/r_path/nil]
     [g_close]
     )
     ==> o_dbid/nil
```

Description

Opens an existing shape to replace its boundary or to modify its voids.

Shape can be left open so you can update the voids within the shape. If only the outline needs to be replaced, you can close the shape as part of this call. The new outline cannot overlap existing voids or allow existing voids to exist outside the outline.

Note: A side-effect of opening an existing shape is the shape will be displayed as unfilled until it is closed.

Arguments

`o_shapeDbid`	dbid of shape to be modified. If dbid is nil then use the existing open shape
`o_polygon`	new shape outline in polygon format
`r_path`	new shape outline in r_path format
`g_close`	optional option to close the shape (t) boundary modification

Value Returned

`o_dbid`	dbid of provided shape or nil if an error

See Also

axlDBCreateCloseShape, axlDBCreateOpenShape, axlDBCreateVoid, axlShapeDeleteVoids, axlShapeAutoVoid

©2023 All Rights Reserved.

Examples

ashOne is a shareware utility that allows user to select an object (see `<CDSROOT>/share/pcb/examples/skill/ash-fxf/ashone.il`)

1. Select a shape and expand it by 100

```
shp = ashOne("shapes")
edge = car( axlPolyFromDB(shp) )
newedge = car( axlPolyExpand(edge 100.0 'NONE) )
newshp = axlDBOpenShape(shp newedge t)
```

2. Select a void delete it

```
shp = ashOne("voids")
edge = axlPolyFromDB(shp)
newedge = car( axlPolyExpand(edge 100.0 'NONE) )
newshp = axlDBOpenShape(shp newedge)
q = axlDBCreateCloseShape(newshp)
```

3. Select a shape, delete all voids and contract boundary by 100

```
shp = ashOne("shapes")
edge = car( axlPolyFromDB(shp) )
newedge = car( axlPolyExpand(edge -100.0 'NONE) )
newshp = axlDBOpenShape(shp nil)
axlShapeDeleteVoids(shp)
q = axlDBCreateCloseShape(newshp)
```


©2023 All Rights Reserved.

axlDeleteFillet

```
axlDeleteFillet(
     o_dbid
     )
     ⇒ t/nil
```

Description

Deletes fillet associated with a PIN, VIA, T, or CLINE. The command also deletes a single fillet if `o_dbid` is a fillet shape.

When deleting via a cline, Allegro PCB Editor searches for the via/pin connections and deletes the fillets from that pin or via. It only deletes FILLETS on the layer of the CLINE. If deleting FILLETS from a PIN or VIA, it deletes FILLETS on all layers.

Arguments

o_dbid	*dbid* of a `PIN`, `VIA`, `PATH`, or `T`.

Value Returned

`t`	Fillet deleted.
`nil`	No fillet deleted.

©2023 All Rights Reserved.

axlFillet

```
axlFillet (
     o_dbid/lo_dbid
     )
     ⇒ t/nil
```

Description

Adds fillet between cline and pin/via, and at T. Removes and re-generates existing fillets. Fillet parameters are controlled from the Glossing **Pad and T Parameter** form.

Arguments

o_dbid	*dbid* can either be a `NET`, Path(`CLINE) or line(segment)`

Value Returned

`t`	Fillet(s) added.
`nil`	Error or no fillet added.

Notes

Pins, vias and Ts are not supported; use `axlDBGetConnect` on these objects to get a list of clines that connect.

For best performance, especially if fillets impact dynamic shapes, make a single call with the list of objects to be filleted.

Examples

fillet new MEMDATA8

```
axlFillet(car(axlSelectByName("NET" "MEM_DATA8")))
```


©2023 All Rights Reserved.

axlFilletConvert

```
axlFilletConvert(
     o_dbid
     ) -> t/nil
```

Description

Converts a fillet or taper to a static shape.

This command should only be used if converting a design to another form such as if you are crafting a panelization solution.

Important

Dynamic fillets should be disabled when using this command.

Some of the side effects of using this command are:

- The converted fillets remain if etch is deleted/modified
- If dynamic fillets are enabled, a duplicate fillet appears.
- DRCs may occur because the converted fillet or taper uses shape spacing.
- Voiding other shapes may change.
- Etch length calculations may be effected.
- Etch editing may work differently on these traces.

Arguments

o_dbid	A fillet shape dbid.

Value Returned

`t` if the fillet is successfully converted to a static shape, `nil` if dbid is not a fillet shape.

See Also

axlDeleteFillet

©2023 All Rights Reserved.

axlFixFillet

```
axlFixFillet(
     o_dbid
     ) ⇒ t/nil
```

Description

Flags a fillet or taper as fixed in the database. Object are never modified while fixed.

Arguments

o_dbid	A fillet shape dbid.

Value Returned

`t`	if the fillet is successfully marked as fixed
`nil`	if fail

See Also

axlUnfixFillet

©2023 All Rights Reserved.

axlGetLastEnterPoint

```
axlGetLastEnterPoint ()
     ⇒ l_point/nil
```

Description

Gets the last pick location from `axlEnterPoint`.

Arguments

None.

Value Returned

`axlGetLastEnterPoint` User pick from last call to `axlEnterPoint()`.

Example

Returned list for a pick: `(1000.000 2000.000)`.

©2023 All Rights Reserved.

axlLastPick

```
axlLastPick(
     l_mode
     )⇒ xy
```

Description

This returns the last processed cursor pick. You can snap to current grid (*l_mode*)⇒ `t`) or leave it unsnapped. Position is returned in design units. The grid used depends on the active layer. A pick event causes the last pick. In SKILL, a call to axlEnterPoint, axlEnterEvent, and so on may generate this. It allows switching from a snapped to an unsnapped event. If a user has made no pick since launching Allegro PCB Editor, then it returns `(0 0)`.

Arguments

l_mode `t` for snapped and `nil` for unsnapped.

Value Returned

`Last pick as an xy list.`

Examples

```
snappedPoint = axlEnterPoint(?prompts list("Pick origin point") ?gridSnap t)
unsnapped = axlLastPick(nil)
```


©2023 All Rights Reserved.

axlWindowBoxGet

```
axlWindowBoxGet(
     )
     ⇒ l_bBox
```

Description

Returns the bounding box of the Allegro PCB Editor window currently visible to the user, in design units.

Arguments

None.

Value Returned

l_bBox	bBox of the current Allegro PCB Editor window.

©2023 All Rights Reserved.

axlWindowBoxSet

```
axlWindowBoxSet(
     l_bBox
     )
     ⇒ l_bBox/nil
```

Description

Sets Allegro PCB Editor display to given bBox. Adjusts it according to the aspect ratio and returns the adjusted bBox.

Arguments

l_bBox	bBox for display change.

Value Returned

l_bBox	Adjusted bBox.
nil	Invalid argument.

©2023 All Rights Reserved.

axlReplacePadstack

```
axlReplacePadstack (
     o_dbid/lo_dbid
     o_padstackdbid/t_padname
     )
     ⇒ lo_dbid
```

Description

Replaces the padstack on a pin or via (or a list of them). Will not print any error messages unless you have argument errors.

The pin/via can be a list or a single *dbid*. Ignores items in the list that are not pins or vias.

The padstack can be referenced by name or a *dbid* and must be present in the Allegro PCB Editor database. Use `axlDBCreatePadStack` to obtain a *dbid*.

Returns a list of pins/vias that have had their padstacks changed. This may not be the same as your initial list as the software removes *dbids* that are not pins or vias and those items where changing the padstack would create a database error.

Note: This function will not change symbol definition pins.

Caution

Changing the padstack on a pin in the drawing editor results in an exploded pin which increases your database size and impacts refresh_symbol.

Using this function can result in disconnects and new DRC violations.

Performance Hints

To change all instances of a particular padstack, it is faster to change the padstack itself.

If you are changing many pins and vias to the same padstack, you can save time by calling this function with a list of pins/vias instead of calling it for each pin or via.

©2023 All Rights Reserved.

axlPurgePadstacks

```
axlPurgePadstack (
     S_mode
     t/nil
     )
     ⇒ x-cnt
```

Description

Purges unused padstacks from the database in the area controlled by *S_mode* symbol.

‘

S_mode symbol	2nd arg = **t**	2nd arg = **nil**
'padstacks	Only purges unused derived padstacks.	Purges all unused padstacks.
'via	Purges vias not found from all via list constraints under the physical rule set and purges vias not loaded in the database, but found by looking on the disk via the PSMPATH environment variable.	Purges vias not found from all the via list constraints under the physical rule set. The nil option is NOT available from the Allegro PCB Editor user interface.

Tip

For best results, first delete the unused padstacks from the database, then purge the via lists.

©2023 All Rights Reserved.

Arguments

S_mode	`'padstacks` or `'via`.
option	`t`- purge unused derived padstacks or `nil` - purge all

Value Returned

x_cnt	Number of padstacks eliminated.

Examples

```
axlPurgePadstacks('padstacks nil)
axlPurgePadstacks('via t)
```

Emulates the default Allegro PCB Editor user interface behavior.

©2023 All Rights Reserved.

axlPurge3DModelMapDataInDesign

```
axlPurge3DModelMapDataInDesign
     -> t/nil
```

Description

Removes 3D model mapping data from the entire design.

Arguments

None

Value Returned

`t`	purge done
`nil`	not done

Example

```
result = axlPurge3DModelMapDataInDesign()
```


©2023 All Rights Reserved.

axlShapeAutoVoid

```
axlShapeAutoVoid(
     o_shapeId
     [s_options/ls_options]
     )
     ==> lo_shapeIds/nil
```

Description

Autovoids a static shape using current static shape parameters to control voiding except where options provide an override. Voiding dynamic shapes or dynamically-generated shapes is not supported.

This function produces a file, `shape.log`, as a side effect of the autovoid.

Options:

- '*`noRipThermals`* - by default autovoid rips up all existing thermal ties in the shape and creates a new set, maintaining existing thermals.
- '*`fragment`* - by default, if shape fragments into multiple shapes, prompts you before proceeding. If you proceed, Allegro PCB Editor allows a silent fragment. Overrides setting in static shape parameter record.
- '*`noFragment`* - opposite of fragment. API fails if shape needs to be fragmented.

Caution

Do not use this function to void shapes on negative planes. Artwork does not represent inside voiding.

©2023 All Rights Reserved.

Arguments

o_shapeId	Voidable shape.
s_options	Single option symbol (see above).
ls_options	List of options (see above).

Value Returned

lo_shapeId	List of voided shape. Normally this is one shape unless shape is broken into multiple pieces.
`nil`	Failed to void or illegal arguments.

See Also

axlShapeDeleteVoids

Examples

See `<cdsroot>/share/pcb/examples/skill/ash/ashshape.il`

```
axlShapeAutoVoid(shapeDbid '(noRipThermals fragment))
```


©2023 All Rights Reserved.

axlShapeChangeDynamicType

```
axlShapeChangeDynamicType(
     o_shapeId
     g_dynamic
     g_msgs
     ) -> o_dynShapeId/l_staticShapeId/nil
```

Description

Swaps a connectivity shape from static to dynamic or the reverse. This offers the same functionality as the Allegro PCB Editor command `shape change type`.

Notes:

- Voids in static are deleted when shape is converted to dynamic.
- Converting a dynamic shape to static can result in the loss of the original boundary since Allegro PCB Editor converts the generated shapes (on ETCH) to static shapes not boundary shapes.
- Shapes converted to static maintain voids.
- Filled rectangles are supported on ETCH, converted to a shape.

Tip

If changing the type of multiple shapes or doing multiple operations on a single shape (for example, convert then raise priority) consider wrapping the code in `axlDBCloak` to batch updates.

©2023 All Rights Reserved.

Arguments

o_shapeId	Dynamic shape id or static id.
g_dynamic	`t` makes the shape dynamic, `nil` makes the shape static.
g_msgs	`t` issue error messages if failed to convert; else be silent

Value Returned

`nil`	Failure.
o_dynShapeId	`dbid` of the dynamic shape converted from static.
l_staticShapeId	List of static shapes converted from dynamic shapes.

See Also

axlShapeChangeDynamicType

Examples

See `<cdsroot>/share/pcb/examples/skill/axlcore/ashshape.il`

Change to dynamic shape with messages:

```
ret = axlShapeChangeDynamicType(shape t t)
```

Change to static shape; no messages

```
ret = axlShapeChangeDynamicType(shape nil nil)
```


©2023 All Rights Reserved.

axlShapeDeleteVoids

```
axlShapeAutoVoid(
     o_shapeId/o_voidId/lo_voidid
     ) -> t/nil
```

Description

Lets you delete voids in a shape. Supports the following three forms of arguments:

- Shape that deletes all voids in that shape
- Delete single void
- Delete list of voids

Non-voids in list of voids options are silently ignored. You cannot delete the voids that are a part of auto-generated shapes.

If you are making a series of modifications to a shape, such as, deleting and adding voids or changing the shape boundary, then for best performance, it is recommended that you wrap your calls in axlDBOpenShape and axlDBCreateCloseShape.

Arguments

o_shapeId	Given a shape; deletes all voids associated with that shape.
o_voidId	Deletes the given void.
lo_voidid	Deletes the list of voids.

Value Returned

`t`	Deletes voids.
`nil`	Error.

See Also

`axlShapeAutoVoid`, axlDBOpenShape, axlDBCreateCloseShape

©2023 All Rights Reserved.

Examples

See `<cdsroot>/share/pcb/examples/skill/axlcore/ashshape.il`

Assuming you have shape `dbid` (`shapeId`):

- Delete a single void

  ```
  axlShapeDeleteVoids(car(p->voids))
  ```

- Delete all voids in shape except first:

  ```
  axlShapeDeleteVoids(cdr(p->voids))
  ```

- Delete all voids in the shape:

  ```
  axlShapeDeleteVoids(p)
  ```


©2023 All Rights Reserved.

axlShapeDynamicUpdate

```
axlShapeDynamicUpdate(
     o_shapeDbid/nil
     g_force
     ) -> x_ood/nil
```

Description

Updates a dynamic shape, or if `nil`, all dynamic shapes are updated. This ignores the current dynamic shape mode setting of the design.

By default, only updates the shape if it is out of date unless *`g_force`* is `t`. In this case, it updates the shape. If *`g_force`* is `nil` the shape is only updated if `dbid->fillOOD` is `t`. This function supports shapes whose `dbid->shapeIsBoundary` is `t`.

Updating a dynamic shape includes voiding, artwork smoothing, and thermal relief generation.

Arguments

`o_shapeDbid`	`dbid` of a dynamic shape.
`g_force`	Force shape to update even if it is up to date.

Value Returned

`x_ood`	If updating all returns count of all shapes that failed in updating. If single shape returns `0`; update successful, `1` otherwise.
`nil`	Return if there is an error; `dbid` is not a dynamic shape.

Examples

- Force update of a dynamic shape

  ```
  axlShapeDynamicUpdate(shapeId, t) -> 0
  ```

- Update all shapes `ood`

  ```
  axlShapeDynamicUpdate(nil nil) -> 0
  ```


©2023 All Rights Reserved.

axlShapeRaisePriority

```
axlShapeRaisePriority(
     o_shapeId
     ) -> x_priority/nil
```

Description

Raises the voiding priority of a dynamic shape (*o_shapeId*) to the highest on the chosen layer. If this shape overlaps other dynamic shapes on the layer, the other shapes void away from this shape.

The priority number is relative. Allegro PCB Editor adjusts the numbers, as necessary. You should only use the priority number for comparison with other dynamic shape priority numbers.

For a dynamic shape (those on CLASS=BOUNDARY) the attribute priority reflects the current priority (for example, `dbid->priority`).

Tip

If raising priority on multiple shapes or doing multiple operations on a single shape (for example, convert; then raise priority) consider wrapping the code in `axlDBCloak` to batch updates.

Arguments

o_shapeId	Dynamic shape id.

Value Returned

x_priority > 0	New priority of shape.
`-1`	Already at highest priority.
`nil`	Not a dynamic shape.

See Also

axlShapeChangeDynamicType

©2023 All Rights Reserved.

Example

See `<cdsroot>/share/pcb/examples/skill/axlcore/ashshape.il`

```
axlShapeRaisePriority(shape)
```


©2023 All Rights Reserved.

axlShapeMerge

```
axlShapeMerge(
     o_shapeId
     lo_shapes
     g_options/lg_options
     ) -> o_dynShapeId/l_staticShapeId/nil
```

Description

This merges shapes. Shapes must be overlapped without the fixed property to merge. All merging shapes (`lo_shapes`) must overlap the primary shape (`o_shapeId`).

Supports merging db types; shapes, rectangle and filled rectangles.

The resulting shape will take on the characteristics of the first shape. This includes shape type and properties. Any properties on the secondary shapes are lost.

Tip

If changing type of multiple shapes or doing multiple operations on a single shape (for example, convert then raise priority) consider wrapping the code in `axlDBCloak` to batch updates.

Arguments

`o_shapeId`	dynamic shape id or static id.
`g_dynamic`	`t` make shape dynamic, `nil` make static
`g_options`	Available options are:
	`check` - do not merge only perform checks for merging
	`'quiet` - do not output any messages

Value Returned

- `nil`: indicates failure
- `o_dynShapeId`: the dbid of the dynamic shape that was converted from static
- `l_staticShapeId`: list of static shapes that was converted from a dynamic shape.

©2023 All Rights Reserved.

See Also

axlShapeChangeDynamicType

Example

ashOne is a shareware utility that allows user to select an object (See `<cdsroot>/share/pcb/examples/skill/ash/ashshape.il`)

- Merge two shapes; interactively select two shapes that overlap

```
s1 = ashOne("shapes")
s2 = ashOne("shapes")
shapeResult = axlShapeMerge(s1 s2 'quiet)
```


©2023 All Rights Reserved.

axlShapeUpdateDegas

```
axlShapeUpdateDegas(
     o_shape
     )⇒ n_count
```

Description

Updates the out-of-date degassing pattern of a shape if specified or every degassed shape that is out-of-date if no argument is passed.

Arguments

`o_shape`	dbid of the specified shape.

Value Returned

`n_count`	The count of the updated shape

Example

- Update a specific out-of-date degassed shape, `o_shape`:

  ```
  axlShapeUpdateDegas(o_shape)
  ```

- Update all out-of-date degassed shapes:

  ```
  axlShapeUpdateDegas(nil)
  ```

See Also

axlShapeIsDegasOutOfDate

©2023 All Rights Reserved.

axlShoveItems

```
list

axlShoveItems(
     l_itemList
     )
     ⇒ t/nil
```

Description

Takes a list of *dbids* and shoves them according to the parameters set using `axlShoveSetParams`.

Arguments

l_itemList	List of *dbids* (clines, pins, or vias) to be shoved.

Value Returned

`t`	One or more items shoved.
`nil`	No items shoved.

Note: Pins and vias are not shoved, but the clines around them are shoved in an attempt to eliminate any DRCs between the pin/via and the cline.

The list of *dbids* passed in does not reflect the results of the shove, as the original item may be deleted and/or replaced.

Example

```
(defun ShoveElement ()
    axlSetFindFilter (?enabled '("CLINES" "VIAS")
                      ?onButtons '("CLINES" "VIAS"))

    axlSelect()
    axlShoveItems (axlGetSelSet())
)
```

Shoves an item (or items) interactively selected by the user.

©2023 All Rights Reserved.

axlShoveSetParams

```
axlShoveSetParams(
     l_params
     )
     ⇒ t/nil
```

Description

Sets the parameters used for shoving by the `axlShoveItems`. If you do not provide all values, the indicated default is used.

Arguments

`l_params` List of parameters of the form:

```
(shoveMode cornerType gridded smooth oop samenet)
```

`ShoveMode` is an integer as shown:

shoveMode	Description
`0`	hug preferred - Items passed in try to mold around items they are in violation with (default)
`1`	shove preferred - Items passed in try to shove items they are in violation with.

`CornerType` is an integer as shown:

cornerType	Description
`90`	90 degree corners.
`45`	45 degree corners.
`0`	Any angle corners.

©2023 All Rights Reserved.

Gridded is an integer as shown:

gridded	Description
0	Ignore grids (default)
1	Perform shoves on grid.

Smooth allows smoothing of shoved traces and is an integer as shown:

smooth	Description
0	No smoothing (default)
1	Minimal smoothing.
2	More smoothing.
3	Still more smoothing.
4	Full smoothing.

Oops allows aborting the shove of DRCs result and is an integer as shown:

oops	Description
0	*Oops* off (default)
1	*Oops* if DRCs are left over.

Samenet tests for the same net violations.

Note: This results in a post-shove check for DRCs that is meaningful only if you also set *oops* to the `"oops if drcs"` value.

samenet	Description
0	No *samenet* tests (default).
1	Enable *samenet* DRC checking.

©2023 All Rights Reserved.

Value Returned

`t`	Shove parameters set.
`nil`	No shove parameters set.

Example

```
(defun SetParams ()
(let (params (shoveMode 1) (cornerType 45) (gridded 1))
    params = list(shoveMode cornerType gridded)
    axlShoveSetParams(params)
))
```

Sets shove parameters to shove preferred, 45 degree mode, and snap to grid.

©2023 All Rights Reserved.

axlSmoothDesign

```
axlSmoothDesign(
     lx_numPasses
     ) -> x_change
```

Description

Smooths the entire design. For good results on complicated designs, multiple passes are necessary. Since changes in one pass may open space that can be used in the next pass. Suggest 3 is a typical number although very complex designs can benefit from a higher number of passes. But the more passes the longer it will take.

Arguments

`lx_numPasses`	list of number of passes to perform

Value Returned

`x_change`, number of items changed

Example

Smooth design using 3 passes

```
axlSmoothSetParams(list("45" -1.0 "0" 10.0 0))
res = axlSmoothDesign(list(3))
```

See Also

axlSmoothSetParams

©2023 All Rights Reserved.

axlSmoothItems

```
axlSmoothItems (
     lo_clineList
     ) ==> (x_list
```

Description

Takes a list of dbids representing clines and/or cline segments and smooths them according to the parameters set using the axlSmoothSetParams() function.

Arguments

`lo_clineList`	List of dbids representing clines and/or cline segments to be smoothed.

Value Returned

This function returns a list containing the number of clines that were changed by the smoothing process and the list of changed items. The format is as follows:

```
(x_change (o_dbid1 o_dbid2 o_dbid3))
```

Where `x_change` indicates the number of items changed, or `-1` if a user interrupt occurred.
If an error occurs, the function will return `nil`.

Example

- Smooth a set of clines

```
clines = <list of ...>
axlSmoothSetParams(list("45" -1.0 "0" 10.0 0))
res = axlSmoothItems(clines)
```

See Also

axlSmoothSetParams

©2023 All Rights Reserved.

axlSmoothSetParams

```
axlSmoothSetParams(
     l_params
     ) ==> t/nil
```

Description

Sets the parameters used for smoothing the routes. All parameters must be supplied but a nil as a parameter option will leave the existing setting.

The smooth functionality is provided on an "as-is" basis. It works well on many designs but has the following restrictions:

- not differential pair aware.
- may have issues with electrically constrained nets

Tip

See axlDBIgnoreFixed if you want to temporary disable FIXED testing.

Arguments

`l_params` List containing the parameters, the list is of the following format.

```
(cornerType maxCornerLength padEntryRestriction minPadEntryLength
     sortDirection)
```


©2023 All Rights Reserved.

`cornerType`	Can be one of the following string values:	
	90	for 90 degree corners
	45	for 45 degree corners
	0	for any angle corners
	1	for arc corners
`maxCornerLength`	This is an integer value indicating the maximum length of a bubble or jog in db units. A negative value indicates UNLIMITED.	
`padEntryRestriction`	Can be one of the following string values:	
	2	Indicates that there are no restrictions
	1	Indicates that all pad entry segments be fixed
	0	Indicates that the entry segments for all rectangular pads be fixed
`minPadEntryLength`	This is an double value indicating the minimum length of fixed pad entry segments in user units. If a pad entry segment is longer than this length, it will be broken at or near that point so that smoothing can occur on that segment. A negative value indicates UNLIMITED. This value is not applicable if padEntryRestriction is "2".	
`sortDirection`	This indicates how the clines are to be sorted before smoothing begins. This can be one of the following integer values:	
	0	No sorting.
	1	Sort from the North.
	2	Sort from the NorthEast.
	3	Sort from the East.
	4	Sort from the SouthEast.
	5	Sort from the South
	6	Sort from the SouthWest
	7	Sort from the SouthWest
	8	Sort from the NorthWest

©2023 All Rights Reserved.

Value Returned

`t` if successful, `nil` if not.

Example

- Set parameters

```
axlSmoothSetParams(list("45" -1.0 "0" 10.0 0))
```

- Update corner type to 90

```
axlSmoothSetParams(list("90" nil nil nil nil))
```

See Also

axlSmoothItems, axlSmoothDesign, axlDBIgnoreFixed

©2023 All Rights Reserved.

axlStepDelete

```
axlStepDelete(
     g_type
     t_name/o_dbid
     )
     ==> t/nil
```

Description

This removes a STEP assignment to a symbol or component definition.

Arguments

g_type	Should be 'primary or 'alt (a nil is equiv to 'primary)
t_name	May be compdef or a symdef name. For a .dra file this should be nil
o_dbid	A symdef or compdef

Value Returned

`t`	Deleted
`nil`	Not deleted

See Also

axlStepGet

Examples

- Delete STEP assignment on a symbol definition

  ```
  result = axlStepDelete(nil "LED_Y")
  ```

- Delete STEP assignment on a component definition

  ```
  result = axlStepDelete(nil "CAP")
  ```


©2023 All Rights Reserved.

axlStepSet

```
axlStepSet(
     g_mapType
     t_name/o_dbid
     t_stepFile
     ll_mappingData
     )
     ==> t/nil
```

Description

Assigns a STEP file with a mapping or change to an existing STEP mapping to a symbol or component definition.

Offsets are specified in current design units. If STEP file uses different units, Allegro will eventually convert the offset values to the units of the STEP file.

Supports both `.stp` and `.step` file extensions.

Arguments

g_mapType	Should be 'primary or 'alt (a nil is equiv to 'primary)
t_name	May be compdef or a symdef name
o_dbid	A symdef or compdef. For a `.dra` file this should be nil
t_StepFile	This is a name of the STEP file. If you have no directory component. If this is nil and the object has the existing step file, then the mapping data provided is updated.
ll_mappingData	Can be nil if default mapping or list of symbol name/value pairs (see axlStepSet for permissible attributes)

Value Returned

`t`	Mapping occurred
`nil`	Error

See Also

axlStepGet

©2023 All Rights Reserved.

Examples

- Assign a STEP model to a `.dra` design (no mappings)

```
result = axlStepSet('primary nil "led-L813_Y" nil)
```

- Assign a STEP model to a `.dra` design (no mappings)

```
map = '(rotation_z 3.1 rotation_y 2.0 rotation_x 1.0 offset_z
6.3 offset_y 5.3 offset_x 4.2 color 9)
result = axlStepSet('primary nil "led-L813_Y" map)
```

- Modify mappings from last example

```
map = '(rotation_z 30.1 rotation_y 20.0 rotation_x 10.0 offset_z
6.3 offset_y 5.3 offset_x 4.2)
result = axlStepSet('primary nil nil map)
```

- Assign a alternative STEP model to a symdef

```
map = '(rotation_z 10.1 rotation_y 20.0 )
result = axlStepSet('alt "CAP10X16MM-RAD" "CAPC3225" map)
```


©2023 All Rights Reserved.

axlSymbolAttach

```
axlSymbolAttach(
     o_symInstDbid
     o_dbid/lo_dbid
     )
     ==> t/nil
```

Description

Attaches an object or list of objects to symbol instance. For etch objects, provides the ability to associate pin escapes with a symbol.

Attach/detach rules:

- For detaching, object must be linked to the symbol instance provided. For attaching, the object can not be linked to any other symbol.
- If text appears of a REFDES class, it can't be linked or unlinked
- Linking or unlinking non-etch objects cause them to be deleted or duplicated if refresh symbol is run. Etch objects is more fully supported by refresh symbol.
- CLINES, LINES, SHAPES, RECTS, FRECTS and TEXT are supported with the layer limits noted below:
    - Items on BOUNDARY class items are NOT supported.
    - Shapes cannot be dynamic or generated from a dynamic shape.
    - Objects cannot be on the DRC class.

Caution

Running refresh_symbol may result in deletion of design level attachments.

©2023 All Rights Reserved.

Arguments

o_symInstDbid	symbol instance
o_dbid	dbid to assign to symbol
lo_dbid	list of dbid to assign to symbol

Value Returned

t	was able to change object
nil	otherwise

See Also

axlSymbolDetach

Example

Examples use ashOne which is a shareware utility that allows user to select an object (see `<cdsroot>/share/pcb/examples/skill/ash-fxf/ashone.il`)

- Attach an object to a symbol:

```
symdbid = ashOne("SYMBOLS")
dbid = ashOne("NOALL")
ret = axlSymbolAttach(symdbid dbid)
```


©2023 All Rights Reserved.

axlSymbolDetach

```
axlSymbolDetach(
     o_symInstDbid
     o_dbid/lo_dbid/g_mode
     )
     ==> t/nil
```

Description

Remove an object from a symbol instance. This function unlinks objects from the given symbol instance.

For pin escapes, two special modes are provided to detach all or most symbol etch from a given symbol instance.

It only unlinks an object from a symbol if it matches the provided symbol instance.

See axlSymbolAttach for the rules.

Caution

Running refresh_symbol result results in duplicate objects as the detached objects are loaded again.

Arguments

o_symInstDbid	symbol instance to modify.
o_dbid	dbid to unlink from symbol
lo_dbid	list of dbids to unlink from symbol
g_mode	special modes for unlinking all "etch" from symbol

- `'allEtch` – deassign all etch from symbol
- `'allClineVia` – design all etch except for shapes from symbol

©2023 All Rights Reserved.

Value Returned

`t`	was able to change symbol
`nil`	Otherwise

See Also

axlSymbolAttach

Example

Examples use ashOne which is a shareware utility that allows user to select an object (see `<cdsroot>/share/pcb/examples/skill/ash-fxf/ashone.il`)

- Typical method: To get the symdbid from the object:
  - if etch

```
symdbid = dbid->symbolEtch
```

  - if nonetch

```
symdbid = dbid->parent
symdbid = ashOne("SYMBOLS")
dbid = ashOne("NOALL")
ret = axlSymbolDetach(symdbid, dbid)
```

- Deassign all etch from symbol except shapes

```
symdbid = ashOne("SYMBOLS")
ret = axlSymbolDetach(symdbid, 'allClineVia)
```


©2023 All Rights Reserved.

axlAddTaper

```
axlAddTaper(
     o_dbid/lo_dbid
     )
     ==> t/nil
```

Description

Adds tapered trace. Tapered trace parameters are controlled from the Glossing "Pad and T" Parameter form.

Arguments

o_dbid	dbid can either be a Path (CLINE) or line (segment).

Value Returned

- *t*, returned when the function call is successful
- *nil*, indicates failure

©2023 All Rights Reserved.

axlTextOrientationCopy

```
axlTextOrientationCopy(
     o_textDbid
     [orient]
     ) -> orient/nil
```

Description

This is a convenience function that updates a TextOrientation defstruct based upon a text dbid. This is typically used with axlDBCreateText or axlDBChangeText.

Arguments

`o_textDbid`	text dbid
`orient`	optional existing defstruct, if `nil` will create a new defstruct

Value Returned

- `orient`, update TextOrientation defstruct
- `nil`, if there are error in the arguments

See Also

axlDBChangeText

©2023 All Rights Reserved.

axlTransformObject

```
axlTransformObject(
     lo_dbid/o_dbid
     ?move l_deltaPoint
     ?mirror t/nil/'GEOMETRY
     ?angle f_angle
     ?origin l_rotatePoint
     ?allOrNone t/nil)
     )
     ⇒ lo_dbid/nil
```

Description

Moves, rotates, and/or spins one object or a list of objects. Each Allegro PCB Editor database object has a legal set of transforms (see Table 5-1 on page 417). If the object does not accept a transform, then that transform is silently ignored.

If multiple transformations are applied, the order used is:

1. move
2. mirror
3. rotate

If `allOrNone` flag is set, then the entire transformation fails when one object's transformation fails. By default, one object's failure does not stop the transformation on the other objects. A failure is a database failure. For example, a move that puts an object outside of the database extents is a database failure. Attempting an illegal transform is NOT a failure. If one or more objects are not transformed, there is no failure.

Table 5-1 Supported Transforms

OBJECT	MOVE	MIRROR	GEOMETRY	ROTATE	SPIN	ORIGIN (5)	NOTES
segments	X	X	X	X		box	
cline	X	X	X	X		box	
line	X	X	X	X		box	
symbol	X	X		X		xy	
shape	X	X	X	X		box	
text	X	X	X	X		xy	

©2023 All Rights Reserved.

Table 5-1 Supported Transforms, *continued*

OBJECT	MOVE	MIRROR	GEOMETRY	ROTATE	SPIN	ORIGIN (5)	NOTES
pin	X			X		xy	3,4
via	X	X	X	X		xy	
rat_t	X			X		xy	
group	X	X	X	X		xy	7

Notes

1. If object is not listed, then it is not supported.
2. If object has attached text, it also has the transformation applied.
3. Mirror occurs within the same class. See mirror rules.
4. Symbol is exploded and *refresh_symbol* does not maintain transformation.
5. For Pins on a board to be transformed, the UNFIXED_PINS either must be present on the drawing or on the symbol owning the pin.
6. *ORIGIN* column shows what rotate/mirror uses when operating on a single object without the origin option. For box, the *dbid* does not have an origin and it uses the center of its bounding box (dbid->bBox). For an *xy* object that has an origin (dbid->xy), it rotates about the origin. For further discussion, see the note 9 on angles.
7. This API rejects objects whose owner is a symbol definition
8. The only groups that support a transform are user and module group types.
9. If mirror is t then we mirror in x-direction AND across subclasses. For example, if object is on ETCH/TOP it will be mirrored both in x and to layer ETCH/BOTTOM. If mirror is `GEOMETRY only a x-direction is done and the object remains on its layer.
10. Rotation (angle option) works as follows:
    - Positive angle results in a counter-clockwise rotation.
    - If just angle is provided, then the object is rotated about its origin point. If the *dbid* has no origin, then the center of its bounding box is used. If a list of *dbids* is provided, then the rotation always occurs about the center of the object set.
    - You can provide a rotation origin.

      (?origin *l_rotatePoint*).

©2023 All Rights Reserved.

This point is then used as the rotation point.

Cautions

- More objects may be added in the future. For example, voids.
- The return list may be changed to show the actual set of objects that were transformed.
- Spin (rotate a list of objects about each of their centers) is not supported. Use `axlTransformObject` for each object in the list.
- If you pass a list containing a symbol and pins of the symbol, you get unexpected results.
- If transforming multiple objects, enclose this operation in an `axlDBCloak` call.
- If transforming a segment, it will have a new owning path `dbid`.

Arguments

lo_dbid/o_dbid	Single *dbid* or a list of *dbids*.
l_deltaPoint	Move distance.
mirror	Mirror object (see table)
f_angle	Rotation angle.
l_rotatePoint	Rotation point.
allOrNone	If `t` and a group of objects, transform must succeed on all objects, or fail.

Value Returned

lo_dbid	List of transformed objects.
`nil`	Failure due to one of the following:

- An object can't be transformed (for example, a net)
- An object is fixed or a pin does not have an `UNFIX_PINS` property.
- Illegal option types used.
- Transformed object is outside of the database extents.

©2023 All Rights Reserved.

Tip

For better performance when transforming a group of objects, call this function with the object group instead of passing each `dbid` individually.

See Also

axlDBCloak, axlCopyObject

Examples

`dbid` represents one database objects.

`ldbid` represents a list of database objects.

Example 1

```
axlTransformObject(ldbid, ?move '(100.0 0.0))
```

Moves a set of objects `100` database units vertically.

Example 2

```
axlTransformObject(dbid ?angle 45)
```

Rotates an object about its origin `45` degrees.

Example 3

```
axlTransformObject(dbid ?angle 45 ?origin 100:100)
```

Rotates an object about a rotation point.

©2023 All Rights Reserved.

axlUnfixFillet

```
axlUnfixFillet(
     o_dbid
     ) ⇒ t/nil
```

Description

Removes fixed status on a fillet or taper object.

Arguments

o_dbid	A fillet shape dbid.

Value Returned

`t`	if the fillet is successfully marked as unfixed
`nil`	if fail

See Also

axlFixFillet

©2023 All Rights Reserved.

axlZoneDelete

```
axlZoneDelete(
     t_zone/o_dbidZone
     ) -> t/nil
```

Description

Deletes a zone and its outline and associated shapes.

If symbols are placed on the surface layers of the zone, the zone is not deleted.

Arguments

t_zone	Zone name
o_dbidZone	Dbid of zone

Value Returned

`t`	If successful
`nil`	If failed

See Also

axlZoneCreate

Examples

- Delete a zone by name

```
result = axlZoneDelete("ZONE_1")
```

- Delete a zone by dbid

```
zone = axlZoneAccess('name "ZONE_1")
when(zone axlZoneDelete(zone))
```


©2023 All Rights Reserved.

axlZoneSet

```
axlZoneSet(
     t_name/o_dbidZone
     s_option
     g_argument
     ...
     )
     -> t/nil
```

Description

Modifies characteristics of a zone. More than one set of option/arguments can be provided. They are:

'name t_newName	Rename a zone
'notes t_notes	Add or update the note if *t_notes* is `nil` deletes the note
'stackup t_stackup	Updates the stackup associated with zone stackup must currently exist and is rejected if surface symbols placed in the zone
'room t_roomName	Assign room name to zone. Room with same name must not exist in the design. Creates a room shape for BOTH_ROOMS. If *t_roomName* is `nil` deletes room name.
'constraint t_constraintName	Assign constraint region. Region must already exist in design and creates a shape on subclass "ALL". If *t_constraintName* is `nil` deletes constraint area.

Arguments

`t_name`	Name of zone
`o_dbidOutline`	Outline (shape) on class==RIGID_FLEX and subclass==RIGFLEX_ZONE_OUTLINE

Value Returned

`t`	If successful

©2023 All Rights Reserved.

`nil`	If failed

See Also

axlZoneCreate, axlXSectionCreate

Examples

Setup zone including rename; associating a stackup and room

```
ret = axlZoneCreate("ZONE_1" 'stackup "FLEX_1" 'room "ROOM_1")
```


©2023 All Rights Reserved.

Padstack Access Functions

This section lists padstack access functions.

axlDBCreatePadStack

```
axlDBCreatePadStack(
     t_name
     r_drill
     l_pad
     [g_nocheck]
     )
     ⇒ l_result/nil
```

Description

Adds a padstack *t_name*, using drill hole *r_drill* and pad definition *l_pad*.

Defstructs used to create padstack

Drill *(r_drill)* use `make_axlPadStackDrill`. Elements are:

`usage`	(string) padstack usage. See axlPadstackUsageTypes(). If this parameter is not provided, code determines type based on padstack characteristics.
`fixed`	*(t/nil)* internal fixed flag
`spanLockCount`	`(t/nil)` Default value is `nil`. If `t`, padstack does not expand or contract if layers are added or deleted. Default it expands/contracts.
`uvia`	*(t/nil)* if padstack is of type bbvia set as sub-type micro-via. Superseded by usage type.
`keepout`	*(t/nil)*. Obsolete for 17.0 and above. Use new 'KEEPOUT pad layer type
`pluralVia`	*(t/nil)*. Create padstack as a plural via (multi-net). Only through hole padstacks can have this setting.
holeType	(symbol) the hole type. Allowed symbols are 'CIRCLE_DRILL, 'SQUARE_DRILL, 'OVAL_SLOT, 'RECTANGLE_SLOT,'SQUARE_HOLE,'CIRCLE_HOLE. Defaults to CIRCLE_DRILL if drill diameter is provided.

©2023 All Rights Reserved.

plating	(symbol) plate status of drill hole Symbols are: 'PLATED, 'NON_PLATED or nil
drillDiameter	(float) drill hole finished diameter.
drillToolSize	(string) Drill tool size, which is used as an identifier. Default is blank.
slotSize	((f_width f_height)) size of slot hole. Use this instead of drillDiameter for SLOT types. The f_width or "Y size" is the drill size. The f_height or "X size" or drill travel.
holeTolerance	((f_pos f_neg)) +/- hole tolerance When a slot defines the X tolerance or route tolerance
holeToleranceY	((f_pos f_neg)) +/- hole tolerance Applies only to slots and defines the drill size tolerance (Y tolerance).
offset	((f_x f_y)) drill hole offset
multiDrillData	list for multiple drill data which is: ((x_num_rows nx_um_columns f_clearance_x [f_clearance_y ["staggered"]])) data type is (int int float [float])
drillNonStandard	(symbol) non-standard drill hole. Supported symbols are: 'LASER_DRILL, 'PLASMA_DRILL, 'PUNCH_DRILL, 'PHOTO_DRILL, 'COND_INK_DRILL, 'WET_DRY_DRILL, 'OTHER_DRILL.

©2023 All Rights Reserved.

`figure`	(symbol) the drill figure. Allowed symbols are NULL, CIRCLE,SQUARE, HEXAGON, HEXAGON_X, HEXAGON_Y, OCTAGON, CROSS, DIAMOND, TRIANGLE, OBLONG_X, OBLONG_Y, RECTANGLE. Note nil is treated as NULL.
`figureSize`	((f_width f_height)) size of drill figure
`drillChar`	(string) drill characters. Maximum 3 characters.
`holeCounterType`	(string) Counter hole type: "bore", "sink" or nil
`holeCounterAngle`	(integer) Applies to Counter sink and indicates an angle between 1 and 90 degrees.
`holeCounterDiameter`	(float) Counter hole diameter in design units
`holeCounterDepth`	(float) Applies to Counter bore and indicates depth of the bore. Accuracy is maintained at a higher level than the current design.
`holeCounterTolerance`	((f_pos f_neg)) +/- counter hole tolerance.
`backdrillDiameter`	(float) diameter in design units of backdrill finished hole
`backdrillFigureName`	(symbol) the drill figure (see figure for allowed types)
`backdrillFigureChar`	(string) backdrill characters (3 max)
`backdrillFigureWidth`	(float) width of backdrill figure in design units
`backdrillFigureHeight`	(float) height of backdrill figure in design units

Pad *`(l_pad)`* structure (up to 4 for each layer indicated by attribute type)

`layer`	(string) etch layer name (for example, "TOP") or "DEFAULT_INTERNAL" if you want one pad layer to map to all internal layers between the top and bottom of the padstack.
`type`	(symbol) pad type. Allowed symbols are: KEEPOUT, ANTIPAD, THERMAL or REGULAR. nil is treated as REGULAR.

©2023 All Rights Reserved.

figure	(symbol) the pad figure For allowed symbols, see axlPadFigureTypes API. If NULL the figureSize is checked and automatically assigns a figure type. If you assign a type the figureSize must match that type. For example, a SQUARE must have both width and height of the same value. For shape symbol use the name of the ssm (minus extension and path) to figure. For example, if you have a shape symbol called "`myshape`" then it would be `'?figure "myshape"'`. For an Anti-pad shape (fsm) assign the symbol 'FLASH and assign the fsm file (minus extension and path) to the flash name. For example, symbol "myflash" would be: `'?figure 'FLASH ?flash "myflash"'` For either a shape or flash, the symbol must be located through PADPATH. Also the *?figureSize* attribute must be the extents of the symbol or larger.
flash	(string) the pad aperture flash name. Reference a flash shape symbol name or nil for no flash (fsm file).
figureSize	((f_width f_height)) height and width of the figure. For a circle, you only need to assign diameter to either height/width, the other can be 0.
offset	((f_x f_y)) offset from the padstack origin
sides	Octagon pad only: Number of sides. Ranges between 6 and 64 as an even integer.
inside	Donut pad only: inside dimension as a floating point user unit
radius	ROUNDED_RECTANGLE and CHAMFERED_RECTANGLE pad only, corner radius as a floating point user unit.

©2023 All Rights Reserved.

corners	ROUNDED_RECTANGLE and CHAMFERED_RECTANGLE pad only, a dash separated string indicating corners chamfered: UR - upper right UL - upper left LR - lower right LL - lower left *nil* if pad type does not support Example: `"UR-LR"` means chamfer Upper Right and Lower Left corners.
koAllowed	KEEPOUT_AREA pads only. A dash-separated (upper-case) string, indicating objects which are allowed within the keepout area. Objects allowed are: VIAS CLINES SHAPES PINS Example: `?koAllowed "VIAS-CLINES-PINS"` means vias, clines, and pins are allowed within the keepout.

PROGRAMMING NOTES:

- N_SIDED_POLY – figureSize uses the smaller of width and height and this maps to diameter. Requires sides and if not present pad is turned into a circle. Sides must be an even number between 6 and 64. If sides is 0 a CIRCLE pad is created.
- ROUNDED_RECTANGLE / CHAMFERED_RECTANGLE – Requires radius and corners string. Radius cannot be larger than half the smaller of height or width. If radius is 0 or corners string does not match any corners then a RECTANGLE pad is created.
- DONUT – figureSize uses the smaller of width and height and this maps to outside diameter. Requires an inside diameter that must be smaller then the outside diameter. If inside diameter is zero then a CIRCLE pad is created
- To create an adjacent layer route keep-out pad, use the following options for make_axlPadStackPad
  - ?layer 'adjacent

©2023 All Rights Reserved.

- ?type 'KEEPOUT

- To create Coverlay pad layers
  - use strings for ?layer "COVERLAY_TOP" or "COVERLAY_BOTTOM"
  - ?type is ignored
- To create backdrill pad layers use:
  - ?layer 'backdrillStart
    - ?type "REGULAR" – larger pad for drill start layer (positive)
    - ?type "ANTI" – larger pad for drill start layer (negative layers)
  - ?layer 'backdrillClearance
    - ?type "ANTI" – pad size for internal backdrill layers for negative layers
    - ?type "KEEPOUT" – generate a KEEPOUT for positive layers for backdrill layers.
  - ?layer 'backdrillSoldermask – soldermask pad to substitute for drill
- Shapes and flash assignment symbol rules:
  - 'REGULAR – shape symbols (flash symbol name can be set for legacy Gerber support)
  - 'THERMAL – flash symbols
  - 'ANTIPAD - shape symbol (flash symbol name can be set for legacy Gerber support)
  - 'KEEPOUT - shape symbol
  - Mask layers - either flash or shape symbols

  A shape symbol can contain one shape with NO voids.

  A flash symbol supports multiple shapes with voids.
- User mask layer support requires a call to axlPadUserMaskLayers with the 'create option to insure a user mask layer exists in the design. If you know that the user mask layer already exists, you do not need to make the call.
- Backdrill data can be seeded by the global design parameters. Padstacks with their backdrill data obtained this way show these values but they are not saved to the disk padstack file (.pad).

©2023 All Rights Reserved.

Arguments

t_name	Padstack name.
r_drill	Drill hole data for the padstack. **Note:** As with all SKILL defstructs, use the constructor function, `make_axlPadStackPad`, to create instances of `axlPadStackDrill`. See the example.
l_pad	Pad definition data for the padstack. **Note:** As with all SKILL defstructs, use the constructor function `make_axlPadStackPad` to create instances of `axlPadStackPad`. See the example.
g_nocheck	Optional. `t` disables checks of the padstack definition. `nil` executes the following checks of the padstack definition: - Contiguous pad definitions - Anti-pad / thermal-relief pad definitions - Existence of two pads with a drilled hole - A drilled hole with the existence of two pads

Value Returned

l_result	*dbid* of the padstack created.
`nil`	Nothing is created.

See Also

axlPadstackEdit, axlLoadPadstack, axlDBCopyPadstack, axlPadstackToDisk, axlDBGetPad, axlPadUserMaskLayers, axlPadFigureTypes, axlPadstackUsageTypes, axlPadDbidDoc

Examples

- Surface Mount Padstack example

  Adds a surface mount padstack having a 25 by 60 rectangular pad.

```
pad_list = cons(make_axlPadStackPad(?layer "TOP", ?type 'REGULAR,?figure
'RECTANGLE, ?figureSize 25:60) nil)
ps_id = axlDBCreatePadStack("smt_pad", nil, pad_list t)
```

- Additional examples in:

©2023 All Rights Reserved.

```
<cdsroot>/share/pcb/examples/skill/dbcreate/pad.il
```


©2023 All Rights Reserved.

axlPadFigureTypes

```
axlPadFigureTypes(

     ) => lt_names
```

Description

Returns list of strings of supported pad figure types.Not all pad types and layers may support a figure type. This is a documentation support function.

Arguments

None

Value Returned

lt_names	List of permitted pad figure types

Examples

```
axlPadFigureTypes()
```


©2023 All Rights Reserved.

axlPadstackEdit

```
axlPadstackEdit(
     nil
     nil
     )
     ==> l_attributes
```

```
axlPadstackEdit(
     o_dbidPadstack/t_Padstack
     s_name
     g_value
     )
     ==> t/nil
```

```
axlPadstackEdit(
     o_dbidPadstack/t_Padstack
     [[s_name g_value] .... ]
     )
     ==> t/nil
```

Description

Inquire and set display options. Edits global settings of an existing padstack.

This edits the padstack definition, this means that any changes made applies to all instances of the padstacks (pins and vias) in the design.

Supports the following modes:

- If first two arguments are `nil`, command returns a list of all editable attributes.
- If padstack, attribute, and new value are provided, changes one attribute of padstack.
- If padstack, and a list of attributes with new values are provided change all the items specified in the padstack. This is the most efficient method for changing multiple items on a single padstack.

Tip

Order is important, so if you are changing a CIRCULAR drill to a slot then you must provide the holeType followed by drillSizeWidth and drillSizeHeight.

Tip

For best performance if changing multiple items in a single padstack use the list mode to change all items in one call.

©2023 All Rights Reserved.

Currently only global padstack settings are supported. Editing pad layer characteristics in not allowed. Certain changes set DRC out of date and dynamic shapes out of date. Attributes currently supported (all Equivalent items are field names in pad_designer):

©2023 All Rights Reserved.

Table 5-2 Supported Controls

Name	Value	Description	Equivalent	Side Effects

usage	symbol or string with possible values as:
	Types, the call axlPadstackUsageTypes() returns available usage types:
	`'Smd`
	`'Through`
	`'Through_pin`
	`'Surface_pin`
	`'Bbvia`
	`'Through_via`
	`'uvia`
	`'Bond_finger`
	`'Die_pad`
	`'Fiducial`
	`'Mechanical_hole`
	`'Mounting_hole`
	`'Slot`
		Changes classification of padstacks. In some cases the use of the padstack may override the actual padstack usage type.
		Note: `Smd` and `Surface_pin` are identical but future releases will check that `Surface_pin` is only used for pins. Similarly, `Through`, `Through_via` and `Through_pin` are the same but future releases will support a check.
		Transition rules (types can be switched among themselves):
		Single layer: Smd, Surface_pin, Die_pad, Bond_finger, Fiducial
		Multi layer: Through, Through_pin, Through_via, Bbvia, uvia, Mechanical_hole, Mounting_hole, Slot
		Note: Future releases may tighten the transition rules.
			Padstack Usage type or `'usage` attribute in the padstack dbid	DRC is out of date and dynamic shapes are disabled

©2023 All Rights Reserved.

Table 5-2 Supported Controls, *continued*

Name	Value	Description	Equivalent	Side Effects
drillDiameter	dbrep	Changes the drill diameter. Value must be a positive number and holeType must not be a slot. For multi-drill applies to all drills.	Drill diameter field	DRC is out of date and dynamic shapes are disabled
drillSizeWidth	dbrep	Changes the slot size width (x direction). Value must be a positive number and holeType must be a slot type. Usually done in association with drillSizeHeight.	Slot size X	DRC is out of date and dynamic shapes are disabled.
drillSizeHeight	dbrep	Changes the slot size width (y direction). Value must be a positive number and holeType must be a slot type. Usually done in association with drillSizeWidth.	Slot size Y	DRC is out of date and dynamic shapes are disabled.
drillToolSize	string	Sets the Drill tool size name. Not applicable if padstack does not have a drill.	Drill tool size	None

©2023 All Rights Reserved.

Table 5-2 Supported Controls, *continued*

Name	Value	Description	Equivalent	Side Effects
holeType	string	One of `"CIRCLE_DRILL"`, `"SQUARE_DRILL"`, `"OVAL_SLOT"` or `"RECTANGLE_SLOT"`. Changes hole type of padstack. If changing fundamental types: ■ slot to drill; drillDiameter inherits drillSizeWidth. ■ drill to slot; both drillSizeWidth and drillSizeHeight inherit drillDiameter For slots drillFigureName takes on figure for slot type selected and its width and height are the same as the slot width and height.	Hole type	DRC is out of date and dynamic shapes are disabled.
drillNonStandard	string	Changes type of non-standard drill. Hole type must be a circular drill. Types are `"LASER_DRILL"`, `"PLASMA_DRILL"`, `"PUNCH_DRILL"`, `"PHOTO_DRILL"`, `"COND_INK_DRILL"`, `"WET-DRY_DRILL"`, and `"OTHER_DRILL"`. Use `nil` if you want to unset this field.	Non-standard drill	None
drillOffset	point/dbrep	Changes the drill offset. Must be a xy point or a single dbrep, which applies to both, x and y.	Offset X and Y	DRC is out of date and dynamic shapes are disabled.

©2023 All Rights Reserved.

Table 5-2 Supported Controls, *continued*

Name	Value	Description	Equivalent	Side Effects
holeTolerance	point/dbrep	Changes the hole tolerance. Point values are taken to be a list of (+tolerance -tolerance) or a single dbrep which applies to both + and -. Both must be a positive number.	Tolerance + and -	None
holeToleranceY	point/dbrep	Changes the slot Y tolerance. Point values are taken to be a list of (+tolerance -tolerance) or a single dbrep which applies to both + and -. Both must be a positive number.	Y Tolerance + and - for slots	None
plating	string	Sets the plating type, must be one of `"NON_PLATED"`, `"OPTIONAL"`, or `"PLATED"`.	Plating	None
pluralVia	t/nil	Sets padstack to have a plural via	Plural Via	Can only be set for through hole padstacks. Padstack cannot be in use in the design
drillChar	string	Sets the drill characters. A maximum string of 3 is supported. Longer strings are truncated. Use a `nil` to remove the string.	Characters	None

©2023 All Rights Reserved.

Table 5-2 Supported Controls, *continued*

Name	Value	Description	Equivalent	Side Effects
drillFigureName	string	Sets the drill figure type. Not supported for slots. Value must be a string that matches one of the drop-down items in the pad_designer "Figure" field.	Figure	None
drillFigureHeight	dbrep	Changes the figure height, value must be a positive number. Option not available for slots. Used in conjunction with drillFigureWidth.	Height (under Drill/ Slot symbol)	None
drillFigureWidth	dbrep	Changes the figure width, value must be a positive number. This is not available for slots. Used in conjunction with drillFigureHeight.	Width (under Drill/Slot symbol)	None
backdrillDiameter	float	Changes the backdrill diameter. Value must be a positive number and holeType must be a regular hole.	Secondary Drill tab	None
backdrillFigureChar	string	Sets the drill characters. A maximum string of 3 is supported. Longer strings are truncated. Use a `nil` to remove the string.	Secondary Drill tab	None
backdrillFigureName	string	Sets the backdrill figure type. Value must be a string that matches one of the drop-down items in the pad_designer "Figure" field.	Secondary Drill tab	None

©2023 All Rights Reserved.

Table 5-2 Supported Controls, *continued*

Name	Value	Description	Equivalent	Side Effects
backdrillFigureHeight	dbrep	Changes the backdrill figure height, value must be a positive number. Used in conjunction with backdrillFigureWidth.	Secondary Drill tab	None
backdrillFigureWidth	dbrep	Changes the backdrill figure width, value must be a positive number. Used in conjunction with backdrillFigureHeight.	Secondary Drill tab	None
spanLockCount	t/nil	Prevents non-through hole padstacks from expanding (or contracting) when layers are added (or deleted). Default is for these padstacks to maintain their original start/stop layers.	Lock layer span	padstacks with this options may create disconnects when new layers are added
uvia	t/nil	Sets the type of via to bbvia (nil) or micro via (t). Padstack must be a bbvia	This is kept for backwards compatibility. Use the `'type` option.	DRC is out of date and dynamic shapes are disabled.
keepout	nil	Obsolete in 17.0. Use new route keepout pad layer type.		none

©2023 All Rights Reserved.

Arguments

o_dbidPadstack	dbid of a padstack (note VIA and PIN dbids are not supported)
t_Padstack	Name of padstack
s_name	Symbol name of attribute to change
g_value	New value
[[s_name g_value] ..]	list of name/value pairs

Value Returned

- `ls_names` - If name is nil then returns a list of all controls.
- `t/nil` - if t successful in updating padstack, nil an error

Examples

Finds a padstack using the ashOne share-ware SKILL. Note that selection will return a pin or via and you must get the padstack from the definition attribute.

```
p = ashOne()
padstack = p->definiton
```

- Set drill characters

```
ret = axlPadstackEdit(padstack 'drillChar "abc")
```

or its equivalent

```
ret = axlPadstackEdit(padstack '((drillChar "abc")))
```

- Set tolerance

```
ret = axlPadstackEdit(padstack 'holeTolerance '(1.2 1.3))
```

- Set tolerance same for + and -

```
ret = axlPadstackEdit(padstack 'holeTolerance 1.5)
```

- Set drill symbol data

```
data = '((drillFigureName "RECTANGLE") (drillFigureHeight 20)
(drillFigureWidth 10) (drillChar A))
ret = axlPadstackEdit(padstack data)
```

- Get list of all editable padstack parameters

```
lst = axlPadstackEdit(nil nil)
```


©2023 All Rights Reserved.

See Also

axlDBCreatePadStack, axlLoadPadstack, axlDBCopyPadstack, axlReplacePadstack

©2023 All Rights Reserved.

axlPadstackSetType

```
axlPadstackSetType(
     o_padstack/t_padstack
     g_uviaBbvia
     ) -> t/nil


axlPadstackSetType(
     o_padstack/t_padstack
     g_type
     g_value
     ) -> t/nil
```

Description

Changes a padstack type. In its 2 argument mode is the same as:

```
axlPadstackSetType(padstack 'type g_uviaBbvia)
```

Permits changing the type of via.

`'type`

Changes a bbvia padstack to a micro via and vice versa. Uvia types can be managed separately in the constraints system.This has no effect if the padstack is used with Pins. Values are '`bbvia` or '`uvia`.

`'keepout`

Obsolete in 17.2. Create a keepout pad layer type of KEEPOUT.

Marks DRC out-of-date if successful.

©2023 All Rights Reserved.

Arguments

o_padstack	padstack dbid
t_padstack	padstack name
g_type	mode (either 'type or 'keepout)
g_value	appropriate setting (see above)

Value Returned

t	change successful
nil	failed. Not a padstack, padstack not in database, type not recognized or padstack not a bbvia or uvia.

Examples

Change padstack named VIA to a micro via

```
axlPadstackSetType("VIA" 'type 'uvia)
```

See Also

axlDBCreatePadStack, axlPadstackEdit

©2023 All Rights Reserved.

axlPadstackUsageTypes

```
axlPadstackUsageTypes(

     ) => lt_names
```

Description

Returns list of strings of supported padstack usage types. This is a documentation support function.

Arguments

None

Value Returned

- List of strings

Examples

```
axlPadstackUsageTypes()
```


©2023 All Rights Reserved.

axlPadUserMaskLayers

```
axlPadUserMaskLayers(
     ['max]
     ) =>lt_names/x_cnt
```

```
axlPadUserMaskLayers(
     'create
     t_user_mask_layer
     ) =>t/nil
```

Description

Supports following modes:

- if argument returns list of user mask layers in design
- `'max` symbol option reports the maximum number that we support.
- `'create` adds a new user mask layer; requires a name

User mask naming:

If you use _TOP and _BOTTOM suffixes, then you will get mirror support. This means if you mirror a VIA with a user mask defined on xxx_TOP then it will be mirrored to the bottom. See axlDBControl('mirrorUserMask). With the mirror mask option enabled, the opposite side mask is auto-created.

©2023 All Rights Reserved.

Arguments

`'max`	Optional. If provided, returns the maximum number of mask layers supported.
`'create`	Create a new user mask layer, requires `t_user_mask_layer`
`t_user_mask_layer`	Name of user mask layer

Value Returned

`lt_names`	List of user mask names
`x_cnt`	Maximum number permitted to be defined
`t/nil`	In create mode, returns `t` if layer was created or exists, `nil` if failed to create. Failure can be due to:

- exhausted number of user mask layers available
- name is illegal

See Also

axlDBCreatePadStack, axlDBControl

Examples

1. Typical use to get all layers defined

```
axlPadUserMaskLayers()
```

2. Return max that can be defined

```
axlPadUserMaskLayers('max) ->  32
```


©2023 All Rights Reserved.

6

Database Read Functions

AXL-SKILL Database Read Functions

The chapter describes the AXL-SKILL functions that read the Allegro PCB Editor database.

©2023 All Rights Reserved.

axlAltSymbolList

```
axlAltSymbolList(
     t_name/o_dbid
     g_layer
     ) lt_symbols/nil
```

Description

This queries the provided object and returns a list of alternative symbol names.

Arguments

t_name	Component definition or a refdes name
o_dbid	a symbol instance, component instance or compdef dbid
g_layer	‘top, 'bottom, or 'internal

Value Returns

list of alternate symbols for the layer provided

nil, in case of error or if the symbol does not have a alternate symbol set

Examples

```
strings = axlAltSymbolList("U1" top)
```

See Also

axlAltSymbolReplace, axlAltSymbolOK, ALT_SYMBOL property

©2023 All Rights Reserved.

axlAltSymbolOK

```
axlAltSymbolOK(
     t_name/o_dbid
     g_layer
     t_symbol
     l_dbpoint
     ) => t/nil
```

Description

This verifies that symbol is legal for component. Must be in the ALT_SYMBOL list with the correct layer.

Arguments

t_name	may be compdef or a refdes name
o_dbid	a symbol instance, component instance or component definition dbid
g_layer	‘top, 'bottom, or 'internal
t_symbol	name of symbol
l_dbpoint	'(x y) location on the board (optional)

Value Returns

t	is legal
nil	error or symbol is not legal for component

Examples

```
result = axlAltSymbolOK("R1" 'top "res400")
result = axlAltSymbolOK("R1" 'top "res400" '(6400 3300))
```

See Also

axlAltSymbolList, axlAltSymbolReplace

©2023 All Rights Reserved.

axlAltSymbolReplace

```
axlAltSymbolReplace(
     t_name/o_dbid
     t_symbol
     ) => t/nil
```

Description

This replaces a PLACED component with one of its allowed replacements (ALT_SYMBOL). To be successful the following must be true:

- The symbol must already be placed
- The provided symbol must be a legal alternative for the layer where the symbol is placed
- The replacement symbol, any of its padstacks and any shape or flash symbols referenced by the padstacks must be found and loaded into the design, which this API will attempt to do.

Note: Text properties on the symbol instance, and attached text re-positioning are preserved.

Arguments

t_name	may be compdef or a refdes name
o_dbid	a symbol instance, component instance or component definition dbid
t_symbol	name of replacement symbol

Value Returns

t	replacement done successfully
nil	error or cannot replace

Examples

```
result = axlAltSymbolReplace("R1" "res400")
```


©2023 All Rights Reserved.

See Also

axlAltSymbolList, axlAltSymbolOK

©2023 All Rights Reserved.

axlBackdrillGet

```
axlBackdrillGet(
     o_dbidPinOrVia
     ) -> lt_backdrillData/nil
```

```
axlBackdrillGet(
     'status
     ) -> g_status
```

Description

In one mode, it returns status of design's backdrilling. In other mode, when a pin or a via is provided, the command returns the backdrilling result on that pin or via.

Note: Symbols do not support backdrilling.

Arguments

o_dbidPinOrVia	query for backdrill on pin or via
status'	status of backdrill on design

Value Returns

`nil`	error or pin/via is not backdrilled
`g_status`	returns status about design's backdrill
`nil`	error
`'notStarted`	backdrill not performed on design
`'t`	backdrill done and is up to date
`'odd`	backdrill done but changes make it out-of-date
`lt_backdrillData`	A disembodied property list having (all non strings are in user units). Refer to Property List

Table 6-1 Property List

holeSize	finished hole size
backdrillSize	backdrill hole size

©2023 All Rights Reserved.

electricalStub	max electrical stub (from the `BACKDRILL_MAX_PTH_STUB` property on net)
mfgStub	manufacturing stub from backdrill parameter dialog

If pin or via is backdrilled from top, topStartLayer is non-nil and the following attributes are set:

topStartLayer	start layer of drill (string)
topMustCutLayer	must cut layer (string)
topMustNotCutLayer	must NOT cut layer (string)
topDrillDepth	depth of backdrill from topStartLayer to immediately before topMustNotCutLayer
topRemainingStub	remaining stub after backdrill. This is from topRemainingStub to first layer with a connection (min value is manufacturing stub length)

if pin/via is backdrilled from bottom, botStartLayer is non-nil and the following attributes are set.

botStartLayer	start layer of drill (string)
botMustCutLayer	must cut layer (string)
botMustNotCutLayer	must NOT cut layer (string)
botDrillDepth	depth of backdrill from botStartLayer to immediately before botMustNotCutLayer
botRemainingStub	remaining stub after backdrill. This is from botRemainingStub to first layer with a connection (min value is manufacturing stub length)

Examples

- Get status

```
axlViaZLength('status)
```

- Get info on a pin or via

```
; ashOne is a selection utility found at
;   <cdsroot>/pcb/examples/skill/ash-fxf/ashone.il
```


©2023 All Rights Reserved.

```
; select a pin or via

pinvia = ashOne('("PINS" "VIAS"))
backdrill = axlBackdrillGet(pinvia)
```

See Also

axlViaZLength

©2023 All Rights Reserved.

axlDBGetDesign

```
axlDBGetDesign()
     ⇒ o_design/nil
```

Description

Returns the root design *dbid*. Use this *dbid* to get the design properties and to add properties to the design.

Note: You cannot edit the root design object. AXL-SKILL edit commands ignore this *dbid*.

This also allows access to lists of many types of dbid in the design, such as nets, components, and so on.

Tip

If you need to access all dbids if the same type (all nets or all components), it is more efficient to use the appropriate attribute of this dbid than to use the Selection APIs to query all elements.

To flatten attributes in lists, use the "~>" reference. For example, to get names of all nets in the design do:

```
netNames = axlDBGetDesign()->nets~>name
```

Arguments

None.

Value Returned

o_design	Root design *dbid*.
nil	Error occurred.

Example

```
mydesign = axlDBGetDesign()
axlDBAddProp( mydesign, list("board_thickness", 0.350))
```

Gets the root design and sets the *BOARD_THICKNESS* property to 0.350 inches.

To verify the property has the value specified:

©2023 All Rights Reserved.

1. From the Allegro PCB Editor menu, select *Display – Element.*
2. From the Find Filter, select *Drawing Select*.

   The **Show** window appears, listing the current properties attached to the design.

©2023 All Rights Reserved.

axlDBGetDrillPlating

```
axlDBGetDrillPlating
     t_padstackname
     )
     ⇒ "PLATED"/"NON PLATED"/nil
```

Description

Retrieves the plating type of the padstack passed as an argument to this function.

Arguments

t_padstackname	Name of padstack.

Value Returned

"Plated" or "Nonplated"	Drillplating name.
nil	Incorrect padstack name, or other error occurred.

©2023 All Rights Reserved.

axlIsDBIDType

```
axlIsDBIDType(
     g_dbid
     )
     ⇒ t/nil
```

Description

Determines if *g_dbid* is an Allegro PCB Editor database *dbid*. Returns `t` if so and `nil` otherwise.

Arguments

g_dbid	Variable to be checked whether a *dbid* or not.

Value Returned

`t`	*g_dbid* is a true Allegro PCB Editor *dbid*.
`nil`	*g_dbid* is not a true Allegro PCB Editor *dbid*.

Example

Defines a function based on `axlIsDBIDType` to tell whether a symbol is an Allegro PCB Editor *dbid* or not. Then creates an *r_path* (which is not an Allegro PCB Editor *dbid*, because *paths* are only temporary building structures) and uses the *r_path* to create an Allegro PCB Editor line (which is an Allegro PCB Editor *dbid*). Shows whether each is a true *dbid*.

```
defun( isItDBID (testDBID)
    "Print whether testDBID is a true Allegro dbid"
    if( axlIsDBIDType( testDBID)
     then
        println( "This is an Allegro DBID.")
    else
        println( "This is NOT an Allegro DBID.") ) )

mypath = axlPathStart( list(100:500))
axlPathLine( mypath, 0.0, 200:250)
myline = axlDBCreatePath( mypath, "etch/top" nil)
isItDBID(mypath)
isItDBID(caar(myline))
```

The function prints the following:

©2023 All Rights Reserved.

```
"This is NOT an Allegro DBID."
"This is an Allegro DBID."
```


©2023 All Rights Reserved.

axlDBGetAttachedText

```
axlDBGetAttachedText(
     o_dbid
     )
     ⇒ l_dbid/nil
```

Description

Returns the list of *dbids* of text objects attached to the object whose *dbid* is *o_dbid*. If axlDBGetDesign is used to retrieve the dbid, the function returns all text attached to root design.

Arguments

o_dbid	*dbid* of object from which attached text *dbids* are retrieved.

Value Returned

l_dbid	List of the text objects attached to *o_dbid*.
nil	No attached text objects.

Example

```
(defun showText ()
    "Print text of selected objects"
    mypopup = axlUIPopupDefine( nil
        (list (list "Done" 'axlFinishEnterFun)
        (list "Cancel" 'axlCancelEnterFun)))
axlUIPopupSet( mypopup)
axlSetFindFilter( ?enabled list("noall")
    ?onButtons "noall")
axlSetFindFilter( ?enabled list("symbols")
    ?onButtons "symbols")
axlOpenFindFilter()
(while (axlSelect)
    progn(
    alltext =
        axlDBGetAttachedText(car(axlGetSelSet()))
        foreach(thistext alltext
            printf( "Text on this symbol is : '%s'\n",
            thistext->text))))
axlCloseFindFilter())
```

Lets the user pick a symbol, then prints the text attributes of each text object attached to that symbol.

©2023 All Rights Reserved.

Run `showText()` and pick a symbol of device type `"74F74"`, assigned as `refdes "T23"`. The function prints the following:

```
Text on this symbol is : 'T23'
Text on this symbol is : '74F74'
```


©2023 All Rights Reserved.

axlDBGetPad

```
axlDBGetPad(
     o_dbid
     t_layer
     t_type
     )
     ⇒ o_pad/nil
```

Description

For the pin or via specified by *o_dbid*, gets the pad of type *t_type* associated with layer *t_layer*.

Note:

smd pads do not have a default internal layer.

To obtain the adjacent layer keepout pad: `axlDBGetPad(dbid 'adjacent "KEEPOUT")`

©2023 All Rights Reserved.

Arguments

o_dbid — *dbid* of the pin, via, or a padstack definition.

t_layer — String or symbol of a layer desired.

Format for regular layers:

- `"ETCH/TOP"`
- `"TOP"`
- Mask layers must use class of pin or via class:
  - `"PIN/SOLDERMASK_TOP"`
- Coverlay pads specify by `"COVERLAY_TOP"` or `"COVERLAY_BOTTOM"`

Special layers:

- `'internal` - default internal layer (not present on SMD padstacks)
- `'composite` - sum of all the layers (worse case) this option ignores the t_type argument
- `'adjacent` – adjacent layer keepout option
- `'backdrillStart`
  - type="REGULAR" – larger pad for drill start layer (positive)
  - type="ANTI" – larger pad for drill start layer (negative layers)
- `'backdrillClearance`
  - type="ANTI" – pad size for internal backdrill layers for negative layers
  - type="KEEPOUT" – generate a KEEPOUT for positive layers for backdrill layers.
- `'backdrillSoldermask` – soldermask pad to substitute for drill start layer

t_type — Type of pad to retrieve: `"REGULAR"`, `"ANTI"`, `"THERMAL"`, or `"KEEPOUT"`.

©2023 All Rights Reserved.

Value Returned

o_pad	*dbid* of the pad of the type associated with *o_dbid* on the layer specified.
nil	Cannot get the pad *dbid*.

Example

- Lets the user pick any pin or via and shows the figureName attribute of the selected pad.

```
(defun showPad ()
     mypopup=axlUIPopupDefine(nil (list (list "Done" 'axlFinishEnterFun)
     (list "Cancel" 'axlCancelEnterFun)))
    axlUIPopupSet( mypopup)
    axlSetFindFilter( ?enabled list("noall") ?onButtons "noall")
    axlSetFindFilter( ?enabled list("pins" "vias")?onButtons list("pins" "vias"))
           (while  axlSelect()
               progn(mypad = axlDBGetPad(car(axlGetSelSet()) "etch/top" "regular")
                printf( "Pad figure type : %s\n", mypad->figureName)))
```

To fetch default internal regular pad:

```
r = axlDBGetPad(car(axlGetSelSet() 'internal "REGULAR")
```

Run showPad() and pick a pin with a square pad on "etch/top", then a circular pad. The function prints the following:

```
Pad figure type : SQUARE
Pad figure type : CIRCLE
```


©2023 All Rights Reserved.

axlDBGetPropDict

```
axlDBGetPropDict(
     S_filter/nil
     ) -> lt_propNames
```

Description

Returns a list of property definitions in the current design. Several trivial filters are defined:

- `nil` – visible Allegro and user-defined properties
- `allegro` – visible Allegro properties. Product tiering results in filtering of these properties.
- `user` – visible user-defined properties.
- `invisible` – Invisible Allegro properties, these are application internal properties.

Arguments

`S_filter`	Symbol or string requesting a list of property types

Value Returned

`lt_propNames`	List of names (unsorted) or `nil`

Examples

```
axlDBGetPropDict('user) -> list of names
```

See Also

axlDBGetPropDictEntry

©2023 All Rights Reserved.

axlDBGetPropDictEntry

```
axlDBGetPropDictEntry(
     t_name
     )
     ⇒ o_propDictEntry/nil
```

```
axlDBGetPropDictEntry(
     nil
     )
     ==> lt_validObjects
```

Description

Gets the property dictionary entry for the property name given by the string *t_name*. Use axlDBGetPropDictEntry to get the information about a property dictionary entry. If name is `nil`, the command returns a list of legal objects that can be used to create property dictionary entries. This is the *objects* attribute of the *o_propDictEntry* data type. You cannot create a property with the same name as an existing Allegro property.

Arguments

t_name	String specifying the name of the property whose dictionary entry is to be retrieved.

Value Returned

o_propDictEntry	*dbid* of the property dictionary entry for the property whose name is given by *t_name*. If could not get the entry, it returns nil.
lt_validObjects	List of valid objects to associate with a property
`nil`	Could not get the entry.

See Also

axlDBAddProp

Example

The following example gets the `"SIGNAL MODEL"` property, and dumps its attributes.

©2023 All Rights Reserved.

```
myprop = axlDBGetPropDictEntry("SIGNAL_MODEL")
myprop->??
    (write nil useCount 0 units nil
         range nil objType "PropDict"
         name "SIGNAL_MODEL"
         dataType "STRING"
         readOnly t
    )
```


©2023 All Rights Reserved.

axlDBGetProperties

```
axlDBGetProperties(
     o_dbid
     [lt_type]
     )
     ⇒ l_result/nil
```

Description

Gets the properties attached to a specified object. Returns the properties in an assoc list, that is, a list of lists, each of which contains a name and a value. The SKILL `assoc` function can operate using this list.

Arguments

o_dbid	*dbid* of the object from which to get the properties.
lt_type	List of strings qualifying the types of properties to be retrieved from *o_dbid*. `"user"` means retrieve user-defined properties only. `"allegro"` means retrieve Allegro PCB Editor defined properties only. `nil` means retrieve both user and Allegro PCB Editor.

Value Returned

l_result	List of name-value pairs. For each name-value pair: (`car`) is the property name (`cadr`) is the property value, including units.
`nil`	No properties found.

©2023 All Rights Reserved.

Example

The following example selects the component with refdes "U1," gets its properties using the axlDBGetProperties command, and prints the associated property list it returns. The properties are:

- ROOM with value D
- DFA_DEV_CLASS with value DIP
- LEAD_DIAMETER with value 23 mil.

```
 axlClearSelSet()
axlSetFindFilter(?enabled '("noall" "alltypes") ?onButtons "alltypes")
 axlSingleSelectName("component" "U1")
myprops = axlDBGetProperties(car(axlGetSelSet()) '("user" "allegro"))
 print myprops
 ==> ((ROOM "D")
         (DFA_DEV_CLASS "DIP")
                 (LEAD_DIAMETER "23 MIL"))
```


©2023 All Rights Reserved.

axlDBGetDesignUnits

```
axlDBGetDesignUnits()
     ⇒ l_value/nil
```

Description

Returns the design units string, accuracy number, and dbuperuu of the active design.

Arguments

None.

Value Returned

l_value	List containing the design units as a string, the accuracy number as an integer, and dbuperuu as an integer
nil	Failed to return the design units, accuracy number, and dbuperuu of the active design.

Example

1. The design Drawing Parameter form shows *User Units* as `Millimeter` and *Accuracy* as `3`.

   ```
   axlDBGetDesignUnits() ==> ("millimeters" 3 1000)
   ```

2. The design is setup in `Microns` to use DBUperUU of `2000`.

   ```
   axlDBGetDesignUnits() ==> ("microns" 4 2000)
   ```


©2023 All Rights Reserved.

axlDBRefreshId

```
axlDBRefreshId(
     o_dbid/nil
     )
     ⇒ o_dbid/nil
```

Description

Updates the attributes of the object specified by *o_dbid*. Subsequent attribute retrieval requests access the updated information.

Important

This does NOT update the Allegro database. It updates the cached dbid view of objects in SKILL.

Note: Because of performance considerations, refreshes only the object itself. If the object being refreshed has *dbids* in any of its attributes, those *dbids* are not refreshed. For example, a net branch has *children*, a list of paths, tees, vias, pins, and shapes. If another path is added to that list of paths due to connectivity change, `axlDBRefreshId` of the branch does not update the *children*. If you move a via that is a child of the branch, then doing `axlDBRefreshId` of the branch and accessing the via as child of branch may yield incorrect attributes of that child (via in this case).

Arguments

o_dbid	SKILL list of *dbids* of the objects whose attributes are to be refreshed.
`nil`	All ids are refreshed.

Note: Refreshing all ids may cause performance problems if done indiscriminately.

Value Returned

o_dbid	Refreshed *dbid*.
`nil`	Could not refresh.

©2023 All Rights Reserved.

Example

```
axlSetFindFilter( ?enabled
    '("noall" "alltypes"))
axlSingleSelectName("net" "sclkl")
mynet = car(axlGetSelSet())
mybranch = car(mynet->branches)
mychildren = mybranch->children
foreach( thismember mychildren
        if( (thismember->objType == "via")
         then
            axlDeleteObject(thismember)))
axlDBRefreshId(mybranch)
⇒ t
```

Finds *net* `"sclkl"`, walks all members of its first branch, deleting any vias. Then refreshes the branch.

If the refresh was not done, `mybranch` would still report having vias following the operation that deleted its vias.

©2023 All Rights Reserved.

axlDBGetLonelyBranches

```
axlDBGetLonelyBranches()
     ⇒ l_dbid/nil
```

Description

Returns a list of the *standalone branch* `dbids` in the design. A *standalone branch* is a branch not associated with any net.

Arguments

None.

Value Returned

l_dbid	List of standalone branches.
`nil`	No standalone branches found.

Example

```
(axlDBGetLonelyBranches)
⇒(dbid:12051156 dbid:11994768 dbid:12002292 dbid:12000892 dbid:11999396
dbid:11996652 dbid:11996048 dbid:11994476 dbid:11992964 dbid:11991564
dbid:11989672 dbid:11989344 dbid:12072172 dbid:11895392 dbid:11892048
dbid:11888704 dbid:11888744 dbid:11888804 dbid:11888844 dbid:11888884
dbid:12074948 dbid:11888984 dbid:11889064 dbid:11889204 dbid:11889224
dbid:11889856 dbid:11890036 dbid:11890056 dbid:11890236 dbid:11890256
dbid:11886180 dbid:12011360 dbid:11886760 dbid:11887140 dbid:11887916 )
```

Gets list of standalone branch *dbids*.

©2023 All Rights Reserved.

axlDBGetConnect

```
axlDBGetConnect(
     o_dbid
     [t_full]
     )
     ⇒ l_result/nil
```

Description

Finds all the elements, including pads and shapes, that are connected to a given *dbid*. Input can be a PIN, VIA, T, CLINE/CARC or CLINE/CARC SEGMENT, and shapes.

If the second argument is `nil` or is not present:

- For pins, vias or Ts, the function returns a list of connected clines.
- For path (clines) or line/arc (segments) returns list of objects connected to either end.
- For shapes same as t_full=t

If the second argument is set to `t`,:

- For pins, vias and T, the command returns full connectivity which includes clines, shapes, pins, vias or T's.
- For path (clines) or line/arc (segments) return value is same as `t_full=nil`
- For shapes list of connected objects which may be clines, shapes, pins, vias or T's.

Note: You should set *t_fill* to `t`. The `nil` option operates in its mode due to legacy considerations and is used by Allegro Package Designer applications.

If a segment is passed as an argument, the command does not report inter-path connectivity. Thus only the first and last segment of a path report any connectivity. Internal segments of a path always return nil. This is because the Allegro database connectivity model guarantees that internal segments are always connected to their adjacent segments. The list of segments reported in a path (cline) dbid is how the individual segments are connected.

©2023 All Rights Reserved.

Arguments

o_dbid	A *dbid*, path (cline), line/arc (segment), shape, pin, via or T.
t_full	`t`: For full connectivity of pins, vias, or Ts. `nil`: Returns connectivity including any connected SHAPES. Also supports segments.

Value Returned

l_result	List of *dbids* connected to *o_dbid*.
	`If o_dbid is a CLINE or SEGMENT, then`
	`l_result = (list list1 list2)`
	`where list1 = nil or elements connected to the first end`
	`list2 = nil or elements connected to the second end.`
	`For all other objects, returns a list of connections.`

`nil`	Nothing connected to *o_dbid*.

©2023 All Rights Reserved.

axlDBIsBondpad

```
axlDBIsBondpad(
     o_dbid
     )
     ⇒ t/nil
```

Description

Verifies whether or not the given element is a *bondpad*.

A *bondpad* (or *bondfinger*) is a `"via"` with the `BOND_PAD` property.

Arguments

o_dbid	*dbid* of the element to be checked.

Value Returned

`t`	*o_dbid* is a bondpad.
`nil`	*o_dbid* is not a bondpad.

©2023 All Rights Reserved.

axlDBIsBondwire

```
axlDBIsBondwire(
     o_dbid
     )
     ⇒ t/nil
```

Description

Verifies whether or not the given element is a *bonding wire*.

A bonding wire is a 3D wire object connecting a die pad to either a finger, power ring, or another die pad.

Arguments

o_dbid	*dbid* of the element to check.

Value Returned

t	*o_dbid* is a bonding wire.
nil	*o_dbid* is not a bonding wire.

©2023 All Rights Reserved.

axlDBIsFixed

```
axlDBIsFixed(
     o_dbid
     [g_showMessage]
     )
     ⇒ nil or [dbid of 1st element that makes the item fixed]
```

Description

Verifies whether or not the specified database object is fixed. When the FIXED property is present if can either be directly on the object, on a parent (for example, a CLINE is fixed if the NET is fixed) or on a child (for example, a symbol is fixed if its place bounds is fixed).

An object can be fixed by the following:

- Object has the `FIXED` property or its parent or child objects have the `FIXED` property. For example, group symbol.
- The object (parent or child) has a private database fixed attribute.
- Object is Read-only (typically due to partition enabled).
- Object is a symbol with test points and the `FIXED` test point flag is set.
- Object is a pin or via with a test point and `FIXED` test point flag is set.
- Object is a symbol and has one or more children with the `FIXED` property.

Returns the first item found that causes the element to be fixed (could be more then one).

Note: Using axlDBCloak with its `'ignoreFixed` option is recommended.

©2023 All Rights Reserved.

Arguments

o_dbid	*dbid* of the element to check.
g_showMessage	Use `t` to have Allegro PCB Editor display the message if the item is fixed or `nil` to have no message displayed.

Value Returned

dbid	*dbid* of the element causing the object to be fixed.
`nil`	Object is not fixed.

Example

```
p = axlSelectByname("SYMBOL" "U1")
ret = axlDBIsFixed(p)
```

See Also

axlDBIgnoreFixed, axlDBIsReadOnly, axlDBCloak

©2023 All Rights Reserved.

axlDBIsPackagePin

```
axlDBIsPackagePin(
     rd_dbid
     )
     ⇒ t/nil
```

Description

Verifies whether or not the given element is a *package pin*.

A *package pin* is a pin with a component class of `IO`.

Arguments

rd_dbid	*dbid* of element to check.

Value Returned

`t`	*rd_dbid* is a package pin.
`nil`	*rd_dbid* is not a package pin.

©2023 All Rights Reserved.

axlDBViaStack

```
axlDBViaStack(
     o_dbidVia
     )
     ⇒ l_result
```

Description

Returns stacked vias that are located at the location of the provided via. Vias are ordered from top to bottom and includes the provided via.

Notes

Allegro does not store stacked vias but determines it based on a calculation. Future versions of Allegro may store stacked vias in the database or the algorithm may change.

Arguments

o_dbidVia	A via

Value Returned

nil	No stack or not a via
l_dbidVias	List of vias in the stack

©2023 All Rights Reserved.

axlGetModuleInstanceDefinition

```
axlGetModuleInstanceDefinition(
     o_modinst
     )
     ⇒ t_moddef/nil
```

Description

AXL interface to the C function that returns the name of the module definition used to create the module instance.

Arguments

o_modinst	AXL *dbid* of the module instance (the *dbid* returned by `axlDBCreateModuleInstance`.)

Value Returned

t_moddef	String containing the name of the module definition.
`nil`	Could not access the information.

Example

```
axlSetFindFilter(?enabled '("noall" "groups") ?onButtons '("noall" "groups" ))
axlSingleSelectName("GROUP" "inst")
modinst = car(axlGetSelSet())
axlGetModuleInstanceDefinition(modinst)
= "mod"
```

Gets the definition of a module instance named `inst`.

©2023 All Rights Reserved.

axlGetModuleInstanceLocation

```
axlGetModuleInstanceLocation(
     o_modinst
     )
     ⇒ l_loc/nil
```

Description

AXL interface to the C function that gets the current location of the module instance in the design.

Arguments

o_modinst	AXL *dbid* of the module instance (the *dbid* returned by `axlDBCreateModuleInstance`.)

Value Returned

l_loc	List of data describing the location of the module instance. The list syntax is as follows. `list(l_origin, x_rotation [g_mirror])` where ■ `l_origin:` origin of module ■ `x_rotation:` rotation in degress * 1000 ■ `[g_mirror]:` Is a n optional parameter, which is set to `t` when mirrored

Example

Gets the location of a module instance named `inst`.

```
axlSetFindFilter(?enabled '("noall" "groups") ?onButtons '("noall" "groups" ))
axlSingleSelectName("GROUP" "inst")
modinst = car(axlGetSelSet())
axlGetModuleInstanceLocation(modinst)
--> ((500 1500) 0)
```


©2023 All Rights Reserved.

axlGetModuleInstanceLogicMethod

```
axlGetModuleInstanceMethod(
     o_modinst
     )
     ⇒ i_logic/nil
```

Description

AXL interface to the C function that determines the logic method used by the module instance.

Arguments

o_modinst	AXL *dbid* of the module instance (the *dbid* returned by `axlDBCreateModuleInstance`.)

Value Returned

i_logic	Value of the logic method flag for the module instance. Legal values are: `0` - no logic `1` - logic from schematic `2` - logic from module definition
`nil`	Could not access the information.

Example

```
axlSetFindFilter(?enabled '("noall" "groups") ?onButtons '("noall" "groups" ))
axlSingleSelectName("GROUP" "inst")
modinst = car(axlGetSelSet())
axlGetModuleInstanceLogicMethod(modinst)
= 2
```

Gets the logic method of a module instance named `inst`.

©2023 All Rights Reserved.

axlGetModuleInstanceNetExceptions

```
axlGetModuleInstanceNetExceptions(
     o_modinst
     )
     ⇒ l_nets/nil
```

Description

AXL interface to the C function that gets the net exception of the module instance in the design.

Arguments

o_modinst	AXL *dbid* of the module instance (the *dbid* returned by `axlDBCreateModuleInstance`.)

Value Returned

l_nets	List of names of the nets that are treated as exceptions in the module instance.
`nil`	Could not access the information.

Example

```
axlSetFindFilter(?enabled '("noall" "groups") ?onButtons '("noall" "groups" ))
axlSingleSelectName("GROUP" "inst")
modinst = car(axlGetSelSet())
axlGetModuleInstanceNetExceptions(modinst)
= ("GND" "+5")
```

Gets the list of net exceptions of a module instance named `inst`.

©2023 All Rights Reserved.

axlIsDummyNet

```
axlIsDummyNet(
     net_dbid)
     ⇒ t/nil
```

Description

Determines if a given net is a Dummy net. Name of net is an empty string ("").

Arguments

net_dbid	Net database object.

Value Returned

t	*net_dbid* is a Dummy Net.
nil	*net_dbid* is not a Dummy Net.

See Also

axlIsPinUnused

©2023 All Rights Reserved.

axlIsLayerNegative

```
axlIsLayerNegative(
     t_layerName
     )
     ⇒ t/nil
```

Description

Determines whether or not the given plane layer is negative.

Arguments

t_layerName	Name of the conductor layer to check.

Value Returned

`t`	Active layer is negative.
`nil`	Active layer is not negative or is not an `ETCH` layer.

See Also

axlXSectionGet

Examples

Tests if layer named GND is negative

```
axlIsLayerNegative("GND")
```


©2023 All Rights Reserved.

axlIsPinUnused

```
axlIsPinUnused(
     pin_dbid
     )
     ⇒ t/nil
```

Description

Determines if the given pin is unused, indicating that it is on a dummy net.

Arguments

pin_dbid	Pin database object.

Value Returned

`t`	Pin is unused.
`nil`	Pin is used.

See Also

axlIsDummyNet

©2023 All Rights Reserved.

axlIsitFill

```
axlIsitFill(
     t_layer
     )
     ⇒ t/nil
```

Description

Determines if fill shape is allowed for a given class subclass.

Arguments

t_layer	Layer name, for example, `ETCH/TOP`.

Value Returned

`t`	Fill shape is allowed.
`nil`	Fill shape is not allowed.

©2023 All Rights Reserved.

axlOK2Void

```
axlOK2Void(
     t_layer
     )
     ⇒ t/nil
```

Description

Determines if voids are allowed for a given *class/subclass*. Determines if a layer supports voids for shapes.

Arguments

t_layer	Layer name, for example, ETCH/TOP. or just class name ("ETCH")

Value Returned

t	Voids are allowed.
nil	Voids are not allowed.

Example

```
axlOK2Void("ETH/TOP")
```


©2023 All Rights Reserved.

axlDBDynamicShapes

```
axlDBDynamicShapes(
     g_value
     )
     ⇒ x_count
```

Description

Queries and updates dynamic shapes. When *g_value* is `t`, updates all out of date dynamic shapes on the board regardless of the dynamic shape updating setting in the **Drawing Options** dialog. When *g_value* is `nil`, returns a count of out of date shapes.

Arguments

g_value	`t` = update dynamic shapes `nil` = return count of out of date shapes

Value Returned

x_count	Count of out of date shapes. If updating shapes, *x_count* is the number of out of date shapes before the update.

©2023 All Rights Reserved.

axlDBGetShapes

```
axlDBGetShapes(
     t_layer
     )
     ⇒ l_dbid/nil
```

Description

Provides quick access to shapes without access to visibility or find settings.

Arguments

t_layer	Layer name
	`nil` = all layers
	<*class*> = all subclasses of the class
	<*class*>/<*subclass*> = specified layer
shape_islands_rpt	To output the same list as the Shape Islands Report. Optional.

Value Returned

`l_dbid`	List of shapes.
`nil`	Incorrect argument.

Examples:

- Returns all shapes on the design.

```
axlDBGetShapes(nil)
```

- Returns all shapes on the BOUNDARY layer.

```
axlDBGetShapes("BOUNDARY")
```

- Returns all shapes on ETCH GND.

```
axlDBGetShapes("ETCH/GND")
```

- Returns all shapes on ROUTE KEEPOUT.

```
axlDBGetShapes("ROUTE KEEPOUT")
```


©2023 All Rights Reserved.

axlDBTextBlockCompact

```
axlDBTextBlockCompact(
     t/nil
     )
     ⇒ x_unusedBlocks
```

Description

Reports and/or compresses unused database text blocks. If compacting text blocks, it always updates database text to reflect the new text block numbers.

The database, even if new, must have at least one text block.

Note: You must force a *dbid* refresh on any text parameters and text type *dbids* in order for them to reflect the new numbering.

Arguments

`t`	Compact the text blocks.
`nil`	Report the number of text blocks that can be eliminated from the database.

Value Returned

x_unusedBlocks	Count of text blocks that are unused.

Example

```
unused = axlDBTextBlockCompact(nil)
printf("This database has %d unused text blocks\n" unused)
```


©2023 All Rights Reserved.

axlShapeArea

```
axlShapeArea(
     g_mode
     o_shapeId
     )
     ⇒ nil/f_area
```

Description

Area of a shape. Subtracts voids and treats xhatch and unfilled shapes as solid.

Note: If using the axl Polygon APIs, the area of the polygons are already part of the polygon structures.

Arguments

g_mode	Must be nil
o_shapeId	Dbid of a shape, rectangle or void

Value Returned

nil	Not a shape
f_area	Area of shape in square design units

©2023 All Rights Reserved.

axlShapeExistDegasOutOfDate

```
axlShapeExistDegasOutOfDate(
     )
     ⇒ t/nil
```

Description

Checks if any of the nondeferred degassed shapes in the design are out of date.

Value Returned

```
t/nil
```

See Also

axlShapeIsDegasOutOfDate, axlShapeGetDegasOutOfDateCount

©2023 All Rights Reserved.

axlShapeGetDegasOutOfDateCount

```
axlShapeGetDegasOutOfDateCount(
     )
     ⇒ n_count
```

Description

Returns the count of nondeferred degassed shapes that are out of date.

Value Returned

`n_count`

See Also

axlShapeIsDegasOutOfDate, axlShapeExistDegasOutOfDate

©2023 All Rights Reserved.

axlShapeIsDegasOutOfDate

```
axlShapeIsDegasOutOfDate(
     o_shape
     )
     ⇒ t/nil
```

Description

Checks if the specified nondeferred degassed shape is out of date.

Arguments

`o_shape`	dbid of the specified shape.

Value Returned

`t/nil`

See Also

axlShapeUpdateDegas

©2023 All Rights Reserved.

axlShapeIsDegasOutOfDateCheckDisabled

```
axlShapeIsDegasOutOfDateCheckDisabled(
     )
     ⇒ t/nil
```

Description

Returns `t (TRUE)` if out-of-date check for degassed shapes is disabled.

Value Returned

`t/nil`

©2023 All Rights Reserved.

axlStepGet

```
axlStepGet(
     g_operation
     g_mapType
     t_name/o_dbid
     ) -> g_return/nil
```

Description

Obtains STEP mapping data on an object.

STEP Attributes

Attributes with Modify of "Yes" are recognized by axlStepSet.

NAME	TYPE	Modify	DESCRIPTION
objectType	string	No	"step”
offset_x	double	Yes	Mapping offset in X direction (in design units)
offset_y	double	Yes	Mapping offset in Y direction (in design units)
offset_z	double	Yes	Mapping offset in Z direction (in design units)
rotation_x	double	Yes	Rotation in degrees in X direction
rotation_y	double	Yes	Rotation in degrees in Y direction
rotation_z	double	Yes	Rotation in degrees in z direction
color	int	Yes	This is the override color for the step model. A value of 0 indicates, the color(s) are taken from the STEP file but not all STEP models have color. Otherwise this is an index into Allegro's color table (see axlColorGet). This value is ignored if the STEP model has color.
step_name	string	No	Step model (relative path)

©2023 All Rights Reserved.

NAME	TYPE	Modify	DESCRIPTION
type	symbol	No	can be 'primary or 'alt

Arguments

g_operation	nil - fetch mapping data
	'map - return type of mapping (ignores the g_type argument)
g_mapType	should be 'primary or 'alt (a nil is equiv to 'primary)
t_name	may be compdef or a symdef name
o_dbid	a symdef or compdef. For a `.dra` file this should be nil

Value Returned

`nil`	Error or object has no STEP association
`if g_operation=='map`	■ If object has a STEP association return a list of its current mappings.This list will have 'primary and/or 'alt symbols. ■ nil no STEP associated with object
`if g_operation == nil`	■ Returns nil if no STEP associated with object and mapType ■ Otherwise returns a disembodied property list of mapping attributes (see STEP Attributes)

See Also

axlStepSet, axlStepDelete, axlColorGet

Examples

- If a `.dra` design STEP assignment for primary

```
result = axlStepGet(nil 'primary nil)
```

- Get primary assignment in a `.brd` for a symbol definition name

```
result = axlStepGet(nil 'primary "CAP10X16MM-RAD")
```

- Report STEP assignments types for same symdef

```
result = axlStepGet('map nil "CAP10X16MM-RAD")
```


©2023 All Rights Reserved.

- Report STEP assignments types for same component definition

```
result = axlStepGet('map nil "CAP")
```

- Report STEP assignments types for same component definition

```
result = axlStepGet('map nil "CAP")
```

- Report STEP assignments types for same component definition using a dbid of a compdef

```
refdes = axlDBFindByName('refdes "C1")
result = axlStepGet('map nil refdes->compdef)
```

- Report STEP assignments types for same component definition using a dbid of a symdef

```
refdes = axlDBFindByName('refdes "C1")
; make sure refdes is placed
when(refdes->symbol
result = axlStepGet('map nil refdes->symbol->definition))
```


©2023 All Rights Reserved.

axlStepMappedInstance

```
axlStepMappedInstance(
     t_name/o_dbid
     ) -> t/nil
```

Description

This returns if a symbol or a component instance has a STEP association.

Arguments

t_name	Is a refdes
o_dbid	A symbol or component instance

Value Returned

`t`	Has a STEP model
`nil`	Does not have a model (or error)

See Also

axlStepGet

Example

See if refdes C1 has a STEP model

```
result = axlStepMappedInstance("C1")
```


©2023 All Rights Reserved.

axlZoneAccess

```
axlZoneAccess(
     g_option
     g_arg
     ) -> lt_types
```

Description

This provides several miscellaneous access functions for zones:

'name	Find zone by name, requires a string for the zone name. Return is o_zoneDbid.
`point	Given a point as the second argument returns the zone enclosing this point, return is xy.
'trim	Given a zone name or dbid as the second argument trim the zone outline to other zones and the design outline.

Arguments

g_option	A symbol (see above)
g_arg	This argument is depends upon the option

Value Returned

`t`	If successful
`nil`	If failed
`others`	Returns depends upon option (see above)

See Also

axlZoneCreate, axlGeoPointInShape

Examples

- Find zone with name ZONE_1

```
zone = axlZoneAccess('name "ZONE_1")
```


©2023 All Rights Reserved.

- Find zone at a point

```
zone = axlZoneAccess('point 3485:-1295.0)
```

- Trim the zone outline (using first example)

```
result = axlZoneAccess('trim zone)
```


©2023 All Rights Reserved.

7

Allegro PCB Editor Interface Functions

Overview

This chapter describes the AXL/SKILL functions that give access to the Allegro PCB Editor interface. These include display control, cursor setup, and soliciting user input, such as text and mouse picks.

AXL-SKILL Interface Function Examples

This section gives examples of the following:

- Dynamic cursor functions used with the `axlEnter` functions
- `axlCancelEnterFun` and `axlFinishEnterFun` used with the popup functions in a command looping on the `axlEnterPath` command
- `axlHighlightObject` and `axlDehighlightObject`

Dynamic Cursor Examples

You use the AXL-SKILL dynamic cursor functions to build up and display Allegro PCB Editor database objects during interactive commands. Using dynamic cursor shows the effects of a command in use. For example, you can display a symbol and the etch lines connected to it, constantly showing where they would be in the drawing if the user clicked at their current position.

The two examples that follow show how to set up the dynamic cursor:

- A package symbol image with pins connected to other etch, with rubberband lines from its connected pins to the points where they had originally connected
- A package symbol image dynamically rotating enabling you to select an angle of rotation

Both examples use the `axlPath` functions described in Chapter 15, “Database Create Functions,” and the `axlAddSimpleXXXDynamics` functions described in this chapter.

©2023 All Rights Reserved.

Example 1: Dynamic Rubberband

This example loads two circular pads and, the outline of a resistor, and rubberband connections from its pins, one with a "path" rubberband, the other a "directline" rubberband into the dynamic cursor buffer.

```
axlClearDynamics()

; Create cross markers to show rubberband origins:
axlDBCreateLine(list(9150:4450 9050:4550) 0.
                 "board geometry/dimension")
axlDBCreateLine(list(9150:4550 9050:4450) 0.
                 "board geometry/dimension")
axlDBCreateLine(list(8550:4450 8450:4550) 0.
                 "board geometry/dimension")
axlDBCreateLine(list(8550:4550 8450:4450) 0.
                 "board geometry/dimension")

mypath = axlPathStart(list( -350:0)) ; Start circular pad
axlPathArcCenter(mypath, 0., -350:0, nil, -300:0)

; Load the first pad into the dynamic cursor buffer
axlAddSimpleMoveDynamics(0:0 mypath "path" ?ref_point 0:0)

mypath = axlPathStart(list( 350:0)) ; Start circular pad
axlPathArcCenter(mypath, 0., 350:0, nil, 300:0)
; Load the other pad into the dynamic cursor buffer
axlAddSimpleMoveDynamics(0:0 mypath "path" ?ref_point 0:0)
mypath = axlPathStart( ; Start resistor body outline
        list( -200:-100 200:-100 200:100 -200:100 -200:-100))
; Load the resistor body outline in the dynamic cursor buf
axlAddSimpleMoveDynamics(0:0 mypath "path" ?ref_point 0:0)
; Load a "path" rubberband to the first pad
axlAddSimpleRbandDynamics(8500:4500 "path"
                 ?origin 8500:4500 ?var_point -300:0)
; Load a "directline" rubberband to the second pad
axlAddSimpleRbandDynamics(9100:4500 "directline"
    ?origin 9100:4500 ?var_point 300:0)
;
mypoint = axlEnterPoint() ; Ask user for point
```


©2023 All Rights Reserved.

Loads two circular pads, the outline of a resistor, and rubberband connections from its pins (one with a `"path"` rubberband, the other a `"directline"` rubberband) into the dynamic cursor buffer.

The following illustration shows the cursor in a typical position as `axlEnterPoint` waits for selection of a point.

©2023 All Rights Reserved.

Example 2: Dynamic Cursor Rotation

```
axlClearDynamics() ; Clean out any existing cursor data

mypath = axlPathStart(list( -350:0)) ; Start circular pad
axlPathArcCenter(mypath, 0., -350:0, nil, -300:0)

; Load the first pad into the dynamic cursor buffer
axlAddSimpleMoveDynamics(0:0 mypath "path" ?ref_point 0:0)

mypath = axlPathStart(list( 350:0)) ; Start circular pad
axlPathArcCenter(mypath, 0., 350:0, nil, 300:0)

; Load the other pad into the dynamic cursor buffer
axlAddSimpleMoveDynamics(0:0 mypath "path" ?ref_point 0:0)

mypath = axlPathStart( ; Start resistor body outline
    list( -200:-100 200:-100 200:100 -200:100 -200:-100))

; Load the resistor body outline in the dynamic cursor buf
axlAddSimpleMoveDynamics(0:0 mypath "path" ?ref_point 0:0)

; Ask user to pick angle of rotation about (8500:4500):
axlEnterAngle(8500:4500)
```

Loads two circular pads, the outline of a resistor, and rubberband connections from its pins, one with a "path" rubberband, the other a "directline" rubberband into the dynamic cursor buffer.

©2023 All Rights Reserved.

The following illustration shows the dynamically rotating cursor in a typical position as `axlEnterAngle` waits for a user-selected point.

©2023 All Rights Reserved.

Enter Function Example

You use the AXL-SKILL `axlCancelEnterFun` and `axlFinishEnterFun` functions when you create an interactive command that loops on input, providing the option to end the command.

```
(defun axlMyCancel ()
    axlClearDynamics()
    axlCancelEnterFun()
    axlUIPopupSet(nil))

(defun axlMyDone ()
    axlClearDynamics()
    axlFinishEnterFun()
    axlUIPopupSet(nil))

mypopup = axlUIPopupDefine( nil
    (list (list "MyCancel" 'axlMyCancel)
    (list "MyDone" 'axlMyDone)))
axlUIPopupSet( mypopup)
; Clear the dynamic buffer
axlClearDynamics()
; Clear mypath to nil, then loop gathering user picks:
mypath = nil
while( (mypath = axlEnterPath(?lastPath mypath))
    progn(
        axlDBCreatePath(mypath, "etch/top")))
```

The Enter Function example does the following:

1. Defines the functions `axlMyCancel` and `axlMyDone`.
2. Defines a pop-up with those functions as the callbacks for user selections *Cancel* and *Done* from the pop-up.
3. Loops on the function `axlEnterPath` gathering user input to create a multi-segment line on `"etch/top"`.

Selecting *Cancel* or *Done* from the pop-up ends the command.

You gather one user-selected point and extend the database path by that selection each time through the *while* loop. Selecting *Done* from the pop-up terminates the loop. Selecting *Cancel* at any time cancels. Segments added become permanent in the database when the loop ends.

©2023 All Rights Reserved.

axlHighlightObject and axlDehighlightObject Examples

You use the AXL-SKILL `axlHighlightObject` and `axlDehighlightObject` functions to highlight database elements during interactive commands.

Example 1

```
(defun highlightLoop ()
mypopup = axlUIPopupDefine( nil
        (list (list "Done" 'axlFinishEnterFun)
            (list "Cancel" 'axlCancelEnterFun)))
axlUIPopupSet( mypopup)
axlSetFindFilter( ?enabled '("noall" "alltypes" "nameform")
                    ?onButtons "alltypes")
    (while (axlSelect)
        progn(
            axlHighlightObject( axlGetSelSet())
            ; Just a dummy delay to see what happens
            sum = 0
            for( i 1 10000 sum = sum + i)
            axlDehighlightObject( axlGetSelSet())))
```

Example 1 does the following:

1. Defines the function `highlightLoop`.
2. Defines a popup with `axlFinishEnterFun` and `axlCancelEnterFun` as the callbacks for user selections *Done* and *Cancel* from the pop-up.
3. Loops on the function `axlSelect` gathering user selections to highlight.
4. Waits in a simple delay loop, then dehighlights.

Selecting *Cancel* or *Done* from the pop-up ends the command.

Example 2

```
axlDBControl('highlightColor 4)
axlHighlightObject(axlGetSelSet() t)
```

Permanently highlights an object using color `4`.

©2023 All Rights Reserved.

Allegro PCB Editor Interface Functions

This section lists Allegro PCB Editor interface functions.

axlClearDynamics

```
axlClearDynamics(
     )
     ⇒ t
```

Description

Clears the dynamic cursor buffer. Call this function each time before you start setting up rubberband and dynamic cursor graphics.

Arguments

None.

Value Returned

`t`	Always returns `t`.

Example

See dynamic cursor examples in the section AXL-SKILL Interface Function Examples on page 507.

©2023 All Rights Reserved.

axlAddSimpleRbandDynamics

```
axlAddSimpleRbandDynamics(
     l_fixed_point
     t_type
     ?origin        l_origin
     ?var_point     l_var_point
     ?lastPath      l_lastPath
     ?width         f_width
     ?color         g_color
     )
     ⇒ t/nil
```

Description

Loads rubber band dynamics buffer with an element. If dynamics buffer is already loaded, the new element is simply added to the existing buffer. Dynamics buffer is not cleared until axlClearDynamics is called.

Rubber band dynamics means stretching of elements to the cursor from an anchor point called the fixed_point.

Caution

This works in conjunction with the axl<Event> APIs. In particular, no grid snapping, only works when these APIs are called. Do not use this in the axlUIWTimerAdd or with axlTriggerSet callbacks.

Arguments

l_fixed_point	Fixed point of rubber band. Anchor point from which the dynamic rubberband stretches. The rubberband cursor stretches dynamically from *fixed_point* to current position of the cursor, as moved by the user. The next argument, *type*, specifies the shape of the rubberband—part of a path, direct, z-line (a combination of horizontal and vertical), arc, circle, or box.

©2023 All Rights Reserved.

t_type	String specifying type of dynamic rubberband to be drawn. Can be one of the following: `path, directline, horizline, vertline, arc, circle, or box`. `directline`: add a single line to buffer between *fixed_point* and *var_point*. origin and variable point of var_point `horizline`: A single horizontal line. `vertline`: A single vertical line `arc`: Arc between fixed_point and var_point. Radius varies as cursor moves "circle": Circle, fixed_point is center and var_point is initial radius. "box": Add a box, fixed point is one corner and the var_point is the opposite corner. "path": Add two segments whose behavior is controlled by the line lock attributes (axlSetLineLock). "fixedline": Adds a constant line to cursor buffer, fixed_point and var_point are the two endpoints.
l_origin	Cursor origin. Useful only if you plan on rotating the object, this is the center of its rotation. Also on arcs to control tangency. In most cases this should be nil.
l_var_point	Variable point for rubberbanding.
l_lastPath	Previous path structure. Needed to calculate tangent point if rubberbanding starts at the end of an existing path.
`f_width`	Optional database width of the rband. Default is 0.0.
`g_color`	Optional arguments for defining the dynamics' color. Possible choices are: ■ A layer string (i.e. class/subclass) for the layer to be used for deriving the color. ■ 'ratsnestColor - the color used for ratsnest lines will be used. ■ 'activeSubclassColor - the color for the active class/subclass is used. If this changes, the color for this rband also changes.

©2023 All Rights Reserved.

Value Returned

`t`	Successfully added data.
`nil`	No data added.

Example

A file, demo_dynamics.il, in `<cdsroot>/share/pcb/examples/skill` demonstrates the various t_type options.

This example loads two circular pad and, the outline of a resistor, and rubberband connections from its pins, one with a "path" rubberband, the other a "directline" rubberband into the dynamic cursor buffer:

```
axlClearDynamics() ; Clean out any existing cursor data
mypath = axlPathStart(list( -350:0)) ; Start circular pad
axlPathArcCenter(mypath, 0., -350:0, nil, -300:0)
; Load the first pad into the dynamic cursor buffer
axlAddSimpleMoveDynamics(0:0 mypath "path" ?ref_point 0:0)

mypath = axlPathStart(list( 350:0)) ; Start circular pad
axlPathArcCenter(mypath, 0., 350:0, nil, 300:0)

; Load the other pad into the dynamic cursor buffer
axlAddSimpleMoveDynamics(0:0 mypath "path" ?ref_point 0:0)

mypath = axlPathStart( ; Start resistor body outline
                 list( -200:-100 200:-100 200:100 -200:100 -200:-100))

; Loads the resistor body outline in the dynamic cursor buffer
         axlAddSimpleMoveDynamics(0:0 mypath "path" ?ref_point 0:0)
; Ask user to pick angle of rotation about (8500:4500):
         axlEnterAngle(8500:4500)
```

See dynamic cursor examples in the section AXL-SKILL Interface Function Examples on page 507.

See Also

axlEnterPoint, axlEnterEvent

©2023 All Rights Reserved.

axlAddSimpleMoveDynamics

```
axlAddSimpleMoveDynamics(
     l_origin
     r_path
     t_type
     ?ref_point l_ref_point
     ?color g_color
     )
     ⇒ t/nil
```

Description

Loads cursor buffer dynamics buffer with an element. If dynamics buffer is already loaded, the new element is simply added to the existing buffer. Dynamics buffer is not cleared until axlClearDynamics is called.

Cursor buffer dynamics means no stretching of elements. The loaded is attached to the cursor and moves with it.

Arguments

l_origin	Cursor origin. (see axlAddSimpleRbandDynamics)
r_path	Path structure containing display objects.
t_type	String specifying type of path: either `path` or `box`. Note that lines and arcs are represented as path. Circle is a special case of arc where the start, end points are the same.
l_ref_point	Element rotation reference point.
g_color	Optional argument for defining the dynamics' color. Possible choices are: ■ A layer string (class/subclass) for the layer to be used for deriving the color. ■ `'ratsnestColor` - the color used for ratsnest lines will be used. ■ `'activeLayerColor` - the color for the active class/subclass is used. If this changes, the color for this rband also changes.

©2023 All Rights Reserved.

Value Returned

`t`	Returned if the data is successfully added.
`nil`	No data added.

Example

See dynamic cursor examples, Example 1: Dynamic Rubberband and Example 2: Dynamic Cursor Rotation, in the section AXL-SKILL Interface Function Examples on page 507.

©2023 All Rights Reserved.

axlDesignFlip

```
axlDesignFlip(
     g_flip
     ) t/nil
```

Description

Visually flips the design in the 'y' axis. Maintains current xy view.

Note: This command not available if OpenGL is disabled.

Arguments

`t`	flipped on y axis
`nil`	unflip

Value Returned

Old flip state. If t flipped (y) if nil normal top view state

See Also

axlWindowFit

Example

Syntax to implement toggle flipping

```
axlDesignFlip( !axlDesignFlip())
```


©2023 All Rights Reserved.

axlEnterPoint

```
axlEnterPoint(
     ?prompts       l_prompts
     ?points        l_points
     ?gridSnap      g_gridSnap
     )
     ⇒ l_point/nil
```

Description

Prompts for and receives user-selected point. Returns the point data to the calling function.

Arguments

l_prompts	List containing one prompt message to display.
l_points	List of points. Returns one of these as the return value. *l_point's* only use is, if passed a point, to immediately return with the point snapped to the nearest grid.
g_gridSnap	Flag to function: `t` means snap the point according to the current grid.

Value Returned

l_point	List of coordinates, if entered. If selected, this is a list of one point.
`nil`	User did not select a point.

Example

See Example 1 in the section AXL-SKILL Interface Function Examples on page 507.

See Also

axlGetLastEnterPoint, axlEnterEvent

©2023 All Rights Reserved.

axlEnterString

```
axlEnterString(
     ?prompts       l_prompts
     )
     ⇒ t_string/nil
```

Description

Displays a dialog box that requires first entering a string, and then pressing *Return* on the keyboard or clicking *OK* or *Cancel.* Default prompt in the dialog box is `"Enter String."` You can supply a prompt string with the `?prompts` keyword. The function returns the string entered, if any. Otherwise it returns `nil`.

Note: This function is a blocker. Allegro PCB Editor will not respond to any user input until the data requested by the dialog box is provided.

Arguments

l_prompts	List containing one prompt message. Displays only the first string if the list contains more than one string.

Value Returned

`t_string`	String entered.
`nil`	No string entered, dialog box dismissed by clicking *Cancel*, or the command failed.

Example

```
user_name = axlEnterString(
            ?prompts list("Please enter your name:"))
⇒ "user name"
```

Prompts for name and collects the response in *user_name*.

Typing the name, then pressing the *Return* key returns the string entered:

©2023 All Rights Reserved.

axlEnterAngle

```
axlEnterAngle(
     origin
     ?prompts       l_prompts
     ?refPoint      l_refPoint
     ?angle         f_angle
     ?lockAngle     g_lockAngle
     )
     ⇒ f_angle/nil
```

Description

Optionally prompts the user. Returns the angle value entered.

Arguments

origin	Fixed point where two lines making up the angle meet.
l_prompts	List containing one prompt message.
l_refPoint	End point of a line from the *origin* that acts as the fixed line of the angle.
f_angle	Angle value in. If non-`nil`, does not prompt for a user-selected point.
g_lockAngle	Initial lock angle for dynamic rotation.

Value Returned

f_angle	Selected angle expressed in degrees.
`nil`	No angle selected.

Example

See Example 1 in the section AXL-SKILL Interface Function Examples on page 507.

©2023 All Rights Reserved.

axlCancelEnterFun

```
axlCancelEnterFun()
     ⇒ t/nil
```

Description

Terminates the wait for a user-selected point. Waiting function returns no data.

Arguments

None.

Value Returned

`t`	Terminates wait for user-selected point. Cancel succeeds.
`nil`	Fails to terminate wait for user-selected point.

Example

See the Enter Function Example on page 512.

©2023 All Rights Reserved.

axlFinishEnterFun

```
axlFinishEnterFun()
     ⇒ t/nil
```

Description

Terminates the wait for a user-selected point. Waiting function returns no data. For a one-point function (for example, `axlEnterPoint`) behaves the same as `axlCancelEnterFun`.

Arguments

None.

Value Returned

`t`	Terminates wait for a user-selected point.
`nil`	Fails to terminate wait for a user-selected point.

Example

See the Enter Function Example on page 512.

©2023 All Rights Reserved.

axlGetDynamicsSegs

```
axlGetDynamicsSegs(
     l_point1
     l_point2
     r_lastPath/nil
     ) ->
```

Description

Normally used with dynamics to calculate arc tangency of two picks to a current *r_path*. Passed coordinates may be modified to preserve tangency. Depends on the current line lock state that you set or `axlSetLineLock`.

Arguments

point1	First pick before dynamics started.
point2	Second pick, after dynamics completes.
lastPath	Previous path to use for tangency calculations. Can pass `nil` if not applicable.

Value Returned

l_pointList

`nil`

See Also

axlAddSimpleRbandDynamics, axlMakeDynamicsPath, axlSetLineLock

Example

```
q = axlGetDynamicsSegs(10:10 100:100 nil)
                  -> (((10.0 10.0) (100.0 100.0) nil))
```


©2023 All Rights Reserved.

axlGetLineLock

```
axlGetLineLock(
     s_name
     [g_value]
     )
     ==> g_currentValue/ls_names
```

Description

Gets the current settings of the line lock or dynamic control options. Equivalent items is the option control panel for "add" commands. Items currently supported:

- Name: arcEnable
  Value: t/nil
  Description: If t Lock Mode is arc, nil is line.
- Name: lockAngle
  Value: 0, 45, 90
  Description: In degrees where 0 is off (no lock).
- Name: minRadius
  Value: float
  Description: Minimum Radius in user units.
- Name: length45
  Value: float
  Description: Fixed 45 Length value in user units.
- Name: fixed45
  Value: t/nil
  Description: If t Fixed 45 length is enabled.
- Name: lengthRadius
  Value: float
  Description: Fixed radius value in user units.
- Name: fixedRadius
  Value: t/nil
  Description: If t in Fixed Radius mode
- Name: lockTangent
  Value: t/nil
  Description: If t tangent mode is on.

©2023 All Rights Reserved.

Arguments

`s_name`	symbol name of control. `nil` returns all possible names

Value Returned

See above.

`ls_names`, If name is `nil` then returns a list of all controls.

See Also

axlSetLineLock

Example

- Return current lock tangent setting

```
axlGetLineLock('lockTangent)
```

- Get all names supported by this interface

```
listOfNames = axlGetLineLock(nil)
```


©2023 All Rights Reserved.

axlEnterBox

```
axlEnterBox(
     ?prompts       l_prompts
     ?points        l_points
     )
     ⇒ l_box/nil
```

Description

Takes two points that define a box and returns them in *l_box*. Optionally prompts the user, if *l_prompts* contains no more than two strings. If *l_points* is `nil`, prompts for two points. If *l_points* contains one point, prompts only for the second point. If *l_points* contains both points, simply returns them as *l_box*.

Arguments

l_prompts	List that should contain two prompt messages. If list is `nil`, uses default Allegro PCB Editor prompts for soliciting a box. (`"Enter first point of box"` and `"Enter second point of box"`) If list contains two strings, the first string prompts for the first point, and the second string prompts for the second point. If the list has only one string, the string prompts for both the first and the second points.
l_points	List of none, one, or two points. Solicits missing points interactively using the prompts given in *l_prompts* in order.

Value Returned

l_box	List of the lower left and upper right coordinates of the box.
`nil`	Failed to get box data.

©2023 All Rights Reserved.

Example

```
axlDBCreateRectangle(
    axlEnterBox(?prompts
     list("First rectangle point, please..."
         "Second rectangle point, please..."))
            t "etch/top")
⇒ (dbid:12134523 nil)
```

Asks for box input to create a filled rectangle on layer `"etch/top"`.

See Also

axlEnterEvent, axlEnterPoint

©2023 All Rights Reserved.

axlEnterPath

```
axlEnterPath(
     ?prompts       l_prompts
     ?points        l_points
     ?lastPath      r_path
     )
     ⇒ r_path/nil
```

Description

Gets the start point and subsequent points for a path, interactively with optional prompting, or from the optional argument *l_points*. Sets the start point to the first value of *l_points*, if any, and the second point to the second value, if any. If *r_path* is given, connects the dynamic rubberband to its most recent segment. Use `axlEnterPath` recursively to build up the coordinates of a path interactively.

Arguments

l_prompts	List containing one prompt message to display.
l_points	List of none, one, or two coordinates to be used as input to `axlEnterPath`.
r_path	The previously gathered part of the path. Used to calculate the tangent point for the dynamic cursor.

Value Returned

r_path	Path containing segments constructed from the combined points in *l_points* and the interactive input to `axlEnterPath`.
`nil`	Failed to get points.

Example

See the Enter Function Example on page 512.

©2023 All Rights Reserved.

axlHighlightObject

```
axlHighlightObject(
     [lo_dbid]
     [g_permHighlight]
     )
     ⇒ t/nil
```

Description

Highlights the figures whose *dbids* are in *lo_dbid*.

Fewer objects support permanent highlighting than support temporary highlighting.

Note: Setting `axlDebug(t)` enables additional informational messages.

Arguments

od_dbid	List of the *dbids* of figures to be highlighted.
g_permHighlight	Distinguishes temporary highlighting from permanent highlighting using color. `t` - use PERM highlight color `nil` - use TEMP highlight color The default is `nil`.

Value Returned

`t`	Highlighted at least one figure.
`nil`	Highlighted no figures due to invalid *dbids* or objects already being highlighted.

Examples

You can use the AXL-SKILL `axlHighlightObject` and `axlDehighlightObject` functions to highlight database elements during interactive commands.

This example does the following:

a. Defines the function `highlightLoop`.

©2023 All Rights Reserved.

b. Loops on the function axlSelect gathering user selections to highlight.

c. Waits in a simple delay loop, then dehighlights.

You can stop the command at any time by selecting *Cancel* or *Done* from the pop-up.

```
(defun highlightLoop ()
    mypopup = axlUIPopupDefine( nil
        (list (list "Done" 'axlFinishEnterFun)
                (list "Cancel" 'axlCancelEnterFun)))
    axlUIPopupSet( mypopup)
    axlSetFindFilter( ?enabled '("noall" "alltypes" "nameform")
                        ?onButtons "alltypes")
    (while (axlSelect)
        progn(
            axlHighlightObject( axlGetSelSet())
            ; Just a dummy delay to see what happens
                sum = 0
                for( i 1 10000 sum = sum + i)
                axlDehighlightObject( axlGetSelSet())))
```

This example permanently highlights an object using color 4:

```
axlDBControl('highlightColor 4)
axlHighlightObject(axlGetSelSet() t)
```

Also see the axlHighlightObject and axlDehighlightObject Examples on page 513.

©2023 All Rights Reserved.

axlDehighlightObject

```
axlDehighlightObject(
     lo_dbid/g_mode
     [g_permHighlight]
     )
     ⇒ t/nil
```

Description

Use this command to turn off highlighting on an object. Dehighlights the objects whose *dbids* are in *lo_dbid*. If 'all option is used then g_permHighlight is treated as t (true).

Arguments

lo_dbid	List of *dbids* of figures to be dehighlighted.
g_mode	`'all` to dehighlight entire design
	`'nets` dehighlight all nets.
g_permHighlight	Distinguishes temporary highlighting from permanent highlighting using color.
	`t` - use PERM highlight color
	`nil` - use TEMP highlight color (The default value is `nil`.)

Value Returned

`t`	Dehighlighted at least one figure.
`nil`	Failed to dehighlight any figures.

Example

See axlHighlightObject on page 532 for examples.

See Also

axlHighlightObject

©2023 All Rights Reserved.

axlMiniStatusLoad

```
axlMiniStatusLoad (
     s_formHandle
     t_formFile/(t_formName t_contents)
     g_formAction
     [g_StringOption]
     [t_restrict]
     [b_reload]
     )
     ⇒ r_form/nil
```

Description

Loads the Ministatus form with the form file provided in this call. Replaces the current Ministatus form contents. This function is a special case of `axlForms`. See Chapter 11, "Form Interface Functions," for details on how AXL forms work.

When the command is finished, Allegro PCB Editor restores the Ministatus contents to the default values. Once the form is opened, you use normal `axlForm` functions to set or retrieve fields.

You typically use this to write a command requiring user interaction such as "swap component."

Two reserved field names are available:

class -- enumerated list of CLASS layers
subclass -- enumerated list of SUBCLASS layers for the current active class.

If you make use of these fields use support changing the active class and subclass you also get (for free) color swatch support. The Form file fragment shown below can be added to you ministatus form file to get that support. The "subcolor" field is optional. You should adjust the position (FLOC) of the fields to suite your form layout.

Caution

For scripting and performance always use the same t_formfile name for an application.

Note: Using these reserved names also causes axlGetActiveLayer to update when user changes the layer.

```
TEXT "Active Class and Subclass:"
FLOC 1 1
ENDTEXT
```


©2023 All Rights Reserved.

```
FIELD class
FLOC 5 4
ENUMSET 19
OPTIONS prettyprint
POP "class"
ENDFIELD
```

option

```
FIELD subcolor
FLOC 2 7
COLOR 2 1
ENDFIELD
```

```
FIELD subclass
FLOC 5 7
ENUMSET 19
OPTIONS prettyprint ownerdrawn
POP "subclass"
ENDFIELD
```

Arguments

A description of the in-line [(t_formName t_contents)] is contained in the function axlFormCreate.

©2023 All Rights Reserved.

t_restrict	This optional argument is a string that indicates class and subclass restrictions if the form contains "class" and "subclass" popup fields that have not been overridden with calls to axlFormBuildPopup. Possible values are: "NONE" - no restrictions "TEXT" - only layers that allow text "SHAPES" - only layers that allow shapes "RECTS" - only layers that allow rectangles "ETCH" - only etch layers "ETCH_PIN_VIA"- only etch, pin, and via layers "ETCH_NO_WIREBOND"- only non-wirebond etch layers
`b_reload`	If true, form file will not be cached for faster performance. By default, all ministatus options forms are cached as it is expected they will be used repeatedly. A value of true here will prevent this behavior and allow the form to reload from disk.

Value Returned

`r_form`	Upon success, *`r_form`* is returned.
`nil`	Failure due to one of the following: No interactive command is active or the active command is not of the type AXL registered interactive. AXL Forms code encounters an error.

Example

See swap component example:

`<install_dir>/share/pcb/etc/skill/examples/swap`

See Also

axlFormCreate on page 843 for further details.

©2023 All Rights Reserved.

axlMiniStatusClose

```
axlMiniStatusClose(
     lo_dbid
     )-> t
```

Description

This function closes the active Options panel and returns things to the idle/default options panel for the active application mode.

Arguments

None

Value Returned

`t`

Example

axlMiniStatusClose

©2023 All Rights Reserved.

axlDrawObject

```
axlDrawObject(
     lo_dbid
     )
     ⇒ t/nil
```

Description

Processes a list of *dbids*.

Redraws any objects that were erased by `axlEraseObject`.

Arguments

lo_dbid	List of *dbids* or one *dbid*.

Value Returned

`t`	One or more objects drawn.
`nil`	No valid *dbids* or all objects already at desired display state.

©2023 All Rights Reserved.

axlDynamicsObject

```
axlDynamicsObject (
     lo_dbid
     [l_ref_point]
     )
     ⇒ t/nil
```

Description

Adds list of objects to the cursor buffer. These objects are attached to the cursor in xor mode. Origin point establishes cursor position relative to objects in the dynamics buffer.

Note: Adding too many objects to the cursor buffer dramatically affects performance.

Tip

If you load a symbol definition via `axlLoadSymbol` but does not place the symbol, the definition will, at some time, be deleted from the database.

Arguments

lo_dbid	List of AXL *dbids* or single *dbid*.
l_ref_point	Optional origin point (takes cursor position if not provided).

Value Returned

`t`	One or more objects added to the cursor buffer.
`nil`	No objects added to the cursor buffer.

Example

- Adds a symbol to the cursor buffer with the symbol origin as a reference point:

```
axlDynamicsObject(symbol_id, symbol_id->xy)
```

- Add a symbol definition to cursor buffer:

```
axlDynamicsObject(symbol_id->defintion, symbol_id->xy)
```

- Load a symbol and add to cursor buffer to the current cursor location:

```
def = axlLoadSymbol("PACKAGE" "dip14")
when(def axlDynamicsObject(def))
```


©2023 All Rights Reserved.

axlEraseObject

```
axlEraseObject(
     lo_dbid
     )
     ⇒ t/nil
```

Description

Processes a list of *dbids* and erases them. Typically used with `axlDynamicsObject` to erase objects before attaching them to the cursor. Any objects erased are restored to their visibility when calling AXL shell or terminating the SKILL program.

Arguments

lo_dbid	List of *dbids* or one *dbid*.

Value Returned

`t`	One or more objects erased.
`nil`	No valid *dbids* or all objects already at desired display state.

©2023 All Rights Reserved.

axlControlRaise

```
axlControlRaise(
     g_option
     )
     ⇒ t/nil
```

Description

Raises a tab in the control panel to the top. If you use this at the start of an interactive command, you override the environment variable, `control_auto_raise`.

Arguments

g_option	Supported symbols are: `'options`, `'find`, `'visibility`, and `nil`. `nil` returns a list of supported symbols.

Value Returned

`t`	Tab raised to top in control panel.
`nil`	Unknown symbol.

Example

```
axlControlRaise('options)
```

Raises the option panel to the top.

©2023 All Rights Reserved.

axlEnterEvent

```
axlEnterEvent(
     l_eventMask
     t_prompt
     g_snap
     )
     ⇒ r_eventId
```

Description

A lower level event manager than other `axlEnter` functions. Provides a SKILL program with more user event details. See Table 7-2 on page 544 for a list of events with descriptions.

Returns event structure containing the attributes described in Table 7-1 on page 543. Event occurrence controls what attributes are set by all event types, and sets the *`objType`*, event and *`time`* attributes.

Table 7-1 Event Attributes

Attribute Name	Type	Description
`objType`	string	Type of object, in this case *event*
`type`	symbol	Event occurrence
`xy`	point	Location of mouse
`xySnap`	point	Location of mouse snapped to grid.
`command`	int/symbol	Returns the callback item of `axlUIPopupDefine`
`time`	float	time stamp (seconds.milliseconds)

Note: Do not put a default handler in your case statement since the event model will change in future releases.

©2023 All Rights Reserved.

Table 7-2 Events

Event	Description	Attributes/Mask
PICK	User has selected a point (equal to axlEnterPoint)	
PICK_EXTEND	Same as PICK except has extend keyboard modifier.	
PICK_TOGGLE	Same as PICK except has toggle keyboard modifier.	xy, xySnap
DBLPICK	User has double picked at a location.	
DBLPICK_EXTEND	Same as DBLPICK except has extend keyboard modifier.	
DBLPICK_TOGGLE	Same as DBLPICK except has toggle keyboard modifier.	xy, xySnap
MOVE	Mouse is moving. Depending upon the amount of time spent in your callback, the system may sum mouse movements to minimize falling behind in processing mouse events.	
STARTDRAG	User starts a drag operation.	
STARTDRAG_EXTEND	Same as STARTDRAG except has extend keyboard modifier.	
STARTDRAG_TOGGLE	Same as STARTDRAG except has toggle keyboard modifier.	xy, xySnap
STOPDRAG	User terminates the drag operation.	
STOPDRAG_EXTEND	Same as STOPDRAG except has extend keyboard modifier.	
STOPDRAG_TOGGLE	Same as STOPDRAG except has toggle keyboard modifier.	xy, xySnap, command
DONE	User requests the command to complete.	This event cannot be masked.

©2023 All Rights Reserved.

Table 7-2 Events

Event	Description	Attributes/Mask
`CANCEL`	Respond to this event by terminating your SKILL program (don't call any more *axlEnter* functions.)	This event cannot be masked.

Notes

- You will get `PICK` before `DBLPICK` events. To differentiate between a `PICK` and `DBLPICK`, highlight the selected object. Do not output informational messages or perform time consuming processing.
- Never prompt user for a double click. Instead, format prompts for the next expected event.
- Events dispatched from `axlEnterEvent` are scripted by the system if scripts are enabled.
- The *done* and *cancel* callbacks optionally defined in `axlCmdRegister` are called before the `DONE` and `CANCEL` events are returned.
- The `extend` keyboard modifier is obtained by holding the `Shift` key while performing the mouse operation.
- The `toggle` keyboard modifier is obtained by holding the `Control` key while performing the mouse operation.

Programming Hints

- You can program more easily by providing a single mask set for your command and by not attempting to change the mask set after each event.
- When *Snap to Object* right mouse button menus are present and the user selects a snap operation:
  - both the xy and xySnap return the snap result
  - the snap argument is ignored
  - normal pick events function normally
- Use `axlSnapDisableAtRMB` if you do not want to snap the menu items.

©2023 All Rights Reserved.

Arguments

l_eventMask/nil	List of events to expect.
t_prompt/nil	User prompt. If nil, the default prompt is used.
g_snapGrid	If t, grid snapping is enabled while the function is active. Otherwise no grid snapping is allowed. This affects the *xySnap* value that is returned as well as dynamics and the *xy* readout. If nil, *xySnap* is not snapped to the grid and is the same as *xy*.

Value Returned

r_eventId	Event structure containing attributes.

See Also

axlEnterPoint and axlSnapEnableAtRMB

Example

A complete example is contained in: <cdsroot>/share/pcb/examples/skill/axlcore/EnterEvent.il

```
let( (eventMask event, loop)
eventMask = '( PICK DBLPICK )
loop = t
while( loop
event = axlEnterEvent(eventMask, nil t)
case(event->type
('PICK
... )
('DBLPICK
... )
('DONE
; cleanup
loop = nil)
)
)
)
```


©2023 All Rights Reserved.

axlEventSetStartPopup

```
axlEventSetStartPopup(
     [s_callback]
     )
     ⇒ t/nil
```

Description

Sets a SKILL callback function called prior to a popup being displayed on the screen. Allows AXL applications to reset the popup (see `axlUIPOPUPSetsee`), thus providing context sensitive popups support.

The callback function is passed a list structure the same as the return list in `axlEnterEvent`. Use this function with `axlEnterEvent`.

The callback function is removed when an AXL application is finished. Set this at the application start, if needed.

Arguments

s_callback	AXL callback function.
`none`	Unsets the callback function which disables the callback mechanism.

Value Returned

`t`	Set SKILL callback function.
`nil`	Failed to set SKILL callback function.

©2023 All Rights Reserved.

Example

```
(defun startpopupcallback (event)
    ...
    newpopup = get a new popup based on event x,y values
    axlUIPopupSet(newpopup)
)
axlEventSetStartPopup('startpopupcallback)
...

let( (eventMask event, loop)
    eventMask = list( 'PICK 'DBLPICK )
    loop = t
    while( loop
            event = axlEnterEvent(eventMask, nil)
            case(event->type

                ('PICK
                        ... )
                ('DBLPICK
                        ... )
                ('DONE
                        loop = nil)
                ('CANCEL
                        loop = nil)
    )
)

...
axlEventSetStartPopup()
```

Typically used in conjunction with `axlEnterEvent`.

©2023 All Rights Reserved.

axlGetTrapBox

```
axlGetTrapBox(
     l_point
     )
     ⇒ l_window/nil
```

Description

Returns coordinates of the *Find* window.

Arguments

l_point	Listing of the *x* and *y* coordinates

Value Returned

l_window	`((x_l y_l) (x_u y_u))` - List of corner coordinates of the *Find* window. `(x_l y_l)` - List containing *x* and *y* coordinates of the lower left corner. `(x_u y_u)` - List of the *x* and *y* coordinates of the upper right corner.
`nil`	*l_point* is `null` or in an incorrect format.

©2023 All Rights Reserved.

axlRatsnestBlank

```
axlRatsnestBlank(
     rd_net
     )
     ⇒ t/nil
```

Description

Blanks all ratsnest lines in a net.

Arguments

rd_net	*dbid* of a net

Value Returned

t	Ratsnest lines are blanked.
nil	Ratsnest lines are not blanked.

©2023 All Rights Reserved.

axlRatsnestDisplay

```
axlRatsnestDisplay(
     rd_net
     )
     ⇒ t/nil
```

Description

Displays all ratsnest lines in a net.

Arguments

rd_net	*dbid* of a net

Value Returned

t	Ratsnest lines are displayed.
nil	Ratsnest lines are not displayed.

©2023 All Rights Reserved.

axlSetDynamicsMirror

sets mirror option for dynamics

```
axlSetDynamicsMirror(
     g_mirror
     ) ==> g_oldmirror
```

Description

Sets the Dynamics mirroring.

Arguments

`g_mirror`	g_mirror type.Possible Values are: ■ `GEOMETRY:` mirror geometry only (same layer) ■ `nil:` mirror none ■ `t:` mirror

Value Returned

old mirror value

See Also

axlAddSimpleMoveDynamics

Example

```
axlSetDynamicsMirror(t)
```


©2023 All Rights Reserved.

axlSetDynamicsRotation

```
axlSetDynamicsRotation(
     f_angle/nil
     ) ==> f_oldangle
```

Description

Sets the Dynamics rotation. If angle is nil then returns current rotation.

Arguments

`f_angle`	Floating point number

Value Returned

old angle

See Also

axlAddSimpleMoveDynamics

Example

```
axlSetDynamicsRotation(45.0)
```


©2023 All Rights Reserved.

axlShowObjectToFile

```
axlShowObjectToFile(
     lo_dbid
     [t_file_name]
     )
     ⇒ (t_file_name x_width x_line_count)
```

Description

Creates a temporary file with show element information on *dbids* specified in *lo_dbid*.

Arguments

lo_dbid	List of *dbids* or a single *dbid*.
t_file_name	File name to use instead of a temporary file.

Value Returned

List of items describing the file created (*t_file_name x_width x_line_count*):

t_file_name	Name of the temporary file.
x_width	Width, in characters, of the widest text line.
x_line_count	Number of lines in the file.
nil	Could not create file.

©2023 All Rights Reserved.

axlUICmdPopupSet

```
axlUICmdPopupSet(
     r_popup
     )
     ⇒ r_prevPopup
```

Description

Sets up a popup menu with all menu items required throughout the execution of the command. Call during the command's initialization process. Use of this procedure modifies the behavior of `axlUIPopupSet` so that it makes unavailable all popup items not in the defined popup.

Adds a `cmdPopupId` property to AXL user data which restores popup entries whenever the AXL command state is restored. The command popup is cleared when the SKILL command ends.

Arguments

r_popup	Popup handle, obtained by calling `axlUIPopupDefine`. A `nil` value turns off this popup.

Value Returned

r_prevPopup	Popup set previously defined.

Note: This procedure does the same as `axlCmdPopupSet` for non-WXL UI's.

©2023 All Rights Reserved.

axlWindowFit

```
axlWindowFit(
     )
     ⇒ l_bBox
```

Description

Zooms in to (or out of) a design fitting it fully on the window. For the Allegro PCB Editor in layout mode, performs a fit on the outline. For the Allegro PCB Editor symbol mode, performs a fit such that all visible objects occupy maximum window area. Returns the bounding box of the window after the fit has been performed.

Arguments

`none`

Value Returned

`l_bBox`	The bounding box of the window after zooming (in user units).

Note: This is available as the Allegro PCB Editor command *window fit.*

©2023 All Rights Reserved.

axlZoomBbox

```
axlZoomBbox (
     x_window
     ) => bBox
```

Description

x_window: window id or nil to currently active window. nil is the active window and 0 is the primary canvas. Allegro currently only supports one additional canvas so the value 1 indicates that canvas.

Arguments

Returns bounding box (bBox) of window.

Value Returned

bBox	a list of two xy coordinates indicating upper right and lower left. These are in design units.

See Also

axlZoomControl

Examples

- BBox of active window

```
axlZoomBbox(nil)
     => ((100 120) (300 320))
```


©2023 All Rights Reserved.

axlZoomCenter

```
axlZoomCenter (
     x_window
     xy
     )
     -=> t/nil
```

Description

Zoom centers on the provided coordinate. It may adjust the point if centering results in the display bounding extents are outside the design extents.

Tip

If you wish to zoom and center use axlZoomInOut.

Arguments

x_window	window id or nil to currently active window (see axlZoomBbox)
xy	Coordinate in design units for centering

Value Returns

t	if successful
nil	an error

See Also

axlZoomControl

Examples

- Create a secondary window and center it

```
axlZoomControl('create)
axlZoomCenter(1 4000:4000)
```


©2023 All Rights Reserved.

axlZoomControl

```
axlZoomControl (
     s_option
     [g_arg]
     )
     -=> g_return
```

Description

Manages the multi-canvas feature. Requires OpenGL to be enabled.Id 0 is the main Allegro canvas.

Supported options are:

`'create`	creates a new canvas. Currently only 1 supported. Return – If success returns canvas id, if max canvases already exist or multi-window not supported returns nil
`'remove`	removes secondary canvas. Cannot remove primary canvas (id=0). Requires a canvas id for g_arg. Return – `t` if canvas removed, `nil` if error
`'supported`	Is multi-window supported. Return – `t` if supported, nil not supported
`'list`	available canvases
`'active`	returns the active window id. This impacts the Allegro menu Zoom commands and if you pass nil to the axlZoom APIs Return: integer indicating active window
`'swap`	swaps the primary and secondary window contents. Return: t did the swap, nil failed

©2023 All Rights Reserved.

Arguments

s_option	see above
g_arg	addition argument some options require, see above

Value Returned

g_return	depends upon the option, See above

See Also

axlZoomBbox axlZoomPoints axlZoomCenter axlZoomWorld

Examples

- Create secondary canvas

```
axlZoomControl('create)
```

- Remove secondary canvas

```
axlZoomControl('remove 1)
```


©2023 All Rights Reserved.

axlZoomFit

```
axlZoomFit (
     x_window
     s_option
     ) => t/nil
```

Description

Zoom fits the window. Depending upon the design type fit is define as:

- logic design (brd, mcm, mdd, etc)

  Fit to board outline, package and route keepin

- partition (dps, dpf)

  Fit to partition boundary

- symbol (dra) - all visible objects

Arguments

x_window	window id or nil to currently active window (see axlZoomBbox)
s_option(visible)	if logic or partition design fit to visible objects

Value Returned

t	if successful
nil	an error

See Also

axlZoomControl

Examples

- Fit primary window to visible objects

```
axlZoomFit(0 visible)'
```


©2023 All Rights Reserved.

axlZoomInOut

```
axlZoomInOut (
     x_window
     x_factor
     [xy]
     ) => t/nil
```

Description

Zooms window in or out by provided factor around optional coordinate.

Arguments

x_window	window id or nil to currently active window (see axlZoomBbox)
x_factor	factor to zoom, a positive number zooms in while negative zooms out. 1 is 2x, 2 is 4x, 3 is 8x etc.
xy	optional coordinates to zoom around. If not provided uses center of current window

Value Returns

t	if successful
nil	an error

See Also

axlZoomControl

Examples

- zoom in by 2x primary window

```
axlZoomInOut(0 1)
```


©2023 All Rights Reserved.

axlZoomPoints

```
axlZoomPoints (
     x_window
     upperLeft_xy
     lowerRight_xy
     ) => t/nil
```

Description

Zoom windows by points. The zoom maintains a 1:1 aspect ratio, the coordinates provided will be fitted into the active window size.

Arguments

x_window	window id or nil to currently active window (see axlZoomBbox)
upperLeft_xy	upper left coordinate
lowerRight_xy	lower right coordinate

Value Returns

t	if successful
nil	an error

See Also

axlZoomControl

Examples

➡ zoom by points on the primary window

```
axlZoomPoints(0 100:120 4000:4000)
```


©2023 All Rights Reserved.

axlZoomToDbid

```
axlZoomToDbid(
     o_dbid/lo_dbid
     g_always
     [x_window]
     )
     ⇒ t/nil
```

Description

Processes a list of *dbids* and centers and zooms the display around them. Zoom is done so objects extents fill about 20% of the display. You should highlight the objects.

Note: If more than 20 objects are passed no zoom is done.

Arguments

o_dbid	List of *dbids* or one *dbid*.
g_always	If `t`, then ignores `NO_ZOOM_TO_OBJECT` environment variable.
x_window	Optional window ID or `nil` to currently active window (see axlZoomBbox). If no value is provided active window is used.

Value Returned

`t`	One or more objects zoomed.
`nil`	No valid *dbids* or all objects are already at desired display state.

Example

- Zoom to U1

```
sym = axlDBFindByName('refdes "U1")
axlZoomToDbid(sym t)
```

See Also

axlZoomManage

©2023 All Rights Reserved.

©2023 All Rights Reserved.

axlZoomWorld

```
axlZoomWorld (
     x_window
     ) => t/nil
```

Description

Zoom world a drawing window

Arguments

x_window	window id or nil to currently active window (see axlZoomBbox)

Value Returns

t	if successful
nil	an error

See Also

axlZoomControl

Examples

➡ world the active window

```
axlZoomWorld (nil)
```


©2023 All Rights Reserved.

axlMakeDynamicsPath

```
axlMakeDynamicsPath(
     l_formatedList
     )
     ⇒ r_path/nil
```

Description

This is a convenience function to construct an *r_path* from a formatted list. axlDBCreate and axlPoly require an *r_path.*

Note: A circle is an arc segment with same end points.

Caution

Passing an illegal format may result in a bad return.

©2023 All Rights Reserved.

Arguments

(l_seg1 l_seg2 ...)	Each *l_seg* is: *(l_startPoint l_endPoint [f_width] [l_center] [f_radius])* *l_startPoint:* Start point of path. *l_endPoint:* End point of path. *f_width:* Optional width (default of 0). *l_center:* Optional center point if *r_path* is an arc. *f_radius:* Optional radius if *r_path* is an arc. If an arc `r_path`, both *l_center* and *f_radius* must be provided.
g_clockwise	Direction to create arc: t ⇒ create arc clockwise from start to endpoint. nil ⇒ create counterclockwise. Default is counterclockwise.
g_clockwise	

Value Returned

`r_path`	*dbid* of `r_path`.
`nil`	No `r_path` constructed due to incorrect arguments.

Example

Simple `r_path` segment with a width of 20.

```
a = axlMakeDynamicsPath(list(list( 10:10 100:100 20)))
```


©2023 All Rights Reserved.

©2023 All Rights Reserved.

©2023 All Rights Reserved.

8

Allegro PCB Editor Command Shell Functions

This chapter describes the AXL-SKILL functions that access the Allegro PCB Editor environment and command shell.

Command Shell Functions

This section lists Allegro PCB Editor command shell functions.

©2023 All Rights Reserved.

axlGetAlias

```
axlGetAlias(
     t_alias/nil
     )
     ⇒ t_value/lt_names/nil
```

Description

Requests the value of the specified Allegro PCB Editor alias, *t_alias*. If given a `nil`, returns a list of aliases currently set. For compatibility purposes, `axlGetAlias` returns funckey settings.

Arguments

t_alias	Name of the Allegro PCB Editor environment alias.

Value Returned

t_value	String value of the Allegro PCB Editor environment alias.
lt_names	List of alias names.
`nil`	Alias not set.

See Also

axlSetAlias, axlGetFunckey

Example 1

```
alias = axlGetAlias("SF2")
⇒ "grid"
```

Gets the value of the alias assigned to shifted function key F2.

Example 2

```
list_alias = axlGetAlias(nil)
⇒ ("F2" "F3" "F4" ...)
```

Returns all set aliases.

©2023 All Rights Reserved.

axlGetFunckey

```
axlGetFunckey(
     t_alias/nil
     )
     ==> t_value/nil
```

Description

Requests the value of the specified funckey, *t_alias*. If given *nil*, returns a list of currently set funckeys.

Arguments

t_alias	Name of the environment funckey.
nil	Returns list of all current funckeys

Value Returned

t_value/nil	String value of the environment funckey. Returns *nil* if the funckey is not set.
lt_names	If passed *nil,* returns list of funckeys names.

See Also

axlSetFunckey, axlGetAlias

Examples

- Gets the value of the funckey assigned to shifted function key m.

```
alias = axlGetFunckey("m")
```

```
==> "grid"
```

- Return all set aliases.

```
list_alias = axlGetFunckey(nil)
```

```
==> ("-" "+" "m")
```


©2023 All Rights Reserved.

axlGetVariable

```
axlGetVariable(
     t_variable
     )
     ⇒ t_value/nil
```

Description

Requests the value of the specified Allegro PCB Editor environment variable, *t_variable*. Returns a list containing the string assigned to the variable or `nil` if the variable is currently not set in Allegro PCB Editor. Use `axlGetVariableList` where the variable stores a list of items (such as a PATH variable) to preserve any spaces in each item.

Note: Variable names are case insensitive.

Important

Variable names and values can change from release to release.

Arguments

t_variable	String giving name of the Allegro PCB Editor environment variable.
`nil`	If nil, returns a list of all set variables in Allegro PCB Editor

Value Returned

t_value	List containing string value of the Allegro PCB Editor environment variable.
`nil`	Variable not set.
`lt_names`	List of variable names (returned when `nil` is passed)

See Also

axlUnsetVariable, axlSetVariable, axlGetVariableList, axlReadOnlyVariable
axlSetVariableFile, axlUnsetVariableFile

©2023 All Rights Reserved.

Example

```
menu = axlGetVariable("menuload")
    ==> "geometry"
psmpath = axlGetVariable("psmpath")
    ==> ". symbols"
```

- Gets value of the current menu loaded.

  Variable name is *menuload*.

- Gets the value of the library search path *libpath*.

©2023 All Rights Reserved.

axlGetVariableList

```
axlGetVariableList(
     t_variable/nil
     )
     ==> t_value/lt_value/nil
```

Description

Requests the value of the specified Allegro PCB Editor environment variable, *t_variable*. Unlike axlGetVariable this returns a list of strings, if the variable is an array, such as one of Allegro PCB Editor's path variables. If variable is a single item, the return is the same as axlGetVariable.

Since path variables can contain spaces, using the axlGetVariable interface and then using the SKILL parseString command, to break them back to the component pieces will not give the correct result.

Note: Variable names are case insensitive.

Note: Variable names and values can change from release to release.

Arguments

t_variable	Name of the Allegro PCB Editor environment variable.
nil	If nil, returns a list of all set variables in Allegro PCB Editor.

Value Returned

t_value	String value of the Allegro PCB Editor environment variable.
nil	Returns nil if the variable is not set.
lt_names	list of variable names, returned when nil is passed as the argument

See Also

axlGetVariable

©2023 All Rights Reserved.

Example

Gets the value of the Package Symbol search path:

```
path = axlGetVariableList("psmpath")
==> ( "." "symbols" "/cds/root/share/pcb/allegrolib/symbols")
```


©2023 All Rights Reserved.

axlJournal

```
axlJournal(
     g_option
     )
     ==> t_tempFileName
```

Description

This function manages the program's journal file. It has several modes of operation:

`g_option = 'close`

closes current journal file; returns name of closed file

`g_option = <t_filename>`

close current journal file and opens no file, returns `t` if successful, `nil` if can't open file. Side effect of failure is current journal file is closed.

`g_option = 'name`

returns fullpath name of current journal file, `nil` if no active journal file

Caution

Typically the journal file is buffered. Reading the file while it is open may be unpredictable.

Caution

On Windows, an open file for writing cannot be read. You must close it first.

Argument

g_mode	see above

Value Returned

See above

Example

- Name of file

©2023 All Rights Reserved.

```
axlJournal('name)
```

- Open new file in tmp in current directory

```
axlJournal("my_journal")
```


©2023 All Rights Reserved.

axlProtectAlias

```
axlProtectAlias(
     t_alias
     t/nil
     )
     ⇒ t/nil
```

Description

Controls the read-only attribute of an alias.

Notes

- Do not unprotect F1 as this is fixed to *Help* by the operating system.
- You must define the alias before you can protect it.

Arguments

t_alias	Name of the Allegro PCB Editor environment alias.
t/nil	t protects the alias, and nil unprotects the alias.

Value Returned

t	Successfully protected or unprotected the alias.
nil	Alias is not set, or the function received invalid data.

Example

```
axlProtectAlias( "F2" t)
```

Protects the F2 function key.

©2023 All Rights Reserved.

axlIsProtectAlias

```
axlIsProtectAlias(
     t_alias
     )
     ⇒ t/nil
```

Description

Tests if the alias is read-only (or writable). This may also be used with funckeys.

Arguments

t_alias	Name of the Allegro PCB Editor environment alias.

Value Returned

`t`	Alias is protected.
`nil`	Alias is unprotected or not set.

See Also

axlIsProtectAlias

©2023 All Rights Reserved.

axlReadOnlyVariable

```
axlReadOnlyVariable(
     t_variable
     [g_Enable]
     )
     ==> t/nil
```

Description

This sets, unsets or queries the read-only state of an Allegro PCB Editor environment variable. Once a variable is set read only it cannot be changed. When you set a variable that is unset to read only, the user then cannot set it.

Note: Variable names are case insensitive.

Arguments

t_variable	The name of the Allegro PCB Editor environment variable.
g_Enable	`t` to set read-only; `nil` to make writable and do not provide if using to test variable read-only state.

Value Returned

`t/nil`	In query mode (*no g_Enable* option) returns `t` if variable is read-only and `nil` if not. If changing the read-only mode, returns `t` if successful and `nil` if variable is not currently set.

See Also

axlGetVariable, axlGetVariableList

Examples

The following example:

- Sets `psmpath` to read-only
- Queries the setting
- Resets `psmpath` to writable

©2023 All Rights Reserved.

- Query the setting

```
axlReadOnlyVariable("psmpath" t)
axlReadOnlyVariable("psmpath")
==> t
axlReadOnlyVariable("psmpath" nil)
axlReadOnlyVariable("psmpath")
==> nil
```

Query all read-only variables:

```
axlReadOnlyVariable("fxf" t)
axlReadOnlyVariable("psmpath" t)
axlReadOnlyVariable(nil)
==> ("psmpath" "fxf")
```


©2023 All Rights Reserved.

axlSetAlias

```
axlSetAlias(
     t_alias
     g_value
     )
     ⇒ t/nil
```

Description

You can set the Allegro PCB Editor environment alias with the name given by the string *t_alias* to the value *g_value* using the `axlSetAlias` function. *g_value* can be a string, int, t, or nil. Returns the string assigned to the alias or `nil` if the alias cannot be set in Allegro PCB Editor.

You can use function keys F2-F12, most Alpha-numeric keys with the control modifier (although Control-C V and X are reserved for copy, paste, and cut) and the Navigation Keys (Home, Up arrow, Esc, etc.) You can modify these items as shown:

Modifier	Indicator	Example
`Shift`	S	SF2
`Control`	C (function keys)	CF2
`Control`	~ (alpha-numeric)	-N
`Meta`	A	AF2

Modifiers may be combined as shown in these examples:

`CSF2`	Control-Shift F2
`ASF2`	Meta-Shift F2
`CAF2`	Control-Meta F2
`CASF2`	Control-Meta-Shift F2
`~SZ`	Control-Shift Z
`SUp`	Shift-Up Arrow
`CUp`	Control-Up Arrow

Both `axlSetFunckey` and `axlSetAlias` share the same data storage.

©2023 All Rights Reserved.

Notes:

- Alias settings only apply to the current session. They are not saved to the user's local env file.
- Alias changes do not affect programs launched from Allegro PCB Editor, for example, import logic, refresh_symbol.
- To set funckeys, see `axlSetFunckey, axlGetAlias, axlProtectAlias, axlIsProtectAlias, axlSetAlias axlGetAlias, axlProtectAlias`, and `axlIsProtectAlias.`

Arguments

t_alias	Name of the Allegro PCB Editor environment alias.
g_value	Value to which the environment alias is to be set. Can be a string or `nil`.

Value Returned

`t`	Alias set.
`nil`	Invalid data or alias is marked read-only.

Example 1

```
axlSetAlias( "F2" "save")
```

Sets the F2 function key to the *save* command.

Example 2

```
axlSetAlias( "~S" nil)
```

Unsets the `Ctrl-S` alias.

©2023 All Rights Reserved.

axlSetAlias

```
axlSetAlias(
     t_alias
     g_value
     )
     ⇒ t/nil
```

Description

You can set the Allegro PCB Editor environment alias with the name given by the string *t_alias* to the value *g_value* using the `axlSetAlias` function. *g_value* can be a string, int, t, or nil. Returns the string assigned to the alias or `nil` if the alias cannot be set in Allegro PCB Editor.

You can use function keys F2-F12, most Alpha-numeric keys with the control modifier (although Control-C V and X are reserved for copy, paste, and cut) and the Navigation Keys (Home, Up arrow, Esc, etc.) You can modify these items as shown:

Modifier	Indicator	Example
`Shift`	S	SF2
`Control`	C (function keys)	CF2
`Control`	~ (alpha-numeric)	-N
`Meta`	A	AF2

Modifiers may be combined as shown in these examples:

`CSF2`	Control-Shift F2
`ASF2`	Meta-Shift F2
`CAF2`	Control-Meta F2
`CASF2`	Control-Meta-Shift F2
`~SZ`	Control-Shift Z
`SUp`	Shift-Up Arrow
`CUp`	Control-Up Arrow

Both axlSetFunckey and axlSetAlias share the same data storage.

©2023 All Rights Reserved.

Notes:

- Alias settings only apply to the current session. They are not saved to the user's local env file.
- Alias changes do not affect programs launched from Allegro PCB Editor, for example, import logic, refresh_symbol.
- To set funckeys, see `axlSetFunckey, axlGetAlias, axlProtectAlias, axlIsProtectAlias, axlSetAlias axlGetAlias, axlProtectAlias`, and `axlIsProtectAlias.`

Arguments

t_alias	Name of the Allegro PCB Editor environment alias.
g_value	Value to which the environment alias is to be set. Can be a string or `nil`.

Value Returned

`t`	Alias set.
`nil`	Invalid data or alias is marked read-only.

Example 1

```
axlSetAlias( "F2" "save")
```

Sets the F2 function key to the *save* command.

Example 2

```
axlSetAlias( "~S" nil)
```

Unsets the `Ctrl-S` alias.

©2023 All Rights Reserved.

axlSetFunckey

```
axlSetFunckey(
     _alias
     g_value
     )
     ==> t/nil
```

Description

Works similar to `axlSetAlias` except allows alpha-number keys to work like function keys (no Enter key required). See `axlSetAlias` for complete documentation.

- Funckey settings only apply to current session. They are not saved to user's local `env` file.
- Funckey changes do not affect programs launched from Allegro PCB Editor: for example, `import logic` or `refresh_symbol`.

Arguments

t_alias	name of the Allegro environment alias.
g_value	Value to which the environment alias is to be set. Can be a string, or nil.

Value Returned

t	Returns *t* if successful.
nil	Returns *nil* if invalid data type of alias is marked read only.

See Also

axlGetFunckey, axlIsProtectAlias, axlIsProtectAlias, axlSetAlias

Examples

Set the funckey alias to move

```
axlSetFunckey( "m" "move" t)
```

Unset the move

©2023 All Rights Reserved.

```
axlSetFunckey( "m" nil)
```


©2023 All Rights Reserved.

axlSetVariable

```
axlSetVariable(
     t_variable
     g_value
     )
     ⇒ t/nil
```

Description

Sets the Allegro PCB Editor environment variable with name given by the string *t_variable* to the value *g_value*. The *g_value* can be a string, int, `t`, or `nil`. Returns the string assigned to the variable or `nil` if the variable cannot be set in Allegro PCB Editor.

Note: 511 is the maximum list long (*lt_variable*).

Notes:

- Variable names and values can change from release to release.
- Variable settings only apply to current session. They are not saved to local env file for the user.
- Variable changes do not effect programs launched from Allegro PCB Editor. For example, import logic, refresh_symbol
- Many Allegro operations are done via batch operations such as items in File Import/ Export, artwork, axlRunBatchDBProgram, and so on. These operations do NOT see variables changed (like PSMPATH) by this call or by the Allegro set command.

©2023 All Rights Reserved.

Arguments

t_variable	String giving the name of the Allegro PCB Editor environment variable.
g_value	Value to which the environment variable is to be set. Can be a string, int, `t`, or `nil`.

Value Returned

`t`	If successful
`nil`	If invalid data type of variable is marked read-only

See Also

axlGetVariable, axlReadOnlyVariable, axlSetVariableFile, axlUnsetVariable, axlUnsetVariableFile

Example

Sets new library search path `libpath`.

```
(axlSetVariable "libpath" "/mytools/library")
⇒ t
libraryPath = axlGetVariable ("libpath")
⇒ "/mytools/library"
```

Using list mode:

```
axlSetVariable("psmpath" '("." "symbols"))
                 ==> t
            axlGetVariableList("psmpath")
                 ==> ("." "symbols")
```


©2023 All Rights Reserved.

axlSetVariableFile

```
axlSetVariableFile(
     t_variable
     g_value
     )
     ==> t/nil
```

Description

Sets and saves to file Allegro environment variable. This operates the same as axlSetVariable except it also saves the setting to the user's local environment file.

Variable is added in the preference section of the env file.

Caution

On Windows, updating the environment file on disk can cause performance issues if this interface is used heavily.

Arguments

t_variable	Name of the Allegro environment variable.
g_value	Value to which the environment variable is to be set. Can be a `string`, `int`, `t`, or `nil`.

Values Returned

t/nil	Returns `t` if successful. Returns `nil` if invalid data type of variable is marked read-only.

See Also

axlSetVariable, axlUnsetVariableFile

©2023 All Rights Reserved.

axlShell

```
axlShell(
     t_command
     )
     ⇒ t
```

Description

Issues the Allegro PCB Editor command string *t_commands* to the connected editor. You can chain commands. This call is synchronous.

Important

This function might not be portable across Allegro PCB Editor releases.

Arguments

t_command	Allegro PCB Editor shell command or commands.

Value Returned

t	Always returns t.

See Also

axlShellPost

Example 1

```
(axlShell "status")
⇒ t
```

Displays Allegro PCB Editor Status form from AXL-SKILL.

Example 2

```
axlShell("zoom points; pick 0 0; pick 100 100")
```

Chained command example:

©2023 All Rights Reserved.

axlShellPost

```
axlShellPost(
     t_command
     ) ==> t
```

Description

This works similar to `axlShell` except it first requires a return from the SKILL interpreter before executing the command(s). It should only be used in the special circumstance where you want to do some processing in SKILL, execute an Allegro PCB Editor interactive command and have that command be left active for the user. If more the one command is embedded in post command then subsequent commands should be prefixed with an underscore to inhibit scripting. For example:

```
axlShellPost("zoom points; _pick 10 20")
```

Caution

Do not attempt to use this as a method to override an existing Allegro PCB Editor command with SKILL code and then call the original command. An infinite loop will result.

Caution

This function may not be portable across Allegro PCB Editor releases.

Arguments

t_command	Allegro PCB Editor shell command or commands.

Value Returned

t	Always returns *t*.

See Also

axlShell

©2023 All Rights Reserved.

EXAMPLES

Over the `move` command to print hello and then let user move objects.

```
axlCmdRegister( "mymove" 'testSkill ?cmdType "interactive")
procedure( testSkill()
         printf("Hello mymove\n")
         axlShellPost("echo hello from post; _move")
         printf("Hello after-mymove\n")
 )
Output -- showing deferred execute:
        Hello mymove
        Hello aftermove
        hello from post
        Select element(s) to move.
```


©2023 All Rights Reserved.

axlUnsetVariable

```
axlUnsetVariable(
     t_variable
     )
     ⇒ t
```

Description

Unsets the Allegro PCB Editor environment variable with the name given by the string *t_variable*. The value of the named variable becomes `nil`.

Important

Variable names and values can change from release to release.

Arguments

t_variable	String giving the name of the Allegro PCB Editor environment variable.

Value Returned

`t`	Always returns `t`.

See Also

axlSetVariable

Example

```
(axlUnsetVariable "libpath")
⇒ "/mytools/library"
libraryPath = (axlGetVariable "libpath")
⇒ nil
```

Clears the library path `libpath` when its current value is `/mytools/library`.

©2023 All Rights Reserved.

axlUnsetVariableFile

```
axlUnsetVariableFile(
     t_variable
     )
     ==> t
```

Description

Unsets the value of specified Allegro environment variable. Works the same as axlUnsetVariable plus it also updates the local environment file of the user with the change.

Caution

On Windows, updating the environment file on disk can cause performance issues if this interface is used heavily.

Arguments

t_variable	String giving the name of the Allegro environment variable.

Value Returned

t	Always returns t.

See Also

axlSetVariableFile, axlSetVariable

©2023 All Rights Reserved.

©2023 All Rights Reserved.

9

IC Packaging Commands

The functions listed in this chapter are available only in Allegro® Package Designer+ (APD+).

©2023 All Rights Reserved.

axlBGATextIn

```
axlBGATextIn(
     t_filename
     ?delim t_delim
     ?delimConsec b_consec
     ?delimTrail b_trail
     ?header g_header
     ?unMirrorY b_mirror
     ?symName t_symname
     ?refDes t_refdes
     ?origin g_origin
     ?extents g_extents
     ?rotation d_rotation
     ?layer t_layer
     )
     ==> t/ErrorMsg/nil
```

Description

Imports a BGA using an ASCII text file containing the BGA information.

Note: This is a SKILL wrapper for the BGA Text-In Wizard. Providing only a filename is equivalent to selecting an ASCII text file containing the BGA information and then clicking *Next* for the remaining steps in the BGA Text-In Wizard. Post-import steps like purging unused nets are not done.

©2023 All Rights Reserved.

Arguments

t_filename	Specify the filename to be imported.
t_delim	Specify up to six delimiters to separate columns of data.
b_consec	Set to ignore consecutive delimiters.
b_trail	Set to ignore trailing delimiters.
g_header	Specify the list of header names to be imported. Must match the number of columns in the imported file.
b_mirror	Set to unmirror the Y pins of the BGA.
t_symname	Specify the name of the symbol to be used.
t_refdes	Specify the reference designator for the BGA symbol.
g_origin	Specify the symbol origin.
g_extents	Specify the symbol extents.
d_rotation	Specify the rotation of the BGA.
t_layer	Specify the pad layer.

Value Returned

t/ErrorMsg/nil	Returns `t` if BGA imported successfully.
	Returns `ERROR` message if an option is invalid.
	Returns `nil` if import is unsuccessful due to any reason other than an invalid option.

Examples

```
axlBGATextIn("BGA_data.txt")
axlBGATextIn("BGA_data.txt" ?delim "\t" ?rotation 20.0 ?refDes "ABC")
axlBGATextIn("BGA_data.txt" ?delim "\t" ?delimConsec nil ?delimTrail t
    ?header '("Pin Number", "Padstack", "X Coord", "Y Coord", "Rotation", "Pin
    Use", "Net Name")
    ?unMirrorY nil ?symName "BGA_N" ?refDes "BGA_S" ?origin '(1000 -2000)
    ?extents '(-10000 -10000 10000 10000) ?rotation 20.0 ?layer "BOTTOM" )
```


©2023 All Rights Reserved.

See Also

axlDieTextIn, axlNetlistTextIn

©2023 All Rights Reserved.

axlChangeLayer

```
axlChangeLayer(
     lo_dbid/o_dbid
     t_newLayer
     [o_padStackDbid]/[t_padstackname]
     )
     ==> t/nil
```

Description

Changes layer for lines, clines or segments, shapes, and text. Functionality offered, at the global level, matches the Allegro PCB Editor `change` command, but can differ in certain areas.

If moving clines or cline segments across layers, you should provide a via to be used to maintain connections. Via must meet constraint rules. For via to be accepted it must have:

- pads on start and destination layers
- be in the constraint via list for the net and location

If the provided padstack is not acceptable, system will select an acceptable padstack based upon the via list for net and location.

Note: If you need to change the layer of multiple etch objects, it is more efficient to pass them as a list of dbids then to call this function for each dbid.

Arguments

lo_dbid/o_dbid	a single dbid or list of dbids
t_newLayer	new layer for placing dbid
o_padStackDbid	if moving clines across layers, allegro will add a via to maintain connection. This is that via. If this argument is not provided the system default via is used.
t_padStackName	name of padstack to be used

Value Returned

`t` if succeeded, `nil` if failure

©2023 All Rights Reserved.

Failures

For debug purposes set axlDebug(t) to see additional messages.

- dbid is of a unsupported type
- illegal option types
- target layer matches object current layer

Examples

- Move an object to ETCH/BOTTOM

```
; ashOne is a selection utility found at <cdsroot>/pcb/examples/skill/ash-fxf/
ashone.il
dbid = ashOne()
; pick an object (set find filter)
result = axlChangeLayer(dbid "ETCH/BOTTOM")
;   or if moving clines
result = axlChangeLayer(dbid "ETCH/BOTTOM" "PAD60SQ36D")
```

See Also

axlTransformObject, axlDBChangeText, axlChangeWidth

©2023 All Rights Reserved.

axlCNSAssemblyModeGet

```
axlCNSAssemblyModeGet(
     nil
     ) => ls_constraints

axlCNSAssemblyModeGet(
     'all
     ) => lls_constraintNModes

axlCNSAssemblyModeGet(
     s_name/t_name
     ) => s_mode/nil

axlCNSAssemblyModeGet(
     s_name/t_name
     'print
     ) => t_name/nil
```

Description

This retrieves the current assembly DRC mode(s). Modes determine if a particular constraint is on or off. These DRC modes apply to the entire design. Use `axlCNSAssemblyModeGet(nil)` to determine the set currently supported assembly modes.The `'print` mode offers the name shown in reports like show element.

Caution

Future releases may add or subtract constraint checks. The axl interface does guarantee the checks returned by this interface will remain constant from release to release.

©2023 All Rights Reserved.

Arguments

nil	returns all modes that are in the spacing domain
'all	returns all checks and current mode
s_name	symbol name of check.
t_name	string name of check
'print	printable constraint name option

Value Returned

ls_names	list of checks `(s_name ...)`
lls_names	list of checks and their mode `((s_name s_mode) ...)`
s_mode	mode `'on`, or `'off`
t_name	the printable constraint name

Examples

- Get current list of assembly constraints

  ```
  axlCNSAssemblyModeGet(nil)
  ```

- Get list of settings for all assembly constraints

  ```
  axlCNSAssemblyModeGet('all)
  ```

- Get current mode of Die to Finger Spacing check

  ```
  axlCNSAssemblyModeGet('die_to_finger)
  ```

See Also

axlCNSAssemblyModeSet, axlCNSGetAssembly

©2023 All Rights Reserved.

axlCNSAssemblyModeSet

```
axlCNSAssemblyModeSet(
     t_name/s_name
     t_mode/s_mode
     )
     => t/nil


axlCNSAssemblyModeSet(
     'all
     t_mode/smode
     )
     => t/nil


axlCNSAssemblyModeSet(
     l_constraintNModes
     t_mode/smode
     )
     => t/nil


axlCNSAssemblyModeSet(
     ll_constraintNModes
     )
     => t/nil
```

Description

This command sets the current DRC modes (on/off) for checks in the area of assembly constraints. These modes are global.

To determine the constraints modes currently supported, use `axlCNSAssemblyModeGet(nil)`.

Several interfaces are supported for this command, all checks `('all)`, individual checks (`t_name`), list of checks within a mode `'(s_name ...) t_mode/s_mode'(t_name ...) t_mode/s_mode`, and sets of checks via a list of:`'((s_name/t_name s_mode/t_mode) ....)`.

The constraints names may be passed as a symbol or a string. For performance reasons, either do all your updates in a single call or wrap individual changes in the map API (see axlCNSMapUpdate).

©2023 All Rights Reserved.

Caution

Future releases may add or subtract constraint checks. The axl interface does guarantee the checks returned by this interface will remain constant from release to release.

Arguments

`s_name`	symbol name of check.
`t_name`	string name of check.
`s_mode`	mode setting; may be 'on or 'off.
`t_mode`	string mode setting "on" or "off".
`'all`	set all checks for assembly design rule checks (including online wire rules)

Value Returned

`t`	if succeeds
`nil`	if failed

Examples

- Turn all constraints off

```
axlCNSAssemblyModeSet('all 'off)
```

- Turn Die to Finger Spacing check on

```
axlCNSAssemblyModeSet('die_to_finger 'on)
```

- Turn two constraint to on

```
axlCNSAssemblyModeSet('(via_to_package_edge die_to_finger) 'on)
```

- Set various constraints to different modes

```
axlCNSAssemblyModeSet( '((die_to_finger off) (via_to_package_edge 'on)) )
```

See Also

axlCNSAssemblyModeGet, axlCNSGetAssembly, axlCNSMapUpdate

©2023 All Rights Reserved.

axlCNSGetAssembly

```
axlCNSGetAssembly(
     t_cset
     t_layer
     s_constraint
     [g_string]
     )
     => g_value/nil
```

```
axlCNSGetAssembly(
     t_cset
     t_layer
     nil
     [g_string]
     )
     => ll_nameValue/nil
```

```
axlCNSGetAssembly(
     nil
     nil
     nil
     )
     => ls_cnsTypes
```

Description

Obtains an Assembly cset values. In the first operational mode, the command obtains the value of an assembly constraint given a cset and a layer. In second mode of operation, it obtains all assembly constraint as name-value pairs for a cset on a layer. For the last mode, a list of all supported assembly constraints is obtained by passing three `nil` values to the interface:`axlCNSGetAssembly(nil nil nil)`

DATA TYPES — Unless otherwise specified constraints are in current design units.

©2023 All Rights Reserved.

Arguments

t_cset	Name of a assembly cset. Use "" for design-level constraints.
t_layer	ETCH layer name (e.g "ETCH/TOP" or "TOP"). If `nil` is specified, gets constraints on all layers.
s_constraint	Name of constraint. If `nil`, returns a set of symbol/value pairs of all constraints.
g_string	By default, returns value in the native units of the constraint. If `g_string` is set to `t`, the data is returned as a string.

Value Returned

g_value	Value of constraint in design units
ll_nameValue	Mame value pairs of assembly constraint symbol and constraint value for all assembly `(s_constraint g_value)`. `'((wire_len_min 10.0) (wire_len_max 50.0) ...)`
ls_cnsTypes	List of supported assembly constraint names
nil	Indicates an error

Examples

- Get min wire length in design cset

```
axlCNSGetAssembly("" nil 'wire_len_min)
```

- Get all assembly constraints for "V" cset, bottom layer

```
axlCNSGetAssembly("V" "BOTTOM" nil)
```

- Get min shape constraint list for "V" cset, top layer

```
axlCNSGetAssembly("V" "TOP" 'min_shape_check)
```

- Get supported Assembly constraint symbols

```
axlCNSGetAssembly(nil nil nil)
```

- Fetch all layers and constraints of Assembly cset V

```
cset = "V"       ;; D
foreach(subclass axlSubclassRoute()
layer = axlCNSGetAssembly(cset subclass nil)
printf("\nLAYER=%s\n\tconstraints=%L\n" subclass, layer)
)
```


©2023 All Rights Reserved.

See Also

axlCNSSetAssembly

©2023 All Rights Reserved.

axlCNSSetAssembly

```
axlCNSSetAssembly(
     t_object/nil
     t_layer/nil
     s_constraint
     g_value
     [s_object_type]
     )
     ==> t/nil
```

```
axlCNSSetAssembly(
     t_object/nil
     t_layer/nil
     ll_constraintValues
     nil
     [s_object_type]
     )
     ==> t/nil
```

Description

Updates assembly cset, wire profile or symbol constraint values. By passing `nil` at the appropriate argument, values for all csets and all layers may be changed.

By default, object type is a cset. To update values on wire profile, use wire profile as an object name and pass fifth argument as `'PROFILE`. To update values on symbols (dies, spacers or interposers) use refdes as an object name, and specify the fifth argument as `'SYMBOL`.

DATA TYPES — See axlCNSGetAssembly for the data type of each constraint.

Design Units:

- A number (integer or floating point) where units is current design units. Must not exceed accuracy of the design.
- Unit less string where accuracy cannot exceed db accuracy.
- String with units, data converted to current design units.

Boolean: Use `t/nil` or "true"/"false".

Tip

For list of Assembly constraints see axlCNSGetAssembly.

©2023 All Rights Reserved.

Caution

This does NOT change override values. For example, you can set wire_len_min value in all csets but if the user has applied it to a wire profile as an override, it will still be used for those items.

Arguments

t_object	cset name, use `""` for design level constraint. Use `nil` to apply change to all cset. wire profile name die refdes
t_layer	ETCH layer name (e.g "ETCH/TOP" or "TOP"). If nil apply change to all layers - applicable to by layer constraints only. Use nil for constraints that cannot be set by layer.
s_contraint	Constraint symbol to change. Use `axlCNSGetAssembly(nil nil nil)` for list of permissible values.
g_value	Value to update. For data type see above for "DATA TYPES".
ll_constraintValues	Multiple values may be updated by passing a list of lists for the third argument. `'((s_contraint g_value) ... )`
s_object_type	By default, object type is cset. Use `'SYMBOL` for die, `'PROFILE` for wire profile

Value Returned

- `t` if succeeds
- `nil`, in case of an error. This value is returned if:
  - cset name does not exit
  - layer does not exist
  - constraint does not exist
  - illegal value for constraint

©2023 All Rights Reserved.

Examples

- Set min shape check on all constraint sets and layers

```
axlCNSSetAssembly(nil nil 'min_shape_check 50)
```

- Set min void check on all layers on design level

```
axlCNSSetAssembly("" nil 'min_void_check 60)
```

- Set min wire length on wire profile PROFILE1

```
axlCNSSetAssembly("PROFILE1" nil 'wire_len_min 75 'profile)
```

- Set die overhang x on die U1

```
axlCNSSetAssembly("U1" nil 'die_overhang_x 50 'symbol)
```

See Also

axlCNSGetAssembly

©2023 All Rights Reserved.

axlCreateDeviceFileTemplate

```
axlCreateDeviceFileTemplate(
     t_deviceName
     t_CLASS
     l_pinList
     ) -> t/nil
```

Description

This function creates a template device file providing the same functionality as the `create device` command in the symbol editor. Normally you would use axlDBCreateComponent to create a device file if in the board.

Arguments

t_deviceName	Name of device file (no file extension or path)
t_CLASS	Class of device (for example, IC, IO, and so on)
`l_pinList`	List of pins. Can be any combination of either pin dbid or pin numbers. If a pin dbid will filter out mechanical pins

Value Returned

`t` - file created

`nil` - an issue

See Also

axlDBCreateComponent

©2023 All Rights Reserved.

axlCompAddPin

```
axlCompAddPin(
     o_comp
     g_absLoc
     o_pin/lo_pins
     ) => t/nil
```

Description

This function adds one or more pins to the specified component. Pins are added to the corresponding component and symbol definition, with changes being reflected in all instances of those definitions.

Arguments

o_comp	Dbid of component instance to which pins should be added.
g_absLoc	If true, locations and rotations for pins are absolute values in the design space. If `nil`, these values are relative to the origin of the unmirrored, unrotated symbol definition.
o_pin/lo_pins	Structure, or list of structures, defining the pins to be added. These objects are defstructs as defined below.

Defstruct used to define a pin. Use `make_axlCompPinRecord`.

Required Elements are:

- *s_pinUse* – Pin use code for this pin. Must be one of the following symbols:
  - UNSPEC
  - POWER
  - GROUND
  - NC
  - LOADIN
  - LOADOUT
  - BI
  - TRI

©2023 All Rights Reserved.

  - OCA
  - OCL

- *n_swapCode* – Swap group code for this pin. A swap code of `0` means this pin is not swappable. Otherwise, all pins with the same swap code are swappable. This value is not used for co-design components, as all co-design comp pins are considered swappable.
- *l_location* – X/Y coordinate location for the pin. Absolute or relative to the symbol def origin, as specified by `g_absLoc`.
- *n_rotation* – Angular rotation of this pin. Absolute or relative to the symbol definition origin, as specified by `g_absLoc`.

Optional Elements are:

- *pinNumber* – Physical pin number to assign to this pin. Must be unique across all pins of the component. If no pin number is provided, the pin number will be computed based on the pin numbering scheme for the component. If the numbering scheme is 'Customized', as is the default for co-design objects, then the tool will assign the first unused integer as the pin's number (1, 2...).
- *pinName* – Logical pin name for the pin. Not used for power/ground pins. If not provided, the pin name for signal pins will be the same as the physical pin number.
- *verilogPort* – Verilog port name for the pin. Not used for power/ground pins. If not provided, there is no verilog port name for the pin and the function pin name is used.
- *net* – Net name or dbid to assign this pin to when created. If nil, pin will be created on a dummy net and can be assigned later.
- *padstack* – Padstack name or dbid to use for this pin. If no padstack is supplied, the padstack already in use for pins of this component will be used for this pin as well.
- *layer* – Layer the pin sits on. If unset, defaults to the front layer for the component. Otherwise, may contain the layer name to place the pin on for a backside pin.
- *connectType* – Type of connection made to host substrate. One of "DEFAULT", "BONDPAD", "BUMP", "PILLAR", "CONNECTPAD", "PROBEPAD", "NCPAD".

Co-design Elements are:

- *codesignNet* – Net name for this pin in the secondary design space. For example:
  - For a co-design die in a package, this is the pin's net in the IC design.
  - For a co-design package in a board, this is the pin's net in the package.

©2023 All Rights Reserved.

- *`codesignPad`* – Pad/Cell name for this pin in the secondary design space. For example:
  - For a co-design die in a package, this is the pin's LEF bump macro.
  - For a co-design package in a board, this is the pin's padstack in the package.

Value Returned

- `t` if the pin(s) were added.
- `nil` if there was an error adding any of the pins, for example, if a pin would be placed outside the extents of the symbol or drawing.

Tip

If many pins are to be added, it is more efficient to pass the entire list to this function to process them in one call than to call axlCompAddPin with each individual pin.

See Also

axlCompDeletePin, axlCompMovePin

©2023 All Rights Reserved.

axlCompDeletePin

```
axlCompDeletePin(o_pin/lo_pins) => t/nil
```

Description

This function deletes the specified pin(s) from the parent component and symbol definition. As a result, the pin will also be deleted from all instances of these definitions and not just the instance the pin passed in belongs to.

Arguments

o_pin/lo_pins	SKILL dbid of the pin to be deleted, or a list of pins to be deleted.

Value Returned

- `t` if the pin(s) were deleted.
- `nil` if there was an error deleting any of the pins, for example, if a pin had the fixed property.

Note: If many pins are to be delete, it is more efficient to pass the entire list to this function to process them in one call than to call axlCompDeletePin with each individual pin.

See Also

axlCompAddPin, axlCompMovePin

©2023 All Rights Reserved.

axlCompMovePin

```
axlCompMovePin(
     o_pin/lo_pins
     ?move            l_deltaPoint
     ?groupMirror     t/nil
     ?groupRotation   f_angle
     ?rotOrigin       l_rotatePoint
     ?pinRotation     f_deltaAngle
     ) => t/nil
```

Description

This function moves the specified pin(s) by the specified delta x/y, rotation, and mirror. Rotation and mirror, if provided, are applied around the `rotatePoint` (defaults to 0,0 if not provided). A rotation to apply to each individual pin may also be provided.

Arguments

o_pin/lo_pins	SKILL dbid of the pin to be moved, or a list of pins to be moved.
move	X/Y delta to move each pin in the set by.
groupMirror	`t` if the position of each pin in the group should be mirrored around the supplied rotOrigin.
groupRotation	angle of rotation that should be applied to each pin in the group to determine its new final location. Applied around rotOrigin.
rotOrigin	X/Y origin for group mirror and rotation application.
pinRotation	Rotation to apply to individual pins once placed at new location. For example, if you are moving a pin from the north side to west side, and the pin is rectangular, you may wish to specify a rotation of 90 degrees to keep the same orientation of the pin rectangle relative to the nearest die edge.

Value Returned

`t` if the pin(s) were moved.

`nil` if there was an error moving any of the pins, for example, if a pin had the fixed property or would be placed outside the extents.

Notes:

©2023 All Rights Reserved.

- If many pins are to be moved, it is more efficient to pass the entire list to this function to process them in one call than to call axlCompMovePin with each individual pin.
- When applying multiple transforms at once to the set of pins, the operations are performed in the following order:
  a. group mirror is performed for the group about the specified rotOrigin.
  b. group rotation is then applied, also around the rotOrigin.
  c. move delta is then applied.

This is important to keep in mind so that you achieve the desired end position for all pins being moved, and so that you use the correct rotOrigin point.

See Also

axlCompAddPin, axlCompDeletePin

©2023 All Rights Reserved.

axlComponentChangeClass

```
axlComponentChangeClass(
     s_devType/o_compDef
     s_class
     ) -> t_oldClass/nil
```

Description

This command changes the component class of a component definition.

Do not change class for the component definitions with component class as MECHANICAL, PLATING_BAR or DRIVER_CELL. Also you may not change an object to those classes.

To get the dbid of a component definition,

- For symbol instance, `cd = syminst->component->compdef`

  Note: A symbol may not have a component instance (for example, mechanical).

- For component instance, `cd = component->compdef`

Caution

Running a Cadence or 3rd party ECO restores the original component class.

©2023 All Rights Reserved.

Arguments

s_devType	Name of the device.
o_compDef	dbid of a component definition.
s_class	Name of the new component class. Possible values are IC, IO, or DISCRETE

Value Returned

t_oldClass	Old component class is returned in case of success.
nil	Returned in case of an error.

Example

```
axlComponentChangeClass("DIP14" "DISCRETE")
```

See Also

axlDBCreateComponent

©2023 All Rights Reserved.

axlCompSetPinAttributes

```
axlCompSetPinAttributes(
     o_pin/lo_pins
     ?number     t_pinNumber
     ?name       t_pinName
     ?use        t_pinUse
     ?padstack   t_padstack/g_padstack
     ?rotation   f_rotation
     ?swapCode   n_swapCode
     ) => t/nil
```

Description

This function modifies attributes of the specified pin(s) at the symbol and component definition level. Things like the padstack, pin number, and swap code (see below for full list of supported attributes). All update items, if not set, will be left at the pin's existing value.

©2023 All Rights Reserved.

Arguments

o_pin/lo_pins	SKILL dbid of the pin to be modified, or a list of pins to be modified.
number	New pin number for pin. It is recommended that this parameter must be used only with single pins sent in, as pin numbers MUST be unique.
name	Function pin name for the pin. Since the actual database function, `pinname`, is a key for the function pin definition, this must be unique within the function definition. However, if a non-unique value is supplied, or the string is not valid for a function pin name (such as it contains lower case characters), the name supplied here is stored as the Verilog_Port_Name for the pin and a legal unique PinName is derived from this name to generate a unique key for the database.
use	New pin use for the pin. If changing the pin use from power/ground to a signal pin, function pins are created. In the reverse scenario — changing pinuse from signal to power/ground — function pins are removed.
padstack	New padstack to be used for the specified pin.
rotation	New rotation of pin (on the specific symbol instance as currently placed in the design). Symbol definition pin is updated to compensate for final instance rotation.
swapCode	New swap code group index for pin.

Value Returned

`t`	Returned when at least one pin is modified.
`nil`	Returned in case there is an error modifying any of the pins.

See Also

`axlCompAddPin`, `axlCompDeletePin`, `axlCompMovePin`

©2023 All Rights Reserved.

axlDBGetDesignStats

```
axlDBGetDesignStats()
     -> structured list/nil
```

Description

This function returns a structure containing information about the design statistics of active drawing such as, routing completion, and so on. Most of this information is also found in the UI through the *Display – Status* dialog box.

©2023 All Rights Reserved.

Value Returned

Returns structured list of information:

`completeConnections`	Number of fully-routed connections.
`incompleteConnections`	Number of open/incomplete connections needing to be routed.
`totalConnections`	Total connections in a design (complete + incomplete)
`placedComponents`	Number of placed components
`unplacedComponents`	Number of unplaced components
`totalComponents`	Total components in a design (placed + unplaced)
	`nil` if error.

Example

```
axlDBGetDesignStats() ->
(totalComponents        355
placedComponents       355
unplacedComponents       0
completeConnections   1926
incompleteConnections    0
totalConnections      1926
noRatNets                0
signalNets             374
totalNets              374
)
```

See Also

axlDesignType

©2023 All Rights Reserved.

axlDBIsBondingWireLayer – Obsolete

This is an obsolete function. Bonding wire layers have been replaced by die stack layers. Use `axlDBIsDieStackLayer` to check whether a layer is a die stack layer.

©2023 All Rights Reserved.

axlDBIsDiePad

```
axlDBIsDiePad(
     rd_dbid
     )
     ⇒ t/nil
```

Description

Verifies whether or not the given element is a *die pad*.

A *die pad* is a pin with a component class of `IC`.

Arguments

rd_dbid	*dbid* of the element to check.

Value Returned

`t`	*rd_dbid* is a die pad.
`nil`	*rd_dbid* is not a die pad.

©2023 All Rights Reserved.

axlDBIsPlatingbarPin

```
axlDBIsPlatingbarPin(
     rd_dbid
     )
     ⇒ t/nil
```

Description

Verifies whether or not the given element is a *plating bar pin*.

A *plating bar pin* is a pin with a component class of `DISCRETE` or `PLATING_BAR`.

Arguments

rd_dbid	*dbid* of the element to check.

Value Returned

t	*rd_dbid* is a plating bar pin.
nil	*rd_dbid* is not a plating bar pin.

©2023 All Rights Reserved.

axlDieTextIn

```
axlDieTextIn(
     t_filename
     ?delim t_delim
     ?delimConsec b_consec
     ?delimTrail b_trail
     ?header g_header
     ?unMirrorY b_mirror
     ?symName t_symname
     ?refDes t_refdes
     ?origin g_origin
     ?extents g_extents
     ?rotation d_rotation
     ?layer t_layer
     ?shrink d_shrink
     ?scribe g_scribe
     )
     ==> t/ErrorMsg/nil
```

Description

Imports a die using a text file.

Note: This is a SKILL wrapper for the Die Text-In Wizard. Providing only a filename is equivalent to selecting a die text file containing the BGA information and then clicking *Next* for the remaining steps in the Die Text-In Wizard. Post-import steps like purging unused nets are not done.

©2023 All Rights Reserved.

Arguments

t_filename	Specify the filename to be imported.
t_delim	Specify up to six delimiters to separate columns of data.
b_consec	Set to ignore consecutive delimiters.
b_trail	Set to ignore trailing delimiters.
g_header	Specify the list of header names to be imported. Must match the number of columns in the imported file.
b_mirror	Set to unmirror the Y pins of the BGA.
t_symname	Specify the name of the symbol to be used.
t_refdes	Specify the reference designator for the symbol.
g_origin	Specify the symbol origin.
g_extents	Specify the symbol extents.
d_rotation	Specify the rotation of the symbol.
t_layer	Specify the pad layer.
d_shrink	Specify a shrink factor for the die between `0` and `100`.
g_scribe	Specify scribe sizes in the `'(North East South West)` order.

Value Returned

t/ErrorMsg/nil	Returns `t` if die imported successfully. Returns `ERROR` message if an option is invalid. Returns `nil` if import is unsuccessful due to any reason other than an invalid option.

Examples

```
axlDieTextIn("Die_data.txt")
axlDieTextIn("Die_data.txt" ?delim "\t" ?rotation 20.0 ?refDes "ABC")
axlDieTextIn("Die_data.txt" ?delim "\t" ?delim_consec nil ?delim_trail t
    ?header '("Pin Number", "Padstack", "X Coord", "Y Coord", "Rotation", "Pin
    Use", "Net Name")
    ?unmirrory nil ?symName "Die_N" ?refDes "Die_S" ?origin '(1000 -2000)
    ?extents '(-10000 -10000 10000 10000)
```


©2023 All Rights Reserved.

```
?rotation 20.0 ?layer "TOP" ?shrink 5.0 ?scribe '(500 1000 1500 2000))
```

See Also

axlBGATextIn, axlNetlistTextIn

©2023 All Rights Reserved.

axlGetBondWireToBondWireDist

```
list axlGetBondWireToBondWireDist(wire1, wire2)
```

Description

This function calculates the distance in 3D space between two bond wires in 3D space and returns the result.

Arguments

wire1	dbid of the first bond wire object
wire2	dbid of the second bond wire object

Value Returned

`list`	If the inputs are correct and a 3D engine is available, the distance between the bond wires as well as the 3D coordinate points between which the distance is calculated. The first element in the list gives the 3D distance
`nil`	If any (or both) of the object is (are) not a bond wire or if 3D engine is not available.

Example

```
axlSetFindFilter( ?enabled ( list "noall" "BondWires" )  ?onButtons (list
"BondWires" ))
axlSingleSelectPoint(3500:2200)
w1 = car(axlGetSelSet())
axlSingleSelectPoint(3500:1900)
w2 = car(axlGetSelSet())
d=axlGetBondWireToBondWireDist( w1 w2 )
Sample Output:
(133.665
(1860.137 1540.014 615.479)
(1846.296 1672.205 601.323)
)
```


©2023 All Rights Reserved.

axlGetDieType

```
axlGetDieType(
     o_componentDBID
     )
     ==> t_dieType
```

Description

Returns the die attachment type for a given die component in a Cadence packaging tool (APD+). A die is considered to be an IC class component in the database. Currently, the supported attachment types include the following:

- WIREBOND
- FLIP CHIP

Arguments

Component DBID	*dbid* handle of the die component to query.

Value Returned

`t_dieType`	If successful.
`nil`	If failed (non-die object passed or not a packaging product).

Examples

```
axlGetDieType(myComp)
    ==> "FLIP CHIP"
```


©2023 All Rights Reserved.

axlGetMetalUsageForLayer

```
axlGetMetalUsageForLayer(
     l_layers
     [l_extents]
     [g_positive]
     [exclude_pins_vias]
     )
     ==> resultStruct/nil
```

Description

Computes the percentage metal coverage on the layers specified in l_layer(s) (combination of all layers listed) in the area specified in `l_extents`. If no extents are provided, then the geometry outline extents of the design are used.

Negative layer metal coverage can be computed by passing nil for g_positive, if processing negative artwork layers such as solder mask layers.

Arguments

`l_layers`	A single layer or list of layers to compute the (combined) metal usage on. For example, passing list("CONDUCTOR/TOP" "PIN/TOP") will compute the coverage of all conductor + pin objects on the top layer. It will not compute the two individually.
`l_extents`	BBox region to compute metal coverage in. If not supplied, the tool will compute based on the substrate geometry outline's extents or, if no outline is present, the database extents.
`g_positive`	Whether the layer(s) being processed are positive or negative layers. Defaults to true.
`exclude_pins_vias`	Excludes pins and vias for ETCH class; returns copper area excluding pins and vias. Default is `nil`. For example,

Value Returned

- `resultStruct/nil` – resultStruct is a defstruct containing for elements:
- `areaUnits` – Units in which the area was computed and returned.
- `regionArea` – The area of the extents region the tool used (user supplied or drawing extents).

©2023 All Rights Reserved.

- `metalArea` – The total metal area in the region checked on the layers indicated.
- `percentMetalCoverage` – The percentage of the extents region covered by metal. Calculated as `((metalArea / regionArea) * 100.0)`
- `nil` is returned if there is an error, with error printed to command line.

©2023 All Rights Reserved.

axlGetWireProfileDefinition

```
list axlGetWireProfileDefinition(profileName)
```

Description

Given a bonding wire profile name, this will returns its definition information.

Arguments

profileName	Name of the profile definition being queried. If this argument is `nil`, definitions of all profiles in design are retrieved.

Value Returned

Structure of information describing the profile definition (material, 3d points list, etc).

In case of failure, an error string is returned.

©2023 All Rights Reserved.

axlAddAutoAssignNetAlgorithm

```
axlAddAutoAssignNetAlgorithm(t_algorithm t_displayName)
     ==> t/nil
```

Description

This function allows the user to add custom auto net assignment algorithms to the list in the Logic -> Auto Assign Net command's algorithms list in APD+. This list will always contain the Cadence standard algorithms (Router-Based, Nearest Match, and Constraint-Driven).

These names cannot be duplicate or overwritten by the customer.

Specifying a pair with either a duplicate algorithm or display name will cause the currently-existing (user) entry to be replaced.

Arguments

t_algorithm	Text string (case sensitive) containing the name of the SKILL function to be called for this algorithm. The function must take two parameters: First parameter: List of source pins. Second parameter: List of destination pins. The function should return "FAIL" if it was unable to complete due to some manner of code failure, or else should return a list of source pins that are still unassigned.
t_displayName	Text string (also case sensitive) that will be used as the name of this algorithm in the auto assign net command's pull-down menu for selecting the algorithm to use.

Value Returned

t if algorithm successfully registered.

`nil` if registration failed (function not defined, name in use, etc).

©2023 All Rights Reserved.

axlGetWireProfileDirection

```
axlGetWireProfileDirection(
     profileName
     )
     ==> "FORWARD"/"REVERSE"/nil
```

Description

This function returns the direction of a wire profile definition defined in the database. Profiles may be either forward or reverse. If the profile definition name provided does not exist in the design, the return value will be `nil`.

Arguments

`profileName`	The name of the wire profile to query the direction of.

Value Returned

- `"FORWARD"` for forward-bond wire profile definitions.
- `"REVERSE"` for reverse-bond wire profile definitions.
- `nil` if the wire profile definition does not exist in the database.

©2023 All Rights Reserved.

axlGetAllVisibleProfiles

```
axlGetAllVisibleProfiles()
     ==> list of profiles / nil
```

Description

Returns a list of all the bond wire profiles currently visible in the design.

Arguments

Nothing.

Value Returned

- list of profile names.
- `nil` if error or no profiles visible.

©2023 All Rights Reserved.

axlSetAllProfilesVisible

```
axlSetAllProfilesVisible(visible)
     ==> t / nil
```

Description

Turns all wire profiles in the design on or off.

Arguments

visible	`t` to turn all profiles on, `nil` to turn them off.

Value Returned

`t`/`nil` to indicate success or failure.

©2023 All Rights Reserved.

axlGetBondWireLength

```
axlSetBondWireLength(
     wire
     method
     )
     ==> length/nil
```

Description

Given a bonding wire object, this function returns the length of the wire, either as its 2D vector or its true 3D path.

Argument

`wire`	dbid of bond wire
`method`	Method of length calculation. Values can be `3D` or `2D`.

Value Returned

`length`	length in database unit
`nil`	if not a bond wire or method is not a valid value

©2023 All Rights Reserved.

axlLoadViaStructure

```
axlLoadViaStructure(
     t_vsName
     t_filePath
     )
     ==> o_vsDbid/nil
```

Description

Searches for via structure XML/EXML files in `PADPATH` and load the symbol into the database.

Note: To delete unused symdefs use `axlDeleteObject`.

Argument

`t_vsName`	Name of via structure symbol (in lower case).
`t_filePath`	Full path to the XML/EXML file.

Value Returned

`dbid`	Of symbol definition
`nil`	Cannot find file, improper file syntax, the license level is not applicable, symbol with provided name already exists.

Example

```
symdef = axlLoadViaStructure("VS_1" "./vs_1.exml")
```

See Also

axlDBCreateViaStructure

©2023 All Rights Reserved.

axlNetlistTextIn

```
axlNetlistTextIn(
     t_filename
     ?delim t_delim
     ?delimConsec b_consec
     ?delimTrail b_trail
     ?header g_header
     ?emptynet i_emptynet
     ?shape b_shape
     ?pins b_pins
     )
     ==> t/ErrorMsg/nil
```

Description

Imports a netlist using an ASCII spreadsheet of net information.

Note: This is a SKILL wrapper for the Netlist-In Wizard. Providing only a filename is equivalent to selecting an ASCII spreadsheet of net information and then clicking *Next* for the remaining steps in the Netlist-In Wizard. Post-import steps like purging unused nets are not done.

©2023 All Rights Reserved.

Arguments

t_filename	Specify the filename to be imported.
t_delim	Specify up to six delimiters to separate columns of data.
b_consec	Set to ignore consecutive delimiters.
b_trail	Set to ignore trailing delimiters.
g_header	Specify the list of header names to be imported. Must match the number of columns in the imported file.
i_emptynet	Specify how to treat empty net name. `0` to use the previous net, `1` to set a dummy net, and `2` to show an error.
b_shape	Set to update connected shapes.
b_pins	Set to update plated pins.

Value Returned

t/ErrorMsg/nil	Returns `t` if Netlist imported successfully. Returns `ERROR` message if an option is invalid. Returns `nil` if import is unsuccessful due to any reason other than an invalid option.

Example

```
axlNetlistTextIn("Netlist_data.txt")
axlNetlistTextIn("Netlist_data.txt" ?delim "\t" ?emptynet 0)
axlNetlistTextIn("Netlist_data.txt" ?delim "\t" ?delimConsec nil ?delimTrail t
    ?header '("Pin Number", "Net Name", "Ref Des")
    ?emptynet 0 ?shape nil ?pins nil)
```

See Also

axlBGATextIn, axlDieTextIn

©2023 All Rights Reserved.

axlPushConnectivity

```
list axlPushConnectivity(
     o_pin/l_pins
     ?ignoreFixedNets
     ?purgeUnusedNets
     )
     ==> t/nil
```

Description

This function is a SKILL-callable function wrapper to the *Logic – Push Connectivity* command. Provided with a set of pins, for each pin, the connectivity analyzer will look for items that are overlapped or connected and then move them to the net of the pin.

If *`ignoreFixedNets`* is `t`, then any item encountered which has a current net owner and is fixed will be moved to the net of the pin. Propagation of the net assignment will continue through this branch. The default is to stop pushing the connectivity changes when a fixed net assignment is encountered.

If *`purgeUnusedNets`* is `t` and all processing is complete, the `purge unused nets command` will be run to remove any now-unassigned nets from the database.

©2023 All Rights Reserved.

Arguments

l_pins	Single pin, or list of pins to use as the starting elements for connectivity pushing.
ignoreFixedNets	Boolean keyword flag for whether to allow assignment changes to items whose nets have the FIXED property. The default is `nil`.
purgeUnusedNets	Boolean keyword flag for whether to run purge unused nets on the database after push is completed. The default is `nil`.

Value Returned

t	Push connectivity was run
nil	Push connectivity was not run. Reason printed to the Command window.

Example

```
; Push connectivity from all the pins on the first component in the design.
pins = car(axlDBGetDesign()->components)->pins
axlPushConnectivity(pins)
```


©2023 All Rights Reserved.

axlSetBondWireProfile

```
axlSetBondWireProfile(
     bondWires
     profileName
     )
     ==> t/nil
```

Description

This command allows you to change the bond wire profile on one or more bond wires in the design. The bond wire profile definition must already exist in the design.

Note: Changing a wire's profile changes not just the profile name, but also the wire's material and its diameter or width to match the new profile definition.

Argument

`bondWires`	either a dbid or a list of dbids representing the bond wires to be modified.
`profileName`	the name of the new bond wire profile to assign to the bond wire(s).

Value Returned

`t`	if profile is defined and one or more bond wires were modified.
`nil`	if an error occurred or no bond wires were modified.

Note: It is much more efficient to assign a wire profile to all bond wires, which should be set to that profile, in a single call to this function, than to call the function on each individual bond wire.

©2023 All Rights Reserved.

axlImportWireProfileDefinitions

```
axlImportWireProfileDefinitions(
     xmlFileName
     setAsMaster
     )
     ==> x/nil
```

Description

This function will import the bond wire profiles defined in the xml file specified. If a profile is defined both in the XML file and in the current design, the design's definition will be updated to match the new definition being imported.

Argument

xmlFileName	The name of the XML file on disk which includes the bond wire profile definitions to be read. If not in the current working directory, this should include the absolute or relative path to the XML file.
setAsMaster	If true, this XML file will be set as the master profile definitions file for this database. The master file is where the user can refresh profile definitions from if they are changed. Only one file is allowed to be the master.

Value Returned

- `x`, the number of profile definitions successfully imported.
- `nil` if an error occurred (message printed to status window).

©2023 All Rights Reserved.

axlSetBondWireProfile

```
axlSetBondWireProfile(
            bondWires
            profileName
         )
         ==> t/nil
```

Description

This command allows you to change the bond wire profile on one or more bond wires in the design. The bond wire profile definition must already exist in the design. Note that changing a wire's profile will change not just the profile name, but also the wire's material and its diameter or width to match the new profile definition.

Note: It is much more efficient to assign a wire profile to ALL bond wires which should be set to that profile in a single call to this function, than to call the function on each individual bond wire.

Argument

bondWires	either a dbid or a list of dbids representing the bond wires to be modified.
profileName	the name of the new bond wire profile to assign to the bond wire(s).

Value Returned

- `t`, if profile is defined and one or more bond wires was modified.

`nil` if an error occurred or no bond wires were modified.

©2023 All Rights Reserved.

axlSetDieStackData

```
axlSetDieStackData (
     g_stackId
     s_dataType
     g_newValue
     )
     ==> t/nil
```

Description

This function sets the given data for the specified die.

Note: The command is available only in APD+.

Arguments

g_stackId	Name or dbid of the die stack to get the data for.

s_dataType	Data type of the given value, one of the following:
	`'(DSA_CAVITY_DEPTH`
	`DSA_CAVITY_LAYER`
	`DSA_CAVITY_DIMENSION)`

g_newValue	New value for the specified data type.

Value Returned

`t` on success, otherwise `nil`

©2023 All Rights Reserved.

axlDBIsDieStackLayer

```
axlDBIsDieStackLayer (
     t_layerName
     )
     ==> t or nil
```

Description

Verifies if layer is a die stack layer. This means that the attribute of the `"paramLayer"` parameter *`dbid`* called `"type"` has a value of `"DIESTACK"`. This is normally used in the APD product.

Arguments

`t_layerName`	Layer name `"CONDUCTOR/<subclass>"`

Note: CONDUCTOR is ETCH in Allegro PCB Editor.

Value Returned

`t`	die stack layer
`nil`	If not.

See Also

axlDBIsDiePad

Examples

```
axlDBIsDieStackLayer("CONDUCTOR/TOP_COND") -> nil
```


©2023 All Rights Reserved.

axlGetDieData

```
axlGetDieData (
     g_dieId
     )
     ==> die-data defstruct/nil
```

Description

Gets the data for the given die and loads it into the a defstruct.

Only available in APD+.

Arguments

`g_dieName`	`refdes` or `dbid` of the given die.

©2023 All Rights Reserved.

Value Returned

`dieData`	defstruct with data for the given die.
`nil`	Die does not exist or there was an error.

*defstruct fields*Example

`dbid`	dbid of die
`refId`	die refdes
`memberType`	DSA_DIE
`stackName`	parent die-stack name
`stackPosition`	integer position of member in stack
`layerName`	die pad layer
`dieThickness`	die thickness (flipchip bumps not included)
`totalThickness`	die thickness (flipchip bumps included)
`stackHeightMin`	starting height within stack
`stackHeightMax`	ending height within stack
`origin`	die symbol x/y location
`rotation`	rotation angle in degrees
`extents`	unioned extents of all members in stack
`type`	one of DSA_DIE_STANDARD or DSA_DIE_CODESIGN
`attachType`	one of DSA_DIE_FLIPCHIP or DSA_DIE_WIREBOND
`orientation`	one of DSA_DIE_CHIPUP or DSA_DIE_CHIPDOWN
`bumpDiamAtPkg`	flipchip bump diameter at package
`bumpDiamAtDie`	flipchip bump diameter at die
`bumpDiamMax`	flipchip bump diameter maximum
`bumpHeight`	flipchip bump height
`bumpEcond`	flipchip electrical conductivity w/units

```
data = axlGetDieData("FLIPCHIP_1")
printf("stack-pos = %L, layer-name = %L, attach-type  = %L\n"
```


©2023 All Rights Reserved.

```
          data->stackPosition  data->layerName data->attachType)


==> stack-pos = 1, layer-name = "TOP_COND", attach-type = DSA_DIE_FLIPCHIP
```


©2023 All Rights Reserved.

axlGetDieStackData

```
axlGetDieStackData (
     g_stackArg
     )
     ==> stack-data defstruct/nil
```

Description

Gets the data for the given die-stack and loads it into a defstruct.

Only available in APD+.

Arguments

`g_stackArg`	name or *`dbid`* of the given die-stack

Value Returned

`stackData`	defstruct with data for the given die stack.
`nil`	Die stack does not exist or there was an error.

defstruct fields:

`dbid`	dbid of member
`refId`	member name
`surface`	one of DSA_SUBSTRATE_CAVITY_TOP, DSA_SUBSTRATE_CAVITY_BOTTOM DSA_SUBSTRATE_TOP, DSA_SUBSTRATE_BOTTOM,
`depth`	for cavity-placed dies, gives the number of layers below the surface the stack is placed
`cavityClearance`	For cavity-placed stacks, the clearance from the stack extents to the edge of the cavity on the lowest layer.
`cavityExpansion`	For cavity-placed stacks, the amount by which the cavity grows on each subsequent layer (the "width" of the stadium step).
`stackHeightMin`	starting height within stack
`stackHeightMax`	ending height within stack

©2023 All Rights Reserved.

`rotation`	rotation angle in degrees
`extents`	unioned extents of all members in stack

Example

```
data = axlGetDieStackData("DIESTACK1")
printf("name = %L, minHeight = %L, maxheight = %L\n"
data->name data->stackHeightMin data->stackHeightMax)

==> name = "DIESTACK1", minHeight = 0.0, maxheight = 496.0
```


©2023 All Rights Reserved.

axlGetDieStackMemberSet

```
axlGetDieStackMemberSet()
     ==> list of die-stack member defstructs/nil
```

Description

Returns a list of defstructs - one for each member of the given die stack.

Only available in APD+.

Arguments

`g_stackArg`	name or *`dbid`* of the die stack

Value Returned

`l_data`	List of die-stack member data defstructs
`nil`	in case of an error

defstruct fields:

`dbid`	*`dbid`* of member
`refId`	member name
`memberType`	one of DSA_DIE, DSA_SPACER, DSA_INTERPOSER
`stackPosition`	integer position of member in stack
`layerName`	etch object subclass of member
`nextMemberOnSameLayer`	flag indicating next member on same layer
`prevMemberOnSameLayer`	flag indicating previous member on same layer

Example

```
data = axlGetDieStackMemberSet("DIESTACK1")

foreach(member data
```


©2023 All Rights Reserved.

```
          printf("refId = %L, memberType = %L\n" member->refId
          member->memberType)
)
==> refId = "FC1", memberType = DSA_DIE
          refId = "IPOSER_1", memberType = DSA_INTERPOSER
          refId = "WB1", memberType = DSA_DIE
          refId = "SPACER_1", memberType = DSA_SPACER
          refId = "WB2", memberType = DSA_DIE
```


©2023 All Rights Reserved.

axlGetDieStackNames

```
axlGetDieStackNames() ==> list of die-stack names/nil
```

Description

Returns a list of the names of all die stacks in the current design.

Only available in APD+.

Arguments

None

Value Returned

List of die-stack names or `nil` if none exist

©2023 All Rights Reserved.

axlGetIposerData

```
axlGetIposerData(
     g_iposerId
     )
     ==> iposer-data defstruct/nil
```

Description

This function fetches the data for the given iposer and loads it into a defstruct.

Important

Only available in APD+.

Arguments

`g_iposerName`	name or *`dbid`* of the given interposer

Value Returned

`iposerData`	defstruct with data for the given iposer.
`nil`	iposer does not exist or there was an error.

defstruct fields:

`dbid`	*`dbid`* of interposer
`refId`	interposer ref-id
`memberType`	DSA_INTERPOSER
`stackName`	parent die-stack name
`stackPosition`	integer position of member in stack
`layerName`	etch-object layer (vias/clines/shapes)
`totalThickness`	dielectric + conductor thickness
`stackHeightMin`	starting height within stack
`stackHeightMax`	ending height within stack
`origin`	interposer symbol x/y location

©2023 All Rights Reserved.

`rotation`	rotation angle in degrees
`extents`	unioned extents of all members in stack
`dielMatl`	name of dielectric material used for substrate
`dielThickness`	thickness of dielectric material
`condMatl`	name of conductor material used for etch objects
`condThickness`	thickness of conductor material

Example

```
data = axlGetDieData("IPOSER_1")
printf("stack-pos = %L, layer-name = %L, thickness = %L\n"
          data->stackPosition  data->layerName data->totalThickness)

==> stack-pos = 4, layer-name = "IP1", thickness = 106.0
```


©2023 All Rights Reserved.

axlGetSpacerData

```
axlGetSpacerData(
     g_spacerId
     )
     ==> spacer-data defstruct/nil
```

Description

Gets the data for the given spacer and loads it into a defstruct.

Important

Only available in APD+.

Arguments

`g_spacerName`	name or *dbid* of the given spacer

Value Returned

`spacerData`	defstruct with data for the given spacer.
`nil`	Spacer does not exist or there was an error.

defstruct fields:

`dbid`	*`dbid`* of spacer
`refId`	spacer ref-id
`memberType`	DSA_INTERPOSER
`stackName`	parent die-stack name
`stackPosition`	integer position of member in stack
`layerName`	etch-object layer (vias/clines/shapes)
`totalThickness`	dielectric + conductor thickness
`stackHeightMin`	starting height within stack
`stackHeightMax`	ending height within stack
`origin`	spacer symbol x/y location

©2023 All Rights Reserved.

`rotation`	rotation angle in degrees
`extents`	unioned extents of all members in stack
`dielMatl`	name of dielectric material used for substrate
`dielThickness`	thickness of dielectric material

Example

```
data = axlGetDieData("SPACER_1")
printf("stack-pos = %L, layer-name = %L, diel-matl  = %L\n"
          data->stackPosition data->layerName data->dielMatl)

==> stack-pos = 4, layer-name = "SP1", diel-matl = "PHENOLIC"
```


©2023 All Rights Reserved.

axlGetWireProfileColor

```
axlGetWireProfileColor(t_profile)
     ==> color index / nil
```

Description

This function will retrieve the color index associated with a bond wire profile. If no profile matching the name supplied is found in the database, nil is returned.

Arguments

`t_profile`	Name of profile to retrieve color for.

Value Returned

Color number assigned to profile if the profile is found.

`nil` if an error occurred or profile not found.

©2023 All Rights Reserved.

axlGetWireProfileVisible

```
axlGetWireProfileVisible(t_profile)
     ==> t / nil
```

Description

This function will retrieve the visibility status of a bond wire profile. If no profile matching the name supplied is found in the database, nil is returned.

Arguments

`t_profile`	Name of profile to retrieve color for.

Value Returned

`t`: if wire profile exists and is visible.

`nil`: if profile is invisible or does not exist.

©2023 All Rights Reserved.

axlPackageDesignCheckAddCategory

```
axlPackageDesignCheckAddCategory(
     t_name
     t_bitmap
     t_description)
     ==> g_category / nil
```

Description

This function will register a new category inside the *package integrity* command check tree of APD+.

You must define a category before adding checks to it. So, this function should always be called prior to axlPackageDesignCheckAddCheck.

A newly added category will be inserted into the tree in alphabetically sorted order. Therefore, you do not need to manage the order categories are added by yourself.

Note: If the category name already exists, it will not be redefined.

Arguments

t_name	Name of the category of checks as it should appear in the user interface. This name should be used when calling axlPackageDesignCheckAddCheck to add specific checks.
t_bitmap	Name of the bitmap file which should be shown when this check category is active in the user interface. This should be a full path to the bitmap or else the bitmap must be resolvable through BMPPATH.
t_description	The description to be displayed in the GUI when this category is highlighted.

Value Returned

g_category	SKILL defstruct defining the category.

See Also

axlPackageDesignCheckAddCheck

©2023 All Rights Reserved.

Example

The following example add a new integrity check category for subsequent addition of user-defined rules:

```
axlPackageDesignCheckAddCategory(
     "User-Defined Rules" "user_defined.bmp" "Descriptive Text"
     )
     ==> g_category
```

The next time the Package Integrity Check tool is run, a new category will be shown, named "User-Defined Rules".

©2023 All Rights Reserved.

axlPackageDesignCheckAddCheck

```
axlPackageDesignCheckAddCheck(
     t_category t_name t_bitmap t_description
     s_runCommand g_fixable
     ) ==> defstruct defining check.
```

Description

This function will register a new check in the specified category of the *package integrity* command check tree of APD+.

You must define a category before adding checks to it. So, this function should always be called after axlPackageDesignCheckAddCategory.

A newly added check will be inserted into the tree in alphabetically sorted order. Therefore, you do not need to manage the order checks are added by yourself.

`s_runCommand` is the SKILL function which should be called if this check is selected to run. This function MUST adhere to the following guidelines:

1. It must take exactly one argument, which is whether to fix errors it encounters or not.
2. It must return an integer value for how many errors were found in the database.
3. It must call the following functions:

   ```
   axlPackageDesignCheckLogError(<error string> <fixed>)
   ```

   and

   ```
   axlPackageDesignCheckDrcError(<error location> <dbids>)
   ```

   to report any errors it finds.

These restrictions are imposed to ensure that output is consistent across all checks run by this command.

©2023 All Rights Reserved.

Arguments

t_category	Name of the category this check should be placed under in the user interface tree. This should be the same name as sent to axlPackageDesignCheckAddCategory.
t_name	Name of the check as it should appear in the user interface. This will be the name given to the check in the resulting log file, and will be the description for any external DRCs created.
t_bitmap	Name of the bitmap file that should be shown when this check is active in the user interface. This should be a full path to the bitmap or else the bitmap must be resolvable through *BMPPATH*.
t_description	The description to be displayed in the GUI when this check is highlighted. This description will also be printed to the log file ahead of any violations found for this check. As a result, the description should be as descriptive as possible in order to maximize its usefulness.
s_runCommand	A symbol representing the function to be called to check this rule. See FUNCTION description for details about the required format and return value of this function.
g_fixable	Boolean flag to tell the user on the interface whether problems found by this check can be automatically fixed or not.

Value Returned

g_check	SKILL defstruct defining the check.

Example

The following example adds a new integrity check to the "User-Defined Rules" category in the Package Integrity Check user interface.

```
axlPackageDesignCheckAddCheck(
     "User-Defined Rules" "My First Rule" "user_defined.bmp"
     "Descriptive Text" 'myCheckFunction t)
     )
     ==> g_check
```

The next time the Package Integrity Check tool is run, "My First Rule" will be available under the "User-Defined Rules" category.

©2023 All Rights Reserved.

See Also

axlPackageDesignCheckAddCategory, axlPackageDesignCheckLogError, axlPackageDesignCheckDrcError

©2023 All Rights Reserved.

axlPackageDesignCheckDrcError

```
axlPackageDesignCheckDrcError(l_location o_dbids)
     ==> nil
```

Description

This function will create an external DRC marker for an error found by the currently running package integrity check. The tool itself will track the check being run so that it knows the name to use for the rule violation.

Arguments

l_location	Location at which to place the DRC marker.
o_dbids	Optional list of database object ids that are associated with this error. Usually 0-2 objects are affected.

Value Returned

`nil`

Example

The following example creates a DRC marker about a missing via found with a fictional rule. In this case, since the via is missing, no dbids for objects are passed in:

```
axlPackageDesignCheckDrcError((0.0 0.0) nil)
     ==> nil
```

In the canvas, an external DRC marker is created at (0.0 0.0) with the name of the user-defined rule that generated the error.

See Also

axlPackageDesignCheckAddCheck, axlPackageDesignCheckLogError

©2023 All Rights Reserved.

axlPackageDesignCheckLogError

```
axlPackageDesignCheckLogError(
     t_errorString
     g_fixed
     g_location)
     ==> nil
```

Description

This function will log an error found by this function to the log file if the log file is enabled. By using this interface, you are ensuring that the API will format your message consistently.

Arguments

t_errorString	String to be printed to the log file. This should have all variable substitutions already done and be a simple string. This function will take care of any formatting necessary.
g_fixed	Boolean indicating whether the error was fixed by the tool.
g_location	Location where the error occurred, if applicable. This is appended to your log entry for you, and is used to let the user zoom to the error location in the design. If the location is unknown or not applicable, pass nil for the location.

Value Returned

`nil`

Example

The following example logs an error about a missing via found with a fictional rule. The error was not fixed by the caller:

```
axlPackageDesignCheckLogError("Missing via" nil (0.0 0.0))
     ==> nil
```

In the log file, the following is printed under the heading of the user-defined rule that found it:

```
"- Missing via at (0.0 0.0)"
```


©2023 All Rights Reserved.

See Also

axlPackageDesignCheckAddCheck, axlPackageDesignCheckDrcError

©2023 All Rights Reserved.

axlSetDieData

```
axlSetDieData(
     g_dieId
     s_dataType
     g_newValue
     )
     ==> t/nil
```

Description

Sets the given data for the given die.

Important

Only available in APD+.

©2023 All Rights Reserved.

Arguments

`g_dieName`	name or *`dbid`* of the die to get the data for

`s_dataType`	data type of the given value, one of:
	`'(DSA_BUMP_PACKAGE_DIAM_DBREP`
	`DSA_BUMP_PACKAGE_DIAM_STRING`
	`DSA_BUMP_DIE_DIAM_DBREP`
	`DSA_BUMP_DIE_DIAM_STRING`
	`DSA_BUMP_MAX_DIAM_DBREP`
	`DSA_BUMP_MAX_DIAM_STRING`
	`DSA_BUMP_HEIGHT_DBREP`
	`DSA_BUMP_HEIGHT_STRING`
	`DSA_BUMP_ECOND_STRING`
	`DSA_DIE_THICKNESS_DBREP`
	`DSA_DIE_THICKNESS_STRING`
	`DSA_LAYER)`

`g_newValue`	new value for the specified data type.

Value Returned

`t` on success, otherwise `nil`

©2023 All Rights Reserved.

axlSetDieType

```
axlSetDieType(
     o_componentDBID
     t_dieType
     )
     ==> t/nil
```

Description

This function sets the attachment type for a die component to one of the available types. Currently, the supported attachment types are:

- WIREBOND
- FLIP CHIP

Arguments

o_componentDBID	dbid handle of the die component to be configured.
t_dieType	Attachment type to configure this component as. Supported values are "WIREBOND" and "FLIP CHIP".

Value Returned

t	if successful.
nil	if failed (non-die object passed or not packaging product).

Example

```
axlSetDieType(myComp "WIREBOND")
            ==> t
```


©2023 All Rights Reserved.

axlSetIposerData

```
axlSetIposerData(
     g_iposerId
     s_dataType
     g_newValue
     )
     ==> t/nil
```

Description

Sets the given data for the given iposer.

Only available in APD+.

Arguments

`g_iposerName`	name or *`dbid`* of the given iposer

`s_dataType`	data type of the given value, one of:
	`'(DSA_CONDUCTOR_MATERIAL`
	`DSA_CONDUCTOR_THICKNESS_DBREP`
	`DSA_CONDUCTOR_THICKNESS_STRING`
	`DSA_DIELECTRIC_MATERIAL`
	`DSA_DIELECTRIC_THICKNESS_DBREP`
	`DSA_DIELECTRIC_THICKNESS_STRING`
	`DSA_PART_NUMBER)`

`g_newValue`	new value for the specified data type

Value Returned

`t` on success, otherwise `nil`

©2023 All Rights Reserved.

axlSetSpacerData

```
axlSetSpacerData(
     g_spacerId
     s_dataType
     g_newValue
     )
     ==> t/nil
```

Description

This function sets the given data for the given spacer.

Important

Only available in APD+.

Arguments

`g_spacerName`	name or dbid of the spacer to get the data for
`s_dataType`	data type of the given value, one of: `'(DSA_DIELECTRIC_MATERIAL DSA_DIELECTRIC_THICKNESS_DBREP DSA_DIELECTRIC_THICKNESS_STRING DSA_PART_NUMBER)`
`g_newValue`	new value for the specified data type.

Value Returned

`t` on success, otherwise `nil`

©2023 All Rights Reserved.

axlSetWireProfileColor

```
axlSetWireProfileColor(t_profile n_color)
     ==> t / nil
```

Description

This function will set the color of a wire profile to the given value.

Arguments

`t_profile`	Name of profile to retrieve color for.
`n_color`	Color index to assign to the profile.

Value Returned

t, if successful.

`nil`, if error (profile does not exist).

©2023 All Rights Reserved.

axlSetWireProfileVisible

```
axlSetWireProfileVisible(t_profile g_visible)
     ==> t / nil
```

Description

This function will make the identified wire profile visible or invisible.

Arguments

`t_profile`	Name of profile to retrieve color for.
`g_visible`	t for visible, nil for invisible.

Value Returned

- `t`, if successful.
- `nil`, if error (profile does not exist).

©2023 All Rights Reserved.

axlShapeEraseDegassingHole

```
axlShapeEraseDegassingHole(
     o_shape
     ?location <pt>
     ?window list(<minXY> <maxXY>)
     )
```

⇒ t/nil

Description

This function erases the advanced degassing hole at the location or the box for a shape.

Arguments

o_shape	Shape for which advanced degassing hole is to be erased
location	The xy coordinates of a location indicate the area where the erase takes place
window	The xy coordinates of a window indicate the area where the erase takes place

Value Returned

t	If successful
nil	If fail

Example

- The following example shows a single location erase:

```
axlShapeEraseDegassingHole(shape ?location '(-3925.000 -13050.000))
```

- The following example shows a window erase:

```
axlShapeEraseDegassingHole(shape ?window list('(-3800.000 -13150.000) '(-
2275.000 -11975.000)))
```


©2023 All Rights Reserved.

axlCDLNetlistSetValue

```
axlCDLNetlistSetValue(
     s_field
     [g_value]
     [b_locked]
     [t_padStack]
     )
     ⇒ nil
```

Description

Configures a value in the CDL Netlist Out command of the `cdl out` command used to export CDL (Circuit Description Language). Use this function to automate the CDL Netlist Out form usually by also registering a trigger with the `axlTriggerSet()` command for the `'open` event. Using this function along with the trigger, you can pre-configure the CDL Netlist Out form based on your requirements, the contents of the active design, and so on.

©2023 All Rights Reserved.

Arguments

s_field	Name of the field to be configured. If `nil`, returns a list of all fields that are supported.
g_value	Value to set in the field. The value should match the type of value stored in the specified field. For example, for resistance, this is a numeric value. For the resistor checkbox column, this is a boolean.
b_locked	If passed, a boolean value indicates whether the field value can be modified or not. If true, the field gets locked from any interactive editing.
t_padStack	If configuring a row of the table in the form, for modifying padstack entry. `nil` sets the *All* rows.

Value Returned

`t`	If successful, when configuring a value.
`nil`	Is passed for *s_field,* returns a list of fields, which may be set.

Example

To set the name of the CDL netlist file to be written and prevent the user from modifying it:

```
;// File name should match current db name with extension of cdl.
fileName = strcat(axlCurrentDesign() ".cdl")
;// Prevent user from interactively editing value set by automation.
axlCDLNetlist('outputFileName fileName t)
```


©2023 All Rights Reserved.

©2023 All Rights Reserved.

10

User Interface Functions

This chapter describes the AXL/SKILL functions you use to confirm intent for an action, prompt for text input, display ASCII text files, and flush pending changes in the display buffer.

Window Placement

Allegro PCB Editor encourages you to place windows in an abstract manner. For example, when you open a form, instead of specifying (*x,y*) coordinates you give a list of placement options. Allegro PCB Editor then calculates the placement location. An advantage of this method is that all windows automatically position themselves relative to the main Allegro PCB Editor window. Windows always position entirely onscreen even in violation of your placement parameters.

The following form placement options (strings with accepted abbreviations in parentheses) are available:

```
north(n)northeast(ne)east(e)southeast(se)
south(s)southwest(sw)west(w)northwest(nw)
center(c)
```


©2023 All Rights Reserved.

In addition you can modify the placement options with the following parameters:

`Inner` or `Outer`	Places the placement rectangle to the outside or the inside of the main window. The default is `inner`.
`Canvas` or `Window`	Uses the canvas (drawing) area or the entire window for the placement rectangle.The default is `Window`.
`Border` or `NoBorder` (Default `Border`)	Leaves a slight border around the placed window. If `noborder` is set, the window is set directly against the placement rectangle. The default is `Border`.
`MsgLines` (Default 1)	Sets the number of message lines at bottom of the placed window to 0 or 1. **Note:** Only `forms` supports this parameter. **Syntax:** `msglines #`

Using Menu Files

You can use drawing menus, symbol menus, and shape menus in Allegro PCB Editor. Allegro tools typically support three menus; drawing, symbol and shape. The Allegro command set is very different between these three design editors. Also menu sets exist for different tools such as APD+ and the SI (Signal Integrity) products.

All of the tiering (product levels) within a product are managed via the "#ifdef" statements within a single menu file. Typically, the settings of environment variables controlling the tiering are documented at the top of file.

Note: You cannot strip out the `#ifdef` statements to gain access to the missing commands.

Allegro finds the menus with its MENUPATH environment variable. You can find the default Allegro PCB Editor menu files in:

```
<cdsroot>/share/pcb/text/cuimenus
```

Caution

As new products are added in a release, new menu files may be added. Cadence may change the name of any menu file in a release.

©2023 All Rights Reserved.

The menus in this directory are as follows (due to the tools and software version you have loaded, some may not be present in your installation). You should not modify any other file type in this directory as only the menu files are supported for user modification.

Table 10-1 Allegro PCB Editor Menu Files

File Name	Description
`allegro.men`	Allegro PCB Editor menu for all Allegro PCB Editor `.brd` designs
`pcb_symbol.men`	Symbol menu for PCB products
`partition.men`	Partition menu for PCB products
`specctraquest.men`	PCB SI menu
`apd.men`	APD+ menu
`icp_symbol.men`	APD+ symbol editor menu
`apd_partition.men`	APD+ Partition editor menu
`apd_si.men`	APD+ SI menu
`padlayout.men`	Pad Designer in the board graphics editor
`padlaystn.men`	Pad Designer (standalone)
`allegro_free_viewer.men`	Allegro Free Viewer
`viewlayout.men`	Allegro Viewer Plus

Menu Terms

- Menu bar - the menu items seen at the top of a Window
- Menu item - a menu line; may either be a command, separator or a submenu.
- Separator - a horizontal line drawn to visually group menu items.
- Submenu - a pulldown (from the menu bar) or a pull-right (from another submenu). Submenus may only have a display and command association is not supported.

Menu Design Considerations

- Certain dynamic items may exist. These are currently the MRU (most recently used files) and Quick reports.

  Do not attempt to modify these items.

©2023 All Rights Reserved.

- Do not use spaces in the display for the menu bar.
- All menu bar items should be submenus. Do not add a command menu item at this level.
- Do not add excessive items to the menu bar. If the menu bar displays on two lines for a typical window width you may have too many items.
- Keep the display text relatively short, especially on the menu bar.

MENU CUSTOMIZATION METHODS

- Provide your own customization menu via CDS_SITE. Replace the Cadence provided menu (.men file) with your own.
  - Advantages: Relatively easy and no SKILL programming required.
  - Disadvantages: For new releases need to merge your menu changes with new Cadence menus. May need to modify multiple menus
- Overload your menu customizations on Cadence menus via SKILL axlUIMenuRegister.
  - Advantages: Relatively easy with minimal SKILL programming. Depending on your site's additions may be immune to many Cadence menu changes.
  - Disadvantages: Cannot delete Cadence menu items or restrict your changes to a one Cadence menu.
- Register a axl menu Trigger notification via axlTriggerSet.
  - Advantages: Almost as much flexibility as overriding the default menu file including targeting specific menus.
  - Disadvantages: Need to examine your SKILL code with new Cadence releases. Requires much more SKILL programming knowledge.

Dynamically Loading Menus

All tools support overriding their default menus by putting your menu file before the default Cadence menu file via the `MENUPATH`. Programs that support AXL-SKILL allow menus to be dynamically changed while the program is running. You do this using the `axlUIMenuLoad` SKILL function. This is not supported in *`allegro_pcb`* and *allegro_viewer*.

Tools support dynamically (via SKILL) modifying menus. For information, see axlUIMenuFind.

©2023 All Rights Reserved.

Understanding the Menu File Format

You can have only one menu definition per file. The following shows the menu syntax in BNF format. The use of indentation reflects hierarchy in the `.men` file.

Menu file grammar reflects the following conventions:

Convention	Description
`[ ]`	Optional
`{ }`	May repeat one or more times.
`< >`	Supplied by the user
`|`	Choose one or the other
`:`	Definition of a token
`CAPS`	Items in caps are keywords

©2023 All Rights Reserved.

The following defines the menu file format:

```
FILE:
        [comment]
        [ifdef]
        <name>MENU DISCARDABLE
        BEGIN
            {popup}
        END

popup:
    POPUP "<display>"
    BEGIN
        {MENUITEM "<display>"‟<command>}
        [{separator}]
        {[popup]}
    END

{[//]}- comment lines

separator:
    MENUITEM SEPARATOR
        - this inserts a separator line at this spot in the menu. This is not
            supported at the top level menubar.
name:This text is ignored. Use the file name without the extension.
comment:Double slash (//) can be used to start a comment.
display:Text shown to the user.
        & -This is used to enable keyboard access to the menus. For this to work,
                each menu level must have a unique key assigned to it. Use double
                ampersand (&&) to display a "&".
    ... -The three dots convention signifies that this command displays a form.
command:This is any Allegro command, sequence of Allegro commands, or Skill
           statement.The Allegro command parser acts on this statement so it offers
           considerable flexibility. The command should be placed within a set of
           double quotes (”). Double quotes are not supported within this command
           string.
ifdef:Use #ifdef/#endif and #ifndef/#endif to make items conditionally appear in
           the menu, depending on whether or not a specified environment variable
           is set.
    An #ifdef causes the menu item(s) to be ignored unless the environment variable
           is set. A #ifndef causes the menu item(s) to be ignored if the
           environment variable is not set. You must have one #endif for each #ifdef
           or #ifndef to end the block of conditional menu items. Also, #ifdef,
           #ifndef, and #endif must start at the first column of the line in the
           menu file.
    The #ifndef is the negation of #ifdef.
```


©2023 All Rights Reserved.

```
>               environment variable is set.  A #ifdef will cause the menu item(s)
>               to be ignored if the environment variable is not set.  You must
>               have one #endif for each #ifdef or #ifndef to end the block of
>              conditional menu items.  Also,  the #ifdef, #ifndef and #endif must
>               start at the first column of its line in the menufile.
<               The condition syntax supports multiple variables with OR '||' or
<               AND '&&' conditions. Also the negation character '!' is supported
<               for the variables:
```


©2023 All Rights Reserved.

These statements may be nested. The simple syntax for `#ifdef` follows:

```
#ifdef <env variable name>
[menu items which appear if the env variable is set]
#endif

#ifndef <env variable name>
[menu items which appear if the env variable is not set]
#endif

<                 # logically equivalent to above state using negation character
<                 #ifdef !<env variable name>
<                 [menu items which appear if the env variable is NOT set]
<                 #endif
<
<             Also logical statements
<            1) if variable1 and variable2 are both set do the included statement
<                 #ifdef <var1> && <var2>
<                 [menu items which appear if both variables are set]
<                 #endif
<
<              2) if either variable1 or variable2 is do the included statement
<                 #ifdef <var1> || <var2>
<                 [menu items which appear if either variable is set]
<                 #endif
```

The items between the `#if[n]def/#endif` can be one or more `MENUITEMS` or could be a `POPUP`.

Example 1

```
#ifdef menu_enable_export
   POPUP "&Export"
   BEGIN
   MENUITEM "&Logic...", "feedback"
   END
#endif
```

The *Export* popup appears in the menu only if the `menu_enable_export` environment variable is set.

©2023 All Rights Reserved.

Example 2

```
#ifndef menu_disable_product_notes
  MENUITEM "&Product Notes", "help -file algpn"
#endif
```

The *Product Notes* menu item appears in the menu only if the `menu_disable_product_notes` environment variable is NOT set.

©2023 All Rights Reserved.

Example 3 - Simple Menu Example

```
        DISPLAY (indents reflect the various pulldown levels)
            FileHelp
                OpenContents
                ExportProduct Notes
                    LogicKnown Problems and Solutions
                Exit----------------------------
                    About Allegro...
FILE:
simple MENU DISCARDABLE
BEGIN
    POPUP "&File"
    BEGIN
        MENUITEM "&Open","open"
        POPUP "&Export"
        BEGIN
        MENUITEM "&Logic...","feedback"
        END
        MENUITEM "&Exit","exit"
    END
    POPUP "&Help"
    BEGIN
        MENUITEM "&Contents","help"
        MENUITEM "&Product Notes","help -file algpn"
        MENUITEM "&Known Problems and Solutions","help -file alkpns"
        MENUITEM SEPARATOR
        MENUITEM "&About Allegro...","about"
    END
END
```

A simple menu and the simple file required to display the menu.

©2023 All Rights Reserved.

AXL-SKILL User Interface Functions

This section lists the user interface functions.

axlCancelOff

```
axlCancelOff(
     )
     ⇒ t
```

Description

Disables checking when a user clicks *Cancel*. See axlCancelOn.

Arguments

`None`

Value Returned

Always returned `t`.

Example

See axlCancelOn

©2023 All Rights Reserved.

axlCancelOn

```
axlCancelOn(
     )
     ⇒ t
```

Description

Allows SKILL code to test for when a user clicks *Cancel*. When an operation is started that takes a long amount of time, enabling cancel allows a user to interrupt the operation by clicking on the Allegro traffic light or pressing the `Esc` key. The cancel checks are performed when the `axlCancelTest` function is called, allowing the SKILL code to determine the best time to abort an operation

When cancel is enabled, the traffic light is yellow.

Although you can nest cancel calls, you should make an equal number of cancel off calls as cancel on calls.

Note: To avoid problems, always place the cancel on/off call pairs in the same function.

These calls do not work from the SKILL or Allegro PCB Editor command line because Allegro PCB Editor immediately disables cancel when exiting the SKILL environment to prevent the system from hanging.

Notes:

- Only enable cancel processing when you are sure there is no user interaction. Having cancel enabled when the user has to enter information is not supported and will hang the system.
- Calling `axlCancelTest` can adversely impact your program's performance.

Arguments

`None`

Value Returned

Always returns `t`.

©2023 All Rights Reserved.

See Also

axlCancelSetFormClosable, axlCancelClearFormClosable

Examples

```
count = 0
    axlCancelOn()
    while(count < 50000 && !axlCancelTest()
        ;; Do work here.  We will break out of the loop if
        ;; the user requests a cancel.
        count++
    )
    axlCancelOff()
```


©2023 All Rights Reserved.

axlCancelTest

```
axlCancelTest(
     ⇒ t/nil
```

Description

See axlCancelOn.

Arguments

None

Value Returned

Only `axlCancelTest` returns meaningful data.

`t`	User click cancel.
`nil`	User did not click cancel.

See Also

axlCancelOn, axlCancelOff

Example

See axlCancelOn

©2023 All Rights Reserved.

axlCancelClearFormClosable

```
axlCancelClearFormClosable(
     o_form
     )
     ⇒ t/nil
```

Description

See axlCancelSetFormClosable.

Arguments

o_form	Form dbid

Value Returned

t	If form is not closable during cancel action processing
nil	If not

See Also

axlCancelOn, axlCancelOff, axlCancelTest, axlCancelSetFormClosable

Examples

See axlCancelSetFormClosable

©2023 All Rights Reserved.

axlCancelSetFormClosable

```
axlCancelSetFormClosable(
     o_form
     )
     ⇒ t/nil
```

Description

Allows a form to be closable during cancel checking.

When cancel processing is enabled by axlCancelOn, most UI events are ignored. As a result any attempts to close a form during a cancel check are also ignored. These functions allow the caller to specify that the given form can be closed during cancel processing.

Closing the form when cancel is enabled will be treated as a user-initiated cancel request.

The axlCancelClearFormClosable call should be made before the form is closed.

Arguments

o_form	Form dbid

Value Returned

`t`	If form is closable during cancel action processing
`nil`	If not

See Also

axlCancelOn, axlCancelOff, axlCancelTest, axlCancelClearFormClosable

Examples

```
;; Create form, set form as active during cancel, then enable cancel.
form = axlFormCreate((gensym) "my.form" '("C" "INNER") '_myFormCallback t)
axlCancelSetFormClosable(form)
axlCancelOn()

;; Do work, check for cancel between iterations.
```


©2023 All Rights Reserved.

```
count = 0;
while(count < 50000 && !axlCancelTest()
    ;; Do something here
    count++
)

;; Unset form as active during cancel, disable cancel, close form.
axlCancelClearFormClosable(form)
axlCancelOff()
axlFormClose(form)
```


©2023 All Rights Reserved.

axlClipboardGetText

```
axlClipboardGetText ()
     => t_text/nil
```

Description

This gets the current text in the system clipboard. Clipboard can contain data other than ASCII text in which case `nil` is returned.

Arguments

No arguments

Value Returns

t_text	Text in clipboard
nil	No text in clipboard

Examples

```
axlClipboardSetText("hello world")
```

```
text = axlClipboardGet()
```

See Also

axlClipboardSetText

©2023 All Rights Reserved.

axlClipboardSetText

```
axlClipboardSetText(
     t_text/nil
     )=> t/nil
```

Description

Sends indicated text to system clipboard. Only ASCII text is supported.

Arguments

t_text	Text string. If `nil` or an empty string is specified, clipboard is emptied.

Value Returns

t	Updated clipboard
nil	Failed

Examples

See example section of axlClipboardGetText

See Also

axlClipboardGetText

©2023 All Rights Reserved.

axlCursorGet

```
axlCursorGet (
     g_pixel
     ) ==> l_xy
```

Description

This command is used to obtain the current cursor position either in pixels (screen units) or converted into current design units. The mapping from pixels to design units takes into account the current window view and zoom factor of the design.

Accessing this in non-graphic mode is undefined.

Arguments

g_pixel	If the value is set to `t`, the xy coordinates are specified in pixels. If the value is set to `nil`, current cursor position as it stands in current design is returned.

Value Returned

The cursor position either in pixels (integer) or design units (floating point).

See Also

axlCursorWarp, axlUIControl

©2023 All Rights Reserved.

axlCursorWarp

```
axlCursorWarp (
     g_pixel
     l_xy
     ) ==> t/nil
```

Description

Use this command to set the cursor position. May set the cursor either by pixel or design units. If setting by design units the new value must be within the current viewable window (axlWindowBoxGet).

Note: See axlCursorGet for a discussion between pixel and design units.

Arguments

g_pixel	If t return xy in pixels else return cursor position where it stands in current design.
l_xy	The xy values may be specified in pixel (g_pixel=t) or design units (g_pixel=nil)

Value Returned

`t`	If moved cursor
`nil`	If bad arguments or moved cursor outside of main window.

See Also

axlCursorGet, axlWindowBoxGet

©2023 All Rights Reserved.

axlMeterCreate

```
axlMeterCreate(
          t_title
          t_infoString
          g_enableCancel
          [t_formname]
          [t_infoString2]
          [g_formCallback]
     -> t/nil
```

Description

Starts progress meter with optional cancel feature.

Note: Always call `axlMeterDestroy` when done with meter.

©2023 All Rights Reserved.

Arguments

t_title	Title bar of meter.
t_infoString	One line of 28 characters used for anything you want (can be updated at meter update).
g_enableCancel	`t` enable the application *Stop* button on graphical UI-based applications. When enabled and the user picks the *Stop* button, a true is returned by the call to axlMeterIsCancelled().
t_formname	(Optional) The name of an alternate form that can be used with these functions which has an info field named *progressText* and a progress field named *bar*. axlMeterIsCancelled will also notice if a *Cancel* menu button has been pressed. If you do not give a form name `axlprogress.form` will be used.
t_infoString2	(Optional) By Default "".
g_formCallback	(Optional) The name of a Callback function that you want called for any buttons or fillings etc you may have on your form. This works the same as `g_formAction` in axlFormCreate.

Value ReturnedSee Also

`t`	On success; otherwise `nil`.

axlMeterCreate, axlMeterIsCancelled, axlMeterDestroy and axlFormCreate

Example

```
axlMeterCreate("SigNoise Design Audit", "", t)
total = <total nets>
done = 0
while(<still next net> && (!axlMeterIsCancelled())
          < do work >
          axlMeterUpdate( (100 * ++done)/total
               sprintf(nil "Check %d of %d nets" done total))
)
axlMeterDestroy()
```


©2023 All Rights Reserved.

axlMeterDestroy

```
axlMeterDestroy() -> t/nil
```

Description

Closes the progress meter form and shuts off Cancel mode if enabled.

Arguments

None

Value Returned

`t`	If meter was destroyed; otherwise `nil`.

See Also

axlMeterCreate

©2023 All Rights Reserved.

axlMeterIsCancelled

```
axlMeterIsCancelled(
     ) -> t/nil
```

Description

If cancel was enabled at meter creation, the status of cancel is returned (`t` if cancelled; otherwise `nil`).

If a field named *Cancel* was hit, it is cancelled

Arguments

None

Value ReturnedSee Also

`t`	If meter was cancelled; otherwise `nil`.

`axlMeterCreate`

©2023 All Rights Reserved.

axlMeterUpdate

```
axlMeterUpdate(
     x_percentDone
     t_infoString
     [t_infoStr2]
     ) -> t/nil
```

Description

Updates progress meter bar and/or info text. The percent done and/or the info string may be updated.

Arguments

x_percentDone	Integer task percent done (0-100)
t_infoString	Update text for progress meter info text line. Value is one of: ■ nil - leave info text as it is. ■ "" - clear info string field.
newText	Update field with new text.
t_infoStr2	(optional) Text for second line.

Value Returned

`t`	On success; otherwise `nil`.

See Also

axlMeterCreate

©2023 All Rights Reserved.

axlUIAppMode

```
axlUIAppMode(
     S_mode
     t_appCommand]
     ) -> g_return
```

Description

Interacts with Allegro's application mode interface. Operation is driven by the first argument:

`'inAppMode`	Returns `t` if in application mode, `nil` in Idle mode
`'mode`	Returns application mode s a string, `nil` if in Idle mode
`'commands`	Returns the set of currently supported application modes. This depends upon the base product and sometimes the product options selected.
`'none`	Turns off application mode, Allegro is put in idle mode. Any dbids that are checked out remain active. Always returns `t`.
`'set`	Sets the application mode to string provided in argument 1. Any dbids are reclaimed (for example, dbid:removed). Returns `t` if app mode was set, `nil` if failure

Arguments

`S_mode`	See above
`t_appCommand`	Only applicable with 'set

Value Returned

`g_return`	Depends on *`S_mode`* see above `'inAppMode`

Examples

- Get application mode commands

  ```
  cmds = axlUIAppMode('commands)
  ```

- To check if an application mode is active

  ```
  amApp = axlUIAppMode('inAppMode)
  ```


©2023 All Rights Reserved.

- Set application mode to none (for example, Idle)

  ```
  axlUIAppMode('none)
  ```

- Set application mode to general edit

  ```
  axlUIAppMode('set "generaledit)
  ```


©2023 All Rights Reserved.

axlUIMenuLoad

```
axlUIMenuLoad (
     t_menufile

)⇒ t_previousMenuName/nil
```

Description

Loads the main window menu from the file *t_menuFile*. Adds a default menu file name extension if *t_menuFile* has none. The MENUPATH environment variable is used to locate the file if *t_menuFile* does not include the entire path from the root drive.

Note: The intent of this procedure is to allow a custom menu to be loaded for debugging purposes.

Arguments

t_menuFile	Name of the file to which the menu is dumped. If *t_menuFile* is nil, the file name is based on the program's default menu name, which may vary based on the current state of the program.

Value Returned

t_previousMenuName	Name of the previous menu.
nil	Menu not be located.

See Also

axlUIMenuFind

©2023 All Rights Reserved.

axlUIMenuDump

```
axlUIMenuDump (
     t_MenuFile
     [g_debug]
     ) ⇒ t_previousMenuName/nil
```

Description

Dumps the current menu of the main window to the *t_menuFile* file. Adds default menu file name extension if *t_menuFile* has none.

Notes:

- There is no user interaction when an existing file is overwritten.
- This function is for the Windows-based GUI only.

Arguments

t_menuFile	Name of the file to which the menu is dumped. If *t_menuFile* is `nil`, the file name is based on the program's default menu name, which may vary based on the current state of the program.
[g_debug]	If this is `'print` then, only the commands contained in the menu file are dumped out. Allows for easier comparison between old and new menu files.

Value Returned

t_previousMenuName	Full name of the file that is written.
`nil`	No file is written.

Note: The intent of this procedure is to provide a base menu file using which you can develop a customized menu.

©2023 All Rights Reserved.

axlUIColorDialog

```
axlUIColorDialog(
     r_window/nil
     l_rgb
     ) -> l_rgb/nil
```

Description

Invokes standard color selection dialog box. You must provide a parent window, Allegro PCB Editor defaults to the main window of the application. The *l_rgb* is a red, green, or blue palette list. Each item is an integer between the values of `0` and `255`. `0` indicates color is off, and a value of `255` indicates color is completely on. For example, `255 255 255` indicates white.

Arguments

r_window	Parent window. If `nil`, use main program window. Return handle of `axlFormCreate` is of type *r_window*.
l_rgb	Seeded red, green, or blue.

Value Returned

l_rgb	User selected values.
`nil`	User canceled dialog box.

See Also

axlColorSet, axlColorGet

Examples

Get color `1` and change it:

```
rgb = axlColorGet(1)
rgb = axlUIColorDialog(nil rgb)
when(rgb
axlColorSet(1 rgb)
axlVisibleUpdate(t))
```


©2023 All Rights Reserved.

axlUIConfirm

```
axlUIConfirm(
     t_message
     [s_level]
     )
     ==> t
```

Description

Displays the string *t_message* in a confirmer window.

The user must respond before any further interaction with Allegro PCB Editor. Useful mainly for informing the user about a severe fatal error before exiting your program. Use this blocker function very rarely.

Note: If environment variable `noconfirm` is set, we immediately return.

Arguments

t_message	Message string.
s_level	Option level symbol; default is info level, other levels are `warn` and `error`.

Value Returned

`t`	Always returns `t`.

Example

Inform user when a significant transition is being made:

```
axlUIConfirm( "Returning to Allegro. Please confirm." )
```

Alert user to an error:

```
axlUIConfirm( "Selected object has FIXED property." 'error )
```

See also

axlUIPrompt, axlUIYesNo, axlUIYesNoCancel, axlUIConfirmEx

©2023 All Rights Reserved.

axlUIConfirmEx

```
axlUIConfirmEx(
     t_message
     t_key/nil
     [s_level]
     )
     ==> t
```

Description

Displays the string `t_message` in a confirmer window with an optional check box to never show the box again.

Functions same as axlUIConfirm except allows a check box to never show confirmer again. System remembers this selection so if user has indicated they do not want the box the call immediately returns.

Requires a unique t_key string which is used to remember the selection.

The optional s_level argument changes the info displayed to the user.

On program start/exit writes a file to `<HOME>/pcbenv/remember_<program>.txt`

Arguments

t_message	Message string.
t_key	Unique key to remember user selection. If value of this parameter is nil, the command works like axlUIConfirm.
s_level	Option level symbol; default is `info` level, other levels are `'warn` and `'error`.

Value Returned

`t`: Always returns `t`

See Also

axlUIConfirm

©2023 All Rights Reserved.

Examples

Inform user when a significant transition is being made:

```
axlUIConfirmEx( "Use this command at your own risk." "mynewcommand")
```


©2023 All Rights Reserved.

axlUIControl

```
axlUIControl(
     s_name
     [g_value]
     )
     ==> g_currentValue/ls_names
```

Description

Inquire about graphics canvas. Inquires and sets the value of graphics. If setting a value, the return is the old value of the control.

A side effect of most of these controls is if a form is active that is displaying the current setting it may not be updated. Additional side effects of individual controls are listed. Items will be added over time. Items currently supported:

```
Name:   screen
Value:  (x_width x_height)
Set?:   No
Description: Retrieves the screen's width and height in pixels
Equiv:  none
Side Effects: none


Name:   vscreen
Value:  (x_width x_height)
Set?:   No
Description: Retrieves the screen's virtual width and height in pixels. This will
not be the same as 'screen if running Windows XP and enabled monitor spanning
option. Also requires multiple monitors and graphic card(s) capable of supporting
multiple monitors.
Equiv:  none
Side Effects: On UNIX always returns the same size as screen.


Name:   vedge

Value:  (x_x x_y)

Set?:   No

Description: Retrieves the virtual left top edge of the screen in pixels

Equiv:  none

Side Effects: On UNIX always returns (0 0)



Name:   monitors
Value:  x_number
Set?:   No
Description: Retrieves the number of monitors available.
Equiv:  none
Side Effects: On UNIX always returns 1 since we currently do not support multi-
monitors on UNIX.
```


©2023 All Rights Reserved.

```
Name:   pixel2UserUnits
Value:  f_number
Set?:   No
Description: Returns number user units per pixel taking into account the current
canvas size and zoom factor. Changes with the current zoom factor.
Equiv:  none
Side Effects: none
```

Arguments

s_name	Symbol name of control. `nil` returns all possible names.
s_value	Optional symbol value to set. Usually a `t` or a `nil`.

Value Returned

ls_names	If name is `nil` then returns a list of all controls.

See above

See Also

axlOSControl

Examples:

Get screen size:

```
size = axlUIControl('screen)
-> (1280 1024)
```

Get pixel to user units:

```
axlUIControl('pixel2UserUnits)
-> 17.2
```


©2023 All Rights Reserved.

axlUIMenuChange

```
axlUIMenuChange(
     x_menuId
     s_option
     g_mode
     ... <pairs of s_option/g_mode>
     ) -> t/nil
```

Description

This changes one or more parameters of an existing menu item.

Unlike other menu commands this function can be safely done outside of the menu trigger callback if the menu command is associated with your SKILL code.

Changes allowed are a variable set of new value pairs:

Table 10-2

	s_option	g_mode
Enable/Disable menu	`'enable`	`t/nil`
Set/Unset Check mark	`'check`	`t/nil`
Change display text	`'display`	`<new text display>`
Change command text	`'command`	`<new command string>`

You should not attempt to change any separator menu items. Also do not attempt to assign command text to a submenu.

Note: See discussion in axlUIMenuFind about menu changes.

©2023 All Rights Reserved.

Arguments

`x_menuId`	The menuId from axlUIMenuFind
`s_option/g_mode pairs`	See Table 10-2 on page 723

Value Returned

`t`, if menu item is changed, and `nil` if the command failed to change the menu item.

See Also

axlUIMenuFind

Examples

- Set menu to be disabled

```
q = axlUIMenuFind( nil "add rect")
axlUIMenuChange(q 'enable nil)
```

- Enable and set check mark from previous example

```
axlUIMenuChange(q 'enable t 'check t)
```


©2023 All Rights Reserved.

axlUIMenuDebug

```
axlUIMenuDebug(
     [g_option]
     ) => ll_menu/t/nil
```

Description

A debug function for axl Menu Trigger. This helps debug issues with axlUIMenuRegister.

Arguments

`g_option`	data to query/clear 'clear = clear the list of menus to load 'list = return list of menus to be loaded (nil no menus) 'trigger = clear the menu trigger callback and menus loaded

Value Returned

`t`, call succeeded

`nil`, failed or if clear no menus present

`ll_menu`, current list of menus queued

See Also

axlUIMenuRegister

©2023 All Rights Reserved.

axlUIMenuDelete

```
axlUIMenuDelete(
     x_menuId
     ) t/nil
```

Description

This deletes a single menu item or submenu based upon what is the current find menu item.

Note: See discussion in axlUIMenuFind about menu changes.

Arguments

`x_menuId`	the menuId from axlUIMenuFind

Value Returned

`t`, if menu item is deleted else `nil` if failed to delete menu item

See Also

axlUIMenuFind

Example

- Delete add rect command menu (add rect command is still available from command line)

```
q = axlUIMenuFind( nil "add rect")
axlUIMenuDelete(q)
```

- Delete entire edit menu (assumes 2 menu item in menu bar)

```
q = axlUIMenuFind( nil 1)
axlUIMenuDelete(q)
```


©2023 All Rights Reserved.

axlUIMenuFind

```
axlUIMenuFind(
     x_menuId/nil
     t_cmdName/x_location
     [g_menuOption]
     ) ==> x_menuId/nil
```

Description

Finds a menu item by location or a command. The location (`x_location`) is 0 based. The 0 location is the left or top most menu item. (Typically, this is the *File* menu item on the menu bar). A negative number may be used to specify a menu counting from the right side with a -1 indicating the menu furthest to the left or bottom.

Two modes are possible:

1. Find by name, finds menu item by command name.

   This method cannot find menu bar items such as *File*. When finding by name you should pass `nil` as the first argument.

2. Find by `x_location`, identifies a menu item off the menu bar (`menuId = nil`) or sub-menu.

   Menu searching is controlled via a menu stack. The first argument, `x_menuId`, controls the stack. For most operations, you should pass a `nil` to this argument. Typically, searching via the menu stack would use `x_location` as the second argument since the `t_cmdName` method is sufficient to find commands multi-levels deep in the menu hierarchy. If you have a nested search active then passing a `nil` will reset the stack. The stack is also popped if you provide a `menuId` older then the last id.

   The `g_menuOption` when used in location mode returns the top or bottom of the indexed sub-menu.

Tip

The following examples provide typical uses.

Caution

CAUTIONS (release to release portability)

- While not frequent, command names may change from release to release.
- Certain products or product tiers may not have a command.

©2023 All Rights Reserved.

- Menus may be reorganized so expecting to find a command on a particular sub-menu may not return the expected result in a new release.
- As always, adding Allegro commands or scripts to menus may require updates in a new release.
- See introduction of this section on menu recommendations.

Arguments

`x_menuId`	`menuId` return of previous call or `nil` to search from menu root.
`x_location`	Find item by location. Location is 0 based. Therefore, the "File" menu is location 0. Negative numbers may be used where -1 is the right-most (or bottom-most) menu item.
`t_cmdName`	Find item by command name. This may not be just a command but is really a command line. For example, if the command is registered as "*echo hello*" then you must find by "*echo hello*" and not "echo".
`g_menuOption`	Permitted values are `top,bottom,or 'displayText top/bottom`. If used with find by command returns the top or bottom of the menu where the command exists. Bottom option also indicates to axlUIMenuInsert to that a new menu item should be appended to end of the menu. If used with find by location and the item is a submenu returns the top or bottom of that submenu. If used by find by command, looks up the item by the menu display string instead of the command name. This allows finding submenu names and other entries that have no associated command string.

Value Returned

If successful returns a menu number else failure is indicated by a `nil`.

©2023 All Rights Reserved.

See Also

axlUIMenuInsert, axlUIMenuChange, axlUIMenuDelete, axlUIMenuDump, axlUIMenuLoad, axlUIMenuRegister, axlTriggerSet

Example

- To add to end of "Add" menu either of the following are equivalent (assumes add line exists on 3rd item of menu bar):

```
l = axlUIMenuFind(nil 3 'bottom)
l = axlUIMenuFind(nil "add line" 'bottom)
```

- Find Help menu, useful for adding a new sub-menu before the help menu

```
l = axlUIMenuFind(nil -1 nil)
```

- Find Top of Help menu, useful for adding new help menu items.

```
l = axlUIMenuFind(nil -1 'top)
```

- Find file menu

```
l = axlUIMenuFind(nil 0 nil)
```

- Find bottom of *File – Import* menu

```
l = axlUIMenuFind(nil "load plot" 'bottom)
```


©2023 All Rights Reserved.

axlUIMenuInsert

- Command to add menu item

```
axlUIMenuInsert(
     x_menuId
     t_display
     t_command
     ) -> t/nil
```

- Command to add Separator

```
axlUIMenuInsert(
     x_menuId
     'separator
     ) -> t/nil
```

- Command to add Sub-menu

```
axlUIMenuInsert(
     x_menuId
     'popup
     t_display
     ) -> x_subMenuId/nil
```

- Command to add Sub-menu end (optional)

```
axlUIMenuInsert(
     x_menuId
     'end
     ) -> t/nil
```

- Command to add multiple items

```
axlUIMenuInsert(
     x_menuId
     ll_items
     ) -> t/nil
```

Description

Inserts menu items to an existing menu. Several modes are supported:

1. Add a new menu item which dispatches a command when selected by user.
   a. Add a new visual separator to menu.
2. Add a new sub-menu item. Assumption is that it will be populated by additional menu insert calls.

©2023 All Rights Reserved.

   a. End a sub-menu. This is optional, see menu stack discussion below.

3. Add multiple menu items.

This is implemented using a menu stack. axlUIMenuFind resets the stack and each submenu created increments the stack. The 'end mode (submenu) decrements the stack. The menu stack allows the building of a menu tree with very little coding overhead. The stack depth is restricted to 8.

Caution

Menu items should not be created outside a menu trigger. See discussion in** axlUIMenuFind**. For development purposes you can create menu items outside of the menu trigger.

Arguments

`x_menuId`	menu id which can be obtained from axlUIMenuFind or creating a submenu via this API. If nil uses the current menu on the menu stack
`t_display`	text that is shown in the menu. Possible values are: `separator` - add a separator (horizontal line) `popup` - create a new submenu
`t_command`	command to run ■ this is ignored for a 'separator ■ this is the display string for '`popup` option 'end ■ pops the menu stack if creating a menu tree
`ll_items`	This is a list of `t_display/t_command` value pairs that instruct this interface to add multiple menu items and submenus in a single call. Both the `'separator` and `'end` options do not have to be a list.

Value Returned

`t` - successful

©2023 All Rights Reserved.

`nil` - failed

`x_menuId` - if creating a new submenu, the nesting id of new submenu

See Also

axlUIMenuFind

Example

- Add a separator before the add rect command

```
q = axlUIMenuFind( nil "add rect")
z = axlUIMenuInsert(q 'separator )
```

- Add a web link at the top of the help menu

```
q = axlUIMenuFind( nil -1 'top)
z = axlUIMenuInsert(q "Google" "http http://google.com" )
```

- Add a new submenu to the right of the help menu with two commands

```
q = axlUIMenuFind( nil -1)
; the nil is intention in here since it demostrates
; the use of the currrent menu from find.
z = axlUIMenuInsert(q 'popup "MyMenu")
;  the nil is required for the next 2 calls since we want to
;  insert these these items into MyMenu
z = axlUIMenuInsert(z "1" "echo hello 1" )
z = axlUIMenuInsert(z "2" "echo hello 2" )
```

- More nested menu

See `<cdsroot>/share/pcb/examples/skill/ui/menu.il`

©2023 All Rights Reserved.

axlUIMenuRegister

```
axlUIMenuRegister(
     t_command/x_location
     ll_menu
     [g_menuOption]
     ) => t/nil
```

Description

This allows you to register menu items to be loaded when Allegro loads a new menu. It is a combination of axlUIMenuFind and axlUIMenuInsert.

If more elaborate menu configuration is required consider calling axlTriggerSet directly.

Tip

For registering menu items based upon product you need to use this API plus the axlTriggerSet method with one or more of the following APIs.

- To determine if the symbol editor is active use axlIsSymbolEditor function.
- axlDesignType may be used to differentiate between PCB or APD+ or SIP.
- Finally, axlVersion with an option:
  - `'programName` - another method to differentiate between PCB, APD+ or SIP
  - `'displayName` - differentiates between the products (PCB Designer vs Allegro Sigrity vs OrCAD PCB Designer Standard). This tends change considerably between releases and may change via ISR.
  - other options to this interface further classify products in a simple `t/nil` return classification.

Caution

- See axlUIMenuFind for cautions about portability across releases.
- When multiple menu registers are done, there may be dependencies.
  For example, if the first menu register adds a new submenu before the File menu the result will be not as expected if the second attempts to add a new item to the Edit menu via the location method.
- This API must never be called from within a axlTriggerSet callback function.

©2023 All Rights Reserved.

Arguments

`t_command`	Command to insert menu before (see axlUIMenuFind)
`x_location`	Location before to insert menu (see axlUIMenuFind)
`ll_menu`	List of menu items to load (see format 3 option of axlUIMenuInsert)
`g_menuOption`	Indication to add to top or bottom of menu (see axlUIMenuInsert)

Value Returned

`t`, if register function for indicated callback, `nil`, if the command failed to register trigger

See Also

axlUIMenuFind, axlUIMenuInsert, axlTriggerSet, axlUIMenuDebug, axlIsSymbolEditor

Example

See `<cdsroot>/share/pcb/examples/skill/ui/menu.il`

©2023 All Rights Reserved.

axlUIPopupDump

```
axlUIPopupDump(
     t_menuFile
     [g_debug]/t_menuState
     t_menuType
     )
     ⇒ t_menuFile/nil
```

Description

Dumps the current menus of the main window to the file *t_menuFile*. The default menu filename extension will be added if *t_menuFile* has none. There is no user interaction when an existing file is over-written.

Arguments

t_menuFile	The name of the file, which the menu is to be dumped to. If *t_menuFile* is `nil`, the file name will be based on the program's default menu name (which may vary based on the current state of the program).
g_debug	If it is `'print` then only the commands contained in the menu file are dumped. Allow for easier comparison between old and new menu files.
t_menuState	The state of the menu like enabled or disabled, checked or unchecked, which will be dumped into the file along with the name and command name of the menu
t_menuType	The type of the menu like parent menu contents or context menu contents, which will be dumped into the file.

Value Returned

- The full name of the file that is written is returned.
- If no file is written, `nil` is returned.

Note: The intent of this procedure is to provide a base menu file from which a customized menu can be developed.

©2023 All Rights Reserved.

axlUIPrompt

```
axlUIPrompt(
                t_message
                [t_default]/'password
                )
        ==> t_response/nil
```

Description

Displays the string *t_message* in a form. The user must type a response into the field. Displays the argument *t_default* in brackets to the left of the field. The user presses the *Return* key or clicks the *OK* button in the window to accept the value of *t_default* as the function return value. If the user selects the *Cancel* button, the function returns `nil`.

This function is a blocker. The user must respond before any further interaction with Allegro PCB Editor.

Arguments

t_message	Message string displayed.
t_default	Default value displayed to the user and returned if user presses only the *Return* key or clicks *OK*.
'password:	Obscure and do not script user input.

Value Returned

t_response	User response or default value.
`nil`	User selected *Cancel*.

©2023 All Rights Reserved.

Example

```
axlUIPrompt( "Enter module name" "demo" )
⇒ "mymcm"
```

Prompts for a module name with a default `demo`. Typing `mymcm` overrides the default.

A text field displays, with the default value "`demo`. To accept the default value, you may either press *Return* or select *OK*. Otherwise, type a new value in the text field and press *Return* or click *OK*. In this example, enter `"mymcm"` in the text field and click *Return*.

`axlprompt` returns the following:

```
==> "mymcm"
```

Password prompt:

```
ret = axlUIPrompt( "Enter password" 'password )
```

See also

axlUIConfirm

©2023 All Rights Reserved.

axlUIWCloseAll

```
axlUIWCloseAll(
     )
     ==> t / nil
```

Description

This closes all temporary windows (dialogs and text view windows). A temporary window is a dialog that closes if you open another design (for example, . brd). Via SKILL this window attribute is set by the axlUIWPerm API. The constraint manager is currently considered a permanent window but this may change in future releases. A blocking window (for example, File Browser dialogs) cannot be closed via this call.

Arguments

None

Value Returned

t	always

See Also

axlUIWPerm

©2023 All Rights Reserved.

axlUIWIconify

```
axlUIWIconify (
     r_window/t_window
     t/nil
     )=> t/nil
```

Description

This command either creates an icon for a window or open a window from an icon.This is different from axlUIWExpose, which also opens a window from an icon but exposes hidden windows and permits raising a window to the top of the stack. Note all sub-windows also open or closed to an icon. So, if you make the main Allegro PCB Editor window an icon, all of its child windows are also closed. `t_window` name may change from release to release although this is not normal. `nil` may be used for the main window. Currently, Constraint Manager interface is not supported by this SKILL command.

Arguments

r_window	Window ID.
t_window	Window name. This is the name that appears in PCB Editor scripting — invoked using the `setwindow` command.
t	To iconify window, `nil` open from an icon.

Value Returned

t	For success
nil	For failure (The specified window could not be found)'

Examples

Command to iconify Allegro PCB Editor

```
axlUIWIconify("pcb")
```

See Also

axlUIWIsWindow, axlUIWIsIconic, axlUIWExpose

©2023 All Rights Reserved.

axlUIWIsIconic

```
axlUIWIsIconic(
     r_window/t_window
     )=> t/nil
```

Description

Is the window in an icon state. `nil` may be used for the main window. `t_window` name may change from release to release although this is not normal. Constraint Manager is not yet supported by this SKILL command.

Arguments

r_window	Window ID.
t_window	Window name. This is the name that appears in Allegro scripting window — using the `setwindow` command.

Value Returned

t	For success
nil	For failure (when the specified window cannot be found)'

Examples

Check if main window is in icon state

```
axlUIWIsIconic("pcb")
```

See Also

axlUIWIsWindow, axlUIWIconify

©2023 All Rights Reserved.

axlUIWIsWindow

```
axlUIWIsWindow (
     t_window
     )=> t/nil
```

Description

Returns `t` if named window is open. `t_window` name may change from release to release although this is not normal.

Arguments

`t_window`	Window name. This is the name that appears in Allegro PCB Editor — using the `setwindow` command.

Value Returns

`t`	For success
`nil`	No window by that name is open

Examples

Is Constraint Manager open

```
axlUIWIsWindow("cmgr")
```

See Also

axlUIWClose

©2023 All Rights Reserved.

axlUIWMove

```
axlUIWMove(
     r_window/nil
     t_window
     l_xy
     )
     -> t/nil
```

Description

Moves a window. New location (`l_xy`) which is upper left corner, is specified in pixels.

`nil` may be used for the main window.

`t_window` name may change from release to release although this is not normal.

Note: Constraint Manager is not yet supported.

Arguments

r_window	Window ID or if nil the main window.
t_window	Window name. This is the name that appears in Allegro scripting from the setwindow command.
l_xy	(`x_X x_y`)

Value Returned

t	window moved
nil	Error, handle is not a window

See Also

axlUIWSize

Example

Move main window to upper left corner of the display.

```
axlUIWMove(nil 0:0)
```


©2023 All Rights Reserved.

axlUIWRedraw

```
axlUIWRedraw(
     r_window/nil
     )=> t/nil
```

Description

Redraws indicated window. If window ID is `nil` redraws the main window.

Arguments

r_window	Window ID or if `nil`, the main window.

Value Returns

t	For success
nil	In case of failure (window already closed or not a window)

©2023 All Rights Reserved.

axlUIWSize

```
axlUIWSize(
     r_window/nil
     )
     -> ll_rect
```

Description

Returns outer size of a window. Size is in pixels. x and y coordinates are upper left corner of window.

On UNIX/Linux, the `y` value will typically include an offset due to title bar height.

Arguments

r_window	Window id or if `nil` the main window.

Value Returned

ll_rect	`( (x_X x_Y) (x_Width x_Height))`
nil	Error, handle is not a window

See Also

axlUIWMove

©2023 All Rights Reserved.

axlIsViewFileType

```
axlIsViewFileType(
     g_userType
     )
     ⇒ t/nil
```

Description

Tests whether *g_userType* is a long message window type.

Arguments

g_userType	Argument to test.

Value Returned

t	*g_userType* is of type *r_windowMsg*.
nil	*g_userType* is not of type *r_windowMsg*.

Example

```
logWindow =
    axlUIViewFileCreate("batch_drc.log" "Batch DRC Log" t)
    axlIsViewFileType(logWindow)
⇒ t
```

- Creates a window using `axlUIViewFileCreate` (See axlUIViewFileCreate on page 746.)
- Tests whether the window is a view file type.
- Returns `t`.

See Also

axlUIViewFileCreate

©2023 All Rights Reserved.

axlUIViewFileCreate

```
axlUIViewFileCreate(
     t_file
     t_title
     g_deleteFile
     [lx_size]
     [lt_placement]
     [g_formToExpose]
     )
     ⇒ r_windowMsg/nil
```

Description

Opens a file view window to display a file (`t_file`), it is an error for file not to exist. Window should be given a title (t_title).

If `g_deleteFile` is set to `t`, the file is deleted when view window is quit or reused. It is suggested that applications not delete view files themselves as the Save and Print buttons will not work.

Size of viewable window is controlled by `lx_size.` Default size is 24x80. Unpredictable results may occur for large row/column values.

Placement of window is handled by `lt_placement` list. If this value is `nil`, the window is centered on editor.

Window may be deleted via program control via axlUIWClose function.

If a window of the same type with the same parent already exists and hasn't been pinned then the function try to reuse it automatically.

©2023 All Rights Reserved.

Arguments

t_file	Name of the ASCII file to display. If the value is "" then last registered log file is displayed.
t_title	Title to be display in window title bar.
g_deleteFile	Deletes the file when the user quits the window or another task reuses the window.
lx_size	Initial size of the window in character rows and columns. The default is 24 by 80. Setting a large window size may cause unpredictable results.
lt_placement	Window placement hints. See the section on Window Placement.
g_formToExpose	Optional handle of another window. If specified then this window is brought to the top of the desktop when the view file window is closed and also is the parent of this window. If not specified then the main program window is the parent.

Value Returned

r_windowMsg	Window *r_windowMsg*.
nil	*r_windowMsg* not displayed.

Example

- Displays the batch DRC log file, saving the window id.
- Deletes the file `drc.log` when the user exits the window.

```
logWindow = axlUIViewFileCreate("batch_drc.log" "Batch DRC Log" nil)
```

The log file displays in a window. When the user chooses *Close*, deletes the file `batch_drc.log`.

©2023 All Rights Reserved.

axlUIViewFileReuse

```
axlUIViewFileReuse(
     r_windowMsg
     t_file
     t_title
     g_deleteFile
     [g_formToExpose]
     )
     ⇒ t/nil
```

Description

Reuses the view window to display a file (t_file). Error is thrown if the file does not exist. Window is given a title (t_title).

Expects r_windowMsg to be type of view window. If user quit the window it will re-open it at the old size/position.

File is deleted is g_deleteFile is t when view window is quit or reused. It is suggested that applications not delete view files themselves as the Save and Print buttons will not work.

©2023 All Rights Reserved.

Arguments

r_windowMsg	*dbid* of the existing view window created earlier with axlUIViewFileCreate.
t_file	Name of the ASCII file to display.
t_title	Title to display in window title bar.
g_deleteFile	Deletes file when the user quits the window or another task reuses the window.
g_formToExpose	Optional argument that defines the handle of a window to be exposed when the text file window is closed. Default is the parent set by axlUIViewFileCreate. Normally you should not use this argument.

Value Returned

t	File displayed.
nil	File not displayed.

Example

```
(axlUIViewFileReuse logWindow "ncdrill.log" "NC Drill Log" nil)
```

- Displays the file ncdrill.log, reusing the window logWindow created when displaying batch_drc.log in the axlUIViewFileCreate example.
- Exiting the window automatically deletes the file ncdrill.log.

©2023 All Rights Reserved.

axlUIYesNo

```
axlUIYesNo(
                t_message
                [t_title]
                [s_default]
                )
        ==> t/nil
```

Description

Provides a dialog box displaying the message *t_message*. Returns `t` if you choose *Yes* and `nil` for *No*.

This function is a blocker. You must respond before any further interaction with Allegro PCB Editor.

Note:

- If environment variable `noconfirm` is set, we immediately return `t` for yes and `nil` for no.

Arguments

t_message	Message string to display.

Value Returned

`t`	User responded *Yes*.
`nil`	User responded *No*.

See Also

axlUIConfirm

Examples

The following examples are a typical overwrite question.

©2023 All Rights Reserved.

```
            axlUIYesNo( "Overwrite module?" )

            axlUIYesNo( "Overwrite module?" nil 'no )

            axlUIYesNo( "Overwrite module?" "My Skill Program" )

        A confirmer window is displayed. If the user selects Yes, the
        function returns t, otherwise it returns nil.
**/

list
axlUIYesNo(int argc, list *argv)
{
    char *str, *title;
    int dflt;

    str = axluGetString(NULL, argv[0]);
    title = (argc>1) ? axluGetString(NULL, argv[1]) : NULL;
    dflt = (argc>2) ? DfltResponse(argv[2]) : MN_YES;

    return(MNYesNoWTitle(str, title, dflt) ? ilcT : ilcNil);
}

 /*
#ifdef DOC_C
```


©2023 All Rights Reserved.

axlUIWExpose

```
axlUIWExpose(
     r_window/nil
     )
     ⇒ t/nil
```

Description

Opens and redisplays a hidden or confined window, bringing it to the front of all other current windows on the display. If `nil`, the main window is displayed.

Arguments

r_window	Window *dbid*.

Value Returned

`t`	Window opened and brought to front.
`nil`	*dbid* was not of a window.

Example

```
logWindow =
    axlUIViewFileCreate("batch_drc.log" "Batch DRC Log" t)
; Other interactive code, possibly
; causing Batch DRC Log window to be covered
; Uncover the log window:
axlUIWExpose(logWindow)
⇒ t
```

- Displays a window using `axlUIViewFileCreate`.
- Interactively moves window behind one or more other windows using the *back* selection of your window manager.
- Calls `axlUIWExpose`.

  Window comes to the top above all other windows.

©2023 All Rights Reserved.

axlUIWClose

```
axlUIWClose(
     r_window/t_window
     )⇒ t/nil
```

Description

Closes a window, if it is open.

Note: Window may also be closed by user. See initial sections of the chapter for specific window types.

Arguments

r_window	Window *dbid*.
t_window	Window name. This is the name that appears in Allegro scripting from the setwindow command.

`t_window` name may change from release to release although this is not normal.

Value Returned

`t`	Window closed.
`nil`	Window already closed, or *dbid* is not of a window.

Example

- The following example, displays a window using axlUIViewFileCreate, and closes it using axlUIWClose.

  ```
  logWindow = axlUIViewFileCreate("batch_drc.log" "Batch DRC Log" t)
  ```

  ;;; Other interactive code

  ```
  axlUIWClose(logWindow)
  ```

- Close Constraint Manager

  ```
  axlUIWClose("cmgr")
  ```


©2023 All Rights Reserved.

See Also

axlUIWIsWindow

©2023 All Rights Reserved.

axlUIWHelpRegister

- Command to register new help file

```
axlUIWHelpRegister(
     t_cmd
     t_helpFile
     ) -> t/nil
```

- Query if help file registered for command

```
axlUIWHelpRegister(
     t_cmd
     ) -> t_file
```

- Delete help file registered for command

```
axlUIWHelpRegister(
     t_cmd
     ""
     ) -> t/nil
```

- Lists all cmds registered for help

```
axlUIWHelpRegister(
     nil
     ) -> lt_cmds
```

Description

This registers a help document for a user written SKILL command or form (dialog). This is typically used in conjunction with axlCmdRegister. You should make this call at the time you do a axlCmdRegister instead of waiting until the SKILL code associated with the command executes.

You can also add the registrations via the `help_config.txt` file (see *<cdsroot>*/`share/pcb/help/help_config.txt`) placed at the site or pcbenv directory.

The document types (determined via file extension) supported on all platforms are:

- `.txt` - a plain text file displayed via Allegro's internal long message window
- `.html` - html browser displayed via a web browser
- `.pdf` - Acrobat file displayed by a Acrobat reader

On Windows other extensions are typically supported which are determined by what programs are installed on the computer (for example, doc for Word and ppt for PowerPoint).

©2023 All Rights Reserved.

Arguments

t_cmd	Command name or form.<formname> for registering help for form buttons
t_helpFile	Document to display. Variable expansion is supported so you can embed Allegro env variables to make the installed location of the files relative to the variable setting.

Value Returned

`t` for success, `nil` for failure (invalid arguments)

See Also

axlCmdRegister

Examples

Override add line help with contents of Allegro's env file

```
axlCmdRegister("add line" "$TELENV")
```


©2023 All Rights Reserved.

axlUIWPrint

```
axlUIWPrint(
     r_window/nil
     t_formatString
     [g_arg1 ...]
)
⇒ t/nil
```

Description

Prints a message to a window other than the main window. If *r_window* does not have a message line, the message goes to the main window. This function does not buffer messages, but displays them immediately. If the message string does not start with a message class (for example *e*), it is treated as a text (*t*) message. (See axlMsgPut on page 970) If `nil`, displays the main window.

Arguments

r_window	Window *dbid*.
t_formatString	Context message (`printf`–like) format string.
g_arg1...	Any number of substitution arguments to be printed using *t_formatString*. Use as you would a C–language `printf` statement.

Value Returned

`t`	Message printed to window.
`nil`	*dbid* is not of a window.

Example

```
axlUIWPrint(nil "Please enter a value:")
Please enter a value:
⇒ t
```

Prints a message in the main window.

©2023 All Rights Reserved.

axlUIWRedraw

```
axlUIWRedraw(
     r_window/nil
)
⇒ t/nil
```

Description

Redraws the indicated window. If the window *dbid* is `nil`, redraws the main window.

Arguments

r_window	Window *dbid* or, if `nil`, the main window.

Value Returned

`t`	Window is redrawn.
`nil`	*dbid* is not of a window.

©2023 All Rights Reserved.

axlUIWBlock

```
axlUIWBlock(
     r_window
)
⇒ t/nil
```

Description

Caution

This function is not compatible with the g_nonBlock = nil option to axlFormCreate. If using this function with axlFormCreate you must set a callback on the g_formAction.

This places a block on the indicated window until it is destroyed. All other windows are disabled. It may be called recursively, unlike the block option in `axlFormCreate`.

Once you enter a blocking mode you should not bring up a window that is non-blocking. This behavior is not defined and is not supported.

If you block, you should set the block attribute `block` in the Window Placement list *`lt_placement`* so that the title bar shows it is a blocking window.

If you have a window callback registered you must allow the window to close since the unblock facility unblocks other windows upon close so that the correct window will get the focus after the blocked window is destroyed.

Note: You should set the block symbol option using the *lt_placement* option in the function that creates the window to visually indicate that the window is in blocking mode.

Arguments

`r_window`	Window *`dbid`*.

Value Returned

`t`	Success
`nil`	Failure (For example, the window is closed or the *`dbid`* is not of a window).

©2023 All Rights Reserved.

axlUIEditFile

```
axlUIEditFile(
     t_filename
     t_title/nil
     g_block
)
⇒ r_window/t/nil
```

Description

Allows the user to edit a file in an OS independent manner (works under both UNIX and Windows.)

User may override the default editor by setting either the `VISUAL` or `EDITOR` environment variables.

Windows notes

- The default editor is *Notepad*.
- The title bar setting is not supported.

Unix notes

- The default editor is `vi`.
- An additional environment variable, `WINDOW_EDITOR`, allows the user to specify an X-based editor such as `xedit`. The title bar is not supported in this mode.

Note: In blocking mode, the windows of the main program do not repaint until the file editor window exits.

Only `axlUIWClose` supports the *`r_window`* handle returned by this function.

©2023 All Rights Reserved.

Arguments

t_filename	Name of file to edit.
t_title	Title bar name, or `nil` for default title bar.
g_block	Flag specifying blocking mode (`t`) or non-blocking mode (`nil`).

Value Returned in Non-blocking Mode

r_window	Success
`nil`	Failure

Value Returned in Blocking Mode

`t`	Success
`nil`	Failure

©2023 All Rights Reserved.

axlUIMultipleChoice

```
axlUIMultipleChoice(
     t_question
     lt_answers
     [t_title]
)
⇒ x_answer/nil
```

Description

Displays a dialog box containing a question with a set of two or more answers in a list. You must choose one of the answers to continue. Returns the chosen answer.

Arguments

t_question	Text of the question for display.
lt_answers	A list of text strings that represent the possible answers.
t_title	Optional title. If not present, a generic title is provided.

Value Returned

x_answer	An integer number indicating the answer chosen. This value is zero-based, that is, a zero represents the first answer, a one the second answer, and so on.
nil	An error is detected.

Example

```
ret = axlUIMultipleChoice("Pick a choice"
     '("Pick me" "No Pick me" "I'm here!") "Cmd title")
```


©2023 All Rights Reserved.

axlUIViewFileScrollTo

```
axlUIViewFileScrollTo(
     r_windowMsg
     x_line/nil
     )⇒ x_lines/nil
```

Description

Scrolls to a specified line in the file viewer. A value of `-1` goes to the end of the viewer.

Note: The number of the line in the view window may not match the number of lines in the file due to line wrapping in the viewer.

Caution

With the html-based viewer the command is unable to return the number of items in scroll window. Return is only valid for the legacy text window.

Arguments

r_windowMsg	Existing view window.
x_line	Line to scroll: `0` is top of the file, `-1` is bottom of the file, `-2` returns the number of lines in the viewer.

Value Returned

x_lines	Number of lines in the view window.
`nil`	No view file window.

Example

```
pm = axlUIViewFileCreate("topology.log" "Topology" nil)
axlUIViewFileScrollTo(pm -1)
```

- Displays the file `topology.log`
- Scrolls to the end of the file

©2023 All Rights Reserved.

axlUIWBeep

```
axlUIWBeep()⇒ t
```

Description

Sends an alert to the user, usually a beep.

Arguments

None

Value Returned

None

Example

```
axlUIWBeep()
```


©2023 All Rights Reserved.

axlUIWDisableQuit

```
axlUIDisableQuit(
     o_window
)
⇒ t/nil
```

Description

Disables the system menu *Quit* option so the user cannot choose it to close the window.

Arguments

o_window	Window handle.

Value Returned

`t`	Window handle is valid.
`nil`	Window handle is invalid.

©2023 All Rights Reserved.

axlUIWExposeByName

```
axlUIWExposeByName(
     t_windowName
)
⇒ t/nil
```

Description

Finds a window by name and exposes it (raises it to the top of the window stack and restores it to a window state it if it is an icon).

You can use the `setwindow` command argument to get Allegro PCB Editor window names via scripting. If the window is a form, you get the name by removing the `form.` prefix from its name.

Note: Names of windows may change from release to release.

To raise an item in the control panel, (for example, *Options*,) use the `axlControlRaise()` function.

Arguments

t_windowName	Window name.

Value Returned

`t`	Window is found.
`nil`	Window is not found.

©2023 All Rights Reserved.

axlUIWPerm

```
axlUIWPerm(
     r_window
     [t/nil]
)
⇒ t/nil
```

Description

Normally forms and other windows close automatically when another database opens. This function allows that default behavior to be overridden.

Notes:

- When you use this function, consider that windows automatically close when a new database opens because the data the windows display may no longer apply to the new database.
- If you do not provide a second argument, returns the current state of the window.

Arguments

r_window	Window id.
t/nil	`t` - set permanent
	`nil` - reset permanent.

Value Returned

`t`	Window exists.
`nil`	Window does not exist.

©2023 All Rights Reserved.

Example 1

```
handle = axlFormCreate('testForm "axlform" nil 'testFormCb, t nil)
axlUIWPerm(handle t)
```

Opens a test form and makes it permanent.

Example 2

```
ret = axlUIWPerm(handle)
```

Tests whether the window is permanent.

©2023 All Rights Reserved.

axlUIWSetHelpTag

```
axlUIWSetHelpTag(
     r_window
     t_tag
     )
     ⇒ t/nil
```

Description

This has been mostly replaced by axlUIWHelpRegister that works for commands and forms.

Attaches the given help tag to a pre-existing dialog with a port. This function supports subclassing of the help tags, that is, if a help tag is already associated with the dialog, it will not be replaced. This functions adds the new help tag. Adding a new help tag to a pre-existing one is done by concatenating the two with a dot.

For example:

Pre-existing Help Tag:	myOldTag
New Help Tag:	myNewTag
Resulting Help Tag:	myOldTag.myNewTag

Arguments

r_window	Window id.
t_tag	Subclass of the help string.

Value Returned

`t`	Help tag attached.
`nil`	Invalid arguments.

See Also

axlUIWHelpRegister

©2023 All Rights Reserved.

axlUIWSetParent

```
axlUIWSetParent(
     o_childWindow
     o_parentWindow/nil

)

⇒ t/nil
```

Description

Sets the parent of a window. When a window is created, its parent is the main window of the application, which is sufficient for most implementations. To run blocking mode on a form launched from another form, set the child form's parent window to be the launched form.

Setting the parent provides these benefits:

- Allows blocking mode to behave correctly.
- If the parent is closed, then the child is also closed.
- If the parent is iconified, then the child is hidden.
- The child stays on top of its parent in the window stacking order.

Arguments

o_childWindow	Child window handle.
o_parentWindow	Parent window (if `nil`, then the main window of the application which is normally the default parent.)

Note: A parent and child cannot be the same window.

Value Returned

`t`	Parent is successfully set.
`nil`	Could not set the parent due to an illegal window handle.

©2023 All Rights Reserved.

axlUIWShow

```
axlUIWShow(
     r_window/nil
     s_option
     )
     ⇒ t/nil
```

Description

Shows or hides a window depending on the option passed. If the window id passed is `nil`, the function applies to the main window.

Notes:

- Using the `showna` option on a window may make the window active.
- Using the `show` option on a window that is already visible may not make it active.

Arguments

r_window	The window id. If `nil`, signifies the main window.
s_option	One of the following:
	`'show:` Show and activate the window
	`'showna:` Show but don't activate the window.
	`'hide:` Hide the window.
	`nil:` Show available options.

Value Returned

`t`	Window shown or hidden.
`nil`	Window id not correct or an invalid option given.

©2023 All Rights Reserved.

axlUIWTimerAdd

```
axlUIWTimerAdd(
     o_window
     x_timeout
     g_oneshot
     u_callback
     )
     ⇒ o_timerId/nil
```

Description

Adds or removes a callback for an interval timer.

This is not a real-time timer. It is synchronous with the processing of window based messages. The actual callback interval may vary. The timer does not go off (and call you back) unless window events for the timer window (*o_window*) are being processed. You must be waiting in a UI related call (for example, `axlEnter*`, a blocking `axlFormDisplay`, `axlUIWBlock`, etc.)

To receive callbacks return to the main program message processing. Another window in blocking mode, however, can delay your return to the main program.

You may add properties to the returned *timerId* to store your own data for access in your timer callback.

Points to be remembered while using the provided callback function.

- Processing in the callback should be relatively short in time
- Do not open or save the design
- Do not open or close forms or windows
- dbids may become stale
- axlAddSimpleRbandDynamics should not be used.
- Too many triggers active can impede performance.
- Allegro dbids are only valid within the callback. You cannot pass dbids in or out of this callback function. You always need to re-fetch them from the database.

©2023 All Rights Reserved.

Arguments

o_window	The window the timer is associated with. If *o_window* is `nil`, the timer is associated with the main window.
x_timeout	Timeout in milliseconds before the timer is triggered and calls your callback procedure. Timeout is not precise because it depends on processing window messages.
g_oneshot	Controls how many times the timer triggers. Use one of these values: `t` - Timer goes off once and automatically removes itself. `nil` - Timer goes off at the set time interval continuously until it is removed by `axlUIWTimerRemove`.
u_callback	Procedure called when the timer goes off. Called with these arguments with its return value ignored: *u_callback(* *o_window* *o_timerId* *n_elapsedTime* *o_window:* Window you provided to `axlUIWTimerAdd` *o_timerId:* Timer id which returned by `axlUIWTimerAdd`. *x_elapsedTime:* Approximate elapsed time in milliseconds since the timer was added.

Value Returned

o_timerId	The identifier for the timer. Use this to remove the timer. This return value is subject to garbage collection when it goes out of scope. When the garbage is collected, the timer is removed. Do not count on garbage collection to remove the timer, however, because you do not know when garbage collection will start. If you need a timer that lasts forever, assign this to a global variable.
`nil`	No timer added.

See Also

axlUIWTimerRemove

©2023 All Rights Reserved.

Example

- Basic:

```
procedure( YourSkillProcedure()
     ; set up a continuous timer using the main window
     timerId = axlUIWTimerAdd(nil 2000 nil 'YourTimerCallback)
     timerId->yourData = yourdata
     )

procedure( YourTimerCallback( window timerId elapsedTime)
     ; your time period has elapsed. do something.
     )
```

- Other examples can be found at `<cdsroot>/share/pcb/examples/skill/ui/timer.il`

©2023 All Rights Reserved.

axlUIWTimerRemove

```
axlUIWTimerRemoveSet(
     o_timerId
)
⇒ t/nil
```

Description

Removes a timer added by `axlUIWTimerAdd`.

Arguments

o_timerId	Id returned by `axlUIWTimerAdd`.

Value Returned

`t`	Timer removed.
`nil`	Timer id invalid.

©2023 All Rights Reserved.

axlUIWUpdate

```
axlUIWUpdate(
     r_window/nil
     )
     ⇒ t/nil
```

Description

Forces an update of a window. If you made several changes to a window and are not planning on going back to the main loop or doing a SKILL call that requires user interaction, use this call to update a window. You could use this, for example, if you are doing time-consuming processing without giving back the control to the UI message pump.

To use, make all your window changes and then make this call. If window ID is `nil`, exposes the main window.

Arguments

r_window	Window id or `nil` if the main window.

Value Returned

`t`	Window updated.
`nil`	Window already closed or invalid window ID.

©2023 All Rights Reserved.

axlUIYesNoCancel

```
axlUIYesNoCancel(
     t_message
     [t_title]
     [s_default]
     )
     ⇒ x_result
```

Description

Displays a blocking *Yes*/*No*/*Cancel* dialog box with the prompt message provided.

Arguments

t_message	Message to display.
t_title	Optional. What to put in the title bar of confirm. The default is the program display name.
s_default	Optional. May be either `yes`, `no` or `cancel` to specify default response. The default is `yes`.

Value Returned

x_result	Number based on the user's choice: `0` for *No* `1` for *Yes* `2` for *Cancel*

Examples

©2023 All Rights Reserved.

axlUIDataBrowse

```
axlUIDataBrowse(
     s_dataType
     ls_options
     t_title
     g_sorted
     [t_helpTag]
     [l_callback]
     [g_args]
     )
     ⇒ lg_return
```

Description

Analyzes all objects requested by the caller function, passing each through the caller's callback function. Then puts the objects in a single-selection list.

This list blocks until a user makes a selection. Once the user selects an object, it is passed back to the caller in a list containing two objects: the selected name and, for a database object, the AXL dbid of the object.

©2023 All Rights Reserved.

Arguments

s_dataType	One of the following:' NET 'PADSTACK 'PACKAGE_SYMBOL 'DEVICE 'PARTNUMBER 'REFDES 'BOARD_SYMBOL 'FORMAT_SYMBOL 'SHAPE_SYMBOL 'FLASH_SYMBOL 'BRD_TEMPLATE 'SYM_TEMPLATE 'TECH_FILE
ls_options	List containing at least one of the following: 'RETRIEVE_OBJECT: Object selected returns its dbid 'RETRIEVE_NAME: Object selected returns its name 'EXAMINE_DATABASE: Initially look in the database for list of objects 'EXAMINE_LIBRARY: Initially use env PATH variable when looking for list of objects 'DATABASE_FIXED: Read-only check box for the database LIBRARY_FIXED: Read-only check box for files (library)
t_title	Prompt for the title of the dialog
g_sorted	Switch indicating whether or not the list should be sorted
t_helpTag	Help tag for the browser
l_callback	Callback filter function which takes the arguments name, object, and g_arg passed in. Returns t or nil based on whether or not the object is eligible for browsing.

©2023 All Rights Reserved.

g_arg	Generic argument passed through to *l_callback* as the third argument.

Value Returned

t_name o_dbid	Selection was made and RETRIEVE_OBJECT used.
t_name nil	Selection was made and RETRIEVE_NAME used.

Examples

```
axlUIDataBrowse('NET '(RETRIEVE_NAME) "hi" t)
axlUIDataBrowse('PADSTACK '(RETRIEVE_NAME) "hi" t)
axlUIDataBrowse('PACKAGE_SYMBOL '(EXAMINE_DATABASE EXAMINE_LIBRARY
    RETRIEVE_NAME)"hi" t)
axlUIDataBrowse('PACKAGE_SYMBOL '(EXAMINE_LIBRARY RETRIEVE_OBJECT) "hi" t)
axlUIDataBrowse('PACKAGE_SYMBOL '(EXAMINE_LIBRARY RETRIEVE_NAME) "hi" t)
axlUIDataBrowse('PARTNUMBER '(RETRIEVE_OBJECT) "Part Number" t)
```


©2023 All Rights Reserved.

11

Form Interface Functions

Overview

This chapter describes the control types and functions you use to create Allegro PCB Editor forms (dialogs) and interact with users through them.

Allegro PCB Editor AXL forms support a variety of field types. See Callback Procedure: formCallback on page 882 and Using Forms Specification Language on page 791 for a complete description of field types.

The SKILL implementation of the forms package does not support the all functionality present in the core form package; short fields and variable tile forms.

See Also

axlFormCreate - open a form

axlFormCallback - callback model for interaction with user

axlFormBNFDoc - Backus Naur Form, form file syntax, demos

axlFormTest

Programming

It is best to look at the two form demo.

- basic controls -- `axlform.il/axlform.form`
- grid control - `fgrid.il/fgrid.form`
- multi-select grid control - `fgrid-msel.il/fgrid.form`

The first step is to create form file. Use `axlFormTest` to ensure fields are correctly positioned.

©2023 All Rights Reserved.

The following procedure is generally used.

1. Open form (`axlFormCreate`)
2. Initialize fields (`axlFormSetField`)
3. Display Form (`axlFormDisplay`)
4. Interactive with user (`axlFormCallback`)
5. Close Form (`axlFormClose`)

Tip

Many users find that it is easier to distribute their program using a form if they embed the form file in their SKILL code. In this case use SKILL to open a temporary file and print the statements, open for form, then delete the file.

Tip

Use `axlFormTest`("*<form file>*") to interactively adjust of fields.

Tip

You can use "`ifdef`", "`ifndef`", and Allegro environment variables (`axlSetVariable`) to control appearance of items in the form file.

Field / Control

Most interaction to the controls are via axlFormSetField, axlFormGetField, axlFormSetFieldEditable, and axlFormSetFieldVisible.Certain controls have additional APIs which are noted in the description for the control.

Most controls support setting their background and foreground colors. See `axlColorDoc` and `axlFormColorize` for more information.

Following is a list of fields and their capabilities.

TABSET / TAB

A property sheet control. Provides the ability to organize and nest many controls on multiple tabs.

©2023 All Rights Reserved.

Unlike other form controls you nest other form controls within TAB/ENDTAB keywords. The size of the tab is control is specified by the FLOC and FSIZE keywords used as part of the TABSET definition. The single option provided to the TAB keyword serves the dual purpose of being both the display name and the tab label name. The TABSET has a single option which is the fieldLabel of the TABSET.

The TABSET has a single option – tabsetDispatch.

When a user picks on a TAB, by default, it is dispatched to the application as the with the fieldLabel set to the name of the tab and the fieldValue as a 't'. With this option we use the fieldLabel defined with the TABSET keyword and the fieldValue as the tab name. In most cases you do not need to handle tab changes in your form dispatch code but when you do each dispatch method has its advantages.

Note: TABSETs cannot be nested.

GROUP

A visible box around other controls. As such, you give it a width, height and optional text. If width or height is 0, we draw the appropriate horizontal or vertical line. Normally the group text is static but you can change it at run-time by assigning a label to the group.

TEXT

Static text, defined in the form file with the keyword "TEXT". The optional second field (use double quotes if more then one word) is any text string that should appear in the field. An optional third field can be use to define a label for run-time control. In addition the label INFO can be used to define the field label and text width.

Multi-line text can be specified by using the FSIZE label with a the height greater then 2. If no FSIZE label is present then a one-line text control is assumed where the field width is specified in the INFO label.

OPTIONS include (form file)

any of:

bold - text is displayed in bold font

underline - text is displayed with underline

border - text is displayed with a sunken border

prettyprint - make text more read-able using upper/lower case

©2023 All Rights Reserved.

and one of justification:

left - left justified (default)

center - center text in control

right - right justify text

STRFILLIN

Provides a string entry control. The STRFILLIN keyword takes two required arguments, width of control in characters and string length (which may be a larger or smaller value then the width of the control).

There are three variations of the fillin control.

- single line text
- single line text with a drop-down (use POP keyword).
  The drop-down provides the ability to have pre-defined values for the user.
- multi-line text control. Use a FSIZE keyword to indicate field width and height.

INTFILLIN

Similar to a STRFILLIN except input data is checked to be an integer (numbers 0 to 9 and + and -). Use the LONGFILLIN keyword with two arguments; field width and string length.

It only supports variations 1 and 2 of STRFILLIN.

It also supports a minimum and maximum data verification. This can be done via the form file with the MIN and MAX keywords or at run-time via `axlFormSetFieldLimits`.

INTSLIDEBAR

This is a special version of the INTFILLIN, it provides an up/down control to the right of the field that allows the user to change the value using the mouse. You should use MIN/MAX settings to limit the allowed value.

©2023 All Rights Reserved.

REALFILLIN

Similar to INTFILLIN except supports floating point numbers. Edit checks are done to only allow [0 to 9 .+-]. If addition to min/max support you can also provide number of decimals via the DECIMAL keyword or at run-time via `axlFormSetDecimal`.

MENUBUTTON

Provides a button control. Buttons are stateless. The MENUBUTTON keyword takes two options; width and height.

A button has one option – multiline.

If button text cannot fit on one line wrap it. Otherwise text is centered and restricted to a single line.

A button can have a popup by inserting the "POP" label.

With no popup pressing the button dispatches a value of 1. If it is a button with a popup then the dispatch is the dispatch entry of the popup.

Standards:

- use "..." if button brings up a file browser
- append "..." to text of button if button brings up another window
- use these labels for:

  close - to Close dialog without

  done/ok - to store changes and close dialog

  cancel - to cancel dialog without making any changes

  help - The is reserved for cdsdoc help

  print - do not use (will get changed to Help).

CHECKLIST

Provides a check box control (on/off). Two variants are supported:

- a check box

©2023 All Rights Reserved.

- a radio box

For both types the CHECKLIST control takes an argument for the text that should appear to the right of the checkbox.

A radio box allows you to several checkboxes to be grouped together. The form package insures only one radio box be set. To enable a radio grouping provide a common text string as a third argument to the CHECKLIST keyword. An idiosyncrasy of a radio box is that you will be dispatched for both the field being unset and also for the field being set.

ENUM *(sometimes called combo box)*

Provides a drop-down to present the user a fixed set of choices. The drop-down can either be pre-defined in the form file via the POPUP keyword or at run-time with `axlFormBuildPopup`. Even if you choose to define the popup at run-time, you must provide a POPUP placeholder in the form file.

POPUP entries are in the form of display/dispatch pairs. Your setting and dispatching of this field must be via the dispatch item of the popup (you can always make both the same). This technique allows you to isolate what is displayed to the user from what your software uses. The special case of nil as a value to axlFormSetField will blank the control.

Two forms of ENUM field are supported, the default is single line always has the drop-down hidden until the user requests it. In this case only define the ENUMSET with the width parameter. A multi-line version is available where the drop-down is always displayed. To enable the multi-line version specify both the width and height in ENUMSET keyword.

Tip

FILLIN fields also offer ENUM capability, see below.

OPTIONS include (form file)

- prettyprint – make text more read-able using upper/lower case.
- ownerdrawn – provided to support color swatches next.to subclass names. See axlSubclassFormPopup.
- dispatchsame – Normally if user selects same entry that is currently shown it will not dispatch.

©2023 All Rights Reserved.

LIST

A list box is a control that displays multiple items. If the list box is not large enough to display all the list box items at once, the list box provides the required horizontal or vertical scroll bar.

We support two list box types; single (default) and multi-selection. You define a multi-select box in form file with a "OPTIONS multiselect" List boxes have a width and height specified by the second and third options to the LIST keyword. The first option to the LIST keyword is ignored and should always be an empty string ("").

List box options are:

SORT - alphabetical sort.

ALPHANUMSORT - takes in account trailing numbers so a NET2 appears before a NET10 in the list.

PRETTYPRINT - case is ignored and items are reformatted for readability.

Special APIs for list controls are: `axlFormListOptions`, `axlFormListDeleteAll`, `axlFormListSelect`, `axlFormListGetItem`, `axlFormListAddItem`, `axlFormListDeleteItem`, `axlFormListGetSelCount`, `axlFormListGetSelItems`, `axlFormListSelAll`.

For best performance in loading large lists consider passing a list of items to `axlFormSetField`.

THUMBNAIL

Provides a rectangular area for bitmaps or simple drawings. You must provide a FSIZE keyword to specify the area occupied by the thumbnail.

In bitmap mode, you can provide a bitmap as an argument to the THUMBNAIL keyword or at run time as a file to `axlFormSetField`. In either case, BMPPATH and a `.bmp` extension is used to locate the bitmap file. The bitmap should be 256 colors or less.

For bitmaps one OPTION is supported:

stretch - draw bitmap to fill space provided. Default is to center bitmap in the thumbnail region.

In the drawing mode you use the APIs provided by `axlGRPDoc` to perform simple graphics drawing.

©2023 All Rights Reserved.

TREEVIEW

Provides a hierarchical tree selector. See axlFormTreeViewSet.

GRID

This provides a simple spreadsheet like control. See axlFormGridDoc for more info.

COLOR

Provides a COLOR swatch. Can be used to indicate status (for example: red, yellow, green). The size of the color swatch is controlled by a width and height option the COLOR keyword.

Add the INFO_ONLY keyword to have a read-only color swatch. Without INFO_ONLY the color swatch provides CHECKBOX like functionality via its up/down appearance.

With COLOR swatches you can use predefine colors or Allegro database colors. See axlColorDoc.

TRACKBAR

Provides a slider bar for setting integer values. The TRACKBAR keyword takes both a width and height and the bar may be either horizontal or vertical.

The length of step of the trackbar can be set in the form file where MIN is the tick mark interval and MAX is the length of the trackbar. The minimum tick mark is 1 and is usually indicated by setting MIN to 0 in the form file.

You can change the length and tick mark interval at run-time through `axlFormSetFieldLimits`

The trackbar indicator can be moved through `axlFormSetField`.

PROGRESS

Provides a progress bar usually used to indicate status of time consuming operations. For setting options to the progress meter pass of list of 3 items to axlFormSetField which are (<step value> <number of steps> <initial position>). A subsequent nil passed to axlFormSetField will step the meter by the *<step value>*.

PROGRESS keyword provides for both a width and height of the bar. Bar should be horizontal.

©2023 All Rights Reserved.

You get information from the user using forms that support the following modes:

Table 11-1 Form Modes

Form Mode	Description
Blocking with no callback	Easy to program. Limited to user interaction, such as checking that the information entered for each field uses syntax acceptable to the form's package. Your program calls `axlUIWBlock` after displaying the form. The user can close a form that has the standard *OK* or *Cancel* button. After *OK* or *Cancel* is selected, `axlUIBlock` returns allowing you to query field values using `axlFormGetField`. **Note:** Use this programming model only with simple forms.
Blocking with callback	Prevents use of Allegro PCB Editor until the user enters information in the dialog. The form callback you provide lets your interactive program accept the data entered.
Callback with no blocking	Works like many native Allegro PCB Editor forms. The user can work with both the form and other parts of Allegro PCB Editor. With Allegro PCB Editor database transactions, the programming is more complex. You can use transactions while the form is open by declaring your command interactive. You end your command when another Allegro PCB Editor command starts by using `axlEvent`.
Options form	Allegro PCB Editor window to the left of the canvas. The options (ministatus) form is non-blocking and restricted to the Options panel size. See `axlMiniStatusLoad` for details.

Do not attempt to set the Button field (except *Done*, *Cancel* and *Help*), as it is designed to initiate actions. Consequently, having buttons in a form without a callback function registered renders those buttons useless.

©2023 All Rights Reserved.

Note: AXL-SKILL does not support the short fields and variable tiles which are part of the Allegro PCB Editor core form package.

You can set background and foreground color on many form fields. For more information, see axlFormColorize on page 888. For information on color specific to grids, see Using Grids on page 805.

Examples

These examples, especially the basic one, help you understand how the forms package works:

`basic`	Demonstrates basic form capabilities.
`grid`	Demonstrates grid control capabilities.
`wizard`	Demonstrates use of a form in Wizard mode.

Use the examples located in `<cdsroot>/share/pcb/examples/form` as follows:

1. Copy all the files from one of the directories to your computer.
2. Start Allegro PCB Editor.
3. From the Allegro PCB Editor command line, change to the directory to which you copied the files as shown:

   ```
   cd <directory>
   ```

4. Load the SKILL file in the directory.

   Note: The SKILL file has the `.il` extension.

   ```
   skill load "<filename>"
   ```

5. Start the demo by typing on the Allegro PCB Editor command line as shown:

   For basic demo:

   ```
   skill formtest
   ```

   For grid demo:

   ```
   skill gridtest
   ```

6. Examine the SKILL code and form file.

©2023 All Rights Reserved.

Tip

Setting the Allegro PCB Editor environment variable `TELSKILL` opens a SKILL interpreter window that is more flexible than the Allegro PCB Editor command area. On UNIX, if you set this variable before starting the tool then the SKILL type-in area is the X terminal you used to start Allegro PCB Editor. See the enved tool to configure the width and height of the window.

Using Forms Specification Language

Backus Naur Form (BNF) is a formal notation used to describe the syntax of a language. Form File Language Description is the BNF grammar for the Forms Specification Language. Forms features in new versions are not backwards compatible.

©2023 All Rights Reserved.

The following table shows the conventions used in the form file grammar:

Convention	Description
`[ ]`	Optional
`{ }`	May repeat one or more times
`< >`	Supplied by the user
`|`	Choose one or the other
`:`	Definition of a token
`CAPS`	Items in caps are keywords

The BNF format definition follows.

```
BNF:
form:
        FILE_TYPE=FORM_DEFN VERSION=2
        FORM [form_options]
        formtype
        PORT w h
        HEADER "text"
        form_header
        {tile_def}
        ENDFORM
formtype:   FIXED | VARIABLE
                - FIXED forms have one unlabeled TILE stanza
                - VARIABLE forms have one or more label TILE stanzas
                - Skill only supports FIXED form types.
PORT:
            -   Width and height of the form. Height is ignored for fixed forms
                  which auto-calculate required height.Width must be in character
                  units.
HEADER:
            -   Initial string used in the title bar of the form. This may be
                  overridden by the application.
form_header:
            [{default_button_def}]
            [{popup_def}]
            [{message_def}]
default_button_def:
```


©2023 All Rights Reserved.

```
            DEFAULT <label>
            -   Sets the default button to be <label>. If not present, the form
                  sets the default button to be one of the following: ok (done),
                  close, or cancel.
            -   Label must be of type MENU BUTTON.
popup_def:
        POPUP <<popupLabel>> {"<display>","<dispatch>"}.
            -   Popups may be continued over several lines by using the backslash
                  (\) as the last character on a line.
message_def:
        MESSAGE messageLabel messagePriority "text"
form_options:
        [TOOLWINDOW]
            -   This makes a form a toolwindow which is a floating toolbar. It is
                  typically used as a narrow temp window to display readouts.
        [FIXED_FONT]
            -   By default, forms use a variable width font. This option sets the
                  form to use a fixed font. Allegro PCB Editor uses mostly variable
                  width while SPECCTRAQuest and SigXP use fixed width fonts.
        [AUTOGREYTEXT]
            -   When a fillin or enum control is greyed, grey static text to the
                  left of it.
        [UNIXHGT]
            -   Works around a problem with Mainsoft in 15.0 where a button is
                  sandwiched vertically between 2 combo/fillin controls. The
                  button then overlaps these controls. This adds extra line spacing
                  to avoid this. You should only use this option as a last resort.
                  In a future release, it may be treated as a Nop. On Windows, this
                  is ignored.
tile_def:
        TILE [<tileLabel>]
        [TPANEL tileType]
        [{text_def}]
        [{group_def}]
        [{field_def}]
        [{button_def}]
        [{grid_def}]
        [{glex_def}]
        ENDTILE
tabset_def:
        TABSET [label]
        [OPTIONS tabsetOptions]
        FLOC x y
        FSIZE w h
        {tab_def}
```


©2023 All Rights Reserved.

```
        ENDTABSET
tab_def:
        TAB "<display>" [<label>]
        [{text_def}]
        [{group_def}]
        [{field_def}]
        [{grid_def}]
        ENDTAB
text_def:
        TEXT "display" [label]
        FLOC x y
        [FSIZE w h]
        text_type
        [OPTIONS textOptions]
        ENDTEXT
text_type:
        [INFO label w] |
        [THUMBNAIL [<bitmapFile>|#<resource>] ]
group_def:
        GROUP "display" [label]
        FLOC x y
        [INFO label]
        FSIZE w h
        ENDGROUP
field_def:
        FIELD label
        FLOC x y
        [FSIZE w h]
        field_type
        field_options
        ENDFIELD
button_def:
        FIELD label
        FLOC x y
        [FSIZE w h]
        MENUBUTTON "display" w h
        button_options
        ENDFIELD
grid_def:
        GRID fieldName
        FLOC x y
```


©2023 All Rights Reserved.

```
        FSIZE w h
        [OPTIONS INFO | HLINES | VLINES | USERSIZE ]
        [POP "<popupName>"]

        [GHEAD TOP|SIDE]
        [HEADSIZE h|w]
        [OPTION 3D|NUMBER]
        [POP "<popupName>"]
        [ENDGRID]
        ENDGRID

field_type:
        REALFILLIN w fieldLength |
        LONGFILLIN w fieldLength |
        STRFILLIN w fieldLength |
        INTSLIDEBAR w fieldLength |
        ENUMSET w [h] |
        CHECKLIST "display" ["radioLabel"] |
        LIST "" w h |
        TREEVIEW w h |
        COLOR w h |
        THUMBNAIL [<bitmapFile>|#<resource>] |
        PROGRESS w h
        TRACKBAR w h

field_options:
        [INFO_ONLY]
            -   Sets field to be read-only

        [POP "<popupName>"]
            -   Assigns a popup with the field.
            -   A POPUP definition by the same name should exist.
            -   Supported by field_types: xxxFILLIN, INTSLIDEBAR, MENUBUTTON,and
                  ENUMSET.
        [MIN <value>]
        [MAX <value>]
            -   Assigns a min and/or max value for the field.
            -   Both supported by field types: LONGFILLIN, INTSLIDEBAR,
                  REALFILLIN.
            -   Value either an integer or floating point number.
```


©2023 All Rights Reserved.

```
        [DECIMAL <accuracy>]
            -   Assigns a floating min and/or max value for the field.
            -   Assigns the number of decimal places the field has (default is 2)
            -   Both supported by field_types: REALFILLIN

        [VALUE "<display>"]
            -   Initial field value.
            -   Supported by field_types: xxxFILLIN
        [SORT]
            -   Alphanumeric sorted list (default order of creation)
            -   Supported by field_type: LIST
        [OPTIONS dispatchsame]
            -   For enumset fields only
            -   If present, will dispatch to application drop-down selection even
                  if the same as current. By default, the form's package filters
                  out any user selection if it is the same as what is currently
                  displayed.
        [OPTIONS prettyprint]
            -   For enumset fields only.
            -   Displays contents of ENUM field in a visually pleasing way.
        [OPTIONS ownerdrawn]
            -   For enumset fields only.
            -   Used to display color swatches in an ENUM field. See
                  axlFormBuildPopup.
x:
y:
w:
h:
        -   Display geometry (integers)
        -   All field, group and text locations are relative to the start of the
               tile they belong or to the start of the form in the case of FIXED
               forms.
        -   x and h are in CHARHEIGHT/2 units.
        -   y and w are in CHARWIDTH units.
button_options:
    [MULTILINE]
        -   Wraps button text to multiple lines if text string is too long for a
               single line.
dispatch:
        -   String that is dispatched to the code.

display:
        -   String that is shown to the user.
```


©2023 All Rights Reserved.

```
bitmapFile:
        -   Name of a bmp file. Finds the file using BITMAPPATH

resource:
        -   Integer resource id (bitmap must be bound in executable via the
               resource file). '#' indicates it is a resource id.
        -   Not supported in AXL forms.

fieldLength:
        -   Maximum width of field. Field scrolls if larger than the field display
               width.
label:
        -   Name used to access a field from code. All fields should have unique
               names.
        -   Labels should be lower case.

messageLabel:
        -   Name used to allow code to refer to messages.
        -   Case insensitive.

messagePriority:
        -   Message priority 0 - (not in journal file), 1 - information, 2 -
               warning, 3 - error, 4 - fatal (display in message box)

radioLabel:
        -   Name used to associate several CHECKLIST fields as a radio button set.
               All check fields should be given the same radioLabel.
        -   Should use lower case.

textOptions:
        [RIGHT | CENTER | BORDER | BOLD | UNDERLINE]
        -   TEXT/INFO field type
        -   text justification, default is left
        -   BORDER: draw border around text
        [STRETCH]
            -   THUMBNAIL field type
            -   Stretch bitmap to fit thumbnail rectangle, default is center
                  bitmap.

tabsetOptions:
        [tabsetDispatch]
```


©2023 All Rights Reserved.

```
            -   By default, tabsets dispatch individual tabs as seperate events.
                  This is not always convenient for certain programming styles.
                  This changes the dispatch mode to be upon the tabset where a
                  selection of a tab causes the event:

                  field=tabsetLabel value=tabLabel

                The default is:

                  field=tabLabel value=t

                Script record/play remains based upon tab in either mode.


tileLabel:
        -   Name used to allow code to refer to this tile.
        -   Should use lower case.
        -   Only applies to VARIABLE forms.
        -   Not supported with AXL forms.


tileType[0|1|2]
        -   0 top tile, 1 scroll tile, 2 bottom tile
        -   Only applies to VARIABLE FORMS.
        -   Region where tile will be instantiated. Forms have the following
               regions: top, bottom, and scroll (middle).
        -   Not supported with AXL forms.


flex_def:Rule based control sizing upon form resize (see axlFormFlex)
        [FLEXMODE <autorule>]
        [FLEX <label> fx fy fw fh]


FLEXMODE <autoRule>
FLEX    fx fy fw fz
        -   see axlFormFlexDoc


autorule:-  Generic sizing placement rule.
fx:
fy:
fh:
        -   Floating value between 0 and 1.0
```

Follow these rules when using BNF format:

- `FILE_TYPE` line must always appear as the first line of the form file in the format shown.
- Form files must have a `.form` extension.
- There may only be one `FORM` in a form file.

©2023 All Rights Reserved.

- There must be one and only one `TILE` definition in a `FIXED` form file. `<tileLabel>` and `TPANEL` are not required.
- Unless otherwise noted, character limits are as follows:
  labels - 128
  title - 1024
  display - 128 except for *xxx*`FILLIN` types which are 1024
- Additional items may appear in existing form files (`FGROUP`) but they are obsolete and are ignored by the form parser. `REALMIN` and `REALMAX` are obsolete and replaced by `MIN` and `MAX` respectively. They will still be supported and are mapped to `MIN` and `MAX`.
- For *grid_def*, two headers (side and top) are maximum.
- `FSIZE` - Most controls determine the size from the text string.
  You must provide `FSIZE` for `GROUP`, `GRID`, `TREEVIEW` and `LIST` controls. For `TEXT` controls, if `FSIZE` is provided, it overrides the width calculated by the text length and, if present, the `INFO` width. If using the `INFO` line, put the `FSIZE` line after it.
- Both `TEXT` and `GROUP` support the optional label on their definition line. This was added as a convenience in supporting `FLEX` capability. If the application wishes to dynamically modify the text, the `INFO` keyword is normally used. When both are present, the `INFO` keyword takes precedence.
- If the optional label for `TABS` is not provided, the field display name is used. Any spaces within the field display name are replaced by underscores (`"_"`).
- The height ([*h*]) for `ENUMSET` is optional. When not set (the default), the drop-down is only presented under user control. When height is greater than 1, the drop-down is always visible (Microsoft SIMPLE drop-down). Only use this feature in forms that can afford the space consumed by the drop-down.

©2023 All Rights Reserved.

The forming syntaxes are NOT supported by the form editor.

This syntax is supported and may be placed anywhere in the form file to support conditional processing of the form file:

```
#ifdef <variable>
{}

{ #elseif <variable>
    }
{   #else
{}  }
```

Moving and Sizing Form Controls During Form Resizing

You can use the axlFormFlexDoc command to move and size controls within a form based on rules described in the form file. Rules may either be general (`FLEXMODE`) or specific to a single control (`FLEX`.) Flex adjusting of the controls is adjusting the form larger than its base size. Sizing the form smaller than the base size disables flex sizing.

Controls are divided into the following classes:

- Containers
  Containers can have other controls as members, including other containers. To be a container member is automatic; the control's *xy* location must be within the container. Container controls of the form are `TABSET`s and `GROUP`s.
- All others, including containers

All controls except `TABS`, which are locked to their `TABSET`, may be moved when a form is resized. Sizing width or height is control dependent as shown:

Table 11-2 Controls - Resizing Options

Control	Resizing Options
REALFILLIN	width
LONGFILLIN	width
STRFILLIN	width
INTSLIDEBAR	width

©2023 All Rights Reserved.

Table 11-2 Controls - Resizing Options, *continued*

Control	Resizing Options
ENUMSET	width
PROGRESS	width
TRACKBAR	width
LIST	width and height
GRID	width and height
TREEVIEW	width and height
THUMBNAIL	width and height
GROUP	width and height
TABSET	width and height
<others>	no change in size

Using Global Modes or FLEXMODE

FLEXMODE represents the general rules that apply to all controls in the form except those with specific overrides (FLEX). Only a single FLEXMODE is supported per form. The last encountered in the form file is used. The following rules are supported:

- EdgeGravity
  All controls have an affinity to the closest edge of their immediate container. Exceptions are: *<xxx>*FILLIN and INTSLIDEBAR controls. The edge gravity, for these, is based upon a TEXT control positioned to the left of the control.
- EdgeGravityOne
  Similar to EdgeGravity except that controls are only locked to the right or bottom edge, but not both. The closest edge is used.
- StandButtons
  Only effects button controls. Uses the same logic as EdgeGravityOne.

FLEXMODE can have an optional pair of additional arguments that specify the minimum form width and height for flexing. The argument values are in character units. Flexing will stop in the given direction when the width/height goes below the specified value.

©2023 All Rights Reserved.

Managing Sizing and Movement of Individual Controls

You use the `FLEX` parameter to manage the sizing and movement of individual controls as shown:

```
FLEX fx fy fw fh
```

The `FLEX` parameter overrides any `FLEXMODE` in effect for that control, and is based upon parameters (*fx*, *fy*, *fw*, *fh*). These values, which are floating point numbers between 0.0 and 1.0, control the fraction of the change in container size that the control should move or change in size:

fx and fy Parameters

`0`	Control remains locked to the left or top edge of its container.
`1`	Control remains locked to the right or bottom edge of its container.

fw and fh Parameters

`0`	Control is not resized.
`1`	Control is resized in width or height based upon the size change of its container.

A container's position and size effect the container's member controls. Containers are hierarchical. Make sure the container of the control also has a `FLEX` constraint. The sum of the width and height of the immediate controls of a container should not be greater than `1` to prevent overlapping. `TABSETS` are slightly different since sizing of their member controls is also based on the `TAB` they belong to.

Caution

It is possible to create FLEX constraints that result in overlapping controls. FLEX does not protect against this.

FLEX Restrictions

- The form must be `FIXED`.
- While `FLEX` rules may appear anywhere in the form file, they should be grouped together immediately before the `<ENDTILE>`

©2023 All Rights Reserved.

- Range errors for `FLEX` option or applying width or height to controls not supporting them are silently ignored.

Example 1

```
FLEXMODE standbuttons
FLEX list 0 0 1 1
```

Simple list-based form with buttons (label of `LIST` is list.) The list gets all of form sizing.

Example 2

```
FLEXMODE EdgeGravity
FLEX a 0 0 0.33 1
FLEX b 0.33 0 0.67 1
FLEX c 0.67 0 1 1
```

Form containing 3 lists (`a`, `b`, and `c`) positioned equally across the form. Each list gets the total change in height, but shares in the increase in form width. Thus, if the form changes width, each control gets 1/3 of this change. Since the list's widths change, the list must move to the right.

Example 3

```
FLEX l1 0 0 1 0.5
FLEX g1 0 0.5 1 0.5
FLEX l2 0 0 1 1
```

Form has a group (`g1`) containing a list (`l2`). These are at the bottom of another list (`l1`). Both lists share in any change of the form size. The second list (`l2`) is a member of the group container (`g1`), so it moves if the group moves (`0` for `y`) and it gets all of the group resizing (`h` is `1`).

Example 4

```
FLEX g1 1 1 0 0
FLEX l1 0 0 1 1
```

Form has a group (`g1`) with a list member (`l1`), but the list doesn't resize because the list is a member of the group which has `0:0` sizing. Though the list has `1:1` sizing, it never changes in size because its container never changes in size. Both the group and its member list move because the group has a `1:1` *x/y* factor.

©2023 All Rights Reserved.

Example 5

```
FLEX t1 0 0 1 1
FLEX l1 0 0 1 1
FLEX l2 0 0 1 1
```

Form is a tabset (`t1`) with 2 tabs. Each tab controls a list (`l1` and `l2`) that accommodates the maximum change in the form size.

➤ Use `axlFormTest(<formname>)` to experiment with your form.

©2023 All Rights Reserved.

Using Grids

You can use the axlFormGridDoc function to control grids. Grids offer tabular support and the following features:

- Optional side and top headers
- Several data types on a per column basis: Text (info), Checkbox with optional text, Enum (Drop-drop) and Fillin (text box with built-in types: string, integer, and real.)
- Row and column indexing which is 1-based

Grids have the following limits:

- Maximum of 200 columns
- Maximum rows of 1,000,000
- Maximum field string length per column of 256 characters
- Column creation only at grid initialization time.

Form File Support for Grids

The following defines the form file structure relating to grids.

```
GRID
    Standard items
        FLOC-   x, y location
        FSIZE-  width and height including headers if used
        POP -   Optional right button popup for body. Also requires application to
                    set the GEVENT_RIGHTPOPUP option.
    OPTIONS:
        INFO-   Entire grid is info-only even if it contains typeable fields
        HLINES- Draw horizontal lines between columns
        VLINES- Draw vertical lines between rows
        USERSIZE-Allow user to resize columns.
         MULTISELROWallows multi-row select (also set via Skill API,
                    axlFormGridEvents)


HEADERS (GHEAD)
    -   Specified within GRID section.
    -   TOP and SIDE header (only one per type allowed in a grid)
    HEADSIZE-Height (TOP) or width (SIDE) for the header.
    OPTIONS:
```


©2023 All Rights Reserved.

```
        3D  -   Display raised.
        NUMBER- For side header, display row number if application does not provide
                    text.
    POP -   Optional right mouse button popup. One per header. Requires application
                    to set GEVENT_RIGHTPOPUP for the header.
```

Programming Support for Grids

The following Grid APIs are available:

`axlFormGridInsertCol`	Insert a column.
`axlFormGridInsertRows`	Insert one or more rows.
`axlFormGridDeleteRows`	Delete one or more rows.
`axlFormGridEvents`	Set grid events.
`axlFormGridOptions`	Miscellaneous grid options.
`axlFormGridNewCell`	Obtain structure for setting a cell.
`axlIsGridCellType`	Is item a cell data type.
`axlFormGridSetBatch`	For setting multiple cells.
`axlFormGridGetCell`	For getting cell data.
`axlFormGridBatch`	Used with `axlFormGridSetBatch`
`axlFormGridUpdate`	Update display after changes.
`make_formGridCol`	For defstruct `formGridCol`
`copy_formGridCol`	For defstruct `formGridCol`

©2023 All Rights Reserved.

In addition, the following standard form APIs may be used:

`axlFormSetFieldVisible`	Set grid visibility
`axlFormIsFieldVisible`	Is field visible
`axlFormSetFieldEditable`	Set grid editability
`axlFormIsFieldEditable`	Is field editable
`axlFormBuildPopup`	Change a popup
`axlFormSetField`	Set individual cell.
`axlFormRestoreField`	Restore last cell changed.Restore supports undoing last *change* event.Adding, deleting, or right mouse event reset restore.

Multi-row select support functions:

`axlFormGridSetSelectRows`	control selection of rows
`axlFormGridSelectedCnt`	number of rows selected
`axlFormGridSelected`	list of rows selected

Data Structures

`r_cell`	User data type for cell update (see axlFormGridNewCell on page 905)
`r_formGridCol`	Defstruct to describe column (see axlFormGridInsertCol on page 900)

Column Field Types

Grids support the assignment of data types by column. You may change an editable cell into a read-only cell by assigning it a *`s_noEdit`* or *`s_invisible`* attribute. See `axlFormGridInsertCol` for a complete description of column attributes and `axlFormGridSetBatch` for a discussion of cell attributes.

`TEXT`	Column is composed of display only text.
`STRING`	Column supports editable text. See edit-combo.

©2023 All Rights Reserved.

`LONG`	Column supports numeric data entry cells. See edit-combo.
`REAL`	Column supports numeric floating point entry cells. See edit-combo.
`ENUMSET`	Column supports combo-box (drop-down) cells. Must have a popup attribute on the column.
`CHECKITEM`	Column has checkbox cells with optional text.
`EDIT-COMBO`	By assigning a popup attribute at the column and/or at the cell level, you can change STRING, LONG, and REAL types to support the original text editing field with the addition of a drop-down.

Initializing the Grid

Once a grid is defined in the form file, you can initialize the grid as follows:

1. Create required columns using `axlFormGridInsertCol`
2. Create initial set of rows using `axlFormGridInsertRows`
3. Create initial grid cells and headers using `axlFormGridSetBatch`, then on callback, use:
   a. `axlFormGridNewCell`
   b. `axlFormGridSetBatch`
4. Set event filters using `axlFormGridOptions`.
5. Display the grid using `axlFormGridUpdate`.

See `grid.il` and `grid.form` for a programming example. You can find these in the AXL Shareware area:

```
<CDS_INST_DIR>/share/pcb/etc/skill/examples/ui
```

Dispatching Events

Unlike other form controls, an application can specify what events are dispatched. You control this using the `axlFormGridEvents` API which documents the usage. Also, the form callback structure has new fields for grids (see axlFormGridEvents on page 895.)

By default, you create a grid with the ’rowselect enabled which is typically appropriate for a multi-column table.

©2023 All Rights Reserved.

Multi-row Selection

A super-set of row selection is the multi-row selection option. With this option the user can select multiple rows. Grids running in this mode do now support cell select or change options.

This is set in SKILL via:

```
axlFormGridEvents(<form> <grid> '(mrowselect))
```

or from the formfile by adding the `MULTISELROW` option to the grid's `OPTION` line.

Standard selection model is supported (not extended). This means:

- left click selects a row
- shift-left click selects all rows between the initial and current row
- ctrl-left click on to selection of row that is currently selected, it de-selects
- control-a selects all rows

APIs are provided (see above) to get current selected rows and set or clear row selections.

Finally, since multiple rows may be selected the standard form callback mechanism only informs you of a selection event. You need to utilize axlFormGridSetSelectRows to determine the current selection.

Using Scripting with Grid Controls

Unlike most other form controls where the programmer needs no concern over scripting, grid programmers should address scripting. By default, the grid uses the event type and row/column number for scripting. Depending on your application, this may create scripts that do not replay given different starting data. Grids support assigning script labels to rows, to columns, and on a per cell basis.

You label by setting the *`scriptLabel`* attribute from the application code with the `axlFormGridInsertCol` function for a column or the `axlFormGridNewCell` function for a row, column, or per cell basis. You can also change this dynamically. Note that (`row=0`, `col=`*`n`*) sets the *`scriptLabel`* for the column using `axlFormGridNewCell` and (`row=`*`n`*, col=0) allows setting for row script labels.

The grid script line format extends upon the standard form scripting as shown:

```
FORM <formname> [tileLabel] <fieldLabel> <event> <glabel> [<value>]
```

where

```
FORM <formname> [tileLabel] <fieldLabel>
```


©2023 All Rights Reserved.

```
    -   standard form script form fieldLabel is the grid label
    <event> is the grid event. Grid events include:
        rowselect:= GEVENT_ROWSELECT
        cellselect:= GEVENT_CELLSELECT
        change:= GEVENT_CELLCHANGE
        rpopup:= GEVENT_RIGHTPOPUP
        rprepopup:= GEVENT_RIGHTPOPUPPRE
        lprepopup:= GEVENT_LEFTPOPUPPRE
    <glabel> label corresponds to the location in the grid the event
        occurred.
    [<value>] optional value depending upon event.

Depending on the event, the rest of the script line appears as follows:
rowselect<glabel:=row>
cellselect<glabel:=cell>
change<glabel:=cell> <value>
rpopup<glabel:=cell> <popup value>
rprepopup<glabel:=cell>
lprepopup<glabel:=cell>
```


©2023 All Rights Reserved.

The *glabel* has several format options depending on the event:

row	If the row has a *scriptLabel*, it is used, otherwise the row number is used.
cell	If the cell has a label, that is used. If the cell does not have a label, the row and /or column labels are used. If either the row or column does not have labels, the row and/or column number is used.

When you set a *scriptLabel* to row, col, or cell, the following character set is enforced: case insensitive, no white space or comma or $. Labels with these characters are replaced by an underscore (_). You may use pure numeric strings, but if you do not label everything, scripts may fall back and use the row/grid number to resolve a number not found as a script label string.

Notes

- If you use row and col as the *glabel*, use a comma (,) to delineate between the row and column name and number.
- Do not turn on events that you do not plan to process since scripts record them. For instance, if you only process on rowselect (no editable cells), then only enable rowselect. As a side benefit, you do not have to label columns or cells since row label is sufficient.
- If you use a row and/or column heading, you may use that for assigning *scriptLabels*.

Examples

- If grids replace the text parameter form, you need not label the columns. A column number is sufficient. You can label the columns for script readability. This application does not require cell labeling.
- If grids replace the color form for certain color grids, like stackup, you would need to label each cell. Each class grouped in the stackup grid is not row consistent. For example, depending on design, subclasses are not the same going across the rows. Other groupings require labeling on class for col and subclass for row since it is orthogonal.

See Using Grids on page 805 for a grid overview.

©2023 All Rights Reserved.

Headers

You can set column (top) headers either using `axlFormGridInsertCol` at column creation time, or using `axlFormGridSetBatch` if you need to change the header using row number `0`.

Row (side) headers default to automatic run numbers with this option set in the form file. Using `axlFormGridSetBatch`, you can set the text for individual rows using col number `0`.

©2023 All Rights Reserved.

AXL Forms: Example 1

```
FILE_TYPE=FORM_DEFN VERSION=2
FORM
FIXED
PORT 50 11
HEADER "Extract Selector"
TILE
TEXT "Select View File to Extract"
TLOC 12 1
ENDTEXT
TEXT "View File:"
TLOC 1 12
ENDTEXT
FIELD view_file
FLOC 12 12
STRFILLIN 24 24
ENDFIELD
FIELD file_list
FLOC 5 3
LIST "" 40 5
ENDFIELD
FIELD cancel
FLOC 5 15
MENUBUTTON "Cancel" 8 3
ENDFIELD
FIELD done
FLOC 15 15
MENUBUTTON "Done" 9 3
ENDFIELD
FIELD print
FLOC 25 15
MENUBUTTON "Print" 9 3
ENDFIELD
FIELD script
FLOC 35 15
MENUBUTTON "Script" 11 3
```


©2023 All Rights Reserved.

```
ENDFIELD
ENDTILE
ENDFORM
```

- Uses a form file (expected to be in the current directory) that can display a selection list.
- Gets the list of available extract definition (view) files pointed to by the `TEXTPATH` environment variable.
- Displays the list in the form.

  The user can then select any filename listed, and the name displays in the *View File* field.

  Selecting the *Done* button causes the form to call `axlExtractToFile` with the selected extract filename as the view file, and `myextract.dat` as the extract output filename, and closes the form. Selecting *Cancel* cancels the command and closes the form.

  The form file has `FIELD` definitions for the selection list, the *View File* field, and each of the buttons (*Cancel*, *Done*, *Print* and *Script*).

©2023 All Rights Reserved.

```
; myExtractViews.il
;             -- Displays a form with a selection list of
;                  the available extract definition files
;             -- Lets the user select any of the files on
;                  the list as the "View file"
;             -- Starts Allegro extract process with the
;                  user-selected View file when
;                 the user picks Done from the form.

; Function to extract user selected view to the output file.
(defun myExtractViews (viewFile outFile)
     axlExtractToFile( viewFile outFile)
); defun myExtractViews
; Function to start the view extraction
(defun _extract ()
 myExtractViews(
buildString(list(cadr(parseString(
    axlGetVariable("TEXTPATH"))) selectedFile) "/")
             "myextract.dat")
); defun _extract
; Form callback function to respond
(defun _formAction (form)
    (case form->curField
         ("done"
             (axlFormClose form)
             (axlCancelEnterFun)
             (_extract)
             t)
         ("cancel"
             (axlFormClose form)
             (axlCancelEnterFun)
             nil)
         ("view_file"
             (if form->curValue
                 (progn
                     ; Accept user input only if on list
                     if(member( form->curValue fileList)
                        then axlFormSetField( form
                             "view_file" form->curValue)
                         else axlFormRestoreField(
                                 form "view_file"))))
             t)
         ("file_list"
             (axlFormSetField form "view_file"
                form->curValue)
             selectedFile = form->curValue
             t)); case
); defun _formAction
; User-callable function to set up and
;        display the Extract Selector form
(defun myExtract ()
    fileList = (cdr (cdr (getDirFiles
    cadr( parseString( axlGetVariable("TEXTPATH"))))))
    form = axlFormCreate( (gensym)
         "extract_selector.form" '("E" "OUTER")
             '_formAction t)
 axlFormTitle( form "Extract Selector")
 axlFormSetField( form "view_file" (car fileList))
 selectedFile = (car fileList)
 foreach( fileName fileList
         axlFormSetField( form "file_list" fileName))
     axlFormDisplay( form)
); defun myExtract
```

- Creates a form named `form` with the callback function `_formAction` that analyzes user action stored in *`form->curField`* and responds appropriately.

©2023 All Rights Reserved.

- Loads the example AXL program shown.
- Enters the command `myExtract()`.

  SKILL displays the **Extract Selector** form, as specified in the form file `extract_selector.form` that this code created when it first loaded. This is a non-blocking form—you can enter other SKILL and Allegro PCB Editor commands while the form displays.

The program shows how to analyze the user selection when control passes to the callback function `_formAction`. Name of the field selected by the user is in *`form->curField`*. In this case, that is one of the strings `done`, `cancel`, `view_file`, or `file_list`. The value of the field is in *`form->curValue`*. This has a value for the `view_file` and `file_list` fields.

The actions in the `callback _formAction` are

`"done"`	The user selected the *Done* button. Closes the form, clears input using `axlCancelEnterFun`, and calls the *_extract* function to execute the data extract.
`"cancel"`	The user selected the *Cancel* button. Closes the form, clears input using `axlCancelEnterFun`, and calls the *_extract* function to execute the data extract.

©2023 All Rights Reserved.

`"view_file"`	The user selected the *View File* field, possibly typed an entry, and pressed *Return*. Sets the *`view file`* name to the current value of the *View File* field, letting the user type in a name. Name must be a name on the list displayed.
`"file_list"`	The user picked a name from the displayed list of view file names. Name picked is *`form->curValue`*, and the program sets *`selectedFile`* (the name of the currently selected extract file) to the new value, and displays it in the *View File* field.

The *Print* and *Script* buttons have pop-ups that call predefined Allegro PCB Editor functions.

AXL Forms: Example 2

The form file `popup.form` for this is shown:

```
FILE_TYPE=FORM_DEFN VERSION=2
FORM
FIXED
PORT 50 5
HEADER "Popup Selector"
POPUP <PRINTP>
    "to File""0","to Printer""1","to Script""2".
POPUP <SCRIPTP>
    "Record""record","Replay""replay","Stop""stop".
POPUP <MYPOPUP>
    "MyPopup1""myPopup1","MyPopup2" "myPopup2".
TILE
TEXT "My Popup Here:"
TLOC 1 1
ENDTEXT
FIELD my_popup
FLOC 12 3
ENUMSET 24
POP "MYPOPUP"
ENDFIELD
FIELD change_pop
FLOC 5 6
MENUBUTTON "Change" 8 3
ENDFIELD
FIELD done
FLOC 15 6
MENUBUTTON "Done" 9 3
ENDFIELD
FIELD print
FLOC 25 6
MENUBUTTON "Print" 9 3
POP "PRINTP"
ENDFIELD
FIELD script
FLOC 35 6
MENUBUTTON "Script" 11 3
POP "SCRIPTP"
```


©2023 All Rights Reserved.

```
ENDFIELD
ENDTILE
ENDFORM
```

Uses a form file (expected to be in the current directory) to create a pop-up. The sample program also displays in the pop-up field the value returned whenever the user selects a pop-up.

The form field `my_popup` originally has the popup values specified by the file `popup.form` (*MyPopup1* and *MyPopup2*). The AXL program responds to the *Change* button by building the pop-up display and returning the values.

```
list( list( "MyPop 1" "myPopValue1")
    list( "MyPop 2" "myPopValue2"))
```

A list of lists of display and dispatch string pairs.

```
list( list( "MyPop 12" 12) list( "MyPop 5" 5))
```

A list of lists of display and dispatch pairs, where the display value is a string, and the dispatch value is an integer.

```
list( "MyPopValue1" "MyPopValue2")
```

A list of strings, which means that each string represents both the display and dispatch values of that popup selection.

```
; formpop.il - Create and display a form with a popup
; Form call back function to respond to user selection of any field in the form
(defun _popAction (form)
     (case form->curField
         ("done"
            (axlFormClose form)
             (axlCancelEnterFun)
             t)
         ("change_pop"
             (case already_changed
                 (0;Use display/dispatch string pairs
                     axlFormBuildPopup(form "my_popup"
                     list(
                     list("NewPopup A" "mynewpopup_a")
                     list("NewPopup B" "mynewpopup_b")))
                    axlFormSetField(form "my_popup"
                        "My First Popups")
                )
                 (1;Display string/dispatch integer pairs
                     axlFormBuildPopup(form "my_popup"
                     list( list("NewPopup 12" 12)
                         list("NewPopup 5" 5)))
                         axlFormSetField(form "my_popup"
                            "My Second Popups")
                )
                 (t;String is both display and dispatch
                     axlFormBuildPopup(form "my_popup"
                     list( "MyPopNValue1"
```


©2023 All Rights Reserved.

```
                                "MyPopNValue2"))
                        axlFormSetField(form "my_popup"
                               "My Third Popups")
                        )
                        )
                        already_changed++
                    t)
                ("my_popup"
                     printf( "Got my_popup event:
                        form->curValue %s", form->curValue)
                     if( form->curValue
                        (progn
                         axlFormSetField( form "my_popup"
                            form->curValue)))
                 t)
             ); case
    )
; defun _popAction
; User-callable function to set up and
;   display the Extract Selector form
(defun myPop ()
    form = axlFormCreate( (gensym) "popup.form"
        '("E" "OUTER") '_popAction t)
     if( axlIsFormType(form)
        then (print "Created form successfully.")
         else (print "Error! Could not create form."))
    axlFormTitle( form "Try My Popup")
    mypopvalue = "my_start_popup"
    axlFormSetField( form "my_popup" mypopvalue)
    axlFormDisplay( form)
    already_changed = 0
); defun myPop
```

Sets the field *my_popup* to the value selected by the user and prints it.

1. Enter `myPop()` on the SKILL command line to display the **Try My Popup** form.
2. Press the middle mouse button over the pop-up field to display the original pop-up specified by the file `popup.form`.

3. Click *Change*.

©2023 All Rights Reserved.

The form displays the first set of pop-up values set by the program. The first pop-up values also display when you press the middle mouse button over the field.

4. Make a selection.

If, for example, you selected *NewPopup B*, the program prints the following on the SKILL command line:

```
Got my_popup event: form->curValue mynewpopup_b
```

The following form is displayed.

5. Click *Change*.

©2023 All Rights Reserved.

The program displays the third set of pop-ups.

©2023 All Rights Reserved.

AXL-SKILL Form Interface Functions

This section lists the form interface functions.

axlFormBNFDoc

This is the BNF grammar for the Forms Specification Language. New options and field types are added every release. Form files are always upwards compatible but may NOT be backwards compatible if you take advantage of a new feature. Thus, a form file created in 12.0 Allegro works in 13.0 Allegro. However, if you take advantage of the TAB control (13.0) or the RIGHT justification of TEXT (13.5), you will have a form file that will not function with 12.0 of Allegro.

The following outlines the conventions used in the grammar:

[]	Optional
{}	May repeat one or more times.
<>	Supplied by user.
|	Choose one or the other.
:	Definition of a token.
CAPS	Items in caps are keywords (note form parser is case insensitive)
(#)	Note: See number at end of this documentation.

BNF

form

```
FILE_TYPE=FORM_DEFN VERSION=2 (1)
FORM [form_options]     (3)
formtype
PORT w h
HEADER "text"
form_header
{tile_def}
ENDFORM
```


©2023 All Rights Reserved.

formtype FIXED | VARIABLE

- FIXED forms have a one unlabeled TILE stanza
- VARIABLE forms have one or more label TILE stanzas
- SKILL only supports FIXED form types.

PORT

- width and height of form. Height is ignored for fixed forms which auto-calculates required height. Width must be in character units.

HEADER

- initial string used in title bar of form (may be overridden by application).

form_header

[{default_button_def}]
[{popup_def}]
[{message_def}]

default_button_def

DEFAULT <label>
- sets the default button to be <label>. If not present form sets default button to one of the following:
ok (done), close, cancel.
- label must be of type MENU_BUTTON.

popup_def

POPUP <<popupLabel>> {"<display>","<dispatch>"}.

- popups may be continued over several lines by using the backslash (\) as the last character on line.

©2023 All Rights Reserved.

- popups work slightly differently when applied to fillin versus other supporting fields, such as, ENUMs and BUTTONs. With Fillin fields, such as, Strings and long, the display portion is always sent back to the application while other supporting field types, such as, ENUMs, send the dispatch portion.

The same applies with setting the field. For ENUMs, you must call the form API with the dispatch value while fillins expect the display string.

message_def

MESSAGE messageLabel messagePriority "text".

form_options

[TOOLWINDOW]
- this makes a form to be a tool window which is a floating toolbar. It is typically used as a narrow temp window to display readouts.

[FIXED_FONT]
- by default forms use a variable width font, this sets this form to use a fixed font. Allegro PCB Editor/APDuses mostly variable width while SpectraQuest (Allegro PCB SI)and SigXplorer use fixed width fonts.

Note: This option is obsolete in the 17.4 release.

[AUTOGREYTEXT]
- when a fillin or enum control is greyed, grey static text to the left of it.

[NOFOCUS]

- when a form opens focus is set to form window which allows you to immediately enter data. If you create a form with no editable fields or don't wish to have the form grab focus set this option.

[UNIXHGT]
- works around a problem with Mainsoft in 15.0 where a button is sandwiched vertically between 2 combo/fillin controls. The button then overlaps these controls. This adds extra line-2-line spacing to avoid this. You should only use this option as a last resort. In a future release it may be treated as a Nop. On Windows this is ignored.

©2023 All Rights Reserved.

tile_def

```
TILE [<tileLabel>]      (4)
[TPANEL tileType]
[{text_def}]
[{group_def}]
[{list_def}]
[{field_def}]
[{button_def}]
[{spacer_def}]
[{grid_def}]
[{flex_def}]
ENDTILE
```

tabset_def

```
TABSET [label]
[OPTIONS tabsetOptions]
FLOC x y
FSIZE w h
{tab_def}
ENDTABSET
```

tab_def

```
TAB "<display>" [<label>]       (10)
[{text_def}]
[{group_def}]
[{field_def}]
[{grid_def}]
ENDTAB
```

text_def

```
TEXT "display" [label]  (9)
FLOC x y
[FSIZE w h]             (8)
text_type
[OPTIONS textOptions]
ENDTEXT
```


©2023 All Rights Reserved.

text_type

```
[INFO label w] |
[THUMBNAIL [<bitmapFile>|#<resource>] ]
```

group_def

```
GROUP "display" [label] (9)
FLOC x y
FSIZE w h          (8)
[INFO label]
ENDGROUP
```

list_def

```
FIELD label
FLOC x y
LIST "" w h
list_options
ENDFIELD
```

field_def

```
FIELD label
FLOC x y
[FSIZE w h]        (8)
[HELPTIP "tip"]     (12)
field_type
field_options
ENDFIELD
```

button_def

```
FIELD label
FLOC x y
[FSIZE w h]        (8)
MENUBUTTON "display" w h
[OPTION button_options
[button_bitmap]
```


©2023 All Rights Reserved.

spacer_def

```
        SPACER
        FLOC x y
        [FSIZE w h]          (14)
        ENDSPACER
ENDFIELD
```

grid_def

```
        GRID fieldName
        FLOC x y
        FSIZE w h            (8)
        [OPTIONS INFO | HLINES | VLINES | USERSIZE | MULTISELROW ]
        [POP "<popupName>"]

        [GHEAD TOP|SIDE]
        [HEADSIZE h|w]
        [OPTION 3D|NUMBER|MULTI]
        [POP "<popupName>"]
        [ENDGREADH]
        ENDGRID
```

field_type

```
        REALFILLIN w fieldLength |
        LONGFILLIN w fieldLength |
        STRFILLIN w fieldLength |
        INTSLIDEBAR w fieldLength |
        ENUMSET w [h] |              (11)
        CHECKLIST "display" ["radioLabel"] |
        LIST "" w h |
        TREEVIEW w h |
        COLOR w h |
        THUMBNAIL [<bitmapFile>|#<resource>] |
        PROGRESS w h
        TRACKBAR w h
```

field_options

The OPTIONS line permits multiple options

©2023 All Rights Reserved.

[INFO_ONLY]
- sets field to be read only.

[POP "<popupName>"]
- assigns a popup with the field.
- a POPUP definition by the same name should exist.
- supported by field_types: xxxFILLIN, INTSLIDEBAR, MENUBUTTON, ENUMSET

[MIN <value>]
[MAX <value>]
- assigns a min and/or max value that field might have.
- both supported by field_types: LONGFILLIN, INTSLIDEBAR, REALFILLIN.
- value by either by an integer or floating point number.

[DECIMAL <accuracy>]
- assigns a floating min and/or max value that field might have.
- assigns number of decimal places field has (default is 2)
- both supported by field_types: REALFILLIN

[VALUE "<display>"]
- initial field value.
- supported by field_types: xxxFILLIN

[SORT]
- alphanumberic sorted list (default order of creation)
- supported by field_type: LIST

[OPTIONS dispatchsame]
- for enumset fields only.
- if present will dispatch to application drop-down selection even if the same as current. By default, the form's package filters out any user selection if it is the same as what is currently displayed.

[OPTIONS prettyprint]
- for enumset fields only
- displays contents of ENUM field in a visually pleasing way

[OPTIONS ownerdrawn]
- for enumset fields only
- used to display color swatches in an ENUM field. See `axlFormBuildPopup`.

©2023 All Rights Reserved.

[OPTIONS password]
- string type only
- Field contains a password. Mask text.

[OPTIONS space]

– string type only

– preserves leading and trailing white space. By default this is stripped.

[OPTIONS dropfile]

– string and multiline types only

– Allows a file to be dropped into the field (Windows drag and drop)
Shortcuts are not resolved.

list_options

[OPTIONS `sort|alphanumsort|prettyprint|multiselect`]
sort - conversion alphabetical sort
alphanumsort - sort so NET10 appears after NET2
prettyprint - make more readable, convert case.
All dispatch entries will be upper case multiselect - multi-select list box.
User can select more then one item (follows Microsoft selection model).

x
y
w
h

- display geometry (integers).
- all field, group and text locations are relative to the start of the tile they belong or to the start of the form in the case of FIXED forms.
- x & h are in CHARHEIGHT/2 units.
- y & w are in CHARWIDTH units.

©2023 All Rights Reserved.

button_options

[MULTILINE]
- wraps button text to multiple lines if text string is too long for a single line.

button_bitmap

```
[BITMAP [<bitmapFile>|#<resource>] ]
```

– display a bitmap for this button.

dispatch

- string that is dispatched to the code.

display

- string that is shown to user

bitmapFile

- name of a bmp file. Can be found via BMPPATH. Bitmap should be static. Animation should not be used.

- #<resource> only available for Cadence applications. It is obsolete.

resource

- integer resource id (bitmap must be bound in executable via the resource file). '#' indicates it is a resource id.
- not support in AXL forms.

fieldLength

- maximum width of field. Field will scroll if larger then field display width.

label

- named used to access field from code. All fields should have unique names.
- should use lower case.

©2023 All Rights Reserved.

messageLabel

- name used to allow code to refer to messages.
- case insensitive

messagePriority

- message priority 0 - info (not in journal file), 1 - info, 2 - warning, 3 - error, 4 fatal (display in message box).

radioLabel

- named used to associate several CHECKLIST fields as a radio button set. All check fields should be given the same radioLabel.
- should use lower case.

textOptions

RIGHT | CENTER | BORDER | BOLD | UNDERLINE]
- TEXT/INFO field type.
- text justification, default is left.
- BORDER: draw border around text.

[INVISIBLE]

field by default is not displayed

[STRETCH]
- THUMBNAIL field type.
- stretch bitmap to fit thumbnail rectangle, default is center bitmap.

[MAP3DCOLORS]
THUMBNAIL field type.
- search the color table of the `.bmp` and replace the following shades of gray with corresponding 3D color:

dk gray RGB(128,128,128) - COLOR_3DSHADOW

gray RGB(192,192,192) - COLOR_3DFACE

©2023 All Rights Reserved.

lt gray RGB(223,223,223) - COLOR_3DLIGHT

This option is typically used to blend the `.bmp`'s background color with the user's dialog background. If using this option, don't reserve these 3 gray colors for background only.

tabsetOptions

[tabsetDispatch]
- By default tabsets dispatch individual tabs as separate events. This is not always convenient for certain programming styles. This changes the dispatch mode to be upon the tabset where a selection of a tab causes the event `field=tabsetLabel value=tabLabel`.
The default is:
`field=tabLabel value=t`
Script record/replay remains based upon tab in either mode.

gridOptions:

Several of these options can also be controlled at run-time via UIFGridVarEvents or UIFGridVarOptions:

- INFO - grid is for info only; can be scrolled but items cannot be selected
- HLINES - display horizontal separator lines
- VLINES - display vertical separator lines
- USERSIZE - user can resize columns
- MULTISELROW - grid is opened in multi-select row mode

gHeadOptions:

- 3D - display header in 3d mode
- NUMBER - auto-number side header (default is blank)
- MULTI - display top header as multiple lines (default single line with clipping)

tileLabel

- name used to allow code to refer to this tile.
- should use lower case.

©2023 All Rights Reserved.

- only applies to VARIABLE forms.
- not support with AXL forms.

tileType [0|1|2]

- 0 top tile, 1 scroll tile, 2 bottom tile.
- only applies to VARIABLE FORMS.
- region where tile will be instantiated. Forms have 3 regions top, bottom and scroll (middle).
- not support with AXL forms.

flex_def - rule based control sizing upon form resize (see axlFormFlex)

[FLEXMODE <autorule> [minWidth minHeight]]
[FLEX <label> fx fy fw fh]

FLEXMODE <autoRule> [minWidth minHeight]
FLEX fx fy fw fz
- see `axlFormFlexDoc`

autorule - generic sizing placement rule

fx
fy
fw
fh

- floating value between 0 and 1.0

#ifdef:

#ifndef:

#else:

#endif:

- Conditionally read portions of the form file based upon the settings of Allegro environment variables
- These statements may be nested.

©2023 All Rights Reserved.

- Note the negation character '!' was added in 15.7. Forms using this capability will not function correctly in earlier releases.

Use #ifdef/#endif and #ifndef/#endif to make items conditionally appear in the menu depending on whether a specified environment variable is set.

An #ifdef causes the form item(s) to be ignored unless the environment variable is set. You must have one #endif for each #ifdef or #ifndef to end the block of conditional menu items. Also, the #ifdef, #ifndef and #endif must start at the first column of its line in the formfile. The #ifndef is the negation of #ifdef.

The #else statement may be inserted between the #if/#endif statements.

The condition syntax supports multiple variables with OR '||' or AND '&&' conditions. Also the negation character '!' is supported for the variables:

The simple syntax is:

```
#ifdef <env variable name>

[form items which appear if the env variable is set]

#endif

#ifndef <env variable name>

[form items which appear if the env variable is NOT set]

#endif

# logically equivalent to above state using negation character

#ifdef !<env variable name>

[form items which appear if the env variable is not set]

#endif

#ifdef <env variable name>

[form items which appear if the env variable is set]

#else

[form items which appear if the env variable is set]
```


©2023 All Rights Reserved.

```
#endif
```

Also logical statements:

1) if variable1 and variable2 are both set do the included statement

```
#ifdef <var1> && <var2>
[form items which appear if both variables are set]
#endif
```

2) if either variable1 or variable2 is do the included statement

```
#ifdef <var1> || <var2>
[form items which appear if either variable is set]
#endif
```

Notes:

- FILE_TYPE line must always appear as the first line of form file in format shown.
- Form files must have a .form extension.
- There may only be one FORM in a form file.
- There must be one and only one TILE definition in a FIXED form file. <tileLabel> and TPANEL are not required.
- Unless otherwise noted limits are as follows:
  labels - 128
  title - 1024
  display - 128 except for xxxFILLIN types which are 1024
- Additional items may appear in existing form files (FGROUP) but they are obsolete and are ignored by the form parser. REALMIN & REALMAX are obsolete and replaced by MIN and MAX respectively. They will still be supported and are mapped to MIN and MAX.
- For grid_def two headers (side and top) are maximum.
- FSIZE - most controls determine the size from the text string. You are required to provide FSIZE for GROUP, GRID, TREEVIEW and LIST controls. For TEXT controls if FSIZE is provided after it overrides the width calculated by the text length and if present the INFO width. If the INFO line appears you should put the FSIZE line after it.

©2023 All Rights Reserved.

- Both TEXT and GROUP support optional label on their definition line. This was added as a convenience in supporting FLEX capability. If application wishes to dynamically modify the text the INFO keyword is normally used. When both are present the INFO keywords takes precedence.
- If the optional label for TABS is not provided, the field display name is used. Any spaces within the field display name are replaced by underscores ("_").
- The height ([h]) for ENUMSET is option. When not set (the default) the drop-down is only presented under user control. When height greater than 1 then the drop-down is always visible (Microsoft SIMPLE drop-down). You only want to use this feature in forms that can afford the space consumed by the drop-down.
- HELPTIP supports two modes for dynamic help association with fields.
  - Default mode requires that you define an INFO field with the label helptip somewhere on your form. For tabbed forms, an INFO helptip field may be added to each tab for better localization of help information. When field is hovered over, the assigned helptip will be displayed in the INFO field.
  - Add the TOOLTIPHELP option somewhere in the form. If set, help tip information will be displayed as tooltips directly with the field when mouse is hovered over. Tooltip based help supports full HTML content, allowing the embedding of graphics and other data to provide additional context information for your user. For HTML tags, multiple HELPTIP lines may be defined for the same form field for easier HTML formatting. Do not enclose each line HTML help tip information in `"s`.

- Options should appear after the fieldtype and MULTILINE in button type.

The forming syntaxes are NOT supported by the formeditor.

This following syntax is supported and may be placed anywhere in the form file to support conditional processing of the form file:

```
#ifdef <variable>|
{ }

 { #elseif <variable>
     }

 {  #else
{ } }
```


©2023 All Rights Reserved.

- FSIZE is optional for SPACER fields, and will default to 0,0 (both vertical and horizontal spacing). If set, a non-zero value indicates a fixed amount of space to be reserved. A zero value indicates the spacer should expand in this direction to keep fields in place on the sides of it.

©2023 All Rights Reserved.

axlFormCallback

```
formCallback(
     [r_form]
     )
     ==> t
```

Description

This is not a function but documents the callback interface for form interaction between a user and SKILL code. The SKILL program author provides this function.

When the user changes a field in a form the Allegro form processor calls the procedure you specified as the `g_formAction` argument in `axlFormCreate` when you created that form. The form attribute `curField` specifies the name of the field that changed. The form attribute `curValue` specifies the current value of the field (after the user changed it). If you set `g_stringOption` to `t` in your call to `axlFormCreate` when you created that form, then `curValue` is a string. If `g_stringOption` was `nil` (the default), then `curValue` is the type you specified for that field in the form file.

Note: The term `formCallback` used in the title of this callback procedure description is a dummy name. The callback function name must match the name or symbol name you used as the `g_formAction` argument in `axlFormCreate` when you created the form.

If you specify the callback name (`g_formAction`) as a string in your call to `axlFormCreate`, SKILL calls that function with no arguments. If you specify `g_formAction` as a symbol, then SKILL calls that function with the form handle as its single argument.

The callback must call `axlFormClose` to close the form and to continue in the main application code if form mode is blocking.

All form information is provided by the `r_form` argument which is a form data type. Applications can extend the data stored on this type by adding their own attributes. Capitalize the first letter of the attribute name to avoid conflicts with future additions by Cadence to this structure. Tables 1 and 2 show the available field types and how they impact the `r_form` data type.

Table 1

Form Field Types:

Type	What the field is commonly known to the user.

©2023 All Rights Reserved.

Keyword — How the field is declared in the form file (see `axlFormBNFDoc`).

curValue — The data type seen in the form dispatch and `axlFormGetField` (see `axlFormCallback`).

curValueInt — If `curValue` can be mapped to an integer. For certain field types provides additional information.

Type	Keyword	cuValue	curValueInt
Button	MENUBUTTON (6)	t	1
Check Box	CHECKLIST (1)	t / nil	1 or 0
Radio Box	CHECKLIST (1)	t / nil	1 or 0
Long (integer)	INTFILLIN	integer	integer
Real (float)	REALFILLIN	floating point	N/A
String	STRFILLIN	string	N/A
Enum (popup)	ENUMSET	string	integer (2)
List	LIST	string	index
Color well	COLOR	t / nil	1 or 0
Tab	TABSET/TAB	string or t (3)	N/A or 1/0
Tree	TREEVIEW	string	See: axlFormTreeViewSet
Text	INFO (4)	N/A	N/A
Graphics	THUMBNAIL (5)	N/A	N/A
Trackbar	TRACKBAR	integer	integer
Grid	GRID	See: axlFormGridDoc	

Notes:

- What distinguishes between a radio button and check box is that radio buttons are a group of check boxes where only one can be set. To relate several check boxes as a set of radio buttons, use supply the same label name as the third field (groupLabel) in the form file description:

```
CHECKLIST <fieldLabel> <groupLabel>
```


©2023 All Rights Reserved.

When a user sets a radio button the button be unset will dispatch to the app's callback with a value `nil`.

- Enum will only set `curValueInt` on dispatch when the dispatch value of their popup uses an integer. Otherwise this field is `nil`.
- Tabs can dispatch in two methods:
  - default when a tab is selected your dispatcher receives the tab name in the `curField` and `curValue` is `t`.
  - If `OPTIONS tabsetDispatch` is set in the TABSET of the form file then when a tab is selected your app dispatcher receives the TABSET as the `curField` and the `curValue` being the name of the TAB that was selected.
- INFO fields can be static where the text is declared in the form file or dynamic where you can set the text via the application at run-time. To achieve dynamic access enter the following in the form file:

```
TEXT "<optional initial text>"
INFO <fieldLabel>
```

  ... reset of TEXT section ...

- Thumbnails support three methods:
  - Static bitmap declared via form file.
  - Bitmaps that can by changed by the application at run-time.
  - Basic drawing canvas (see `axlGRPDoc`).
- Buttons are stateless. The application cannot set the button to the depressed state. You can only use `axlFormSetField` to change the text in the button. Several button fieldLabels are reserved. Use them only as described:
  - *Done* or *OK:* Do action and close form.
  - *Cancel*: Cancel changes and close form.
  - *Print*: Print form; do not use.
  - *Help*: Call cdsdoc for help about form. Do not use.

©2023 All Rights Reserved.

Table 2

Attribute Name	Set?	Type*	Description
curField	no	string	Name of form field (control) that just changed.
curValue	no	See->	Value dependant upon field type (2).
curValueInt	no	See->	Value dependant upon field type (2).
doneState	no	int	0 = action; 1 = done; 2 = cancel; 3 = abort (1)
form	no	string	Name of this form (form file name).
isChanged	no	`t` / `nil`	`t` = user has changed one or more fields.
isValueString	no	`t` / `nil`	`t` all field values are strings. `nil` one or more fields are not strings.
objType	no	string	Type of object; in this case `form`.
type	no	string	Always `fixed`.
fields	no	list of strings	All fields in the form (3).
infos	no	list of strings	All info. fields in form (3).
event	no	symbol	List, tree and grid control only. See `axlFormGridDoc` for grid info, otherwise see bullets 4 and 5 in the following ***Notes*** section.
row	no	integer	Grid control only.
col	no	integer	Grid control only.
treeViewSelState	no	integer	Tree control only.

©2023 All Rights Reserved.

Notes:

- The `doneState` shows 0 for most actions. If a button with *Done* or *OK* is pushed, then the done state is set. A button with the *Cancel* label sets the cancel state.
  In either the Done or Cancel state, you need to close the form with `axlFormClose`. If the abort state is set, the form closes even if you do not issue an `axlFormClose`.
- Data type is dependant upon the field type, see Table 1.
- The difference between the fields and infos list is that items appearing in the infos list are static text strings that can be changed by the program at the run-time. All other labels appear in the fields list and can be changed by the user (even buttons, tabs, grayed and hidden fields).
- Event for list box is `t` if item is selected, `nil` if deselected. This is always `t` for single select list box while the multi-select option can have both states.
- Event and treeViewSelState for a tree control see `axlFormTreeViewAddItem`.

Arguments

`r_form`	Form dbid

Value Returned

`t`	Always returns `t`

Examples

See `axlFormCreate` and `axlFormBuildPopup` examples.

©2023 All Rights Reserved.

axlFormCreate

```
axlFormCreate(
     s_formHandle
     t_formfile/(t_formName t_contents)/(t_formName (t_contents))
     [lt_placement]
     g_formAction
     g_nonBlock
     [g_stringOption]
     )
     ⇒ r_form/nil
```

Description

Creates a dialog based on the form descriptive file *t_formfile*. This call only supports forms of type "fixed" and fails if *t_formfile* contains any variable tiles. This function does not display the form. Use axlFormDisplay to display a form.

An alternative interface is supported that allows embedding the contents of the form file in the SKILL code. Instead of passing the external form file name provide the name (t_formName) for scripting purposes and form file contents (t_contents) as string. The packaged SKILL code has a example of this method at the end of the *<cdsroot>*/share/pcb/examples/form/finline.il file. This method has the advantage of only distributing one file.

Rules to remember when creating this form content string:

- Every non-blank line must have a tab character

  Example:

  ```
  FILE_TYPE=FORM_DEFN VERSION=2
  ```

- Any embedded quotes must be escaped (use backslash '\')

  Example:

  ```
  MENUBUTTON \"Ok\" 10 3\n
  ```

- Any parenthesis '()' must be escaped '\'

Note: If *s_formHandle* is an existing *r_form*, then axlFormCreate does not create a new form, but simply exposes and displays the existing form, *s_formHandle*, and returns nil.

©2023 All Rights Reserved.

Arguments

s_formHandle	Global SKILL symbol used to reference form.**Note:** Do not use the same symbol to reference different form instances.
t_formfile	Filename of the form file to be used to define this form. `axlFormCreate` uses the Allegro PCB Editor environment variable, `FORMPATH`, to find the file, if *t_formfile* is not a full path. The filename, by convention, should use the `.form` extension.Alternative interface to embed form file into SKILL code: ■ `t_formName`: Name of form (used for scripting) ■ `(t_contents)`: Contents of form file. This may be a string or a list containing or a string. The string format is obsolete and you should use `t_contents` ■ `t_contents`: the list with string format
lt_placement	Form placement. Allegro PCB Editor uses its default placement if this argument is `nil`. See Window Placement on page 687
g_formAction	Specifies the SKILL commands (callbacks) to be executed after every field change (Note that this is very different from Cadence IC forms). You can set this to one of the formats shown.
g_form	*Action* Options

Option	Description
t_callback	String representation of the SKILL command to be executed.
s_callback	Symbol of the SKILL function to be called (passes the *r_form* returned from `axlFormCreate` as its only parameter.)
`nil`	`axlFormDisplay` blocks until the user closes the form.You must place a *Done* button (field name `done`) and optionally a *Cancel* button (field name `cancel`) in the form for *g_formAction* to function properly. The user can access all of the fields and values using the *r_form* user type.

©2023 All Rights Reserved.

g_nonBlock	If *g_nonBlock* is `t`, the form runs in non-blocking mode. In blocking mode (the default), `axlFormDisplay` blocks until the user closes the form. Blocking is an easier programming mode but might not be appropriate for your application. If the callback (*g_formAction*) is `nil`, then `axlFormDisplay` ignores *g_nonBlock*, and the form runs in blocking mode. Use of blocking mode blocks the progress of the SKILL code, but does not prevent other Allegro PCB Editor events from occurring. For example, if blocked, users can start the *Add Line* command from Allegro PCB Editor menus.
g_stringOption	If `t`, the form returns and accepts all values as strings. By default, it returns and accepts values in the format declared in the form file.

Value Returned

r_form	*dbid* of form created.
`nil`	No form created.

Example

See *<cdsroot>/share/pcb/examples/form*

basic: demonstrates basic form capabilities

finline.il shows correct inline method

grid: demonstrates grid control capabilities

wizard: form when used in a Wizard mode

finline: demonstrates inline option to avoid having a .form file

See AXL Forms: Example 1 on page 813.

See Also

- axlFormIntroDoc: Introduction to the Allegro Form Package.
- axlFormBNFDoc: Form file language description
- axlFormCallback: Methods and structures for interacting with user.

©2023 All Rights Reserved.

axlFormClearMouseActive

```
axlFormClearMouseActive(
     r_form
     )
     ==> t/nil
```

Description

Clears the option to dispatch the MouseActive event on a form.

Arguments

r_form	Handle for the form

Value Returned

`t`	Option was cleared
`nil`	r_form does not reference a valid form

©2023 All Rights Reserved.

axlFormClose

```
axlFormClose(
     r_form
     )
     ⇒ t/nil
```

Description

Closes the form *r_form*. Unless the form is running without a callback handler, you must make this call to close the form. Without a registered dispatch handler, Allegro PCB Editor closes the form automatically before returning to the application from `axlFormDisplay`.

Note: `axlUIWClose` also performs the same function.

Arguments

r_form	Form *dbid*.

Value Returned

`t`	Closed the form.
`nil`	Form was already closed.

Example

See AXL Forms: Example 1 on page 813:

```
(case form->curField
     ("done"
         (axlFormClose form)
         (axlCancelEnterFun)
         (_extract)
         t)
```


©2023 All Rights Reserved.

axlFormDisplay

```
axlFormDisplay(
     r_form
     )
     ⇒ t/nil
```

Description

Displays the form *r_form* already created by `axlFormCreate`. For superior display appearance, set all the field values of the form before calling this function. A form in blocking mode blocks until the user closes the form.

If a form is already displayed, this function simply exposes it.

Arguments

r_form	Form *dbid*.

Value Returned

`t`	Successfully opened or exposed the form.
`nil`	Failed to open or expose the form.

Example

See AXL Forms: Example 1 on page 813.

```
axlFormDisplay( form)
```


©2023 All Rights Reserved.

axlFormBuildPopup

```
axlFormBuildPopup(
     r_form
     t_field
     l_pairs
     )
     ⇒ t/nil
```

Description

This provides the ability to dynamically change popups of fields that have them. These fields are enum (or pop-up) and other fields that have a popup icon. Buttons, optionally, may also have a popup if they have a right arrow. Attempting this call on a field without a popup is an error.

Arguments

r_form	a form handle
t_field	Name of form field.
l_pairs	May be one of four formats where each element is a single popup entry. A maximum of 256 popup entries are allowed.

- normal

  `( (t_display t_dispatch) ... )`

- alternative normal

  `( t_displayNdispatch ... )`

- for enum field types

  `( (t_display x_dispatch) ... )`

-

  `( (t_display t_dispatch/x_dispatch options) ... )`

  Options can be 1 or 2 additional list options that are `S_color/x_color` for enum field types with color; bold or underline for bold or underlined items.

Note: All entries in an `l_pairs` argument must be the same type of format. That is, you cannot have a list containing, for example, both display/dispatch strings and display/enum types, or display/dispatch and single-string entries. Must be one of the

©2023 All Rights Reserved.

formats described. Each list object defines a single popup entry.

Table 11-3 l_pairs Format Options

Option	Description	Example
List of lists of string pairs	The first member of each string pair list is the display value–the string displayed in the pop-up. The second member of each string pair is the dispatch value-the string value returned as *form->curValue* when the user selects that pop-up entry.	`(list (list "MyPop A" "myvalue_a")` `list("MyPop B" "myvalue_b"))`
List of lists of pairs	List of lists of pairs where the first member of each pair is a string giving the display value, and the second member is an integer that is the dispatch value, returned as *form - curValue* when the user selects that pop-up entry. You can use the return value as an index into an array.	`(list (list "MyPop A" 5)` `list("MyPop B" 7))`
List of strings	Uses each string both for display value and the return value.	`(list "MyPop A" "MyPop B")`

©2023 All Rights Reserved.

Table 11-3 l_pairs Format Options

Option	Description	Example

Optional field	Specifies a color swatch. This is currently only supported by ENUM field types (it is ignored by other field types). With an ENUM you need to add `OPTIONS ownerdrawn` in the form file for the FIELD in question to see the color swatch in the popup. You can use either pre-defined color names (see `axlColorDoc`) or Allegro board colors (see `axlLayerGet`).	You can't mix this color type in a single popup.
		`'(("Green" 1 green) ("Red" 2 red) ("Yellow" 3 yellow))`
		`'(("Top" "top" 2) ("Gnd "gnd" 4) ("Bottom" "btm" 18))`
		If instead of a color or Allegro color number, you provide a `nil`, then that popup entry will not have a color swatch.
		`'("(None" 0 nil) ("Green" 1 green) ("Red" 2 red) ("Yellow" 3 yellow))`
		Font type of bold or underline can be specified via:
		`'(("Top" "top" bold) ("Gnd "gnd" underline) ("Bottom" "btm"))`
		When font type is combined with color it looks like:
		`'(("Top" "top" "Green" bold) ("Gnd "gnd" "Red" underline)`

Notes:

- Allows a maximum of 1000 pop-up entries in one pop-up.
- If creating a dynamic popup (entries created under program control) a dummy entry must exist in the form file or build popup will fail. Example:

  `<popupname> """".`

- The field name is actually a search mechanism. We first search the fields for the field name with a popup and then search the popup names. Since the only way to change grid

©2023 All Rights Reserved.

column or cell based popups is by popup name you may run into failures if that popup name has the same name as another field in the form.

Value Returned

`t`	Field set.
`nil`	Field not set.

Example

See AXL Forms: Example 2 on page 817.

©2023 All Rights Reserved.

axlFormGetField

```
axlFormGetField(
     r_form
     t_field
     )
     ⇒ g_value/nil
```

Description

Gets the value of *t_field* in the open form *r_form*. The value is a string if *g_stringOption* was set in `axlFormCreate`. Otherwise the value is in the field type declared in the form file.

Arguments

r_form	Form *dbid*.
t_field	Name of field.

Value Returned

g_value	Current value of the field.
`nil`	Field does not exist, or false if boolean field such as check box or radio button.

Example

1. Load the example code given in AXL Forms: Example 1 on page 813.
2. Enter the command `myExtract()` on the SKILL command line.

   The command displays the **Extract Selector** form, listing all available extract view files.
3. Select any file in the list, or type a name into the *View File* field.

©2023 All Rights Reserved.

`allegro2rlb_view.txt` is entered.

```
axlFormGetField( form "view_file")
    ⇒ "allegro2rlb_view.txt"
```

Examines the value of "*view_file*" .

©2023 All Rights Reserved.

axlFormGetFieldRange

```
axlFormGetFieldRange (
     r_form
     t_field
     )
     ⇒ l_fieldRange/nil
```

Description

Returns the minimum/maximum values specified for an INTFILLIN or REALFILLIN. For other field types, or if these values have not been set on the field, `nil` is returned.

Arguments

form	Form dbid.
t_field	Name of the field.

Value Returned

`l_fieldRange/nil`	nil, if field doesn't exist
	nil, if field isn't INTFILLIN or REALFILLIN
	nil, if the field doesn't have range set
`list(min max)`	If field has legal range set

©2023 All Rights Reserved.

axlFormGetOptionValue

```
axlFormGetOptionValue(
     t_formName
     t_fieldName
     )
     ⇒ field value/nil
```

Description

Retrieve the value of the field in the specified form.

If the form is not open, the field doesn't exist, or any other error, `nil` is returned.

Note: This function will not do any mapping for you. If Cadence changes a form or field name, you must update your code to the new values.

Arguments

t_formName	Name of form to query (see `jrl` contents for names)
t_fieldName	Name of field on form (see `jrl` contents for name)

Value Returned

value or `nil`

©2023 All Rights Reserved.

axlFormGridGetSize

```
axlFormGridGetSize(
     r_form
     t_field
     )
     ⇒ list(rows columns)/nil
```

Description

Returns the size of the grid as a list of two elements, the rows and the columns, if grid is initialized. If grid has not been initialized, or field is not a grid, returns nil to indicate error.

Arguments

r_form	Standard form handle
t_field	Standard field name

Value Returned

`list (rows columns)`	If successful
`nil`	On error

©2023 All Rights Reserved.

axlFormListGetCount

```
axlFormListGetCount(
     r_form
     t_field
     )
     ⇒ x_count/nil
```

Description

Returns a count of number of items in the specified list box.

Arguments

r_form	Form control
t_field	Name of the field

Value Returned

x_count	Number of items in the list
nil	If not a list box

See Also

axlFormListGetSelCount

Example

See `axlform.il` example.

©2023 All Rights Reserved.

axlFormGridSelected

```
axlFormGridSelected(
     r_form
     t_field
     ) -> lx_selected/nil
```

Description

This returns the selected item in a multi-select grid control. This should only be used if grid is running with the multi-select row option.

Arguments

`r_form`	standard form handle
`t_field`	standard field name

Value Returned

Returns list of selected items in a multi-select grid or nil if not the correct control.

See Also

axlFormGridNewCell

Examples

See `fgrid.il` in `<CDSROOT>/share/pcb/examples/skill/form/grid`

Pseudo code:

```
axlFormGridEvents(fg "grid" 'mrowselect)
;; select items
selected = axlFormGridSelected(fg "grid")
; if form select rows 5,6,7 (click on 5, then Shift click on 7)
;; select items
selected = axlFormGridSelected(fg "grid")
-> (5 6 7)
```


©2023 All Rights Reserved.

axlFormGridSelectedCnt

```
axlFormGridSelectedCnt(
     r_form
     t_field
     ) -> x_cnt/nil
```

Description

This returns the count of rows selected in a multi-select grid control. This should only be used if grid is running with the multi-select row option.

Argument

r_form	standard form handle
t_field	standard field name

Value Returned

Returns count of selected items or `nil` if wrong type of control

See Also

axlFormGridNewCell

Examples

See `fgrid.il` in `<CDSROOT>/share/pcb/examples/skill/form/grid`

Pseudo code:

```
axlFormGridEvents(fg "grid" 'mrowselect)
; if form select rows all rows (Ctrl-A in grid)
;; select items
selected = axlFormGridSelectedCnt(fg "grid")
-> 16
```


©2023 All Rights Reserved.

axlFormGridSetSelectRows

```
axlFormGridSetSelectRows(
     r_form
     t_field
     x_min
     x_max
     g_option
     ) -> x_cnt/nil
```

Description

This allows setting, clearing or toggling of selection state for a grid in multi-select row mode.

Arguments

r_form	standard form handle
t_field	standard field name
x_min	min row number
x_max	max row number
g_option	what to do
	`t` – set row as selected
	`nil` – clear row as selected
	`'toggle` – toggle selected state of row

Value Returned

`t` if succeeded, `nil` if not a grid field or not in multi-row select mode

See Also

axlFormGridNewCell

Examples

See `fgrid.il` in `<CDSROOT>/share/pcb/examples/skill/form/grid`

©2023 All Rights Reserved.

Pseudo code:

```
axlFormGridEvents(fg "grid" 'mrowselect)
```

- set row 4 as selected

```
axlFormGridSetSelectRows(fg "grid" 4 4 t)
```

- clear rows 4 thru 8 being selected

```
axlFormGridSetSelectRows(fg "grid" 4 8 t)
```

- clear all rows

```
axlFormGridSetSelectRows(fg "grid" -1 -1 nil)
```

- toggle state of row 1

```
axlFormGridSetSelectRows(fg "grid" 1 1 'toggle)
```


©2023 All Rights Reserved.

axlFormListDeleteAll

```
axlFormListDeleteAll(
     r_form
     t_field
     )
     ⇒ t/nil
```

Description

Deletes all the items from the form list field, *t_field.* Use `axlFormListDeleteAll` to clear an entire list field to update it using `axlFormSetField`, then display it using `axlFormSetField` on the field with a `nil` field value.

Arguments

r_form	Form *dbid*.
t_field	Name of field.

Value Returned

`t`	All items deleted properly.
`nil`	All items not deleted.

Examples

In this example you do the following:

1. Use the `axlFormCreate` examples to create and display the Extract Selector dialog box shown in Figure 11-1 on page 864.
2. On the SKILL command line, enter:

   ```
   axlFormListDeleteAll(form "file_list")
       ==> nil
   ```

   The list is removed from the dialog box as shown in Figure 11-2 on page 864.
3. On the SKILL command line, enter:

   ```
   axlFormSetField(form "file_list" "fu")
   ```


©2023 All Rights Reserved.

```
axlFormSetField(form "file_list" "bar")
axlFormSetField(form "file_list" nil)
==> t
```

The Extract Selector dialog box is displayed with new list as shown in Figure 11-3 on page 865.

Figure 11-1 Extract Selector Dialog Box

Figure 11-2 Extract Selector Dialog Box - List removed

©2023 All Rights Reserved.

Figure 11-3 The Extract Selector dialog box - Displayed with a new list

©2023 All Rights Reserved.

axlFormListSelect

```
axlFormListSelect(
     r_form
     t_field
     t_listItem/nil
     )
     ⇒ t/nil
```

Description

Highlights, and if not visible in the list, shows the designated item. Since Allegro PCB Editor forms permit only one item to be visible, it deselects any previously selected item. If `nil` is passed for *`t_listItem`* the list is reset to top and the selected list item is deselected.

Arguments

`r_form`	Form id
`t_field`	Name of field.
`t_listItem``/nil`	String of item in the list. Send `nil` to deselect any selected item and set list back to top.

Value Returned

`t`	Highlights item. Arguments are valid.
`nil`	Arguments are invalid.

©2023 All Rights Reserved.

axlFormSetEventAction

```
axlFormSetEventAction(
     r_form
     g_callback
     ) -> t/nil
```

Description

This function allows the user to register a callback function to be called whenever the user changes to a new active cell in the form. The callback registered during axlFormCreate dispatches events only when the user modifies a field value on the form (on exit from the field). This function allows the caller to receive an event when a field is first entered.

Arguments

r_form	Form *dbid*
g_callback	Specifies the SKILL command(s) (callback(s)) to be executed whenever a new field is activated. The setting can be one of two formats: *t_callback*: the string representation of the SKILL command(s) to be executed *s_callback*: the symbol of the SKILL function to be called (the function is passed the *r_form* returned from `axlFormCreate` as its only parameter).

See Also

axlFormBNFDoc and axlFormCreate

Value Returned

`t`	Field set to desired value.
`nil`	Field not set to the desired value due to invalid arguments.

Example

```
form = axlFormCreate( MyForm
    "extract_selector.form" '("E" "OUTER")
```


©2023 All Rights Reserved.

```
    '_formAction t)
axlFormSetEventAction( form '_formEventAction)
```


©2023 All Rights Reserved.

axlFormSetField

```
axlFormSetField(
     r_form
     t_field
     g_value/nil
     )
     ⇒ t/nil
```

Description

Sets values of individual form fields. These values may differ and depend on type of the field. For a complete discussion of field types, see the discussion at the front of this section.

Special notes for certain controls:

- LIST TYPE

  Value may be a string, integer or real. Items are converted to strings before being displayed. A `nil` is needed to display the list.

  Alternatively, value may be a list of strings. This results in better performance when you have many items to display.

- COLOR TYPE

  `g_value` parameter may have several types:

`s_colorSymbol`	Set field to predefined color
`x_number`	Set field to product color
`t` or `nil`	Depress or raise field
`l_both`	A list allows setting both check and value; pass a list of the color set

  `s_colorSymbol` May be black, white, red, green, yellow, multivalue, button or default.

  `x_number` is an integer between 1 and 24 with 0 being background.

- CHECKBOX

  The values that unset the checkbox are: `nil`, `0`, `"nil"`, `"false"` and `"no"`. All other values set the checkbox.

- TRACKBAR

  If the field is a trackbar, two modes are supported.

©2023 All Rights Reserved.

- g_value = t

  Moves the slider to the next position.

- g_value = integer

  Absolutely sets trackbar to the indicated position.

Arguments

r_form	Form *dbid*.
t_field	Name of field. Field name is a string or symbol.
g_value	Desired value of field. May be a string, boolean, integer or floating point number or a list; function of field type.

Value Returned

`t`	If Successful
`nil`	Failed

Examples

List Field (field is named `"list"`)

```
;; display 3 items in list
axlFormSetField(fw, "list", "a")
axlFormSetField(fw, "list", "b")
axlFormSetField(fw, "list", "c")
; nil required first time list is displayed
axlFormSetField(fw, "list", nil)

;; display 3 items in list - alternative
axlFormSetField(fw, "list", '("a" "b" "c"))
```

Color field (field is named `"color"`)

```
;; sets the color field to pre-defined color "red"
axlFormSetField(fw, "color", `red)
;; sets the color field to product color 1
axlFormSetField(fw, "color", 1)
```


©2023 All Rights Reserved.

```
;; visually depresses the color field if not greyed
axlFormSetField(fw, "color", t)
;; visually depresses the color field and set to
;;      pre-defined green color
axlFormSetField(fw, "color", '(green t))
```

Tab field (field is named `"tab"`)

```
;; puts the tab on top
axlformSetField(fw, "tab", nil)
```


©2023 All Rights Reserved.

axlFormSetFieldHelpTip

```
axlFormSetFieldHelpTip(
     r_form
     t_field
     t_value
     )
     ⇒ t/nil
```

Description

Sets the help tip associated with the indicated field. The value may be either a simple string or an HTML with a proper structure. Note that HTML is only recommended when the TOOLTIPHELP tag is set on your form to enable mouse-over help instead of INFO field text to display field help.

Arguments

r_form	Form *dbid*.
t_field	Name of field.
t_value	Help tip string to associate with the field, `nil` to clear existing

Value Returned

`t`	Returns `t` if the help tip was set to desired value.
`nil`	Otherwise

Examples

```
axlFormSetFieldHelpTip(form "my_field" "This field is for entering data")
```

See the use of axlFormSetField in axlFormCreate examples.

©2023 All Rights Reserved.

axlFormSetInfo

```
axlFormSetInfo(
     r_form
     t_field
     t_value
     )
     ⇒ t/nil
```

Description

Sets info *t_field* to value *t_value* in open form *r_form*. Unlike axlFormSet, user cannot change an info field.

Note: You can also use axlFormSetField for this function.

Arguments

r_form	Form *dbid*.
t_field	Name of field.
t_value	Desired value of field.

Value Returned

t	Field was set to desired value.
nil	Field not set to desired value due to invalid arguments.

Example

See the use of axlFormSetField in the "AXL Forms: Example 1" on page 813.

```
axlFormSetInfo( form "file_list" fileName)
```


©2023 All Rights Reserved.

axlFormSetMouseActive

```
axlFormSetMouseActive(
     r_form
     )
     ==> t/nil
```

Description

Sets the option to dispatch the MouseActive event on a form.

While this can be use to display dynamic help on a per field basis (this is what the example code does) a better method exists called the "helptip" which is driven from the form file. See the axlFormBNFDoc (note 12).

Arguments

r_form	Handle for the form

Value Returned

t	Option was set
nil	`r_form` does not reference a valid form

Example

See `<cdsroot>/share/pcb/examples/form/basic`

©2023 All Rights Reserved.

axlFormTest

```
axlFormTest(
     t_formName
     ) r_form/nil
```

Description

This is a development function for test purposes. Given a form file name this opens a form file to check for placement of controls. If form uses standard button names (for example, *ok, done, close, cancel*), you can close it be clicking the button. Otherwise, use the window control. If form is currently open, exposes form and returns.

Arguments

t_formName	Name of form.

Value Returned

Form handle if successfully opens.

Example

Open Allegro PCB Editor drawing parameter form:

```
axlFormTest("status")
```


©2023 All Rights Reserved.

axlFormRestoreField

```
axlFormRestoreField(
     r_form
     t_field
     )
     ⇒ t/nil
```

Description

Restores the *t_field* in the open form *r_form* to its previous value. The previous value is only from the last user change and not from the form set field functions. This is only useful in the *form callback* function.

Use in the `form callback` to restore the previous value when you detect the user has entered an illegal value in the field.

Arguments

r_form	Form *dbid*.
t_field	Name of field.

Value Returned

`t`	Field restored.
`nil`	Field not restored and may not exist.

©2023 All Rights Reserved.

Example

See "AXL Forms: Example 1" on page 813 where the callback function checks that the user has entered a filename that is on the list of available extract view filenames. If the user-entered value is not on the list, then the program calls `axlFormRestoreField` to restore the field to its previous value.

```
(case form->curField
           ("view_file"
                (if form->curValue
                     (progn
                          ; Accept user input only if on list
                          if(member( form->curValue fileList)
                              then axlFormSetField( form
                                   "view_file" form->curValue)
                               else axlFormRestoreField(
                                        form "view_file"))))
                t)
```


©2023 All Rights Reserved.

axlFormTitle

```
axlFormTitle(
     r_form
     t_title
     )
     ⇒ t/nil
```

Description

Overrides title of the form.

Arguments

r_form	Form *dbid*.
t_title	String to be used for new form title

Value Returned

t	Changed form title.
nil	No form title changed.

Example

See "AXL Forms: Example 1" on page 813.

```
axlFormTitle( form "Extract Selector")
```


©2023 All Rights Reserved.

axlIsFormType

```
axlIsFormType(
     g_form
     )
     ⇒ t/nil
```

Description

Tests if argument *g_form* is a form *dbid*.

Arguments

g_form	*dbid* of object to test.

Value Returned

t	*r_form* is the *dbid* of a form.
nil	*r_form* is not the *dbid* of a form.

Example

```
form = axlFormCreate( (gensym)
    "extract_selector.form" '("E" "OUTER")
    '_formAction t)
if( axlIsFormType(form)
    then (print "Created form successfully.")
    else (print "Error! Could not create form."))
```

Checks that the form you create is truly a form.

©2023 All Rights Reserved.

axlFormSetFieldVisible

```
axlFormSetFieldVisible(
     r_form
     t_field
     x_value
     )
     ⇒ t/nil
```

Description

Sets a form field to visible or invisible.

Arguments

r_form	Form id.
t_field	Form field name (string).
x_value	1 - set field visible or 0 - Set field invisible

Value Returned

t	Form field set visible.
nil	Form field set invisible.

©2023 All Rights Reserved.

axlFormIsFieldVisible

```
axlFormIsFieldVisible(
     r_form
     t_field
)
⇒ t/nil
```

Description

Determines whether a form field is visible.

Arguments

r_form	Form id.
t_field	Form field name (string).

Value Returned

t	Form field is visible.
nil	Form field is not visible.

©2023 All Rights Reserved.

Callback Procedure: formCallback

```
formCallback(
     [r_form]
     )
     ⇒ t
```

Description

This is not a function but documents the callback interface for form interaction between a user and SKILL code. The SKILL programmer provides this function.

When the user changes a field in a form, the Allegro PCB Editor form processor calls the procedure you specified as the *g_formAction* argument in axlFormCreate when you created that form. The form attribute *curField* specifies the name of the field that changed. The form attribute *curValue* specifies the current value of the field (after the user changed it). If you set *g_stringOption* to t in your call to axlFormCreate when you created that form, then *curValue* is a string. If *g_stringOption* was nil (the default), then *curValue* is the type you specified for that field in the form file.

Note: The term formCallback used in the title of this callback procedure description is a dummy name. The callback function name must match the name or symbol name you used as the *g_formAction* argument in axlFormCreate when you created the form.

If you specify the callback name (*g_formAction*) as a string in your call to axlFormCreate, SKILL calls that function with no arguments. If you specify *g_formAction* as a symbol, then SKILL calls that function with the form handle as its single argument.

The callback must call axlFormClose to close the form and to continue in the main application code if form mode is blocking.

All form information is provided by the *r_form* argument which is a form data type. Applications can extend the data stored on this type by adding their own attributes. Please capitalize the first letter of the attribute name to avoid conflicts with future additions by Cadence to this structure. Table 11-4 on page 883 and Table 11-5 on page 885 show the available field types and how they impact the *r_form* data type.

Table 11-4 on page 883 describes Form Field Types using the following:

Type	What the user calls the field
Keyword	What the form file calls the field

©2023 All Rights Reserved.

`curValue`	Data type seen in the form dispatch and axlFormGetField. See Callback for more information.
`curValueInt`	Additional information for certain field types that can be mapped to integers.

Table 11-4 Form Field Types

Type	Keyword	curValue	curValueInt
Button	`MENUBUTTON`	dispatch action only (t)	1
Check Box	`CHECKLIST`	`t/nil`	0 or 1
Radio Button	`CHECKLIST`	`t/nil`	0 or 1
Long (integer)	`INTFILLIN`	integer number	Integer
Real (float)	`REALFILLIN`	float number	n/a
String	`STRFILLIN`	string	n/a
Enum (popup)	`ENUMSET`	string	Possible integer[1]
List	`LIST`	string	Offset from start of list (`0` = first entry).
Color well	`COLOR`	`t/nil`	`1` or `0`
Tab	`TABSET/TAB`	string or `t`	n/a or `1/0`
Tree	`TREEVIEW`	string	see `axlFormTreeViewSet`
Text	`INFO`	n/a	n/a
Graphics	`THUMBNAIL`	n/a	n/a
GRID	`GRID`	see Using Grids on page 805	

1. Integer if the dispatch value of the pop-up is an integer.

Notes:

- What distinguishes between a radio button and a check box is that radio buttons are a group of boxes where only one can be set. To relate several check boxes as radio buttons, supply the same label name as the third field (groupLabel) in the form file description:

```
CHECKLIST <fieldLabel> <groupLabel>
```


©2023 All Rights Reserved.

When a user sets a radio button, the button being unset will dispatch to the application's callback with a value of nil.

- Enum will only set curValueInt on dispatch when their dispatch value of their popup uses an integer. Otherwise this field is `nil`.
- Tabs can dispatch in two methods:
  - Default when a tab is selected, your dispatcher receives the tab name in the curField and curValue is t.
  - If "OPTIONS tabsetDispatch" is set in the TABSET of the form file, then when a tab is selected your application dispatcher receives the TABSET as the curField and the curValue being the name of the TAB that was selected.
- INFO fields can be static where the text is declared in the form file or dynamic where you can set the text via the application at run-time. To achieve dynamic access, enter the following in the form file:

```
TEXT "<optional initial text>"
INFO <fieldLabel>
... reset of TEXT section ...
```

- Thumbnails support the following methods:
  - static bitmap declared via the form file
  - bitmaps that can be changed by the application at run-time
  - basic drawing canvas -- see Chapter 12, "Simple Graphics Drawing Functions"
- Buttons are stateless. The application cannot set the button to the depressed state. You can only use axlFormSetField to change the text in the button. Several button fieldLabels are reserved. Use them only as described:

`done or OK`	Do action and close the form.
`cancel`	Cancel changes and close the form.
`print`	Print the form -- do not use.
`help`	Call cdsdoc for help about the form -- do not use.

©2023 All Rights Reserved.

Table 11-5 Form Attributes

Attribute Name	Set?	Type*	Description
curField	no	string	Name of form field just changed
curValue	no	See -->	Depends on value of *curField* (`string`, `int`, `float`, `boolean`)
curValueInt	no	See -->	Depends on value of *curField* field
doneState	no	int	`0` = action; `1` = done; `2` = cancel; `3` = abort
form	no	string	Name of this form
isChanged	no	`t/nil`	`t` = user has changed one or more fields in form.
isValueString	no	`t/nil`	`t` = all field values are strings `nil` = one or more fields are not strings
objType	no	string	Type of object, in this case `"form"`
type	no	string	Form type, always `"fixed"`
fields	no	list of strings	All fields in the form.
infos	no	list of strings	All info fields in the form.
event	no	symbol	Grid control only -- see Using Grids on page 805
row	no	integer	Grid control only
col	no	integer	Grid control only
treeViewSelState	no	integer	Tree control only

* You can add your own attribute types to the form type. It is recommended you capitalize the first letter of the name to avoid conflict with future Allegro PCB Editor releases.

Notes:

- The doneState shows 0 for most actions. Selecting a *Done* or *OK* button sets the done state. Selecting a *Cancel* button sets the cancel state. With the done or cancel state set, you use `axlFormClose` to close the form. Setting the abort state closes the form, even if you do not issue an `axlFormClose` command.

©2023 All Rights Reserved.

- Data type is dependent on the field type. See Table 11-4 on page 883 for more information on Form Field Types.
- The infos list is different from the fields list. The infos list comprises static text strings that the program can change at run-time. The fields list comprises all other labels which can be changed by the user including even those on buttons and tabs, grayed and hidden fields.

Arguments

r_form	Form *dbid*.

Value Returned

t	Always returns t.

Example

See axlFormCreate on page 843 and axlFormBuildPopup on page 849 for examples.

©2023 All Rights Reserved.

axlFormAutoResize

```
axlFormAutoResize(
     r_form
     )
     ⇒ t/nil
```

Description

Resizes a form to fit its controls. Recalculates the required width and height and resizes the form based on the current visibility of the form's fields.

Arguments

r_form	Form handle.
t_field	Form field name (string).

Value Returned

t	Form resized.
nil	*r_form* does not reference a valid form.

©2023 All Rights Reserved.

axlFormColorize

```
axlFormColorize(
     o_form
     t_field
     g_option
     g_color
     )
     ⇒ t/nil
```

Description

Allows the override of background and/or text color of a control. Only the following controls are supported:

- `STRFILLIN`
- `READFILLIN`
- `LONGFILLIN`
- `INTSLIDEBAR`
- `ENUMSET`
- `CHECKLIST`
- `TEXT or INFO`

These names appear in the form BNF file syntax.

These controls use the default system colors:

`'background`	Set background of control
`'text`	Set text of control

The *`g_color`* argument is either a color symbol (for non DB options), a number for DB color options, or `nil` (for restoring to system default). See Accessing Allegro PCB Editor Colors with AXL-SKILL on page 79 for the allowed values.

Other form controls support color as a fundamental part of their interface. These are *`COLOR`* (See Accessing Allegro PCB Editor Colors with AXL-SKILL on page 79) and *`GRID`* (See Using Grids on page 805) controls.

Restrictions:

©2023 All Rights Reserved.

Note the following restrictions:

- Setting the same or close text and background colors can cause readability issues.
- Setting the background of `CHECKLIST` controls is not supported on UNIX.
- Dialog boxes with popups do not correctly show color.

Caution

If setting the background of a ENUM field on Windows, you must set the OPTION color in the form file as in the following example.

```
FIELD enum_control
FLOC 16 12
ENUMSET 41
OPTIONS color
POP "enum_popup"
ENDFIELD
```

This is the same option as the '`ownerdrawn`'. The color option is ignored on UNIX which does not support themes. For theming purposes, Microsoft takes the background color so setting this option disables Microsoft themes for this control.

Arguments

o_form	Form handle.
t_field	Field name.
g_option	Option (see above)
g_color	Color (see `axlColorDoc`) or `nil`

Value Returned

`t`	Color changed.
`nil`	Error due to an incorrect argument.

Example 1

You can find an example in `axlform.il`.

©2023 All Rights Reserved.

```
axlFormColorize(f1s "string" 'text 'red)
```

Sets text of string control to red.

Example 2

```
axlFormColorize(f1s "string" 'background 'green)
```

Sets background of string control to green.

Example 3

```
axlFormColorize(f1s "string" 'text nil)
axlFormColorize(f1s "string" 'background nil)
```

Sets control back to default.

Example 4

```
axlFormColorize(f1s "string" 'background 1)
```

Sets control background to Allegro PCB Editor database color 1

©2023 All Rights Reserved.

axlFormGetActiveField

```
axlFormGetActiveField(
     r_form
     )
     ⇒ t/nil
```

Description

Gets the form's active field.

Arguments

r_form	Form's *dbid*.
t_field	Form field name (string).

Value Returned

t_field	Active field name.
nil	No active field.

©2023 All Rights Reserved.

axlFormGridBatch

```
axlFormGridBatch(
     r_cell
)
⇒ t/nil
```

Description

Always used with `axlFormGridSetBatch`. Sets many grid cells efficiently.

Arguments

`r_cell`	Obtained from `axlFormGridNewCell`.

Value Returned

`t`	Grid cells set.
`nil`	No grid cells set.

©2023 All Rights Reserved.

axlFormGridCancelPopup

```
axlFormGridCancelPopup(
     r_form
     t_field
     )
     ⇒ t/nil
```

Description

After any change to grid content, the application must tell the grid that the changes are complete. The grid then updates itself to the user. Changes include: adding or deleting columns and changing cells.

Arguments

r_form	Form handle.
t_field	Field name.

Value Returned

t	Success.
nil	Failure due to incorrect arguments.

©2023 All Rights Reserved.

axlFormGridDeleteRows

```
axlFormGridDeleteRows(
     r_form
     t_field
     x_row
     x_number
     )
     ⇒ t/nil
```

Description

Deletes *x_number* rows at *x_row* number. *x_row*=,*n*>, *x_number*=-1 deletes the entire grid. *x_row*=-1, *x_number*-1 may be used to delete the last row in the grid.

Arguments

r_form	Form handle.
t_field	Field name.
x_row	Row number to start delete.
x_number	Number of rows to delete.

Value Returned

t	Rows deleted.
nil	No rows deleted.

©2023 All Rights Reserved.

axlFormGridEvents

```
axlFormGridEvents(
     r_form
     t_field
     s_event/(s_event1 s_event2 ...)
     )
     ⇒ t/nil
```

Description

Sets user events of interest. It is critical for your application to only set the events that you actually process since enabled events are scripted.

Grid events include the following:

`'rowselect`	Puts grid into row select mode. This is mutually exclusive with `cellselect`.
`'mrowselect`	Puts grid into multi-row select mode. This is mutually exclusive with `cellselect`. Use axlFormGridSelected to determine what rows are selected.
`'cellselect`	Puts grid into cell select mode. This is mutually exclusive with `rowselect` and `mrowselect`.
`'change`	Enables cell change events. Use this option if you have check box and text box type cells.
`'rightpopup`	Enables right mouse button popup. A popup must have been specified in the form file.
`'rightpopupPre`	Enables callback to application before a right mouse popup is displayed. This allows the user to modify the popup shown. Also requires `'rightpopup` be set.
`'leftpopupPre`	Enables callback to application before a left mouse popup is displayed. This allows the user to modify the popup shown. Left mouse popups are only present in the drop down cell type.

By default, the grid body has `rowselect` enabled while the headers have nothing enabled.

©2023 All Rights Reserved.

The form callback structure (*r_form*) has the following new attributes that are only applicable for grid field types:

Event	Row	Col	<Data Fields>
rowselect	<*row*>	1	No
cellselect	<*row*>	<*col*>	Yes (1)
change	<*row*>	<*col*>	Yes (1)
rightpopup	<*row*>	<*col*>	Yes
rightpopupPre	<*row*>	<*col*>	No (2) (3)
leftpopupPre	<*row*>	<*col*>	No (2) (3)

where:

<*row*>	Row number (1 based)
<*col*>	Column number (1 based)
<*Data fields*>	Setting of the *r_form* attributes *curValue*, *curValueInt* and *isValueString*.

- Communicates the value of the data *before* the field is changed. The change event sends the value *after* the field is changed.
- Events are sent immediately before a popup is displayed so the application has the opportunity to modify it. See axlFormGridEvents on page 895 to set this and other event options.
- If using events `rightpopupPre` or `leftpopupPre`, the popup may be cancelled by calling `axlFormGridCancelPopup` when you receive one of these events.

See Using Grids on page 805 for a grid overview.

Assigning events to a grid overrides the previous assignment. Therefore, following do not work:

```
axlFormGridEvents(fw "grid 'change)
axlFormGridEvents(fw "grid 'cellselect)
```

Instead, use the following command.

```
axlFormGridEvents(fw "grid '(cellselect change) )
```


©2023 All Rights Reserved.

Arguments

r_form	Form handle.
t_field	Field name.
s_events	See above.

Value Returned

`t`	User event set.
`nil`	No user event set.

See Also

axlFormGridNewCell

©2023 All Rights Reserved.

axlFormGridGetCell

```
axlFormGridGetCell(
     r_form
     t_field
     r_cell
)
⇒ r_cell/nil
```

Description

Returns grid cell data for a given row and column. All associated data for the cell is returned.

Note: The cell value is always returned as a string except for REAL and LONG data types which are returned in their native format.

If row or cell number of 0 is used then top or side heading data is returned (if present.)

Note: For best performance, reuse the cell if accessing multiple cells.

Arguments

r_form	Form handle.
t_field	Field name.
r_cell	Grid cell from `axlFormGridNewCell()`.

Value Returned

r_cell	Cell data.
`nil`	Invalid form id, field label or cell doesn't exist in the grid.

©2023 All Rights Reserved.

Example

```
cell = axlFormGridNewCell()
cell->row = 3
cell->col = 1
axlFormGridInsertRows(form, "grid" cell)
printf("cell value = %L\n", cell)
```

Returns the value of cell - (1,3).

©2023 All Rights Reserved.

axlFormGridInsertCol

```
axlFormGridInsertCol(
     r_form
     t_field
     r_formGridCol
     )
     ⇒ t/nil
```

Description

Adds a column with the indicated options (*g_options*) to a grid field. The *g_options* parameter is based on the type `formGridCol`. The `formGridCol` structure has default behavior for all settings.

Note: For more information on using this function, see Using Grids on page 805 for an overview.

Table 11-6 on page 900 describes the `FormGridCol` attributes.

Table 11-6 FormGridCol Attributes

Attribute	Type	Default	Description
`fieldType`	symbol	TEXT	Field types include: TEXT, STRING, LONG, REAL, ENUMSET, and CHECKITEM.
`fieldLength`	integer	16	Maximum data length.
`colWidth`	integer	0	Width of column.
`headText`	n/a	n/a	If the grid has a top heading, sets the heading text. Can also set using `axlFormGridSet`.
`Alignment Types (left, right, and center):`			
`align`	symbol	Left	Column alignment.
`topAlign`	symbol	Center	Column header alignment.

©2023 All Rights Reserved.

Table 11-6 FormGridCol Attributes

Attribute	Type	Default	Description
`scriptLabel`	string	`<row number>`	Column scripting name. If the column entry can be edited, you can provide a name which is recorded to the script file. For fieldTypes of TEXT, this option is ignored. Case is ignored and text should not have white space or the symbol '`!`'.
`helpTip`	string	n/a	Text to display when user hovers over the column header
`popup`	string	n/a	Name of the associated popup. May be applied to columns or cells of types ENUMSET, STRING, LONG, or REAL.
Note: Accuracy support is only applicable for LONG and REAL column types. If used, you must set both min and max values.			
`decimals`	integer	n/a	Number of decimal places.
`max`	integer or float	n/a	Maximum value.
`min`	integer or float	n/a	Minimum value.

Note: You can add columns to a grid field only at creation time. Once rows have been added to a grid, no new columns may be added. This is true, even if you delete all rows in the grid.

©2023 All Rights Reserved.

Arguments

r_form	Form handle.
t_field	Field name.
r_formGridCol	Instance of type `formGridCol`.

Value Returned

`t`	Column added.
`nil`	Failure due to a nonexistent form or field, field not of type `GRID`, errors in the *g_options* defstruct, or grid already had a row added.

Examples

For a complete grid programming example, see: `<cdsroot>/share/pcb/examples/skill/form/grid`.

Example 1

```
options = make_formGridCol
options->fieldType = 'TEXT
options->align = 'center
axlFormGridInsertCol(r_form "grid" options)
```

Adds the first column of type `TEXT` (non-editable) with center alignment.

Example 2

```
options->fieldType = 'ENUMSET
options->popup = "grid2nd"
options->colWidth = 10
options->scriptLabel = "class"
axlFormGridInsertCol (r_form "grid" options)
```

Adds the second column of type `ENUM` (non-editable) with column width of 10 and center alignment, assuming that the form file has a popup definition of *grid2nd*.

©2023 All Rights Reserved.

axlIsGridCellType

```
axlIsGridCellType(
     r_cell
     )
     ⇒ t/nil
```

Description

Tests the passed symbol to see if its user type is of the form `"grid cell"`.

Arguments

r_cell	Symbol

Value Returned

`t`	Symbol is of the type form grid cell.
`nil`	Symbol is not of the type form grid cell.

©2023 All Rights Reserved.

axlFormGridInsertRows

```
axlFormGridInsertRows(
     r_form
     t_field
     x_row
     x_number
     )
     ⇒ t/nil
```

Description

Inserts *x_number* rows at *x_row* number location. Rows are inserted empty. A -1 may be used as *x_row* to add to end of the grid. Since grids are 1 based, a 1 inserts at the top of the grid.

Arguments

r_form	Form handle.
t_field	Field name.
x_row	Row number of insertion point.
x_number	Quantity of rows to add.

Value Returned

`t`	One or more rows inserted.
`nil`	No rows inserted.

©2023 All Rights Reserved.

axlFormGridNewCell

```
axlFormGridNewCell(
     )
     ⇒ r_cell
```

Description

Creates a new instance of *r_cell* which is required as input to axlFormGridBatch or axlFormSetField for form grid controls. As a convenience, the consuming APIs do not modify the cell attributes. You need not reset all attributes between API calls.

See axlFormGridDoc for grid overview.

See axlFormGridSetBatch on page 907 for a complete description of cell attributes.

Arguments

None.

Value Returned

r_cell	New list gridcell handle.

See Also

axlIsGridCellType, axlFormGridInsertRows, axlFormGridDeleteRows, axlFormGridCancelPopup, axlFormGridEvents, axlFormGridOptions, axlFormGridSetBatch, axlFormGridBatch, axlFormGridGetCell, axlFormGridReset, axlFormGridSelected, axlFormGridSelectedCnt, axlFormGridSetSelectRows

©2023 All Rights Reserved.

axlFormGridReset

```
axlFormGridReset(
     r_form
     t_field
     )
     ⇒ t/nil
```

Description

Resets grid to its unloaded state. Application should then set the columns, then rows, to the same state as when they initially loaded the windows.

Changes the number of columns after the grid has already been initialized.

Arguments

r_form	Form handle.
t_field	Field name.

Value Returned

`t`	Grid reset.
`nil`	Grid not reset.

Example

For a programming example, see `fgrid.il` in `<cdsroot>/share/pcb/examples/skill/`

Pseudo code:

```
axlFormGridReset(fg "grid")
initCols()
initRows()
axlFormGridUpdate(fg "grid")
```


©2023 All Rights Reserved.

axlFormGridSetBatch

```
axlFormGridSetBatch(
     r_form
     t_field
     s_callback
     g_pvtData
     )
     ⇒ t/nil
```

Description

Changes grid cells much faster than `axlFormSetField` when changing multiple cells. Both APIs require a grid cell data type (`axlFormGridNewCell`.)

Grid performs single callback using *`s_callback`* to populate the grid. You must call `axlFormGridBatch` in the callback in order to update grid cells.

See the programming example, `fgrid.il` at `<`*`cdsroot`*`>/share/pcb/examples/skill/form/grid`. Create rows and columns before calling this batch API.

Within the callback, use only `axlFormNewCell` and `axlFormGridBatch` from the `axlForm` API.

After changing cells, update the display using `axlFormGridUpdate` outside of the callback.

Grid Cell Data Type (r_cell) Attributes

`x_row`	Row to update.
`x_col`	Column to update.
`g_value`	Value (may be string, integer, or float) if `nil`, preserve current grid setting for the cell.
`s_backColor`	Optional background color.
`s_textColor`	Optional text color.
`s_check`	Set or clear check mark for `CHECKITEM` cells. Ignored for non-check cells. Value may be `t` or `nil`.
`s_noEdit`	If cell is editable, disables edit. Ignored for `TEXT` columns since they are not editable. Current settings are preserved.
`s_invisible`	Make cell invisible. Current cell settings are preserved by the grid.

©2023 All Rights Reserved.

s_popup	Use popup name in the form file to set this, or "" to unset. If enum, string, long, or real cell, then overrides column popup, else restores back to popup of the column. Ignored for all other cell types.
t_objType	Object name `"r_cell"` (read-only)

Note: Previous grid cell settings are overridden by values in `s_noEdit` and `s_invisible`.

Column and Row access:

Rows and columns are 1 based. To set the cell in the first column and row, you set the row and col number to 1.

You can control header and script text with reserved row and column values as follows:

(<*row*>, 0)	Set side header display text.
(<*row*>, -1)	Set side header scripting text.

Note: Case is ignored, and text must not contain spaces or the '`!`'

(0, <*col*>)	Set top header display text. You may also set the top header at column creation time using `axlFormGridInsertCol`.
(0, 0)	Setting not supported.

For headers and script text, *g_value* is the only valid attribute other than *row* and *col*.

©2023 All Rights Reserved.

Colors available for `s_backColor` and `s_textColor`:

- nil - use system defaults for color, typically white for background and black for text
- black
- white
- red
- green
- yellow
- button - use the current button background color

Arguments

`r_form`	Form handle.
`t_field`	Field name.
`t_callback`	Function to callback. Takes a single argument: *`g_pvtData`*
`g_pvtData`	Private data (Pass `nil` if not applicable.)

Value Returned

`t`	Grid cell changed.
`nil`	No grid cell changed, or application callback returned `nil`.

©2023 All Rights Reserved.

axlFormGridUpdate

```
axlFormGridUpdate(
          r_form
          t_field
) -> t/nil
```

Description

Unlike the form lists control you must manually notify the grid control that it must update itself. You should use this call in the following situations:

- Inserting a row or rows
- Deleting a row or rows
- Changing cell(s)

You should make the call at the end of all of changes to the grid.

Caution

Do not make this call inside the function you use with axlFormGridSetBatch. Make it after axlFormGridSetBatch returns.

Arguments

r_form	Standard form handle.
t_field	Standard field name.

Value Returned

Returns `t` for success, `nil` for failure.

See Also

axlFormGridNewCell

©2023 All Rights Reserved.

axlFormInvalidateField

```
axlFormInvalidateField(
     r_form
     t_field
     )
     ⇒ t/nil
```

Description

Invalidates the form's field. Allows Windows to send a redraw message to the field's redraw procedure.

Use only for thumbnail fields.

Arguments

r_form	Form handle.
t_field	Field name.

Value Returned

`t`	Field invalidated.
`nil`	No field invalidated.

©2023 All Rights Reserved.

axlFormIsFieldEditable

```
axlFormIsFieldEditable(
     r_form
     t_field
     )
     ⇒ t/nil
```

Description

Checks whether the given form field is editable. If the field is editable, `t` is returned. If the field is greyed, then `nil` is returned.

Arguments

r_form	Form id.
t_field	Field name.

Value Returned

`t`	Field is editable.
`nil`	Field is grayed, or not editable.

©2023 All Rights Reserved.

axlFormListAddItem

```
axlFormListAddItem(
     r_form
     t_field
     t_listItem/lt_listItems/nil
     g_index
     )
     ⇒ t/nil
```

Description

Adds an item to a list at position *x*. To add many items efficiently, pass the items as a list.

Arguments

r_form	Form id.
t_field	Field name.
t_listItem	String of items in the list. If adding to list for the first time, you must send a `nil` to display the list.
lt_listItems	List of strings to add.
g_index	0 = First item in the list. -1 = Last item in the list.

Value Returned

`t`	One or more items added to list.
`nil`	No items added to list due to incorrect arguments.

Example 1

```
axlFormListAddItem(f1, "list" "a" -1)
axlFormListAddItem(f1, "list" "b" -1)
axlFormListAddItem(f1, "list" "c" -1)
; since first time, send a nil to display the list
axlFormListAddItem(f1, "list" nil, -1)
```

Adds three items to the end of a list.

©2023 All Rights Reserved.

Example 2

```
axlFormListAddItem(f1, "list" '("a" "b" "c"), -1)
```

Adds three items to the end of a list (alternate method).

©2023 All Rights Reserved.

axlFormListDeleteItem

```
axlFormListDeleteItem(
     r_form
     t_field
     t_listItem/x_index/lt_listItem/nil
     )
     ⇒ t/x_index/nil
```

Description

Deletes indicated item in the list. You can delete by a string or by position. Deleting by string works best if all items are unique. Position can be problematic if you have the list sort the items that you add to it.

To quickly delete multiple items, call this interface with a list of items.

Note: Delete by list only supports a list of *strings*.

Arguments

r_form	Form id.
t_field	Field name.
x_index	Position of the item to be deleted. 0 is the first item in the list, -1 is the last item in the list.
t_listItem	String of item to delete.
lt_listItems	List of items to delete.
nil	Deletes the last item.

©2023 All Rights Reserved.

Value Returned

x_index	If using strings (*t_listItem*) to delete items, returns the index of strings deleted. Useful for allowing the code to automatically select the next item in the list.
t	If deleting by index (*x_index*), it returns t if successful in deleting the item.
nil	Failed to delete the item.

©2023 All Rights Reserved.

axlFormListGetItem

```
axlFormListGetItem(
     r_form
     t_field
     x_index
     )
     ⇒ t_listItem/nil
```

Description

Returns the item in the list at index (*x_index*.) Lists start at index 0. If -1 is passed as an index, returns the last item in the list.

Arguments

r_form	Form id.
t_field	Field name.
x_index	Offset into the list. 0 = First item in the list. -1 =Last item in the list.

Value Returned

t_listItem	String of item in the list.
nil	Index not valid, or no item at that index.

©2023 All Rights Reserved.

axlFormListGetSelCount

```
axlFormListGetSelCount(
          r_form
          t_field
          )
     ==> x_count/nil
```

Description

This only applies to a multi-select list box (OPTIONS multiselect in form file).
Returns a count of number of items selected in a multi-select list box.

Arguments

r_form	Form control.
t_field	Name of the field.

Values Returned

`nil`	If not a multi-list box.
x_count	Number of items selected.

See Also

axlFormListGetSelItems, axlFormListGetCount

Example

See `axlform.il` example.

©2023 All Rights Reserved.

axlFormListGetSelItems

```
axlFormListGetSelItems(
     r_form
     t_field
     )
     ==> lt_selected/nil
```

Description

This only applies to a multi-select list box (OPTIONS multiselect in form file).

For a multi-select list box returns list of strings for items selected. If no items selected or this is not appropriate for control returns `nil`.

Arguments

r_form	Form control.
t_field	Name of the field.

Value Returned

lt_selected	List of strings for items selected.
`nil`	Error or nothing selected.

See Also

axlFormListGetSelCount, axlFormListSelAll

Example

See `axlform.il` example.

©2023 All Rights Reserved.

axlFormListOptions

```
axlFormListOptions(
     r_form
     t_field
     s_option/(s_option1 s_option2 ...)
     )
     ⇒ t/nil
```

Description

Sets options for a list control. The following options are supported:

'doubleClick	Enable double-click selection. Passing a `nil` for an option sets default list behavior. Default is single click.

Double-click events are handled as follows:

- Receive the first click as an event with the item selected and the result is: `doubleClick = nil`.
- Receive the second click as an event with the item selected and the result is: `doubleClick = t`.

Suggested use model:

On first click do what would normally happen if the user clicks only once. The second click is a natural extension. For example, on a browser the first click selects the file. The second click does what the *OK* button would do: send the file to the application and close the form.

Arguments

r_form	Form id.
t_field	Field name.
s_option	Sets option for list control. `nil` resets to default.

©2023 All Rights Reserved.

Value Returned

`t`	Options set.
`nil`	No options set due to incorrect arguments.

Example 1

```
axlFormListOptions(form "list" 'doubleClick)
```

Enables double-click for a list.

Example 2

```
axlFormListOptions(form "list" nil)
```

Disables double-click for a list.

©2023 All Rights Reserved.

axlFormListSelAll

```
axlFormListSelAll(
     r_form
     t_field
     g_set
     )
     ==> t/nil
```

Description

This only applies to a multi-select list box (OPTIONS multiselect in form file).

This either selects or deselects all items in list box.

Arguments

r_form	Form control.
t_field	Name of the field.
g_set	`t` to select all; `nil` to deselect all.

Value Returned

`t` if successful, `nil` field is not a mutli-select list box

See Also

axlFormListGetSelItems

Examples

Select all items in multi-list control; `mlistfield`.

```
axlFormListSelAll(fw "mlistfield" t)
```

De-Select all items in multi-list control; `mlistfield`.

```
axlFormListSelAll(fw "mlistfield" nil)
```


©2023 All Rights Reserved.

axlFormMsg

```
axlFormMsg(
     r_form
     t_messageLabel
     [g_arg1 ...]
     )
     ⇒ t_msg/nil
```

Description

Retrieves and prints a message defined in the form file by message label (*t_messageLabel*.) Form file allows definitions of messages using the "MESSAGE" keyword (see Using Forms Specification Language on page 791.) Use this to give a user access to message text, but no access to your SKILL code.

Messages are only printed in the status area of the form owning the message (*r_form*.) You cannot access message ids from one form file and print to another. The main window is used for forms with no status lines.

You use standard formatting and argument substitution (see `printf`) for the message.

Arguments

r_form	Form *dbid*.
t_messageLabel	Message label defined in form file by the MESSAGE keyword.
g_arg1 ...	Substitution parameters (see `printf`)

Value Returned

t_msg	Message that prints.
`nil`	No message with the given name found in this form file.

©2023 All Rights Reserved.

Examples

```
Form file (level: 0 is info, 1 is info with no journal entry, 2 is warning, 3
is error, and 4 is fatal.);
    MESSAGE drccount 0 "Drc Count of %d for %s"
    MESSAGE drcerrors 2 "Drc Errors"

axlFormMsg(fw "drccount" 10 "spacing")
axlFormMsg(fw "drcerrors")
```


©2023 All Rights Reserved.

axlFormGetFieldRange

```
axlFormGetFieldRange(
     r_form
     t_field
     )
     ⇒ l_fieldRange/nil
```

Description

Returns the min/max values specified for an INTFILLIN or REALFILLIN value. For other field types, or if these values are not set on the field, `nil` is returned.

Arguments

r_form	Form *dbid*.
t_field	Name of the field.

Value Returned

l_fieldRange/nil	`nil` if field doesn't exist
	`nil` if field isn't INTFILLIN or REALFILLIN
	`nil` if the field doesn't have range set
	`list(min max)` if field has legal range set

©2023 All Rights Reserved.

axlFormGetFieldType

```
axlFormGetFieldType(
     r_form
     t_field
     )
     ⇒ g_fieldType/nil
```

Description

Returns the control type for a form field. See the keywords in Callback Procedure: formCallback on page 882 for a list of supported field types.

Arguments

r_form	Form *dbid*.
t_field	Field name.

Value Returned

g_fieldType	One of the control types.
nil	Field does not exist or is not one of the types supported.

©2023 All Rights Reserved.

axlFormDefaultButton

```
axlFormDefaultButton(
     r_form
     t_field/g_mode
     )
     ⇒ t/nil
```

Description

Forms normally automatically set a *default button* in a form with the `DEFAULT` section in the form file or with the *OK* and *DONE* labels. When the user hits a carriage return, the *default button* is executed.

A form can have, at most, one default button. Only a field of type `BUTTON` can have the default button attribute.

Note: If default buttons are disabled in a form, then attempts to establish a new default button are ignored. You can only change the default button if the capability in the form is enabled.

Arguments

r_form	Form *dbid*.
t_field	Field name to establish as new button default.
g_mode	`t` to enable the default button in the form, `nil` to disable it.

Value Returned

`t`	Default button set.
`nil`	Field does not exist.

©2023 All Rights Reserved.

Example 1

```
axlFormDefaultButton(form nil)
```

Sets no default button in form.

Example 2

```
axlFormDefaultButton(form "cancel")
```

Sets the default button to be `Cancel` instead of the default `OK`.

©2023 All Rights Reserved.

axlFormGridOptions

```
axlFormGridOptions(
     r_form
     t_field
     s_name
     [g_value]
     )
     ⇒ t/nil
```

Description

Miscellaneous grid options. See Using Grids on page 805 for a grid overview.

Arguments

r_form	Form handle.
t_field	Field name.
s_name/g_value	Supported options shown.

s_name/g_value Supported Options

['goto *x_row*]	Puts the indicated row on display, scrolling the grid if necessary.

Note: -1 signifies the last row.

['goto *x_row*:*x_col*]	Sends grid to indicated row and column.

Note: -1 signifies the last row or column.

['select *x_row*]	Selects (highlights) indicated row.
['select *x_row*:*x_col*]	Selects (highlights) indicated cell. Grid must be in cell select mode else row is selected instead of cell. See `axlFormGridEvents` for more information.
['deselectAll]	Deselect any selected grid cells or rows.

©2023 All Rights Reserved.

Value Returned

`t`	Selected grid option performed.
`nil`	Selected grid option not performed.

Example 1

```
axlFormGridOption(fw, "mygrid" 'goto 10)
```

Makes row 10 visible.

Example 2

```
axlFormGridOption(fw, "mygrid" 'goto 5:2)
```

Makes row 5 column 2 visible.

Example 3

```
axlFormGridOption(fw, "mygrid" 'deselectAll)
```

Deselects anything highlighted in the grid.

©2023 All Rights Reserved.

axlFormSetActiveField

```
axlFormSetActiveField(
     r_form
     t_field
     )
     ⇒ t/nil
```

Description

Makes the indicated field the active form field.

Note: If you do an `axlFormRestoreField` in your dispatch handler on the field passed to your handler, then that field remains active.

Arguments

r_form	Form *dbid*.
t_field	Field name.

Value Returned

`t`	Field set active.
`nil`	Failed to set the field active.

©2023 All Rights Reserved.

axlFormSetDecimal

```
axlFormSetDecimal(
     o_form
     g_field
     x_decimalPlaces
     )
     ⇒ t/nil
```

Description

Sets the decimal precision for real fill-in fields in the form. If *g_field* is `nil`, sets the precision for all real fill-in fields in the form.

Arguments

o_form	Form handle.
g_field	Field label, or `nil` for all fields.
x_decimalPlaces	Number of decimal places - must be a positive integer.

Value Returned

`t`	Successfully set new decimal precision.
`nil`	Error due to invalid arguments.

©2023 All Rights Reserved.

axlFormSetFieldEditable

```
axlFormSetFieldEditable(
     r_form
     t_field
     g_editable
     )
     ⇒ t/nil
```

Description

Sets individual form fields to editable (`t`) or grayed (`nil`).

Arguments

r_form	Form *dbid*.
t_field	Field name.
g_editable	Editable (`t`) or grayed (`nil`).

Value Returned

`t`	Set form field to editable or grayed.
`nil`	Failed to set form field to editable or grayed.

©2023 All Rights Reserved.

axlFormSetFieldLimits

```
axlFormSetFieldLimits(
     o_form
     t_field
     g_min
     g_max
     )
     ⇒ t/nil
```

Description

Sets the minimum or maximum values a user can enter in an integer or real fill-in field. If a `nil` value is provided, that limit is left unchanged.

For a `REAL` field, the type for *`g_min`* and *`g_max`* may be `int`, `float`, or `nil`. For an `INT` or `LONG`, the type must be `int` or `nil`.

TRACKBAR: When used for a trackbar field type. If either of the argument is `0`, then the current setting for that option is maintained. Both *`g_min`* and *`g_max`* must be integer numbers. *`g_min`* is the interval of the tickmarks (default is 1). Tickmarks may not be shown in all user interfaces. This is the interval size when moving the trackbar to the next tick mark via axlFormSetField. *`g_max`* is the number of steps in the trackbar (default is 100).

Arguments

`o_form`	Form handle.
`t_field`	Field label.
`g_min`	Minimum value for field.
`g_max`	Maximum value for field.

Value Returned

`t`	Set max or min.
`nil`	Error, indicating a problem with one of the input parameters.

©2023 All Rights Reserved.

axlFormTreeViewAddItem

```
axlFormTreeViewAddItem(
     r_form
     t_field
     t_label
     g_hParent
     g_hInsertAfter
     [g_multiSelectF]
     [g_hLeafImage]
     [g_hOpenImage]
     [g_hClosedImage]
     )
     ⇒ g_hItem/nil
```

Description

Adds an item to a treeview under *parent* and after *insertAfter* sibling. If sibling is `nil`, the item is added as the last child of a parent. If parent is `nil`, item is created as the root of the tree.

Note: This is the only interface for adding an item to a tree. `axlFormSetField` is disabled for Tree controls.

Applications must keep the returned handle *`l_hItem`* since a handle will be passed as *`form->curValueInt`* when the item is selected from tree view. The string associated with the selected item is also passed as *`form->curValue`*, however the string value may not be unique and cannot be used as a reliable identifier for the selected treeview item.

The tree view defaults to single selection mode. There is no checkbox associated with items in the tree view to make multiple selections. To make a tree view item multi select, pass one of the following values for *`t_multiSelectF`*:

- `nil` or `'TVSELECT_SINGLE` for no selection state checkbox
- `t` or 'TVSELECT_2STATE for 2 state checkbox
- `'TVSELECT_3STATE` for 3 state checkbox

If an item is defined as multi select, a check box appears as part of the item. The user can check/uncheck (2 state) this box to indicate selection or select checked/unchecked/disabled modes for a 3 state checkbox. When the user makes any selection in the checkbox, its value is passed to application code in *`form->treeViewSelState`*. In this case, *`form->curValue`* is `nil`.

©2023 All Rights Reserved.

Callback Values

In the callback function for the form, the first argument form, has the following properties relevant to treeviews:

form->curValue	Contains the label of a treeview item. This is set in single select mode and in multi select mode when the user selects the item. In this case, the *result->tree.selectState* is -1.
form->curValueInt	Contains id of the selected treeview item.
form->selectState	In multi select mode, when the user picks the selection checkbox, this field will contain: 0 if selection checkbox is not checked 1 if selection checkbox is checked 2 if selection checkbox is disabled ((3 state mode only) In this case the *result->string* is empty. In all other cases the value is -1.
form->event	If event property is set to `"rightpopup"`, treeview control has a popup and the user has selected an item in the popup. In this case, *form->curValue* is set to the popup index selected, and *form->selectState* is set to `-1`. *form->curValueInt* is set to the treeview item id.You add popups to treeview fields in a form like you add any other field in a form. For all non-popup operations, event is set to `"normal."`

©2023 All Rights Reserved.

Arguments

r_form	Form *dbid*.
t_field	Field name.
t_label	String of item in the treeview.
g_hParent	Handle of the parent. If `null`, item created as the root of the tree.
g_hInsertAfter	Handle of the sibling to add the item after. If `null`, item added at the end of siblings of the parent.
t_multiSelectF	If `t`, the item has a checkbox for multi selection.
g_hLeafImage	Handle of the image to use whenever this item is a leaf node in the tree view. If `nil` or not supplied, the default pink diamond image is used.
g_hOpenImage	Handle of image to be used whenever this item is an expanded parent node in the tree view. If `nil` or not supplied, the default open folder image is used.
g_hClosedImage	Handle of image to use whenever the item is an unexpanded parent node in the tree view. If `nil` or not supplied, the default closed folder image is used.

Value Returned

g_hItem	Item is added to the tree view control.
`nil`	No item is added to the tree view control due to an error.

Example

see `<cdsroot>/share/pcb/examples/skill/form/basic/axlform.il`

©2023 All Rights Reserved.

axlFormTreeViewChangeImages

```
axlFormTreeViewChangeImages(
     r_form
     t_field
     g_hItem
     [g_hLeafImage]
     [g_hOpenImage]
     [g_hClosedImage]
     )
     ⇒ t/nil
```

Description

Modifies various bitmap images associated with a given tree view item.

Arguments

r_form	Form id.
t_field	Field name.
g_hItem	Handle of item in tree view. Handle was returned as a result of the call to `axlFormTreeViewAddItem` when item was initially added.
g_hLeafImage	Handle of the image to use whenever item is a leaf node in the tree view. If `nil` or not supplied, the default pink diamond image is used.
g_hOpenImage	Handle of image to use whenever item is an expanded parent node in the tree view. If `nil` or not supplied, the default open folder image is used.
g_hClosedImage	Handle of image to use whenever item is an unexpanded parent node in the tree view. If `nil` or not supplied, the default closed folder image is used.

©2023 All Rights Reserved.

Value Returned

`t`	Tree view item's images are modified.
`nil`	Failed to modify tree view item's images.

See Also

axlFormTreeViewLoadBitmaps

©2023 All Rights Reserved.

axlFormTreeViewChangeLabel

```
axlFormTreeViewChangeLabel(
     r_form
     t_field
     g_hItem
     t_label
     )
     ⇒ t/nil
```

Description

Modifies text of a given treeview item.

Arguments

r_form	Form id.
t_field	Field name.
g_hItem	Handle of item in the tree view. This handle was returned as a result of the call to `axlFormTreeViewAddItem`.
t_label	New label.

Value Returned

`t`	Tree view item's label is modified.
`nil`	Failed to modify tree view item's label.

©2023 All Rights Reserved.

axlFormTreeViewGetImages

```
axlFormTreeViewGetImages(
     r_form
     t_field
     g_hItem
     )
     ⇒ l_hImage/nil
```

Description

various bitmap image handles that refer to images used by a specified item in the tree view.

Arguments

r_form	Form id.
t_field	Field name.
g_hItem	Handle of item in the tree view. This handle was returned as a result of the call to `axlFormTreeViewAddItem` when this item was initially added.

Value Returned

l_hImage	List of three image handles. The first is the handle of the image used when this item is a leaf node. The second is the handle of the image used when this item is an expanded parent node. The third is the handle of the image used when this item is an unexpanded parent node.
`nil`	Error due to invalid arguments.

©2023 All Rights Reserved.

axlFormTreeViewGetLabel

```
axlFormTreeViewGetLabel(
     r_form
     t_field
     g_hItem
     )
     ⇒ t_label/nil
```

Description

Returns text of a given treeview item.

Arguments

r_form	Form id.
t_field	Field name.
g_hItem	Handle of item in the tree view. This handle was returned as a result of the call to `axlFormTreeViewAddItem` when this item was initially added.

Value Returned

t_label	Text of given tree view item.
`nil`	Failed to get text of given tree view item due to invalid arguments.

©2023 All Rights Reserved.

axlFormTreeViewGetParents

```
axlFormTreeViewGetParents(
     r_form
     t_field
     g_hItem
     )
     ⇒ lg_hItem/nil
```

Description

Returns a list of all the ancestors of a treeview control item, starting from the root of the tree. Helps in search operations in SKILL. Applications can traverse their tree list following parent lists to a given item instead of searching the whole tree for an item.

Arguments

r_form	Form id.
t_field	Field name.
g_hItem	Handle of item in the tree view. This handle was returned as a result of the call to `axlFormTreeViewAddItem` when this item was initially added.

Value Returned

lg_hItem	List containing all parents, starting from the root.
`nil`	Failed to obtain list due to invalid arguments.

©2023 All Rights Reserved.

axlFormTreeViewGetSelectState

```
axlFormTreeViewGetSelectState(
     r_form
     t_field
     g_hItem
     )
     ⇒ x_selectState
```

Description

In multi select mode, returns the select state of a treeview item. This is different than the current selected item in single select tree views. In multi select mode, users can change the select state by clicking on the select checkbox associated with each item.

Arguments

r_form	Form id.
t_field	Field name.
g_hItem	Handle of item in the tree view. This handle was returned as a result of the call to `axlFormTreeViewAddItem` when this item was initially added.

Value Returned

In multi select mode:

`0`	Checkbox is unchecked.
`1`	Checkbox is checked.
`2`	Checkbox is disabled.
`-1`	Single select mode or failure due to invalid arguments.

©2023 All Rights Reserved.

axlFormTreeViewLoadBitmaps

```
axlFormTreeViewLoadBitmaps(
     r_form
     t_field
     lt_bitmaps
     )
     ⇒ l_hImage/nil
```

Description

Allows an application to load one or more bitmaps into Allegro PCB Editor for use in specified tree view.

Arguments

r_form	Form id.
t_field	Field name.
lt_bitmaps	Either a string containing the name of the bitmap file to load, or a list of strings, each of which is the name of a bitmap file to load.

Notes:

- Bitmap is found using BMPPATH variable.
- Uses file extension `.bmp`
- Bitmap images must be 16 x 16 pixels.
- A bitmap file can contain more than one image provided they are appended horizontally (i.e. a bitmap file containing n images will be (16*n) x 16 pixels).
- The color RGB(255,0,0) is reserved for the transparent color.
- Any pixel with this color is displayed using the background color.

©2023 All Rights Reserved.

Value Returned

l_hImage	List of image handles that the caller will use to reference the images in subsequent `axlFormTreeViewAddItem` calls. The list is ordered to correspond with the order that the images were listed in the *lt_bitmaps* parameter.
`nil`	One or more of the bitmap files could not be found, or an error was encountered while adding images.

See Also

axlFormTreeViewChangeImages, axlFormTreeViewAddItem

Example

➡ File `myBmp1.bmp` is a 16 x 16 bitmap and `myBmp2.bmp` is a 32 x 16 bitmap:

```
tree = axlFormTreeViewAddItem(fw "tree" "one" nil nil 'TVSELECT_3STATE)
l = axlFormTreeViewLoadBitmaps(fw "tree" list("myBmp1" "myBmp2"))
axlFormTreeViewChangeImages(fw "tree" tree car(l) cadr(l) nil)
```

axlFormTreeViewLoadBitmaps may return (6 7 8) into variable l.

This mean that the image handle 6 would refer to the bitmap contained in myBmp1.bmp, the image handle 7 would refer to the left half of myBmp2.bmp, and the image handle 8 would refer to the right half of myBmp2.bmp.

©2023 All Rights Reserved.

axlFormTreeViewSet

```
axlFormTreeViewSet(
     r_form
     t_field
     s_option
     g_hItem
     [g_data]
     )
     ⇒ t/nil
```

Description

Allows an application to change global and individual items in a tree view control.

Arguments

r_form	Form id.
t_field	Field name as a string
s_option	*s_option* is one of the symbols listed.
g_hItem	Tree view user data type.
[s_data]	*optional symbol*

Each *s_option* is paired with *g_hItem*, the handle of an item in the tree view control. If the option you are setting is global, you use `nil` in place of *g_hItem*. The pairs of different values of *s_option* with *g_hItem* is in the following manner.

s_option	***g_hItem***
TV_REMOVEALL	nil
TV_DELETEITEM	*g_hItem*
TV_ENSUREVISIBLE	*g_hItem*
TV_EXPAND	*g_hItem(4)*
TV_EXPAND_TOP	nil (5)
TV_COLLAPSE	*g_hItem(4)*
TV_COLLAPSE_TOP	nil (5)
TV_SELECTITEM	g_hItem (2) (3)

©2023 All Rights Reserved.

TV_SORTCHILDREN	g_hItem
TV_NOEDITLABEL	nil - disables in place label editing
TV_NOSELSTATEDISPATCH	nil -check box selection not dispatched
TV_ENABLEEDITLABEL	nil - enable in place label editing
TV_MULTISELTYPE	*g_hItem (1)*
TV_NOSHOWSELALWAYS	nil
TV_SHOWSELALWAYS	nil

Notes:

- For TV_MULTISELTYPE, you can also use the option *g_data* which is one of the following: TVSELECT_SINGLE, TVSELECT_2STATE, TVSELECT_3STATE. Default is TVSELECT_SINGLE.
- *g_hItem* is the Handle of item in the tree view control. Its value can be received in the following ways:
  - Call axlFormTreeViewAddItem.
  - Call axlFormTreeViewGetParents.
  - Change a tree control that causes a form dispatch. Then the form User Type attributes curValue and curValueInt are the *g_hItem*.
- You can pass nil for *g_hItem* in some cases. Pass nil for TV_SELECTITEM option to deselect the item that is currently selected.
- If nil is passed for TV_EXPAND or TV_COLLAPSE then all levels (including) children are expanded or collapse.
- The two _TOP options, TV_EXPAND_TOP and TV_COLLAPSE_TOP, respectively, expand and collapse all top level tree items. Children tree item states are preserved.

©2023 All Rights Reserved.

Value Returned

`t`	Changed one or more items in tree view control.
`nil`	Failed to change items in tree view control.

Example

- Delete selected treeview item in a form.

```
(axlFormTreeViewSet form form->curField 'TV_DELETEITEM form->curValue)
```

- Expand all levels including children:

```
axlFormTreeViewSet(form "tree" 'TV_EXPAND nil)
```

- Collapses all expanded top levels:

```
axlFormTreeViewSet(form "tree" 'TV_COLLAPSE_TOP nil)
```

For more examples see `<cdsroot>/share/pcb/examples/skill/form/basic`

©2023 All Rights Reserved.

axlFormTreeViewSetSelectState

```
axlFormTreeViewSetSelectState(
     r_form
     t_field
     g_hItem
     g_state
     )
     ⇒ t/nil
```

Description

In multi select mode, sets the select state. This is different than the current selected item in single select tree views. In multi select mode, users can change the select state by clicking on the select checkbox associated with each item.

Arguments

r_form	Form id.
t_field	The name of the field.
g_hItem	Handle of the item in the tree view. This handle was returned as a result of the call to `axlFormTreeViewAddItem` when this item was initially added.
g_state	Select state to set. ■ Select state is unchecked if *g_state* is `nil` or `'TVSTATE_UNCHECKED` ■ Select state is checked if *g_state* is `t` or `'TVSTATE_CHECKED` ■ Select state is disabled if *g_state* is `'TVSTATE_DISABLED`

Value Returned

`t`	Set select state.
`nil`	Failed to set select state.

©2023 All Rights Reserved.

©2023 All Rights Reserved.

©2023 All Rights Reserved.

12

Simple Graphics Drawing Functions

This chapter describes the AXL-SKILL functions related to Simple Graphics Drawing. You use these drawing utilities for drawing into bitmap areas such as thumbnails within the UIF forms package. (For more information on thumbnails, see the axl form BNF document, look for the entries with THUMBNAIL).

`axlGRP` is the AXL interface to a Simple Graphics Drawing utility.

You can simplify application drawing into thumbnails within forms as follows:

1. Specify the thumbnail field within the form file. This should not have a bitmap associated with it.
2. Call the `axlGRPDrwInit` function with the form, field name, and a callback function. Keep the handle returned by this function so you can use it in later processing.
3. Using the functions provided, redraw the image. The callback function is invoked with the graphics handle as the parameter.
4. Use the `axlGRPDrwUpdate` function to trigger the callback function.

Note: The application cannot set bitmaps or graphics callbacks using the facilities outlined in the Thumbnail documentation while using this package.

©2023 All Rights Reserved.

Simple Graphics Drawing package supports the following:

- Rectangles (Filled and unfilled)
- Polygons (Filled and unfilled)
- Circles (Filled and unfilled)
- Simple Lines
- Poly Lines
- Bitmaps
- Text

This package supports a mappable coordinate system. With the `GRPDrwMapWindow` function, you can specify a rectangle that gets mapped to the actual drawing area. An aspect ratio of 1 to 1 is maintained.

The zero point of the drawing area is the upper left point of the drawing:

Note: Objects drawn earlier are overlapped by objects drawn later. The application must manage this.

©2023 All Rights Reserved.

Setting Option Properties on the r_graphics Handle

You can set option properties on the `r_graphics` handle before calling the drawing functions. These properties, if applicable, are used by the drawing properties.

Table 12-1 r_graphics Option Properties

Option	Default	Description	Available Settings
color	black	Applies to all elements	(represents the current button color) The color can be SVG color names provided by WWW consortium. ■ #RGB (each of R,G,B is a single hex digit) ■ #RRGGBB ■ #AARRGGBB ■ #RRRGGGBBB ■ #RRRRGGGGBBBB Standard colors are: black, white, red, green, yellow, blue, light blue, rose, purple, teal, dark pink, dark magenta, aqua, gray, olive, orange, pink, beige, navy, violet, silver, rust, lime, brown, mauve, magenta, light pink, cyan, salmon, peach, dark gray, button
fill	unfilled	Applies only to rectangles and polygons.	filled, filled_solid, unfilled
width	0	Applies only when geometric elements are unfilled.	
text_align	left	Text justification. Applies only to text.	left, center, right

©2023 All Rights Reserved.

Table 12-1 r_graphics Option Properties, *continued*

text_bkmode	transparent	Text background display mode. Applies only to text.	transparent, opaque

The following geometric elements are not supported:

- Arcs
- Shapes (for example, polygon's with arcs)
- Bitmaps from resources
- Ellipses

Additionally, the following capabilities are not supported:

- Geometric transformations (rotation, translation, scaling)
- Transparency
- Loading bitmaps from the resource file
- No 3 or 2.5 D

Examples

See `<cdsroot>/share/pcb/examples/skill/form/basic/axlform.il` for a complete example.

©2023 All Rights Reserved.

Functions

axlGRPDrwBitmap

```
axlGRPDrwBitmap(
     r_graphics
     t_bitmap
     )
     ⇒ t/nil
```

Description

Loads a bitmap into a form draw window (drawing area in the graphics field). More drawing can take place on top of the bitmap.

Arguments

r_graphics	Graphics handle.
t_bitmap	Name of bitmap file. File must be on the `BMPPATH`, with `.bmp` as the extension.

Value Returned

`t`	Bitmap loaded into drawing area in the graphics field.
`nil`	No bitmap loaded into the drawing area in the graphics field due to invalid arguments.

©2023 All Rights Reserved.

axlGRPDrwCircle

```
axlGRPDrwCircle(
     r_graphics
     l_origin
     x_radius
     )
     ⇒ t/nil
```

Description

Draws a circle into the area identified by the *r_graphics* handle, at the origin specified, and with the specified radius. Option properties attached to the *r_graphics* handle are applied when drawing the circle.

Arguments

r_graphics	Graphics handle.
l_origin	List noting the *x* and *y* coordinates of the origin.
x_radius	Integer noting the radius of the circle.

Value Returned

`t`	Circle drawn.
`nil`	No circle drawn due to invalid arguments.

©2023 All Rights Reserved.

axlGRPDrwInit

```
axlGRPDrwInit(
     r_form
     t_field
     t_func
     )
     ⇒ r_graphics/nil
```

Description

Use this command to set graphics callback in a form field. It sets up necessary data structures for triggering the graphics callback into the graphics field.

Arguments

r_form	Handle of the form.
t_field	Name of field into which the package should draw. (Only `THUMBNAIL` fields are supported.)
t_func	Name of the drawing callback function. Callback function is invoked with the graphics handle as the parameter.

Value Returned

r_graphics	Graphics package handle.
`nil`	Failed to set up necessary data structures for triggering the graphics callback due to invalid arguments.

©2023 All Rights Reserved.

axlGRPDrwLine

```
axlGRPDrwLine(
     r_graphics
     l_vertices
     )
     ⇒ t/nil
```

Description

Draws a line into the area identified by the *r_graphics* handle and the list of coordinates. Option properties attached to the *r_graphics* handle are applied when drawing the line.

Arguments

r_graphics	Graphics handle.
l_vertices	List of coordinates describing the line.

Value Returned

`t`	Line drawn.
`nil`	No line drawn due to invalid arguments.

©2023 All Rights Reserved.

axlGRPDrwMapWindow

```
axlGRPDrwMapWindow(
     r_graphics
     x_Xextent
     x_Yextent
     )
     ⇒ t/nil
```

Description

Forces a draw in a mapped window. Allows the application to denote the coordinate system that is mapped into the drawing area of the graphics field.

Arguments

r_graphics	Graphics handle.
x_Xextent	X-extent of the drawing window.
x_Yextent	Y-extent of the drawing window.

Value Returned

`t`	Successful
`nil`	Error occurred due to invalid arguments.

See Also

axlGRPDoc

©2023 All Rights Reserved.

axlGRPDrwPoly

```
axlGRPDrwPoly(
     r_graphics
     l_vertices
     )
     ⇒ t/nil
```

Description

Draws a polygon (multi-segment line) into the area identified by the *r_graphics* handle and the list of coordinates. Option properties attached to the *r_graphics* handle are applied when drawing the polygon. If the coordinates do not form a closed polygon, the first and last coordinates in the list are connected by a straight line.

Arguments

r_graphics	Graphics handle.
l_vertices	List of coordinates describing the line.

Value Returned

`t`	Polygon or line drawn.
`nil`	No polygon or line drawn due to invalid arguments.

©2023 All Rights Reserved.

axlGRPDrwRectangle

```
axlGRPDrwRectangle(
     r_graphics
     l_upper_left
     l_lower_right
     )
     ⇒ t/nil
```

Description

Draws a rectangle into the area identified by the *r_graphics* handle and the *upper_left* and *lower_right* coordinates. Option properties attached to the *r_graphics* handle are applied when drawing the rectangle.

Arguments

r_graphics	Graphics handle.
l_upper_left	List noting the coordinate of the upper left point of the rectangle.
l_lower_right	List noting the coordinate of the lower right point of the rectangle.

Value Returned

`t`	Rectangle drawn.
`nil`	No rectangle drawn due to incorrect arguments.

©2023 All Rights Reserved.

axlGRPDrwText

```
axlGRPDrwText(
     r_graphics
     l_origin
     t_text
     )
     ⇒ t/nil
```

Description

Draws text into the area identified by the *r_graphics* handle at the origin specified. Option properties attached to the *r_graphics* handle are applied when drawing the text.

Arguments

r_graphics	Graphics handle.
l_origin	List noting the *x* and *y* coordinate of the origin.
t_text	Text string to be drawn.

Value Returned

`t`	Text drawn.
`nil`	No text drawn due to incorrect arguments.

©2023 All Rights Reserved.

axlGRPDrwUpdate

```
axlGRPDrwUpdate(
     r_graphics
     )
     ⇒ t/nil
```

Description

Force call to register callback function for a draw window. Triggers calling of the application supplied callback function.

Arguments

r_graphics	Graphics handle.

Value Returned

`t`	Application supplied callback function called.
`nil`	No callback function called due to an incorrect argument.

©2023 All Rights Reserved.

©2023 All Rights Reserved.

13

Message Handler Functions

Overview

This chapter describes the AXL-SKILL message handler system and functions. The message handler system allows you to write AXL-SKILL code that does not have to deal explicitly with errors after each call to a lower level routine, but rather checks at only one or two points. This contrasts with application programs that do not have a buffering and exception-handling message facility, where you must test for and respond to errors and exceptions at each point of possible occurrence in your code. Using the functions described in this chapter, you can do the following:

- Establish a *context* for your application messages.

  A context is a logical section of your application during which you want to buffer and test for the potential errors and warnings you provided for in the lower levels of your application code.

- Write messages to the user with one of five levels of *severity*:

Severity Level	Type	Type Description and Response by AXL Message Handler
0	Text	Data created by the application, such as a log or report. Writes to journal and the user interface without being buffered.
1	Info	Such as “10% done,” “20% done”... Writes to user interface only, *not* to context message buffer nor to the journal.
2	Warning	Such as “Connect line is 5 mils wider than allowed.” Writes to context message buffer and journal with a “W” warning tag.

©2023 All Rights Reserved.

Severity Level	Type	Type Description and Response by AXL Message Handler
3	Error	Such as “Cannot find symbol DIP24_200 in library.” Beeps and writes to context message buffer and journal with an “E” error tag.
4	Fatal	Such as “Disk read error. Cannot continue.” Double beeps and writes to context message buffer and journal with an “F” fatal tag.

- Test and change the severity level of the messages created and buffered in a context.
- Check for specific messages in the message buffer, and respond appropriately to anticipated conditions detected by lower-level functions.
- Close a context.

The following illustration shows how `axlMsg` functions move messages to and from a context message buffer and the SKILL user interface.

©2023 All Rights Reserved.

Message Handler Example

```
context = axlMsgContextStart("My own context.")
axlMsgPut(list("My warning" 2))
axlMsgPut(list("My error" 3))
printf("Message severity %d",axlMsgContextTest(context))
axlMsgPut(list("My fatal error %s" 4) "BAD ERROR")
if( axlMsgContextInBuf(context "My error")
    printf("%s\n" "my error is there"))
printf("Message severity %d",axlMsgContextTest(context))
axlMsgContextPrint(context)
axlMsgContextFinish(context)
 ⇒ t
```

1. Starts a context with `axlMsgContextStart`
2. Puts a warning, an error, and a fatal error message using `axlMsgPut`
3. Checks for the error message with `axlMsgContextInBuf`
4. Tests for the context severity level with `axlMsgContextTest`
5. Prints the context buffer with `axlMsgContextPrint`
6. Ends with `axlMsgContextFinish`

When you load the SKILL program shown above, the SKILL command line outputs the following:

```
W- My warning
E- My error
F- My fatal error BAD ERROR
Message severity 3
my error is there
Message severity 4
t
```

General usage of the axlMsg System

- Messages first go to the context buffer
- `axlMsgContextPrint` prints them to the SKILL command line
- The contents of the output buffer from any `print` and `printf` data write to the command line when control returns to the command line. That is why the messages "`Message severity 3`," "`my error is there`" and "`Message severity 4`" follow the buffered messages ("`W- My warning`" ...)

©2023 All Rights Reserved.

Message Handler Functions

This section lists message handler functions.

axlMsgPut

```
axlMsgPut(
     g_message_format
     [g_arg1 ...]
     )
     ⇒ t
```

Description

Puts a message in the journal file. Use this function to “print” messages. It buffers any *errors* or *warnings*, but processes other message classes immediately.

Arguments

g_message_format	Context message (`printf` like) format string. See “Overview” on page 967 for a description of messages and valid arguments.
g_arg1 ...	Values for substitution arguments for the format string.

Value Returned

`t`	Always returns `t`.

Example

See the “Message Handler Example” on page 969.

```
axlMsgPut(list("Cannot find via %s" 3) "VIA10")
 ⇒ t
```


©2023 All Rights Reserved.

axlMsgContextPrint

```
axlMsgContextPrint(
     r_context
     )
     ⇒ t
```

Description

Prints the buffered messages and removes them from the message buffer.

Arguments

r_context	Context handle from `axlMsgContextStart`. Prints messages only for this context (or any children). An argument of `nil` causes `axlMsgContextPrint` to look through all contexts.

Value Returned

`t`	Always returns `t`.

Example

See the "Message Handler Example" on page 969 in the beginning of this chapter.

```
axlMsgContextPrint(context)
 ⇒ t
```

Prints the buffered messages in that context to SKILL command line:

```
W- My warning
E- My error
F- My fatal error BAD ERROR
```


©2023 All Rights Reserved.

axlMsgContextGetString

```
axlMsgContextGetString(
     r_context
     )
     ⇒ lt_messages/nil
```

Description

Gets the messages in the message buffer and removes them from the buffer. Call `axlMsgContextGetString` subsequently to communicate those messages to the user (for example, in a log file).

Arguments

r_context	Context handle from `axlMsgContextStart`. Gets messages only for this context (or any children). An argument of `nil` causes `axlMsgContextGetString` to look through all contexts.

Value Returned

lt_messages	List of the text strings of the buffered messages.
`nil`	No buffered messages found.

Example

See the "Message Handler Example" on page 969.

```
axlMsgContextGetString(context)
⇒ ("My warning" "My error" "My fatal error BAD ERROR")
```


©2023 All Rights Reserved.

axlMsgContextGet

```
axlMsgContextGet(
     r_context
     )
     ⇒ lt_format_strings/nil
```

Description

Gets the format strings of the buffered messages. (*Not* the messages themselves. Compare the example here and the one shown for `axlMsgContextGetString`.*)* Does not remove the messages from the message buffer, rather it simply provides the caller an alternative to making a number of `axlMsgContextInBuf` calls.

Arguments

r_context	Context handle from `axlMsgContextStart`. Gets messages only for this context (or any children). An argument of `nil` causes `axlMsgContextGet` to look through all contexts.

Value Returned

lt_format_strings	List of format strings of the buffered messages.
`nil`	No buffered messages found.

Example

See the "Message Handler Example" on page 969.

```
mylist = axlMsgContextGet(context)
⇒ ("My warning" "My error" "My fatal error %s")
```


©2023 All Rights Reserved.

axlMsgContextTest

```
axlMsgContextTest(
     r_context
     )
     ⇒ x_class
```

Description

Returns the most severe message class of the messages in the context message buffer. See axlMsgContextInBuf on page 975 to check for a particular message class.

Arguments

r_context	Context handle from `axlMsgContextStart`. Looks only for messages for this context. If *r_context* is `nil`, `axlMsgContextTest` looks through all contexts.

Value Returned

x_class	The most severe message class of the messages in the message buffer of the given context.

Example

See the Message Handler Example on page 969.

```
printf("Message severity %d\n" axlMsgContextTest(context))
⇒ Message severity 4
```


©2023 All Rights Reserved.

axlMsgContextInBuf

```
axlMsgContextInBuf(
     r_context
     t_format_string
     )
     ⇒ t
```

Description

Checks whether message *t_format_string* is in the message buffer of context *r_context*. Gives the application the ability to control code flow based on a particular message reported by a called function. The check is based on the original format string, not the fully substituted message.

Arguments

r_context	Context handle from `axlMsgContextStart`. Looks only for messages in this context (or any children). If *r_context* is `nil`, `axlMsgContextInBuf` looks through all contexts.
t_format_string	Format string of the message.

Value Returned

`t`	Specified message is in the buffer.
`nil`	Specified message is not in the buffer.

Example

See the "Message Handler Example" on page 969.

```
if( axlMsgContextInBuf(context "My error")
    printf(%s\n" "My error is there"))
```


©2023 All Rights Reserved.

axlMsgContextRemove

```
axlMsgContextRemove(
     r_context
     t_format_string
     )
     ⇒ t
```

Description

Removes a message (or messages) from the buffered messages. Lets you remove messages (usually warnings) from the buffer that you decide, later in a procedure, that you do not want the user to see.

Arguments

r_context	Context handle from `axlMsgContextStart`. Removes messages for only this context (or any children). If *r_context* is `nil`, `axlMsgContextRemove` looks through all contexts.
t_format_string	Format string of the message. The match for the message in the buffer ignores the substitution parameters used to generate the full text of the message.

Value Returned

`t`	Always returns `t`.

Example

See the "Message Handler Example" on page 969.

```
axlMsgContextRemove(context, "My fatal error %s")
⇒ t
```


©2023 All Rights Reserved.

axlMsgContextStart

```
axlMsgContextStart(
     g_format_string
     [g_arg1 ...]
     )
     ⇒ r_context
```

Description

Indicates the start of a message context. Prints any buffered messages for the context.

Arguments

g_format_string	Context message (`printf` like) message format string.
g_arg1 ...	Values for the substitution arguments for the format string. Use `axlMsgClear` (and `Test/Set`) functions to control code flow if the function returns insufficient values.

Value Returned

r_context	Context handle to use in subsequent `axlMsgContext` calls.

Example

See the "Message Handler Example" on page 969.

```
context = axlMsgContextStart("Messages for %s" "add line")
Messages for add line
5
```


©2023 All Rights Reserved.

axlMsgContextFinish

```
axlMsgContextFinish(
     r_context
     )
     ⇒ t
```

Description

Indicates the finish of a message context. Prints any buffered messages in the context and clears the context buffer.

Arguments

r_context	Context handle from `axlMsgContextStart`.

Value Returned

`t`	Always returns `t`.

Example

See the "Message Handler Example" on page 969.

```
context = axlMsgContextStart()
... do some things ...
axlMsgContextFinish(context)
```


©2023 All Rights Reserved.

axlMsgContextClear

```
axlMsgContextClear(
     r_context
     )
     ⇒ t
```

Description

Clears the buffered messages for a context.

Note: You should not normally use this function. Use functions that print (`axlMsgContextPrint`) or retrieve (`axlMsgContextGetString`) messages and then clear them, or use a context finish (`axlMsgContextFinish`) that forces the messages to be printed.

Arguments

r_context	Context handle from `axlMsgContextStart`. If *r_context* is `nil`, clears all messages in all contexts.

Value Returned

`t`	Always returns `t`.

Example

See the "Message Handler Example" on page 969.

```
context = axlMsgContextStart()
... do some things ...
axlMsgContextClear(context)
```


©2023 All Rights Reserved.

axlMsgCancelPrint

```
axlMsgCancelPrint()
     ⇒ t
```

Description

Prints a message informing the user that he requested *cancel*. Since the severity of this message is *Error* (3), AXL writes it to the context buffer as it does other warning, error, and fatal messages. Call this function only from a routine that requests user input.

Arguments

None

Value Returned

`t`	Always returns `t`.

Example

See the "Message Handler Example" on page 969.

```
axlMsgCancelPrint()
```

Sets severity level to 2 (warning) and puts the following into the message buffer (if `axlMsgSys` messages are in English):

```
User CANCEL received
```


©2023 All Rights Reserved.

axlMsgCancelSeen

```
axlMsgCancelSeen()
     ⇒ t/nil
```

Description

Checks to see if the `axlMsgCancelPrint` message was printed. Does not poll the input stream for a *CANCEL* key. Checks the buffer of current messages for the occurrence of the `axlSsgSys.cancelRequest` message.

Arguments

None

Value Returned

`t`	Requested *cancel* has been seen.
`nil`	No requested *cancel* has been seen.

Example

See the "Message Handler Example" on page 969.

```
if( axlMsgCancelSeen()
    ; clear input and return
    ...
```


©2023 All Rights Reserved.

axlMsgClear

```
axlMsgClear()
     ⇒ t
```

Description

Clears the current error severity level. You can reset the severity by first saving it using `axlMsgTest`, then setting it using `axlMsgSet`.

Arguments

None

Value Returned

`t`	Always returns `t`.

Example

See the "Message Handler Example" on page 969.

```
axlMsgClear()
```


©2023 All Rights Reserved.

axlMsgSet

```
axlMsgSet(
     x_class
     )
     ⇒ t
```

Description

Sets the current error severity level. Use only to reset the severity cleared using `axlMsgClear`.

Arguments

x_class	Severity level.

Value Returned

`t`	Always returns `t`.

Example

See the "Message Handler Example" on page 969.

```
level = axlMsgTest()
; Do something
...
axlMsgSet(level)
```


©2023 All Rights Reserved.

axlMsgTest

```
axlMsgTest()
     ⇒ x_class
```

Description

Determines the current error severity level. Returns a single number giving the severity level of the most severe message that has been printed since the last `axlMsgClear` or `axlMsgContextClear`/`Print`/`GetMsg` call.

Arguments

None.

Value Returned

x_class	Highest severity level of all the messages currently in the message buffer.

Example

See the "Message Handler Example" on page 969.

```
level = axlMsgTest()
⇒ 4
```


©2023 All Rights Reserved.

14

Design Control Functions

AXL-SKILL Design Control Functions

The chapter describes the AXL-SKILL functions you can use to get the name and type of the current design.

©2023 All Rights Reserved.

axlAppendDBDiary

```
axlAppendDBDiary(
     t_entryText
     )
```

⇒ `t/nil`

Description

This function adds a non-empty text string entry to the database diary history of the active design. The login information is taken from the active user of the tool, and the time is taken as the current system time.

Arguments

t_entryText	The text string entry to be added to the database diary.

Value Returned

`t`	The entry was successfully added.
`nil`	Failed to add the entry to the database diary.

Example

This function can be used to record important events of a design. It indicates who made the change and when it happened.

```
axlAppendDBDiary("I did something!")
==> t
```


©2023 All Rights Reserved.

axlCurrentDesign

```
axlCurrentDesign(
     )
     ⇒ t_design
```

Description

Returns the name of the currently active layout. This is the drawing name in the main window's title bar.

Arguments

None.

Value Returned

axlCurrentDesign	Returns the current design name as a string. There is always a current name, even if it is "unnamed" (`unnamed.brd`).

See Also

axlGetDrawingName, axlOpenDesign

Example

```
axlCurrentDesign()⇒ "mem32meg"
```

Gets the name of the currently active layout.

©2023 All Rights Reserved.

axlDesignType

```
axlDesignType(
     g_option
     )
     ⇒ t_type/lt_type
```

Description

Returns the type of design as a string.

Arguments

g_option Possible values are:

nil Return design type domain.

Examples are:

LAYOUT for .brd or .mcm

SYMBOL for .dra

t fully qualified design type. Examples are:

For layout: "board", "mcm", "mdd" (module)

For symbol: "package", "mechanical", "format" "shape" or "flash"

- 'domain — return universe of domains (strings may be repeated). This is all possible values that nil may return.
- 'members — return list of fundamental design types.
- 'symbols — return list of symbol types. If a "SYMBOL" this is sub-type of the dra.

The combination of 'members and 'symbols is the universe of the 't' option.

©2023 All Rights Reserved.

Value Returned

t_type	string describing design type.
lt_type	list of strings in a universe.

See Also

axlIsSymbolEditor

Example

- Gets the high-level design type of the current active layout.

```
axlDesignType(nil)
⇒ "LAYOUT"
```

- Gets the detailed design type.

```
axlDesignType(t)
⇒ "BOARD"
```


©2023 All Rights Reserved.

axlCompileSymbol

```
axlCompileSymbol(
     ?symbol t_name
     ?type t_type
     )
     ⇒ t_symbolName/nil
```

Description

Compiles and edit checks the current (symbol) design and saves the compiled version on disk under the name *t_name*. If *t_name* is not provided, then *t_name* is the current drawing name. If *t_name* is provided as `nil`, you are prompted for the name. Uses the symbol type in determining some of the edit checks.

Arguments

t_name	Name of the compiled symbol.
t_type	Type of symbol, the default is the current symbol type (see axlDesignType).

Value Returned

t_symbolName	Name of the symbol.
`nil`	Error due to incorrect arguments.

Note: This function is only available in the symbol editor. This is a SKILL interface to the Allegro PCB Editor *"create symbol"* command and thus has the same behavior.

©2023 All Rights Reserved.

axlSetSymbolType

```
axlSetSymbolType(
     t_symbolType
     )
     ⇒ t_symbolType/nil
```

Description

Sets the Allegro PCB Editor symbol type. Has some minor effect on the commands available and the edit checks performed when the symbol is “compiled” (axlCompileSymbol).

Use axlDesignType to determine current symbol type.

Arguments

t_symbolType	`"package"`, `"mechanical"`, `"format"`, `"shape"` or `"flash"`

Value Returned

t_symbolType	Symbol exists.
`nil`	Error due to incorrect argument.

Note: This function is only available in the symbol editor. This is a SKILL interface into the change symbol type in the Drawing Parameters dialog box in *allegro_symbol*.

See Also

axlCompileSymbol, axlDesignType

©2023 All Rights Reserved.

axlDBControl

```
axlDBControl(
     s_name
     [g_value]
     )
     g_currentValue/ls_names
```

Description

Inquires and/or sets the value of a special database control. If the setting is a value, the return is the old value of the control.

A side effect of most of these controls is that, if an active dialog box displays the current setting, the setting may not be updated. Additional side effects of individual controls are listed.

Note: Several display options have been moved to axlDBDisplayControl but for backward compatibility are still supported using this interface.

Items currently supported for *s_name* include the following:

Name: *busRats*
Value: `t` or `nil`
Set?: Yes
Description: Queries and changes the bus rats option
Equivalent: Prmed Display group
Side Effects: If changing should do ratsnestDistance first
Symphony Supported: Yes

Name: *drcEnable*
Value: `t` or `nil`
Set?: Yes
Description: Enables or Disables DRC/CBD system.
Equivalent: Same as status dialog box DRC on/off buttons.
Side Effects: Does not perform batch DRC.
Symphony Supported: Yes

Name: fixedPattern
Value: `nil` (disabled), `1` max pattern index (enabled)
Set?: Yes
Description: Sets the pattern index for fixed objects.
Equivalent: Same as color192 form Display tab fixed pattern field.
Side Effects: Display updates.
Symphony Supported: Yes

©2023 All Rights Reserved.

Name: *ratnestDistance*
Value: `t` or `nil`
Set?: Yes
Description: Accesses the ratsnest display mode.

`t` - pin to pin

`nil` - closest dangling net cline/via

Equivalent: Same as status dialog box Ratsnest Dist control.
Side Effects: Will recalculate the display when this is changed.
Symphony Supported: Yes

Name: *activeTextBlock*
Value: `1` to *maxTextBlock*
Set?: Yes
Description: Accesses the active text block number.
Equivalent: Same as status dialog box text block.
Side Effects: None
Symphony Supported: Yes

Name: *maxTextBlock*
Value: 16 to 64
Set?: No
Description: Reports the maximum text block number.
Equivalent: None
Side Effects: None
Symphony Supported: Yes

Name: *activeLayer*
Value: <*class*> / <*subclass*>
Set?: Yes
Description: Accesses the current class/subclass. To obtain subclass do

```
cadr(parseString(axlDBControl('activeLayer "/")) )
```

Equivalent: Same as ministatus display.
Side Effects: None
Symphony Supported: Yes

Name: *activeAltLayer*
Value: *<subclass>*
Set?: Yes
Description: Accesses the current alternative etch layer
Equivalent: Same as ministatus display when in add connect.
Side Effects: None
Symphony Supported: Yes

©2023 All Rights Reserved.

Name: *defaultSymbolHeight*
Value: float
Set?: Yes
Description: Sets the default symbol height in the database.
Equivalent: Prmed from DRC Symbol Height.
Side Effects: Will set DRC out of date, and does not update status dialog box if it is present.
Symphony Supported: No

Name: *editingTime*
Value: int
Set?: Reset
Description: Reports editing time of design in minutes.
Equivalent: status from
Side Effects: Can reset time by passing `g_value == t`
Symphony Supported: Yes

Name: *symbolRotation*
Value: float
Set?: Yes
Description: Sets the initial symbol rotation
Equivalent: Prmed form's symbol angle
Side Effects: None
Symphony Supported: No

Name: *symbolMirror*
Value: `t`/`nil`
Set?: Yes
Description: Sets the initial symbol mirror.
Equivalent: Prmed form's Symbol mirror.
Side Effects: None
Symphony Supported: No

Name: *schematicBrand*
Value: none, concepthdl, capture
Set?: Yes
Description: Queries current database schematic branding. You can set the branding only to 'none via SKILL.
Equivalent: See netin in the Allegro PCB Editor dialog.
Side Effects: None.
Symphony Supported: No

Name: *cmgrEnabledFlow*
Value: `t` or `nil`
Set?: Yes (only if flag is set)

©2023 All Rights Reserved.

Description: Reports if board is in constraint manager enabled flow. Only valid in HDL Concept Flow.`t` - Cadence schematic Constraint Manager flow enabled (5 .pst files required) `nil` - traditional Cadence schematic flow (3 .pst files)
Equivalent: Import Logic Branding shows “Constraint Manager Enabled Flow”
Side Effects: It is not advisable to clear this flag. This interface is provided for those customers who enabled the flow and want to restore the traditional flow. You need to do additional work on the schematic side to clear the option.
Symphony Supported: No

Name: *`cdszFile`*
Value: *`t`* or *`nil`*
Set?: *`t`* or *`nil`*
Description: Reports if a single `.cdsz` file was used by netrev instead of multiple `.pst` files. If *`t`*, then `genfeed` format will output a `.cdsz` file.
Symphony Supported: No

Name: *`schematicDir`*
Value: directory path
Set?: Yes
Description: Queries/changes the Cadence schematic directory path. This is the directory location for the Cadence `pst` files. This does not support 3rd party netlist location. If database is unbranded (see above), then the directory location is not stored. Existence of location is not verified.
Equivalent: Import Logic Branding Cadence Tab
Side Effects: none
Symphony Supported: No

Name: *`testPointFixed`*
Value: `t` or `nil`
Set?: Yes
Description: Sets global flag to lock test points. `t` - test points fixed `nil` - test points not fixed
Equivalent: Same as testprep param `"Fixed test points"`
Side Effects: None
Symphony Supported: No

Name: *`ecsetApplyRipupEtch`*
Value: `t` or `nil`
Set?: Yes
Description: If enabled, and the schedule is anything other than min tree, ripup any etch that disagrees with the schedule. Etch may be ripped up when a refdes is renamed due to this option. Only applicable with "expert" level tools. Applies setting at system level to all open designs.

©2023 All Rights Reserved.

`t` - ripup etch
`nil` - preserve etch

Equivalent: Same as Constraint Manager *Tools — Options — "Rip up etch..."*
Side Effects: None
Symphony Supported: No

Name: *`maxEtchLayers`*
Value: number
Set?: No
Description: Returns maximum number of etch subclasses.
Equivalent: none
Side Effects: none
Symphony Supported: Yes

Name: *`dynamicFillMode`*
Value: `'wysiwyg, 'rough`, `nil` (Disabled) (must be a symbol not a string)
Set?: Yes
Description: Controls filling of dynamic shapes.
Equivalent: shape global param
Side Effects: Disabled in symbol editor.
Symphony Supported: No

Name: *`maxNameLength`*
Value: number
Set?: Yes
Description: Sets maximum name length. Minimum is 31 and maximum is 255. For designs, you cannot set it lower then the current length. For new designs, the initial value is set by the value in the env variable *`allegro_long_name_size`*.
Equiv: Design Parameter Editor, Long Name Size
Symphony Supported: No

Name: *`dynamicFilletsOn`*
Value: t nil
Set?: Yes
Description: Controls filling of dynamic shapes
Equiv: Gloss param fillet - dynamic fillets option
Side Effects: Disabled in symbol editor and lower level PCB tools. When enabled will update design with fillets.
Symphony Supported: No

Name: *`newFlashMode`*
Value: t/nil
Set?: Yes

©2023 All Rights Reserved.

Description: Returns if board is running old style (nil) or new style (t) flash mode (WYSIWYG negative artwork using fsm files) Note WYSIWYG is now Smooth in the display.
Equiv: none
Side Effects: If you change the mode to t without updating flash symbols, wrong artwork may occur. You should only change the mode at design creation time before any padstacks with flashes are loaded into the design.
Symphony Supported: No

Name: *maxAttachmentSize*
Value: integer value in bytes
Set?: No
Description: Returns the largest attachment size (`axlCreateAttachment`) that may attach to the database.
Equivalent: None.
Side Effects: None.
Symphony Supported: Yes

Name: *dbSize*
Value: int
Set?: No
Description: returns current database size (memory footprint)
Equiv:none
Side Effects: none
Symphony Supported: Yes

Name: *retainElecCnsOnNets*
Value: t or nil
Set?: Yes
Description: Queries and changes the retain electrical constraints on nets
Equiv: netrev based option
Side Effects: This should only be set on new designs. With populated designs existing Electrical constraints will remain at xnet level. Setting the option will not promote existing settings to the xnet.
Symphony Supported: No

Name: *mirrorUserMask*
Value: t or nil
Set?: t or nil
Description: Most designs with padstack user mask layers offer Allegro mirror capability (layers with suffix _TOP will mirror to layer suffix _BOTTOM and vice versa). When padstack user mask layers was introduced in 16.2, they did not offer this capability. New designs will offer this capability but designs containing user mask layers that were created in 16.2 or 16.3 will have this mirror option disabled. a cdsz file.
Symphony Supported: No

©2023 All Rights Reserved.

Name: *xnetState*
Value: dml, gates, or off
Set?: No
Description: Queries current database xnet state
Equiv: none
Side Effects: none
Symphony Supported: Yes

Tip

The first argument is a symbol (`'drcEnable`) and not a string ("`drcEnable`"). See axlBackdrillGet to get backdrill status.

Arguments

s_name	Symbol name of control. `nil` returns all possible names.
g_value	Optional symbol value to set. Usually a `t` or a `nil`.

Value Returned

See above.

ls_names	If name is `nil`, then returns a list of all controls.

Example

- Sets DRC system off

```
old = axlDBControl('drcEnable, nil)
```

- Gets current value of pin-2-pin ratsnest

```
current = axlDBControl('ratsnestDistance)
```

- Gets all names supported by this interface

```
listOfNames = axlDBControl(nil)
```

- Set dynamic shape mode to smooth

```
old = axloDBControl('dynamicFillMode, 'wysiwyg)
```

See Also

axlDBDisplayControl

©2023 All Rights Reserved.

axlDBGetExtents

```
axlDBGetExtents(o_dbid
     g_visibleOnly
     )
     ==> bBox/nil
```

Description

Provides the extents of a physical database object. You choose between getting the extents of the entire object (even if it is currently not visible) or just the current visible objects.

With the visible option the extents may be smaller then the `bBox` attribute of the element `dbid bBox`.

If a list of `dbids` is provided, the union of the extents is returned.

Unsupported dbids are ignored. Dbids that contribute to the extent are SEGMENT, CLINE, LINE, RECTANGLE, FRECTANGLE, FIGURE, TEXT, SHAPE, VOID, VIA, PIN, and SYMBOL_INSTANCE.

Arguments

o_dbid	`dbid` of an element.
lo_dbid	list of `dbids`
visible_only	`t` return the extents of visible parts of the element.
	`nil` return the extents of the entire element.

Value Returned

bBox	The extents of the element. This might be zero extents, if the object has no extents visible or does not have extents (for example, nets).
`nil`	Error; bad arguments

©2023 All Rights Reserved.

axlDBIgnoreFixed

```
axlDBIgnoreFixed(
     [g_ignore]
     ) -> t/nil
```

Description

Provides similar functionality to that offered by many Allegro batch programs which allow FIXED and LOCKED properties to be ignored (for example: `netrev -z`).

If `g_ignore` is `t`, FIXED testing is ignored; `nil` restores FIXED testing. No argument reports the current state of FIXED testing.

This does not disable READ-ONLY states. A parent can be locked, which means the children cannot be modified (symbols locked to prevent editing of its components). READ-ONLY objects are typically seen when you are in the partition editor.

Caution

It is important that FIXED property testing be restored. Allegro automatically restores FIXED testing if your SKILL program returns to Allegro. This includes calling `axlShell`***.***

Note: Recommend using axlDBCloak since that API catches any SKILL errors and restores the mode.

Arguments

`g_ignore`	If `t`, turn off FIXED testing; `nil` restore.
no argument	Return current state of FIXED testing.

Value Returned

old fixed (`nil` FIXED is enable, `t` is enabled)

See Also

axlDBIsFixed, axlDBCloak

©2023 All Rights Reserved.

Examples

; Select an object

```
p = ashOne()
```

; Add fixed property

```
axlDBAddProp(p, '("FIXED" t))
```

; Attempt to delete it

```
axlDeleteObject(p)
```

; now delete it

```
axlDBIgnoreFixed(t)
axlDeleteObject(p)
axlDBIgnoreFixed(nil)
```


©2023 All Rights Reserved.

axlDBIsReadOnly

```
axlDBIsReadOnly(
     o_dbid
     ) -> t/nil
```

Description

This API command checks if indicated database object is read-only.

An example of why an object is marked read-only due to a partition being active.

Arguments

o_dbid	dbid of the element to be checked.

Value Returned

- `t` – object is read-only
- `nil`– not read-only or not a dbid

See Also

axlDBIsFixed

Example

```
p = axlSelectByname("SYMBOL" "U1")
ret = axlDBIsReadOnly(p)
```


©2023 All Rights Reserved.

axlDBSectorSize - Obsolete

This is obsolete. It is kept for backwards compatibility. It now calls axlDBTuneSectorSize. Tuning sectors is now built into dbdoctor.

©2023 All Rights Reserved.

axlGetDrawingName

```
axlGetDrawingName(
     )
     ⇒ t_drawingPathName
```

Description

Retrieves the full path of the drawing.

Arguments

None

Value Returned

t_drawingPathName Full path of the drawing.

See Also

axlCurrentDesign

Example

```
axlGetDrawingName() => "/net/nile/home/neeti/testboards/test1.brd"
```


©2023 All Rights Reserved.

axlIgnoreFixed

See `axlDBIgnoreFixed`.

©2023 All Rights Reserved.

axlInTrigger

```
axlInTrigger(
     ) ==> t/nil
```

Description

Tests if the application or the utility in a axlTrigger callback. Returns `t` if currently in a trigger call. This function is only required in rare cases when you might have a utility that you want to run differently if called as part of a axlTrigger callback.

Arguments

None

Value Returned

`t` if in a trigger callback, `nil` otherwise

See Also

axlTriggerSet, axlInTriggerFunc

©2023 All Rights Reserved.

axlInTriggerFunc

```
axlInTriggerFunc() -> s_triggerFunc/nil
```

Description

If in a trigger callback, reports trigger function symbol. `nil`, if not in a trigger callback.

Arguments

No argument required

Value Returned

`s_triggerFunc`	Current function name if in a trigger or `nil` if not in a trigger

See Also

axlTriggerSet, axlInTrigger

©2023 All Rights Reserved.

axlIsSymbolEditor

```
axlIsSymbolEditor() -> t/nil
```

Description

Returns `t` if in symbol editor, `nil` for all other editors.

When loading custom menus you might want to differentiate between the symbol editor and design editor.

Arguments

None.

Value Returned

Returns `t` if symbol editor.

See Also

axlDesignType

Example

```
axlIsSymbolEditor()
```


©2023 All Rights Reserved.

axlKillDesign

```
axlKillDesign()
     ⇒ t/nil
```

Description

Same as (`axlOpenDesign <unnamed> "wf"`), where <*unnamed*> is the standard Allegro PCB Editor name provided for an unnamed design. If the specific name is important, you can determine it using the axlCurrentDesign command.

Arguments

None

Value Returned

`t`	New design opened, replacing current design.
`nil`	No new design opened.

Note

This will void all *`axl dbid`* handles and clear the selection set.

See Also

`axlOpenDesign`

©2023 All Rights Reserved.

axlOpenDesign

```
axlOpenDesign(
     ?design t_design
     ?mode t_mode
     ?noMru g_noMru
     ?ignoreLock g_noMru
     )
     ⇒ t_design/nil
```

Description

Opens a design. The new design replaces the current design. If the current design has unsaved edits, confirmation is needed for discarding the edits, unless the current design was opened in "`r`" mode (not supported in this release) or *`t_mode`* is "`wf" or "nf"`. If cancelled, the function returns `nil` and the current design is left remains open.

If *`t_mode`* is "`n`", opens a new design and specify the name and location on disk for that design without having it read any existing design of that name at that location.

Caution

Warning: Any existing design of that name at that location will be overwritten when the design is saved.

If *`t_design`* is not provided, you are prompted for the name of the design to open.

If *`t_design`* is provided but does not exist on disk, the standard Allegro PCB Editor Drawing Parameters form opens.

The designType of the new design is set as the same as the current design. It can be changed using axlSetDesignType.

©2023 All Rights Reserved.

Arguments

t_design	The name of the new design to edit
t_mode	Can be any one of "w", "wf", or "n". Add "l" to disable Allegro file locking. The "w" mode opens a design in the write mode, "wf" in the forced write mode, and "wl" in no lock mode.
g_noMru	If set to t, the design is not included in the most recently used file list. (Default is to update.)
ignoreLock	If set to t, design lock file is ignored if present. The is not recommended by Cadence.

Value Returned

t_design	If design opens
nil	If error.

Note: This function is similar to the Allegro PCB Editor open command, except that the *t_mode* can be set to "wf" in order to discard the current edits without confirmation. However, when *t_mode* is 'n', it behaves the same as the Allegro PCB Editor new command.

Since confirmation uses the standard Allegro PCB Editor confirmer, using the "wf" mode is essentially the same as setting the NOCONFIRM environment variable.

This will void all axl dbid handles and clear the selection set.

See Also

axlCurrentDesign, axlKillDesign, axlRenameDesign, axlSaveDesign, axlSetSymbolType, axlRunBatchDBProgram, axlSaveEnable, axlCompileSymbol

©2023 All Rights Reserved.

axlOpenDesignForBatch

```
axlOpenDesignForBatch(
     t_design
     t_mode
     )==> t_design/nil
```

Description

Opens a design. The new design replaces the current design. Since this is for batch usage, commands and menus are not changed. If the current design has unsaved edits, then you are asked to confirm the discard unless the current design was opened in `"r"` mode (not supported in this release) or `g_mode` is `"wf"`. If you cancel the confirmer, then the function returns `nil` and the current design is left open.

If `t_design` is not provided, then you are prompted for the name of the design to open.

If `t_design` does not exist on the disk, then the standard Allegro Drawing Parameters form appears.

The `designType` of the new design is set the same as the current design. It can be changed using `axlSetDesignType`.

Arguments

`t_design`	The name of the new design to edit
`g_mode`	`"w"` or `"wf"` (see above) add a "l" to disable Allegro file locking example: "wl" for no locking

Value Returned

`t_design` if opened, or `nil` if error

Note: This command functions the same as the Allegro `edit` command, except that the `t_mode` can be set to `"wf"` in order to discard the current edits without confirmation. Since confirmation uses the standard Allegro confirmer, the `"wf"` mode is the same as setting the `NOCONFIRM` environment variable.

This removes all axl dbid handles and clears the selection set.

©2023 All Rights Reserved.

Example

Open `u.dra` in current directory with noconfirm option

```
axlOpenDesignForBatch("u.dra"  "wf")
```


©2023 All Rights Reserved.

axlRenameDesign

```
axlRenameDesign(
     t_design
     )
     ⇒ t_design/nil
```

Description

Changes the current design name. Has no effect on the existing disk version of the current design. The new current design name will be displayed in the window border and becomes the default name for `axlSaveDesign`.

Arguments

t_design	New current design name (without file extension).

Value Returned

t_design	New current design name.
`nil`	Error due to incorrect argument.

See Also

axlOpenDesign

Examples

```
axlRenameDesign("foobar")
```


©2023 All Rights Reserved.

axlSaveDesign

```
axlSaveDesign(
     ?design t_design
     ?mode t_option
     ?noMru g_noMru
     ?noConfirm g_noConfirm
     ?writeModel g_write
     )
     ⇒ t_design/nil
```

Description

Saves the design with the name specified (*t_design*). If *t_design* is not specified, the current design name is used. If *t_design* is provided but the value is `nil`, you are prompted for the name. If *t_option* is `"nocheck"`, the database “quick check” is not provided. Use this option only when there is a very compelling reason.

NOTES

- This is essentially the Allegro "save" command.
- This will clear all axl dbid handles and the selection set.
- Use axlRunBatchDBProgram, if the intent is to save the design to run another program.

©2023 All Rights Reserved.

Arguments

t_design	Name for the saved design.
t_option	"nocheck" - No database check performed.
g_noMru	If t does not update the Most Recently Used file list. (Default is to update.)
g_noConfirm	If t does not present a confirmer if overwriting an existing design. File is overwritten.
g_write	If t uses allegro write file model. This means file is written to disk with provided name but current drawing name is not updated.

Value Returned

t_design	Name for the saved design.
nil	Error due to incorrect argument(s).

Note: Essentially the Allegro PCB Editor *save* command. The current design name is not changed. Use axlRenameDesign to change the current design name.

This will void all axl dbid handles and clear the selection set.

See Also

axlOpenDesign, axlRenameDesign, axlRunBatchDBProgram

©2023 All Rights Reserved.

axlSaveEnable

```
axlSaveEnable(
     [g_saveEnable]
     ) -> t/nil
```

Description

This queries or sets the design to save design. When `t`, the *File – Save design* menu command is enabled. If `nil`, it is disabled.

If no arguments are provided, then returns the current status. If `g_saveEnable` is `t`, then enables save menu (reset of next database save). If `g_saveEnable` is `nil`, disables the save menu.

It is not recommended that you unset the save enable.

Arguments

`g_saveEnable` `t`

If not provided, just does query.

Value Returned

Returns current save setting if query and previous setting if changing the value.

See Also

axlSaveDesign

Examples

1) Query state of save

```
state = axlSaveEnable()
```

2) Set state of save to `t` (enable save menu)

```
oldState = axlSaveEnable(t)
```


©2023 All Rights Reserved.

axlDBChangeDesignExtents

```
axlDBChangeDesignExtents(
     l_bBox
     )
     ⇒ t/nil
```

Description

Changes design extents. This may fail if an object falls outside the new extents or if the extents exceed the database range.

Arguments

l_bBox	New design extents.

Value Returned

t	Size changed.
nil	Failed to change size.

Note: This function may take extra time on large designs.

Example 1

```
extents = axlExtentDB('obstacle)
axlDBChangeDesignExtents(extents)
```

Reduces the database to its smaller extent.

Example 2

```
extents = axlExtentDB('obstacle)
extents = bBoxAdd(extents '((-100 -100) (100 100))
axlDBChangeDesignExtents(extents)
```

To reduces the database to its minimum size plus 100 mils all around.

©2023 All Rights Reserved.

axlDBChangeDesignOrigin

```
axlDBChangeDesignOrigin(
     l_point
     )
     ⇒ t/nil
```

Description

Changes the origin of the design. This may fail if the new design origin falls outside the maximum integer range.

This is an offset. A negative number moves the database left or down and a positive number moves the database to the right or up.

Note: This may take extra time on large designs.

Arguments

l_point	*X/Y* offset.

Value Returned

t	Changed the origin of the design.
nil	Failed to change the origin of the design due to an incorrect argument.

Example

```
axlDBChangeDesignOrigin(900:900)
```

Moves the origin.

©2023 All Rights Reserved.

axlDBChangeDesignUnits

```
axlDBChangeDesignUnits(
     t_units/nil
     x_accuracy/nil
     [x_dbuperuu/nil]
     x_drcCount/nil
     )
     ⇒ x_drcCount/nil
```

Description

Changes the units, accuracy,or dbuperuu of the design. Either accuracy or dbuperuu can be set. Both cannot be set at the same time.To maintain the current design value, use `nil` for *`t_units`* or *`x_accuracy`*.

When you change units, also change accuracy to maintain adequate precision within the database. Reference the following table to determine the appropriate accuracy.

Units	Min Accuracy	Max Accuracy	Delta
`mils`	0	4	0 (more then 2 not advised due Gerber)
`inches`	2	4	3
`microns`	0	4	0
`millimeters`	1	4	3
`centimeters`	2	4	4

- Decreasing accuracy is not recommended.
- Switching units between Metric and English is not recommended due to inevitable rounding issues.
- Use the new `DELTA` to decide what the accuracy should be when changing units.

  ```
  new acc = orig acc + (new delta - old delta)
  ```

  This example shows mils to millimeters with a current accuracy of 1.

  ```
  new acc = orig acc+ (millim delta- mils delta)
      4   = 1     +   3       -   0
  ```


©2023 All Rights Reserved.

- When changing from one English unit to another or from one Metric unit to another, the default accuracy must match that of the previous unit. For example, if your design uses `MILS` 0 and you change to `INCHES`, the accuracy must be set to 3.
- If you change from an English unit to a Metric unit or from a Metric unit to an English unit, then the accuracy must be set to a number that is at least as accurate as the current database. For example, if the design is in `MILS` 0 and you change to `MILLIMETERS`, then the accuracy must be set to 2. Then if you change to `INCHES`, the accuracy must be set to 3 (inches and 3 = mils and 0.)
- If the accuracy needed is not allowed due to a limitation on the number of decimal places allowed for a particular unit, or if you reduce the level of accuracy, the error message, "`E-Accuracy will be decreased, database round-offs may occur`," displays. For example, if your design is in `MICRONS` and an accuracy of 1 and you change to `CENTIMETERS`, you get an error since `CENTIMETERS` are not allowed with an accuracy of 5.

DBUperUU Notes

- Only use DBUperUU to match another design tool, which supports DBUperUU (such as Virtuoso, designs coming from OA, and so on).
- When changing units, you should change either accuracy or DBUperUU to maintain adequate precision within the database.
- The value of DBUperUU chosen will dictate the internal accuracy.

Examples

DBUperUU	Accuracy
200	3
2000	4
4000	5

- Legal values for dbuperuu are: `160, 200, 400, 800, 1600, 2000, 4000, 8000`

©2023 All Rights Reserved.

Arguments

t_units	`Mils, inches, millimeters, centimeters, or microns.`
x_accuracy	Range is 0 to 4, according to the table shown.
x_dbuperuu	`160, 200, 400, 800, 1600, 2000, 4000, 8000`

Value Returned

x_drcCount	DRC count
`nil`	Failed to change design units
`nil nil nil`	String of legal dbuperuu values

Notes:

- This function may take extra time on large designs.
- This function reruns DRC if enabled.

Example 1

```
axlDBChangeDesignUnits("millimeters" 4)
```

Changes a design from mils/0 to millimeter/4 (accuracy maintains database precision).

Example 2

```
axlDBChangeDesignUnits(nil 2)
```

Increases accuracy from 0 to 2 and keeps the same units.

Example 3

```
axlDBChangeDesignUnits(nil nil 4000)
```

Set dbuperuu 4000 to match Virtuoso and keep the same units.

©2023 All Rights Reserved.

axlDBCheck

```
axlDBCheck(
     g_option/lg_options
     [p_file]
     )
     ⇒ (x_errors x_warnings)/nil
```

Description

Runs DBDoctor on the active drawing with the specified options. This function is equivalent to running the same checks with the `dbdoctor` command from the operating system command line.

By default, no log file is produced. You can specify the `'log` option which writes the standard `dbdoctor.log` file. A port descriptor can be the second argument to write the `dbdoctor` output to an external file.

Note: axlDBCheck function works best for the large designs as it has fewer capabilities. Use axlRunBatchDBProgram instead to call `dbdoctor` batch program.

Arguments

g_option/lg_options

Option	Function
`'checkOnly`	Runs the specified checks. Does not correct errors.
`'general`	Performs a full database check.
`'xnets`	Regenerate XNets
`'shapes`	Checks shapes (autovoid) ■ May be slow for complicated shapes. ■ Normally fast. ■ Slow on large databases.
`'attributes`	Checks all the attribute-owner relationships
`'noDynShapes`	Inactivates dynamic shape updating. This option does not update out-of-date dynamic shapes. It prevents dynamic shapes from updating due to other database fixes.
`'sectorTune`	Forces sector map to be retuned.

©2023 All Rights Reserved.

Option	Function
`'all`	Performs a full check and fix. Does not perform a shape check.
`'drc`	Performs a batch DRC.
`'log`	Uses the standard `dbdoctor.log` file for output.
`p_file`	Specifies an optional port to write the log data.

Value Returned

`(x_errors x_warnings)`	List containing the number of errors and the number of warnings found.

Notes

This function is the same as running the `dbdoctor` command from the operating system command line. This function is more efficient than running the `dbdoctor` command, as it removes the need to save the drawing, load it in DBDoctor, and reload the modified database when complete. This function also clears the undo history in the layout editor.

Examples

```
;// This function:
    res = axlDBCheck('all)
    printf("errors = %d; warnings = %d", car(res), cadr(res));

    ;// Equivalent command-line flow:
    ;// For full list of arguments, run dbdoctor -help from the command line.
   axlRunBatchDBProgram("dbdoctor", "dbdoctor <options> %s" ?logfile "mydbdoctor"
?reloadDB t)
```


©2023 All Rights Reserved.

axlDBCopyPadstack

```
axlDBCopyPadstack(
     o_dbid/t_padstackName
     lt_startEnd
     [g_dontTrim]
     )
     ⇒ o_dbid/nil
```

Description

Creates a new padstack by copying an existing padstack, with optional removal of layers. The name for the new padstack automatically derives from the existing name by adding a unique post fix. The padstack is marked in the design as derived from its starting padstack.

Start/end must be provided and must be legal ETCH layers.

Caution

If the padstack is not used, it is deleted by the next dbdoctor run.

Arguments

o_dbid	*dbid* of the padstack to copy from.
t_padstackName	Name of the padstack to copy from.
lt_startEnd	List of start (*class*/*subclass*) and stop (*class*/*subclass*) layers.If class is used, it must be ETCH (PCB) or CONDUCTOR (APD+)
g_dontTrim	Obsolete, ignored.

Value Returned

dbid	*dbid* of the new padstack.
nil	Failed to create new padstack.

©2023 All Rights Reserved.

Example

1) To derive an exact copy:

```
newPadId = axlDBCopyPadstack(padId, '("ETCH/TOP" "ETCH/BOTTOM"))
```

2) To derive and trim to only connect from top layer to 2

```
newPadId = axlDBCopyPadstack(padId, '("TOP" "2") nil)
```

or

```
newPadId = axlDBCopyPadstack("VIA", '("TOP" "GND") nil)
```


©2023 All Rights Reserved.

axlDBDelLock

```
axlDBDellLock(
     [t_password]
     )
     ⇒ t/nil
```

Description

Deletes a lock on the database. If the database is locked with a password, you must supply the correct password to unlock it.

View locks cannot be unlocked.

Arguments

t_password	Optional password string. String length should be 6 to 20 characters. Period (.), space, forward slash (\) and some character patterns are not legal.

Value Returned

`t`	Lock is removed or there is no lock to remove.
`nil`	Failed to remove lock due to an incorrect password.

See Also

axlDBSetLock, axlDBGetLock

Example

- Delete lock with no password.

  ```
  axlDBDelLock()
  ```

- Delete lock with the password, "foobar".

  ```
  axlDBDelLock("foobar")
  ```


©2023 All Rights Reserved.

axlDBGetLock

```
axlDBGetLock()
    ⇒ nil/l_info
```

Description

Returns information about a lock on the database. You retrieve the following information:

t_userName	User login who locked the database (auto-generated)
t_lockDate	Date the database was locked (auto-generated)
t_systemName	System on which the database was locked (auto-generated)
t_locklevel	Level of the lock: view, export or write
t_expiration	Expiration duration associated with the lock from the lock date
t_comments	Comments set by user who locked database
g_useNtp	`t` if using a NTP for timer, `nil` uses system time
t_ntpServer	NTP server name or null

You can also determine whether or not a database is locked as this function returns `nil` when the database is unlocked, and returns a list of information when the database is locked.

Arguments

none

Value Returned

`nil`	Database is unlocked.
l_info	List (`t_userName` `t_lockDate` `t_systemName` `t_locklevel` `t_expiration` `t_comments` `g_useNtp` `t_ntpServer`)
	Database is locked.

See Also

axlDBSetLock, axlDBDelLock

©2023 All Rights Reserved.

axlDBMemoryReclaim

```
axlDBMemoryReclaim( )
     -> x_sizeReclaimed
```

Description

Reclaims database memory for reuse by the Allegro database. Normally in SKILL memory of deleted database objects is not reused until SKILL code returns to the main processing loop.

Should only be used in special cases since the default programming model works for most all SKILL programs. For a well written SKILL program this is typically not required.

Before utilizing this API, first try the following techniques:

- use axlDBCloak if are adding/deleting objects that are etch based (vias, clines, etch shapes, pings (for example, like moving a symbol).
- insure that you do not have any long running db transactions (axlDBTransactionStart). For example, commit all transactions you have active.Transactions can be nested so you should commit all the way to the initial transaction.

The one known programming model that uses this API is the "try-it" model. This is where a program adds an object to the database, performs a test and then deletes it (for example, utilizes axlAirGap to get distances to other db objects).

For the API to be most effective make sure:

- Are not inside an axlDBCloak.
- The most memory can be reclaimed if you have no active db transactions.

Memory reclaimed is returned to the database for reuse. It is not be returned to the program's memory pool nor returned to the OS. The program’s memory usage at the OS level is NOT reduced.

As a side effect some of the dbids that are checked-out may be reclaimed since they actually link to deleted db objects. They are reported as "dbid:remove".

Note: Do NOT use instead axl trigger callbacks.

Arguments

none

©2023 All Rights Reserved.

Value Returned

Amount of memory reclaimed (bytes).

See Also

axlDBCloak, axlDBTransactionStart

©2023 All Rights Reserved.

axlDBSetLock

```
axlDBSetLock(
     ['password t_password]
     ['locklevel            t_locklevel]
     ['expiration           t_expiration/x_expiration]
     ['comments t_comments]
     ['useNtp               t/nil]
     ['ntpServer            t_server]
     )
     ⇒ t/nil
```

Description

Provides a mechanism to lock the database against future changes. If you lock the database it is locked in memory, to save the lock, you need to save the database to disk. Therefore, after locking the database, you can save the database once before all further attempts to save the database are rejected.

When a user opens a locked database, a warning, indicating that the database is locked, is thrown. An attempt to save the database fails with the above exception of above and uprev (see following text).

Arguments

`password`

If provided, this must be provided to unlock the database. If you forget the password you will not be able to unlock the database.

- Password must be greater then 5 or less then 20.
- Following characters are not allowed in the password.
  - \ whitespace
  - leading dash (-)

`locklevel`

Three levels of locking are provided with the lock — view, export, and write. If user does not provide any locklevel, or provides the wrong argument, or provides it without any password, default level of write would be used.

`expiration`

With the lock, user can set the expiration duration for the design. The arguments passed must in number of days with a minimum of 1. If wrong expiration is provided, then default (no duration limit) is used.

©2023 All Rights Reserved.

`comments`	Free form comments. You may embed carriage returns ("\r") in the string to force a new-line in the locking user interface.
`useNtp`	Use NTP server to verify time when a expiration value is provided
`ntpServer`	NTP Server to use for verify an expiration lock. If not provided uses NTPSERVER environment variable which defaults to `0.pool.ntp.org`.

Caution

If using NPT based expiration locks then you must ensure that the user opening the design can access the NTP server specified. Frequently, firewalls block the NTP serve/port. The port is 123 UDP.

Note: Upreving the database from to a new version ignores the lock flag. For a simple lock provide no arguments. If a nil is provided, it returns list of options to this function.

Value Returned

`t`	Locked database.
`nil`	Failed to lock database due to argument errors or database already locked

Examples

- Most basic lock (no password, no locklevel, no expiration, no comments)

```
axlDBSetLock()
```

- Lock with comments and disable data export

```
axlDBSetLock('password "passwd" 'locklevel "view" 'expiration 6 'comments
"Test")
axlSaveDesign(?design "locked_data")
printf("Locked info %L\n" axlDBGetLock())
```


©2023 All Rights Reserved.

See Also

axlDBGetLock, axlDBDelLock, axlSaveDesign

©2023 All Rights Reserved.

axlDBTuneSectorSize

```
axlDBTuneSectorSize( )
     ==> nil/l_result
```

Description

This tune's Allegro's sector size for better performance. Normally, this occurs automatically via dbdoctor or performance advisor. In addition, it is done periodically during design open.

Allegro's optimal sector size changes over the course of a design cycle. As the design becomes complete a smaller sector size typically results in better performance at a cost of a slightly higher memory requirement.

Note: For the current release, the sector size is in dbunits, future releases may change this to design units.

Arguments

None

Value Returned

- `nil`: If no tuning is required
- a disembody property list: If tuning was required. The a disembody property list contains:
  - old sectors
  - their size
  - new sectors
  - new sector size

©2023 All Rights Reserved.

axlTechnologyType

```
axlTechnologyType()
    ⇒ t_technology
```

Description

Returns the type of design technology in use.

Arguments

none

Value Returned

`t_technology`	Technology type as shown:

Technology Type	Product
`"mcm"`	Allegro Package Designer L or Allegro Package SI XL
`"pcb"`	Allegro PCB Editor

©2023 All Rights Reserved.

axlTriggerClear

```
axlTriggerClear(
     s_trigger
     s_function
     )
     ⇒ t/nil
```

Description

Removes a registered callback trigger. You pass the same arguments you passed as you registered the trigger.

Arguments

s_trigger	Trigger type. See `axlTriggerSet`.
s_function	Trigger function to remove - the same as you passed to `axlTriggerSet`.

Value Returned

`t`	Trigger removed.
`nil`	Failed to find a trigger by the specified name.

Example

See `axlTriggerSet` for an example.

©2023 All Rights Reserved.

axlTriggerPrint

```
axlTriggerPrint()
     ⇒ t
```

Description

Debug function that prints what is registered for triggers.

Arguments

`none`

Value Returned

`t`	Always returns `t`.

©2023 All Rights Reserved.

axlTriggerSet

```
axlTriggerSet(
     s_trigger
     s_function
     )
     ⇒ t/nil
```

```
axlTriggerSet(
     nil
     nil
     )
     ⇒ (ls_listOfSupportTriggers)
```

Description

Allows an application to register interest in events that occur in Allegro PCB Editor. Supported events are shown by the *s_trigger* option. When called with both arguments as `nil`, returns a list of supported triggers.

Restrictions

Unless otherwise indicated, in you SKILL callback trigger you cannot:

- open, save or close the current database.
- call axlShell.
- call any of the axlEnter functions or any of the Select object functions to request a user pick.

You should restrict any user interaction to blocking dialogs (forms).

Notes

- All trigger functions take a single argument. If you provide a function that does not match this standard, your trigger is **not** called.
- Any processing you do in triggers increases the time to open or save a database. So it is recommended that you must keep these short. If it must be longer, inform the user regarding the processing delay using `axlUIWPrint`.
- You can register multiple functions for a single trigger, but each registration must have a different function. The order that these functions are called when the trigger occurs is undefined.

©2023 All Rights Reserved.

- Allegro PCB Editor sends a close trigger when Allegro PCB Editor exits normally. Abnormal exits such as crash, user kill, etc. result in this trigger not being generated.
- You can do user interface work in triggers. You must have the user enter all information before returning from the trigger. Opening a dialog box may involve returning before getting data from the user. To avoid this problem, call `axlUIWBlock` after `axlFormDisplay`. This ensures you do all processing inside the trigger. For correct dialog box display, use the block option in `axlFormCreate`, the *`lt_placement`* parameter.
- You should use caution when using axlShell API within a trigger function. Cadence advises against this and does not support it. For example, calling Allegro commands or running scripts is not supported. Using axlShell API within a trigger function can cause the following:
    - Allegro layout editor may block in the script resulting in trigger failures.
    - Messages may appear to the user that you cannot suppress.
    - Scripts, commands and command behavioral can change from release to release.
    - User can also issue commands to different functionality.
- The triggers for opening and saving the database are generally not called when the database needs to do temporary saves, for example, `axlRunBatchDBProgram`, reports, or `netrev`.
- You can disable triggering by setting the environment variable *`dbg_noskilltriggers`*. If you suspect that applications running on triggers are causing problems, set this environment variable to help you debug.

©2023 All Rights Reserved.

Arguments

s_trigger	Trigger type as follows:

s_trigger Option	Description
'open (*t_database g_existing*)	Called immediately after a database is opened. Passed a list of two items: the name of the database and `t` if existing or `nil` if a new database. Restrictions: You should not open, save, and close the current database.
'save (*t_oldName t_newName*)	Called before a database is saved to disk. Passed a list of two items: the old name of the database and the new name of the database. If these are the same, then the database was overwritten. This is not called when autosaving.
'close *t_name*	Called before another database is opened. The single item is the name of the database being discarded.
'exit x_status	Called when program is exiting except if it is an abnormal termination. `x_status` is a number where `0` indicates a clean exit, `1` indicates warnings, and `2` is exiting due to an error. **Note:** GUI programs do not currently exit with warnings but this may change in the future. Trigger is provided for applications to clean-up the environment. For database specific work, use save or close trigger. Restrictions: ■ Do not read or change the database. ■ Do not display dialogs or blocking confirmers.

©2023 All Rights Reserved.

s_trigger Option	Description
`'menu t_menuName`	Called when a new menu is loaded in the main tool window. Targeted at application code to modify the menu. Restrictions: ■ While a database is active do not change the database. ■ Do not display dialogs or blocking confirmers. ■ Do not call axlUIMenuLoad.
`'xprobe (s_mode lo_dbid)`	Called when object(s) is highlighted or dehighlight `s_mode` is a symbol which may be highlight or dehighlight and `lo_dbid` is a list of dbids. This is the same interface used to cross-probe to ConceptHDL/Capture. This is targeted to allow sending messages to external tools. Restrictions: ■ Do not change the database ■ Do not invoke a dialog or blocking confirmer ■ Keep processing at a minimum since this will impact user interactive performance.
`'window l_windowBox`	Called when the canvas display window changes the display area. This may be caused by a zoom, a pan in any direction, or a resize of the canvas window. `l_windowBox` is a bBox giving the current display area of the database. This is not triggered during a roam (mouse panning) action. This would flood your trigger with events as the screen is being constantly repositioned as your user moves the mouse. Restrictions: ■ Do not change the window display region in this trigger. ■ This can cause infinite loops .
`s_function`	Callback function for the event. Each trigger should have its own function. If you use the same function for multiple triggers you can not determine what function caused the trigger.

©2023 All Rights Reserved.

Value Returned

`t`	Trigger is registered for the indicated callback.
`nil`	Trigger is not registered for the indicated callback.

See Also

axlTriggerClear, axlTriggerPrint, axlInTrigger, axlInTriggerFunc

Examples

See `<cdsroot>/share/pcb/examples/skill/trigger` for an example.

Example 1

In `ilinit`, add:

```
procedure( MyTriggerOpen( t_open)
    let( (brd old)
    brd = car(t_open)
    old = cadr(t_open)
    if (old then
        old = "Existing"
    else
        old = "New"
    )
    printf("SKILLCB Open %s database %s\n" old brd)
    t
))
axlTriggerSet('open 'MyTriggerOpen)
```

Shows how to use this with `~/pcbenv/allegro.ilinit` to be notified when your user opens a new board. Echoes a print every time a user opens a new database.

Example 2

```
when( isCallable('axlTriggerSet) axlTriggerSet('open 'MyTriggerOpen))
```

To be compatible with pre-14.1 software, substitute for `axlTriggerSet` in `allegro.ilinit`.

©2023 All Rights Reserved.

axlGetActiveLayer – Obsolete

This function is obsolete and is kept for compatibility reasons. Use `axlDBControl`.

©2023 All Rights Reserved.

axlGetActiveTextBlock – Obsolete

This function is obsolete.

©2023 All Rights Reserved.

axlSetActiveLayer – Obsolete

This function is obsolete and is kept for compatibility reasons. Use `axlDBControl`.

©2023 All Rights Reserved.

axlWFMAnyExported

```
axlWFMAnyExported()
     ==> t/nil
```

Description

Reports if there are any exported partitions.

Use axlDesignType to see if the design is currently a partition.

Arguments

None

Value Returned

`t`, if one or more partitions are currently exported

`nil`, if no partitions exported

See Also

axlDesignType

Examples

```
axlWFMAnyExported()
```


©2023 All Rights Reserved.

axlDBDisplayControl

```
axlDBDisplayControl(
     s_name
     [g_value]
     )
     ==> g_currentValue/ls_names
```

Description

This command is used to inquire and set the display database controls. When used for setting a value, the command returns the old value of the control.

Note: For most of these controls, if the form that is displaying the current setting is active, it may not be updated. Additional side effects of individual controls are listed.

Use the axlColorGet and axlColorSet commands to change the background color.

Items currently supported are listed in Table 14-1 on page 1047.

Table 14-1 Supported Controls

Name	Value	Set	Description	Equivalent	Side Effects
connectPointSize	dbrep	Yes	Changes the size of connect points (diamond figures)	prmed Display group	Call axlVisibleUpdate to update display.
connectPointEnabled	t/nil	Yes	Changes visibility of connect points (diamond figures)	prmed Display group	Call axlVisibleUpdate to update display.
customColorEnabled	t/nil	Yes	Changes the display of custom colors	color192 dialog ("Enable Custom Colors")	Call axlVisibleUpdate to update display.
displayNetNames	t/nil	Yes	Enables the display of net names on etch. OpenGL must be enabled.	prmed Display group	Call axlVisibleUpdate to update display.

©2023 All Rights Reserved.

Table 14-1 Supported Controls, *continued*

Name	Value	Set	Description	Equivalent	Side Effects
designOrigin	t/nil	Yes	Enables the display of design origin	prmed Display group	Call axlVisibleUpdate to update display.
drcMakerSize	dbrep	Yes	Changes the size of DRC markers	prmed Display group	Call axlVisibleUpdate to update display.
endcapsEnable	t or nil	Yes	Controls display of line endcaps	prmed Display group	Call axlVisibleUpdate to update display.
filledPadsEnable	t or nil	Yes	Pads are displayed filled or hollow	prmed Display group	Call axlVisibleUpdate to update display.
gridColor	`1` to *`<maxcolor>`*	Yes	Changes the grid color **Note:** You can find the *`<maxColor>`* by running the command, `maxColor = axlColorGet(` count`)`	color dialog Display group	Call axlVisibleUpdate to update display.
gridEnable	`t` or `nil`	Yes	Queries and changes the grid visibility	Color form, Display Group, Grids	Call axlVisibleUpdate to update display.

©2023 All Rights Reserved.

Table 14-1 Supported Controls, *continued*

Name	Value	Set	Description	Equivalent	Side Effects
highlightColor	`1` to *`<maxcolor>`*	Yes	Queries/changes the permanent highlight color. Can be used with axlHighlightObject	Color form, Display Group, Permanent highlight	Also changes the perm highlight color in the `hilite` command. Call axlVisibleUpdate to update display.
holeColor	`1` to *`<maxcolor>`*	Yes	Queries/changes the drill hole color.	Color form, Display Group	Call axlVisibleUpdate to update display.
backdrillHoleColor	`1` to *`<maxcolor>`*	Yes	Queries/changes the backdrill hole color.	Color form, Display Group	Call axlVisibleUpdate to update display.
lastSaveUser	string	No	Reports last user login who saved design. This may be an empty string, if the design was never saved.	Status form	None
nonPlatedHolesEnable	`t` or *`nil`*	Yes	Queries and changes the non-plated holes visibility. Unlike in the prmed dialog, setting this option to `t` does not set `padlessHolesEnable` to t.	Color form, Display Group, Grids	Call axlVisibleUpdate to update display.

©2023 All Rights Reserved.

Table 14-1 Supported Controls, *continued*

Name	Value	Set	Description	Equivalent	Side Effects
backdrillHolesEnable	`t` or *`nil`*	Yes	Queries and changes the backdrill holes visibility. Must have performed the backdrill process to see the holes.	Color form, Display Group, Grids	Call axlVisibleUpdate to update display.
padlessHolesEnable	t or nil	Yes	Queries and changes the padless holes visibility	Color form, Display Group, Grids	Call axlVisibleUpdate to update display.
platedHolesEnable	t or nil	Yes	Queries and changes the plated visibility. Unlike in the prmed dialog, setting this option to `t` does not set `padlessHolesEnable` to t.	Color form, Display Group, Grids	Call axlVisibleUpdate to update display.
tempColor	`1` to *`<maxcolor>`*	Yes	Queries/changes the temporary highlight color. Can be used with axlHighlightObject	Color form, Display Group, Temporary highlight	Call axlVisibleUpdate to update display.
ratsnestColor	`1` to *`<maxcolor>`*	Yes	Queries/changes the ratsnest color for top to bottom ratsnest. In pre-16.2 releases, this set the color for all ratsnest.	Color form, Display Group, Ratsnest Color	Call axlVisibleUpdate to update display.

©2023 All Rights Reserved.

Table 14-1 Supported Controls, *continued*

Name	Value	Set	Description	Equivalent	Side Effects
ratsnestBBColor	`1` to *`<maxcolor>`*	Yes	Queries/changes the ratsnest color for bottom to bottom ratsnest.	Color form, Display Group, Ratsnest Color	Call axlVisibleUpdate to update display.
ratsnestTTColor	`1` to *`<maxcolor>`*	Yes	Queries/changes the ratsnest color for top to top ratsnest.	Color form, Display Group, Ratsnest Color	Call axlVisibleUpdate to update display.
ratsnestJog	t/nil	Yes	Queries/changes the ratsnest jog option.	prmed form, Display Group, Ratsnest Jog	None
ratTSize	dbrep	Yes	Changes the size of RatT markers	prmed Display group	Call axlVisibleUpdate to update display.
thermalPadEnable	t/nil	Yes	Queries and changes the thermal pads. Only applicable for negative planes.	prmed Display group	Call axlVisibleUpdate to update display.
transparencyGlobal	1 to 255	Yes	Changes the OpenGL global transparency where 1 is completely translucent and 255 is solid.	prmed Display group	Call axlVisibleUpdate to update display.

©2023 All Rights Reserved.

Table 14-1 Supported Controls, *continued*

Name	Value	Set	Description	Equivalent	Side Effects
transparencyShape	1 to 255	Yes	Changes the OpenGL shape transparency where 1 is completely translucent and 255 is solid.	prmed Display group	Call axlVisibleUpdate to update display.
viaLabel	t/nil	Yes	Queries and changes the via label display.	prmed Display group Now called "Drill labels" in dialog	Call axlVisibleUpdate to update display.
viaLabelColor	`1` to *`<maxcolor>`*	Yes	Queries and changes the via label color.	Color form, Display Group Now called "Drill labels" in dialog	Call axlVisibleUpdate to update display.
stackedViaLabelColor	`1` to *`<maxcolor>`*	Yes	Queries and changes the stacked via label color.	Color form, Display Group	Call axlVisibleUpdate to update display.
waiveDRCColor	`1` to *`<maxcolor>`*	Yes	Queries and changes the waived DRC color.	Color form, Display Group, Waived DRC	Call axlVisibleUpdate to update display.
waiveDRCEnable	t/nil	Yes	Queries and changes the waived DRC display state	Color form, Display Group, Waived DRC	Call axlVisibleUpdate to update display.

©2023 All Rights Reserved.

Arguments

s_name	symbol name of control. nil returns all possible names
s_value	optional symbol value to set. Usually a `t` or a `nil`.

Value Returned

See above

`ls_names`: If name is `nil` then returns a list of all controls.

See Also

axlDBControl, axlColorGet, axlColorShadowGet

Examples

- Find out grid color

```
color = axlDBDisplayControl('gridColor, nil)
```

- Turn on grids

```
old = axlDBDisplayControl('gridEnable t)
```

- Get all names supported by this interface

```
listOfNames = axlDBDisplayControl(nil)
```


©2023 All Rights Reserved.

AXL-SKILL Pulse Functions

This section describes the AXL-SKILL Pulse functions.

axlPulseCommit

```
axlPulseCommit(
     [t_revisionString]
     [t_commentString]
     [t_tagString]
     [t_keepLockedString]
     )
     ⇒ t/nil
```

Description

This function commits the current design to the Pulse platform. If no arguments are provided, it displays the *Commit* dialog box with default values. If only `t_revisionString` is provided, the dialog box is displayed with the pre-populated appropriate fields. When any additional arguments are provided, the commit operation is initiated without displaying the *Commit* dialog box.

Note: The return value of this function does not indicate the success or failure of the Pulse operation itself, but only indicates whether the Pulse operation was successfully attempted.

Arguments

t_revisionString	Set as `major` or `minor`. Specifies whether the active design is saved as a major or minor revision in the Pulse database.
t_commentString	A comment string associated with the new revision.
t_tagString	A comma-separated list of tags associated with the new revision.
t_keepLockedString	Set as `keep_locked`, if commit operation should keep design in locked state. By default, (if this argument is not specified) the commit operation unlocks the design when it ends.

Value Returned

`t`	If the Pulse operation was initiated successfully.

©2023 All Rights Reserved.

`nil`	If the Pulse operation was not initiated successfully.

See Also

axlPulseVersionControl

Example

- Opens the *Pulse Commit* dialog box with default arguments:

```
axlPulseCommit()
```

- Opens the *Pulse Commit* dialog box with `major` revision selected:

```
axlPulseCommit("major")
```

- Initiates a commit operation as a `minor` revision update with the comment string `Minor edits`:

```
axlPulseCommit("minor" "Minor edits")
```

- Initiates a commit operation with the given revision type, comment, and tags:

```
axlPulseCommit("major" "Start new variant" "pcb,variant,customerA")
```

- Initiates a commit operation with the given revision type, comment, and tags and keeping design in locked state:

```
axlPulseCommit("major" "Start new variant" "pcb,variant,customerA"
"keep_locked)
```


©2023 All Rights Reserved.

axlPulseCopyAs

```
axlPulseCopyAs(
     )
     ⇒ t/nil
```

Description

This function displays the *Pulse Copy As* dialog box.

Note: The return value of this function does not indicate the success or failure of the Pulse operation itself, but only indicates whether the Pulse operation was successfully attempted.

Arguments

None.

Value Returned

`t`	If the Pulse operation was initiated successfully.
`nil`	If the Pulse operation was not initiated successfully.

See Also

axlPulseVersionControl

Example

- Opens the *Pulse Copy As* dialog:

```
axlPulseCopyAs()
```


©2023 All Rights Reserved.

axlPulseDownloadAttachment

```
axlPulseDownloadAttachment(
     )
     ⇒ t/nil
```

Description

This function downloads an attachment from the currently open Pulse-managed design. using the default name.

Arguments

t_fileName	The file name of the attachment to download.
t_downloadPath	The full path for downloading the attached file.

Value Returned

`t`	If the download operation is successful.
`nil`	If the download operation fails.

See Also

axlPulseGetAttachmentNames, axlPulseUploadAttachment

Example

- Downloads an attachment `test.txt` from the currently Pulse-managed design and saves it into `C:/temp` directory:

  ```
  axlPulseDownloadAttachment("test.txt","C:/temp")
  ```


©2023 All Rights Reserved.

axlPulseEnabled

```
axlPulseEnabled(
     )
     ⇒ t/nil
```

Description

This function checks whether the Pulse services are running and available for use. No Pulse-related functionality is available if the Pulse services are not running.

Arguments

None.

Value Returned

`t`	If the Pulse operation was initiated successfully.
`nil`	If the Pulse operation was not initiated successfully.

See Also

axlPulseLock

Example

- Opens the *Pulse Unlock* dialog box:

```
axlPulseEnabled()
```


©2023 All Rights Reserved.

axlPulseGetAttachmentNames

```
axlPulseGetAttachmentNames(
     )
     ⇒ Name of the files that are attached to the currently open Pulse-
     managed design.
```

Description

This function prints the name of all the files that are attached to the active Pulse-managed design.

Arguments

None.

Value Returned

List of file names that are attached to the active Pulse-managed design/nil.

See Also

axlPulseDownloadAttachment, axlPulseUploadAttachment

Example

- Prints the file names that are attached to the currently open Pulse-managed design:

  ```
  axlPulseGetAttachmentNames()
  ```


©2023 All Rights Reserved.

axlPulseGetDesignStatus

```
axlPulseGetDesignStatus(
     )
     ⇒ PulseStatusModel
```

Description

This function queries the design state in Pulse and return a summary of Pulse design status.

Arguments

None.

Value Returned

Summary of the design, such as connection state, platform state, platform mode, and so on.

Example

```
axlPulseGetStatus()
```


©2023 All Rights Reserved.

axlPulseGetRevision

```
axlPulseGetRevision(
     t_revisionString
     )
     ⇒ t/nil
```

Description

This function retrieves and opens the design with the given revision from the Pulse database.

Note: The return value of this function does not indicate the success or failure of the Pulse operation itself, but only indicates whether the Pulse operation was successfully attempted.

Arguments

t_revisionString	The design revision to retrieve. Expected values are either of the form "`#.#`', or "`latest`", or "`current`".

Value Returned

`t`	If the Pulse operation was initiated successfully.
`nil`	If the Pulse operation was not initiated successfully.

See Also

axlPulseCommit

Examples

- Retrieves and opens version `1.1` of the current design:

  ```
  axlPulseGetRevision("1.1")
  ```

- Retrieves and opens the latest version of the current design:

  ```
  axlPulseGetRevision("latest")
  ```

- Retrieves and opens the current version of the current design (useful for reverting uncommitted changes):

  ```
  axlPulseGetRevision("current")
  ```


©2023 All Rights Reserved.

axlPulseGetStatus

```
axlPulseGetStatus(
     )
     ⇒ Unknown/Stopped/Starting/Registering/Connected/Deregistering/
     Deregistered/Stopping
```

Description

This function returns the state of the Allegro-Pulse interface.

Arguments

None.

Value Returned

`Unknown`	Pulse server not reachable.
`Stopped`	Pulse server stopped.
`Starting`	Pulse server starting.
`Registering`	Registering user on Pulse server.
`Connected`	Allegro application is connected to Pulse server.
`Deregistering`	Deregistering user on Pulse server.
`Deregistered`	User deregistered on Pulse.
`Stopping`	Pulse server stopping.

Example

```
axlPulseGetStatus()
```


©2023 All Rights Reserved.

axlPulseLock

```
axlPulseLock(
     )
     ⇒ t/nil
```

Description

This function displays the *Pulse Lock* dialog box.

Note: The return value of this function does not indicate the success or failure of the Pulse operation itself, but only indicates whether the Pulse operation was successfully attempted. This function is available with a remote server configuration only.

Arguments

None.

Value Returned

`t`	If the Pulse operation was initiated successfully.
`nil`	If the Pulse operation was not initiated successfully.

See Also

axlPulseUnlock

Example

- Opens the *Pulse Lock* dialog box:

```
axlPulseLock()
```


©2023 All Rights Reserved.

axlPulseOpenDesign

```
axlPulseCommit(
     ?design t_design_url
     ?mode t_mode
     ?path t_download_path
     )
     ⇒ t_design/nil
```

Description

This function opens a specified design. If the current design has unsaved edits, confirmation is needed for discarding the edits, unless the current design was opened with `wf` mode. If canceled, the function returns `nil`, and the current design remains open. The design type of the new design is set as the same as the current design and can be changed using `axlSetDesignType`.

Note: This function is similar to the '`open from pulse`' command of the Allegro PCB Editor, except that the `t_mode` can be set to "`wf`" in order to discard the current edits without confirmation. Since confirmation uses standard Allegro PCB Editor confirmer, using the "`wf`" mode is essentially the same as setting the *`NOCONFIRM`* environment variable. It voids all axl dbid handles and clear the selection set.

Arguments

`t_design`	The URL of the design (Same as Pulse Share dialog box).
`t_mode`	Can be either "`w`" or "`wf`".
`t_download_path`	Optional, if you want to download design at a specified location.

Value Returned

`t_design`	If design opens.
`nil`	If error occurs.

See Also

axlCurrentDesign, axlKillDesign, axlRenameDesign, axlSaveDesign, axlSetSymbolType, axlRunBatchDBProgram, axlSaveEnable, axlCompileSymbol

©2023 All Rights Reserved.

axlPulseShowDesigns

```
axlPulseShowDesigns(
     )
     ⇒ t/nil
```

Description

This function displays the *Pulse Design List* dialog box.

Note: The return value of this function does not indicate the success or failure of the Pulse operation itself, but only indicates whether the Pulse operation was successfully attempted.

Arguments

None.

Value Returned

`t`	If the Pulse operation was initiated successfully.
`nil`	If the Pulse operation was not initiated successfully.

See Also

axlPulseVersionControl

Example

- Opens the Pulse Design List dialog:

  ```
  axlPulseShowDesigns()
  ```


©2023 All Rights Reserved.

axlPulseShowShare

```
axlPulseShowShare(
     )
     ⇒ t/nil
```

Description

This function displays the *Pulse Share* dialog box.

Note: The return value of this function does not indicate the success or failure of the Pulse operation itself, but only indicates whether the Pulse operation was successfully attempted. This function is only available with a remote server configuration.

Arguments

None.

Value Returned

`t`	If the Pulse operation was initiated successfully.
`nil`	If the Pulse operation was not initiated successfully.

See Also

axlPulseVersionControl

Example

- Opens the *Pulse Share* dialog box:

```
axlPulseShowShare()
```


©2023 All Rights Reserved.

axlPulseUnlock

```
axlPulseUnlock(
     )
     ⇒ t/nil
```

Description

This function displays the *Pulse Unlock* dialog box.

Note: The return value of this function does not indicate the success or failure of the Pulse operation itself, but only indicates whether the Pulse operation was successfully attempted. This function is only available with a remote server configuration.

Arguments

None.

Value Returned

`t`	If the Pulse operation was initiated successfully.
`nil`	If the Pulse operation was not initiated successfully.

See Also

axlPulseLock

Example

- Opens the Pulse Unlock dialog:

```
axlPulseUnlock()
```


©2023 All Rights Reserved.

axlPulseUploadAttachment

```
axlPulseUploadAttachment(
     )
     ⇒ t/nil
```

Description

This function uploads the file specified as parameter into Pulse and attaches it to the currently open Pulse-managed design.

Arguments

t_fileName	The full path with the file name for uploading it into Pulse and attached to the currently open Pulse-managed design.

Value Returned

`t`	If the upload operation was completed successfully.
`nil`	If the upload operation failed.

See Also

axlPulseDownloadAttachment, axlPulseGetAttachmentNames

Example

- Uploads file `C:/temp.test.txt` into pulse and attaches it to the currently open Pulse-managed design

  ```
  axlPulseUploadAttachment("C:/temp.test.txt")
  ```


©2023 All Rights Reserved.

axlPulseVersionControl

```
axlPulseVersionControl(
     )
     ⇒ t/nil
```

Description

This function displays the *Pulse Version Control* dialog box.

Note: The return value of this function does not indicate the success or failure of the Pulse operation itself, but only indicates whether the Pulse operation was successfully attempted.

Arguments

None.

Value Returned

`t`	If the Pulse operation was initiated successfully.
`nil`	If the Pulse operation was not initiated successfully.

See Also

axlPulseCommit

Example

- Opens the *Pulse Version Control* dialog box:

```
axlPulseVersionControl()
```


©2023 All Rights Reserved.

©2023 All Rights Reserved.

15

Database Create Functions

Overview

This chapter describes the AXL functions that add objects to the Allegro PCB Editor database. Some functions require input that you set up using available auxiliary functions, which are also described in this chapter. For example, Allegro PCB Editor paths consist of any number of contiguous line and arc segments. To add this multi-structure to the Allegro PCB Editor database, first create a temporary path, adding each line or arc segment using separate function calls. Once the temporary path contains all required segments, create the Allegro PCB Editor line-object, shape or void by calling the appropriate database create function, giving the path structure as an argument. The chapter shows several examples of the process.

Database create (`DBCreate`) functions modify the active Allegro PCB Editor database in virtual memory and require a database save to make changes permanent in the file.

Supply all coordinates to these functions in user units, unless otherwise noted.

The functions described here do not display the objects immediately as they create them. To display all changes, call an interactive function, exit SKILL, or return control to the Allegro PCB Editor command interpreter.

➤ To immediately display an object you have just created, do one of the following:

- ❑ Call the function `axlDisplayFlush`

–or–

- ❑ Call an interactive function

If you create an object and then delete it without calling `axlDisplayFlush` or calling an interactive function, the object never appears in the display.

The class of geometric objects that `DBCreate` functions create are called *figures*. `DBCreate` functions return, in a list, the *`dbids`* of any figures they create and a Boolean

©2023 All Rights Reserved.

value `t` if the creation caused any DRCs. The functions return `nil` if they could not create any figures. The exact structure of the data returned differs among the commands. See the individual commands for detailed descriptions.

You can set the active layer (Allegro PCB Editor class/subclass) by calling the `axlSetCurrentLayer` function. This function returns a `nil` if you try to set an invalid layer or if you try to create a figure on a layer that does not allow that figure type.

AXL-SKILL creates a figure as a member of a net only if the figure is on an etch layer. Where a function has a netname as an argument, and the active layer is an etch layer, the function attaches the figure to the net specified by that netname. If the net does not exist, an error occurs. If you specify `nil` for the netname, the function determines the net for the figure by what other figure it touches. If the figure is free standing, that is, touches nothing, the figure becomes a member of the dummy net (no net).

The functions use defaults for all parameters you do not supply. If you do not supply a required parameter (one without a default, for example, *`pointList`*) the function considers the call an error and returns `nil`.

The database create functions do not add figures to the select set. They leave the select set unchanged.

Path Functions

An Allegro PCB Editor *`line`* is a figure consisting of end-to-end straight line and arc segments, each segment having a width you can define separately. Allegro PCB Editor *`shapes`* and *`polygons`* are figures that define an area. A shape owns a closed line figure that defines the perimeter of the shape. The shape has an associated fill pattern and can also own internal *`voids`*. Each void in turn owns a polygon that defines its boundary.

A *`path`* is a set of contiguous arc and single straight line segments. In AXL, you first create a path consisting of the line and arc segments by adding each segment with a separate AXL function, then creating the actual figure using the appropriate `axlDBCreate` function, with the path as one of the arguments. With AXL convenience functions described later in this chapter, you can create rectangles, circles, and lines consisting only of straight segments.

All coordinate arguments to the path functions are in user units and are absolute to the layout origin.

©2023 All Rights Reserved.

Example

This general example shows how to create a path, then use it as an argument in an `axlDBCreate` function. The example creates a path consisting of a straight line segment, then adds an arc and another line segment, and uses it as an argument to create a path that is a member of net `"net1"` on etch subclass `"top"`:

```
path = axlPathStart( (list 100:250))
    axlPathLine( path, 0.0, 200:250 )
    axlPathArcCenter( path, 0.0, 300:350, nil, 200:350 )
    axlPathLine( path, 0.0, 300:450 )
    axlDBCreatePath( path, "etch/top", "net1")
```

©2023 All Rights Reserved.

axlPathStart

```
axlPathStart(
     l_points
     [f_width]
     )
     ⇒ r_path/nil
```

Description

Creates a new path with a startpoint and one or more segments as specified by the list *l_points* and returns the path *dbid*. You can add more straight-line and arc segments to the returned *r_path* using the `axlPathArc` and `axlPathLine` functions described in this section. Once *r_path* has all the segments you require, create the actual database figure using the appropriate `axlDBCreate` function, with *r_path* as one of the arguments.

Arguments

Value Returned

l_points	List of *n* vertices, where *n* > 1. If *n* = 1, *r_path* returns with that single vertex as its startpoint, but with no segments. You must subsequently add at least one segment before adding it to the database. If *n* > 1, *r_path* returns with *n*-1 straight-line segments.
f_width	Width for all segments, if any created, between the *l_points*. *f_width* is the default width for all additional segments added to *r_path* using `axlPath` functions. You can override this default width each time you add a segment using an `axlPath` function by using a *f_width* argument when you invoke the function.
r_path/nil	Returns the *r_path* handle.

Note: This is a handle object, but is *not* an Allegro PCB Editor *dbid.*

Example

See start of the Path Functions on page 1072.

©2023 All Rights Reserved.

axlPathArcRadius

axlPathArcAngle

axlPathArcCenter

```
axlPathArcRadius(
     r_path
     f_width
     l_end_point
     g_clockwise
     g_bigarc
     f_radius
     )
     ⇒ r_path/nil

axlPathArcAngle(
     r_path
     f_width
     l_end_point
     g_clockwise
     f_angle
     )
     ⇒ r_path/nil

axlPathArcCenter(
     r_path
     f_width
     l_end_point
     g_clockwise
     l_center
     )
     ⇒ r_path/nil
```

Description

Each of these functions provides a way to construct an arc segment from the current endpoint of *r_path* to the given *l_end_point* in the direction specified by the Boolean *g_clockwise*, as described below and shown in Figure 15-1 on page 1076.

Attempts to create small arcs using many decimal points of accuracy may fail due to rounding errors.

©2023 All Rights Reserved.

Arguments

Figure 15-1 Effects of *axlPathArc* Arguments

r_path	Handle of an existing *r_path* to receive arc segment.
f_width	Width of an arc segment in user units. Overrides, for this segment only, any width originally given in `axlPathStart`;`nil` = use current width
l_end_point	End point to which an arc is to be constructed. Start point is the last point currently in *r_path* in absolute coordinates.
g_clockwise	Direction to create arc: `t` → create arc clockwise from start to endpoint `nil` → create counterclockwise. Default is counterclockwise (See Figure 15-1 on page 1076).
g_bigarc	`axlPathArcRadius`: Create an arc greater than or equal 180 degrees (See Figure 15-1 on page 1076).
f_radius	`axlPathArcRadius`: Arc radius in user units.
f_angle	`axlPathArcAngle`: Angle in degrees subtended by arc (See Figure 15-1 on page 1076).
l_center	`axlPathArcCenter`: Arc center point in absolute coordinates.

©2023 All Rights Reserved.

Value Returned

r_path	Current path handle.
nil	Arc path not created.

Example 1

```
mypath = axlPathStart( list( 8900:4400))
axlPathArcRadius( mypath, 12., 8700:5300, nil, nil, 500)
axlDBCreatePath( mypath, "etch/top")
```

Adds a smaller-than-180 degree counterclockwise arc by radius.

©2023 All Rights Reserved.

Creates the smaller possible arc:

Example 2

```
mypath = axlPathStart( list( 8900:4400))
axlPathArcAngle( mypath, 12., 8700:5300, nil, 330)
axlDBCreatePath( mypath, "etch/top")
```

Adds a counterclockwise arc subtending 330 degrees.

Example of axlPathArcCenter

See Example on page 1073.

©2023 All Rights Reserved.

axlPathLine

```
axlPathLine(
     r_path
     f_width
     l_end_point
     )
     ⇒ r_path/nil
```

Description

Adds a single straight line segment to the end of an existing *r_path* structure as specified by the arguments. Start point of the line is the last point in *r_path*.

Arguments

r_path	Handle of an existing path.
f_width	Width of the segment.
	`nil` = segment takes the width given when *r_path* was created.
l_end_point	End point of the line segment in absolute coordinates.

Value Returned

r_path	Path structure following addition of single straight line segment to end of *r_rath* structure.
`nil`	No line segment added to *r_path* structure.

Example

See start of the Path Functions on page 1072.

©2023 All Rights Reserved.

axlPathGetWidth

```
axlPathGetWidth(
     r_path
     )
     ⇒ f_width/nil
```

Description

Gets the default width of an existing path structure.

Arguments

r_path	Handle of an existing path structure.

Value Returned

f_width	Default width of the path structure.
nil	*r_path* is not a path, or is empty.

Example

`axlPathGetWidth` returns the default path width of 173 mils.

```
path = axlPathStart( (list 1000:1250), 173)
    axlPathLine( path, 29, 2000:1250)
    axlPathLine( path, 33, 3000:3450)
    axlDBCreatePath( path, "etch/top")

axlPathGetWidth( path)
    ⇒ 173.0
```

- Creates a path with width 173 mils
- Adds line segments at widths 29 and 33 mils

©2023 All Rights Reserved.

axlPathSegGetWidth

```
axlPathSegGetWidth(
     r_pathSeg
     )
     ⇒ f_width/nil
```

Description

Gets the width of a single segment in a path structure.

Arguments

r_pathSeg	Handle of a segment of a path structure.

Value Returned

f_width	Returns the width of the segment.
nil	*r_pathSeg* is not a segment.

Example

`axlPathSegGetWidth` returns the width of that segment only, 33 mils.

```
path = axlPathStart( (list 1000:1250), 173)
    axlPathLine( path, 29, 2000:1250)
    axlPathLine( path, 33, 3000:3450)

lastSeg = axlPathGetLastPathSeg(path)

axlPathSegGetWidth( lastSeg)
    ⇒ 33.0
```

- Creates a path with default width 173 mils
- Adds line segments at widths 29 and 33 mils
- Gets the last segment added with `axlPathGetLastPathSeg`

©2023 All Rights Reserved.

axlPathGetPathSegs

```
axlPathGetPathSegs(
     r_path
     )
     ⇒ r_pathList/nil
```

Description

Gets a list of the segments of a path structure, in the order they appear in the path.

Arguments

r_path	Handle of an existing path structure.

Value Returned

Example

r_pathList	Returns a list of the segments of the path.
nil	*r_path* is not a path.

```
mypath = axlPathStart( (list 1000:1250), 173)
    axlPathLine( mypath, 29, 2000:1250)
    axlPathArcCenter( mypath, 12, 3000:2250, t, 3000:2250)
mysegs = axlPathGetPathSegs( mypath)
print mysegs
    ⇒(array[6]:1057440 array[6]:1057416 array[6]:1057392)
```

- Creates a path
- Gets the segments of the path
- Prints the segments of the path

©2023 All Rights Reserved.

axlPathGetLastPathSeg

```
axlPathGetLastPathSeg(
     r_path
     )
     ⇒ r_pathList/nil
```

Description

Gets the last segment of a path structure.

Arguments

r_path	Handle of an existing path structure.

Value Returned

Example

r_pathList	Returns the last segment of the path.
nil	*r_path* is not a path.

`axlPathSegGetWidth` returns the width of that segment only, 33 mils.

```
path = axlPathStart( (list 1000:1250), 173)
    axlPathLine( path, 29, 2000:1250)
    axlPathLine( path, 33, 3000:3450)
lastSeg = axlPathGetLastPathSeg(path)
axlPathSegGetWidth( lastSeg)
    ⇒33.0
```

- Creates a path with the default width 173 mils
- Adds line segments at widths 29 and 33 mils
- Gets the last segment added using `axlPathGetLastPathSeg`

©2023 All Rights Reserved.

axlPathSegGetEndPoint

```
axlPathSegGetEndPoint(
     r_pathSeg
     )
     ⇒ l_endPoint/nil
```

Description

Gets the end point of an existing path structure.

Arguments

r_pathSeg	Handle of a path segment.

Value Returned

l_endPoint	List containing the end point of the path structure.
nil	*r_pathSeg* is not the *dbid* of a path segment, or the structure is empty.

Example

```
path = axlPathStart( (list 1000:1250), 173)
    axlPathLine( path, 29, 2000:1250)
    axlPathLine( path, 33, 3000:3450)

lastSeg = axlPathGetLastPathSeg(path)

axlPathSegGetEndPoint( lastSeg)
    ⇒(3000 3450)
```

- Creates a path with default width 173 mils
- Adds line segments at widths 29 and 33 mils
- Gets the last segment added with `axlPathGetLastPathSeg`

`axlPathSegGetWidth` returns the width of that segment only, 33 mils.

©2023 All Rights Reserved.

axlPathSegGetArcCenter

```
axlPathSegGetArcCenter(
     r_pathSeg
     )
     ⇒ l_point/nil
```

Description

Gets the center point of a path arc segment.

Arguments

r_pathSeg	Handle of a path arc segment.

Value Returned

l_point	List containing the center coordinate of the arc segment.
nil	Segment is not an arc.

Example

`axlPathSegGetArcCenter` gets the center of the last arc segment.

```
path = axlPathStart( (list 1000:1250), 173)
    axlPathLine( path, 29, 2000:1250)
    axlPathArcCenter( path, 12., 3000:2250, nil, 2000:2250)

lastSeg = axlPathGetLastPathSeg(path)

axlPathSegGetArcCenter( lastSeg)
    ⇒(2000 2250)
```

- Creates a path with a straight line segment and an arc segment
- Gets the last segment added with `axlPathGetLastPathSeg`

©2023 All Rights Reserved.

axlPathSegGetArcClockwise

```
axlPathSegGetArcClockwise(
     r_pathSeg
     )
     ⇒ t/nil
```

Description

Gets the clockwise flag (`t` or `nil`) of a path segment.

Arguments

r_pathSeg	Handle of a path segment.

Value Returned

`t`	Segment is clockwise.
`nil`	Segment is counterclockwise.

Example

`axlPathSegGetArcCenter` returns `t`, meaning the arc segment is clockwise.

```
path = axlPathStart( (list 1000:1250), 173)
    axlPathLine( path, 29, 2000:1250)
    axlPathArcCenter( path, 12., 3000:2250, t, 2000:2250)

lastSeg = axlPathGetLastPathSeg(path)

axlPathSegGetArcClockwise( lastSeg)
    ⇒ t
```

- Creates a path with a straight line segment and a clockwise arc segment
- Gets the last segment added using `axlPathGetLastPathSeg`

©2023 All Rights Reserved.

axlPathStartCircle

```
axlPathStartCircle(
     l_location
     f_width
     )
     ⇒ r_path/nil
```

Description

Creates an `axlPath` structure (*`r_path`*) for a circle.

Arguments

`l_location`	Center and radius as ((X Y) R).
`f_width`	Edge width of the circle.

Value Returned

`r_path`	*`r_path`* with the circle as the only segment.
`nil`	`axlPath` structure not created.

Note: Width must be specified for this interface (it may be 0.0) and since it uses standard SKILL arg check, it must be a flonum.

Example

```
(axlPathStartCircle (list 100:200 20),0)  ; no width specified.
```


©2023 All Rights Reserved.

axlPathOffset

```
axlDB2Path(
     r_path
     xy
     )
     ==> r_path
```

Description

Adds an offset, `xy`, to all points within a `r_path`.

Arguments

`r_path`	
`offset`	offset xy

Value Returned

new `r_path`

See Also

axlPathStart, axlDB2Path

Examples

Obtain shape outline as a `r_path` and then move if by 10:20.

```
p = ashOne("shapes")
path = axlDB2Path(p)
path1 = axlPathOffset(path 10:20)
```


©2023 All Rights Reserved.

axlDB2Path

```
axlDB2Path(
     o_dbid
     )
     ==> r_path
```

Description

This takes a database id (`od_dbId`) and converts it to an r_path. This function supports all dbids with a segment attribute. For example, shape, void, path, and line.

Note: In AXL-SKILL terminology, path and line, refers to cline/line and segments, respectively.

Arguments

`od_dbId`	The dbid for the line.

Value Returned

- `r_path` - if object can be converted
- `nil` - object cannot be converted.

See Also: axlPathStart

Examples

To obtain shape outline as a r_path, use following commands.

```
p = ashOne("shapes")
path = axlDB2Path(p)
```


©2023 All Rights Reserved.

axlDBCreatePath

```
axlDBCreatePath(
     r_path
     [t_layer]
     [t_netName]/['line}
     [o_parent]
     [lo_props]
     [s_font]
     )
     ⇒ l_result/nil
```

Description

Creates a path figure (line or cline) as specified. Does not add a net name to etch when the etch is not connected to a pin, via, or shape. If etch is added, it ties to the first net it touches, otherwise it remains “not on a net” as specified by the arguments described below.

Clines may merge with other clines so that the resulting coordinates may be a superset of the provided coordinates. This is not currently true for line types.

Normally, if you want to attach properties to a newly-created object, call `axlDBAddProp()` after creating the object. CLINEs may merge with existing CLINEs, so the object you end up adding properties to may not match the one you created. The *`lo_props`* option deals with this issue. You can add properties when you create the CLINE and if the property list on your CLINE differs from any merged target CLINES, your CLINE will not merge.

LINES with the interface are supported even though lines do not merge.

Allegro restricts the layers that allow fonts (s_font). ETCH layers may never have fonted lines.

©2023 All Rights Reserved.

Arguments

r_path	Existing path consisting of the straight-line and arc segments previously created by `axlPath` functions
t_layer	Layer on which to create a path figure. Default is the active layer.
t_netName	Name of the net to which the path figure belongs. If the net *t_netName* does not exist, `axlDBCreatePath` does not create any path, and returns `nil`.
`'line`	By default a path created on an Etch layer creates clines unless you pass 'line for this argument.
o_parent	*dbid* of object to be the parent of the path figure. Use the symbol instance or use `nil` to specify the design. If you attach etch figures to a symbol parent, the figures are not associated with the symbol, and do not move with it.
[lo_props]	Optional list of property name/value pairs. (See `axlDBAddProp()` for format.)
[s_font]	Optional line font, may have values as 'SOLID 'HIDDEN 'PHANTOM 'DOTTED 'CENTER. nil is the same as 'SOLID

Value Returned

`l_result`	Returns a list: ■ (car) list of *dbids* of all path figures created or modified ■ (cadr) `t` if DRCs are created. `nil` if DRCs are not created.
`nil`	Nothing was created.

See Also

axlDBAddProp

Example

```
path = axlPathStart( list 100:0 100:500))

; create path on current default layer
```


©2023 All Rights Reserved.

```
axlDBCreatePath(path)

; create a cline path on top etch layer and assisgn to GND
axlDBCreatePath(path "ETCH/TOP" "gnd")

;create a line path on top etch layer
axlDBCreatePath(path "ETCH/TOP" 'line)

;have user create a two pick path on board geometry outline
axlDBCreatePath( axlEnterPath() "BOARD GEOMETRY/OUTLINE")

;create a cline path on top etch layer with properties
propList = list( '(FIXED t) )
axlDBCreatePath(path "ETCH/TOP" "gnd" nil propList)
```


©2023 All Rights Reserved.

axlDBCreateLine

```
axlDBCreateLine(
     l_points
     [f_width]
     [t_layer]
     [t_netname]/['line]
     [rd_parent]
     [s_font]
     )
     ⇒ l_result/nil
```

Description

Create a path of fixed width straight segments, a line with series of provided points. If line is on an ETCH layer a cline will be created unless overridden with the `'line` symbol.

All points are absolute in user units. For <n> points provided, the function creates <n-1> segments.

Allegro restricts the layers that allow fonts. ETCH layers may never have fonted lines.

Tip

The t_netname option is used as a tie breaker in cases where the cline may want to connect to multiple objects. A cline cannot maintain a net by itself. This connectivity behavioral means if adding multiple clines and vias you must sequence them so that each cline or via is added such that it connects to an object with the desired net already in the database.

For example, you add 3 clines to drive a connection between 2 pins; where cline 1 and 3 terminate on a pin and cline 2 is in the middle. You should add them as 1 2 then 3. Adding them as 2, 1 and 3 may result in cline 2 being connected to a difference net.

©2023 All Rights Reserved.

Arguments

l_points	List of the vertices (at least two) for this path.
f_width	Width for all segments in the path. Default is 0.
t_layer	Layer to which to add the path. Default is the current active layer.
t_netname	Name of the net or `nil`
rd_parent	*dbid* of the object to which to the line is added. Use the symbol instance *dbid* or use `nil` to specify the design itself.
s_font	Optional line font, may have values as `'SOLID`, `'HIDDEN` 'PHANTOM 'DOTTED 'CENTER. `nil` is the same as 'SOLID

Value Returned

l_result	List: (car) list of *dbids* of all paths created or modified (cadr) `t` if DRCs are created. Otherwise the function returns `nil`.
`nil`	Nothing is created.

See Also

axlDBCreatePath

Example

```
axlDBCreateLine( (list 1000:1250 2000:2250), 15, "etch/top")
    ⇒ ((dbid:122784) t)
```

This example creates a line at width 15 mils from (1000, 1250) to (2000, 2250) on `"etch/top"`. The command returns the *dbid* of the line and `t`, indicating that it created DRCs.

©2023 All Rights Reserved.

axlDBCreateCircle

```
axlDBCreateCircle(
     l_location
     [f_width]
     [t_layer]
     [rd_parent]
     )
     ⇒ l_result/nil
```

Description

Create a circle at indicated location and with indicated diameter.

Arguments

l_location	Center and radius as (X:Y R).
f_width	Width of circle edge.
t_layer	Layer. Default is the current active layer.
rd_parent	*dbid* of object to add circle to (symbol instance or `nil` for design).

Value Returned

l_result	List containing: (`car`) list of circle *dbids*. There is always one `dbid` in the list. (`cadr`) `t` if any DRCs are created. `nil` if no DRCs are created.
`nil`	Nothing was created.

See Also

axlDBCreatePath

©2023 All Rights Reserved.

Create Shape Interface

You can create shapes using AXL functions as follows:

- To create a simple shape, filled or unfilled, without any voids, first create its boundary path using the `axlPath` functions described earlier. Next, call `axlDBCreateShape` using the path as an argument. `axlDBCreateShape` creates the shape in the database and returns, completing the process.
- To create a shape with voids, first create a shape in “open state” using `axlDBCreateOpenShape`. Next, add voids to the shape as needed using `axlDBCreateVoid` and `axlDBCreateVoidCircle`. Finally, put the shape permanently into the database with `axlDBCreateCloseShape`.

  This final function changes the state of the shape from “open” to “closed,” making it a permanent part of the database. Only one shape can be in the “open” state at one time.

You specify both shape and void boundaries with the *`r_path`* argument, just as you do creating lines and connect lines. `axlDBCreateShape` and `axlDBCreateOpenShape` also check that the following are true:

- All boundary path arguments—shape or void—are closed (equal startPoint endPoint)
- No boundary path segments touch or cross (no “bow ties”).
- All void boundaries are completely within the boundary of their parent shape

If you fail to meet one or more of these conditions, the functions do not create the shape or void, and return `nil`.

Example

- Closes the shape so that it fills and the command does DRC

```
mypath = axlPathStart( list(1000:1250))
mypath = axlPathLine( mypath, 0.0, 2000:1250)
mypath = axlPathArcCenter(
    mypath, 0.0, 2000:3250, nil, 2000:2250)
mypath = axlPathLine( mypath, 0.0, 1500:3250)
mypath = axlPathLine( mypath, 0.0, 1000:1250)
myfill1 = make_axlFill( ?angle 45.0, ?origin 10:20,
    ?width 50, ?spacing 80)
myfill2 = make_axlFill( ?angle 135.0, ?origin 10:20,
    ?width 5, ?spacing 100)
myfill = list( myfill1 myfill2)
myshape = axlDBCreateOpenShape( mypath, myfill,
    "etch/top", "sclkl")
if( myshape == axlDBActiveShape()
    println( "myshape is the active shape"))
axlDBCreateVoidCircle( myshape, list(1600:1700 300))
```


©2023 All Rights Reserved.

```
myvoidpath = axlPathStart( list(1600:2300))
myvoidpath = axlPathLine( myvoidpath, 0.0, 2400:2100)
myvoidpath = axlPathLine( myvoidpath, 0.0, 2600:2700)
myvoidpath = axlPathLine( myvoidpath, 0.0, 2100:3000)
myvoidpath = axlPathLine( myvoidpath, 0.0, 1600:2300)
axlDBCreateVoid(myshape, myvoidpath)
axlDBCreateCloseShape( myshape)
```

- Creates a closed path
- Creates the fill structures specifying the crosshatch parameters
- Creates the open shape on `"etch/top"` associated with net `"sclkl"` with `axlDBCreateOpenShape`
- Checks that the shape created is the active shape using `axlDBActiveShape` which will print the message
- Creates a circular void and attach it to the shape
- Creates a void shape and attach it to the shape

©2023 All Rights Reserved.

axlDBComposeShapesFromLines

```
axlDBComposeShapesFromLines(
     o_dbid/lo_dbids
     n_maxGap
     n_cornerRadius
     t_layer
     b_shapeFill
     [t_netName]
     [b_deleteLines]
     )
     ⇒ o_dbid/lo_dbids/error string
```

Description

Use this function to convert a group of lines and arcs created from a DXF or Gerber input into a shape. The function encapsulates the `compose shape` command. It allows you to gather the same objects and programmatically convert those into shapes on the target layers.

Any shape created from lines using this function is equivalent to the shape created from the `axlDBCreateOpenShape` and `axlDBCreateShape` functions. This function provides convenient access to features like bridging gaps in lines, which are brought in from external files. It can also round or trim corners the same way as the interactive compose shape tool does.

©2023 All Rights Reserved.

Arguments

o_dbid/lo_dbids	Any combination of line segments, lines, and shapes in the database for conversion. The shapes may become voids in other shapes, and so on, based on the nesting of the resulting shapes that are created.
n_maxGap	The maximum air gap between vertices, which should be close enough to create a closed shape outline. This argument corresponds to the *Maximum gap* option of the `compose shape` command. If `nil`, the value is computed from the provided segments.
n_cornerRadius	Radius for corners, if corners are to be rounded. This argument corresponds to the *Radius* option of the `compose shape` command. If `nil`, corners are not rounded.
t_layer	Destination layer on which shape is to be created
b_shapeFill	Either `t` or `nil`: ■ `t`: creates a solid-filled shape ■ `nil`: creates an unfilled shape Certain layers are allowed to have only one type of shape. If the specified destination layer only allows one shape fill state, this argument is ignored, and the layer's required shape type is used.
[t_netName]	Net assigned to the shape. Only applicable when creating shapes on cross-section layers.
[b_deleteLines]	`t/nil` indicates whether the lines used in the construction of the shapes should be deleted. Lines not incorporated into a shape are never deleted.

©2023 All Rights Reserved.

Value Returned

`o_dbid/l_dbids/string`

One of three possible results may be returned:

- `o_dbid`: A single shape dbid, if only one shape (with or without voids) is created
- `lo_dbids`: List of all shape dbids, if multiple shapes are created from provided lines
- `string`: On error or invalid arguments, a string indicating the problem.

Notes

- Some layers have restrictions on objects which are allowed. The `axlDBComposeShapesFromLines` function abides by these restrictions when creating shapes from the lines. For instance, unfilled shapes cannot be created in the PLACE_BOUND_TOP/BOTTOM layers.
- The DESIGN_OUTLINE layer is unique. This layer may only have a single (unfilled) shape outline on it. If multiple shapes result from the operation, or if shapes already exist on this layer, then all additional shapes are assumed to be cutouts in the design outline and are created on the CUTOUT layer, instead.
- Details about the process are available in the `axl_compose_shape_from_lines.log` file. This file is provided for debugging during development. The file will be overwritten by the next call to the API.

Example

```
; Define path and create as a line in database
path = axlPathStart( list(0:0 0:500 500:500 500:0 0:0))
line = car(axlDBCreatePath(path "DRAWING FORMAT/OUTLINE" 'line))
; Convert line to rectangular design outline on design outline layer.
; Leave original path line on the DRAWING FORMAT layer for reference.
outline = axlDBComposeShapesFromLines(line nil nil
"BOARD GEOMETRY/DESIGN_OUTLINE" nil nil nil)
```


©2023 All Rights Reserved.

axlDBCreateBoundingShape

```
axlDBCreateBoundingShape(
     lo_dbids
     t_padLayer
     n_expansion
     t_shapeLayer
     [t_netName]
     [b_deleteExisting]
     )
     ⇒ list(o_dbid b_drcs)
```

Description

Creates a convex hull, also called a bounding shape, around a set of objects. Objects supporting a convex hull are pins, vias, bond fingers, and cline segments. Other objects passed to the function are filtered from the *lo_dbids*.

©2023 All Rights Reserved.

Arguments

lo_dbids	Cline segments, vias, pins, and bond fingers for which the function calculates and creates the convex hull. All other items are removed from the list. A minimum of two items is required to create a convex hull shape.
t_padLayer	Pad layer for vias, pins, and bond fingers. The same layer must be used for all pads. Cline segments may exist on any layer. **Note:** The regular metal pad is used from the layer specified.
n_expansion	Expansion to apply around all objects when calculating convex hull. Positive value provides additional clearance from the edge of pads, while negative value keeps the shape inside the edge of pads.
t_shapeLayer	Layer on which shape is to be created.
[t_netName]	Net assigned to the shape. Only applicable when creating shapes on cross-section layers.
[b_deleteExisting]	`t/nil`. If true, any shape on the specified target layer overlaps the new bounding shape is removed.

Value Returned

`list(o_dbid b_drcs)`	dbid of shape and boolean indicator of whether DRCs have resulted.
`nil`	Error in parameters sent to function

Notes

Convex hulls represent the outline of a shape you would get by snapping a rubber band around the set of objects. It will not have inlets or concave sections in the boundary. It is a strictly positive shape outline.

Example

```
; Select all vias in the -500:-500 500:500 visible window.
axlSetFindFilter(?onButtons list("NOALL" "VIAS") ?enabled list("NOALL"
"VIAS"))
axlAddSelectBox(list(-500:-500 500:500));
```


©2023 All Rights Reserved.

```
vias = axlGetSelSet();
; Create bounding shape around these vias on the SOLDERMASK_TOP layer, removing
any old
; soldermask shape found overlapping.
shape = axlDBCreateBoundingShape(vias "ETCH/TOP" 50.0 "BOARD GEOMETRY/
SOLDERMASK_TOP" nil t)
```


©2023 All Rights Reserved.

axlDBCreateOpenShape

```
axlDBCreateOpenShape(
     o_polygon/r_path
     [l_r_fill]
     [t_layer]
     [t_netName/o_netdbid]
     [o_parent]
     )
     ⇒ o_shape/nil
```

Description

Creates a shape based on the characteristic of either *o_polygon* or *r_path*. With *r_path*, fills parameters, layer, netname, and parent you specify. Returns the *dbid* of the shape in open state. Open state means you can add and delete voids of the shape. With *o_polygon*, creates a shape with the boundary defined by the boundary of the polygon. The holes in the polygon are added as voids to the shape. (See axlPolyFromDB.)

The shape model uses the open/close model for performance reasons. While adding a shape without voids, you can use axlDBCreateShape, which hides the open and close. While adding voids you should do the following:

```
shape = axlDBCreateOpenShape(...)
... add voids ...
axlDBCreateCloseShape(shape).
```

You can modify an existing shape by using the axlDBOpenShape, as follows:

```
axlDBOpenShape(shape <new boundary>)
... add or delete voids ...
axlDBCreateCloseShape(shape).
```

Will not allow hole polygons as input. When holes are passed as input, the following warning displays:

```
Invalid polygon id argument -<argument>
```

See axlDBCreateSymDefSkeleton on notes about restrictions on shapes that are part of symbol definitions.

A static shape is created if you create shape on class ETCH; dynamic shapes are created if class is BOUNDARY. For example, to create a static shape on the TOP layer, make *t_layer=ETCH/TOP*. To make a dynamic shape, make *t_layer=BOUNDARY/TOP*. The same rule also applies to axlDBCreateShape.

©2023 All Rights Reserved.

fill structure for xhatch shapes is:

`l_fill1`	A fill_type.
`[l_fill2]`	(optional) A fill_type. Supplied when more then second xhatch pattern is desired.
`[f_outlineWidth]`	(optional) Width of outline must be greater than or equal to fill width(s). Specified in design units. Default is current board xhatch width. Only supported for *`o_polygon`* since outline width for *`r_path`* should be supplied through the *`r_path`* defstruct.

where fill_type is a defstruct with members

`f_spacing`	spacing between xhatches (design units)
`f_width`	width of xhatch (design units)
`l_origin`	origin of xhatch (absolute to board)
`f_angle`	angle of xhatches

©2023 All Rights Reserved.

Arguments

o_polygon/r_path	The outline as an *r_path* from axlPathXXX data structure or an o_polygon from axlPolyXXX interfaces.
l_r_fill	List of fill structures (*r_fill*) for non solid fill shapes or: t → solid fill nil → unfilled
t_layer	Layer name. nil uses the default active layer.
t_netname	Name of net. Only allowed for shapes being added to etch layers.
o_netdbid	Can use *DBID* of net instead of the netname. Same restrictions apply as for *t_netname*.
o_parent	axl *DBID* of the object to add the shape to. Use the symbol instance, or use nil to specify the design itself.

Value Returned

o_shape	axl *DBID* of the shape. AXL-SKILL does not perform DRC on the shape until you close it using axlDBCreateCloseShape.
nil	No shape created.

Notes

- An open shape can have voids added to it. It is not DRC checked or filled, until axlDBCreateCloseShape is called.
- A path starts at startPoint and a segment is created for each segment in the pathList. If the path does not end at the startPoint, it is considered an error.
- A list of o_polygons is not considered valid input. Only a single o_polygon is correct input.
- All path segment coordinates are absolute.
- Only one shape can be in open state at one time.

©2023 All Rights Reserved.

See Also

axlDBActiveShape, axlDBOpenShape, axlDBCreateVoid, axlShapeDeleteVoids, axlDBCreateCloseShape, axlDBCreateRectangle, axlDBCreateShape, axlDBCreateVoidCircle, axlShapeAutoVoid, and axlDBCreateFillet

Example

- Create a shape using rpath

```
path = axlPathStart( list( 0:0 400:000 600:400 400:600 0:0))
shp = axlDBCreateOpenShape(path); defaults to a solid filled shape
                                        ; unless layer allows unfilled only
         ; This is optional unless you are adding a shape to etch
         ; If you do axlDBCreateShape it automatically closes it for you
axlDBCreateCloseShape(car(shp))
```

- Create a shape using a poly

```
p1 = axlPolyFromDB(inElem)
;; add it as an unfilled shape on BOARD GEOMETRY/OUTLINE
res = axlDBCreateShape( car(p1) nil "BOARD GEOMETRY/OUTLINE")
```

- See examples `axldbctshp.il`.

©2023 All Rights Reserved.

axlDBCreateCloseShape

```
axlDBCreateCloseShape(
     o_shape
     [g_forceShape]
     )
     ⇒ l_result/nil
```

Description

Closes the current open shape and applies the fill pattern specified in `axlDBCreateOpenShape`. Then performs DRC. If the fill fails, the function returns `nil`.

Arguments

o_shape	*dbid* of the open shape created by `axlDBCreateOpenShape`.
g_forceShape	By default, Allegro creates a rectangle in its database when an outline is a rectangle. This is for performance and space reasons. To override this behavior, pass the argument value as `t` when closing a shape.
r_fill	Shape can be filled differently then voided. This should only be done with xhatch shapes and should use spacing/width in power of two multiples. We strongly discourage this option. Used in place of g_forceShape.

Value Returned

l_result	List:\(`car`) *dbid* of the shape created. (`cadr`) `t` if DRCs are created. `nil` if DRCs are not created.
`nil`	Nothing was created.

Example

See Create Shape Interface on page 1096 for an example.

©2023 All Rights Reserved.

axlDBActiveShape

```
axlDBActiveShape(
     )
     ⇒ o_shape/nil
```

Description

Returns the *dbid* of the open shape, if any.

Arguments

None.

Value Returned

o_shape	*dbid* of the active shape created by `axlDBCreateOpenShape`.
`nil`	There is no active shape.

Example

See Create Shape Interface on page 1096 for an example.

©2023 All Rights Reserved.

axlDBCreateVoidCircle

```
axlDBCreateVoidCircle(
     o_shape
     l_location
     [f_width]
     )
     ⇒ o_polygon/nil
```

Description

Creates a circular void in the open shape *o_shape*. Calling this function without an open shape causes an error.

Arguments

o_shape	*dbid* of the open shape created by `axlDBCreateOpenShape`.
l_location	Center and radius of the circular void to create. The structure of the argument is: (X:Y R).
f_width	Void edge width used by cross-hatch. Default is 0.

Value Returned

o_polygon	*dbid* of the circular void created.
`nil`	Error due to calling the function without an open shape. No void is created.

Example

See Create Shape Interface on page 1096 for an example.

©2023 All Rights Reserved.

axlDBCreateVoid

```
axlDBCreateVoid(
     o_shape/nil
     r_path/o_polygon
     )
     ⇒ o_polygon/nil
```

Description

Adds a void to a shape. To add multiple voids, it is recommended that you either add the voids when creating the shape (axlDBCreateShape) or re-open the shape (axlDBOpenShape) before creating the voids.

Only certain layers, such as ETCH layer, allow voids in a shape. Use axlOK2Void to determine if shape supports voids. While adding multiple voids to an etch shape, for best performance, first call axlDBOpenShape, add the voids, and then close the shape (axlDBCreateCloseShape).

Unless you want the void to be permanent, do not add voids to dynamic shapes. User added voids on dynamic shapes must be put on the dynamic shape, with class=BOUNDARY, not on the generated shape, class=ETCH.

Arguments

o_shape	*dbid* of the open shape. If this value is `nil`, the command uses the open shape
r_path	Existing path structure created by the `axlPath` functions.

Value Returned

o_polygon	*dbid* of the void created.
`nil`	Error due to calling the function with no open shape.

See Also

axlDBCreateShape, axlDBOpenShape, axlOK2Void, axlDBCreateVoidCircle

©2023 All Rights Reserved.

Example

- Create Shape Example

  See Create Shape Interface on page 1096 for an example.

- Add to existing shape

  See `dbc_shp_t10` function in `axldbctshp.il` example code.

©2023 All Rights Reserved.

axlDBCreateShape

```
axlDBCreateShape(
     o_polygon/r_path
     [l_r_fill]
     [t_layer]
     [t_netName]
     [o_parent]
     )
     ⇒ l_result/nil
```

Description

Takes the same arguments as `axlDBCreateOpenShape` and adds the *`r_path`* shape to the database. The difference is that this function creates the shape and puts it into the closed state immediately, rather than leaving it open for modification. Use `axlDBCreateShape` to add shapes without voids.

`axlDBCreateShape` has the same argument restrictions as `axlDBCreateOpenShape`.

©2023 All Rights Reserved.

ArgumentsZ

o_polygon/r_path	Existing path structure created by `axlPath` functions.
l_r_fill	One of three possible values: `t` → create shape solid filled `nil` → create shape unfilled List of structures specifying crosshatch parameters for creating the shape: `(defstruct axlFill:` (*r_fill*) - shape crosshatch data `origin:` a point anywhere on any xhatch line `width:` width in floatnum user units `spacing:` spacing in floatnum user units `angle):` angle of the parallel lines **Note:** As with all SKILL defstructs, use the constructor function `make_axlFill` to create instances of `axlFill`. Use the copy function `copy_ axlFill` to copy instances of `axlFill`.
t_layer	Layer on which to create the shape.
t_netName	Name of the net to which the shape is to belong.
o_parent	*dbid* of the object to be the parent of the shape. The parent is a symbol instance or is `nil` if the design itself.

Value Returned

l_result	List: (`car`) *dbid* of the shape created (`cadr`) `t` if DRCs are created. `nil` if DRCs are not created.
`nil`	Nothing is created.

Example

See Create Shape Interface on page 1096 for an example.

©2023 All Rights Reserved.

axlDBCreateRectangle

```
axlDBCreateRectangle(
     l_bBox
     [g_fill]
     [t_layer]
     [t_netname]
     [o_parent]
     )
     ⇒ l_result/nil
```

Description

Creates a rectangle with coordinates specified by *l_bBox*. If the rectangle is not created, the function returns `nil`.

If *t_netname* is non-null, the rectangle becomes a member of that net. Ignores *t_netname* if the rectangle is unfilled.

Does not create the rectangle and returns `nil` (error) in these instances:

- Net does not exist.
- Attempt to create a filled rectangle on an Allegro PCB Editor layer requiring an unfilled rectangle.
- Attempt to create an unfilled rectangle on an Allegro PCB Editor layer requiring a filled rectangle.

See axlDBCreateSymbolSkeleton for notes about restrictions on shapes that are part of symbol definitions.

©2023 All Rights Reserved.

Arguments

l_bBox	Bounding box of the rectangle: Lower left and upper right corners of rectangle
g_fill	If `t` then the fill is solid. If `nil` (default) then the rectangle is unfilled. It may have optional line font, with possible values as 'SOLID 'HIDDEN 'PHANTOM 'DOTTED 'CENTER. Line fonts can only be used with unfilled shapes.Only certain Allegro layers support fonted unfilled shapes.
t_layer	Layer to which to add the rectangle. Default is the active layer.
t_netname	Name of net to which the rectangle is to belong. This argument is meaningful only if the rectangle is being added on an Etch layer.
o_parent	*dbid* of object of which the rectangle is to be a part. Use either the *dbid* of a symbol instance or use `nil` to specify the design itself.

Value Returned

l_result	List: (`car`) rectangle *dbid* (`cadr`) `t` if DRCs are created. `nil` if DRCs are not created.
`nil`	Nothing is created.

Example

- Unfilled shape indicated layer

```
axlDBCreateRectangle(list(100:100 200:200) nil "BOARD GEOMETRY/OUTLINE")
```

- Filled shape on active layer

```
axlDBCreateRectangle(list(200:200 400:300) t)
```

- Filled shape on ETCH/TOP assigned to NET_1 using user supplied picks

```
axlDBCreateRectangle( axlEnterBox() t "ETCH/TOP" "GND")
```

- Fonted dotted line shape on indicated layer

```
axlDBCreateRectangle(list(400:100 500:300) 'DOTTED "BOARD GEOMETRY/OUTLINE" )
```


©2023 All Rights Reserved.

axlDBCreateVectorizedEllipse

```
axlDBCreateVectorizedEllipse(
     l_center
     n_radiusA
     n_radiusB
     n_ccwRotationAngleOfEllipse
     n_numSegs
     [g_fill]
     [t_layer]
     [t_netname]
     [o_parent]
     )
     ⇒ l_result/nil
```

Description

Creates a vectorized ellipse at the specified location, with given parameters and number of ellipse segments. If the ellipse is not created, the function returns `nil`.

If *`t_netname`* is non-null, then the ellipse becomes a member of that net. `axlDBCreateVectorizedEllipse` ignores *`t_netname`* if the ellipse is unfilled.

The function does not create the ellipse and returns `nil` (error) in the following instances:

- The net does not exist.
- Attempt to create a filled ellipse on an Allegro PCB Editor layer requiring an unfilled ellipse.
- Attempt to create an unfilled ellipse on an Allegro PCB Editor layer requiring a filled ellipse.

See axlDBCreateSymbolSkeleton on notes about restrictions on shapes that are part of symbol definitions.

©2023 All Rights Reserved.

Arguments

l_center	The location of the center of the ellipse
n_radiusA/ d_radiusB	Half of the axes of the ellipse
n_ccwRotationAngleOfEllipse	Angle by which the ellipse is rotated counterclockwise
n_numSegs	Number of segments to use in creating the ellipse
g_fill	If `t` then fill is solid. If `nil` (default) then the ellipse is unfilled. It may have optional line font, with possible values as 'SOLID 'HIDDEN 'PHANTOM 'DOTTED 'CENTER. Line fonts can only be used with unfilled shapes. Only certain layout editors layers support fonted unfilled shapes.
t_layer	Layer to which to add the ellipse. Default is current active layer.
t_netname	Name of net of which this ellipse is to be a part. This argument is meaningful only if the ellipse is being added on an Etch layer.
o_parent	*dbid* of object of which the ellipse is to be a part. This can be either the *dbid* of a symbol instance or `nil` for the design itself.

Value Returned

`l_result/nil`	`nil` if nothing was created. Otherwise it returns `l_result`
`list`	List: ■ `* (car)` ellipse *dbid* ■ `* (cadr) t` if DRCs created. Otherwise returns `nil`

Example

■ Unfilled shape indicated layer

```
axlDBCreateVectorizedEllipse(100:100, 100, 55, 0, 22, nil "BOARD GEOMETRY/
OUTLINE")
```

■ Filled shape on active layer

```
axlDBCreateVectorizedEllipse(100:100, 100, 55, 0, 14, t)
```


©2023 All Rights Reserved.

- Filled shape on ETCH/TOP assigned to NET_1 using user supplied picks

```
axlDBCreateVectorizedEllipse( 100:100 100.0 55.0 0.0 14 t "ETCH/TOP")
```


©2023 All Rights Reserved.

Nonpath DBCreate Functions

This section describes the `DBCreate` functions that add nonpath figures to the Allegro PCB Editor database.

axlCreateBondFinger

```
axlCreateBondFinger(
     parentSymbol
     fingerName
     list(fingerLocation fingerRotation fingerPadstack)
     list(placementStyle ewlLength fingerSnap fingerAlign)
     )
     ==> dbid/nil
```

Description

This function adds a valid, fully-instantiated bond finger to the database. Bond fingers created through this interface can be safely manipulated by the wirebond toolset and will also be properly recognized by all aspects of the database (DRC, signal integrity, 3D viewer, and so on).

Arguments

parentSymbol	dbid of the symbol (generally a die) with which this finger should be associated when performing operations like a move or delete.
fingerName	The optional parameter that specifies the name of the bond finger, as stored in the BOND_PAD property.
fingerLocation Rotation Padstack	The physical information about the bond finger being creation, the location is a database coordinate point, the rotation and angle in degrees, and the padstack the dbid of a padstack to use.
placementStyle/ewlLength/ fingerSnap/fingerAlign	The placement data for the bond finger being created, as follows:

©2023 All Rights Reserved.

placementStyle	String value in the following list: ■ Orthogonal ■ Equal Wire Length ■ On Path ■ Free Placement
ewlLength	Length value for Equal Wire Length style, which represents the desired length of the wire.
fingerSnap	String value in the following list: ■ Center of Finger ■ Finger Origin ■ Near End ■ Far End ■ Nearest Point ■ Farthest Point
fingerAlign	String value in the following list: ■ Aligned with Wire ■ Orthogonal to Die Side ■ Orthogonal to Guide ■ Pivoting Ortho to Guide ■ Average Wire Angle ■ Constant Angle ■ Match CW Neighbor ■ Match CCW Neighbor

Value Returned

- `dbid` of newly created bond finger if successful.
- `nil` if an error occurred (message printed to status window).

©2023 All Rights Reserved.

axlCreateBondWire

```
axlCreateBondWire(
     parentSymbol
     list(wireStartOwner wireStartLocation)
     list(wireEndOwner wireEndLocation)
     list(wireDiameter wireProfile)
     )
     ==>dbidt/nil
```

Description

This function adds a valid, fully-instantiated bond wire to the database. Bond wires created through this interface can be safely manipulated by the wirebond toolset and will also be properly recognized by all aspects of the database (DRC, signal integrity, 3D viewer, etc).

Arguments

parentSymbol	dbid of the symbol (generally a die) with which this wire should be associated when performing operations like a move or delete.
wireStartOwner/Location	Optional. This is a list with the first item being, the dbid of the object to which the start of the wire attaches. If this object is a pin or finger, the location will be derived from the object's origin. If the object is a shape, you must pass the location for the connection as well.
wireEndOwner/Location	- This is a list with the first item being, the dbid of the object to which the end of the wire attaches. If this object is a pin or finger, the location will be derived from the object's origin. If the object is a shape, you must pass the location for the connection as well.
wireDiameter/Profile	- This list of two items describes the physical placement of the wire in terms of its 3D profile (a string) and the wire diameter (a number).

©2023 All Rights Reserved.

Value Returned

- dbid of newly created bond wire if successful.
- nil if an error occurred (message printed to status window).

©2023 All Rights Reserved.

axlDBCreateExternalDRC

```
axlDBCreateExternalDRC(
     t_constraint/lt_constraint
     l_anchor_point
     t_layer
     [lo_dbid]
     [l_secondPoint]
     [t_actualValue]
     )
     ⇒ l_result/nil
```

Description

Creates an externally-defined (by user) DRC containing the values given in the arguments. An externally defined DRC marker always has the two characters “X D” in it.

You may pass the constraint as the traditional argument (*t_constraint*) where this contains both the constraint and expected value in a one string. The downside of this method is that the `show element` and `reports` commands report 0 for the expected value. Alternatively, you can pass it as a list containing two strings: constraint name and expected value. This format reports properly in both the `show element` and `reports` commands.

The *t_actualValue* argument is optional and provides an externally-defined actual value with the DRC in design units.

In show element:

SKILL Item	Show Element	Comments
l_anchorPoint	Origin xy	Required Value
t_constraint	Constraint set	Required Value

©2023 All Rights Reserved.

SKILL Item	Show Element	Comments
t_type	Constraint Type	default "EXTERNAL REFERENCE"
t_expectValue	Constraint value	default "None"
t_actualValue	Actual Value	default "None"

Property mapping

`t_expectValue`	EXTERNAL_DRC_VALUE

Note: Attempting to create a DRC object on a non-DRC class is an error.You can use this function in the layout editor, but not in the symbol editor.

Tip

`t_type` can be used to group similar DRCs. You might give all of your company written DRC checks your company name.

©2023 All Rights Reserved.

Arguments

t_constraint	Name of the violated constraint. String contains the type of constraint and the required value and comparison.
lt_constraint	Alternative method. It is a list of (t_constraint t_expectValue)
l_anchor_point	Coordinate of the DRC marker.
t_layer	Layer of the DRC marker. This must either include the DRC error class or just the subclass name.
lo_dbid	Optional list of the objects that caused the DRC (maximum of two).
l_secondPoint	Second reference point. This is a coordinate on the object of the DRC pair that does not have the DRC marker on it. Using this point, you can identify the second object involved in causing the DRC by reading the DRC data in later processes.
t_actualValue	Actual value that caused the DRC.

Value Returned

l_result	List: (car) *dbid* of the DRC created (always only one) (cadr) `t` (always) (in future, `t` if DRC is new, else `nil` if DRC existed already)
`nil`	Nothing is created.

Example

Creates a user-defined DRC marker at x,y (1500, 1800) to mark a violation of user rule: `"Line to Pin--MY SPACING RULE"` with a required value of 12 and an actual value of 10.

- Original method:

```
axlDBCreateExternalDRC( "MY Spacing Line to Pin/req:12" 1500:1800 "drc
error calss/top", nil, nil, "10 MILS")
```

- New method for better `show element` and `reports` command behavior:

```
axlDBCreateExternalDRC('("My Spacing Line to Pin" "12")
         1500:1900 "top", nil nil "10 MILS")
```

- Name classification

©2023 All Rights Reserved.

```
axlDBCreateExternalDRC(
     '("My Spacing Line to Pin" "12" "Cadence")
     1500:2000 "top", nil nil "10 MILS")
```

Adds "X D" DRC markers at (1500 1800) and (1500 1900).

The DRC marker displays the following information with the `show element` command:

```
LISTING: 1 element(s)
< DRC ERROR >
Class: DRC ERROR CLASS
    Subclass: ALL
    Origin xy: (1500,1800)
CONSTRAINT: Externally Determined Violation
    CONSTRAINT SET: NONE
    CONSTRAINT TYPE: LAYOUT
    Constraint value: 0 MIL
    Actual value: 10 MILS
Properties attached to drc error
    EXTERNAL_VIOLATION_DESCRIPTION = Line to Pin--MY SPACING
    RULE/req:12; actual:10
 - - - - - - - - - - - - - - - - - - -
```


©2023 All Rights Reserved.

axlDBCreateFillet

```
axlDBCreateFillet(
     o_polygon/r_path
     t_layer
     o_filletObject
     )
     ⇒ l_result/nil
```

Description

Adds a fillet shape to the object.

See axlDBCreateOpenShape for description of the first argument.

The provided shape must touch the connect point of the parent object.

Tees cannot be directly selected. You must select a cline that it is connected and use axlDBGetConnect (basic mode) to find the Tee of interest. The cline may have a Tee on either end.

Typical reasons for failure to create a fillet are:

- The object must exist on the layer (in case of vias or pins it must span the object).
- It must touch or overlap the connect point of the object.
- The cline must not be a thermal.

Notes

- To delete a fillet use axlDeleteFillet.
- Fillets are automatically removed if the fillet object is modified.
- If adding multiple fillets use `axlDBCloak`.
- Fillets created with this API will be reported as fillets throughout Allegro.
- Fillets may cause DRCs.
- The partial fillet type is not supported.
- Fillets cannot be added in symbol editor.
- Additional info on failures may be returned by setting `axlDebug(t)`

©2023 All Rights Reserved.

Arguments

o_polygon/r_path	The outline as an r_path from axlPathXXX data structure or an o_polygon from axlPolyXXX interfaces.
t_layer	Layer name. Must be an etch layer and the parent object must exist on that layer.
o_filletObject	axl DBID of object to add the Fillet. Must be a Via, Pin or Tee.

Value Returned

`l_result/nil`	`nil` if not created, or a list containing (car) axl DBID of the shape (cadr) t if DRCs created or nil.

See Also

axlDBCreateOpenShape, axlDBGetConnect, axlDeleteFillet.

©2023 All Rights Reserved.

axlDBCreatePin

```
axlDBCreatePin(
     t_padstack/o_padstackDbid
     l_anchorPoint
     r_pinText/nil
     [f_rotation]
     )
     ⇒ l_result/nil
```

Description

Adds a pin with padstack *t_padstack*, pin name *r_pinText* at location *l_anchorPoint*, and rotated by *f_rotation* degrees.

Notes:

1) This interface may only be used in the Symbol Editor.

2) Use `axlDBCreatePin` only in package and mechanical symbol drawings. Creating a pin in any other type of drawing causes errors.

3) Use *nil* for *r_pinText* to create a mechanical pin.

Arguments

t_padstack	Padstack name for the via. If a padstack definition with this name is not already in the layout, the function searches in order the libraries specified by `PADPATH` and loads the definition into the database.
o_padstackDbid	a padstack dbid
l_anchorPoint	Layout coordinates of the location to add the pin.

©2023 All Rights Reserved.

r_pinText Pin number text structure:

```
(defstruct axlPinText ;(r_pinText) - pin number
text data

number ;pin number as a text string

offset ;offset (X:Y) for pin number text

text) ;textOrientation - ;for positioning text
```

This requires the axlTextOrientation structure:

```
defstruct axlTextOrientation

;(r_textOrientation) - description of the
orientation of text textBlock

;string - text block name

rotation ;rotation in floatnum degrees

mirrored ;t-->mirrored, nil --> not mirrored


;`GEOMETRY --> only geometry is mirrored

justify) ;"left", "center", "right"
```

Note: As with all SKILL defstructs, use constructor functions `make_axlPinText` to create instances of `axlPinText` and `make_axlTextOrientation` for `axlTextOrientation`.

See Create Shape Interface on page 1096 for an example. Use copy functions `copy_axlPinText` to copy instances of `axlPinText` and `copy_axlTextOrientation` for `axlTextOrientation`.

f_rotation Rotation of pin in degrees.

©2023 All Rights Reserved.

Value Returned

l_result	List:
	(car) *dbid* of the pin
	(cadr) t if DRCs are created. nil if DRCs are not created.
nil	Nothing is created.

Example

- The following example adds pins "1", "2", "3", and a mechanical to a package symbol drawing. Pin "1" with a square pad is rotated 45 degrees, pins "2" and "3" with round pads, and pin "3" with its pin text mirrored.

```
mytext = make_axlTextOrientation(
                                ?textBlock 6, ?rotation 60.0
                                ?mirrored nil ?justify "center")
         mypin = make_axlPinText(?number "1",
                                ?offset 0:75, ?text mytext)
         axlDBCreatePin( "pad1" 0:0 mypin 45.0)
    mytext->justify = "left"
         mytext->rotation = 0.0
         mypin->number = 2
         mypin->offset = -125:0
         axlDBCreatePin( "pad0" -100:-100 mypin)
    mytext->rotation = -45.0
         mytext->justify = "right"
         mytext->mirror = t
         mypin->number = 3
         mypin->offset = 50:0
         axlDBCreatePin( "pad0" 100:-100 mypin)
    mypin->mytext = nil
         axlDBCreatePin( "pad0" 100:100 mypin)
```


©2023 All Rights Reserved.

Adds the three pins in the positions shown:

- 2) Create 8 pins using a loop

```
            x=1000.0
            y=1000.0

            myText = make_axlTextOrientation(?textBlock 6
                          ?justify "center")
            myPin= make_axlPinText(?offset 0:0 ?text myText)

            for(i 1 8
                y=y-100
                sprintf(buf "a%d" i)
                myPin->number = buf
                axlDBCreatePin("VIA" x:y myPin)
            )
)
```


©2023 All Rights Reserved.

axlDBCreateSymbol

```
axlDBCreateSymbol(
     t_refdes
     l_anchorPoint
     [g_mirror]
     [f_rotation]
     [t_embeddedLayer]
     )
     ⇒ l_result/nil
```

```
axlDBCreateSymbol(
     l_symbolData
     l_anchorPoint
     [g_mirror]
     [f_rotation]
     [t_embeddedLayer]
     )
     ⇒ l_result/nil
```

Description

Places a symbol instance in the design. Creates a symbol instance at location `l_anchor_point` with the given mirror and rotation. Examines its first argument to determine what symbol to add, as explained later. Next, searches for the symbol in the symbol definitions, first in the layout, then in the `PSMPATH`. Loads the definition if it is not already in the layout and creates the symbol instance. Returns `nil` a symbol definition is not found.

Note: Do not use this function in the symbol editor.

Arguments

The first argument can be either *`t_refdes`* or *`l_symbolData`*, as described here:

`t_refdes` Reference designator of the component. If this is the first argument, the function looks for a component in the layout with that refdes, finds the package symbol required for its component device type, adds a package symbol with the symbol name prescribed by the component definition, and assigns that refdes to the symbol (example, refdes U1 requires a `DIP14` package symbol). Returns `nil` if it cannot find the given refdes.

©2023 All Rights Reserved.

l_symbolData If this is the first argument, the function looks for the symbol, symbol type, and refdes specified by this structure.

l_*symbolData* is a list (t_symbolName [[*t_symbolType* [*t_refdes*]]), where:

t_symbolName is the name of the symbol (example: `DIP14`)

t_symbolType is a symbol type: `"PACKAGE"` (default),`"MECHANICAL"` or `"FORMAT"`

t_refdes is an optional refdes; if *t_refdes* is present,

t_symbolType must be `"PACKAGE"`.

An example is the list: ("`DIP16`" "`package`" "`U6`")

To create a component with an alternate symbol, that is, a symbol different from the one specified in the component library, use the *l_symbolData* structure. For example, refdes `C7` might be a capacitor requiring the top-mount package "`CAP1206F`". However, your design requires the alternative package "`CAP1206B`" on the bottom side of the layout.

To create the component mirrored, use `axlDBCreateSymbol` with the *l_symbolData* argument:

```
"CAP1206B" "package" "C7")
```

t_refdes Reference designator of the component associated with the symbol to be created.

l_symbolData List (*t_symbolName* [[*t_symbolType* [*t_refdes*]]). (See example above.)

l_anchorPoint Layout coordinates specifying where to create the symbol.

g_mirror `nil` - create unmirrored. (default)

`t` - create symbol mirrored.

`'GEOMETRY` - geometry is mirrored.

f_rotation Rotation of the symbol in degrees.(default is 0)

©2023 All Rights Reserved.

t_embeddedLayer	Place on embedded layer. Layer must be enabled for embedded. Mirror option is ignored. Layer may either be fully qualified ("ETCH/GND") or just the subclass ("GND"). May not use the top or bottom layer.

Value Returned

`nil`	Nothing is created.
`l_result`	a list containing: (`car`) axl *DBID* of the symbol created (`cadr`) `t` if DRCs are created. `nil` if DRCs are not created.

Note: The symbol definition in the drawing is used. If there is none in the drawing, then the symbol library is searched and the definition loaded.

Example

```
axlDBCreateSymbol("y29", 5600:4600)
    ⇒(dbid:423143 nil)
```

Creates a symbol with the assigned refdes.

```
axlDBCreateSymbol( list( "dip14" "package"), 5600:4600)
    ⇒(dbid:423144 nil)
```


©2023 All Rights Reserved.

Creates a symbol with the unassigned refdes, just the generic U*:

- Typical component driven symbol placement:

```
p = axlDBCreateSymbol("U1" 2175:1000)
```

- Place an embedded component. Assumes a layer, SIGNAL_2 is enabled for embedded.

```
p = axlDBCreateSymbol("R1" 2175:1000 nil nil "SIGNAL_2")
```

- Place non-logical package symbol with rotation of 90

```
p = axlDBCreateSymbol('("R_0402" "PACKAGE") 2000:800.1 nil 90.0)
```


©2023 All Rights Reserved.

axlDBCreateSymbolSkeleton

```
axlDBCreateSymbolSkeleton(
     t_refdes
     l_anchorPoint
     g_mirror
     f_rotation
     l_pinData
     [t_embeddedLayer]
     )
     ⇒ l_result/nil
```

or

```
axlDBCreateSymbolSkeleton(
     l_symbolData
     l_anchorPoint
     g_mirror
     f_rotation
     l_pinData
     [t_embeddedLayer]
     )
     ⇒ l_result/nil
```

Description

Places a skeleton or a minimal symbol instance at `l_anchorPoint` with mirror and rotation given but no data in the instance, except the pin data given by *`l_pinData`*. This is a list of `axlPinData` defstructs defining the data for all pins. The pin count and pin numbers must match that of the library symbol definition. The symbol definition must exist in the database or on `LIBPATH`.

Behaves like `axlDBCreateSymbol`, except that it adds no symbol data except the symbol pins in the instance. Use to create the “foundation” of a symbol. Then build, using `axlDBCreate` functions to add lines, shapes, polygons, and text as required.

Use, for example, to construct symbols when translated from other CAD systems that define symbol instances in different ways than Allegro PCB Editor.

AXL-SKILL applies each `axlPinData` instance in *`l_pinData`* only to the pin specified by its *number*. (See the description of the *`l_pinData`* argument below.) A `nil` value for *`l_pinData`* means `axlDBCreateSkeleton` adds the pins as they are in the library definition of the symbol. You can selectively customize none, one, or any number of the pins of the symbol instance you create.

Note: Do not use this function in the symbol editor.

©2023 All Rights Reserved.

Caution

This function is intended for programmers with a high level of knowledge of the Allegro PCB Editor database model. It provides a powerful method for creating symbols within Allegro PCB Editor. Although you can use this command to create non-conventional symbols, the rest of Allegro PCB Editor may not behave as you expect. To ensure a symbol behaves as a conventional symbol, you must ensure that what you create abides by symbol rules. For example, you can create a symbol with no attached graphics. Allegro PCB Editor's Find utility will not be able to find it. Another programmer may use this feature to create a temporary symbol instance as a placeholder.

Through interaction, the user changes this symbol into a conventional Allegro PCB Editor symbol.

Arguments

The first argument may be either `t_refdes` or `l_symbolData`, as described here:

`t_refdes`	If this is the first argument, the function looks for a component in the layout with that refdes, finds the package symbol required for its component device type, adds a package symbol with the symbol name prescribed by the component definition, and assigns that refdes to the symbol (example, refdes `U1` requires a `DIP14` package symbol). Returns nil if it cannot find the given refdes.

©2023 All Rights Reserved.

l_symbolData If this is the first argument, the function looks for the symbol, symbol type, and refdes specified by this structure.

l_symbolData is a list

(*t_symbolName* [[*t_symbolType* [*t_refdes*]]), where:

t_symbolName is the name of the symbol (example: DIP14)

t_symbolType is a symbol type: "PACKAGE" (default), "MECHANICAL" or "FORMAT"

t_refdes is a refdes; if *t_refdes* is present, *t_symbolType* must be "package"

Example of a list: ("DIP16" "package" "U6").

To create a component with an alternate symbol, a symbol different from the one specified in the component library, use the *l_symbolData* structure.

For example, refdes C7 is a capacitor requiring the top-mount package "CAP1206F". Your design requires the alternative package "CAP1206B" on the bottom side of the layout.

To create the component mirrored, use axlDBCreateSymbol with the *l_symbolData* argument:

```
"CAP1206B" "package" "C7")
```

l_anchorPoint Layout coordinates of the location to create the symbol. This will be the origin of the symbol.

g_mirror nil - create unmirrored (default).

t - create symbol mirrored.

'GEOMETRY - geometry is mirrored.

f_rotation Rotation angle of the symbol in degrees.

nil - 0.0.

©2023 All Rights Reserved.

l_pinData List of axlPinData defstructs for any pins you require to be different from their library definition, as shown below:

```
(defstruct axlPinData;(r_pinData) - pin data
number ;pin number as a text string
padstack ;padstack for the pin (text string)
origin ;relative location (X Y) of the pin
rotation) ;relative rotation of pin in degrees
```

Note: As with all SKILL defstructs, use the constructor function make_axlPinData to create instances of axlPinData. Use the copy function copy_axlPinData to copy instances of axlPinData.

t_embeddedLayer Place on embedded layer. Layer must be enabled for embedded. Mirror option is ignored. Layer may either be fully qualified ("ETCH/GND") or just the subclass ("GND"). May not use the top or bottom layer.

Value Returned

l_result `nil` – Nothing is created.

List Containing the following:

(`car`) axl *DBID* of the symbol created

(`cadr`) `t` if DRCs are created. `nil` if DRCs are not created.

Example

```
mypins = list( make_axlPinData( ?number "2",
    ?padstack "pad1", ?origin -100:-100 ?rotation 45)
make_axlPinData( ?number "4", ?padstack "pad1",
    ?origin -100:-300 ?rotation 45)
make_axlPinData( ?number "6", ?padstack "pad1",
    ?origin -100:-500 ?rotation 45)
make_axlPinData( ?number "9", ?padstack "pad1",
    ?origin 200:-500 ?rotation 45)
make_axlPinData( ?number "11", ?padstack "pad1",
    ?origin 200:-300 ?rotation 45)
make_axlPinData( ?number "13", ?padstack "pad1",
    ?origin 200:-100 ?rotation 45))

axlDBCreateSymbolSkeleton( list("dip14"),
    5600:4600, nil, 0, mypins)
            fi (dbid:426743 nil)
```


©2023 All Rights Reserved.

Adds a DIP14 symbol with all even-numbered pins having the same padstack as pin 1, rotated 45 °, and offset -100 mils.

Library symbol

Skeleton symbol created by code sample above

©2023 All Rights Reserved.

axlDBCreateText

```
axlDBCreateText(
     t_text
     l_anchorPoint
     r_textOrientation
     [t_layer]
     [o_attach]
     )
     ⇒ l_result/nil
```

Description

Creates a text string in the layout using the arguments described.

Arguments

t_text Text string to add. `axlDBCreateText` accepts newlines embedded in the text. Each newline causes the function to create a new text line as a separate database object. The function returns the *dbids* of all text lines it creates. The textBlock parameter block specified in the `axlTextOrientation` structure specifies spacing between multiple text lines.

l_anchorPoint Layout coordinates of the location to add the text.

©2023 All Rights Reserved.

r_textOrientation *axlTextOrientation* structure:

```
defstruct axlTextOrientation
;;(r_textOrientation) - description of
;; the orientation of text
textBlock ;string - text block name
rotation ;rotation in floatnum degrees
mirrored ;t-->mirrored, nil --> not mirrored,
'GEOMETRY --> only geometry is mirrored
justify) ;"left", "center", "right"
```

Note: As with all SKILL defstructs, use the constructor function `make_axlTextOrientation` to create instances of `axlTextOrientation`. Use the copy function `copy_axlTextOrientation` to copy instances of `axlTextOrientation`.

t_layer Name of the layer on which the text is to be added.

o_attach `DBID` of the object to which the text must be attached, or use `nil` for the design.

Value Returned

l_result Otherwise the function returns a list:

(`car`) list of text *DBIDs* created, one for each line of text input

(`cadr`) `t` if DRCs are created. Otherwise the function returns `nil`.

`nil` Nothing is created.

Notes:

- If *o_attach* is a symbol instance, then the text is “stand alone”, but a child of the symbol instance.
- If the *t_text* string contains NEWLINEs, then multiple text records will be created (and multiple *DBIDs* returned).

©2023 All Rights Reserved.

See Also

axlTextOrientationCopy, axlDBChangeText

Example

The following example adds the e text string “Chamfer both sides” center justified, mirrored and rotated 60 degrees.

```
myorient = make_axlTextOrientation(?textBlock "8", ?rotation 60.0,
                                   ?mirrored t, ?justify "center")
         ret = axlDBCreateText( "Chamfer both sides", 7600:4600,
                                   myorient, "board geometry/plating_bar", nil)
                 ==> (dbid:526743 nil)
```

Adds the text string “`Chamfer both sides`” center justified, mirrored and rotated 60°.

©2023 All Rights Reserved.

axlDBCreateVia

```
axlDBCreateVia(
     t_padstack/o_padstackDbid
     l_anchorPoint
     [t_netName]
     [g_mirror]
     [f_rotation]
     [o_parent]
     )
     ⇒ l_result/nil
```

Description

Creates a via in the layout as specified by the arguments described below.

©2023 All Rights Reserved.

Arguments

t_padstack	Padstack name for the via. If a padstack definition with this name is not already in the layout, the function searches in order the libraries specified by `PADPATH` and loads the definition into the database.
`o_padstackDbid`	A padstack dbid
l_anchorPoint	Layout coordinates of the location to create the via.
t_netName	Name of the net to which the via is to belong;
	`nil` → via is stand-alone.
g_mirror	`t` → create mirrored via.
	`nil` → create unmirrored via.
	`'GEOMETRY` → only via geometry is mirrored. Via layers are not mirrored
	`'LAYERS` → only via layers are mirrored. Via geometry is not mirrored.
f_rotation	Rotation angle of via in degrees.
o_parent	axl DBID of the object to which to attach the via. Use a symbol instance or use `nil` to specify the design itself.

Value Returned

l_result	List:
	(`car`) axl *DBID* of the via created.
	(`cadr`) `t` if DRCs are created.
	`nil` if DRCs are not created.
`nil`	Nothing is created.

Note:

`axlDBCreateVia` cannot create a test point. You have to create testpoints by using the `axlTestPoint` function.

©2023 All Rights Reserved.

Example

```
myvia = axlDBCreateVia( "pad1", 5600:4200,
    "sclkl", t, 45.0, nil)
    ⇒ (dbid:526745 nil)
```

Adds a standalone via using padstack "`pad1`" at x5600 y4200 on net "`sclkl`", mirrored and rotated. Adds a via rotated at 45 degrees:

©2023 All Rights Reserved.

axlDBCreateSymbolAutosilk

```
axlDBCreateSymbolAutosilk(
     o_symbol
     )
     ⇒ t/nil
```

Description

Creates or updates the `AUTOSILK` information for the specified symbol, as required. Also updates, as required, any other `AUTOSILK` information near the symbol.

Arguments

o_symbol	*dbid* of the symbol.

Value Returned

`t`	A valid symbol *dbid* is provided.
`nil`	The *dbid* provided is not for a valid symbol.

©2023 All Rights Reserved.

axlDBCreateViaStructure

```
axlDBCreateViaStructure(
     t_refdes/o_vsDbid
     l_anchorPoint
     [t_netName/o_netDbid]
     [g_mirror]
     [f_rotation]
     [g_snapFlag]
     )
     ==> l_result/nil
```

Description

Verify arguments and add the structure instance with specified parameters in the design. Check out the Allegro database id.

Arguments

t_refdes	Structure symbol name
o_vsDbid	Structure symbol reference
t_netName	Return path net name
o_netDbid	Return path net reference
l_anchorPoint	The location of the structure
g_mirror	■ `nil`: not (default) ■ `t`: Structure is mirrored
f_rotation	The rotation angle in degrees (default is 0 degree)
g_snapToLocation	Specifies if structure needs to be snapped to an object at location assuming it shares common layer (snaps to pin, via, dangling cline). In case of snapping structure inherits connectivity from snapped object. ■ `nil`: Structure is not snapped (default) ■ `t`: Structure is snapped

©2023 All Rights Reserved.

Value Returned

`l_result`	List:
	(car) list of DBID of all symbols created
	(cadr) `t` if DRCs are created or `nil`
`nil`	if not created

Examples

- Typical structure placement:

```
p = axlDBCreateViaStructure("VS1" 2175:1000)
```

- Place high-speed via structure with return path

```
p = axlDBCreateViaStructure("VS2" 2175:1000 "Vss")
```

- Place standard via structure with rotation on 90 and snapping

```
p = axlDBCreateViaStructure("VS3" 2000:800 nil nil 90.0 t)
```


©2023 All Rights Reserved.

axlCreateWirebondGuide

```
axlCreateWirebondGuide(
     r_path
     )
     ==> dbid/nil
```

Description

This function adds a wirebond guide path into the design, which can then be used to snap fingers through the wirebond tools.

Arguments

`r_path`	Existing path consisting of the straight-line and arc segments previously created by axlPath functions

Value Returned

- dbid of newly created guide path if successful.
- nil if an error occurred (message printed to status window).

©2023 All Rights Reserved.

axlZoneCreate

```
axlZoneCreate(
     t_name
     o_dbidOutline
     )==> o_zoneDbid/nil
```

Description

Creates a zone with the name *t_name* and with *o_dbidOutline*. Should use the `axlZoneAccess` API to trim the zone outline and associated shapes to the design and zone outlines. The behavior of Allegro PCB Editor is undefined if zone shapes overlap the design outline or other zone shapes.

Recommended steps to create a zone:

- Create zone outline shape on RIGID_FLEX/ZONE_OUTLINE class and subclass
- Create a zone using `axlZoneCreate`
- Set the characteristics including the associated stackup using axlZoneAccess
- Trim the zone shapes using axlZoneAccess

Side effects:

- DRC is marked out of date
- Creates attached text with zone name
- Outline cannot be modified or deleted
- Zone allows full placement

Arguments

t_name	Name of zone
o_dbidOutline	Outline (shape) on class==RIGID_FLEX and subclass==ZONE_OUTLINE

©2023 All Rights Reserved.

Value Returned

`t`	If successful
`nil`	If failed

See Also

axlZoneSet, axlZoneDelete, axlZoneAccess

`axlDBGetDesign()->zone` returns a list of all zones of a design.

Example

Create a zone (assumes a shape (dbid) exists) on class==RIGID_FLEX and subclass==ZONE_OUTLINE

```
axlDBCreateZone("MY_ZONE" shape)
```


©2023 All Rights Reserved.

Property Functions

This section describes the `DBCreate` functions you use to create your own (user-defined) property definitions, and add properties to database objects.

axlDBCreatePropDictEntry

```
axlDBCreatePropDictEntry(
     t_name
     t_type
     lt_objects/t
     [ln_range]
     [t_units]
     [g_hidden])
     )
     ⇒ od_propDictEntry/nil
```

```
axlDBCreatePropDictEntry(
     nil
     )
     ==> lt_availbeObject
```

Description

Creates an Allegro user-defined property dictionary entry with given attributes. Once a dictionary entry is created, the property can then be attached to objects.

STRING property values are limited to 1024. STRING_ID allows property values up to 4096. STRING_ID is not currently supported in "define property" dialog of Allegro PCB Editor.

If you need to store larger data within the database, use attachments (axlCreateAttachment).

©2023 All Rights Reserved.

Arguments

t_name	Name of the property. Must be different from all other property names in the design, both Allegro PCB Editor pre-defined and user-defined property names.
t_type	Data type of the property value. Legal values are: Typical: BOOLEAN, INTEGER, REAL, STRING, and DESIGN_UNITS. Other supported types are: ALTITUDE CAPACITANCE DISTANCE ELEC_CONDUCTIVITY FAILURE_RATE IMPEDANCE INDUCTANCE LAYER_THICKNESS NAME NOISE_VOLTAGE PERCENTAGE PROP_DELAY RESISTANCE TEMPERATURE THERM_CONDUCTANCE THERM_CONDUCTIVITY THERM_RESISTANCE VOLTAGE VELOCITY STRING_ID

©2023 All Rights Reserved.

lt_objects	List of strings representing the object types to which this property can be added. (Use `axlDBGetPropDictEntry` (`nil`) to get a list of valid objects). If only a single object type is allowed, then it may be specified as a string, rather than a list containing one string. If this value is t then all allowed properties are allowed.
ln_range	List of the lowest and highest legal values for the (numeric) property. If the first value is `nil`, it means negative infinitely. If the second value is `nil`, it means infinity.
t_units	A text string so be used with data types (*t_type*) without units, such as `STRING`, `INTEGER`, or `REAL`.
g_hidden	*t* property is hidden from the user. Hidden properties are not shown in any Allegro UI like Constraint Manager, Show Element or Property Edit. Hidden properties can be accessed via SKILL. Typically, properties are hidden if they are only meant to be changed outside of the SKILL program. Hidden properties are also visible via `extracta`.

Value Returned

o_propDictEntry	*DBID* of the property dictionary entry created.
`nil`	Property not created.

See Also

axlDBAddProp, axlCreateAttachment

Example

- Add a new property of type string, supported on db objects

```
propDoct = axlDBCreatePropDictEntry("ACME" "STRING" t)
```

- Create `MYPROP` as a real number property with range -50 to 100 units of `"level"`, attachable to pins, nets, and symbols.

```
axlDBCreatePropDictEntry( "myprop", "real", list( "pins" "nets" "symbols"),
list( -50. 100), "level")
```

```
propDict:2421543
```


©2023 All Rights Reserved.

To check

1. From Allegro PCB Editor, select *Setup – Property Definitions*.

   The Define User Properties window appears.

2. Select *MYPROP* from the Available Properties list.

©2023 All Rights Reserved.

axlDBAddProp

```
axlDBAddProp(
     lo_attach
     ll_name_value
     )
     ⇒ l_result/nil
```

Description

Adds the property/value pairs listed in *ll_name_value* to the object database DBIDs listed in *lo_attach*. If an object does not accept a property name in *ll_name_value*, `axlDBAddProp` ignores that combination, and continues. If an object already has the specific property attached, `axlDBAddProp` replaces its original value with the one specified in *ll_name_value*.

If any errors occur or if `axlDBAddProp` has not added or changed any properties, the function returns `nil`.

©2023 All Rights Reserved.

Arguments

lo_attach	List of Allegro PCB Editor object dbids to which the property/value combinations listed in *ll_name_value* is to be added. A list of `nil` denotes attachment to the design *(list* `nil`*)*. However, if *lo_attach* is `nil`, there are no objects for attachment, and `axlDBAddProp` does nothing, returning `nil`.

©2023 All Rights Reserved.

ll_name_value

List of property-name/property-value pairs. If the first element of the list is not a list, `axlDBAddProp` treats *`ll_name_value`* as a single name-value list and assigns the value to the property of that name.

The first element of each name-value pair is the property name as a string. The second element of the name-value list is the property value. The property value is either a string with or without units included, or a simple value (fixed or floating number). In either case, if units are not included explicitly, `axlDBAddProp` uses the units specified in the system `units.dat` file.

A BOOLEAN property has no value, the property either exists on the object or it does not. `axlDBAddProp` ignores the value for a BOOLEAN property and simply adds the property to the object. If you query the value of a BOOLEAN property it will return t if the property exists. You can call `axlDBAddProp` for a BOOLEAN property with the name of the property; for example, `(list "fixed")`.

Caution

Calling `axlDBAddProp` ***for a BOOLEAN property and passing the value*** `nil` ***will still add the property to the object. For example,*** `axlDBAddProp('(dbid) '("fixed" nil))` ***will add the fixed property to the object. If you query the value of "***`fixed`***" on that object later, it will return a value of*** `t` ***to indicate that the property exists, even though the originally specified value was*** `nil`***. To make a BOOLEAN property query return*** `nil`***, use*** `axlDBDeleteProp` ***to remove the property from the object. STRING type properties allow the value to be set to*** `t` ***or*** `nil`***, even though those are not string values.*** `t` ***is an alias for the string "TRUE", while*** `nil` ***is an alias for the string "FALSE". For example,*** `axlDBAddProp((list nil) (list "COMMENT" t))` ***will add a COMMENT property to the design object with the value "TRUE". Trying to set any other property type to*** `t` ***or*** `nil` ***will produce an error.***

©2023 All Rights Reserved.

Caution

Even though STRING properties support setting the value to "TRUE" or "FALSE", Cadence strongly recommends against using a STRING property to represent BOOLEAN values. STRING type properties are slower to access and test than BOOLEAN properties and require more storage in the database. Therefore, using STRING properties to store BOOLEAN values can lead to performance problems.

Value Returned

`l_result`	List: (`first element`) list of *`dbids`* of objects with at least one property successfully added (`second element`) always `nil`.
`nil`	No properties are added.

See Also

axlDBDeleteProp, `axlDBCreatePropDictEntry` axlDBGetPropDictEntry axlDBGetProperties, axlDBDeletePropAll, axlDBDeletePropDictEntry, and axlDBGetPropDict

Example

see axlDBDeleteProp

©2023 All Rights Reserved.

The Show Element window appears with the MYPROP value at `23.500000 level.`

User-defined property MYPROP attached to net ENA2

©2023 All Rights Reserved.

Load and Save Functions

This section describes the *Load* functions that add external objects to the Allegro PCB Editor database.

axlLoadPadstack

```
axlLoadPadstack (
     t_padname
     )
     ⇒ o_dbid
```

Description

Loads a padstack by attempting to find the padstack by name in the existing database. Failing that, Allegro PCB Editor looks in the pad library on the disk.

Arguments

t_padname	Padstack name. If loaded from disk, Allegro PCB Editor uses the `PADLIB` path variable to find the pad. Pad name is limited to 20 characters.

Value Returned

o_dbid	*dbid* of padstack loaded.
`nil`	Nothing is found.

Example

```
pad = axlLoadPadstack (VIA)
```

Loads the VIA padstack.

©2023 All Rights Reserved.

axlLoadSymbol

```
axlLoadSymbol(
     t_symKind
     t_symName
     ) -> o_dbidSymDef/nil
```

Description

Searches for indicated symbol in database. If not present, searches PSMPATH and loads the symbol into the database. In the symbol editor, this can only be used for shape and mechanical symbols for use with padstacks.

Caution

If a symbol definition is not in use (dbid->instance is nil) then the definition is deleted. This deletion of unused symbols occurs during save drawing, refresh symbol, place manual among other places. This means the database is saved as part of axlRunBatchDBProgram then the unused symdefs will be deleted.

FLASH and SHAPE symbols are loaded automatically when a padstack using those symbols is loaded. This interface allows loading of these symbol types to allow analysis of the contents of these symbols types since you cannot use the extracta program.

Notes:

- `axlDBCreateSymbol` also loads the symbol definition if required. You do not need this API to place symbols.
- You can delete unused symdefs via axlDeleteObject.

©2023 All Rights Reserved.

Arguments

t_symkind	"PACKAGE", "MECHANICAL", "FORMAT" , "SHAPE, or "FLASH" (case insensitive)
t_symName	Name of symbol (lower case). This is the root name of the symbol, do not include an extension (for example, `.psm`) or a directory path.

Value Returned

dbid	Of symbol definition
nil	Cannot find symbol, unknown symbol type, symbol type doesn't match symbol, can't find a padstack that is required for a sym pin, or symbol revision is too old.

See Also

axlDBCreateSymbol

EXAMPLE

```
symdef = axlLoadSymbol("package" "dip14")
```


©2023 All Rights Reserved.

axlPadstackToDisk

```
axlPadstackToDisk(
     [t_padName]
     [t_outPadName]
     )
     ⇒ t/nil
```

Description

Saves a board padstack out to a library.

Arguments

t_padName	Name of the pad to be saved to a library.
t_outPadName	Name of the output pad.

Value Returned

`t`	Pad is created.
`nil`	Failed to create pad.

Example

- Dump all the padstacks in the layout.

```
axlPadstackToDisk()
```

- Dump padstack "`pad60cir36d`" from the layout as "`pad60cir36d.pad`".

```
axlPadstackToDisk("pad60cir36d")
```

- Dump padstack "`pad60cir36d`" from the layout as "`mypadstack.pad`".

```
axlPadstackToDisk("pad60cir36d" "mypadstack")
```


©2023 All Rights Reserved.

axlRefreshSymbol

```
axlRefreshSymbol(
     t_symName/o_SymDef
     [g_options]
     )
     ==> t/nil
```

Description

Refreshes a symbol from file on disk which is located by current PSMPATH. Works the same as the refresh_symbol functionality except updates one symbol definition. Unlike refresh_symbol this does not support the reset custom drill option since this is done at the padstack level not the symbol level.

Tip

1) If updating multiple symbols use axlDBCloak for best performance and minimal memory use.
2) To ignore the FIXED property see axlDBIgnoreFixed.

Arguments

t_symName	existing symbol name
o_SymDef	symbol definition dbid
g_options	The available options are: ■ `'text` – reset text locations ■ `'fanout` – reset fanouts (if design has fanouts delete them). Default is to only delete fanouts if disk symbol has them. ■ `'keepPadstack` – keep instance edited padstacks

RETURNS

- `o_SymDef` – refreshed symdef
- `nil` – fails; typically if cannot find symbol on disk or if a FIXED property is present.

©2023 All Rights Reserved.

Example

1. Update the DIP14 and reset text locations

```
axlRefreshSymbol("DIP14" 'text)
```

2. Update first symbol def off database root and set both the text and pin escape option

```
symdef = axlDBGetDesign()->symdefs
axlRefreshSymbol(car(symdef) '(text fanout))
```

See Also

axlDBCloak, axlDBIgnoreFixed, axlReplacePadstack

©2023 All Rights Reserved.

©2023 All Rights Reserved.

16

Database Group Functions

Overview

This chapter describes the AXL-SKILL Database Group functions.

©2023 All Rights Reserved.

axlDBAddGroupObjects

```
axlDBAddGroupObjects(
     o_group
     lo_members
     )
     ⇒ t/nil
```

Description

Adds the database objects specified in the new members list to a group. All restrictions and disclaimers specified in axlDBCreateGroup also apply for this procedure.

Arguments

o_group	*dbid* of the group to receive new members.
lo_members	List of *dbid*'s specifying the new group members. Database objects already in the group are silently ignored (giving a return value of `t`.) A single *dbid* can be substituted for a list.

Value Returned

`t`	Objects added to the group.
`nil`	Objects could not be added to the group because the resulting group does not meet the restrictions specified in `axlDBCreateGroup`.

See Also

axlDBCreateGroup

©2023 All Rights Reserved.

axlDBCreateGroup

```
axlDBCreateGroup(
     t_name
     t_type
     lo_groupMembers
     )
     ⇒ o_dbid/nil
```

Description

Creates a new group database object with members specified by *lo_groupMembers*.

©2023 All Rights Reserved.

Arguments

t_name String providing the group name. If name is in use by an existing group, this function fails and returns `nil`.

t_type String defining the group type. Legal values are:

"`generic`" - Allegro user groups

members: anything except other non-generic group objects

"`bus`"

members: net and xnets

"`net_group`"

members: xnet, net, diffpair, bus and net_group

"`nets_rko`" - a net keepout group

members: xnet, net, diffpair bus, net_group shape and fill rectangles (via and route keepout)

"`die_stack`" - APD+ only

members: compinst, syminst, rectangle, shape

"`ratbundle`"

members: pinpair

"`wire_profile`" - APD+ only

members: a wire (cline or wire subclass)

"`module`" - suggest to use `axlDBCreateModuleDef`

Accessible but not recommended.

"`db_drill_legend`" - drill legend tables

"`rf_nets`" - RF "super" nets

©2023 All Rights Reserved.

lo_members List of AXL *dbids* defining the group members. Duplicate *dbid* entries are silently ignored. An object is added to a group only once. A single *dbid* can be substituted for a list.

If certain restrictions on the group members are violated, this function fails and returns `nil`.

- For each group type has only certain objects that are allowed. For example generic groups only permits:
  - group
  - component
  - symbol
  - net
  - path
  - via
  - shape
  - polygon
  - pin
  - text
- A circular group relationship cannot be formed.

For example, group A cannot be added as a member of group B if group B is directly or indirectly a member of group A.

Value Returned

`o_dbid`	*dbid* of the newly formed group.
`nil`	If the group could not be created.

See Also

axlDBAddGroupObjects, axlDBDisbandGroup, axlDBRemoveGroupObjects

©2023 All Rights Reserved.

Example

- Generic group

```
groupMembers = axlGetSelSet()
group_dbid = axlDBCreateGroup("my_group" "generic" groupMembers)
```

- Net group

```
groupMembers = axlSelectByName("NET" "NET*" t)
group_dbid = axlDBCreateGroup("NG1" "net_group" groupMembers)
```

Note: The order of the group members provided when you access the *`groupMembers`* property may vary from the order provided in *`lo_groupMembers`*.

©2023 All Rights Reserved.

axlDBDisbandGroup

```
axlDBDisbandGroup(
     o_group
     )
     ⇒ t/nil
```

Description

Disbands the database group you specify with the *o_group* argument, thereby immediately removing the group. Members of the group are not deleted.

Arguments

o_group	*dbid* of the group to be deleted.

Value Returned

t	Group disbanded.
nil	Group could not be disbanded due to an invalid argument, for example, the *dbid* not being for a valid group.

See Also

axlDBCreateGroup

©2023 All Rights Reserved.

axlDBGetGroupFromItem

```
axlDBGetGroupFromItem(
     o_dbid
     t_groupType
     [g_promoteToNet]
     ) -> lo_groupDbid/nil
```

Description

Filter object's group membership by a group type. You can normally fetch the list of groups that an object is a member of by using the groups attribute of its dbid (etc. o_dbid->groups). This function provides additional filtering where you can request if an belongs to a particular group type. Depending upon the group characteristics an object can either belong to single group of a type or can be a member multiple groups of a single type. For example, an object can belong to multiple generic groups can belong to only one differential pair group.

The g_promoteToNet option for groups for which membership is limited to nets/xnets. It promotes the object provided to its owning xnet, and is targeted for use with diffpair and bus groups, where membership is limited to the net's xnet. It provides an easy way for those groups if given the dbid of a net to promote the id to its xnet.

Arguments

`o_dbid`	dbid to be examined
`t_groupType`	group type name. This is the group type name NOT the name of the group. In dbid terms this is group->type.
`g_mode`	If this value is `t`, it promotes the object to its net/xnet and performs test on that object. If the value is set to `'all` then it traverses group hierarchy and returns both direct and indirect group membership of dbid. For example, if net is a member of a xnet which is a member of a diffpair, and you specify group type of "DIFF_PAIR", this returns diffpair group for object.

©2023 All Rights Reserved.

Value Returned

`lo_groupDbid`	Group dbids or nil if not a member of requested group type

See Also: axlDBCreateGroup

Examples

In both case ashOne is a shareware utility that allows user to select one object (see `<CDSROOT>/share/pcb/examples/skill/ash-fxf/ashone.il`

- differential pair; set `g_promoteToNet` to `t` in case net is part of a xnet

```
p = ashOne()      ; select a net that is a diffpair member
l = axlDBGetGroupFromItem(p "DIFF_PAIR" t)
```

- generic group

```
p = ashOne()      ; create a group and select an object that is part of group
l = axlDBGetGroupFromItem(p "GENERIC")
```


©2023 All Rights Reserved.

axlDBGroupRename

```
axlDBGroupRename(
     o_groupDbid
     t_newName
     )
     ==> t/nil
```

Description

Renames a group. Groups supported are GENERIC, BUS, DIFF_PAIR, NETCLASS, NET_GROUP and MATCH_GROUP. Do not attempt to rename group types not listed.

Note: All restrictions and disclaimers specified in axlDBCreateGroup also apply for this API.

Arguments

o_groupDbid	The dbid of the group to be renamed
t_newName	New name of the group. Group name must be unique for the group type.

Value Returned

t	Successful in rename.
nil	Failed in rename; dbid not a group, group can't be renamed, new name is not legal for group type or name already exists in that group type.

See Also

axlDBCreateGroup

©2023 All Rights Reserved.

axlDBRemoveGroupObjects

```
axlDBRemoveGroupObjects(
     o_group
     lo_members
     )
     ⇒ t/nil
```

Description

Removes the database objects from the specified group. Group members, though removed, are not deleted.

Arguments

o_group	Group *dbid*.
lo_members	List of database objects to be removed from the group. A single *dbid* can be substituted for a list.

Value Returned

t	One or more objects removed from the group.
nil	*lo_members* contained no *dbids* of objects that could be removed from the group.

Notes:

- If a group is left with no members, the group is tagged for deletion, but is not removed immediately.
- You do not need to explicitly remove objects from a group before deleting the object with `axlDeleteObject`. Deleting an object removes it from all groups to which it belongs.

See Also

axlDBCreateGroup

©2023 All Rights Reserved.

axlNetClassAdd

```
axlNetClassAdd(
     o_netclassdbid/t_netclassName
     o_dbid/lo_dbid
     )==> t/nil
```

Description

Adds members to a netclass group. Eligible members are:

- nets
- XNnets
- differential pairs
- busses

See netclass discussion in axlNetClassCreate. This will mark DRC out of date. It is up to the application to update the DRC system.

Tip

Using dbids is faster then using names.

©2023 All Rights Reserved.

Arguments

o_netclassdbid	dbid of a netclass group
t_netclassName	name of a netclass group
o_dbid	legal database dbid to add to netclass
lo_dbid	list of legal database dbids to add to netclass

Value Returned

t	added elements
nil	failed one or more element adds; object might already be a member of a netclass in that domain or not legal dbid to add to a netclass

Examples

To netclass group created in axlNetClassCreate add two nets

```
nc = car(axlSelectByName("NETCLASS" "5_MIL"))nets = axlSelectByName("NET"
'("NET8" "NET9")
axlNetClassAdd(nc nets)
```

See Also

axlNetClassCreate

©2023 All Rights Reserved.

axlNetClassCreate

```
axlNetClassCreate(
     t_name
     g_domain/lg_domain
     )==> o_dbid
```

Description

This creates a new netclass group. If a netclass exists with this name then `nil` is returned. Net Classes need to be populated via `axlNetClassAdd`. Empty net classes may be deleted on database save. A netclass must be part of one or more domains. These domains are shown below. The Same Net Constraint domain uses the netclass spacing domain. An object (bus, diffpair, xnet or net) may be a member of single netclass in a domain. For example, if net VCC exists in the POWER netclass in the physical domain then you cannot add it to another netclass in the physical domain. You can still add this net of a netclass in the spacing or electrical domain. You can obtain the current set of net classes in the database via: `axlDBGetDesign()->netclass`. axlNetClassGet reports if an object is a member of a netclass either directly or via the logic hierarchy.

To assign a cset to a netclass assign the PHYSICAL_CONSTRAINT_SET, SPACING_CONSTRAINT_SET, SAME_NET_SPACING_CONSTRAINT_SET or ELECTRICAL_CONSTRAINT_SET property to the netclass where the value of the property is the cset name.

Same Net constraints shares the same domain with the SPACING_CONSTRAINT_SET.

©2023 All Rights Reserved.

Arguments

t_name	name of netclass group (changed to upper case)
g_domain	netclass domain can be 'spacing, 'physical, 'electrical or 'all
lg_domain	list of netclass domains

Value Returns

nil:	error or netclass with that name exists
o_dbid:	dbid of group

See Also

axlNetClassDelete, axlNetClassAdd, axlNetClassRemove, axlNetClassGet, axlDBAddProp, axlCNSCreate

Examples

Create a netclass in physical domain called "5_MIL"

```
nc = axlNetClassCreate("5_mil" 'physical)
```


©2023 All Rights Reserved.

axlNetClassDelete

```
axlNetClassDelete(
     o_netclassdbid/t_netclassName/lg_netclassdbid
     ) -> t/nil
```

Description

This deletes a net class group. It does not delete the objects belonging to the group. It is up to the application code to update DRC.

Note: Using dbids is faster then using names.

Arguments

o_netclassdbid	dbid of a net class group
t_netclassName	name of a net class group
lg_netclassdbid	list of net class groups (dbids or names)

Value Returned

t	net class group deleted
nil	failed

See Also

axlNetClassCreate

Examples

Delete net class group created in axlNetClassCreate

```
nc = car(axlSelectByName("NETCLASS" "5_MIL"))
axlNetClassDelete(nc)
```

or

```
axlNetClassDelete("5_MIL")
```


©2023 All Rights Reserved.

axlNetClassGet

```
axlNetClassGet(
     o_dbid
     s_domain
     g_hierarchal
     )==> o_netclass
```

Description

Given a dbid (net, xnet, diffpair or bus) and a domain (spacing, physical or electrical) return its netclass. If g_hierarchical is nil, returns object's netclass if a direct member. If g_hierarchal=t returns first netclass encountered in logical hierarchy. For example, if a net is a member of a bus and the bus is assigned to netclass, BUSCLASS, and you pass a net of the bus to this API:

will return nil if g_hierarchy=nil

will return netclass dbid, BUSCLASS, if g_hierarchy=t

Arguments

o_dbid	dbid may be net, xnet, diffpair or bus
s_domain	netclass domain; spacing, physical or electrical
g_hierarchal	

Value Returned

o_netclass	dbid of netclass
nil	object not part of a netclass in the domain or an invalid object

See Also

axlNetClassCreate

Examples

Use example in axlNetClassAdd

From example in (should return netclass in both cases)

©2023 All Rights Reserved.

```
net = car(axlSelectByName("NET" "NET8"))
axlNetClassGet(nets 'physical nil)
axlNetClassGet(nets 'physical t)
```


©2023 All Rights Reserved.

axlNetClassRemove

```
axlNetClassRemove(
     o_netclassdbid/t_netclassName
     o_dbid/lo_dbid
     )==> t/nil
```

Description

Removes elements from an existing net class group. Element must currently be a direct member of the group. This will mark DRC out of date. It is up to the application to update the DRC system.

Tip

Using dbids is faster then using names.

Arguments

o_netclassdbid	dbid of a netclass group
t_netclassName	name of a netclass group
o_dbid	legal database dbid to remove from group
lo_dbid	list of legal database dbids to remove from group

Value Returned

t	removed elements
nil	failed to remove one or more elements. Object may not be a cset member (member must be a direct member).

Examples

Using the example from axlNetClassAdd remove one of the nets:

```
axlNetClassRemove(nc car(nets))
```

See Also

axlNetClassCreate

©2023 All Rights Reserved.

axlRegionAdd

```
axlRegionAdd(
     o_regiondbid/t_regionName
     o_dbid/lo_dbid
     )==> t/nil
```

Description

Adds members to a region group. Eligible members are:

- shapes
- rectangles

Only objects on the CONS_REGION class may be added to a region. See region discussion in axlRegionCreate. This will mark DRC out of date. It is up to the application to update the DRC system

Note: Using dbids is faster then using names.

Arguments

o_regiondbid	dbid of a region group
t_regionName	name of a region group
o_dbid	legal database dbid to add to region
lo_dbid	list of legal database dbids to add to region

Value Returned

t	added elements
nil	failed one or more element adds; object might already be a member of a region or not legal dbid to add to a region

See Also

axlRegionAdd

©2023 All Rights Reserved.

Examples

To region group created in axlRegionCreate add a shape

```
nc = car(axlSelectByName("REGION" "BGA"))
lyr = "CONSTRAINT REGION/OUTER_LAYERS"
shape = axlDBCreateRectangle( list(100:100 200:200) nil lyr)
shape = car(shape)
axlRegionAdd(nc shape)
```


©2023 All Rights Reserved.

axlRegionCreate

```
axlRegionCreate(
     t_name
     )==> o_dbid
```

Description

Creates a new region group. If a region exists with this name then `nil` is returned. Regions may contain shapes on CONS_REGION class. Shapes are added to the region group via the axlRegionAdd. Empty regions may be deleted on database save. You can obtain the current set of regions in the database via: `axlDBGetDesign()->region`. None of the region APIs are enabled in the PCB L product.

Note: For better performance, when modifying regions you may wish to wrap all the calls with the axlDBCloak command.

Arguments

t_name	name of region group (changed to upper case)

Value Returned

nil:	error or region with that name exists
o_dbid:	dbid of group

If shapes are a member of a region then their dbid region attribute will refer to the region dbid

Examples

Create a region called "BGA"

```
nc = axlRegionCreate("BGA")
```

See Also

axlRegionDelete, axlRegionAdd, axlRegionRemove, axlDBCreateShape,

axlDBCreateRectangle

©2023 All Rights Reserved.

axlRegionDelete

```
axlRegionDelete(
     o_regiondbid/t_regionName/lg_regiondbid
     ) -> t/nil
```

Description

This deletes a region group. It does not delete the objects belonging to the group.

Note: Using dbids is faster then using names.

Arguments

o_regiondbid	dbid of a region group
t_regionName	name of a region group
lg_regiondbid	list of region groups (dbids or names)

Value Returned

t	net class group deleted
nil	failed

See Also

axlRegionCreate

Examples

Delete region group created in axlRegionCreate

```
nc = car(axlSelectByName("REGION" "BGA"))
axlRegionDelete(nc)
```

or

```
axlRegionDelete("BGA")
```


©2023 All Rights Reserved.

axlRegionRemove

```
axlRegionRemove(
     o_regiondbid/t_regionName
     o_dbid/lo_dbid
     )==> t/nil
```

Description

Removes shapes from an existing region group. Element must currently be a direct member of the group. This will mark DRC out of date. It is up to the application to update the DRC system.

Note: Using dbids is faster then using names.

Arguments

o_regiondbid	dbid of a region group
t_regionName	name of a region group
o_dbid	legal database shapes to remove from group
lo_dbid	list of legal database shapes to remove from group

Value Returned

t	removed elements
nil	failed to remove one or more elements. Object may not be a region member (member must be a direct member).

See Also

axlRegionCreate

Examples

Using the example from axlRegionAdd remove the shape:

```
axlRegionRemove(region  shape)
```


©2023 All Rights Reserved.

©2023 All Rights Reserved.

©2023 All Rights Reserved.

17

Database Attachment Functions

Overview

This chapter describes the AXL-SKILL Database Attachment functions.

©2023 All Rights Reserved.

axlCreateAttachment

```
axlCreateAttachment(
     t_attachmentId
     t_passwd
     x_revision
     s_dataFormat
     t_data
     )
     ⇒ o_attachment/nil
```

Description

Creates a new Allegro PCB Editor database attachment with the given attachment id. The attachment may optionally be given a password and a revision number. The attachment data may be specified as a string or as a file name.

`axlDBControl('maxAttachmentSize)` returns the maximum size of data that can attach to the database.

Caution

Do not create or replace attachments you do not own. This includes any predefined Allegro attachments like DFA or quickviews.

©2023 All Rights Reserved.

Arguments

t_attachmentId	Id or name of the attachment to retrieve. Can be up to 31 characters in length.
t_passwd	Password for this attachment. Can be up to 31 characters in length. If no password is desired this may be `nil`.
x_revision	Revision number of the attachment. If `nil`, the revision number is set to zero.
s_dataFormat	Indicates the format of the *t_data* argument. Permitted values: 'string — the value of the t_data argument is used for the attachment data. 'file — t_data references an ASCII file that is read into the database attachment. 'binary — t_data references a binary file that is read into the database attachment. Use this option with zip or compressed files.
t_data	

Value Returned

o_attachment	AXL id for the new attachment, which can then be queried using the right arrow (->) operator.
`nil`	Failed to create an attachment due to incorrect arguments.

Note: Once an attachment is password protected it needs to be deleted, then re-added to remove or change the password protection.

See Also

axlGetAttachment

EXAMPLE

This uses an attachment to store in the database a list of variables. For example, you design a form where the user enters in their preferences and you manage them in SKILL via a disembodied property list. You would like to store the user's preferences with the design.

©2023 All Rights Reserved.

Create an attachment name. Create a name using an underscore, company name and application to make it unique. For example, `_acme_bom_rpt`, would be a good attachment name.

```
attachName = "fxf"
```

; A typical disembodied property list

```
mylist = ncons(nil)
mylist->ccw = t
mylist->middle = nil
mylist->cx = 0.12
mylist->cy = 10.192
mylist->layer = "TOP"
```

Note: Do not store dbid's in the disembodied list or make sure to remove them before storing as an attachment.

Store list in current design (assuming user saves design)

```
dataString = sprintf(nil " '%L" mylist)
axlCreateAttachment(attachName nil 0 'string dataString)
```

Next time user runs the SKILL code, here is how to init the list:

```
attach = axlGetAttachment(attachName 'string)
    if( attach)  then
        mylist = car(errsetstring(attach->data))
    else     ; no list stored in design so init to default settings
        mylist = ncons(nil)
        mylist->ccw = t
    )
```


©2023 All Rights Reserved.

axlDeleteAttachment

```
axlDeleteAttachment(
     t_attachmentId
     [t_passwd]
     )
     ⇒ t/nil
```

Description

Deletes the given attachment. If the attachment is password protected, the correct password must be given.

Caution

Do NOT delete attachments you do not own. This includes any predefined Allegro attachments like DFA or quickviews.

Arguments

t_attachmentId	Id or name of the attachment to delete.
t_passwd	Password for this attachment.

Value Returned

t	Attachment successfully deleted.
nil	Attachment not deleted.

See Also

axlGetAttachment

©2023 All Rights Reserved.

axlGetAllAttachmentNames

```
axlGetAllAttachmentNames(
     )
     ⇒ l_attachment/nil
```

Description

Returns a list of the ids for all database attachments in the current Allegro PCB Editor database. If no attachments are present, then `nil` is returned. The attachments can retrieved using the `axlGetAttachment()` function.

Arguments

none

Value Returned

`l_attachment`	List of attachment ids.
`nil`	No attachments exist in the database.

©2023 All Rights Reserved.

axlGetAttachment

```
axlGetAttachment(
     t_attachmentId
     [s_dataFormat]
     )
     ⇒ o_attachment/nil
```

Description

Returns the database attachment with the given id. If the attachment exists, an *attachment record* is returned containing information about the attachment. The data is in the format specified by the *s_dataFormat* argument. If `'file` format, then the *data* attribute contains a temporary file name to which the data was written. If `'string`, then the *data* attribute contains the attachment data itself. If the *s_dataFormat* argument is omitted or is `nil`, then the *data* attribute is `nil`.

The attachment record has the following attributes:

Name	Type	Set?	Description
objType	string	NO	Is always "`attachment`".
id	string	NO	Id (name) of the attachment.
password	boolean	NO	`t`/`nil` - Indicates if the attachment is password protected.
timeStamp	integer	NO	Indicates the time last modified in seconds.
revision	integer	YES	User defined revision number for the attachment data.
dataFormat	symbol	YES	Indicates the format of the data stored in the "data" attribute and is one of `'file`, `'string`, or `nil` (in which case the data is not displayed.) `'file` is displayed if you use `'binary` option to create the attachment.
data	string	YES	Attachment data. May be a file name, the data itself, or `nil` depending on the value of the *dataFormat* attribute.
timeStamp	integer	NO	Indicates the size of the attachment.

©2023 All Rights Reserved.

Caution

Access to attachments in the private database is allowed. Do not create, change, or delete these attachments. The rule for attachments access is: If your application did NOT create the attachment do NOT change it.

Arguments

t_attachmentId	Id or name of the attachment to retrieve. Can be up to 31 characters in length.
s_dataFormat	Format in which the attachment data is stored in the "*data*" attribute. Must be: ■ `'string:` return data as a string. ■ `'file:` return data stored in a tmp file. You should use this option if you used `'binary` method to create the attachment. ■ `nil:` use the method describe in the attachment dataFormat attribute.

Value Returned

o_attachment	AXL id for the attachment structure which can be queried using the right arrow (->) operator.
`nil`	Attachment does not exist.

Example

```
attachment = axlGetAttachment("attachmentOne" 'file)
⇒ attachment:attachmentOne
```

See Also

axlIsAttachment, axlGetAllAttachmentNames, axlCreateAttachment, axlSetAttachment, axlDeleteAttachment

©2023 All Rights Reserved.

axlIsAttachment

```
axlIsAttachment(
     o_attachment
     )
     ⇒ t/nil
```

Description

Determines if the given object is an AXL attachment.

Arguments

o_attachment	Object to check.

Value Returned

`t`	Object is an attachment.
`nil`	Object is not an attachment.

See Also

axlGetAttachment

©2023 All Rights Reserved.

axlSetAttachment

```
axlSetAttachment(
     o_attachment
     [t_password]
     )
     ⇒ o_attachment/nil
```

Description

Modifies an existing Allegro PCB Editor database attachment with the data contained in the given AXL attachment id. Original attachment object must be obtained from the `axlCreateAttachment`, `axlGetAttachment`, or `axlGetAllAttachments` function. The attachment revision number and the attachment data may both be modified.

Format of the data is determined by the *`dataFormat`* attribute structure, which may be set by the user. If "*`dataFormat`*" is `'string`, then the value of the *`data`* attribute is used for the new attachment data. If "*`dataFormat`*" is `'file`, then the value of the *`data`* attribute is a file name from which the attachment data is read.

If the existing attachment is password protected, you must provide the correct password or the function fails.

Arguments

`o_attachment`	AXL id of the existing attachment to be modified. The *`revision`*, *`dataFormat`*, and *`data`* attributes may all be set to new values by the user.
`t_password`	Password for the given existing attachment. If this does not match the password of the existing attribute, the attachment update fails. If the existing attachment is not password protected, you may omit this.

Value Returned

`o_attachment`	AXL id of the modified attachment.
`nil`	Failed to modify the attachment.

Note: Once an attachment is password protected, to remove or change the password protection you must delete and then re-add the attachment.

©2023 All Rights Reserved.

See Also

axlGetAttachment

©2023 All Rights Reserved.

©2023 All Rights Reserved.

18

Database Transaction Functions

This chapter describes the AXL-SKILL Database Transaction functions.

axlDBCloak

```
axlDBCloak(
     g_func
     [s_mode]/[ls_mode]
     )
     ⇒ g_return
```

Description

Improves performance and program memory use while modifying many items in the database. You use `axlDBCloak` to update many etch or package symbols in batch mode. Works like SKILL's `eval` function. You pass it a function and its arguments using the following format:

```
axlDBCloak ('MyFunc( myargs) )
```

You can use `axlDBCloak` to do the following:

- Batch any net based DRC updates.
- Batch connectivity update.
- Optionally, batch dynamic shape updates if *s_mode* is `'shape`.
- Optionally, ignores the FIXED property if *s_mode* is `'ignoreFixed`.
- Optionally, delays canvas redraws if *s_mode* is `'disableDisplay`.
- Incorporate an errset around your function so any SKILL errors thrown are caught by `axlDBCloak`.

This function must be used if you need to update many etch or package symbols in a batch fashion.

©2023 All Rights Reserved.

Do not use `axlDBCloak` in these circumstances:

- If you are adding or deleting non-connectivity database items (for example, loading many lines to a manufacturing layer)
- If you need to interact with the user. Since connectivity is not updated, do not use the `axlEnter`*XXX* functions. Instead, get the information from the user first, then do the cloak update.
- If you are reading the database, using cloak does not help and may actually slow performance.
- If making a single change, using Cloak slows performance.

Note: Using Cloak sets any database ids to `nil`.

gmode options (if multiple required pass a list of options

`'shape`	Improves performance if changes being made effect any dynamic shapes on the design. Generally you should set this if effecting ETCH layers with your changes.
`'ignoreFixed`	Have the system ignore the FIXED property (see axlDBIgnoreFixed)
`'disableDisplay`	Do not update the main canvas display during processing.

CAUTIONS:

- A frequent programming error is to leave of the tick (') mark that allows axlDBCloak to evaluate the function.

  CORRECT MODEL:

  ```
  axlDBCloak( 'MyFunc(myArgs) '(shape ignoreFixed))
  ```

  INCORRECT MODEL:

  ```
  axlDBCloak( MyFunc(myArgs) '(shape ignoreFixed))
  ```

  Both work but in the incorrect case now performance benefit offered by the cloaking function will by applied to MyFunc.

- Database transactions and cloaking (axlDBTransactionStart):
  - Do NOT start and transaction inside a cloak and then terminate it outside the cloak. Terminate means calling either axlDBTransactionRollback, axlDBTransactionCommit axlDBTransactionOops.
  - If you start a transaction inside a cloak then complete it before returning.

©2023 All Rights Reserved.

- If you start a transaction outside the cloak then its completion must outside the cloak.

Tip

For effective debugging, first call your function directly from the top level function, then wrap in the cloak call.

Arguments

g_func	Function with any of its arguments.
s_mode	option
ls_mode	list of options

Value Returned

Returns what *g_func* returns.

Example

```
procedure( DeleteSymbols()
let( (listOfSymbols)

    listOfSymbols = axlDBGetDesign()->symbols
    when( listOfSymbols
        axlDBCloak( 'DeleteDoit(listOfSymbols) 'shape ))
        axlShell("cputime stop"
    ))
procedure( DeleteDoit(listOfDatabaseObjects )

    foreach(c_item listOfDatabaseObjects
        printf("REFDES %s\n", c_item->refdes)
        axlDeleteObject(c_item)
    )
    nil
)
```

Deletes all placed symbols in the database.

©2023 All Rights Reserved.

See Also

axlDBTransactionStart

©2023 All Rights Reserved.

axlDBTransactionCommit

```
axlDBTransactionCommit(
     x_mark
     )
     ⇒ t/nil
```

Description

Commits a database transaction from the last transaction mark.

Arguments

x_mark	Database transaction mark returned from `axlDBTransactionStart`.

Value Returned

`t`	Database transaction committed.
`nil`	Database transaction not committed.

Example

See `axlDBTransactionStart()` for an example.

©2023 All Rights Reserved.

axlDBTransactionMark

```
axlDBTransactionMark(
     x_mark
     )
     ⇒ t/nil
```

Description

Writes a mark in the database that you can use with axlDBTransactionOops to rollback database changes to this mark.

When a transaction mark is committed or rolled back, all `axlDBTransactionMarks` associated with that mark are discarded.

Arguments

x_mark	Database transaction mark returned from `axlDBTransactionStart`.

Value Returned

`t`	Mark written in the database.
`nil`	No mark written in the database.

Example

See `axlDBTransactionStart()` for an example.

©2023 All Rights Reserved.

axlDBTransactionOops

```
axlDBTransactionOops(
     x_mark
     )
     ⇒ t/nil
```

Description

Undoes a transaction back to the last mark, or to start if there are no marks. Supports the Allegro *oops* model for database transactions.

When a transaction mark is committed or rolled back all, then that mark is no longer valid for *oops* action.

Arguments

x_mark	Database transaction mark returned from `axlDBTransactionStart`.

Value Returned

`t`	Transaction undo completed.
`nil`	Transaction is already back to the starting mark and there is nothing left to *oops*.

Example

See `axlDBTransactionStart` for an example.

©2023 All Rights Reserved.

axlDBTransactionRollback

```
axlDBTransactionRollback(
     x_mark
     )
     ⇒ t/nil
```

Description

Undo function for a database transaction.

Arguments

x_mark	Database transaction mark returned from `axlDBTransactionStart`.

Value Returned

`t`	Transaction undo completed.
`nil`	Transaction undo not completed.

Example

See `axlDBTransactionStart` for an example.

©2023 All Rights Reserved.

axlDBTransactionStart

```
axlDBTransactionStart(
     [g_undoMark])
     ⇒ x_mark/nil
```

Description

Marks the start of a transaction to the database. Returns a mark to the caller which is passed back to commit, mark, oops or rollback for nested transactions. Only the outermost caller of this function (the first caller) has control to commit or rollback the entire transaction.

You use this function with other `axlDBTransaction` functions.

Allegro cancels any transactions left active when your SKILL code terminates. You cannot start a transaction and keep it active across Allegro commands as an attempt to support *undo*.

Saving or opening a database cancels transactions.

Arguments

g_undoMark	This should be set to 'undoMark that are for commands that want multiple undo events. For example, when placing multiple individual symbols, you may want each placement to be an individual undo event. By default, with a undo interactive all operations within the command results in a single undo even. See in axlCmdRegister on how write a SKILL command that supports Allegro undo.

Value Returned

x_mark	Integer mark indicating transaction start.
`nil`	Failed to mark transaction start.

©2023 All Rights Reserved.

Example 1

Emulates the Allegro *oops* model.

```
mark = axlDBTransactionStart()
...#1 do stuff ...
axlDBTransactionMark(mark)
...#2 do stuff ...
axlDBTransactionMark(mark)
...#3 do stuff ...

;; do an oops of the last two changes
axlDBTransactionOops( mark ) ; oops out #3
axlDBTransactionOops( mark ) ; oops out #2
axlDBTransactionOops( topList); commit only #1
```

Example 2

Multiple Start marks

```
i = axlDBTransactionStart()
    ... do stuff ...
j = axlDBTransactionStart()
    ... stuff ...
    axlDBTransactionCommit(j) ;; this is not really commited
                                ;;till the outer commit
j = axlDBTransactionStart()
    ... do more stuff ...
axlDBTransactionRollback(j) ;; oops out "do more stuff"

axlDBTransactionCommit(i) ;; commit changes to database
```

Note: Database transaction functions do NOT mark select sets. The application handles select set management.

See Also

axlDBTransactionMark, axlDBTransactionOops, axlDBTransactionCommit, axlDBTransactionRollback, axlCmdRegister

©2023 All Rights Reserved.

©2023 All Rights Reserved.

©2023 All Rights Reserved.

19

Constraint Management Functions

Overview

This chapter describes the AXL-SKILL functions related to constraint management.

For a list of constraints, see Appendix B in the *Allegro Constraint Manager User Guide.*

©2023 All Rights Reserved.

axlCnsAddVia

```
axlCnsAddVia(
     t_csetName
     t_padstackName
     )
     ==> t/nil
```

Description

Adds padstack to the constraint via list of a physical cset. Via is added to end of list (see axlCnsGetViaList of via ordering functionality in etch editing).

Padstack does not need to exist to be added to a constraint via list.

If *t_csetName* is `nil`, add padstack to all physical csets.

Note: If a via already exists in the via list, a `t` is returned. Locked csets return a `nil`.

Arguments

t_csetName	Name of physical cset or `nil` for all csets.
t_padstack	Name of a via padstack.

Value Returned

`t`	If added.
`nil`	Error in arguments; cset does not exist or illegal padstack name.

Examples

Add ALLPAD to all csets

```
axlCnsAddVia(nil "ALLPAD")
```

Add ONEPAD to DEFAULT cset

```
axlCnsAddVia("DEFAULT" "ONEPAD")
```


©2023 All Rights Reserved.

axlCnsAssignPurge – Obsolete

This function is obsolete. Kept for backward compatibility

©2023 All Rights Reserved.

axlCnsClassTableChange

```
axlCnsClassTableChange(
     o_dbidClassTable
     s_csetType/ll_typeAndName
     [t_csetName]
     ) -> o_dbidClassTable/nil
```

Description

This command changes the Csets associated with an existing net class table entry.

Note: See axlCnsClassTableCreate for complete family of functions.

You cannot change any table entries containing a region entry in Allegro PCB Designer or lower tiers.

Arguments

o_dbidClassTable	dbid of an existing classTable entry.
s_csetType	symbol for cset type. spacing, 'physical or 'sameNet)
ll_typeAndName	lists `s_csetType` and `t_csetName`
t_csetName	cset name string

Value Returned

Updated classTable dbid or nil if failure

See Also

axlCnsClassTableCreate

Examples

Before running the sample SKILLcode for `axlCnsClassTableChange`, create a class table by running the example code in the axlCnsClassTableCreate command. Next, execute the following SKILL code and update the entry created in axlCnsClassTableCreate by adding it to the spacing.

```
cset named 1, physical cset named 2 and a same net cset named 3.
     prop =  '((spacing "1") (physical "2") (sameNet "3"))
```


©2023 All Rights Reserved.

```
tbl = axlCnsClassTableChange(tbl prop)
```


©2023 All Rights Reserved.

axlCnsClassTableCreate

```
axlCnsClassTableCreate(
     g_class1
     g_class2
     g_region
     s_csetType/ll_typeAndName
     [t_csetName]
     ) -> o_dbidClassTable/nil
```

Description

This command creates a class table entry that consists of any of the following:

- class to class (spacing only)
- region to class (spacing, same net and physical)
- region to class to class (spacing only)

Optionally, the command also associates a spacing cset, a physical cset, and same net cset with the table entry. If a class table entry already exists, it is modified with the provided csets.

Regions are not available in Allegro PCB Designer and lower products. Command will fail if you attempt to create a region-based table entry in these products. Class tables may not be created in symbol editor.

Points to remember:

1. The order of class1 and class2 does not matter.
2. If an entry already exists it will return the existing entry.
3. Net classes can be classified by domain (spacing and/or physical). If a netclass is restricted to one domain, it is possible to create a netclass to any entry that crosses domains. This table entry will be ignored by DRC. For example, you have a netclass, `ANY`, in both physical and spacing domains; and another netclass `PHYS` that is restricted to the physical domain. It is possible to create a `ANY` to `PHYS` relationship which is only appropriate in the spacing domain but the `PHYS` netclass is not legal in that domain.

   Note: This condition might be tested for and rejected in future releases.
4. DRC is set out-of-date, you must manually update the DRC.
5. Unlike Constraint Manager, you can add cset names that don't yet exist in the database. In these cases, we will automatically create a cset. Check via axlCnsList if your cset exists if you don't wish to create new csets.

©2023 All Rights Reserved.

6. Class table entries may also have constraint overrides attached via property overrides (`axlDBAddProp`)

Arguments

g_class1	NETCLASS dbid or name of name class
g_class2	NETCLASS dbid, name of name class or nil
g_region	REGION dbid, name of region or nil
s_csetType	symbol cset type one of 'spacing, 'physical or 'samenet
t_csetName	string cset name for given type
ll_typeAndName	option list of values where you have `((s_csetType t_csetName) (s_csetType t_csetName) ...)`

Value Returned

returns `dbid` of type `classTable` for new or existing cset or nil if error

See Also

axlCnsClassTableFind, axlCnsClassTableSeek, axlCnsClassTableChange, axlCnsClassTableDelete, axlCnsList,

Also see classTable dbid object description.

Examples

Create appropriate entries in design

```
region = axlRegionCreate("ANALOG")
ncls = axlNetClassCreate("VOLTAGE" '(spacing physical))
```

1. Add new spacing region-class table entry and give it the spacing cset "25MILS"

```
tbl = axlCnsClassTableCreate("VOLTAGE" nil "ANALOG" 'spacing "25MILS")
```

2. Alternative method plus also add a physical voltage cset.

```
props = '((spacing "25MILS") (physical "VOLTAGE"))
tbl = axlCnsClassTableCreate(ncls nil region props)
```


©2023 All Rights Reserved.

axlCnsClassTableDelete

```
axlCnsClassTableDelete(
     o_dbidClassTable/lo_dbidClassTable
     ) -> t/nil
```

Description

Deletes one or more entries in the class table.

DRC is marked out of date.

Arguments

o_dbidClassTable	dbid of an existing classTable entry.
lo_dbidClassTable	deletes list of classTable entries.

Value Returned

`t` if successful, `nil` if an error

See Also

axlCnsClassTableCreate, axlCnsDeleteRegionClassClassObjects, axlCnsDeleteClassClassObjects

Examples

Create a classTable entry by executing example code in axlCnsClassTableCreate. Delete entry just created by running the following command.

```
axlCnsClassTableDelete(tbl)
```


©2023 All Rights Reserved.

axlCnsClassTableFind

```
axlCnsClassTableFind(
     s_type
     [o_dbid]
     ) -> lo_dbidClassTable/nil
```

Description

This command searches the class table for class table entries matching the search criteria.

Arguments

s_type

Specifies the type of search to perform. The options available are:

- `'netclass` – returns all class entries (all entries except for wire and component)
- `` `classClass `` – returns all class to class entries
- `` `classRegion `` – returns all class to region entries
- `` `classClassRegion `` – returns all class to class to region entries
- `` `wireProf `` – returns all wire profile entries (APD+ only)
- `` `component `` – returns all component entries (APD+ only)
- `` `match `` – returns all entries that contain provided region or class dbid (`o_dbid`)

o_dbid

only applicable for the match option will return all class table entries containing the dbid.

Value Returned

List of class table dbids matching search criteria or `nil` if no match is found.

©2023 All Rights Reserved.

See Also

axlCnsClassTableCreate, axlCnsClassTableSeek, axlSelectByName

Examples

1. Return all class entries that effect physical, spacing or same net DRC

```
tbl = axlCnsClassTableFind('netclass)
```

2. Return all entries that contain Region "ANALOG" entry (assumes design has a region called "ANALOG")

```
region = car (axlSelectByName("REGION" "ANALOG"))
tbl = axlCnsClassTableFind('match region)
```


©2023 All Rights Reserved.

axlCnsClassTableSeek

```
axlCnsClassTableSeek(
     g_class1
     g_class2
     g_region
     ) -> o_dbidClassTable/nil
```

Description

This command seeks a specific class table entry matching exactly the provided `dbids`. Order of class1 and class2 does not matter since C1/C2 is the same as C2/C1 and only one entry exists in the table.

Tip

Constraint overrides may exist on a table entry via the `prop` attribute. While fetching multiple table entries, best performance is achieved by using dbids or using axlCnsClassTableFind.

Arguments

g_class1	NETCLASS dbid, name of net class or nil
g_class2	NETCLASS dbid, name of net class or nil
g_region	REGION dbid, name of region or nil

Value Returned

Class table entry matching search criteria or `nil` if none found.

See Also

axlCnsClassTableCreate

Examples

Create a classTable entry by executing example code in axlCnsClassTableCreate

1. Return class table entry for a netclass called VOLTAGE and region called ANALOG.

```
tbl = axlCnsClassTableSeek("VOLTAGE" nil "ANALOG")
```


©2023 All Rights Reserved.

2. Alternative method using dbids

```
region = car( axlSelectByName("REGION" "ANALOG"))
netclass = car( axlSelectByName("NETCLASS" "VOLTAGE"))
tbl = axlCnsClassTableSeek(netclass nil region)
```


©2023 All Rights Reserved.

axlCNSCreate

```
axlCNSCreate(
     g_domain
     t_name
     t_copyName
     )
     ==> t/nil
```

Description

Creates a new constraint set in the specified domain. For spacing and physical csets, you must supply an existing cset as the copy cset. If the *copyName* is nil, the DEFAULT cset is used. Electrical csets (ECsets) are created empty for a nil *copyName* . By default, the ECset created is empty. If you provide a second argument, the ECset contents are copied.

To assign a cset to a logical object such as a net, bus, or a netclass, assign a PHYSICAL_CONSTRAINT_SET, SPACING_CONSTRAINT_SET, SAME_NET_SPACING_CONSTRAINT_SET or ELECTRICAL_CONSTRAINT_SET property to the logical object where the value of the property is the cset name.

Note: Electrical csets cannot be created in Allegro PCB Designer.

©2023 All Rights Reserved.

Arguments

g_domain	Specifies the domain of the Cset. Possible values are Physical, spacing, electrical, or ‘sameNet.
t_name	Name of new cset. (Changed to upper case) string must pass allowed character set
t_copyName	Name of cset to use as template. If this is `nil`, spacing and physical domains use DEFAULT as the template, while in case of electrical domain, an empty ECset is created.

Value Returned

t	Cset created.
nil	Failed for the following reasons: domain name is illegal; name of cset is illegal; cset already exists; or *copyName* cset does not exist.

See Also

axlCNSEcsetCreate, axlCNSDelete, axlCnsList, axlDBAddProp, axlNetClassCreate

Example

Create a new physical cset called `foo`.

```
axlCNSCreate('physical "foo" nil)
```


©2023 All Rights Reserved.

axlCNSCsetLock

```
axlCNSCsetLock(
     g_domain
     t_csetName
     g_mode
     )
     ==> t/nil
```

Description

This locks or unlocks a constraint set in the given domain. See discussion in axlCNSIsLockedDomain.

You should usually lock or unlock the entire domain since this matches the DRC user model. We provide this interface to temporary unlock a locked cset, make changes then reapply the lock.

Note: Changing the lock on a cset can take a considerable amount of time since DRC needs to be updated. In the spacing domain, dynamic shapes need to be updated. If doing other changes, consider cloaking axlDBCloak the entire process. This API already uses cloaking for the individual cset.

Arguments

g_domain	domain of cset; `'physical`, `'spacing`, `'sameNet`, `'electrical`
t_csetName	cset name
g_mode	may either be `t` (to lock) or `nil` to unlock

Value Returned

Returns `t` if updated lock status, `nil` an error.

Examples

Lock Spacing cset DEFAULT, which has a side effect of locking spacing and same net domains

```
axlCNSCsetLock('spacing "DEFAULT" t)
```


©2023 All Rights Reserved.

See Also

axlCNSIsLockedDomain

©2023 All Rights Reserved.

axlCNSDelete

```
axlCNSDelete(
     g_domain
     t_name/o_dbidEcset
     )
     ==> t/nil
```

Description

Deletes a cset and its references to any objects such as nets, net classes, etc. Locked csets must first be unlocked before you delete them. If it is a spacing or physical domain, you cannot delete the DEFAULT cset. You cannot delete electrical csets in Allegro PCB Design L.

Arguments

g_domain	Specifies the domain of cset. Valid values are: `'physical`, `'spacing`, `'sameNet`, `'electrical`
t_name	Name of cset.
o_dbidEcset	If an ECset, its *dbid*.

Value Returned

t	Cset deleted.
nil	Cset not deleted because cset does not exist or the cset is locked, or cset is `t`.

Example

Deletes electrical cset named UPREV_DEFAULT.

```
axlCNSDelete('electrical "UPREV_DEFAULT")
```

See Also

axlCNSCreate

©2023 All Rights Reserved.

axlCnsDeleteClassClassObjects

```
axlCnsDeleteClassClassObjects(
     ) => x_delCount
```

Description

Delete all Class-Class entries.

Arguments

None

Value Returned

The count of the objects deleted.

See Also

axlCnsPurgeCsets

©2023 All Rights Reserved.

axlCnsDeleteRegionClassClassObjects

```
axlCnsDeleteRegionClassClassObjects(
     ) => x_delCount
```

Description

Deletes all Region-Class-Class entries.

Arguments

None

Value Returned

The count of the objects deleted.

See Also

axlCnsPurgeCsets

©2023 All Rights Reserved.

axlCnsDeleteRegionClassObjects

```
axlCnsDeleteRegionClassObjects(
     ) => x_delCount
```

Description

Delete all Region-Class entries.

Arguments

None

Value Returned

The count of the objects deleted.

See Also

axlCnsPurgeCsets

©2023 All Rights Reserved.

axlCnsDeleteVia

```
axlCnsDeleteVia(
     t_csetName
     t_padstackName
     )
     => t/nil
```

Description

Deletes padstack from the physical via constraint list, *t_csetName*. If *t_csetName* is `nil`, delete provided padstack from all physical constraint sets.

Notes:

- Will return `t` if asked to delete a via that does not exist in the via list.
- Locked csets will return a `nil`.

Arguments

t_csetName	Name of physical cset or nil for all csets.
t_padstack	Name of a via padstack.

Value Returned

`t`	If deleted.
`nil`	Error in arguments; cset does not exist or illegal padstack name.

Example

Delete via to default cset

```
axlCnsDeleteVia("DEFAULT" "VIA")
```

Delete via to all csets

```
axlCnsDeleteVia(nil "VIA")
```


©2023 All Rights Reserved.

See Also

`axlCnsGetViaList` and axlPurgePadstacks

©2023 All Rights Reserved.

axlCNSDesignModeGet

```
axlCNSDesignModeGet(
     nil
     )
     ⇒ ls_constraints
```

```
axlCNSDesignModeGet(
     'all
     )
     ⇒ lls_constraintNModes
```

```
axlCNSDesignModeGet(
     'editable
     )
     ⇒ t/nil
```

```
axlCNSDesignModeGet(
     s_name/t_name
     )
     ⇒ s_mode/nil
```

```
axlCNSDesignModeGet(
     s_name/t_name
     'print
     ) ==> t_name/nil
```

Description

Gets the current DRC modes for checks that fall into the set of design constraints. These constraints pertain to the entire board. To determine the design constraint checks currently supported, use the `axlCNSDesignModeGet()` command.

The `'print` mode offers the name shown in reports like show element.

This has axlDebug support.

Note: Available constraint checks may change from release to release.

©2023 All Rights Reserved.

Arguments

`nil`	Returns all checks in design type DRC.
`'all`	Returns all checks and current mode.
`'editable`	Returns `t` if mode can be changed, `nil` mode is not changed and when in Allegro PCB Editor studio which does not offer this option.
`s_name`	Symbol name of check.
`t_name`	String name of check.
`'print`	Printable constraint name option.

Value Returned

`ls_names`	List of checks (*`s_name`* ...)
`lls_names`	List of checks and their mode ((*`s_name`* *`s_mode`*) ...)
`s_mode`	Mode `'on`, `'off` or `'batch`
`t_name`	The printable constraint name

Example 1

```
axlCNSDesignModeGet(nil)
```

Gets a current list of design constraints.

Example 2

```
axlCNSDesignModeGet('all)
```

Gets a list of settings for all design constraints.

Example 3

```
axlCNSDesignModeGet('Package_to_Package_Spacing)
```

Gets current setting of package to package.

Example 4

```
axlCNSDesignModeGet("Negative_Plane_Islands")
```


©2023 All Rights Reserved.

Gets current setting of negative plane islands using a string.

©2023 All Rights Reserved.

axlCNSDesignModeSet

```
axlCNSDesignModeSet(
     t_name/s_name
     t_mode/s_mode
     )
     ⇒ t/nil

axlCNSDesignModeSet(
     'all
     t_mode/smode
     )
     ⇒ t/nil

axlCNSDesignModeSet(
     l_constraintNModes
     t_mode/smode
     )
     ⇒ t/nil

axlCNSDesignModeSet(
     ll_constraintNModes
     )
     ⇒ t/nil
```

Description

Sets the current DRC modes for design constraints. The modes control the DRC for that design constraint check on the entire board.

To determine the checks that are supported, use the following command:

```
axlCNSDesignModeGet()
```

You can set all checks using the argument `'all`, set individual checks using *`t_name`*, or set a list of checks to the same mode as follows:

```
'(s_name...) t_mode/s_mode
'(t_name...) t_mode/s_mode
```

You can list sets of checks as follows:

```
'((s_name/t_name s_mode/t_mode)...)
```

For performance reasons, changing modes or values does not invoke DRC. You must manually invoke DRC. You can mark changes in order to perform fewer DRC updates, depending on your changes (see axlCNSMapUpdate on page 1349.)

Note: Available constraint checks may change from release to release.

©2023 All Rights Reserved.

Arguments

s_name	Symbol name of check.
t_name	String name of check.
s_mode	Mode setting may be `'on`, `'off`, or `'batch`.
t_mode	String mode setting may be `"on"`, `"off"` or `"batch"`
`'all`	Returns all checks for a given tier of Allegro PCB Editor.

Value Returned

`t`	Success
`nil`	Failure.

Example 1

```
axlCNSDesignModeSet('Package_to_Place_Keepin_Spacing 'on)
```

Turns on package to package keepin check.

Example 2

```
axlCNSDesignModeSet('all 'batch)
```

Makes all design constraints batch only.

Example 3

```
axlCNSDesignModeSet('(Negative_Plane_Islands Pad_Soldermask_Alignment)' off)
```

Turns two constraints off.

©2023 All Rights Reserved.

Example 4

```
axlCNSDesignModeSet('((Package_to_Place_Keepout_Spacing 'on)) )
```

Sets various constraints to different modes.

For a programming example, see `cns-design.il`, which you can find in the following location:

```
<cdsroot>/share/pcb/examples/skill/cmds
```


©2023 All Rights Reserved.

axlCNSDesignValueCheck

```
axlCNSDesignValueCheck(
     s_name/t_name
     g_value
     )
     ⇒ (t_string/nil, nil/t_errorMsg)/nil
```

Description

Checks the syntax of the given value against the allowed syntax for the given constraint. You use the function `axlCNSDesignGetValue(nil)` to get the constraint names.

Note: Allowed syntax may change from release to release.

Arguments

s_name	Symbol name of the constraint.
t_name	String name of the constraint.
g_value	Value to verify

Value Returned

(*t_string*/nil)	Value correct. *t_string* shows current user unit preference. For example, if you supply "10", the return might be `"10.0 MILS"` if `MILS` is the current database unit.
(nil/*t_errorMsg*)	Value incorrect. *t_errorMsg* reflects the error.
nil	Arguments are incorrect.

Examples

```
axlCNSDesignValueCheck('Negative_Plane_Islands "10 mils")
```

Tests if allowed to set.

©2023 All Rights Reserved.

axlCNSDesignValueGet

```
axlCNSDesignValueGet(
     nil
     [g_returnNameString]
     )
     ⇒ ls_constraints
```

```
axlCNSDesignValueGet(
     'all
     [g_returnString]
     )
     ⇒ lls_constraintNValues
```

```
axlCNSDesignValueGet(
     s_name
     [g_returnString]
     )
     ⇒ f_value/t_value/nil
```

Description

Fetches the values from those design constraints that support values. Use `axlCNSDesignValueGet(nil)` to determine the set of these constraints.

Note: Constraint checks may change from release to release.

©2023 All Rights Reserved.

Arguments

`nil`	Returns all checks that support values.
`'all`	Returns all checks with values and current value.
`s_name`	Symbol name of value.
`t_name`	String name of value.
`g_returnNameString`	Returns constraint names as strings (default is symbol return.)
`g_returnString`	By default, this returns native type in user units (a float) for all checks supported. If `t`, return is a MKS string where `nil` returns native.

Value Returned

`ls_names`	List of all controls that support values (symbol.)
`lls_constraintNValues`	List of all controls with their values `'((`*`s_name f_value/t_value`*`) ...` *`f_value`* = user unit value, and *`t_value`* = MKS string value.

Example 1

```
axlCNSDesignValueGet(nil)
```

Gets a list of design constraints that support values.

Example 2

```
axlCNSDesignValueGet('all 't)
```

Gets a list of settings for all design constraints with values returned as MKS strings.

Example 3

```
axlCNSDesignValueGet('Negative_Plane_Islands)
    = 10.0
```

Gets the current setting of `Negative_Plane_Islands` in user units.

©2023 All Rights Reserved.

Example 4

```
axlCNSDesignValueGet("Pad_Soldermask_Alignment" t)
    = "10 mils"
```

Gets the current setting of `Pad_Soldermask_Alignment` as a MKS string (this passes in inquiry as a string).

©2023 All Rights Reserved.

axlCNSDesignValueSet

```
axlCNSDesignValueSet(
     t_name/s_name
     f_value/t_value
     )
     ⇒ t/nil
```

```
axlCNSDesignValueSet(
     ll_constraintNValues
     )
     ⇒ t/nil
```

Description

This sets the value of the design constraint.

To determine the list of supported values, use the following command:

```
axlCNSDesignValueGet(nil)
```

You may set single values or a list of values:

```
'((s_name/t_name f_value/t_value) ...)
```

For performance reasons, changing a value does not invoke DRC. You must manually invoke DRC. See axlCNSMapUpdate for a set of interfaces you can use to mark changes in order to perform fewer DRC updates.

Note: Constraint checks may change from release to release.

©2023 All Rights Reserved.

Arguments

s_name	Symbol name of check.
t_name	String name of check.
f_value	Floating point value provided is assumed to be in the default user unit for the constraint. Value may be rounded.
t_value	If given as a string with MKS type, the value is converted to current user units for the constraint. Rounding may result.

Value Returned

`t`	Design constraint value set.
`nil`	Failed to set design constraint value.

Example 1

```
axlCNSDesignValueSet('Negative_Plane_Islands 10.0))
```

Sets a negative plan tolerance to 10 in current database units.

Example 2

```
axlCNSDesignValueSet('Negative_Plane_Islands "10.0 mils")
```

Sets a negative plan tolerance to 10 mils.

Example 3

```
axlCNSDesignValueSet('((Negative_Plane_Islands "20 inches")
    (Pad_Soldermask_to_Pad_Soldermask_Spacing 15.9)))
```

Sets various constraints to different values.

For a programming example, see `cns-design.il` which you can find in the following location:

```
<cdsroot>/share/pcb/examples/skill/cmds
```


©2023 All Rights Reserved.

axlCNSDFAExport

```
axlCNSDFAExport(t_fileName
     ) -> t_dfaFile
```

Description

Saves current attachment file.

Value Returned

`t`	if successful
`nil`	failed

See Also

axlCNSDFAImport

Example

Export DFA attachment file

```
ret = axlCNSDFAExport()
```


©2023 All Rights Reserved.

axlCNSDFAImport

```
axlCNSDFAImport(
     t_dfaFileName/nil
     ) -> t/nil
```

Description

This assigns or re-assigns a new DFA table to the design. Finds the file using DFACNSPATH and assumes a `.dfa` extension.

Arguments

t_name	Name of a DFA file. If `nil` DFA table is removed from the design

Value Returned

`t`	If successful
`nil`	Failed or if deleting attachment it does not exist

See Also

axlCNSDFAExport, axlCNSDFAMode

Examples

Assigns a DFA table file called `mfg.dfa`

```
axlCNSDFAImport("mfg")
```


©2023 All Rights Reserved.

axlCNSDFAMode

```
axlCNSDFAMode(
     s_option
     [s_DRCMode]
     ) -> t/nil/s_mode
```

Description

The function sets or queries the DFA mode. This accesses DFA options.

The `s_option` settings are:

`'table`	Returns name of DFA table (for example, `filename`)
`'mode`	Returns the current DRC mode
`'mode` with an argument of `'on, 'off` or `'batch`	Sets the DFA DRC mode

If DRC mode is enabled DRC is set to out of date.

Tip

Use `axlCNSDFAMode('table)` to test if a DFA table exists in design.

Arguments

`s_option`	See above
`s_DRCMode`	Optional argument for mode (see above)

Value Returned

`t`	if successful
`nil`	failed

For `'mode` can return `'on,'off` or `'batch`. For `'table` returns DFA table name (this is DFA_TABLE_NAME attribute contained in the dfa file. It may not always match original filename).

©2023 All Rights Reserved.

See Also

axlCNSDFAImport

Examples

1. Query if DFA table exists with design

```
ret = axlCNSDFAMode('table)
```

2. Get current DRC mode of DFA

```
ret = axlCNSDFAMode('mode)
```

3. Set current DRC mode of DFA to on

```
ret = axlCNSDFAMode('mode 'on)
```


©2023 All Rights Reserved.

axlCNSEcsetCreate

```
axlCNSEcsetCreate(
     t_name
     [t_copyName/o_dbidCopyEcset]
     )
     ⇒ o_dbidEcset/nil
```

Description

Creates a new ECset. Electrical Constraint Set (ECset) is a mechanism for packaging up a set of electrical constraints into a group and applying them to a set of nets. The name must be legal and less than the maximum length allowed. Function fails if the ECset already exists.

By default, the ECset is created empty. You can provide a second argument to copy the contents of another ECset into the new ECset.

Arguments

t_name	Name of new ECset (Changed to upper case) String must pass allowed character set.
t_copyName	Optional name to copy from.

Value Returned

o_dbidEcset	*dbid* of the new ECset
nil	Failed due to one of the following: the name is illegal, or the ECset already exists.

See Also

axlCNSDesignModeSet, axlCNSCreate

Example 1

```
axlCNSEcsetCreate("MyEmptyEcset")
```

Creates a new empty ECset.

Example 2

```
p = car(axlDBGetDesign()->ecsets)
```


©2023 All Rights Reserved.

```
axlCNSEcsetCreate("MyNewEcset" p)
```

Copies the contents of the first ECset in a list.

©2023 All Rights Reserved.

axlCNSEcsetDelete

```
axlCNSEcsetDelete(
     t_name/o_dbidEcset
     )
     ⇒ t/nil
```

Description

Deletes an ECset from the Allegro PCB Editor database and also deletes the *ELECTRICAL_CONSTRAINT_SET* property from any nets assigned this ECset value. Electrical Constraint Set (ECset) is a mechanism for packaging up a set of electrical constraints into a group and applying them to a set of nets.

If the ECset is locked, you must unlock it before you can delete it.

Arguments

t_name	ECset name
o_dbidEcset	ECset *dbid*

Value Returned

`t`	ECset successfully deleted.
`nil`	ECset is not deleted because of one of the following: the name is incorrect, or ECset is locked.

Example 1

```
axlCNSEcsetDelete("UPREV_DEFAULT")
```

Deletes an ECset by name.

Example 2

```
p = car(axlDBGetDesign()->ecsets)
axlCNSEcsetDelete(p)
```

Deletes the first ECset in a list of ECsets.

©2023 All Rights Reserved.

axlCNSEcsetGet

```
axlCNSEcsetGet(
     t_name
     )
     ⇒ o_dbidEcset/nil
```

Description

Returns the *dbid* of the electrical cset when you request it by the ECset name. Electrical Constraint Set (ECset) is a mechanism for grouping a set of electrical constraints and applying them to a set of nets.

Arguments

t_name	ECset name.

Values Returned

o_dbidEcset	*dbid* of the ECset requested.
nil	Function failed due to an illegal name.

See Also

axlCNSEcsetValueGet and axlCnsList

Example

```
axlCNSEcsetGet("foo")
```

Tests for the existence of an ECset named foo.

©2023 All Rights Reserved.

axlCNSEcsetModeGet

```
axlCNSEcsetModeGet(
     nil
     )
     ⇒ ls_constraints
```

```
axlCNSEcsetModeGet(
     'all
     )
     ⇒ lls_constraintNModes
```

```
axlCNSEcsetModeGet(
     s_name/t_name
     )
     ⇒ s_mode/nil
```

```
axlCNSEcsetModeGet(
     s_name/t_name
     'print
     ) ==> t_name/nil
```

Description

Returns the current DRC modes for checks that are members of electrical constraints. These modes pertain to the entire board. Electrical Constraint Set (ECset) is a mechanism for packaging up a set of electrical constraints into a group and applying them to a set of nets.

The `'print` mode offers the name shown in reports, similar to the show element command.

This has axlDebug support.

Note: Not all checks are available in all levels of Allegro PCB Editor. To determine the set of checks supported, use the command: `axlCNSEcsetModeGet()`. Constraint checks may change from release to release.

Arguments

`nil`	Returns all checks in design type DRC.
`'all`	Returns all checks and current mode.
`s_name`	Symbol name of the check.
`t_name`	String name of the check.
`'print`	Printable constraint name option.

©2023 All Rights Reserved.

Value Returned

ls_names	List of checks (*s_name* ...).
lls_names	List of checks and related modes ((*s_name s_mode*) ...)
s_mode	Returns mode `'on`, `'off`, or `'batch`
t_name	Printable constraint name.

See Also

axlCNSEcsetModeSet, axlCNSEcsetValueGet

Example 1

```
axlCNSEcsetModeGet(nil)
```

Lists currently available electrical constraints.

Example 2

```
axlCNSEcsetModeGet('all)
```

Lists settings for all electrical constraints.

Example 3

```
axlCNSEcsetModeGet('Maximum_Stub_Length)
```

Shows current setting of stub length.

Example 4

```
axlCNSEcsetModeGet("Maximum_Via_Count")
```

Shows current setting of via count.

©2023 All Rights Reserved.

axlCNSEcsetModeSet

```
axlCNSEcsetModeSet(
     t_name/s_name
     t_mode/s_mode
     )
     ⇒ t/nil

axlCNSEcsetModeSet(
     'all
     t_mode/s_mode
     )
     ⇒ t/nil

axlCNSEcsetModeSet(
     l_constraintNModes
     t_mode/s_mode
     )
     ⇒ t/nil

axlCNSEcsetModeSet(
     ll_constraintNModes
     )
     ⇒ t/nil
```

Description

Sets the DRC modes for checks that are members of the electrical constraints set. These modes control the entire board. Electrical Constraint Set (ECset) is a mechanism for packaging up a set of electrical constraints into a group and applying them to a set of nets.

Note: Not all checks are available in all levels of Allegro PCB Editor. To determine the set of checks supported, use the command: `axlCNSEcsetModeGet()`. Constraint checks may change from release to release.

You can set all checks using the argument `'all`, set individual checks using *`t_name`*, or set a list of checks with the same mode as shown:

```
'(s_name ...) t_mode/s_mode
'(t_name ...) t_mode/s_mode
```

You can list sets of checks as shown:

```
'((t_name t_mode) ...)
'((s_name s_mode) ...)
```

For performance reasons, changing modes or values does not invoke DRC. You must manually invoke DRC. See axlCNSMapUpdate on page 1349 for a set of interfaces you can use to mark changes in order to perform fewer DRC updates.

©2023 All Rights Reserved.

Caution

Future releases may add or subtract constraint checks. The axl interface does guarantee the checks returned by this interface will remain constant from release to release.

Arguments

s_name	Symbol name of the check.
t_name	String name of the check.
s_mode	Mode setting; may be `'on`, `'off`, or `'batch`.
t_mode	String mode setting; may be `"on"`, `"off"`, or `"batch"`.
`'all`	Set all checks for a given tier of Allegro PCB Editor.

Value Returned

`t`	DRC mode set.
`nil`	DRC mode not set.

Example 1

```
axlCNSEcsetModeSet('Maximum_Via_Count 'off)
```

Turns off max via check.

Example 2

```
axlCNSEcsetModeSet('all 'batch)
```

Makes all electrical constraints batch only.

Example 3

```
axlCNSEcsetModeSet('(Maximum_Crosstalk Route_Delay) 'off)
```

Turns two constraints off.

©2023 All Rights Reserved.

Example 4

```
axlCNSEcsetModeSet( '((Maximum_Crosstalk off)
    (Propagation_Delay on) (Route_Delay 'on) (Impedance 'batch)) )
```

Sets various constraints to different modes.

©2023 All Rights Reserved.

axlCNSEcsetValueCheck

```
axlCNSEcsetValueCheck(
     s_name/t_name
     g_value
     )
     ⇒ (t/t_errorMsg)/nil
```

Description

Checks the syntax of the given value against the allowed syntax for the given constraint. You use the function `axlCNSEcseValueGet (nil)` to get the constraint names. Electrical Constraint Set (ECSet) is a mechanism for packaging up a set of electrical constraints into a group and applying them to a set of nets.

Note: Allowed syntax may change from release to release.

Arguments

s_name	Symbol name of constraint.
t_name	String name of constraint.
g_value	Value to verify.

Value Returned

`t`	Syntax is correct.
t_errorMsg	Syntax is incorrect. The message indicates the reason.
`nil`	Constraint name is not supported.

Examples

```
axlCNSEcsetValueCheck('Net_Schedule_Topology "STAR")
```

Tests if allowed to set.

©2023 All Rights Reserved.

axlCNSEcsetValueGet

```
axlCNSEcsetValueGet(
     nil
     [g_returnNameString]
     )
     ⇒ ls_constraints
```

```
axlCNSEcsetValueGet(
     'all
     [g_returnString]
     )
     ⇒ lls_constraintNValues
```

```
axlCNSEcsetValueGet(
     o_ecsetDbid/t_ecsetName
     s_name
     [g_returnString]
     )
     ⇒ f_value/t_value/nil
```

Description

Fetches the constraint values for a given ECset. Electrical Constraint Set (ECset) is a mechanism for packaging up a set of electrical constraints into a group and applying them to a set of nets.

Use `axlCNSEcsetValueGet(nil)` to determine the set of allowable constraints.

Each ECset may have all or none of the allowed constraints.

You can retrieve the ECset values by the ECset name or by its *dbid*. You can get the *dbid* of an ECset by using one of the following commands:

- `axlDBGetDesign()->ecsets`
- `axlCNSEcsetCreate()`

Note: Constraint checks may change from release to release. Not all checks are available in all levels of Allegro PCB Editor.

©2023 All Rights Reserved.

Arguments

o_ecsetDbid	ECset *dbid*.
t_ecsetName	ECset name.
`nil`	Returns all checks that support values.
`'all`	Returns all checks with values and current value.
s_name	Symbol name of value.
t_name	String name of value.
g_returnNameString	Returns constraint names as strings (default is symbol return)
g_returnString	Default is to return native type for all checks supported, this is in user units (a float). If `t`, return is an MKS string where `nil` returns native.

Value Returned

ls_names	List of all controls that support values (symbol).
lls_constraintNValues	List of all controls with their values as shown: `'((`*s_name f_value/t_value*`) ...` *f_value* = user unit value and *t_value* = MKS string value.

Example 1

```
axlCNSEcsetValueGet(nil)
```

Gets a current list of design constraints that support values.

Example 2

```
ecsets = axlDBGetDesign()->ecsets
ecset = car(ecsets)
axlCNSEcsetValueGet(ecset 'all t)
```

Gets a list of settings for all design constraints with values returned as MKS strings.

Example 3

```
axlCNSEcsetValueGet("UPREVED_DEFAULT" 'Maximum_Via_Count)
```


©2023 All Rights Reserved.

```
    = 10.0
```

Gets the current setting of `Maximum_Via_Count` on ECset `UPREVED_DEFAULT`.

Example 4

```
axlCNSEcsetValueGet("UPREVED_DEFAULT" "Pad_Soldermask_Alignment" t)
    = "10 mils"
```

Gets the current setting of `Pad_Soldermask_Alignment` as a MKS string (this passes in inquiry as a string).

©2023 All Rights Reserved.

axlCNSGetDefaultMinLineWidth

```
axlCNSGetDefaultMinLineWidth(
     t_sublassName
     )
     => f_minLineWidthValue
```

Description

Retrieves the minimum default line width value for the specific subclass.

Arguments

t_subclassname	A subclass name of the ETCH or CONDUCTOR class.

Value Returned

f_minSpacingValue	Minimum line width value (in design units) on the subclass.

Example

```
axlCNSGetDefaultMinLineWidth("TOP")
                          => 0.004
```

Gets the minimum line width value for layer TOP.

©2023 All Rights Reserved.

axlCNSGetPhysical

```
axlCNSGetPhysical(
     t_cset
     t_layer
     s_constraint
     [g_string]
     )
     ==> g_value/nil
```

```
axlCNSGetPhysical(
     t_cset
     t_layer
     nil
     [g_string]
     )
     ==> ll_nameValue/nil
```

```
axlCNSGetPhysical(
     nil
     nil
     nil
     )
     ==> ls_cnsTypes
```

Description

In its first operational mode, obtains the value of a physical constraint given a cset and layer. In the second mode of operation, it obtains all physical constraint as name/value pairs for a cset on a layer. This, in turn, may be passed to `axlCNSSetPhysical`.

In the final mode, a list of all supported physical constraints may be obtained by passing three `nil` values to the interface:

```
axlCNSGetPhysical(nil nil nil)
```

Data types

Unless otherwise specified, constraints are in current design units.

`allow_etch`	(boolean) *`t/nil`*
`allow_ts`	(symbol) NOT_ALLOWED, ANYWHERE, PINS_ONLY, PIN_VIAS_ONLY
`allow_padconnect`	(symbol) ALL_ALLOWED, VIAS_PINS_ONLY, VIAS_VIAS_ONLY, NOT_ALLOWED

©2023 All Rights Reserved.

`vias`	(string) colon separates the list of via names. Vias are not layer dependent, so are only returned for TOP. Order is important for etch editing working layer model. Use axlCnsGetViaList to get the via list as a list of strings. When `width_max, dp_neck_gap, dp_primary_gap,` and `necklength_max` are set to 0, it indicates that this value is not used.

Arguments

`t_cset`	Name of a physical cset. Can use "" for "DEFAULT".
`t_layer`	ETCH layer name (for example, "ETCH/TOP" or "TOP"). If *`nil,`* applies the change to all layers.
`s_constraint`	Name of constraint. If *`nil,`* returns a set of symbol/value pairs of all constraints.
`g_string`	By default, returns value in the native units of the constraint. If *`g_string`* is *`t,`* always returns data as a string.

Value Returned

`g_value`	Value of constraint in design units, except for `same_net`, which is returned as a *`t/nil`*.
`ll_nameValue`	Name values of pairs of physical constraint symbol and constraint value for all physical (*`s_constraint g_value`*). '((`necklength_min` 10.0) (`neckwidth_max` 5.0) ...)
`ls_cnsTypes`	List of supported physical constraint names.
`nil`	Returns *`nil`* on error (or `allow_etch`).

Example 1

```
axlCNSGetPhysical("" "TOP" 'width_min)
```

Gets the minimum line width in the default cset, TOP layer.

Example 2

```
axlCNSGetPhysical("VOLTAGE" "BOTTOM" nil)
```


©2023 All Rights Reserved.

Gets all physical constraints for the DEFAULT, BOTTOM layer

Example 3

```
axlCNSGetPhysical("" "TOP" 'vias)
```

Gets the via list for default cset.

Example 4

```
axlCNSGetPhysical(nil nil nil)
```

Gets supported physical constraint symbols.

Example 5

```
cset = ""       ;; DEFAULT cset
foreach(subclass axlSubclassRoute()
layer = axlCNSGetPhysical(cset subclass nil)
printf("\nLAYER=%s\n\tconstraints=%L\n" subclass, layer)
)
```

Fetches all layers and constraints of physical cset DEFAULT.

See Also

axlCNSSetPhysical, axlCnsList, axlSubclassRoute, and axlCnsGetViaList

©2023 All Rights Reserved.

axlCNSGetPinDelayEnabled

```
axlCNSGetPinDelayEnabled()
     => t/nil
```

Description

Returns if pin delay is enabled.

Arguments

None

Value Returned

`t:`	Pin delay is enabled.
`nil:`	Pin delay is not enabled.

©2023 All Rights Reserved.

axlCNSGetPinDelayPVF

```
axlCNSGetPinDelayPVF()
     => t_pinDelayPVF
```

Description

Returns the pin delay propagation velocity factor.

Arguments

None

Value Returned

t_pinDelayPVF	If the pin delay propagation velocity factor is defined, it is returned as a string. If not defined, a blank string is returned.

©2023 All Rights Reserved.

axlCNSGetSameNet

```
axlCNSGetSameNet(
     t_cset
     t_layer
     s_constraint
     [g_string]
     )
     ==> g_value/nil
```

```
axlCNSGetSameNet(
     t_cset
     t_layer
     nil
     [g_string]
     )
     ==> ll_nameValue/nil
```

```
axlCNSGetSameNet(
     nil
     nil
     nil
     )
     ==> ls_cnsTypes
```

Description

Obtains a same net spacing cset values. Documentation same as axlCNSGetSpacing.

©2023 All Rights Reserved.

Arguments

t_cset	Name of a same net spacing cset. Can use "" for "DEFAULT". If `nil`, return the list of all supported same net constraint symbols. **Note:** The value of the other arguments is ignored if *t_cset* is `nil`.
t_layer	ETCH layer name ("ETCH/TOP" or "TOP"). *t_layer* cannot be `nil` or a blank or empty string.
s_constraint	Name of constraint. If `nil` returns a set of symbol/value pairs of all constraints for the layer specified by *t_layer.*
g_string	By default returns value in the native units of the constraint. If *g_string* is `t`, it will always return data as a string.

Value Returned

`g_value`	Value of constraint in design units
`ll_nameValue`	Name value pairs of spacing constraint symbol and constraint value for all spacing. (*s_constraint g_value*). *'((shape_shape 10.0) (line_line 5.0) ...)*
`ls_cnsTypes`	List of supported same net spacing constraint names.
`nil`	Returns nil on error (or same_net).

See Also

axlCNSSetSameNet, axlCnsList, axlCNSGetSpacing

Examples

- Get shape to shape same net spacing in default cset, TOP layer

```
axlCNSGetSameNet("" "TOP" 'shape_shape)
```

- Get all same net constraints for 25_MIL_SPACE, BOTTOM layer

```
axlCNSGetSameNet("25_MIL_SPACE" "BOTTOM" nil)
```

- Get all same net constraints for default BOTTOM layer as strings

```
axlCNSGetSameNet("" "BOTTOM" nil t)
```


©2023 All Rights Reserved.

- Get supported same net constraint symbols

```
axlCNSGetSameNet(nil nil nil)
```

- Fetch all layers and constraints of same net cset DEFAULT

```
cset = ""       ;; DEFAULT cset
foreach(subclass axlSubclassRoute()
layer = axlCNSGetSameNet(cset subclass nil)
printf("\nLAYER=%s\n\tconstraints=%L\n" subclass, layer)
)
```


©2023 All Rights Reserved.

axlCNSGetSameNetXtalkEnabled

```
axlCNSGetSameNetXtalkEnabled() => t/nil
```

Description

Returns if Same Net Xtalk is enabled.

Arguments

None

Value Returned

t:	same net Xtalk is enabled.
nil:	same net Xtalk is not enabled.

©2023 All Rights Reserved.

axlCNSGetSpacing

```
axlCNSGetSpacing(
     t_cset
     t_layer
     s_constraint
     [g_string]
     )
     ==> g_value/nil
```

```
axlCNSGetSpacing(
     t_cset
     t_layer
     nil
     [g_string]
     )
     ==> ll_nameValue/nil
```

```
axlCNSGetSpacing(
     nil
     nil
     nil
     )
     ==> ls_cnsTypes
```

Description

In its first operational mode, obtains the value of a spacing constraint given a cset and layer. All values are returned in design units, except for `same_net`, which is a boolean (*`t/nil`*). In a second mode of operation, it obtains all spacing constraints as name/value pairs for a cset on a layer. This, in turn, may be passed to `axlCNSSetSpacing`. For the final mode, a list of supported spacing constraints may be obtained by passing three *`nil`* values to this interface:

```
axlCNSGetSpacing(nil nil nil)
```

Data types

- Unless otherwise specified, constraints are in current design units.

`same_net`	(boolean) *`t/nil`*

- bbvia_gap is not layer dependent. You must use the TOP layer name as the `t_layer` value to get or set this value.

©2023 All Rights Reserved.

Arguments

t_cset	Name of a spacing cset. You can use "" for "DEFAULT".
t_layer	ETCH layer name (for example, "ETCH/TOP" or "TOP"). If *nil,* applies change to all layers.
s_constraint	Name of constraint. If *nil,* returns a set of symbol/value pairs of all constraints.
g_string	By default, returns value in the native units of the constraint. If *g_string* is *t*, always returns data as a string.

Value Returned

g_value	Value of constraint in design units, except for same_net, which is returned as *t/nil*.
ll_nameValue	Name value pairs of spacing constraint symbol and constraint value for all spacing (*s_constraint g_value*).'((shape_shape 10.0) (line_line 5.0) ...)
ls_cnsTypes	List of supported spacing constraint names.
nil	Returns *nil* on error (or same_net).

Example 1

```
axlCNSGetSpacing("" "TOP" 'shape_shape)
```

Gets shape to shape spacing in default cset, TOP layer.

Example 2

```
axlCNSGetSpacing("25_MIL_SPACE" "BOTTOM" nil)
```

Gets all spacing constraints for 25_MIL_SPACE, bottom layer.

Example 3

```
axlCNSGetSpacing("" "BOTTOM" nil t)
```

Gets all spacing constraints for DEFAULT, bottom layer as strings.

Example 4

```
axlCNSGetSpacing(nil nil nil)
```

Gets supported spacing constraint symbols.

©2023 All Rights Reserved.

Example 5

```
cset = ""       ;; DEFAULT cset
foreach(subclass axlSubclassRoute()
layer = axlCNSGetSpacing(cset subclass nil)
printf("\nLAYER=%s\n\tconstraints=%L\n" subclass, layer)
)
```

Fetches all layers and constraints of spacing cset DEFAULT.

See Also

axlCNSSetSpacing, `axlCnsList`, and axlSubclassRoute

©2023 All Rights Reserved.

axlCNSGetViaZEnabled

```
axlCNSGetViaZEnabled()
     => t/nil
```

Description

Returns if Via Z is enabled.

Arguments

None

Value Returned

t:	via Z is enabled
nil:	via Z is not enabled

©2023 All Rights Reserved.

axlCNSGetViaZPVF

```
axlCNSGetViaZPVF()
     => t_viaZPVF
```

Description

Returns the via Z propagation velocity factor

Argument

None

Value Returned

t_viaZPVF:	If the via Z propagation velocity factor is defined, it is returned as a string. If not defined, a blank string is returned.

©2023 All Rights Reserved.

axlCNSPhysicalModeGet

```
axlCNSPhysicalModeGet(
     nil
     ) ==> ls_constraints

axlCNSPhysicalModeGet(
     'all
     ) ==> lls_constraintNModes

axlCNSPhysicalModeGet(
     s_name/t_name
     ) ==> s_mode/nil

axlCNSPhysicalModeGet(
     s_name/t_name
     'print
     ) ==> t_name/nil
```

Description

This fetches the current physical DRC mode(s). Modes determine if a particular constraint is on or off. These modes apply to the entire board. To determine the set currently supported, physical modes do a `axlCNSPhysicalModeGet`(nil). The physical mode set may be a subset of physical values since the implementation may associate certain values under a master mode. For example, via_list is not a constraint and the differential pair mode is under the ecset domain.

Note: Future releases may add or subtract constraint checks. The axl interface does guarantee the checks returned by this interface will remain constant from release to release.

©2023 All Rights Reserved.

Arguments

nil	returns all modes that are in spacing domain
all	returns all checks and current mode
s_name	symbol name of check.
t_name	string name of check
'print	printable constraint name option

Value Returned

ls_names	list of checks (s_name ...)
lls_names	list of checks and their mode ((s_name s_mode) ...)
s_mode	mode 'on, or 'off
t_name	the printable constraint name

Examples

Get current list of physical constraints

```
axlCNSPhysicalModeGet(nil)
```

Get list of settings for all physical constraints

```
axlCNSPhysicalModeGet('all)
```

Get current mode of max line with

```
axlCNSPhysicalModeGet('width_max)
```

Get current setting of allow Ts using a string

```
axlCNSPhysicalModeGet("allow_ts")
```

See Also

axlCNSPhysicalModeSet, axlCNSGetPhysical

©2023 All Rights Reserved.

axlCNSIsCsetLocked

```
axlCNSIsCsetLocked(
     g_domain
     t_csetName
     )
     ==> t/nil
```

Description

This returns if a cset is locked. See discussion in axlCNSIsLockedDomain.

A locked cset has the following characteristics:

- Cannot be edited
- Has the effect of locking the entire domain

Argument

g_domain	domain of cset; `'physical`, `'spacing`, `'sameNet`, `'electrical`

Value Returned

- `t` if cset is deleted
- `nil`, if cset is not deleted due to being locked or not a cset

Examples

Command to check if the cset DEFAULT is locked

```
axlCNSIsCsetLocked('electrical "DEFAULT")
```

See Also

axlCNSDesignModeSet

©2023 All Rights Reserved.

axlCNSIsLockedDomain

```
axlCNSIsLockedDomain(
     g_domain
     )
     ==> t/nil
```

Description

Used to check if the is constraint domain locked. A locked constraint domain has the following characteristics:

- csets cannot be edited, although new csets can be added
- any object (for example, net) level property overrides are ignored

Notes:

- The spacing and sameNet domains are locked as a single domain.
- Locking is typically done via the techfile. In the techfile, you can lock individual csets. If one cset is locked, Allegro PCB Editor treats the entire domain as locked from the DRC perspective. When a domain is locked, any object level property constraint override is ignored.
- If a cset is locked it cannot be modified or deleted.

Tip

Use `axlCnsList(nil)` to get a list all domains.

Arguments

g_domain	domain of cset; `'physical`, `'spacing`, `'sameNet`, `'electrical`

Value Returned

- t if a constraint domain is locked.
- nil - domain is not locked

©2023 All Rights Reserved.

Examples

- Command to check if the Electrical domain locked

```
axlCNSIsLockedDomain('electrical)
```

- To find a list of locked domains

```
lockedDomains = setof( x axlCnsList(nil) axlCNSIsLockedDomain(x))
```

See Also

axlCNSCsetLock, axlCNSIsCsetLocked, axlCNSLockDomain, axlCNSDesignModeSet, axlCnsList

©2023 All Rights Reserved.

axlCNSLockDomain

```
axlCNSLockDomain(
     g_domain
     g_mode
     )
     ==> t/nil
```

Description

This command locks or unlocks a constraint domain.

See discussion in axlCNSIsLockedDomain.

Note: Changing the lock on a domain can take a considerable amount of time since DRC status for that domain needs to be updated. In the spacing domain dynamic shapes also need to be updated. If doing other changes, you should consider cloaking (axlDBCloak the entire process. This API already uses cloaking.

Arguments

g_domain	domain of cset; `'physical`, `'spacing`, `'sameNet`, `'electrical`
g_mode	may either be `t` (to lock) or `nil` to unlock

Value Returned

Returns `t` if lock status is updated, and `nil` in case of an error.

Examples

Lock Spacing and Same net spacing domains

```
axlCNSLockDomain('spacing t)
```

See Also

axlCNSIsLockedDomain

©2023 All Rights Reserved.

axlCNSOptions

```
axlCNSOptions(
     s_name
     [g_value]
     )
     ==> g_currentValue/ls_names
```

Description

Inquires and/or sets the value for constraint options. Typically, setting options will mark DRC out of date. It is calling code to update DRC.

Items currently supported:

Name	holeAlways
Value	`t` to `nil`
Set?	Yes
Description	Reports if hole check should always be done. Default is only to do the hole check if the pad is suppressed.
Equiv	*Analysis Modes – Spacing Options*
Side Effects	None

Arguments

`s_name`	Symbol name of control. `nil` returns all possible names
`s_value`	Optional symbol value to set. Usually a `t` or a `nil`.

Value Returned

See above.

`ls_names`	If name is `nil` then returns a list of all controls

See Also

axlCNSDesignModeSet, axlDBControl

Examples

Check hole always

©2023 All Rights Reserved.

```
old = axlDBControl('holeAlways, nil)
```


©2023 All Rights Reserved.

axlCNSPhysicalModeSet

```
axlCNSPhysicalModeSet(
     t_name/s_name
     t_mode/s_mode
     )
     ==> t/nil

axlCNSPhysicalModeSet(
     'all
     t_mode/smode
     )
     ==> t/nil

axlCNSPhysicalModeSet(
     l_constraintNModes
     t_mode/smode
     )
     ==> t/nil

axlCNSPhysicalModeSet(
     ll_constraintNModes
     )
     ==> t/nil
```

Description

This sets the current DRC modes (on/off) for checks in the area of physical constraints. These modes are global. To determine the constraints modes currently supported do a `axlCNSPhysicalModeGet(nil)`. We support several interfaces. All checks may be set (`'all`), individual checks, (`t_name`), list of checks with a same mode`'(s_name ...) t_mode/s_mode'(t_name ...) t_mode/s_mode` and sets of checks via a list of: `'((s_name/t_name s_mode/t_mode) ....)`

The constraints names may be passed as a symbol or a string. For performance reasons, you should either do all your updates in a single call or wrap individual changes in the map API (see axlCNSMapUpdate).

Note: Future releases may add or subtract constraint checks. The axl interface does guarantee the checks returned by this interface will remain constant from release to release.

©2023 All Rights Reserved.

Arguments

s_name:	symbol name of check.
t_name:	string name of check.
s_mode:	mode setting; may be 'on or 'off.
t_mode:	string mode setting "on or "off".
'all:	set all checks for given tier of Allegro.

Value Returned

Returns `t` if succeeds or nil if failure.

See Also

axlCNSPhysicalModeGet, axlCNSGetPhysical, axlCNSMapUpdate

Examples

Turn all constraints off

```
axlCNSPhysicalModeSet('all 'off)
```

Turn on line width max

```
axlCNSPhysicalModeSet('width_max 'on)
Turn two constraint to on
axlCNSPhysicalModeSet('(bbvia_stagger_max bbvia_stagger_min) 'on)
```

Set various constraints to different modes

```
axlCNSPhysicalModeSet( '((width_max off) (allow_etch 'on)) )
```


©2023 All Rights Reserved.

axlCNSSameNetModeGet

```
axlCNSSameNetModeGet(
     nil
     ) ==> ls_constraints

axlCNSSameNetModeGet(
     'all
     ) ==> lls_constraintNModes

axlCNSSameNetModeGet(
     s_name/t_name
     ) ==> s_mode/nil

axlCNSSameNetModeGet(
     s_name/t_name
     'print
     ) ==> t_name/nil
```

Description

Same as axlCNSSpacingModeGet.

©2023 All Rights Reserved.

Arguments

nil	returns all modes that are in same net spacing domain
'all	returns all checks and current mode
s_name	symbol name of check.
t_name	string name of check
'print	printable constraint name option

Value Returned

ls_names	list of checks (`s_name ...`)
lls_names	list of checks and their mode (`(s_name s_mode)` ...)
s_mode	mode 'on, or 'off
t_name	The printable constraint name

Examples

Get current list of same net spacing constraints

```
axlCNSSameNetModeGet(nil)
```

Get list of settings for all same net spacing constraints

```
axlCNSSameNetModeGet('all)
```

Get current setting of line to line

```
axlCNSSameNetModeGet('line_line)
```

Get current setting of line to shape using a string

```
axlCNSSameNetModeGet("line_shape")
```

See Also

axlCNSSameNetModeSet, axlCNSGetSameNet, axlCNSSpacingModeGet

©2023 All Rights Reserved.

axlCNSSameNetModeSet

```
axlCNSSameNetModeSet(
     t_name/s_name
     t_mode/s_mode
     )
     ==> t/nil

axlCNSSameNetModeSet(
     'all
     t_mode/smode
     )
     ==> t/nil

axlCNSSameNetModeSet(
     l_constraintNModes
     t_mode/smode
     )
     ==> t/nil

axlCNSSameNetModeSet(
     ll_constraintNModes
     )
     ==> t/nil
```

Description

Same as axlCNSSpacingModeSet.

Arguments

s_name:	symbol name of check.
t_name:	string name of check.
s_mode:	mode setting; may be 'on or 'off.
t_mode:	string mode setting "on or "off".
'all:	set all checks for given tier of Allegro.

Value Returned

Returns `t` if succeeds or `nil` if failure.

©2023 All Rights Reserved.

See Also

axlCNSSameNetModeGet, axlCNSGetSameNet, axlCNSSpacingModeSet

Examples

Turn off all same net spacing constraints

```
axlCNSSameNetModeSet('all 'off)
```

Turn on line to line check

```
axlCNSSameNetModeSet('line_line 'on)
```

Turn two constraints to on

```
axlCNSSameNetModeSet('(line_shape thrupin_line) 'on)
```

Set several constraints to different modes

```
axlCNSSameNetModeSet( '((line_line off)
                                (thrupin_shape on)) )
```


©2023 All Rights Reserved.

axlCNSSetPhysical

```
axlCNSSetPhysical(
     t_cset/nil
     t_layer/nil
     s_constraint
     g_value
     )
     ==> t/nil
```

```
axlCNSSetPhysical(
     t_cset/nil
     t_layer/nil
     ll_constraintValues
     nil
     )
     ==> t/nil
```

Description

Allows updating physical constraint values. By passing nil at the appropriate argument, values for all csets and all layers may be changed.

Data types

See `axlCNSGetPhysical` for the data type of each constraint.

Allowed Design Units:

- A number (integer or floating point) where units is current design units. Must not exceed accuracy of the design.
- Unitless string where accuracy cannot exceed database accuracy.
- String with units, data converted to current design units.

Allowed Data Values:

- Boolean: Use *`t/nil`* or *`"true"/"false"`*.
- Symbol: Use the symbol name or its string.

For best performance, when calling multiple axlCNS interfaces to update constraint values, wrap them in the `axlCnsMap` interfaces as shown below:

```
axlCNSMapClear()
axlCNSSetPhysical(nil nil 'width_min 5)
axlCNSSetPhysical("" nil 'allow_padconnect 'VIAS_PINS_ONLY)
```


©2023 All Rights Reserved.

```
...
axlCNSMapUpdate()
```

Single change calls do not require this.

For a list of physical constraints, see `axlCNSGetPhysical`. If adding/deleting individual vias, you may find it easier to use `axlCnsAddVia` and `axlCnsDeleteVia`.

Caution

Same_net behavior will change in 16.2. This does not change override values. For example, you can set width_min value in all csets, but if the you applied it to a net or constraint area as an override, it will still be used for those items.

Arguments

t_cset	Cset name. You can use "" for the DEFAULT cset. Use *nil* to apply changes to all csets.
t_layer	ETCH layer name (for example, "ETCH/TOP" or "TOP"). If nil, applies changes to all layers.
s_constraint	Constraint symbol to change. Use `axlCNSGetPhysical(nil nil nil)` for list of permissible values.
g_value	Value to update. For data types, see Data Types above.
ll_constraintValues	Multiple values may be updated by passing a list of lists for the third argument. `'((s_constraint g_value) ... )`

Value Returned

t	Success.
nil	An error occurs when the ECset name does not exist; the layer does not exist; the constraint does not exist; the value for the constraint is illegal; or the cset is locked.

Example 1

```
axlCNSSetPhysical(nil nil 'width_min 5)
```


©2023 All Rights Reserved.

Sets minimum line width on all constraints and layers

Example 2

```
axlCNSSetPhysical("" nil 'allow_etch t)
```

Sets `allow_etch` on all layers in default cset.

Example 3

```
axlCNSSetPhysical("VOLTAGE" "top" 'allow_ts "NOT_ALLOWED")
```

Doesn't allow Ts on top layer of VOLTAGE cset.

Example 4

```
axlCNSSetPhysical("VOLTAGE" "top" 'allow_ts 'NOT_ALLOWED)
```

Uses the same value.

See Also

`axlCNSGetPhysical`, `axlCNSMapClear`, `axlCNSMapUpdate` `axlCnsAddVia`, and axlCnsDeleteVia

©2023 All Rights Reserved.

axlCNSSetSpacing

```
axlCNSSetSpacing(
     t_cset/nil
     t_layer/nil
     s_constraint
     g_value
     )
     ==> t/nil
```

```
axlCNSSetSpacing(
     t_cset/nil
     t_layer/nil
     ll_constraintValues
     nil
     )
     ==> t/nil
```

Description

Allows updating spacing constraint values. By passing *nil* at the appropriate argument values for all CSets and all layers may be changed.

Data types

See axlCNSGetSpacing for the data type of each constraint.

Allowed Design Units:

- A number (integer or floating point) where units is current design units. Must not exceed accuracy of the design.
- Unit-less string where accuracy cannot exceed database accuracy.
- String with units, data converted to current design units.

Allowed Data Values:

- Boolean: Use *t/nil* or *"true"/"false"*.

Tip

For best performance, when calling multiple `axlCNS` interfaces to update constraint values, wrap them in the `axlCnsMap` interfaces as shown below:

```
axlCNSMapClear()
axlCNSSetSpacing(nil nil 'line_shape 10.0)
```


©2023 All Rights Reserved.

```
axlCNSSetSpacing("" nil 'line_line 5)
...
axlCNSMapUpdate()
```

Single change calls do not require this.

Tip

For a list of current spacing constraints, see `axlCNSGetSpacing`.

Caution

Same_net constraint has been moved to the same net spacing domain.

Caution

An idiosyncrasy when values sent as strings requires the number of decimal points to be no more than the current database accuracy, or the change will be rejected.

Caution

This does NOT change override values. For example, you can change the line to line value in all csets but if you have applied a net or constraint area override, it will still be used for those items.

©2023 All Rights Reserved.

Arguments

t_cset	The CSet name. You can use "" for DEFAULT CSet. Use *nil* to apply the changes to all CSets.
t_layer	The ETCH layer name (for example, "ETCH/TOP" or "TOP"). If *nil,* applies the changes to all layers.
s_constraint	Constraint symbol to change. Use `axlCNSGetPhysical(nil nil nil)` for a list of permissible values.
g_value	Value to update. For data types, see Data types above.
ll_constraintValues	Multiple values may be updated by passing a list of lists for the third argument. `'((s_constraint g_value) ... )`

Value Returned

t	Success.
nil	Indicates an error. An error occurs when the ECset name does not exist; the layer does not exist; the constraint does not exist; the value for the constraint is illegal; or the CSet is locked.

Examples

- Set line to shape spacing in all CSets, all layers

```
axlCNSSetSpacing(nil nil 'line_shape 5)
```

- Set line to line spacing to 5 on DEFAULT CSet, all layers

```
axlCNSSetSpacing("" nil 'line_line 5)
```

- Value of DEFAULT CSet

```
axlCNSSetSpacing("25_MIL_SPACE" "top" 'line_line 5)
```

- Set a single spacing for all ids for all layers

```
cnsIds = axlCNSGetSpacing(nil nil nil)
values = nil
defaultSpace = 10.0
foreach( id cnsIds
    values = cons(list(id defaultSpace) values)
    )
axlCNSSetSpacing("10_MIL_SPACE" nil values)
```


©2023 All Rights Reserved.

See Also

axlCNSGetSpacing, axlCNSMapClear, and axlCNSMapUpdate

©2023 All Rights Reserved.

axlCNSSetPinDelayEnabled

```
axlCNSSetPinDelayEnabled(g_value) => t
```

Description

Enables or disables Pin Delay.

Argument

g_value:	`t` or `nil` to indicate if Pin Delay is turned on or off.

Value Returned

`t`

©2023 All Rights Reserved.

axlCNSSetPinDelayPVF

```
axlCNSSetPinDelayPVF(g_value)
     => t/nil
```

Description

Sets a value for pin delay propagation velocity.

Arguments

g_value:	a string to define the new pin delay propagation velocity factor. A `nil` value indicates that the value is to be deleted.

Value Returned

t:	no errors
nil:	error detected

©2023 All Rights Reserved.

axlCNSSetSameNet

```
axlCNSSetSameNet(
     t_cset/nil
     t_layer/nil
     s_constraint
     g_value
     )
     ==> t/nil
```

```
axlCNSSetSameNet(
     t_cset/nil
     t_layer/nil
     ll_constraintValues
     nil
     )
     ==> t/nil
```

Description

Updates the same net spacing cset value. Documentation same as axlCNSSetSpacing.

©2023 All Rights Reserved.

Arguments

t_cset	CSet name, can use "" for DEFAULT CSet. Use `nil` to apply change to all CSet.
t_layer	ETCH layer name (for example, "ETCH/TOP" or "TOP"). If `nil` apply change to all layers.
s_contraint	Constraint symbol to change. Use `axlCNSGetSameNet`(`nil nil nil`) for list of permissible values.
g_value	Value to update. For data type, see above for "DATA TYPES".
ll_constraintValues	Multiple values may be updated by passing a list of lists for the third argument. '((s_contraint g_value) ...)

Value Returned

t	if succeeds
nil	an error if any of the following occurred: ■ ECSet name does not exit ■ layer does not exist ■ constraint does not exist ■ illegal value for constraint ■ CSet is locked

See Also

axlCNSGetSameNet, axlCNSSetSpacing

Examples

- Set line to same net spacing in all CSets, all layers

```
axlCNSSetSameNet(nil nil 'line_shape 5)
```

- Set line to line same net to 5 on DEFAULT CSet, all layers

```
axlCNSSetSameNet("" nil 'line_line 5)
```

- Value of DEFAULT CSet

```
axlCNSSetSameNet("25_MIL_SPACE" "top" 'line_line 5)
```


©2023 All Rights Reserved.

axlCNSSetSameNetXtalkEnabled

```
axlCNSSetSameNetXtalkEnabled(g_value)
     => t
```

Description

Enables or disables Same Net Xtalk.

Arguments

g_value:	`t` or `nil` to indicate if same net Xnet is turned on or off.

Value Returned

`t`

©2023 All Rights Reserved.

axlCNSSetViaZEnabled

```
axlCNSSetViaZEnabledenabled(g_value) => t
```

Description

Enables or disables Via Z.

Arguments

g_value:	`t` or `nil` to indicate if Via Z is turned on or off.

Value Returned

```
t
```


©2023 All Rights Reserved.

axlCNSSetViaZPVF

```
axlCNSSetViaZPVF(g_value)
     => t/nil
```

Description

Sets a value for Via Z propagation velocity factor.

Arguments

g_value:	a string to define the new via Z propagation velocity factor. A `nil` value indicates that the value is to be deleted.

Value Returned

t:	no errors
nil:	error detected

©2023 All Rights Reserved.

axlCNSSpacingMax

```
axlCNSSpacingMax(
     [s_spacingType]
     [t_layer]
     )
     => f_maxSpacing
```

Description

Returns maximum spacing in design. This can be worst case spacing of entire design or base upon the object filtering.

Maximum spacing is calculated from all spacings in the domains of spacing, same net, and assembly (APD+). The state of the check (on/off) is ignored (this is different from the minimum spacing API).

Arguments

s_spacingType	Symbol representing the spacing constraint type. The supported values are: `'line`, `'shape`, `'via`, `'pin`
t_subclassname	A subclass name of the class ETCH or CONDUCTOR or `nil` for all layers

Value Returned

`f_maxSpacing`	Maximum spacing on entire design or sub-filtered setting.

Examples

- Get maximum spacing on entire design

  ```
  axlCNSSpacingMax(nil)
  ```

- Get maximum spacing on lines (clines) layer TOP

  ```
  axlCNSSpacingMax('line "TOP")
  ```

- Get maximum spacing on lines (clines) all layers

  ```
  axlCNSSpacingMax('line nil)
  ```


©2023 All Rights Reserved.

See Also

axlCNSSpacingMin

axlCNSSpacingMin

```
axlCNSSpacingMin(
     [s_spacingType]
     [t_layer]
     )
     => f_minSpacing
```

Description

Returns minimum spacing value in the design. This can be the minimum spacing of entire design or based upon the object filtering.

Maximum spacing is calculated from spacings in the domains of spacing, same net, and assembly (APD+). The spacing check must be enabled (on) to be possibly included as a minimum.

Arguments

s_spacingType	Symbol representing the spacing constraint type. The supported values are: `'line`, `'shape`, `'via`, `'pin`
t_subclassname	A subclass name of the class ETCH or CONDUCTOR or `nil` for all layers

Value Returned

`f_minSpacing`	Minimum spacing on entire design or sub-filtered setting.

Examples

See Examples section of axlCNSSpacingMax

©2023 All Rights Reserved.

See Also

axlCNSSpacingMax

©2023 All Rights Reserved.

axlCNSSpacingModeGet

```
axlCNSSpacingModeGet(
     nil
     ) ==> ls_constraints

axlCNSSpacingModeGet(
     'all
     ) ==> lls_constraintNModes

axlCNSSpacingModeGet(
     s_name/t_name
     ) ==> s_mode/nil
```

Description

This fetches the current spacing DRC mode(s). Modes determine if a particular constraint is on or off. These modes apply to the entire board. To determine the set currently supported spacing modes do a axlCNSSpacingModeGet(nil).

The spacing mode set may be a subset of spacing values since the implementation may associate certain values under a master mode.

Note: Future releases may add or subtract constraint checks. The axl interface does guarantee the checks returned by this interface will remain constant from release to release.

©2023 All Rights Reserved.

Arguments

nil	returns all modes that are in spacing domain
'all	returns all checks and current mode
s_name	symbol name of check.
t_name	string name of check

Value Returned

ls_names	list of checks (s_name ...)
lls_names	list of checks and their mode ((s_name s_mode) ...)
s_mode	mode 'on, or 'off

See Also

axlCNSSpacingModeSet, axlCNSGetSpacing

Examples

Get current list of design constraints

```
axlCNSSpacingModeGet(nil)
```

Get list of settings for all design constraints

```
axlCNSSpacingModeGet('all)
```

Get current setting of line to line

```
axlCNSSpacingModeGet('line_line)
```

Get current setting of line to shape using a string

```
axlCNSSpacingModeGet("line_shape")
```


©2023 All Rights Reserved.

axlCNSSpacingModeSet

```
axlCNSSpacingModeSet(
     t_name/s_name
     t_mode/s_mode
     )
     ==> t/nil

axlCNSSpacingModeSet(
     'all
     t_mode/smode
     )
     ==> t/nil

axlCNSSpacingModeSet(
     l_constraintNModes
     t_mode/smode
     )
     ==> t/nil

axlCNSSpacingModeSet(
     ll_constraintNModes
     )
     ==> t/nil
```

Description

This sets the current DRC modes (on/off) for checks in the area of spacing constraints. These modes are global. To determine the constraints modes currently supported do a `axlCNSSpacingModeGet`(nil). We support several interfaces. All checks may be set ('all), individual checks, (t_name), list of checks with a same mode '(s_name ...) t_mode/s_mode '(t_name ...) t_mode/s_mode and sets of checks via a list of: '((s_name/t_name s_mode/t_mode) ....) The constraints names may be passed as a symbol or a string. For performance reasons, you should either do all your updates in a single call or wrap individual changes in the map API (see axlCNSMapUpdate).

Note: Future releases may add or subtract constraint checks. The axl interface does guarantee the checks returned by this interface will remain constant from release to release.

©2023 All Rights Reserved.

Arguments

s_name:	symbol name of check.
t_name:	string name of check.
s_mode:	mode setting; may be 'on or 'off.
t_mode:	string mode setting "on or "off"
'all:	set all checks for given tier of Allegro.

Value Returned

Returns `t` if succeeds or `nil` if failure.

See Also

axlCNSSpacingModeGet, axlCNSMapUpdate

Examples

Turn off all spacing constraints

```
axlCNSSpacingModeSet('all 'off)
```

Turn on line to line check

```
axlCNSSpacingModeSet('line_line 'on)
```

Turn two constraints to on

```
axlCNSSpacingModeSet('(line_shape thrupin_line) 'on)
```

Set several constraints to different modes

```
axlCNSSpacingModeSet( '((line_line off)
                                (thrupin_shape on)) )
```


©2023 All Rights Reserved.

axlCnsPurgeAll()

```
axlCnsPurgeAll(
     ) -> x_purgeCount
```

Description

Removes all unused constraint objects and constraint sets. Process all netclasses, regions, physical constraint sets and spacing constraint sets. Deletes all empty netclasses and regions.

Arguments

None

Value Returned

The count of the deleted items.

See Also

axlCnsPurgeCsets

Examples

```
axlCnsPurgeAll()
```


©2023 All Rights Reserved.

axlCnsPurgeCsets

```
axlCnsPurgeCsets(
     list l_type
     ) -> x_purgeCount
```

Description

Process all constraint sets of the specified domain and delete those without references.

This class of functions is design to help migrate designs to take advantage of the 16.0 constraint model. These functions do have to be used when migrating designs. Before using these functions you need to evaluate your constraint usage.

Arguments

Domain of interest 'physical or 'spacing

Value Returned

Count of the csets deleted.

Examples

```
axlCnsPurgeCsets('physical)
axlCnsPurgeCsets('spacing)
```

See Also

axlCnsPurgeObjects, axlCnsPurgeAll(), axlCnsDeleteClassClassObjects, axlCnsDeleteRegionClassClassObjects, axlCnsDeleteRegionClassObjects

©2023 All Rights Reserved.

axlCnsPurgeObjects

```
axlCnsPurgeObjects(
     list l_type
     ) -> x_purgeCount
```

Description

Process the database and delete all group_type objects that have no members; a netclass with no nets, or a region with no shapes.

Arguments

Domain of interest 'physical or 'spacing.

Value Returned

Count of the objects deleted.

Examples

```
axlCnsPurgeObjects('netclass)
axlCnsPurgeObjects('region)
```

See Also

axlCnsPurgeCsets

©2023 All Rights Reserved.

axlViaZLength

```
axlViaZLength(
     t_layer1
     t_layer2
     [g_inclusion]
     ) -> f_length
```

Description

Returns the via length from layer1 to layer2. The layer names can either be given as the ETCH subclass name (TOP) or given as the formal SKILL layer name ("ETCH/TOP").

This is the length used in the ViaZ option to several DRC checks.

By default, does not use the thickness of the layer1 or layer2 in its calculation.

Arguments

t_layer1	start layer name
t_layer2	end layer name
g_inclusion	Optional inclusion in calculation. ■ `first:` include thickness of t_layer1 ■ `'second:` include thickness of t_layer2 ■ `'both:` include both layers ■ `'nil:` do not include either

Value Returned

f_length	via length in design units

Examples

Get length from top to bottom (excluding top and bottom thickness)

```
axlViaZLength("TOP" "BOTTOM")
```


©2023 All Rights Reserved.

See Also

axlCNSGetViaZPVF

©2023 All Rights Reserved.

axlNetEcsetValueGet

```
axlNetEcsetValueGet(
     o_itemDbid/t_netName
     t_cnsName/s_name
     )
     ==> t_cnsValue/nil
```

Description

Returns the value of a specific electrical constraint that has been assigned to a given net. Both fixed and user defined constraints may be accessed. This will not return a "flattened" net view of constraints applied to pinpairs. Use `axlCnsNetFlattened` to obtain this constraint view.

Tip

If requesting multiple constraints from the same net it is faster to get the `dbid` of the net and pass that as first argument instead of using the net name.

Arguments

o_itemDbid	`dbid` of any item that is assigned to a net or Xnet.
t_cnsName	Property name for the constraint to be fetched. This can be either a fixed constraint or a user-defined constraint.
s_name	Symbol name of DRC check (values returned by `axlCNSEcsetModeGet(nil)`). These names may not exactly match the property name. They do not exist for user-defined properties in the ECset.

Value Returned

`t_cnsValue`	Value returned as a string.
`nil`	No value defined for the net.

See Also

axlCnsNetFlattened

©2023 All Rights Reserved.

Examples:

Net is part of an ECset (electrical constraint set) which has a MAX_EXPOSED_LENGTH constraint:

```
net = car(axlSelectByName("NET" "NET2")
rule = axlNetEcsetValueGet(net "MAX_EXPOSED_LENGTH")
```

Net has an override constraint for MAX_VIA_COUNT:

```
rule = axlNetEcsetValueGet("NET2" "MAX_VIA_COUNT")
```

Same as above example but uses the DRC check name:

```
rule = axlNetEcsetValueGet("NET2" 'Maximum_Via_Count)
```


©2023 All Rights Reserved.

axlCNSEcsetValueSet

```
axlCNSEcsetValueSet(
     o_ecsetDbid/t_ecsetName
     t_name/s_name
     f_value
     )⇒ t/nil
```

```
axlCNSEcsetValueSet(
     o_ecsetDbid/t_ecsetName
     ll_constraintNValues
     )
     ⇒ t/nil
```

Description

Sets the value of the ECset DRC. Electrical Constraint Set (ECset) is a mechanism for packaging up a set of electrical constraints into a group and applying them to a set of nets.

To determine the list of supported values, use the following command:

```
axlCNSEcsetValueGet(nil)
```

You may set single values or a list of values. *ll_constraintNValues* represents a list of values as shown:

```
'((s_name/t_name f_value/t_value) ...)
```

Passing a `nil` or empty string " " as a value deletes the constraint from the ECset.

For performance reasons, changing a value does not invoke DRC. You must manually invoke DRC. See axlCNSMapUpdate on page 1349 for a set of interfaces that you use in order to mark changes to perform fewer DRC updates.

Note: Constraint checks may change from release to release.

©2023 All Rights Reserved.

Arguments

o_ecsetDbid	*dbid* of the ECset.
t_ecsetName	Name of the ECset.
s_name	Symbol name of constraint.
t_name	String name of constraint.
f_value	Floating point value provided is assumed to be in the default user unit for the constraint. Value may be rounded.
t_value	If given as a string with MKS type, the value is converted to current user units for the constraint. Rounding may result.

Value Returned

`t`	Set value of ECset DRC.
`nil`	Failed to set value of ECset DRC due to incorrect argument(s).

Examples

Sets impedance:

```
axlCNSEcsetValueSet("UPREVED_DEFAULT"
                 'Impedance ALL:ALL:100.0:2)
```

Sets multi-value:

```
axlCNSEcsetValueSet("UPREVED_DEFAULT"
              '((Impedance "ALL:ALL:100.0:2") (Maximum_Via_Count 5)))
```


©2023 All Rights Reserved.

axlCnsGetViaList

```
axlCnsGetViaList(
     t_csetName
     )
     ==>lt_padstacks/nil
```

Description

Returns padstacks defined in a physical constraint set. If the cset name is provided then returns only vias assigned for that cset. Otherwise the function returns vias for all csets. The same vias may appear more than once when using the `nil` option.

If a cset name is given, order of vias in list effects the via selection behavior of the etch editing's working layer model (see this documentation for more information).

Note that padstacks in via list may not currently be loaded in database or may not exist on disk (via that cannot be found is shown by a `"*"` indicators in cns physical set dialog).

Arguments

t_csetName	Name of physical cset.
`nil`	Process all csets.

Value Returned

lt_padstacks	List of padstacks defined in a cset or all csets.
`nil`	If no padstacks found or cset not found.

See Also

axlCnsAddVia, axlCnsDeleteVia, and axlCNSGetPhysical

Examples

Report vias in default physical constraint set

```
axlCnsGetViaList("DEFAULT")
```

Report vias in all physical constraint sets

©2023 All Rights Reserved.

```
axlCnsGetViaList(nil )
```


©2023 All Rights Reserved.

axlGetAllViaList

```
axlGetAllViaList(
     [g_attrVias]
     )
     ==> lo_padstack_dbid
```

Description

Returns a list of all padstacks included in via lists in the design. This is a compilation of all via lists from all constraint sets. Optionally it provides padstacks from net VIA_LIST properties.

The order of padstack `dbids` depends on the order of constraint sets, VIA_LIST properties and the associated via lists.

Caution

This interface will result in the via padstacks being loaded into the design if they are not already loaded.

Arguments

[g_attrVias]	Optional argument to add padstacks that are not included in constraint sets but are provided in some net VIA_LIST attributes.

Value Returned

lo_padstack_dbid	List of padstack `dbids`.
`nil`	The design has empty via lists.

©2023 All Rights Reserved.

axlGetMaxSpacingCNS

```
axlGetMaxSpacingCNS(
     )
```

⇒ `list having spacing details/nil`

Description

This function returns the maximum spacing constraint between two objects. The function finds out constraint between the two objects and returns the largest constraint value along with the source of the constraint. In case the objects are on the same net, the API returns the same net spacing constraint value. Otherwise it returns the spacing constraint.

Arguments

obj1	dbid of the first object
obj2	dbid of the second object

Value Returned

`list`	A list containing the maximum constraint value, the constraint associated with the value, and the name of the constraint source which can be a CSet name or an attribute name
`nil`	If not found

Example

The following example shows the use of the function and sample output:

```
axlSetFindFilter(?enabled ( list "noall" "PINS" "VIAS" "CLINES") ?onButtons
(list "PINS" "VIAS" "CLINES"))
axlSingleSelectPoint(500:1000)
d1 = car(axlGetSelSet())
axlSingleSelectPoint(375:1050)
d2 = car(axlGetSelSet())
axlSingleSelectPoint(500:900)
d3 = car(axlGetSelSet())
axlSingleSelectPoint(700:975)
d4 = car(axlGetSelSet())
axlGetMaxSpacingCNS(d1 d2)
```


©2023 All Rights Reserved.

```
axlGetMaxSpacingCNS(d2 d3)
axlGetMaxSpacingCNS(d3 d4)
```

Sample output

- `(15.0 "Line to Thru Pin Same Net Spacing" "DEFAULT") <- after axlGetMaxSpacingCNS(d1 d2)`
- `(15.0 "Line to Thru Pin Spacing" "DEFAULT") <- after axlGetMaxSpacingCNS(d2 d3)`
- `(5.0 "Thru Pin to Thru Pin Spacing" "DEFAULT") <- after axlGetMaxSpacingCNS(d3 d4)`

©2023 All Rights Reserved.

axlGetSNSTolerance

```
axlGetSNSTolerance(
     )
```

⇒ `t/nil`

Description

This function returns the allowable tolerance for rules from the same net spacing domain.

Value Returned

`Tolerance value in user units`	If successful
`nil`	If not found

See Also

axlGetSPCTolerance

Example

```
ll = axlGetSNSTolerance( )
```


©2023 All Rights Reserved.

axlGetSPCTolerance

```
axlGSetSPCTolerance(
     )
```

⇒ `t/nil`

Description

This function returns the allowable tolerance for a rule from the spacing domain. If set, any actual violations for the rules under spacing domain that exceeds the spacing constraint by less than the tolerance are not reported as a DRC.

Value Returned

`Tolerance value in user units`	If successful
`nil`	If fail

See Also

axlGetSNSTolerance

Example

```
ll = axlGetSPCTolerance( )
```


©2023 All Rights Reserved.

axlDRCUpdate

```
axlDRCUpdate(
     g_mode
     ) -> x_cnt/nil
```

Description

Performs a DRC check on entire design.

Has two return options controlled via `g_mode` option:

- `nil`: interactive (on) checks; similar to `drcupdate` command
- `t`: on and batch checks; similar to `dbdoctor drc` option

Will enable On-Line DRC if it is disabled. Obeys current DRC mode settings.

Caution

Batch mode is being phased out.

Arguments

`g_mode`	`t` do all checks plus batch only checks, `nil` do only interactive checks

Value Returned

`x_cnt`	Returns number of errors

See Also

`axlDRCGetCount`, axlDBControl, `axlDRCWaive`, axlDBCheck

Example

Run a DRC check on a net named "GND"

```
db = axlDBFindByName('net "GND")
```

```
cnt = axlDRCItem(nil p)
```


©2023 All Rights Reserved.

axlDRCWaive

```
axlDRCWaive(
     g_mode
     o_DrcDbid/lo_DrcDbid
     [t_comment]
     )==> t/nil
```

Description

Manages waive DRC state and access to the waive DRC functionality. It supports both waiving and restoring (unwaive) DRC markers. The interface supports both a single and a list of DRC *dbids*. If restoring a DRC marker, it will reappear but it may no longer reflect an actual DRC error. This may be due to:

- Change in the constraint expected value
- Change in the object(s) causing DRC
- Different DRC mode settings

The only way of determining if a DRC still should exist is to perform an `axlDRCItem` on the first item in the DRC's *dbid* violation attribute. The exception to this rule is external DRCs where the tool that created the DRC must be re-run. Note: Comment can also be added by adding the comment property to the DRC by:

```
axlDBAddProp(drcDbid '("COMMENT" "This drc is OK"))
```


©2023 All Rights Reserved.

Arguments

g_mode	t: waive DRC. nil: unwaive DRC.
o_DrcDbid	A single DRC marker.
lo_DrcDbid	A list of DRC markers.
t_comment	Optional, add a comment to waived DRC. Only applies in waive mode.

Values Returned

`t`	Success.
`nil`	Failed due to incorrect arguments.

See Also

axlDBControl, `axlDRCWaiveGetCount`

Example 1 Waive 1st DRC in DRC list

```
p = axlDBGetDesign()->drcs
axlDRCWaive(t car(p) "This DRC is OK")
```

Example 2 Waive all DRCs in design

```
p = axlDBGetDesign()->drcs
axlDBGetWaive(t p)
```

Example 3 Restore all waived DRCs

```
p = axlDBGetDesign()->waived
axlDBGetWaive(nil p)
```


©2023 All Rights Reserved.

axlDRCGetCount

```
axlDRCGetCount(
     )⇒ x_count
```

Description

Returns the total number of DRCs in the design. Note the design DRC may be out of date.

Arguments

None.

Value Returned

x_count	DRC count.

©2023 All Rights Reserved.

axlDRCItem

```
axlDRCItem(
     g_mode
     o_dbid/lo_dbid
     )⇒ x_cnt/lo_drcDbid/nil
```

Description

Performs a DRC check on the indicated item(s). The *dbid* may be any *dbid* type (except the design). If the same item appears multiple times in the list, then the same DRC error(s) are returned, and the count is the sum of errors created by each *dbid*. The *g_mode* option controls two return options:

nil	Returns DRC error count.
t	Returns list of DRC errors.

This obeys current DRC mode settings, which includes the master DRC on/off switch.

Due to waive and duplicate DRC suppression processing, the list of DRCs returned using *g_mode=t* may be less then the count returned by *g_mode=nil*.

Caution

This is not an efficient way to run batch DRC or "what if" checks.

©2023 All Rights Reserved.

Arguments

g_mode	*nil*: Returns DRC error count.
	t: Returns list of DRC errors.
o_dbid	A single.

Value Returned

x_cnt	Returns number of errors associated with list of items.
lo_drcDBid	List of DRC *dbids.*
nil	No *dbids* (if *g_mode* = *t*) or error in arguments.

See Also

axlDRCGetCount, axlDBControl, axlDRCWaive, axlDRCUpdate

Examples

Run a DRC check on a net named "GND":

```
db = axlDBFindByName ('net "GND")
cnt = axlDRCItem(nil p)
```


©2023 All Rights Reserved.

axlDRCWaiveGetCount

```
axlDRCWaiveGetCount()
     ⇒ x_count
```

Description

Returns total number of waived DRCs in the design.

Arguments

None.

Value Returned

`x_count` Returns waived DRC count.

©2023 All Rights Reserved.

axlLayerSet

```
axlLayerSet(
     o_dbid
     )
     ==>o_dbid/nil
```

Description

Updates changes to layer parameters. You can only update the color and visibility attributes of a parameter. This is a wrapper for `axlSetParam`. After completing color or visibility changes, call `axlVisibleUpdate` to update the display.

Arguments

o_dbid	Layer parameter `dbid`.

Value Returned

o_dbid	Layer parameter `dbid`.
`nil`	If error.

See Also

axlSetParam and axlLayerGet

Examples

1. Change color of top etch layer:

```
q = axlLayerGet("ETCH/TOP")
q->color = 7
q->pattern = 0          ; solid pattern
q->visibility = nil
axlLayerSet(q)
; if setting multiple layer colors/visisbility only call
; visible update after last change
axlVisibleUpdate(t)
```

2. To set all items to the same color on a class do

```
q = axlGetParam("paramLayerGroup:ETCH")
q->color = 7
axlSetParam(q)
axlVisibleUpdate(t)
```


©2023 All Rights Reserved.

axlCnsList

```
axlCnsList(
     s_csetDomain/nil
     )
     ==> lt_csetNames/ls_csetsDomain
```

Description

Returns the list of cset names of the domain specified. See `axlDBGetDesign()->ecsets` for a list of electrical csets.

See Also

axlPurgePadstacks, axlCnsDeleteVia, axlCnsAddVia, and axlCnsGetViaList

Arguments

s_csetDomain	Domains supported: spacing, physical, sameNet, and electrical.
nil	Lists all supported domains.

Values Returned

lt_csetNames	Lists csets in specified domain.
ls_csetDomains	List of supported domains.

See Also

axlCNSCreate

Example 1

```
axlCnsList('spacing)
```

Returns all spacing cset names.

Example 2

```
axlCnsList(nil)
```


©2023 All Rights Reserved.

Returns supported domains.

©2023 All Rights Reserved.

axlCNSMapClear

```
axlCNSMapClear(
     )
     ⇒ t
```

Description

See `axlCNSMapUpdate`.

Arguments

none

Value Returned

`t`	Always returns `t`.

Examples

See axlCNSMapUpdate on page 1349 for an example.

©2023 All Rights Reserved.

axlCNSMapUpdate

```
axlCNSMapUpdate(
     )
     ⇒ x_drcCount/nil
```

Description

This function and `axlCNSMapClear`, which do not support nesting, batch and tune DRC updates from constraint changes made by `axlCNS<xxx>` functions. No `axlCNS<xxx>` functions perform a DRC update. Rather, they set the DRC system out-of-date.

You can run DRC system once on a *set* of constraint changes, which is more efficient than running it as part of each change. You may notice the increased efficiency on large boards.

Arguments

none

Value Returned

`nil`	There is no matching `axlCNSMapClear`.
`x_drcCount`	Number of DRCs caused by batch changes.

Examples

- Turns off electrical max via check, turns all design checks on, and sets the island tolerance to 10. The Clear/Update calls batch up and optimize the DRC update required by these changes.

```
axlCNSMapClear()
axlCNSEcsetModeSet('Maximum_Via_Count 'off)
axlCNSDesignModeSet('all 'on)
axlCNSDesignValueSet('Negative_Plane_Islands 10.0)
axlCNSMapUpdate()
```

- Doing one change.

```
axlCNSMapClear()
axlCNSEcsetModeSet('Maximum_Via_Count 'on)
xlCNSMapUpdate()
```


©2023 All Rights Reserved.

For other real examples, see `<cdsroot>/share/pcb/examples/cmds files cns-design.il` and `acns_design.form`.

©2023 All Rights Reserved.

axlCnsNetFlattened

```
axlCnsNetFlattened(
     o_netDbid/t_netName
     t_cnsName/s_name
     )
     ==> t_cnsValue/nil
```

Description

Permits a view of constraints where explicit pinpair rules are promoted to the net. The information reported by the function is the same as in `show element` under the Properties attached to net heading. It is also in a format used by the third party netlist (`netin`) and in the `pstxnet.dat` file used by `netrev`.

If pinpairs are constrained by an electrical rule (for example, PROPAGATION_DELAY), Allegro PCB Editor stores the constraints on the pinpair, not on the net. The electrical constraints stored on the net are those applied to dynamic pinpairs (the use of the `AD:AR`, `L:S`, syntax) or where the rule applies to the net (for example, MAX_VIAS).

This does not return all constraint values applied to the net, if the constraint is obtained via the electrical constraint set (ECset) or overrides exist at the bus or diffpair level. This information is reported in `show element` under the heading, Electrical constraints assigned to net. Allegro PCB Editor maps electrical constraints from xnets, matched groups, and pin pairs to nets by promoting or flattening the electrical property to present a traditional net view of the constraints and to provide compatibility with schematic netlisters. Additional constraints may effect the net because of the ECset assigned to the net, xnet, differential pair or bus level. Additional override properties may exist at the differential pair or bus level. You can use `axlNetECsetValueGet`, but it will not flatten constraints.

Tip

When requesting multiple constraints from the same net, use the `dbid` of the net as first argument instead of the net name.

©2023 All Rights Reserved.

Arguments

o_netDbid/ t_netName	`dbid` or name (string) of the net.
t_cnsName	Property name for the constraint.
s_name	Symbol name of DRC check (values returned by `axlCNSEcsetModeGet(nil)`. These names may not exactly match the property name.

Value Returned

t_cnsValue	Value returned as a string exactall.
`nil`	No value defined for the net.

Examples

Get impedance rule by name on `net1`:

```
rule = axlCnsNetFlattened("NET1" "IMPEDANCE_RULE")
```

Get impedance rule by DRC check name on `net1`:

```
rule = axlCnsNetFlattened("NET1" 'Impedance)
```

Get PROPAGATION_DELAY on MEM_DATA8 using the `dbid` of net:

```
net = car(axlSelectByName("NET" "MEM_DATA8"))
rule = axlCnsNetFlattened(net "PROPAGATION_DELAY")
```


©2023 All Rights Reserved.

axlSetSNSTolerance

```
axlSetSNSTolerance(
     tolerance_value
     )
```

⇒ `t/nil`

Description

This function can be used to set the allowable tolerance for rules from the same net spacing domain.If set, any actual violations for the rules under spacing domain that exceeds the spacing constraint by less than the tolerance are not reported as a DRC.

Arguments

tolerance_value	Allowable tolerance value as string in user units, such as `0.05`. This tolerance value is in current design units and changes when design units changes.

Value Returned

`t`	If successful
`nil`	If fail

See Also

axlSetSPCTolerance

Example

```
ll = axlSetSNSTolerance( "0.30")
```


©2023 All Rights Reserved.

axlSetSPCTolerance

```
axlSetSPCTolerance(
     tolerance_value
     )
```

⇒ `t/nil`

Description

This function can be used to set the allowable tolerance for rules from the spacing domain. If set, any actual violations for the rules under spacing domain that exceeds the spacing constraint by less than the tolerance are not reported as a DRC.

Arguments

tolerance_value	Allowable tolerance value as string in user units, such as `0.05`. This tolerance value is in current design unitsand changes when design units changes.

Value Returned

`t`	If successful
`nil`	If fail

See Also

axlSetSNSTolerance

Example

```
ll = axlSetSPCTolerance( "0.30")
```


©2023 All Rights Reserved.

DFM DRC Modes Functions

axlCNSModeSet

```
axlCNSModeSet(
     t_domain/s_domain
     t_name/s_name
     t_mode/s_mode
     )
     ⇒ t/nil
```

```
axlCNSModeSet(
     t_domain/s_domain
     'all
     t_mode/s_mode
     )
     ⇒ t/nil
```

```
axlCNSModeSet(
     t_domain/s_domain
     l_constraintNModes
     t_mode/s_mode
     )
     ⇒ t/nil
```

```
axlCNSModeSet(
     ll_domain
     ll_constraintNModes
     )
     ⇒ t/nil
```

Description

This function sets the current DRC modes for checks that fall into set of constraints belonging to a domain. These modes control the DRC for that check on the entire board.

To determine the set currently supported do a axlCNSModeGet().

This supports several interfaces.

All checks may be set to ('all), individual checks, (t_name), list of checks with a same mode '(s_name ...) t_mode/s_mode

'(t_name ...) t_mode/s_mode

and sets of checks via a list of:

©2023 All Rights Reserved.

'((s_name/t_name s_mode/t_mode) ....)

For performance reasons, changing modes or values does not invoke DRC automatically. You need to run the DRC manually. A set of interfaces supports marking changes to perform an minimal set of DRC updates depending upon your changes (see axlCNSMapUpdate).

Caution

Future releases may add or subtract constraint checks. The axl interface does guarantee the checks returned by this interface will remain constant from release to release.

Arguments

t_domain	String name of the domain; may be "electrical", "design" "dff" "dfa", "dft" "spacing" "physical"
s_domain	Symbol name of the domain; may be 'electrical, 'design, 'dff, 'dfa, 'dft, 'spacing, 'physical
s_name	Symbol name of check
t_name	String name of check
s_mode	Mode setting; may be 'on, 'off, or 'batch
t_mode	String mode setting "on", "off" or "batch"
'all	Set all checks for given tier of allegro in the specified domain.

Value Returned

t	If successful
nil	If failed

See Also

axlCNSDesignModeGet, axlCNSDesignValueGet, axlCNSMapUpdate

Example

- Turn on pkg to pkg keepin check

```
axlCNSModeSet('design 'Package_to_Place_Keepin_Spacing 'on)
```


©2023 All Rights Reserved.

- Make all design constraints batch only

```
axlCNSModeSet('design 'all 'batch)
```

- Turn two constraint to off

```
axlCNSModeSet('design '(Negative_Plane_Islands Pad_Soldermask_Alignment)
'off)
```

- Set various constraints to different modes

```
axlCNSModeSet('design '((Package_to_Place_Keepin_Spacing off)
(Package_to_Place_Keepout_Spacing 'on)))
```

- Turn on all DFF constraints

```
axlCNSModeSet('dff 'all 'on)
```

- Turn off all DFT constraints

```
axlCNSModeSet('dft 'all 'off)
```


©2023 All Rights Reserved.

axlCNSModeGet

```
axlCNSModeGet(
     t_domain/s_domain
     nil
     )
     ⇒ ls_constraints

axlCNSModeGet(
     t_domain/s_domain
     'all
     )
     ⇒ lls_constraintNModes

axlCNSModeGet(
     t_domain/s_domain
     'editable
     )
     ⇒ t/nil

axlCNSModeGet(
     t_domain/s_domain
     s_name/t_name
     )
     ⇒ s_mode/nil

axlCNSModeGet(
     t_domain/s_domain
     s_name/t_name
     'print
     )
     ⇒ t_name/nil
```

Description

This function fetches the current DRC modes for checks that fall into set of constraints under the specified domain. These constraints pertain to the entire board.

The 'print mode offers the name shown in reports like show element. This has axlDebug support.

Caution

Future releases may add or subtract constraint checks. The axl interface does guarantee the checks returned by this interface will remain constant from release to release.

©2023 All Rights Reserved.

Arguments

t_domain	String name of the domain; may be "electrical", "design" "dff" "dfa", "dft" "spacing" "physical"
s_domain	Symbol name of the domain; may be 'electrical, 'design, 'dff, 'dfa, 'dft, 'spacing, 'physical nil: returns all checks in the DRC domain specified 'all: returns all checks and current mode 'editable: returns t if mode can be change, nil otherwise nil is returned when in Allegro studio which does not offer this option
s_name	Symbol name of check
t_name	String name of check
'print	Printable constraint name option

Value Returned

`ls_names`	List of checks (s_name ...)
`lls_names`	List of checks and their mode ((s_name s_mode) ...)
`s_mode`	Mode 'on, 'off or 'batch
`t_name`	The printable constraint name

See Also

axlCNSDesignModeSet, axlCNSDesignValueGet

Example

- Get current list of design constraints

```
axlCNSModeGet( 'design nil)
```

- Get list of settings for all design constraints

```
axlCNSModeGet( 'design 'all)
```

- Get current setting of pkg to pkg

```
axlCNSModeGet('design 'Package_to_Package_Spacing)
```


©2023 All Rights Reserved.

- Get current setting of negative plane islands using a string

```
axlCNSModeGet("design" "Negative_Plane_Islands")
```

- Get the current settings of DFF constraints

```
axlCNSModeGet('dff 'all )
```


©2023 All Rights Reserved.

20

Command Control Functions

The chapter describes the AXL-SKILL functions that register and unregister AXL-SKILL functions with Allegro PCB Editor and set various modes in the user interface.

AXL-SKILL Command Control Functions

This section lists the command control functions.

©2023 All Rights Reserved.

axlCmdGetAppMode

```
axlCmdGetAppMode()
     -> t_appMode/nil
```

Description

Retrieves name of the current application mode.

Arguments

None

Value Returned

`nil`	If no current application mode ("none" picked)
`application mode`	If one is set

Example

```
axlCmdGetAppMode() ==> "generaledit"
```


©2023 All Rights Reserved.

axlCmdIsRegistered

```
list axlCmdIsRegistered(
     t_allegroCmd
     )
     ⇒ 'user/'system/nil
```

Description

Checks whether a command name is registered in the running application. Commands may be system commands or user-defined SKILL commands. If a command is already registered and you try to register it with `axlCmdRegister` using the same name, your command will replace the original. The original command will no longer be accessible in the system until your command has been unregistered again with `axlCmdUnregister`.

Arguments

t_allegroCmd	Name of command to be queried.

Value Returned

`'user`	Command is registered as a user-defined SKILL command.
`'system`	Command is registered as a standard Allegro product command.
`nil`	Command is not registered.

Example

```
(axlCmdIsRegistered "move")
```

See Also

axlCmdRegister, axlCmdUnregister

©2023 All Rights Reserved.

axlCmdRegister

```
list axlCmdRegister(
     t_allegroCmd
     ts_callback
     ?cmdType t_cmdType
     ?doneCmd ts_doneCmd
     ?cancelCmd ts_cancelCmd
     ?undo t
     )
     ⇒ t/nil
```

Description

Registers a command named *t_allegroCmd* with the Allegro PCB Editor shell system. If the command already exists, either because it is a base Allegro PCB Editor command or because it has been registered by this function at an earlier time, it will be hidden.

Additional arguments on the Allegro command line are passed unparsed to the AXL program.

You can call the `axlCmdRegister()` function at any time. Once a command is registered, you can type it at the Allegro PCB Editor command line and also incorporate it into menus and pop-ups.

Tip

Interactive mode should be used if you are changing the database. It will "done" an active interactive command before starting your command. General mode should be used to view the database or to provide some non-database capabilities. It is allowed to co-exist with other general and interactive commands. If changing the database using a form only command, for example, not requesting user picks from the canvas, then you should provide a dummy event handler to prevent your SKILL code from returning to Allegro.
See example in `<cdsroot>/share/pcb/examples/skill/cns-design.il` function `_AcDesignEvent()`.
You can pass arguments from the Allegro command line to your registered SKILL function. See `<cdsroot>/share/pcb/examples/skill/examples/axlcore/arg.il`

Commands that support undo or redo must follow the programming concepts.

Programming checklist includes:

- utilize `axlDBTransaction` APIs around database changes
- do not save or open the databases

©2023 All Rights Reserved.

- do not call `axlRunBatchDBProgram` with an option to reload the database
- do not make use of `axlShell`
- if your program typically performs extensive database changes, do not register it as undoable due to memory consumption requirements

The following items do not follow undo or redo:

- files saved or updated on disk
- database attachment changes (see `axlCreateAttachment`)
- communication to external programs or user interfaces
- certain design state changes such as active layer
- if your program maintains state across invocations then redo may not work properly

An interactive command may be updated or written to support undo (see `cline2shape.il`) using two models:

- Undo all Allegro database changes made by the command from start to done. If you use database transactions in an existing SKILL command then to convert it to support undo all you need to do is to add the undo option to `axlCmdRegister`.
- To have it work like place manual, where each individual placement operation is an undo then you will need to revamp the transaction model of your code. You need to start and commit and a database transaction around each user change to the design. The `cline2shape.il` shows how the code is slightly different in transaction handling between the two modes.
  - Avoid doing a start transaction with the undoMark symbol and a commit if you do not perform database operations.
  - If you do this incorrectly, additional undo items are listed on the toolbar's undo icon. The code still performs properly but some undo operations will not do anything.

Caution

You cannot access interactive Allegro PCB Editor commands using `axlShell` ***if you register your SKILL code as interactive, because nesting of interactive commands is not supported. This includes using*** `axlShell` ***to spawn Allegro PCB Editor scripts that contain interactive commands, which are those that display in the lower left side of the Allegro PCB Editor window (where the*** `Idle` ***string appears). For an interactive command, the status area shows the command name. Failing that, if you***

©2023 All Rights Reserved.

notice odd behavior when calling `axlShell`***, try changing your command type to General. As noted above, you should not call any APIs in the*** `axlEnter` ***or*** `axlSelect` ***families in a General command type.***

©2023 All Rights Reserved.

Arguments

t_allegroCmd	Name of the command to register.
ts_callback	Name of SKILL callback routine called when the command is activated from the Allegro PCB Editor window.

t_cmdType	String denoting the type of this command:
	`"interactive"`
	In which case all the auto-interactive rules for interactive commands are applied to this command. This is the default value.
	`"general"`
	Immediate command that executes as soon as the command is called, even during another command. Use for display refresh commands, for example.
	`"sub_cmd"`
	Must be called inside an interactive command. Use this type for pop-up commands.

ts_doneCmd	*Done* callback function that Allegro PCB Editor calls when the user types `done` or selects *Done* from the pop-up. Can be either a symbol or string. If `nil`, Allegro PCB Editor calls `axlFinishEnterFun` by default. **Note:** The Done callback function is only registered for "`interactive`" command type. These arguments are ignored for any other command type.
ts_cancelCmd	Cancel callback function that Allegro PCB Editor calls when the user types `cancel` or selects *Cancel* from the pop-up. This argument can be either a symbol or a string. If it is `nil`, Allegro PCB Editor calls `axlCancelEnterFun` by default. **Note:** The Cancel callback function is only registered for "`interactive`" command type. These arguments are ignored for any other command type.
undo	If `t`, command can be undone. It is only applicable for `t_cmdType "interactive"`. Refer Tips section for programming requirements of undo commands. Other options may be added at a future time.

©2023 All Rights Reserved.

Value Returned

`t`	Command registered successfully.
`nil`	Command not registered.

See Also

axlCmdUnregister, axlCmdList, axlUIWHelpRegister, axlDBTransactionStart, axlCmdIsRegistered,

Example

Registers the command `my swap gates` as calling the function `axlMySwapGates`.

```
axlCmdRegister("interboxcmd"
     'axlEnterBox
     "interactive"
     ?doneCmd 'axlBoxDone
     ?cancelCmd 'axlBoxCancel)
axlCmdRegister( "my swap gates" 'axlMySwapGates
?cmdType "interactive" ?doneCmd 'axlMySwapDone
?cancelCmd 'axlMySwapCancel)
```

For commands (`s_allegroCmd` value) that accept parameters as strings, the SKILL function converts the parameters to symbols. The following example is of a registered function that takes arguments:

```
axlCmdRegister( "do it" 'do_print)
do it myFile Text AshFindAllText
```

Sample `axlCmdRegister()` with a registered function that takes arguments where *`myFile`* is an output port.

The following functions parse and process the *`do it`* arguments.

```
(defun do_print (arg1 description find_func) ;; Added to deal with strings
        myport = evalstring(arg1)            ;; Added to deal with strings
     do_print2( myport description find_func) ;; Added to deal with strings
        ) ;  ;; Added to deal with strings
# Here is the real function
(defun do_print2 (p description find_func)
    (let (list)
        (fprintf p "Properties on %s:\n" description)
```


©2023 All Rights Reserved.

```
        (setq list (apply find_func nil))
        (print_list_props list p)
        (fprintf p "\n\n")
        ) ; let
) ;
```

See `<cdsroot>/share/pcb/examples/skill/examples/axlcore/cline2shape.il` for the undo examples.

©2023 All Rights Reserved.

axlCmdUnregister

```
list axlCmdUnregister(
     t_allegroCmd
     )
     ⇒ t/nil
```

Description

Unregisters from the Allegro PCB Editor shell system, a previously registered command named `t_allegroCmd`. If the command already exists because it is a base Allegro PCB Editor command, the original command is available again. If the existing command was registered using axlCmdRegister, it will be lost.

Arguments

t_allegroCmd	Name of command to be unregistered.

Value Returned

`t`	Command unregistered successfully.
`nil`	Failed to unregister the specified command.

Example

```
axlCmdUnregister( "interboxcmd")See Also
```

axlCmdRegister, axlCmdIsRegistered

©2023 All Rights Reserved.

axlEndSkillMode

```
axlEndSkillMode(
     )
     ⇒ t
```

Description

Returns from the SKILL command mode to the program's command line. The SKILL exit function is mapped to this function. In a SKILL program this command has no effect.

Arguments

None

Value Returned

`t`	Always returns `t`.

Example

```
axlEndSkillMode()
⇒ t
```

Exits AXL-SKILL.

©2023 All Rights Reserved.

axlFlushDisplay

```
axlFlushDisplay(
     )
     ⇒ t
```

Description

Flushes all data from the display buffer to the display screen itself. Displays items intended to be displayed, but not yet displayed because no event has triggered a flush of the display buffer.

You can display the following Items:

- Visible objects added to the database
- Messages
- Highlighting and dehighlighting of selected objects
- Pending display repairs

Generally, AXL delays screen updates until a prompt for user input occurs or an AXL program completes, such as `axlEnterPoint`. Certain programs, such as those that spend long times doing calculations between screen updates, might want to call `axlFlushDisplay` after each batch of screen updates to indicate the progress of the command. Overuse of this call may hurt performance.

Arguments

None

Value Returned

`t`	Always returns `t`.

©2023 All Rights Reserved.

Example

```
mypath = axlPathStart( list(8900:4400))
axlPathArcRadius(mypath, 12., 8700:5300, nil, nil, 500)
myline = axlDBCreatePath( mypath, "etch/top" nil)
; Arc is not yet visible
axlFlushDisplay()
; Now arc is visible
```

Creates a path and displays it immediately regardless of whether the user has caused a display event such as moving the cursor into the Allegro PCB Editor window.

©2023 All Rights Reserved.

axlOKToProceed

```
axlOKToProceed(
     )
     ⇒ t
```

Description

Checks whether Allegro PCB Editor is processing another interactive command or engaged in some process that might interfere with a SKILL command. Use this to check before starting functions such as `dbcreate`, user interactions, and select set operations. Returns `t` if Allegro PCB Editor is ready to properly execute a SKILL command, and returns `nil` if it is not.

Arguments

`t`	Suppresses the error message produced when it is not OK to proceed.

Value Returned

`t`	Allegro PCB Editor can allow AXL-SKILL database, selection, and interactive functions to execute.
`nil`	Allegro PCB Editor cannot allow AXL-SKILL database, selection, and interactive functions to execute.

Example

```
(when axlOKToProceed
    ;; do AXL interactive command
    )
```


©2023 All Rights Reserved.

axlSetLineLock

```
axlSetLineLock(
     ?arcEnableg_arcEnable
     ?lockAnglef_lockAngle
     ?minRadiusf_minRadius
     ?length45f_length45
     ?fixed45g_fixed45
     ?lengthRadiusf_lengthRadius
     ?fixedRadiusg_fixedRadius
     ?lockTangentg_lockTangent
     )
     ⇒ t/nil
```

Description

Sets one or more of the line lock parameters. The parameters are the same as those accessible in the *Line Lock* section of the Allegro PCB Editor Status form.

All parameters not explicitly set in a call to `axlSetLineLock` keep their current settings.

©2023 All Rights Reserved.

Arguments

g_arcEnable	If `t`, sets Lock Mode to `Arc`. Otherwise Lock Mode is Line. Default is Line.
f_lockAngle	Sets Lock Direction. Allowed values are: 45 (degrees), 90 (degrees), or 0 (off, or no lock).
f_minRadius	Sets Minimum Radius, a value in user units.
f_length45	Sets the Fixed 45 Length value in user units.
g_fixed45	If `t`, sets the Fixed 45 Length mode. You cannot set this parameter unless *f_lockAngle* is 45, and *g_arcEnable* is `nil`.
f_lengthRadius	Sets Fixed Radius value in user units.
g_fixedRadius	If `t`, sets the Fixed Radius mode. You cannot set this parameter unless *f_lockAngle* is 45 or 90, and *g_arcEnable* is `t`.
g_lockTangent	If `t`, sets the Tangent mode to `on`.

Value Returned

`t`	Set the given line lock parameters successfully.
`nil`	Failed to set the given line lock parameters.

Example

```
axlSetLineLock( ?arcEnable t ?lockAngle 90 ?fixedRadius t
?lengthRadius 50)
```

Sets the Line Lock parameters to Lock Direction: `90`, Lock Mode: `Arc`, Fixed Radius: `on` at `30` mils.

©2023 All Rights Reserved.

axlSetRotateIncrement

```
axlSetRotateIncrement(
     ?angularf_angular
     ?radialf_radial
     )
     ⇒ t/nil
```

Description

Sets the dynamic rotate angle increment in degrees (*f_angular*) or radians (*f_radial*). Sets the rotate increment for rotation of objects in the dynamic buffer.

Arguments

f_angular	Sets angle lock increment in degrees.
f_radial	Sets radial lock increment in radians.

Value Returned

t	Set the given rotate increment parameters successfully.

Example

```
(axlSetRotateIncrement ?angular 15)
⇒ t
```

Sets the dynamic rotate angle to 15 degrees.

©2023 All Rights Reserved.

axlUIGetUserData

```
axlUIGetUserData()
     ⇒ r_userData/nil
```

Description

Gets the current user data structure from Allegro PCB Editor. The user data structure stores basic information about the state of the user interface. By default it contains the properties:

doneState	How the user returned control to the application. Possible values are either: `done` or `cancel`.
popupId	List of the current pop-up values. A list of string pairs, as shown: `(("Done" "axlFinishEnterFun") ("Cancel" "axlCancelEnterFun"))`
ministatForm	Always `nil`. (Reserved for future releases.)

You can set your own attributes in the user data structure to communicate with callbacks, as shown in the example. You cannot overwrite the three basic attributes: *doneState*, *popupId*, or *ministatForm*.

Arguments

None

Value Returned

r_userData	User data structure from Allegro PCB Editor.
`nil`	Failed to get user data structure from Allegro PCB Editor.

Example

```
userdata = axlUIGetUserData()
    userdata->??
    ⇒ (doneState cancel
    popupId (("Cancel" "axlCancelEnterFun"))
    ministatForm nil
 )
```


©2023 All Rights Reserved.

axlUIPopupDefine

```
axlUIPopupDefine(
     r_popup
     ts_pairs)
     ⇒ r_popup/nil
```

Description

Creates a pop-up from the name value pair list . If *r_popup* is set appends the name value pairs to the end of the popup Returned id must be used when calling `axlUIPopupSet()` to activate the pop-up in layout editor.

Arguments

r_popup	Predefined pop-up handle to append new entries to. Can be `nil` to create a new pop-up.
ts_pairs	A list containing pairs of display name AXL callback. Number of pairs can be passed *((t_display t_dispatch) ...)* A display name of "MENU_SEPARATOR" coupled with a `nil` callback will result in a menu separation line in the popup.

Value Returned

r_popup	Id of the pop-up created or updated.
`nil`	No pop-up created or updated.

©2023 All Rights Reserved.

Example

```
(set popId (axlUIPopupDefine( nil
        (list (list "Complete" 'axlMyComplete)
        (list "Rotate" 'axlMyRotate)
        (list "Something" 'axlMySomething))))
        (list "Cancel" 'axlCancelEnterFun))

⇒ (     ("Complete" 'axlMyComplete)
        ("Rotate" 'axlMyRotate)
        ("Something" 'axlMySomething)
        ("Cancel" 'axlCancelEnterFun))
```

Creates a pop-up with the following selections:

- *Complete*, associated with your function `axlMyComplete`
- *Rotate*, associated with `axlMyRotate`
- *Something*, associated with `axlMySomething`
- *Cancel*, associated with `axlCancelEnterFun`

©2023 All Rights Reserved.

axlUIPopupSet

```
axlUIPopupSet(
     r_popup
     )
     ⇒ t/nil
```

Description

Sets the active pop-up in Allegro PCB Editor. If *r_popup* is `nil`, unsets the currently active pop-up.

If this call is preceded by a call to axlUICmdPopupSet with a non-nil r_popup, the contents of this popup are used to control graying of the popup items defined in the call to axlUICmdPopupSet. Otherwise r_popup is used to replace the popup entries. In both cases, the popup callbacks will be replaced.

Note: The popup is invoked by pressing mouse popup button, this is normally the right mouse button.

You can clear the active pop-up by calling outside of the form callback, as follows:

```
axlUIPopup (nil)
```

Arguments

r_popup	Predefined pop-up handle created by `axlUIPopupDefine`.

Value Returned

`t`	Set *r_popup* as the active pop-up.
`nil`	Failed to set *r_popup* as the active pop-up.

©2023 All Rights Reserved.

Example

```
popid = axlUIPopupDefine( nil
        (list (list "Complete" 'axlMyComplete)
        (list "Rotate" 'axlMyRotate)
        (list "Something" 'axlMySomething)
        (list "Cancel" 'axlCancelEnterFun))

⇒ (     ("Complete" 'axlMyComplete)
        ("Rotate" 'axlMyRotate)
        ("Something" 'axlMySomething)
        ("Cancel" 'axlCancelEnterFun))
```

Creates a pop-up with the following selections:

- *Complete*, associated with your function `axlMyComplete`
- *Rotate*, associated with `axlMyRotate`
- *Something*, associated with `axlMySomething`
- *Cancel*, associated with `axlCancelEnterFun`

```
axlUIPopupSet( popid)
    ⇒ t
```

Sets up the pop-up.

©2023 All Rights Reserved.

axlBuildClassPopup

```
axlBuildClassPopup(
     r_form
     t_field
     )
     ⇒ t/nil
```

Description

Supports building a form pop-up with a list of classes.

Arguments

r_form	Form handle.
t_field	Field name in form or pop-up name of form.

Value Returned

t	Pop-up built.
nil	Failed to build pop-up due to incorrect arguments.

Examples

```
axlBuildClassPopup(fw, "CLASS")
axlFormSetField(fw, "CLASS" axlMapClassName("ETCH"))
```


©2023 All Rights Reserved.

axlBuildSubclassPopup

```
axlBuildSubclassPopup(
     r_form
     t_field
     t_class
     )
     ⇒ t/nil
```

Description

Supports building a form pop-up with a list of subclasses from the indicated class.

Arguments

r_form	Form handle
t_field	Field name
t_class	Class name

Value Returned

t	Built form subclass pop-up.
nil	Failed to build form subclass pop-up due to incorrect arguments.

©2023 All Rights Reserved.

Example

```
    # place holder since popup will be overridden by the code
    POPUP <subclass>"subclass" "subclass".
    ...
    # field name should match t_field
    FIELD subclass
    FLOC 9 3
    ENUMSET 19
    OPTIONS prettyprint ownerdrawn
    POP "subclass"
    ENDFIELD
axlBuildSubclassPopup(fw, "subclass" axlMapClassName("ETCH"))
axlFormSetField(fw, "subclass" "GND")
```

Form file entry provides a subclass pop-up with color swatch support.

Note: `axlMapClassName` supports Allegro Package Designer L and Allegro Package SI XL, which rename certain classes.

©2023 All Rights Reserved.

axlSubclassFormPopup

```
axlSubclassFormPopup(
     r_form
     t_field
     t_class
     nil/lt_subclass
     )
     ⇒ t/nil
```

Description

Builds a form pop-up for a given Allegro PCB Editor class for a given field of *r_form* using the `axlSubclassFormPopup` function. This function is a combination of `axlGetParam` and `axlFormBuildPopup` with color swatching.

If the fourth argument is `nil`, the pop-up is based on all subclasses of the given class.

You can easily build a subclass pop-up containing current colors as swatches. To do this, add the following in the form file for that field:

```
OPTIONS ownerdrawn
```

Pop-ups built this way are dispatched back to the application as strings.

Note: if list of subclasses are passed, illegal subclass names are silently ignored.

To take advantage of color swatches in your subclass pulldown (ENUMSET) use this interface and the owner drawn option in the form file. The form file entry for your control should look like:

FIELD *<field name>*

FLOC *<x y location>*

ENUMSET *<width of field>*

OPTIONS *prettyprint ownerdrawn*

POP *<popup name>*

ENDFIELD

Note: The *prettyprint* option upper/lower cases the popup name the user sees.

©2023 All Rights Reserved.

Arguments

r_form	Standard form handle (see axlFormCreate on page 843)
t_field	Field name in form or pop-up name of form.
t_class	Class name.
nil/*lt_subclass*	Use nil for all members of the class, otherwise specify a list.

©2023 All Rights Reserved.

Value Returned

`t`	Form pop-up built.
`nil`	Failed to build form pop-up.

Example

```
axlSubclassFormPopup( form "subclass_name" "ETCH" nil)
```


©2023 All Rights Reserved.

axlVisibleUpdate

```
axlVisibleUpdate(
     t_now)
     ⇒ t
```

Description

The `axlVisible` family and its base building block permit changing layer color and visibility.

```
axlSetParam("paramLayerGroup:...")
```

You can also use these functions in conjunction with Find Filter interaction to permit filtering objects by layer via changing visibility.

The SKILL application must indicate display update via `axlVisibleUpdate` when changing visibility on the user.

Updates any forms that display color or visibility to the user.

For most situations, pass `nil` to this function. This defers updating the main graphics canvas until control is returned to the user, allowing a combination of several canvas updates into one update.

Arguments

`t`	Update now.
`nil`	Update when control is returned to the user.

Value Returned

`t`	Returns `t` always.

©2023 All Rights Reserved.

Example 1

```
;; You should not interact with the user when you have
;; visibility modified
;; get current visibility
p = axlVisibleGet()
axlVisibleDesign(nil) ; turn off all layers
;;... change visiblity of selected layers ...
;;... Selection of objects without user interaction
; restore visibility
axlVisibleSet(p)
```

Selects items using visibility without updating the display.

Example 2

```
;; only leave top etch layer on
axlVisibleLayer("etch" nil)
axlVisibleLayer("etch/top" t)
; update display when control is returned to the user
axlVisibleUpdate(nil)
```

Updates the display after changing visibility.

Example 3

```
p = axlLayerGet("etch/top")

; legal numbers are 1 to 24
p->color = 10
axlSetParam(p)

;make this call after you change all colors and visibility
axlVisibleUpdate(t)
```

Changes color on top etch layer.

©2023 All Rights Reserved.

21

Polygon Operation Functions

This chapter describes the AXL/SKILL Polygon Operation functions and includes the following sections:

- About Polygon Operations
- AXL-SKILL Polygon Operation Attributes
- AXL-SKILL Polygon Operation Functions
- Use Models

About Polygon Operations

A *poly* is a set of points linked so that the start and end point are the same. A poly is always non-intersecting and may contain *holes*. A hole is a non-intersecting closed loop enclosed within a poly.

Figure 21-1 Poly with Holes

Note: These polys refer to the `o_polygon` object in AXL-SKILL. Polys are different from the AXL SKILL Database *polygon* object which represents an Allegro PCB Editor unfilled shape.

These functions, which perform geometric operations on polys, are called logical operations and do the following:

©2023 All Rights Reserved.

- Create route keepouts based on the board outline, offset by a pre-determined distance.
- Create split planes from route-keepin and Anti-etch.
- Automatically generate a package keepout surrounding a package and its pins, contoured around the package.

Logical operations in AXL-SKILL enable SKILL programmers to do the following:

- Create logical operation objects (`lo_polygon`) from these Allegro PCB Editor database objects:
  - pins
  - lines
  - clines
  - vias
  - shapes
  - rectangles
  - frectangles (filled rectangles)
  - voids
- Create `o_polygon` from holes in a poly (`o_polygon`)
- Create an Allegro PCB Editor database shape from an `o_polygon`
- Perform geometric operations on `lo_polygons`, resulting in the creation of other `lo_polygons`.
  - Logical AND - The intersection of two polys.

©2023 All Rights Reserved.

- Logical OR - The union of two polys.

- Logical ANDNOT - Subtracting one poly from another.

- Logical EXPAND (CONTRACT is expand in the opposite direction.)

- Perform query operations on a `o_polygon`, including the following:
  - The area of the poly
  - The bounding box around the poly
  - The holes and vertices of a poly
  - If the `o_polygon` is a hole
- Access path data and holes from an `o_polygon`
- Locate a point respective to the poly

©2023 All Rights Reserved.

Error Handling

Return values for each function are specified along with the description of the function, in case of error.

AXL-SKILL Polygon Operation Attributes

The following are the attributes of the *o_polygon* type:

Attribute Name	Type	Description
area	float	Area of the poly in the same units as the drawing.
bBox	bBox	Poly's bounding box.
vertices	list	Path-like data of the outer boundary of the poly available as a list of lists where each of the sublists will contain a point representing a vertex of the poly and a floating point number representing radius of the edge from the previous vertex to the present vertex. No arcs spanning across quadrants or greater than 90 degrees. Radius of 0.0 indicates a straight line edge between the two vertices. Positive radius value indicates that the arc lines to the left of the center and negative radius imply that the arc lies to the right of the center of the arc.
holes	list	*lo_polygon*
isHole	boolean	`t` = hole, `nil` = poly

©2023 All Rights Reserved.

The following figures illustrate the attributes described.

■ Attributes

```
vertices(((9775.0 775.0)0.0)
     ((9100.0 1075.0)0.0)
     ((8350.0 950.0)0.0))
holes(poly:20199696 poly:20199896
     poly:22204476)
isHole nil
```

Note: All the 3 polys representing holes of the above poly have their isHole attribute set to `t`.

■ Attributes

```
vertices(((5975.0 976.0)   0.0)
     ((5787.0 788.0) 188.0)
     ((7225.0 599.0)   0.0)
     ((7413.0 787.0)-188.0)
     ((7225.0 975.0-188.0))

holes nil
isHole nil
```


©2023 All Rights Reserved.

AXL-SKILL Polygon Operation Functions

This section lists the polygon operation functions.

axlPolyFromDB

```
axlPolyFromDB(
     o_dbid/r_path
     ?endCapTypes_endCapType
     ?layert_layer
     ?padType s_padType
     ?holes      t/nil
     ?line2poly  t/nil)
     ?xhatch t/nil)
     ?window nil/bBox)
     ⇒ lo_polygon
```

Description

Creates a list of *o_polygon* objects from the *dbid* or an *r_path*. Use the *lo_polygon* list to get the polygon attributes or to perform logical operations on these polygons. In the case of *r_path* option, this function expects a path that reflects a closed shape with no intersections. It is important that the first and last point be the same. The width option of *r_path* is ignored as well as the '?' arguments to `axlPolyFromDB`.

Polygon Attributes

area	(float) Area of polygon in design units. If a hole this is negative. If a polygon is not a hole then the area is the sum of the base poly area minus any of its holes.
bBox	(bBox) bounding box of polygon
holes	(list of o_polys/nil) list of any holes in polygon
isHole	(t/nil) is this a hole (void) or a shape
objType	(t_string) "polygon"

©2023 All Rights Reserved.

vertices (list of coordinates). This always describes a closed shape.

Format for each coordinate is:

`(xy f_radius)`

Where

`xy` - vertex point in design units

`f_radius` - 0 if previous point and this point forms a segment else points form a arc with radius. The positive sign of the radius indicates that the arc is to the left of the y-axis and a negative sign indicates arc is to the right.

If arcs are present a polygon typically may contain more segments than the underlying shape dbid. This is due to the polygon arcs cannot cross a quadrant so are broken along quadrant boundaries.

Notes

- A polygon is not a dbid.
- Comparing two polys using SKILL functions:
  - equal function: geometrically compares that two polygons are the same thus slightly slower than the eq function.
  - eq function compares that the polygon ids are the same.

This is different from the dbid comparison where both the `equal` and `eq` return the same results.

What this means from a programming standpoint, is that if you have two identical shapes in Allegro PCB Editor, the '`equal`' comparison on the shape dbids returns that they are not equal but converting these shapes to polys via `axlPolyFromDB` and doing a 'equal' of the resulting polygons will return '`t`' while the 'eq' comparison will return 'nil'.

©2023 All Rights Reserved.

Arguments

o_dbid	axl *dbid* for one of the following: path (line, cline,or bondwire), shape, rect, frect, pin, via, void,bond finger, segment (arc or line), figure, text or DRC from which to construct the polygon. **Note:** Arc and line are segments reported by `show element`.
r_path	Path construct from the `axlPath` API family. This is not an Allegro PCB Editor database object and is a much more efficient method for creating an Allegro PCB Editor shape, than converting it to a Poly. Note `axlDBCreateOpenShape` also supports an *r_path*. For more details, see `line2poly`. `r_path` must describe a closed non-intersecting shape unless the line2poly is `t` (see below).
s_endCapType	Keyword string specifying the end cap type to use for the polygon, one of `'SQUARE`, `'OCTAGON`, or `'ROUND`. Used in case of line or cline only, otherwise ignored. Default is `'SQUARE`. Used in case of line or cline only.
t_layer	String specifying the layer of the pad to retrieve, for example, `"ETCH/TOP"`. Used in the case of pin or via only, otherwise ignored. Default is `"ETCH/TOP"`.
s_padType	Keyword string specifying the type of the pad to be retrieved, one of `'REGULAR`, `'ANTI`, `'THERMAL, or 'KEEPOUT`. Used for pins, vias, or if `r_path` is based with the `line2poly` option, otherwise ignored. Default is `'REGULAR`.
`holes`	Default value is `t`. If the value is set to `t`, for shapes with voids returns any voids as holes. If the value is set to `nil`, does not return the holes.
`line2poly`	Applicable only if first argument is an `r_path`. By default, an `r_path` describes a closed path. When this option is `t`, the `r_path` itself is converted to a polygon in a manner similar to line dbids. It is strongly recommended that the `r_path` has width otherwise the artwork undefined line width is used.Typically one polygon is returned for each segment in the `r_path`. If the value is set to `nil`, the `r_path` which describes a closed path is converted to that closed polygon. If the `r_path` does not describe a closed path, then this argument makes no difference. The default is `t`.

©2023 All Rights Reserved.

`xhatch`	If `t` and the dbid is a cross-hatch shape returns a polygon of the cross-hatching. By default, cross-hatch shapes are treated as solid shapes with respect to polygon generation. For complex shapes (>500 edges; this includes both outline and voids) generating a poly of the cross-hatching can take a considerable amount of time and memory.If this option is `t`, the holes option for cross-hatch shapes is assumed to be `t`.
`window`	For converting shape objects, this option provides a bounding box to restrict the extents of the returned shape. Only the metal of the shape, which is inside this window is returned. For large complex shapes with many voids, this can be much more efficient than requesting the full poly and then using an axlPolyOperation call to cut it down to the area of interest. Default value is nil.

Value Returned

`lo_polygon`	Object representing the resulting geometry.
`nil`	Cannot get polygons from the object.

See Also

Other APIs that support or generate polygons:

- axlPolyOperation – performs various logical operations on 2 lists of polygon
- axlPolyExpand – expands or contracts polygon
- axlIsPolyType – is object a polygon object
- axlPolyErrorGet – returns last error from axlPolyOperation
- axlPolyFromDB – converts an Allegro dbid to a polygon
- axlPolyFromDrillHole – return a poly for a drill hole
- axlPolyMemUse – debug function to return memory use of polygon sub-system
- axlPolyOffset – moves a polygon
- axlPolyFromHole – converts a hole polygon to a positive polygon
- axlDBCreateShape – creates a shape

©2023 All Rights Reserved.

See documentation for individual use.

Examples

- Create a polygon from a via

```
polyList = axlPolyFromDB(via_dbid ?layer "ETCH/BOTTOM" ?padType 'ANTI)
```

- Create a rectangle polygon (one corner at 0,0 with a width 1000 and height of 500) using *r_path* method

```
; note first and last points are the same
myPath = axlPathStart( list(0:0 1000:0 1000:500 0:500 0:0) 0)
pathPoly = axlPolyFromDB(myPath )
poly = car(pathPoly)
poly->??
```


©2023 All Rights Reserved.

axlPolyFromHole

```
axlPolyFormHole(
     o_polygon
     )
     ⇒ lo_polygon
```

Description

Creates a new poly from the vertices of the hole, and sets the isHole attribute of the resulting poly to `nil`. Function returns `nil` in case of error.

Arguments

o_polygon	o_polygon on which the operation is to be done. The o_polygon must have isHole attribute set to `t` (that is the argument must be a hole).

Value Returned

`lo_polygon`	Returns a list of o_polygons, which represent the resulting geometry after creating polygon from the hole argument. In case of an error, it returns nil.

Creates an lo_polygon object from a hole.

The lo_polygon object can be manipulated with the following operations:

axlPolyOperation()	Performs various logical operations on 2 lists of polygons
axlPolyExpand()	Expands or contracts the size of polygon

Examples

```
poly = axlPolyFromDB(shape_dbid)
hole = car(poly->holes)
polyList = axlPolyFromHole (hole)
```


©2023 All Rights Reserved.

axlPolyMemUse

```
axlPolyMemUse (
     ) -> lx_polyCounts
```

Description

This returns a list of integers reflecting the internal memory use of the `axlPoly` interfaces. If you assign Poly objects to global handles (instead of assigning to locals, for example, `let` or `prog` statements) then you need to insure all of global data is `nil`-ed at the end of your program. The following example shows how to check that you have written your program correctly.

Description of 5 integers. Integers 2 through 5 are for Cadence use.

1 - Most important and shows number of SKILL Polygons still in use.

2 - Number of Allegro Polys in use. This is always >= to SKILL Polys. The additional polys are voids (holes) in the SKILL polys.

3 - Number of edges in all Allegro polys.

4 - Number of Allegro Floating Point Polys (should be 0).

5 - Number of edges in all Allegro Floating Point Polys (should be 0).

Arguments

None

Value Returned

`lx_polyCounts`	A list of 5 integers reflecting Poly memory usage.

See Also

`axlPolyOperation`

Example

Verify at end of your program you have no hanging Poly memory in use.

©2023 All Rights Reserved.

```
gc() ; requires Skill development licenses
axlPolyMemUse()
;; should return all 0's
```


©2023 All Rights Reserved.

axlPolyOffset

```
axlPolyOffset (
     o_polygon/lo_polygon
     l_xy
     [g_copy]
     )
     => o_polygon
```

Description

This offsets the entire poly by the provided xy coordinate. Optionally, if `g_copy` is `t` it will copy the poly, default is to offset the provided poly.

Note: The offseted polygon must be entirely within the extents of the drawing.

Arguments

o_polygon	`o_polygon` on which the operation is to be done.
lo_polygon	Optionally pass a list of polys.
l_xy	Coordinates in user units for offset.
g_copy	Optional, if `t` does the offset on a copy.

Value Returned

lo_polygon/	
o_polygon	In place offset (`g_copy nil`) or offseted copy of polygon (`g_copy` is `t`). If passed a list of polys returns a list otherwise return a poly.

See Also

axlPolyFromDB, axlPolyRotate

Example

```
<cdsroot>/share/pcb/examples/skill/axlcore/ashpoly.il
```


©2023 All Rights Reserved.

axlPolyOperation

```
axlPolyOperation
     o_polygon1 / lo_polygon1
     o_polygon2 / lo_polygon2
     s_operation
     )
     ⇒ lo_polygon/nil
```

Description

Performs the logical operation specified on the two sets of polygons. Does not allow hole polygons as input. When holes are passed as input, the following warning is displayed:

```
Invalid polygon id argument -<argument>
```

Caution

This function is provided "as-is". Result, in certain cases, may fail or deliver incorrect results. No commitment can be made to address issues uncovered when using this API.

Caution

Underlying polygon operation function fails and returns `nil` in rare dense geometrical situations.

Caution

This API may consume a large amount of memory and take a considerable of amount of time to return a result. This is normally only noticeable when the number of polygons provided exceed 10000. The number polygons can be calculated by taking the length of the polygons provided to args 1 and 2 PLUS adding all of the polys holes (poly->holes) in the polygons.

Caution

Algorithm has lines take have a width 1 or 0 database units. This means if you have a design with 2 units of accuracy, 1 database unit is .01.

©2023 All Rights Reserved.

Arguments

o_polygon1 / lo_polygon1	*o_polygon* or list of *o_polygons* on which the operation is to be done.
o_polygon2 / lo_polygon2	*o_polygon* or the list of *o_polygons* on which the operation is to be done.
s_operation	String specifying the type of logical operation, one of `'AND`, `'OR`, or `'ANDNOT`.

Value Returned

lo_polygon	List of *o_polygons* which represent the resulting geometry from performing the operation on the arguments.
`nil`	Error due to incorrect arguments.

For example:

(*o_polygon_out1 o_polygon_out2* ...) is returned if the result after performing the operation is a list of polygons.

`nil` is returned if the result after performing the operation is a `nil` polygon. For example, consider performing the `AND` operation on two non-overlapping sets of polys.

`nil` is returned if the operation fails. You can obtain a descriptive error message by calling `axlPolyErrorGet`.

Example

```
poly1_list = (axlPolyFromDB cline dbid)
poly2_list = (axlPolyFromDB shape_dbid)
res_list = (axlPolyOperation poly1_list poly2_list 'OR)
```


©2023 All Rights Reserved.

axlPolyExpand

```
axlPolyExpand(
     o_polygon1 / lo_polygon1
     f_expandValue
     s_expandType
     )
     ⇒ lo_polygon/nil
```

Description

This function yields a list of polys after expanding them by a specified distance. Use of a negative number causes contraction. Distance is specified in user units. This function does not allow hole polys as input. When holes are passed as input, the following warning is displayed:

```
Invalid polygon id argument -<argument>
```

Caution

Underlying logical operation function fails and returns `nil` in rare dense geometrical situations. 'ALL_ARC mode may have round-off issues when shape has very small arc segments.

Trimming options are (`s_expandType`):

'NONE	no corner modifications
'ACU_ARC	Trim inside acute (less then 90 degrees) line/line corners with arcs and always chamfer spikes. No obtuse or right angle trimming is done.
'ACU_BLUNT	Trim acute inside corners and spikes with line segments.
'ALL_ARC	Trim inside and outside line/line, line/arc and arc/arc corners with respect to the following angle rules: ■ All acute angles are trimmed. ■ Most obtuse angles (more then 135 degrees) are trimmed. ■ 90 degree corners are trimmed. Finally always chamfer spikes.

©2023 All Rights Reserved.

Note: Poly expansion with `0` returns the original poly. To perform trimming only, use axlPolyTrim (trim still needs a length of trim segments, which in this interface is the expansion value).

Arguments

o_polygon1 /lo_polygon1

o_polygon / list of *o_polygons* on which the operation is to be done.

f_expandValue	Amount of expansion in user units.
s_expandType	Symbol specifying the exterior corners of the geometry during expansion, (see above)

Value Returned

lo_polygon	List of *o_polygons* which represent the resulting geometry after performing the expansion on the polys passed as arguments.
`nil`	In case of error.

To be more specific:

- (*o_polygon_out1 o_polygon_out2* ...) is returned if the result after performing the operation is a list of polys.
- `nil` is returned if the result after performing the operation is a `nil` poly, for example, consider contracting a 20x30 rectangle by 40 units.
- `nil` is returned if the operation fails. You can get a descriptive error message by calling `axlPolyErrorGet()`.

See Also

axlPolyFromDB, axlPolyTrim

Example

```
poly_list = axlPolyFromDB(shape_dbid)
    exp_poly = axlPolyExpand(poly_list 10.0 'ALL_ARC)
```


©2023 All Rights Reserved.

The following sequence of diagrams illustrates the behavior of each of the options.

Figure 21-2 Original Poly

ALL_ARC

During expansion of the poly boundary, an arc is inserted for the edges in the offset shape that satisfy the following criteria:

- Edges form an *outside* (or convex) point of the poly boundary.
  The reverse is true for the voids.

©2023 All Rights Reserved.

Figure 21-3 Expanded Using ALL_ARC

©2023 All Rights Reserved.

ACU_ARC

During expansion of the poly boundary, an arc is inserted for the edges in the offset shape that satisfy the following criteria:

- Edges form an *outside* (or convex) point of the poly boundary.
- Edges form an angle sharper than 90 degree.
  The reverse is true for the voids.

Figure 21-4 Expanded Using ACU_ARC

©2023 All Rights Reserved.

ACU_BLUNT

During expansion of the poly boundary, a blunt edge is inserted for the edges in the offset shape that satisfy the following criteria:

- Edges form an *outside* (or convex) point of the poly boundary.
- Edges form an angle sharper than 90 degree.
  The reverse is true for the voids.

Figure 21-5 Expanded Using ACU_BLUNT

©2023 All Rights Reserved.

axlIsPolyType

```
axlIsPolyType (
     g_polygon
     )
     ⇒ t/nil
```

Description

Tests if argument *g_polygon* is a polygon user type.

Arguments

g_polygon	Object to test, any SKILL variable

Value Returned

t	*g_polygon* is a polygon user type.
nil	*g_polygon* is not a polygon user type.

See Also

axlPolyFromDB

Example

```
poly = axlPolyFromDB(cline_dbid)
axlIsPolyType(poly) returns t.
axlIsPolyType(cline_dbid) returns nil.
```


©2023 All Rights Reserved.

axlPolyFromDrillHole

```
axlPolyFromDrillHole (
     o_dbid
     [b_full]
     )
     ⇒ lo_polygon
```

Description

Creates a polygon from a drill hole. Requires a via, pin, or padstack *dbid*.

Function is restricted to do the following:

- Supports finished drill (future versions may add backdrill support)
- Multidrill returns a poly of the extent (future versions may add option to return a poly of each drill).

See `axlPolyFromDB` for polygon attributes.

Arguments

o_dbid	axl DBID for one of the following:
	pin, via, padstack definition
b_full	`nil`, returns poly of the drill extents.
	`t`, returns set of individual drill hole polygons.

Value Returned

`lo_polygon`	Returns the `lo_polygon` object representing the resulting geometry.
`nil`	If object is not a pin, via,padstack, or if lacks a drill hole

See Also

Other APIs that support or generate polygons:

- axlPolyOperation: performs various logical operations on 2 lists of polygon
- axlPolyExpand: expands or contracts polygon

©2023 All Rights Reserved.

- axlIsPolyType: is object a polygon object
- axlPolyErrorGet: return last error from axlPolyOperation
- axlPolyFromDB: convert an allegro dbid to a polygon
- axlPolyMemUse: debug function to return memory use of polygon sub-system
- axlPolyOffset: move a polygon
- axlPolyFromHole: converts a hole polygon to a postive polygon
- axlDBCreateShape: create a shape

See documentation for individual use.

Example

Returns a drill polygon using the ashOne sample code that allows you to select a pin or via:

```
p = ashOne('("PINS" "VIAS"))
poly = car( axlPolyFromDrillHole(p))
```


©2023 All Rights Reserved.

axlPolyErrorGet

```
axlPolyErrorGet (
     )
     ⇒ t_error/nil
```

Description

Retrieves the error from the logop core. See the following list of error strings returned by the logical operation core:

Error type	String returned
problem with arcs	"Bad arc data in polygon operations."
bad data	"Data problem inside polygon operations."
internal error in logical op data handling	"Polygon operation failed because of internal error."
numerical problem in logical op	"Computational problem while doing polygon operations."
memory problem	"Out of memory."
no error	NIL

Arguments

None

©2023 All Rights Reserved.

Value Returned

t_error	Error from the logical operation core.
nil	No logical operation error.

Example

```
l_poly1 = axlPolyFromDB(shape_dbid)
l_poly2 = axlPolyFromDB(cline_dbid ?endCapType 'SQUARE)
l_polyresult = axlPolyOperation(l_poly1 l_poly2 'ANDNOT)
if (null l_polyresult) axlMsgPut(list axlPolyErrorGet())
```


©2023 All Rights Reserved.

axlPolyRotate

```
axlPolyRotate(
     o_polygon/lo_polygon
     n_angle
     l_origin
     [b_copy]
     )
     ⇒ o_polygon
```

Description

Rotates a polygon or list of polygons. This function rotates the entire polygon by the provided angle around the given point. Optionally, if *g_copy* is `t` it copies the polygon. Default is to rotate the provided polygon directly.

The rotated polygon must be entirely within the extents of the drawing.

Arguments

o_polygon / lo_polygon	A polygon or list of polygons on which the operation is to be performed
n_angle	Rotation angle to be applied in degrees
l_xy	Point around which the polygon is to be rotated
b_copy	Optional, if `t` does the rotation on a copy. Default is `nil`.

Value Returned

`lo_polygon / o_polygon`	In-place offset (`g_copy nil`) of provided polygons or a rotated copy of the provided polygons (`g_copy is t`). If passed a list of polygons returns a list, otherwise returns a single polygon.

Example

`<cdsroot>/share/pcb/examples/skill/axlcore/ashpoly.il`

See Also

axlPolyFromDB, axlPolyOffset

©2023 All Rights Reserved.

axlPolyTrim

```
axlPolyTrim
     o_polygon1/lo_polygon1
     s_trimMode
     [f_cornerRadius]
     ==> lo_polygon/nil
```

Description

This function performs smooth/trim type adjustments to the provided polygons to ensure that items like acute angles are properly cleaned up and ready for artwork generation.

This function is similar to the trimming done through the axlPolyExpand API. However, it does not expand or contract the original outline at all. It performs only the trimming requested. This API also allows you to specify the corner or chamfer radius to be used, whereas axlPolyExpand uses the expansion value as the radius.

Trimming options are as follows:

- 'CHAMFER: Trim with chamfer style settings.
- 'ROUND: Trim with round arc style settings.
- 'FULL_ROUND: Trim with full-round artwork settings.
- 'FULL_CHAMFER: Trim with full-chamfer artwork settings.

FULL indicates that right angles will also be trimmed/rounded. For example, see the full round artwork settings for dynamic shape voiding. A square hole will have its corners rounded.

©2023 All Rights Reserved.

Arguments

o_polygon1 / lo_polygon1	Polygons to process.
s_trimMode	Trim style to perform as mentioned in the description
f_cornerRadius	Corner radius or chamfer length to be used

Value Returned

`lo_polygon`	Returns the polygons after performing specified trim actions
`nil`	In case of error

See Also

axlPolyExpand, axlPolyFromDB

Example

```
poly_list = axlPolyFromDB(shape_dbid)
trim_poly = axlPolyExpand(poly_list 'FULL_ROUND 10.0)
```


©2023 All Rights Reserved.

Use Models

Example 1

The existing Split Plane functionality can use the AXL version of the logical operation.

The objective is to split the route-keepin shape on the basis of the anti-etch information and add the resulting split-shapes to the database.

Split Plane Usage

1. startShape - route keepin rectangle

2. antiEtchGeom - anti-etch line on layer “ANTI ETCH/XYZ”

3. The above two shapes are created after doing the operation ANDNOT and then creating the shape for the resultant polys.

```
; retrieve the route keepin rectangle
startShape = (myGetRouteKeepin)
; retrieve the shapes and lines on the anti-etch subclass
antiEtchGeom = (myGetAntiEtchGeom (axlGetActiveLayer))

; create the polygon for the route-keepin rectangle
startPoly = (axlPolyFromDB startShape)
; create the polygon for all the anti-etch elements
antiEtchPoly = nil
(foreach antiElem antiEtchGeom
    antiElmPoly = (axlPolyFromDB antiElem ?endCapType 'ALL_ARC)
    antiEtchPoly = (append antiElmPoly antiEtchPoly)
)
; do the LogicalOp operation
splitPolyList = (axlPolyOperation startPoly antiEtchPoly 'ANDNOT)

;check for any error in logop
(if splitPolyList then
```


©2023 All Rights Reserved.

```
        (; add the resultant polygons as a set of filled shapes on the
        ; active class/subclass with no net name.
        (foreach resPoly splitPolyList
            (axlDBCreateShape resPoly t)
        ))
    else
        (axlMsgPut(list axlPolyErrorGet()))
    )
```

Example 2

```
    ; retrieve the polygon corresponding to clock gen
    clockPoly = (axlPolyFromDB rect_id)
    ; get polygon associated with the ground shape
    gndPoly = (axlPolyFromDB shp_dbid)
    ; get the intersection of the two polygons
    shieldedPoly = (axlPolyOperation clockPoly gndPoly 'AND)

    ; check for any error in logop
    (if shieldedPoly then
        (; get the area of the intersection polygon
        shieldedArea = shieldedPoly->area
        ; get the area associated with clock gen
        clockArea = clockPoly->area

        ;get the ratio of the two areas
        ratioArea = shieldedArea / clockArea)
    else
        (axlMsgPut(list axlPolyErrorGet()))
    )
```

Gets the shielded area of a clock generator by a ground shape using the rule stating that the ratio of the shielded area to the actual area should be less than a particular threshold.

©2023 All Rights Reserved.

22

Allegro PCB Editor File Access Functions

AXL-SKILL File Access Functions

This chapter describes the AXL-SKILL functions that open and close Allegro PCB Editor files.

Important

Use these functions, instead of SKILL's infile and outfile, to access files using Allegro PCB Editor standards, not via the SKILL path.

©2023 All Rights Reserved.

axlDMFileError

```
axlDMFileError(
     ) -> nil/t_errorMessage
```

Description

This returns the error from the last `axlDM`xxx call. Subsequent calls reset the error message so you should retrieve the error as soon as a call fails.

Arguments

none

Value Returned

`nil`	No error message available.
`t_errorMessage`	Message indicating why last operation failed.

See Also

axlDMOpenFile

Example

```
q = axlDMOpenFile("TEMP" "foo.bar" "r")
unless(q
printf("ERROR is %L\n" axlDMFileError()))
```


©2023 All Rights Reserved.

axlDMFindFile

```
axlDMFindFile (
     t_id
     t_name
     t_mode
     [t_prop]
     )
     ⇒ t_name/nil
```

Description

Opens a file using Allegro PCB Editor conventions. Adds an extension and optionally looks it up in an Allegro PCB Editor search path.

Note: Must have an entry in `fileops.txt` file.

Arguments

t_id	Id describing file attributes from `fileops.txt`
t_name	Name of file to find.
t_mode	Open mode. One of the following:
	`r:` read-only
	`w:` write
	`wf:` write line-buffered
t_prop	Property string.

Value Returned

t_name	Name of file opened.
`nil`	Failed to open file.

See Also

axlDMOpenFile

©2023 All Rights Reserved.

Example

```
(setq aPort(axlDMFindFile "ALLEGRO_TEXT","clip","w",":HELP=clipboard"))
```

Finds the fully qualified name `clip.txt` for writing.

©2023 All Rights Reserved.

axlDMGetFile

```
axlDMGetFile(
     t_id
     t_name
     t_mode
     [t_prop]
)
⇒ t_name/nil
```

Description

Gets the file name *t_name* using Allegro PCB Editor conventions as described in the arguments. Returns the full path name of the file. Displays an error message if the file cannot be opened.

©2023 All Rights Reserved.

Arguments

t_id	File attribute id. This string must be one of the types in the Allegro PCB Editor system file `fileops.txt`. Examples are `ALLEGRO_LAYOUT_DB` for Allegro PCB Editor layouts with extension `brd`, `ALLEGRO_REPORT` for Allegro PCB Editor report files with extension `rpt`.
t_name	String giving name of the file to open.
t_mode	Open mode. One of the following: `r`: read-only `w`: write `wf`: write line-buffered
t_prop	Property string.

Value Returned

t_name	Name of the file. In the case of *t_mode* = "`r`", the file must exist for successful completion.
`nil`	File not found. Displays a confirmer giving the name of the file it could not find.

See Also

axlDMOpenFile

Example

```
myfile = axlDMGetFile( "ALLEGRO_TEXT" "clip" "r")
    ⇒ "/usr/home/fred/myproj/clip.txt"
```

Finds the file `clip.txt`, available for reading.

©2023 All Rights Reserved.

axlDMOpenFile

```
axlDMOpenFile(
     t_id
     t_name
     t_mode
     )
     ⇒ p_port/nil
```

Description

Opens a file in conventional Allegro manner; adds an extension and optionally looks it up in an Allegro search path. Must have an entry in `fileops.txt` file.

Allegro currently does not support directory or file names containing spaces.

Use this in place of SKILL's infile/outfile. The SKILL interfaces resolve the file location using SKILLPATH which may mean that files may not open in the local directory if the SKILLPATH does not have "." as its first component. `axlDMOpenFile` uses the Allegro convention to open file.

Note: If you use `axlDMOpenFile` to open a file, use `axlDMClose` to close it. All other SKILL file APIs work on the port returned by this interface.

If you want to use Allegro's standard file extension support (the extension is appended if not present), then see `<cdsroot>/share/pcb/text/fileops.txt` for a list of `t_ids`. Otherwise, if you always provide an extension, use the `TEMP` id.

Tip

Use `get_filename(p_port)` to obtain the name of the file.

©2023 All Rights Reserved.

Arguments

t_id	File attribute id. This string must be one of the types in the Allegro PCB Editor system file `fileops.txt`. Examples are `ALLEGRO_LAYOUT_DB` for Allegro PCB Editor layouts with extension `brd`, `ALLEGRO_REPORT` for Allegro PCB Editor report files with extension `rpt`.
t_name	String giving the name of the file to open.
t_mode	Open mode. One of the following: `r`: read-only `w`: write, create if doesn't exist, truncate to zero length if exists `a`: open for writing, create if doesn't exist, go to end of file for appending if exists

In addition, the following modifiers are supported

`f`: Flush file after each write. This can be slow on Windows if writing across the network. This is typically used if a process will take a long time and you would like to look at the file to see the progress. Example `"wf"`.

`b`: Open in binary mode. This only has effect on Windows. If file is ASCII, this has the effect for reading of not eliminating the carriage-returns (\r) that are in DOS ASCII files. For writing, it does not add the carriage-returns when it sees a linefeed (writes it like a UNIX ASCII file). Example `"rb"`.

`s`: Allow spaces in the file or directory name. Currently, Allegro does not support this behavior. Setting this option is unsupported. Example `"rbs"`.

Value Returned

p_port	Port of the opened file. In the case of *t_mode* `="r"`, the file must exist for successful completion.
`nil`	File not found. Displays a confirmer giving the name of the file it could not find.

See Also

axlDMFileError, axlDMFindFile, axlDMGetFile, axlDMOpenLog, axlDMClose, axlDMFileParts

©2023 All Rights Reserved.

Example

Opens a file `clip.txt` for writing.

```
aPort = axlDMOpenFile("ALLEGRO_TEXT" "clip" "w")
```

Opens a file `b.bar`.

```
aPort = axlDMOpenFile("TEMP" "foo.bar" "r")
```


©2023 All Rights Reserved.

axlDMOpenLog

```
axlDMOpenLog(
     t_program
     )
     ⇒ p_port/nil
```

Description

Opens a file for writing log messages. Uses the name of your program or application without an extension. Opens a file with that name and the extension `.log`. Returns the port of the file if it succeeds.

Arguments

t_program	Your program name - no extension.

Value Returned

p_port	Port of the opened file. In the case of *t_mode* `= "r"`, the file must exist for successful completion.
`nil`	File not found. Displays a confirmer giving the name of the file it could not find.

See Also

axlDMOpenFile

Example

```
logport = axlDMOpenLog("clipboard"))
```

Opens the file `clipboard.log` for writing.

©2023 All Rights Reserved.

axlDMClose

```
axlDMClose(
     p_port
)
⇒ t/nil
```

Description

Closes a file currently open in Allegro PCB Editor. Instead of using SKILL's infile/outfile commands, this command must be used to close the files opened using `axlDMOpenFile` or `axlDMOpenLog` commands.

Important

While the core SKILL function, `close` can be used to close a file, it is recommended that any file opened using an `axlDM` function, must be closed using this function. Programs that adhere to this standard, will be compatible with future Allegro Data Management enhancements.

Arguments

p_port	Id of the open port to be closed.

Value Returned

`t`	Closed the file.
`nil`	File not found.

Example

```
mylog = axlDMOpenLog("myapplic")
    ⇒ port: "/usr/home/fred/myproj/myapplic.log"
axlDMClose(mylog)
    ⇒ t
```

Opens and closes the file `myapplic.log`.

©2023 All Rights Reserved.

axlDMBrowsePath

```
axlDMBrowsePath(
     t_adsFileType
     [t_title]
     [t_helpTag]
     )
     ⇒ t_fileName/nil
```

Description

Invokes a standard Allegro PCB Editor file browser supporting paths, for example, `SCRIPTPATH`. To use, pass one of the file types supported by `fileops.txt`. Browses file types that include the fileops `PATH` attribute. `axlDMFileBrowse` should be used to browse other file types. This works on non-PATH file types since this browses in the current working directory. The user is not able to change the directory with this browser.

Arguments

t_adsFileType	First entry in `fileops.txt`.
t_title	Title for the dialog
t_helpTag	Tag for the help file (used only by Cadence)

Value Returned

t_filename	Full path to the filename.
`nil`	Error due to incorrect arguments.

Example

```
ret = axlDMBrowsePath("ALLEGRO_SCRIPT")
ret = axlDMBrowsePath("ALLEGRO_CLIPBOARD" "Select Clipboard")
```


©2023 All Rights Reserved.

axlDMDirectoryBrowse

```
axlDMDirectoryBrowse(
     t_startingDirectory
     g_writeFlag
     [?helpTag t_helpTag]
     [?title t_title]
     )
     ⇒ t_dirName/nil
```

Description

Opens a directory browser. Unlike file browsers, this only allows a user to select a directory. This function call blocks until the user selects or cancels.

Arguments

t_startingDirectory	Name of the starting directory.
g_writeFlag	A boolean - if the file is to be opened for write (`t`), or for read (`nil`).
t_helpTag	Defines the help message to display if the *Help* button is selected in the browser. Default help is provided if this option is not set.
g_title	Override default title bar of the browser. Normally, this is the name of the command that invoked the browser.

Value Returned

t_dirName	Name of directory selected.
`nil`	No directory selected.

Example

```
axlDMDirectoryBrowse("." t ?title "Pick a directory")
```

Browses the current directory.

©2023 All Rights Reserved.

axlDMFileBrowse

```
axlDMFileBrowse(
     t_fileType
     g_writeFlag
     [?defaultName t_defaultName]
     [?helpTag t_helpTag]
     [?directorySet g_directorySet]
     [?noDirectoryButton g_noDirectoryButton]
     [?mainFile g_mainFile]
     [?noSticky g_noSticky]
     [?title t_title]
     [?optFilters t_filters]
     )
     ⇒ t_fileName/nil
```

Description

Opens a standard file browser. Unlike the other `axlDM` functions, this always presents the user with a file browser. This function call blocks until the user selects a file or cancels.

Note: The name of the file is selected and returned to the caller. Does not open the selected file.

The final filter is `'All files (*.*)'`.

©2023 All Rights Reserved.

Arguments

t_id	Id describing the file attributes from `fileops.txt`, or list of ids for different types, or `nil` if you use `optFilters` to describe files.
g_writeFlag	If the file is to be opened for write (`t`), for read (`nil`).
t_defaultName	Name of file to select by default.
t_helpTag	Tag that defines the help message to display if the Help button is selected in the browser. Default help provided if option not set.
g_directorySet	Sets the directory change button which, by default, is not set.
g_noDirectoryButton	Hiding of the directory change button in the browser. By default, the button is present.
g_noSticky	File browser normally remembers the directory from the previous invocation. This helps the user who browses in the same location that is different from the current working directory. If `t`, then it starts the browser in the current working directory. Normally, you should set this option if *g_directorySet* is `t`.
g_mainFile	Matches options Allegro PCB Editor uses to open files from the File menu. This is *g_noSticky*=`t` & *g_directorySet*=`t`. For non-main files, use no options.
g_title	Overrides default title bar of the browser. Normally this is the name of the command that invoked the browser.
g_filters	Filters added to default `t_id` filter. The format is: <*msg*>|<*filter*>|<*msg*>|<*filter*>...

Value Returned

t_fileName	Name of the file selected.
`nil`	No file selected.

Examples

- Browses Allegro PCB Editor text files.

```
axlDMFileBrowse("ALLEGRO_TEXT" nil)
```


©2023 All Rights Reserved.

- Browses Allegro PCB Editor text files and allows secondary filter of `*.log`.

```
axlDMFileBrowse("ALLEGRO_TEXT" nil ?optFilters "All log files (*.log)|*.log")
```

- Browse SKILL files (both .il and .ils extensions).

```
axlDMFileBrowse(nil nil ?optFilters "Skill files(*.il)|*.il|Skill
Oops(*.ils)|*.ils")
```


©2023 All Rights Reserved.

axlDMFileParts

```
axlDMFileParts(
     t_filespec
     )
     ⇒ (directory file fileWext ext)
```

Description

Breaks a filename into it's component parts.

Arguments

t_filespec	Filename or full path spec.

Value Returned

list	(*directory file fileWext ext*)

See Also

axlDMOpenFile

Example

```
fileparts =  axlDMFileParts("/usr1/xxx/stuff.txt"))
          --> ("/usr1/xxx/" "stuff" "stuff.txt" "txt")
fileparts = axlDMFileParts("stuff.txt"))
          --> ("/usr1/xxx/" "stuff" "stuff.txt" "txt")
```

**where /usr1/xxx is the cwd

©2023 All Rights Reserved.

axlOSFileCopy

```
axlOSFileCopy(
     t_src
     t_dest
     g_append
     )
     ⇒ t/nil
```

Description

Copies a given source file to a given destination with optional append.

Arguments

t_src	Full path of the source file.
t_dest	Full path of the destination file.
g_append	Flag for the append function (`t`/`nil`)

Value Returned

`t`	Copied file.
`nil`	Failed to copy file due to incorrect arguments.

Example

```
unless(axlOSFileCopy("~/myfile" "~/newfile" nil)
    axlUIConfirm("file copy FAILED") )
```


©2023 All Rights Reserved.

axlOSFileMove

```
axlOSFileMove(
     t_src
     t__dest
     )
     ⇒ t/nil
```

Description

Moves the given source file to the given destination.

Arguments

t_src	Full path of the source file.
t_dest	Full path of the destination file.

Value Returned

`t`	Moved file.
`nil`	Failed to move file.

Example

```
unless (axlOSFileMove("/mydir/myfile" "/newdir/newfile")
    axlUIConfirm("file move FAILED") )
```


©2023 All Rights Reserved.

axlOSSlash

```
axlOSSlash(
     t_directory
     )
     ⇒ t_directory/nil
```

Description

Changes DOS style backslashes to UNIX style slashes which are more amenable to SKILL. On UNIX, returns the incoming string.

Arguments

t_directory	Given directory path.

Value Returned

t_directory	Directory path using UNIX style slashes (/).
nil	Failed due to incorrect argument.

See Also

axlOSBackSlash

Example

```
p = axlOSSlash("\tmp\mydir")
    -> "/tmp/mydir"
```


©2023 All Rights Reserved.

axlRecursiveDelete

```
axlRecursiveDelete(
     t_directory
     )
     ⇒ t/nil
```

Description

Recursively removes directories and subdirectories in the argument list. Directory is emptied of files and removed. If the removal of a non-empty, write-protected directory is attempted, the utility fails. If it encounters protected files or sub-directories, it does not remove them or the parent directories, but removes all other objects.

Caution

This can be dangerous since it can severely damage your system or data if not used with care. For example, axlRecursiveDelete("/") could delete your OS and all of your data.

Arguments

t_directory	The given directory or filename.

Value Returned

t	Directory is successfully removed.
nil	Failed for one of the following reasons: - doesn't exist - read protected - sub-file or directory does not allow remove (*partial success*) - sub-file or directory is in use (NT only) (partial success) A partial success means that some of the files and directories were deleted.

©2023 All Rights Reserved.

Example

```
parent = "./tmp"
child = (strcat parent "/child")
(createDir parent)
(createDir child)
(axlOSFileCopy"~/.cshrc" (strcat parent"/csh") nil)
(axlOSFileCopy"~/.cshrc" (strcat child"/csh") nil)
(axlRecursiveDelete parent)
```


©2023 All Rights Reserved.

axlTempDirectory

```
axlTempDirectory(
     )
     ⇒ t_directoryName/nil
```

Description

Returns the temporary directory for the current platform.

Arguments

none

Value Returned

t_directory	Temporary directory for the current platform.
nil	Failed to identify temporary directory for the current platform.

©2023 All Rights Reserved.

axlTempFile

```
axlTempFile(
     [g_local]
     )
     ⇒ t_tempFileName/nil
```

Description

Returns a unique temp file name. The temp file should be removed, even if not used, by `axlTempFileRemove`.

By default, the files are written to `/tmp`, but you can modify this with the environment variable `TEMPDIR`.

Arguments

g_local	Flag, which if `t`, creates a temp file in the current directory. Most applications should use the default `/tmp` directory. The local directory should only be used if the file will be more than 2 megabytes.

Value Returned

t_tempFileName	Name of the unique temp file.
`nil`	Failed to create temp file.

©2023 All Rights Reserved.

axlTempFileRemove

```
axlTempFileRemove(
     t_filename
     )
     ⇒ t
```

Description

Deletes the temporary file and removes the temporary name from the pool. It is important to call this function once you are finished with a temporary filename.

This can also be used to delete files whose names are not obtained from `axlTempFile`.

Arguments

t_filename	Name of the file to delete.

Value Returned

`t`	Deleted temporary file specified.
`nil`	Failed to delete temporary file specified due to incorrect argument.

©2023 All Rights Reserved.

©2023 All Rights Reserved.

23

Reports and Extract Functions

AXL-SKILL Data Extract Functions

The chapter describes the AXL-SKILL functions that extract data from an Allegro layout and write it to an ASCII file for external processing.

axlExtractToFile

```
axlExtractToFile(
     t_viewFile
     lt_resultFiles
     [lt_options]
     )
     ⇒ t/nil
```

Description

Extracts data from the current design into an ASCII file. Performs the same process as the Allegro batch command `a_extract`.

©2023 All Rights Reserved.

Arguments

t_viewFile	Name of the extract command file (view file).
lt_resultFiles	List of file names for the extract output. If one file is specified, output is string instead of list. Maximum of 24 files are supported. If more then 24 views are required, use multiple view files.
lt_options	List of keyword strings for various options: ■ `"crosshatch":` Generate crosshatch lines when extracting crosshatched shapes. ■ `"ok":` Unknown field names are OK. Useful when the extract command file has property names not defined for the design being extracted. ■ `"short":` Extract data in the short format ■ `"quiet":` Do not print progress messages on `stdout`. ■ `"mcm":` Output MCM terminology.

Value Returned

`t`	Extract complete.
`nil`	Failed to complete the extract. See the file `extract.log` for explanatory error messages.

Example

```
axlExtractToFile( "cmp_rep_view" "my_comp_data")
    ⇒ t
```

Extracts the component data from the current layout. Writes the data to the file `my_comp_data.txt`.

©2023 All Rights Reserved.

axlExtractMap

```
axlExtractMap(
     t_viewFile
     [s_applyFunc]
     [g_userData]
     )
     ⇒ t/l_dbid/nil
```

Description

Takes a set of Allegro database objects you select using the Allegro extract command file and applies to each object a SKILL function you have chosen. The extract command file (the *view*) selects the objects and also sets any filters. Ignores the output data fields listed in the extract command file, since it does not create an output file.

Applies to each object that passes the selection and filter criteria in `s_applyFunc`, the SKILL function you supplied. SKILL calls `s_applyFunc` with two arguments—the `dbid` of the object and the variable `g_userData` that you supply as an argument. `g_userData` may be `nil`. If not, it normally is a *defstruct* or disembodied property list so that the called routine can update it destructively.

If `s_applyFunc` returns `nil`, then *axlExtractMap* stops execution, writes the message, **`User CANCEL received`** to the extract log file, and returns `nil`. If the callback function returns non `nil` then execution continues.

If `s_applyFunc` is `nil`, then `axlExtractMap` simply returns `l_dbid`, a list of `dbids` of the objects that pass the filter criteria. Use `l_dbid` to perform a `foreach` to operate on each object. (See examples below.)

Behaves slightly differently from a standard extract to a file. Provides `s_applyFunc` with the `dbid` of the parent (rotated) rectangle or shape, and not individual line/arc segments. Returns the attached text in the `FULL GEOMETRY` view.

Allegro “pseudoviews” (DRC, ECL, ECS, ECL_NETWORK, PAD_DEF, and so on) may not be used with *axlExtractMap*. The callback function is never called.

Note: `axlExtractMap` extracts only objects AXL-SKILL can model. For example, it does not extract function instances and unplaced components.

©2023 All Rights Reserved.

Arguments

t_viewFile	Name of the extract command file (view file).
s_applyFunc	SKILL function to call for each selected object.
g_userData	Data to pass to *s_applyFunc*. May be `nil`. Ignores *g_userData* if *s_applyFunc* is `nil`.

Value Returned

`t`	*s_applyFunc* is non `nil`. Applied SKILL functions to specified objects.
l_dbid	List of *dbids* of the specified objects.
`nil`	Failed to apply SKILL functions to specified objects. See the file `extract.log` for explanatory error messages.

Example

```
; user callback provided - function declared
; with the (lambda) function
; returns a list of the names of all nets
    (defun get_netnames ()
        ; byReference is disembodied prop list
        ; with property 'nets to be used to store
        ; the net names
        (let ((byReference (list nil 'nets nil)))
         (axlExtractMap "net_baseview"
            ; function created right here
            (lambda (dbid netRef)
            ; add the name of this net to
            ; the list of names
                (putprop netRef
                (cons (get dbid 'name)
                    (get netRef 'nets)) 'nets)
                t)      ; success return
            byReference)
        (get byReference 'nets))) ; return list of names
```


©2023 All Rights Reserved.

axlReportGenerate

```
axlReportGenerate(
     t_reportName
     g_showReport
     [t_fileName]
     ) -> t/nil
```

```
axlReportGenerate(
     'list
     nil
     ) -> t
```

Description

This generates a report from one of the Allegro available reports.

For development purposes, if the report name is 'list a file, `reports_list.txt`, is created with the names of all supported reports.

Many, but not all, of these reports are available at the OS level via the `report` command.

Cautions

- This only supports the reports available via the `reports` command. Allegro has application generated reports that cannot be accessed via this interface.
- Reports may be added or deleted and their names may change across releases.
- Report formats may change. You may need to update the code for report enhancements.

Arguments

t_reportName	Name of report or 'list if you want a list of reports
g_showReport	If `t`, show the report to the user
t_fileName	Save report to indicated name

Value Returned

`t`	Successful
`nil`	Problem with the arguments, the interface does not know if the report generation was successful

©2023 All Rights Reserved.

See Also

axlReportRegister

Examples

- Generate a report and save to file

```
axlReportGenerate("Bill of Material Report" nil "bom.txt")
```

- See what reports are available

```
axlReportGenerate('list nil)
```


©2023 All Rights Reserved.

axlReportList

```
axlReportRegister(
     ) -> ll_reportList/nil
```

Description

Lists all the SKILL reports registered to the Allegro PCB Editor report interface. Even if you do not register any reports, Allegro PCB Editor registers default reports written in SKILL.

Arguments

None.

Value Returned

ll_reportList	List of lists of reports register.

Each sub-list has the following format:

(g_reportCallback t_description t_title)

nil	No reports registered.

See Also

axlReportRegister

©2023 All Rights Reserved.

axlReportRegister

```
axlReportRegister(
     g_reportCallback
     t_description
     t_title
     ) ==> t/nil
```

Description

Allows registration of user reports using the Allegro PCB Editor Reports dialog box. You provide a report name (displayed in the dialog), title (displayed in the title bar when the report is shown), and a report-generating callback function.

Callback is of format where a filename is passed that you should open, write your report and close. Callback function format is: `g_reportCallback(t_outfile)`.

The callback should, if it generates a report, return a `t` from the function. If it does not generate a report return a `nil`.

If you provide a `nil` *`t_description`* then the current report is unregistered. You can disregard the *`t_title`* in the unregister mode. You can register only one report per callback function (`g_reportCallback`).

To delete an existing report, pass the callback function assigned to the report, a `nil` for the *`t_description`*, and an empty string for the *`_title`*.

Note: Only applicable if you enable the *HTML-style reports*.

You can generate the report file in two formats: text or HTML.

Text:

- File is text based.
- Conversions include inserting links when following keywords are encountered:

  (http://) - add an HTML link

  (num <,> num) (XY coordinate)- add a cross-probe link to zoom center on that coordinate

HTML:

- File starts with an <HTML>
- To enable xy zoom center, decorate all xy coordinates as follows:

©2023 All Rights Reserved.

```
<a href="xprobe:xy:x_value,y_value">(x_value y_value)</a>
```

Example: xy coordinate is (310 140)

```
<a href="xprobe:xy:310.0,140.0">(310.0 140.0)</a>
```

Tips and restrictions:

- Your report description string should start with your company name or some other standard to keep all your reports together in the report dialog. Keep the description short to fit within the space provided in the dialog box.
- The report dialog is blocking. You cannot ask for picks from the Allegro canvas. Do not use the following:

  APIs:

  - any user pick or selection API, `axlSelect`, `axlEnter`
  - `axlShell`
  - save or open a drawing
- You can invoke your own form within the report callback but make sure it is blocking (use `axlUIWBlock(<formhandle>)`)
- The provided SKILL callback function must return a
  - 't' if you want to the report to display.
  - A 'nil' if there is no report to display.
- If building a context where your report function is stored, you cannot make the `axlReportRegister` inside the context. The `axlReportRegister` must be placed in `allegro.ilinit` or the autoload file (`.al`) if building autoload contexts. This is the same rule that applies to `axlCmdRegister`.

©2023 All Rights Reserved.

Arguments

g_reportCallback	Symbol or string of a SKILL function.
t_name	Name of report (shown in reports dialog box); if `nil` will delete the report associated with `g_reportCallback`.
t_title	Name in title bar when displaying report.

Value Returned

`t`	Arguments correct. A report is registered.
`nil`	An illegal argument.

Examples

- The following registers the report “My Hello”. The optional keyword in MyReport lets a direct call to MyReport generate a report to a fixed name file, `helloWorld.rpt`. otherwise it takes the name from the report dialog box.

```
axlReportRegister('MyReport, "XYZ Inc. Hello" "Hello World")

             ; optional keyword allows a you to call MyReport with a nil where
              ; the report file generated will be helloWorld.rpt. Otherwise if
            ; called from report dialog, it will be passed a temporary filename
             procedure( MyReport(@optional (reportName "helloWorld"))

                 let( (fp)
                 fp = axlDMOpenFile("ALLEGRO_REPORT" reportName "w")
                 axlLogHeader(fp "This is my report")
                 fprintf(fp, "\nHello World\n")
                 close(fp)
                 t
            ))
```

- Unregister above report:

```
axlReportRegister('MyReport, nil nil)
```

See Also

axlReportList axlLogHeader

©2023 All Rights Reserved.

©2023 All Rights Reserved.

©2023 All Rights Reserved.

24

Utility Functions

The chapter describes the AXL-SKILL utility functions. These include functions to derive arc center angle and radius, and to convert numeric values to different units.

©2023 All Rights Reserved.

axlCheckString

```
axlCheckString(
     t_type
     t_string
     ) -> t_modString/nil
```

```
axlCheckString(
     nil
     nil
     ) -> lt_types
```

```
axlCheckString(
     'error
     nil
     ) -> t_errorMsg/nil
```

Description

Checks the provided string for legal characters and length. You must also provide the data type. Give this API two nils if you want to see the list of supported data types.

It performs the following checks for the data type provided:

- length check
- legal characters

For all data types except PROPVALUE, it may also modify the provided string and return the updated string to meet Allegro database rules.

- stripping leading and trailing white space
- upper case

Unique considerations by data type:

- PROPVALUE checks for common property value restrictions. Typically, a property may have more severe restrictions.
- GROUP checks for common group naming restrictions. A particular group may enforce additional restrictions.

You should use the return string since it may have been modified.

Errors messages may evolve over time. Last error is only maintained until next call to axlCheckString.

©2023 All Rights Reserved.

Arguments

t_type	data type (nil to return all supported data types)
t_string	input string
'error	fetch last error message

Value Returned

t_modString	Modified output string if check is successful
lt_types	List of data types supported
nil	Failed check

See Also

axlDBControl - max name length

Examples

- return all supported types

```
axlCheckString(nil nil)
```

- typical check

```
axlCheckString("REFDES" "u1") -> "U1"
```

- error

```
axlCheckString("NET" "!GND") -> nil
axlCheckString('error nil)
-> "ERROR(SPMHUT-1): Illegal character(s) present in the name or value."
```


©2023 All Rights Reserved.

axlCmdList

```
axlCmdList(
     )
     ⇒ ll_strings/nil
```

Description

Lists commands registered by `axlCmdRegister`. The list consists of paired strings.

((<*allegro command*> <*skill function*>)...)

Arguments

None.

Value Returned

ll_strings	List of registered Allegro PCB Editor commands paired with the related SKILL functions.
`nil`	No commands registered.

Examples

```
axlCmdRegister("interboxcmd" 'axlEnterBox)
axlCmdList()
    will return the following:
        (
            ("interboxcmd" "axlEnterBox")
        )
```


©2023 All Rights Reserved.

axlDebug

```
axlDebug(
     t/nil
     ) t/nil
```

Description

This enables/disables AXL debug mode. See `axlIsDebug` for description of what this entails.

Enable debug also enables error messages for invalid attributes of Allegro *`dbids`*. This enables detecting typos when fetching data from *`dbids`*. This entails a slight performance hit. For example, if you have a pin *`dbid`* and you do a `pin->bbox` (instead of `pin->bBox`), then an error will be issued.

Arguments

Values Returned

`t`	To enable AXL SKILL debug mode.
`nil`	To disable.

Returns last setting

See Also

`axlIsDebug`

©2023 All Rights Reserved.

axlDetailLoad

```
axlDetailLoad(
     t_filename
     point
     f_scale
     x_rotation
     g_mirror)
     ==> t/nil
```

Description

This loads a the designated `ipf` file `(t_filename)` into the current design at location (point), with scaling (`f_scale`), rotation (`f_rotation`) and mirror (`g_mirror`). Items are clipped to rectangle provided a save file time. It will load the detail to the active layer.

Note: scale values much less then 1.0 may have unpredictable results.

Arguments

t_filename	the name of the plot file which contains the detail.
point	the location to place the detail.
f_scale	the scaling factor of the details as a floating point number (1.0 is no scaling). Most be greater then 0.1
x_rotation	the rotating angle in degrees. Rotation is restricted to integers.
g_mirror	whether the detail should be mirrored (t/nil.

Value Returned

t	was able to load
nil	otherwise

Examples

Select a group of objects and load at 0,0 with double scaling.

- use `ashSelect` function in SKILL examples area

```
file = "myplt.plt"
```


©2023 All Rights Reserved.

```
objs = ashSelect(nil)
lyr = "MANUFACTURING/DETAIL"
win = axlDBGetDesign()->bBox
when(objs
    axlDetailSave(file win objs)
    axlLayerCreateNonConductor(layer)
    axlVisibleLayer(layer t)
    axlSetActiveLayer(layer)
    axlDetailLoad(file 0:0 2.0 0 nil)
)
```

See Also

axlDetailSave, axlSetActiveLayer – Obsolete

©2023 All Rights Reserved.

axlDetailSave

```
axlDetailSave(
     t_filename
     l_bBox
     o_dbid/lo_dbid
     [g_filledPads]
     )
     ==> t/nil
```

Description

This saves a clipping box (l_bBox) and the passed set of geometries (lo_dbid) to a Allegro ipf file (t_filename).

Notes:

- Any attached text to the dbids is saved.
- Ignores logical dbids such as nets, components, etc.

Arguments

t_filename	the name of the file into which the detail is saved
l_bBox	list of two xy coordinates defining selection box
lo_dbid	list of AXL DBID's or single DBID
g_filledPads	output filled pads as filled (t) or unfilled (nil). Default is filled. Certain other filled figures may be effected by this option

Value Returned

t	was able to save into the file
nil	otherwise

See Also

axlDetailLoad

©2023 All Rights Reserved.

axlEmail

```
axlEmail(
     t_to
     t_cc/nil
     t_subject
     t_body
     )
     ==> t/nil
```

Description

Sends an e-mail. If multiple *To* or *Cc* addresses are required; separate their names with a semicolon (;). On Windows, a warning confirmer may generate. To disable the warning, add the following to the registry:

```
HKEY_CURRENT_USER/Identities/[ident code]/Software/
   Microsoft/Outlook Express/5.0/Mail/Warn on Mapi Send
```

Set the data value to `0`.

Important

On UNIX, it is not possible for the interface to return an e-mail delivery failure.

Arguments

t_to	E-mail address.
t_cc	Any carbon copy persons to send; `nil` if none.
t_subject	What to put on the subject line.
t_body	Body of message.

Value Returned

`t`	If successful.
`nil`	Failure.

Example

```
axlEmail("aperson" nil "A test message" "anybody home?")
```


©2023 All Rights Reserved.

axlHistory

- Report history buffer (first to last)

```
axlHistory(
    [x_num]
    ) -> t
```

- Read or write history to a file

```
axlHistory(
    s_operation
    t_filename
    ) -> t/nil
```

Description

Caution

This is a developers aid only. Do NOT use it in a SKILL program.

Provides command recall capability to the SKILL development window.

Functionality also applies to the Allegro PCB Editor command line except the command is: `"history <n>"` where n is the print the last N commands.

The command line has no ability to read or write history files. They are automatically read on program startup and saved on exit.

History environment variables:

- `allegro_history = <n>` (default is 200 commands)

  Command recall buffer length.

- `allegro_savehist = <n>` (default off)

  Save history file to be saved on program exit. Will be read next time on startup. File is saved at `<HOME>/pcbenv/history_<name>.txt`

  where `<name>`

  - is SKILL for the SKILL command area
  - program name for Allegro command area

History support:

- `!!` – last command (same as `!-1`)

©2023 All Rights Reserved.

- `!<num>` – redo command number (ex `!5`)
- `!-<num>` – redo relative to last cmd (ex `!-2`)
- `!<str>` – redo cmd starting with string last to first search (ex `!echo`)
- `!?<str>` – redo cmd matching with string last to first search. For example, `!?unnamed`

Arguments

x_num	print last `<num>` commands, `0` or no argument prints entire recall buffer
s_operation	*'read* – read history buffer from provided file and append to history *'write* – write history buffer to provided file
t_filename	A history file (default extension is `.txt`)

Value Returned

t	Operation succeeded
nil	Failed

Also prints history buffer if running with option 1.

Example

- Report history buffer

```
a = 1
b = 2
axlHistory()
```

- Save history

```
axlHistory('write "skillhist")
```

- Read history

```
axlHistory()
axlHistory('read "skillhist")
axlHistory()
```


©2023 All Rights Reserved.

axlHttp

```
axlHttp(
     t_url
     )
     ⇒ t
```

Description

Displays a URL from Allegro PCB Editor in an external web browser. First attempts to use the last active window of a running web browser, raising the browser window to the top if required. If no browser is running, tries to start one.

On UNIX, supports only the browser, Netscape. If Netscape is not running, tries to start it. May not detect failure if the web page fails to load.

Note: Netscape must be in your search path.

You can override the program name using the environment variable:

```
set http_netscape = <program name>
```

For example:

```
set http_netscape = netscape405
```

Note: On UNIX, this function has been tested with Netscape only and may not function properly with another web browser.

On Windows, this function uses the default web browser listed in the Windows registry. If no browser is registered, this function fails. Both Netscape and Windows Explorer work with this function. You can open any file type with a Windows registry entry.

Arguments

t_url	URL to display.

©2023 All Rights Reserved.

Value Returned

`t`	URL displayed in web browser.
`nil`	Failure due to web browser not being found (on UNIX), not being registered (on Windows), or being unable to load the URL.

Note: The function may not detect when a URL has not loaded on UNIX.

Examples

```
axlHttp("http://www.cadence.com")
```


©2023 All Rights Reserved.

axlIsDebug

```
axlIsDebug(
     ) ==> t/nil
```

Description

This checks if AXL debug mode is enabled. This is associated with the `axldebug` Allegro environment variable.

When this mode is set, AXL may print additional AXL API argument warnings when arguments to AXL functions are incorrect. Many warnings do not obey this variable because they are considered serious or edge conditions. Warnings supported are less serious and are known from user feedback to be troublesome to program around.

Typically, when an AXL API function encounters an argument error, it will print a warning and return `nil`.

When unset, the code runs in development mode and eliminates many of these warnings. You should have this mode enabled when developing SKILL code.

This functionality was introduced in 15.2. Currently, few AXL functions take advantage of this option.

Arguments

None

Value Returned

`t` if mode is enabled, `nil` otherwise.

See Also

axlDebug

Example

```
when( axlIsDebug() printf("Error\n"))
```


©2023 All Rights Reserved.

axlIsProductLineActive

```
axlIsProductLineActive(t_productLine) -> t/nil
```

Description

This routine determines if a product in a given product line has been started.

Arguments

`productLine`	The product line that you want to check. The legal values are: ■ SI ■ PCB ■ CONCEPT ■ ORCAD ■ APD

Value Returned

- `t`: There is a license checked out for the given product line.
- `nil`: There is no license checked out for the given product line.

©2023 All Rights Reserved.

axlISProductStarted

```
axlIsPointInsideBox(
     t_productName
     ) -> t/nil
```

Description

Caution

This should not be used, use axlLicIsProductEnabled.

©2023 All Rights Reserved.

axlLicDefaultVersion

```
axlLicDefaultVersion(
     )-> f_version
```

Description

This returns the default version number used in licensing. Most applications in a release will use this version number when checking out licenses.

Arguments

None

Value Returned

`f_version` - floating point number (forexample,16.6)

©2023 All Rights Reserved.

axlLicFeatureExists

```
axlLicFeatureExists(
     t_license
     [f_version]
     )-> t/nil
```

Description

Checks if license feature exists. Does not verify that the license is available. If no version is provided, the tool default version (see axlLicDefaultVersion) is used.

Argument

t_license	license name
f_version	floating point number (forexample,16.3)

Value Returned

`t` if checkout, `nil` in case of failure

See Also

axlLicIsProductEnabled

©2023 All Rights Reserved.

axlLicIsProductEnabled

```
axlLicIsProductEnabled(
     t_license
     ) -> t/nil
```

```
axlLicIsProductEnabled(
     `all
     ) -> lt_licenses
```

Description

Checks if license is checked-out by tool.

In first form, if given a license string returns `t` when license is checked-out and `nil` if it isn't. The test is based on the result obtained by running tool. There is no SKILL method to determine licenses.

In the second form, if called with the symbol `all` returns a list of licenses currently checked out by the tool.

Arguments

t_license	Name of license (case sensitive)
'all	Get all licenses currently checked-out by the program.

Value Returned

- `t` - license checked out
- `nil` - license not checked out
- `lt_licenses` - list of licenses checked-out by program (all mode)

See Also

axlLicFeatureExists, axlLicDefaultVersion

Examples

See if SKILL developer license (product 900) is checked out:

```
axlLicIsProductEnabled("skillDev")
```


©2023 All Rights Reserved.

axlLogHeader

```
axlLogHeader(
     p_port
     t_titleString
     [t_prefix]
     )
     ⇒ t/nil
```

Description

Writes the standard Allegro PCB Editor log file header to the passed open file. The header record includes:

- Title String
- Drawing Name
- Software Release
- Date and Time

Arguments

p_port	SKILL port for the open file.
t_titleString	Title string in the log file header.
t_prefix	Optional prefix string to header for easier parsing (recommend "#")

Value Returned

t	Wrote log file header to open file.
nil	Failed to write log file header to open file due to incorrect arguments.

©2023 All Rights Reserved.

axlMKS2UU

```
axlMKS2UU(
     t_mksString
     )
     ⇒ f_value/nil
```

Description

Converts between an MKS string to the current database user units. String can be any length name plus many common abbreviations (see `units.dat` file in the Allegro PCB Editor share/text hierarchy for supported names.)

Conversion can fail for the following reasons:

- Input string not a legal MKS format.
- Conversion will overflow the maximum allowed database size.

Notes:

- Conversion between metric and english units may result in rounding.
- Return number is rounded to the database precision.

Arguments

t_mksString	Input unit's string with MKS units.

Value Returned

f_value	Floating point number.
nil	Conversion failed. See previous description for possible reasons.

©2023 All Rights Reserved.

Example 1

```
axlMKS2UU("100.1") -> 100.0
```

Default conversion with database in mils.

Example 2

```
axlMKS2UU("100 mils") -> 100.0
```

Database is in mils.

Example 3

```
axlMKS2UU("100 inches") -> 100000.0
```

Database is in mils.

Example 4

```
axlMKS2UU("100 METER") -> 3937008.0
```

Database is in mils.

©2023 All Rights Reserved.

axlMKSAlias

```
axlMKSalias(
     t_MKSAlias
     )
     ⇒ t_alias/nil
```

Description

Searches the MKS unit database for the current definition associated with *unitName*. Unlike `axlMKSConvert`, this function does not convert.

You load the MKS database from the following file:

```
<cds_root>/share/pcb/text/units.dat
```

Argument

t_mksAlias	Name of the alias string.

Value Returned

t_def	Definition name as a string.
`nil`	Definition name could not be found.

Examples

```
axlMKSAlias("VOLTAGE") -> "V" (Intended usage)
axlMKSAliaas("M") -> "METER"
axlMKSAlias("KG") -> NIL (The function supports only the use of basic units.)
```


©2023 All Rights Reserved.

axlMKSConvert

Operates in several ways, depending on the arguments passed.

1. To convert a number from an input units type to an output unit type, general case:

```
axlMKSConvert (
    n_input
    t_inUnits
    [t_outUnits]
    )
=> f_output/nil
```

2. To convert a number from an input units type to MKS units:

```
axlMKSConvert (
    n_input
    t_inUnits
    nil
    )
=> f_output/nil
```

3. To convert a number from MKS units to an output unit type:

```
axlMKSConvert (
    n_input
    nil
    t_outUnits
    )
=> f_output/nil
```

4. To convert an MKS string to an output units, i.e. ".5 MILS" to "INCHES":

```
axlMKSConvert (
    t_input
    [t_outUnits]
    )
=> f_output/nil
```

5. To pre-register an input units, so that subsequent calls need not specify units:

```
axlMKSConvert (
    nil
    t_inUnits
    )
=> t/nil
```

6. To convert a unit from a pre-registered input units:

```
axlMKSConvert (
    n_input
    )
=> f_output/nil
```

Description

Converts any allowable unit to any other allowable unit. It operates in several ways, depending on the arguments.

©2023 All Rights Reserved.

In all instances with `t_outUnits` as an argument, if that argument is omitted, the function converts to active design units.

1. If the first argument is a number and the second argument is evaluated as the units of that number, the number is converted to the units specified by the third argument.

   A special case is if first argument is a number, the second is "design" and the third is a length unit then the input number is converted from current design units to specified length units.

2. In the case where the first argument is a string, that string must be a fully instantiated units string, i.e. "15 MILS". In this case the second string is interpreted as the output units, and the value of the first string is converted to these units.

3. If the first argument is nil, then the input units specified by the second argument is remembered for the future calls. The output units will default to the active design, and the function will fail as above if no design is active. Note that pre-registration will not work if there is no active design.

4. When only a number is specified, the function will confirm that an input unit has been pre-registered, and will convert that number, in the pre- registered units, to the design units. Function will issue a warning and return nil if no pre-registered input units, or no active design

5. When the second and third arguments are present but one is nil, it represents MKS standard units for the input or output units, respectively.

©2023 All Rights Reserved.

Arguments

n_input	Number to convert
t_inUnits	String giving the units of the input number. If first argument is not specified, this string should specify the input number to convert and its units.
t_outUnits	String giving the new units for `f_output`. If *t_outUnits* is `nil`, converts the number to the current units of the layout.

Value Returned

f_output	Converted value of *n_input.*
`nil`	Failed to convert value due to incorrect arguments.

Examples

- Typical use, convert from design units to another type (design is in mils)

```
axlMKSConvert(.5 "design" "INCHES") => 0.0005
axlMKSConvert(".5 MILS" "INCHES") => 0.0005
```

- Pre-register a unit type then use if on future conversions

```
axlMKSConvert(nil "MILS") => t
axlMKSConvert(.5) => 0.0005
```

- Go to default output conversion (METERS)

```
axlMKSConvert(.5 "MILS" nil) => 2.54e-05
```

- Not just length is supported (go to farads)

```
axlMKSConvert(1e-09 nil "pF") => 1000.0
```


©2023 All Rights Reserved.

axlMKSStr2UU

```
axlMKSStr2UU(
     t_String
     )
     ⇒ t_mksString/nil
```

Description

Converts an input string to a MKS string in current database units. If the input string is in MKS units, that is used as the basis for the conversion. If the string has no units, the function uses the default database units for the string.

Conversion may fail for the following reasons:

- Input string is not a legal MKS format.
- Conversion overflows the maximum database size allowed.

Notes:

- Conversion between metric and english units may result in rounding.
- Number returned is rounded to the database precision.

Argument

t_String	Input string.

Value Returned

t_mksString	MKS string in current database units.
nil	Failed to convert input string. See earlier Description for possible reasons.

Example

```
axlMKSStr2UU("100.1") -> "100.0 MILS"
```

Default conversion with the database in mils.

©2023 All Rights Reserved.

axlMapClassName

```
axlMapClassName(
     t_oldName/lt_oldName
     [g_mapToPCB]
     )
     ⇒ t_newName/lt_newName
```

Description

Use this function to write a SKILL program that runs in Allegro PCB Editor and APD. You can map from class names to the name appropriate to the program running your SKILL program. For example, you can write a program using Allegro PCB Editor class names and have the program run in APD.

The table shows the name mapping between Allegro PCB Editor and APD.

Table 24-1 Class Name Mapping

Allegro PCB Editor Class Name	APD Class Name
BOARD GEOMETRY	SUBSTRATE GEOMETRY
ETCH	CONDUCTOR
ANTI ETCH	ANTI CONDUCTOR
PACKAGE GEOMETRY	COMPONENT GEOMETRY
PACKAGE KEEPIN	COMPONENT KEEPIN
PACKAGE KEEPOUT	COMPONENT KEEPOUT
BOARD	SUBSTRATE

When using the list of names mode, names that are not recognized are returned "as is".

©2023 All Rights Reserved.

Argument

t_oldName	Allegro PCB Editor class name.
lt_oldName	List of Allegro PCB Editor class name.
g_mapToPCB	Optional. `t` maps from the APD name to the PCB names. Default is `nil` (PCB to APD conversion).

Value Returned

t_newName	Appropriate class name based on product type.
lt_newName	List of class names renamed.

Examples

1. Get APD class name when in APD.

```
axlMapClassName("ETCH") -> "CONDUCTOR"
```

2. Gets Allegro PCB Editor class name when in Allegro PCB Editor.

```
axlMapClassName("ETCH") -> "ETCH"
```

3. List in APD

```
axlMapClassName('("ETCH" "ANALYSIS")) -> ("CONDUCTOR" "ANALYSIS")
```


©2023 All Rights Reserved.

axlMemSize

```
axlMemSize(
     )
     ⇒ x_size
```

Description

Returns an estimate of memory use. Returns not what the program is *using*, rather what it is *requesting* from the operating system.

Argument

nothing

Value Returned

x_size	Estimate of memory use in bytes.

©2023 All Rights Reserved.

axlOSBackSlash

```
axlOSBackSlash(
     t_directory
     )
     ==> t_directory/nil
```

Description

This changes UNIX style forward slashes to DOS style backslashes. While most applications support either style, certain older Windows applications only support DOS style path.

The UNIX style is more amenable to SKILL programming.

On UNIX this just returns the incoming string.

Arguments

t_directory	String containing directory path with forward slashes

Value Returned

t_directory/nil

See Also

axlOSSlash

Example

```
p = axlOSBackSlash("/tmp/foo")
     -> "\\tmp\\foo"
```


©2023 All Rights Reserved.

axlOSControl

```
axlOSControl(
     s_name
     [g_value]
     )
     ==> g_currentValue/ls_names
```

Description

Inquires and/or sets the value dealing with the graphics. If setting a value, the return is the old value of the control.

A side effect of most of these controls is if a form is active that is displaying the current setting it may not be updated. Additional side effects of individual controls, currently supported, are listed in the following table.

Name	Value	Set?	Description	Equivalent	Side Effects
cpu	x_number	No	Returns number of available CPUs. Included in the number are multi-cpu multi-core, and hyper threading.	none	none
is64exe	t/nil	No	Returns t if this executable is 64bit	none	none
is64os	t/nil	No	Returns t if this is a 64bit based OS.	none	none
isWindows	t/nil	No	Returns t if a Windows OS and nil if UNIX or Linux.	none	none
hostname	string	No	Returns hostname of computer this programming is running on.	none	none
physicalMemory	x_number	No	Returns in units of 1Mbyte the amount of physical memory. This is not to be confused with virtual memory. **Note:** 32bit OS can at most address 4GB (4000MB) of memory. 32bit Windows is restricted to 3GB. So even if you have more installed on your PC this will still report 3GB.	none	none

©2023 All Rights Reserved.

Arguments

s_name	Symbol name of control. If this value is `nil`, all possible names are returned.
g_value	Optional symbol value to set. Usually a `t` or a `nil`.

Value Returned

See above

ls_names	If name is `nil` then returns a list of all controls.

Example

1. Get CPUs

```
size = axlOSControl('cpu)
-> 2
```

2. Get if 64bit program

```
axlOSControl('is64exe)
-> nil
```

See Also

axlUIControl, axlMemSize

©2023 All Rights Reserved.

axlOSNtp

```
axlOSNtp(
     s_mode
     t_serverName/nil
     )
     ==> x_nwtime/t_nwtime/t_server/nil
```

Description

Reports time from a NTP server.

If the value of *s_mode* is set to `'name`, then Allegro PCB Editor reports the default NTP server, obtained using the environment variable NTPSERVER. Default is `0.pool.ntp.org`.

Currently, the `axlOSNtp` command uses a timeout of 50 milliseconds.

On Linux, you can query NTP time using the following command.

```
/usr/sbin/ntpdate -q <hostname>
```

Note: IPv6 networks not supported.

Caution

Must be connected to Internet and, if a firewall is enable, it must be configured to allow port 123.

©2023 All Rights Reserved.

Arguments

s_mode	The possible values are: `'name`: Returns default NTP server name for Allegro PCB Editor. `t`: Returns network time and date as string (current time zone) `nil`: Returns time ID (seconds since 00:00:00 UTC, January 1, 1970)
t_serverName	Use NTP server or if the value specified in `nil`, default Allegro NTP server is used.

Value Returned

- `x_nwtime`: A time ID. This value is returned when the value of `s_mode` is set to `nil`.
- `t_nwtime`: Time and date in ASCII using current time zone. This value is returned when the value of `s_mode` is set to `t`.
- `t_server`: Name of the default time server. Returned when the value of `s_mode` is set to `'name`.
- `nil`: Returned in case of an error.

Example

```
time = axlOSNtp(t nil)
```


©2023 All Rights Reserved.

axlOSExit

```
axlOSExit(
     x_return
     )
     ⇒ no return
```

Description

This exits the program to the OS with the return value provided. The database is not saved. Typically for Allegro programs:

0	Success
1	Warnings
2	Error

Arguments

x_return

Value Returned

This does not return to the calling SKILL procedure.

Example

```
axlOSExit(0)
```


©2023 All Rights Reserved.

axlPPrint

```
axlPPrint(
     t_name
     )
     ⇒ t_pname
```

Description

Converts a string with Allegro PCB Editor's pretty print text function as follows:

- Ensures that the first character after a white space, _ (underscore) or / (forward slash) is capitalized.
- Ensures the rest of the text in the given string is lower case.

Argument

t_name	A string.

Value Returned

t_pname	The converted string.

Example

```
axlPPrint("ETCH/TOP") -> "Etch/Top"
```


©2023 All Rights Reserved.

axlPdfView

```
axlPdfView(
     t_pdfFile
     )
     ⇒ t
```

Description

Displays a PDF file from Allegro PCB Editor. If just the filename is given, attempts to find the PDF file using Allegro PCB Editor's `PDFPATH` variable. Displays the PDF file in an external PDF viewer.

On UNIX, the only supported PDF viewer is Acroread. The program, Acroread, must be in your `PATH`.

On Windows, uses the default PDF viewer registered with the Windows registry. If there is no registered PDF viewer, the call fails.

Argument

t_pdfFile	Name of PDF file to display.

Value Returned

`t`	PDF file displayed.
`nil`	Failed to display PDF file due one of the following: - No Acroread PDF viewer found on UNIX. - No PDF viewer registered on Windows.

Example

```
axlPdfView("allegro.pdf")
```


©2023 All Rights Reserved.

axlPrintDbid

```
axlPrintDbid(
     o_dbid/lo_dbid
     [o_port]
     ) -> t
```

Description

This is a debug function to print one or a list of dbids. Output format is terse and parsable. This will not print all attribute data in a dbid but is customized to aid in understanding the dbid data.

```
Format: <key> <attribute> <value>
```

where key can be

c	common value of attribute (objType, name, xy)
a	other attributes
l	printable detail on list of dbids associated with element Not all list of dbids are reported.
g	what groups have the object. Format: `g group <type> name= <name>`

Output is either directed to the SKILL window or if port is provided written to a file.

Note using the environment variable, `pv_showelem` you can get the same data in the s*how element* command.

Arguments

o_dbid/lo_dbid	dbid or a list of dbids
o_port	option port object (from outfile)

Value Returned

`t`

©2023 All Rights Reserved.

See Also

axlShowObject

Example

```
l = axlGetDesign()
axlPrintDbid(l)
```


©2023 All Rights Reserved.

axlRegexpIs

```
axlRegexpIs(
     t_exp
     )
     ⇒ t/nil
```

Description

Determines whether an environment variable expression contains Allegro PCB Editor compatible wildcard characters. Certain select-by-name functions support wildcard characters. You can test for the presence of wildcards before calling the select-by-name type of functions.

Regular expressions used by Allegro PCB Editor are more compatible with the character set allowed in the Allegro PCB Editor object names than SKILL regular expressions. Do not use to test patterns being sent to the SKILL `regexp` family of functions.

Argument

t_exp	SKILL symbol for the environment variable name.

Value Returned

`t`	Expression contains Allegro PCB Editor compatible wildcards.
`nil`	Expression does not contain Allegro PCB Editor compatible wildcards.

©2023 All Rights Reserved.

axlRunBatchDBProgram

```
axlRunBatchDBProgram(
     t_prog
     t_cmdFmt
     [?logfilet_logfile]
     [?startMsgt_startMsg]
     [?reloadDBt/nil]
     [?noUnloadt/nil]
     [?silentt/nil]
     [?noProgress   t/nil]
     [?warnProgram  t/nil]
     )
     ⇒ t/x_error
```

Description

Spawns batch jobs that require an open database via an abstract model. When the job completes, it prints a message and optionally reloads (`?reloadDB`) the database if successful. If the database is saved from the current active database, it uses a temporary name to avoid overwriting the database on disk.

The following options are always required (UIBatchSpawn):

t_prog	Name of the program to run.
t_cmdFmt	Command string.

The following options are optional.

t_logFile	Name of log file that the program creates. Registers this with the log file viewlog facility if the program ends in an error. If no log file is required, do not set this option. If no extension is given, adds `.log` as the extension.
startMsg	Enables a start message to display when the program starts. Defaults to the program name. If you override by providing this string, the message begins with `"Starting..."`
reloadDB	If you set this to `t`, the database reloads after a successful run of the program. If the batch program does not save the database (for example, reports) then there is no reason to reload database. dbids are refreshed.

©2023 All Rights Reserved.

noUnload	If you set this to `t`, you don't save the database to disk. You use this for a program that creates a new database or doesn't require an Allegro PCB Editor database. Default is `nil`.
silent	If you set this to `t`, no messages are displayed. Use when the user does not need to know that a program is spawned. Default is `nil`.
noProgress	If `t`, the progress meter does not display. Default is `nil`.
noLogview	When set, it prevents display if log file on program exit.
noWarnOnExit	When set, suppresses some exit warning messages.
warnProgram	Program supports warning status (returns 0, if success; 1, if warnings; and 2, if errors).
noExitMsgs	When set, suppresses messages about program success or failure.

Note: For `t_cmdFmt`, the formatting should include everything except the design filename. Place a `%s` where the design should appear. To get a `%s` while doing a `sprintf`, use a "`%%s`" as shown in following examples:

```
cmdFmt = "netrev -$ -q -r %s"
sprintf(cmdFmt, "%s -$ %s %s %%s", prog, argq argr)
```

Tip

a. For debug, set the env variable, `wait_debug`, on the Allegro command line:

```
set wait_debug
```

or in SKILL

```
axlSetVariable("wait_debug" nil)
```

This echos the spawning arguments of your program. You can also use this variable to see how Allegro spawns programs from its dialogs. The `"#T<num>.tmp"` name seen in this output is the temporary save of the current design to disk and the use of the `"%s"` argument in your `t_cmdFmt` statement.

b. For a list of Allegro programs and their command line arguments see the directory:

```
<cdsroot>/share/pcb/batchhelp
```

or run the batch program with the `"-help"` argument.

```
Example: idf_in -help
```


©2023 All Rights Reserved.

c. Many Allegro batch programs support `'-$'` as a standard argument. This prevents prompting for missing input arguments.

Argument

t_prog	string containing program name
t_cmdFmt	string containing starting arguments (including program)
t_logfile	optional string showing logfile
t_startMsg	optional string having start message
?reloadDB	Optional t/nil having database be reloaded after job completes
?noUnload	Optional t/nil stating database shouldn't be saved
?silent	Optional t/nil controlling info messages
?noProgress	Optional t/nil controlling progress meter

Value Returned

`t`	Batch job ran.
x_error	Error number that is program dependent on failure.

Examples

- Spawn genfeedformat which requires design to be saved to a temp file

  Program Args:

  - `-$` - silent
  - `-b` - name of design (required)
  - `%%s` - because we `sprintf` the format before calling batch we need to escape the `%s` by perpending an extra %

  SKILL:

```
sprintf(format "genfeedformat -$ %s %%s", "-b")
;format=  "genfeedformat -$ -b %s"
axlRunBatchDBProgram("genfeedformat" format
?logfile "genfeed")
```

  Without `sprintf`

©2023 All Rights Reserved.

```
axlRunBatchDBProgram("genfeedformat" "genfeedformat -$ -b %s" ?logfile
"genfeed")
```

- Spawn 3rd party program, notepad, on an existing file `"allegro.jrl"`. In this case we do not want to save design (`?noUnload t`) and no progress meter is required (`?noProgress t`)

```
axlRunBatchDBProgram("notepad" "notepad allegro.jrl"
    ?noUnload t ?noProgress t)
```

- Spawn 3rd party import login, a program that requires read/write database wrapping. Read existing 3rd party netlist file called "netlist.txt". Since design needs to be reloaded if import is successful use the "?reloadDB t" option.

  Program Args:

  - `-$` - silent
  - `-g` - run gate assign
  - `-y 1` - Always Place changed component
  - `netlist` - name of netlist file (for example, netlist.txt)
  - `%s` - use current design

  SKILL:

```
axlRunBatchDBProgram("netin"
"netin -$ -g -y 1 netlist %s"
?startMsg "Logic Import"
?logfile "netin"
?reloadDB t)
```

- Export IDF

  Program Args:

  - -d IDF - File name type
  - -V 3.0 - IDF version
  - -h 2000 - default package height
  - -s ... - Source id (note \"...\" allows spaces in name)
  - -o myidf - output idf files (with bdf and ldf extensions)
  - %s - axl will enter name of temp database saved to disk

  SKILL:

```
axlRunBatchDBProgram("idf_out"
     "idf_out %s -d IDF -o myidf -s \"allegro_16.3\" -b 1 -h 2000 -V 3.0")
```


©2023 All Rights Reserved.

- Import IDF, assumes an existing bdf file, unnamed.bdf. If successful load updated design back into memory via the reload option (`?reloadDB t`).

  Program Args:

  - -o %s - name of current design (%s - substitute in current design)
  - unnamed - name of bdf file on disk

  SKILL:

```
axlRunBatchDBProgram("idf_in" "idf_in -o %s unnamed" ?reloadDB t)
```


©2023 All Rights Reserved.

axlShowObject

```
axlShowObject(
     lud_dbid
     )
     ⇒ t/nil
```

Description

Displays the object data for each *dbid* in *lud_dbid* in a *Show Element* window. Does the same function as the interactive command `list element.` *lud_dbid* can be either a single *dbid* or a list of *dbids*.

Arguments

lud_dbid	*dbid*, or list of *dbids*.

Value Returned

`t`	Displayed the **Show Element** window for any objects.
`nil`	Failed to display the Show Element window for any objects.

Example

```
axlDBCreatePropDictEntry(
    "myprop", "real", list( "pins" "nets" "symbols"),
    list( -50. 100), "level")
axlClearSelSet()
axlSetFindFilter(
    ?enabled '("NOALL" "ALLTYPES" "NAMEFORM")
    ?onButtons "ALLTYPES")
axlSingleSelectName( "NET" "ENA2")
axlDBAddProp(axlGetSelSet(), list("MYPROP" 23.5))
axlShowObject(axlGetSelSet())
⇒ t
```

1. Defines the string-valued property `MYPROP`.
2. Adds it to the net `ENA2`.
3. Displays the result to the user with `axlShowObject`.

©2023 All Rights Reserved.

axlSleep

```
axlSleep(
     x_time
     )
     ==> t/nil
```

Description

Sleeps specified time.

This is a replacement for SKILL's sleep which is actually provided by the IPC SKILL package. On Windows the IPC sleep crashes if you call `axlEnterEvent`.

If you are using the IPC interfaces then you should call `axlSleep` instead of using `sleep`.

Arguments

x_time	Time in seconds.

Value Returned

`t`	All of the time.

©2023 All Rights Reserved.

axlSort

```
axlSort(
     t_infile
     t_outfile
     [t_sortfields]
     [t_sort_options]
     )
     ⇒ t/nil
```

Description

Sorts contents of a given input file and places results in the output file. No warning is given if the output file overwrites an existing file - any checking must be done by the caller of this function.

Default sort is a left to right, ASCII ascending sort of the input file, with duplicate lines left in. You can control the sort behavior using the optional parameters.

©2023 All Rights Reserved.

Argument

t_infile	Name of the input file to sort.
t_outfile	Name of the file containing results of the sort.
t_sortfields	String specifying which fields to use as sort keys, the sort order of those fields, and how to interpret the data type of the field for sorting. String contains a series of triplets: *field_number sortOrder fieldType* String can contain multiple triplets separated by commas. Triplets can contain valid elements as shown:

Triplet Element	Description
field_number	Number representing the position of the field on the line, from left to right. Numbering starts at 1.
sortOrder	A - Ascending sort order
	D - Descending sort order
fieldType	A - Alpha
	I - Integer
	F - Float

An example of a *t_sortfields* triplet:

```
"3 A A, 5 D I, 1 A F"
```

This triplet sorts based on the following:

1. The third field, ascending, field type ASCII.
2. The fifth field, descending, field type Integer.
3. The first field, ascending, field type Float.

t_sort_options	String containing directives controlling the global sort parameters. Sort options can appear in any order, and must be separated by commas. These options are available:

©2023 All Rights Reserved.

Option	Description
Field Delimiter	Supported delimiters include any character in punctuation character class except comma.
U	Remove duplicate lines. Default is keep duplicate lines.
D	Descending order. Default is ascending order.

An example of the *`t_sort_options`* string:

```
"!,U"
```

This means to use the '`!`' character as the field delimiter and to remove any duplicate lines.

Value Returned

`t`	Sort successful.
`nil`	Sort unsuccessful due to incorrect arguments.

©2023 All Rights Reserved.

Examples

Input file

```
2!3!4!5!6
2!3!4!5!6
5!6!7!8!9
5!1!7!8!9
2!2!3!4!5
1!2!3!4!5
3!4!5!6!7
4!5!6!7!8
```

Example 1

```
(axlSort "input.txt" "output.txt" nil "!,U")
```

Results 1

```
1!2!3!4!5
2!2!3!4!5
2!3!4!5!6
3!4!5!6!7
4!5!6!7!8
5!1!7!8!9
5!6!7!8!9
```

Example 2

```
(axlSort "input.txt" "output.txt" "2 A I, 1 D I" "!")
```

Results 2

```
5!1!7!8!9
2!2!3!4!5
1!2!3!4!5
2!3!4!5!6
2!3!4!5!6
3!4!5!6!7
4!5!6!7!8
5!6!7!8!9
```


©2023 All Rights Reserved.

axlStrcmpAlpNum

```
axlStrcmpAlpNum(
     t_str1
     t_str2
     )
     ⇒ t/nil
```

Description

Provides an alpha-numeric sort similar to `alphalessp` with one important distinction. If both strings end in the number, the number portion is separated and the two stripped strings are first compared. If they are equal, then the number sections are compared as numbers, rather than strings.

`alphalessp sort`	`U1 U10 U2`
`axlStrcmpAlpNum sort`	`U1 U2 U10`

Arguments

`t_str1`	A string
`t_str2`	A string

Value Returned

`0`	The two strings are equal.
`+num`	If *`t_str1`* is greater than *`t_str2`* (1 goes after 2)
`nil`	If *`t_str1`* is less than *`t_str2`* (1 goes before 2)

Example

```
l = '("U5" "U10" "U1" "U5" "U2")
sort(l 'axlStrcmpAlpNum)
===> ("U1" "U2" "U5" "U5" "U10")
```


©2023 All Rights Reserved.

axlStringCSVParse

```
axlStringCSVParse(
     t_string
     [g_stripWhite]
     [t_separator]
     ) -> lt_string/nil
```

Description

Parses a comma delimited line (typical from Excel). This differs from the SKILL parseString function in several areas which make it compatible with Excel csv file format:

- parseString ignores two adjacent commas.
- if a separator is contained within a cell, Excel quotes the cell. `parseString` treats this as two cells.
- Correctly processes double quotes in a cell.

Arguments

t_string	A csv string
g_stripWhite	Option to strip leading and trailing white space from each output string. Default is to leave whitespace. Do not advise using this option with separator set to " ".
t_separator	Optional separator character, default is a comma (,).

Value Returned

`lt_string`	list of strings parsed based on comma separator.
`nil`	error (unlikely to happen)

See Also

parseString in *Cadence SKILL Language Reference*

Examples

- White space strip example

©2023 All Rights Reserved.

```
ret = axlStringCSVParse(" a ,b" t)
-> ( "a" "b")
```

- Properly parse a csv file

```
ret = axlStringCSVParse("a,,c,\"d,e\"" )
-> ( "a" "" "c" "d,e")
```

- Properly parse a csv file

```
ret = axlStringCSVParse("a||c|\"d|e\"" nil "|" )
```


©2023 All Rights Reserved.

axlStringRemoveSpaces

```
axlStringRemoveSpaces(
     t_string
     ) -> t_modString/nil
```

```
axlStringRemoveSpaces(
     lt_string
     ) -> lt_modString/nil
```

Description

This will strip leading or trailing whitespace from a string (standard C `ilspace()` macro). Has two modes:

- one string
- list of strings

In list of strings, items in list that are not a string are filtered out of the return.

Argument

t_string	A string.
lt_string	list of strings

Value Returned

t_modString	Modified string
lt_modString	Modified strings
`nil`	Not a string

See Also

axlCheckString

Example

```
ret = axlStringRemoveSpaces(" a ")
ret = axlStringRemoveSpaces( '(" a " " b "))
```


©2023 All Rights Reserved.

axlVersion

```
axlVersion(
     s_option
     )
     ⇒ g_value/nil
```

Description

Returns Allegro PCB Editor or OS dependent data.

Argument

s_option	SKILL symbol for the environment variable name.

Value Returned

Return depends upon option given.

Option	Value	Returns
none	*ls_values*	List of available options.
version	*f_value*	Allegro PCB Editor program version, for example, 15.7.
tVersion	*t_value*	Allegro PCB Editor program version as a string, for example, 16.3.
fullVersion	*t_value*	Allegro PCB Editor program version and patch as a string (for example, 15.7 s01).
buildDate	*t_value*	Date program was built at Cadence (month/day/year), for example, 7/19/2006.

©2023 All Rights Reserved.

Option	Value	Returns
`release`	*`t_value`*	Allegro PCB Editor release value. Consists of a prefix and a number (*`<p><nn>`*), where prefixes are as shown: A - Alpha B - Beta P - Production S - Patch For example, S23 indicates the 23rd patch release.
`internalVersion`	*`t_value`*	Internal program version, for example, v13-5-26a.
`programName`	*`t_value`*	Executable being run, for example, `allegro`.
`displayName`	*`t_value`*	Short display name of program (may contain spaces.) Certain programs may change this during run-time depending on the license level. This may be the same or shorter then the formal name. It may change from release to release. *Example:* `"Allegro PCB Designer"`
`formalName`	*`t_value`*	Long display name of program (may contain spaces). This is the full formal name of program and may change during run-time since it depends upon the license level. The name can be the same or longer than *`'displayName`*, and may change from release to release.
`isWindows`	*`g_value`*	`t` if Windows operating system. `nil` if UNIX operating system.
`isAPDSi`	*`g_value`*	`t` if Allegro Package Designer SI L , `nil` otherwise

©2023 All Rights Reserved.

Option	Value	Returns
`isAPDSiL`	*g_value*	`t` if Allegro Package Designer SI L, `nil` otherwise
`isAllegroExpert`	*g_value*	`t` if Allegro Expert product, `nil` otherwise.
`isAllegroDesigner`	*g_value*	`t` if Allegro Designer product, `nil` otherwise.
`isAllegroOrcad`	*g_value*	`t` if Allegro OrCAD product, `nil` otherwise.
`isAllegroPCB`	*g_value*	`t` if Allegro PCB product, `nil` otherwise.
`isAPD`	*g_value*	`t` if Allegro Package Designer product, `nil` otherwise.
`isAPDL`	*g_value*	`t` if Allegro Package Designer L, `nil` otherwise
`isAPDXL`	*g_value*	`t` if Allegro Package Designer XL, `nil` otherwise
`isAPDLegacy`	*g_value*	`t` if Allegro Package Designer VT2300, `nil` otherwise
`isChipIOPlanner`	*g_value*	`t` if any Chip I/O Planner product, `nil` otherwise
`isICP`	*g_value*	`t` if any ICP based product (apd, sip), `nil` otherwise
`isSIP`	*g_value*	`t` if any SIP product, `nil` otherwise
`isSIPDigital`	*g_value*	`t` if any SIP Digital product, `nil` otherwise
`isSIPDigArch_L`	*g_value*	`t` if any SIP Digital Architect L product, `nil` otherwise
`isSIPRF`	*g_value*	`t` if any SIP RF product, `nil` otherwise
`isSIPRFArch_L`	*g_value*	`t` if any SIP RF Architect L product, `nil` otherwise
`isSigxp`	*g_value*	`t` if any version of SigXP product, `nil` otherwise.
`isSxExpert`	*g_value*	`t` if SigXP Expert product, `nil` otherwise.
`isSxExplorer`	*g_value*	`t` if SigXP Explorer product, `nil` otherwise.
`isEmbedded`	*g_value*	`t` if Embedded placement allowed.
`isBackdrill`	*g_value*	`t` if Backdrill functionality allowed.

©2023 All Rights Reserved.

Option	Value	Returns
`isToolbox`	*`g_value`*	`nil` no toolbox, `'orcad` – OrCAD toolbox active, `'allegro` – Allegro toolbox `axlIsToolbox()`: API is provided for legacy purposes and returns the same results.
`isSymphony`	*`g_value`*	`t` if running in Symphony (multi-user) mode.

Examples

```
axlVersion()
```


©2023 All Rights Reserved.

axlVersionIdGet

```
axlVersionIdGet(
     )
     ⇒ x_time
```

Description

Returns an id stamp based upon computer time.

Argument

none

Value Returned

x_time	Returns an id stamp based on computer time.

©2023 All Rights Reserved.

axlVersionIdPrint

```
axlVersionIdPrintd(
     x_time/t_time
     )
     ⇒ t_printTime/nil
```

Description

Prints version_id.

VERSION_ID is stored as a property on the database root and on the symbol definitions as shown:

```
axlDBGetDesign()->prop->VERSION_ID
```

Use to determine if a symbol should be refreshed. VERSION_ID is updated every time the database is saved, except if done as part of an uprev.

Argument

x_time/t_time	VERSION_ID obtained from the database property or returned from `axlVersionIdGet()`.

Value Returned

t_printTime	Printable string in standard Allegro PCB Editor date/time format.
`nil`	Failed to print VERSION_ID due to incorrect argument.

Example

```
axlVersionIdPrint(axlDBGetDesign()->prop->VERSION_ID
-> "Mon Dec 16 12:45:16 2004"
```


©2023 All Rights Reserved.

©2023 All Rights Reserved.

©2023 All Rights Reserved.

25

Math Utility Functions

Overview

This chapter describes the AXL-SKILL Math Utility functions.

axlDegToRad

```
axlDegToRad(
     n_angle
     ) => f_angle
```

Description

Converts an angle in degrees to radians.

Arguments

n_angle	Angle in degrees

Value Returned

f_angle	Angle in radians

See Also

axlRadToDeg, axlMathConstants

Example

```
axlDegToRad(45.0)
                 => 0.7853982
```


©2023 All Rights Reserved.

axlDistance

```
axlDistance(
     l_point1
     l_point2
     )
     ⇒ f_distance
```

Description

Returns the distance between two points. You may use floating point.

Arguments

l_point	A point.
ll_line	Two points at the ends of a line.

Value Returned

f_distance	Distance between two points in floating point form.

Example

```
axlDistance(10:20 5:20) = 5.0
```


©2023 All Rights Reserved.

axlGeo2Str

```
axlGeo2Str(
                 f_dbrep/point
        ) -> t_result/nil
```

Description

When converting floating point numbers to strings you may find the number printed is slightly differently then the value Allegro reports. This is difference is due to how floating point numbers are represented in the computer. The following article is an excellent paper on the subject: *What Every Computer Scientist Should Know About Floating-Point Arithmetic* by David Goldberg.

http://docs.sun.com/source/806-3568/ncg_goldberg.html

This article also explains why sometimes the comparison of two floating numbers that appear the same results in a non-equal result. The results only differ from printf when a "5" exists at the location one place more then the database accuracy. The behavior is as follows for rounding:

- if digit at db accuracy is odd and then 5 round up
- if digit at db accuracy is even and then 5 round down

See examples below. This supports two modes, a single floating point number and a point (a list of two floating point numbers).

Arguments

dbrep	a floating point number
point	a xy point

Value Returned

Returns a string with Allegro rounding. If a point is passed then the return format is: `"<x> <xy>"`

`nil`: not a legal argument

©2023 All Rights Reserved.

See Also

axlGeoEqual

Examples

Assume database is two decimal places

```
procedure( testit( f)
            printf("printf=%.2f\taxlGeo2Str=%s \toriginal value %.3f\n"
                        f axlGeo2Str(f) f)
            )
            testit(1.115)
            testit(1.125)
            testit(-1.115)
            testit(-1.125)
Results:
         printf=1.11     axlGeo2Str=1.12         original value 1.115
         printf=1.12     axlGeo2Str=1.12         original value 1.125
         printf=-1.11    axlGeo2Str=-1.12        original value -1.115
         printf=-1.12    axlGeo2Str=-1.12        original value -1.125
```

Using a point

```
axlGeo2Str(100.124:123.345)
```


©2023 All Rights Reserved.

axlGeoAngleBetweenLines

```
axlGeoAngleBetweenLines(
     l_line1
     l_line2
     )
     ⇒ f_angle
```

Description

Finds angle between two lines, in radians. If the lines are parallel or coincident, `0` is returned. The angle is the acute angle from *`l_line1`* to *`l_line2`*, and is positive if clockwise, negative if counter clockwise.

Arguments

`l_line1`	List of two points defining line 1
`l_line2`	List of two points defining line 2

Value Returned

`f_angle`	The angle between lines in RADIANS

©2023 All Rights Reserved.

axlGeoArcCenterAngle

```
axlGeoArcCenterAngle(
     l_startPoint
     l_endPoint
     f_angle
     [g_clockwise]
     )
     ⇒ l_center/nil
```

Description

Calculates the center of an arc given the angle between its endpoints. Uses the arguments depending on *g_clockwise* as shown in Figure 25-1 on page 1530.

Figure 25-1 Center of Arc Calculation

©2023 All Rights Reserved.

Arguments

l_startPoint	Start point of the arc
l_endPoint	End point of the arc
f_angle	Included angle of the arc
g_clockwise	Rotational sense of the arc: `t` is clockwise. `nil` is counterclockwise (the default).

Value Returned

l_center	Center of the arc as a list: (*X Y*).
`nil`	Cannot calculate the center from the given arguments.

Example

```
print axlGeoArcCenterAngle( 7500:5600 8000:4700 68.5 t)
mypath = axlPathStart(list( 7500:5600))
    axlPathArcAngle(mypath, 0., 8000:4700, t, 68.5)
    axlDBCreatePath( mypath, "etch/bottom")
⇒ (7089.086 4782.826)
```

Prints the center for the clockwise arc going through the points (7500:5600) and (8000:4700) using `axlGetArcCenterAngle`, then adds the arc through those points using `axlPathArcAngle`, and compares their centers.

The arc is shown in the following figure.

©2023 All Rights Reserved.

Do *Show Element* on the arc to show its center coordinate. The arc lists: `"center-xy (7089,4783)"` which agrees with the *(7089.086 4782.826)* printed by `axlGeoArcCenterRadius`.

©2023 All Rights Reserved.

axlGeoArcCenterRadius

```
axlGeoArcCenterRadius(
     l_startPoint
     l_endPoint
     f_radius
     [g_clockwise]
     [g_bigArc]
     )
     ⇒ l_center/nil
```

Description

Calculates center of an arc given its radius. Calculates `l_center` either for one arc or another depending on the arguments, as shown.

©2023 All Rights Reserved.

Arguments

l_startPoint	Start point of the arc
l_endPoint	End point of the arc
f_radius	Radius of the arc
g_clockwise	Rotational sense of the arc: `t` is clockwise. `nil` (default) is counterclockwise.
g_bigArc	Flag telling whether the arc extends as the larger or the smaller of the two arcs possible between the start and endpoints.

Value Returned

l_center	Center of the arc as a list: (*X Y*).
`nil`	Cannot calculate the center from the given arguments.

Example

```
print axlGeoArcCenterRadius( 7500:5600 8000:4700 1000)
⇒ (8499.434 5566.352)

mypath = axlPathStart(list( 7500:5600))
axlPathArcRadius(mypath, 0., 8000:4700, t, nil, 1000)
axlDBCreatePath( mypath, "etch/bottom")

print axlGeoArcCenterRadius( 7500:5600 8000:4700 1000 t)
⇒ (7000.566 4733.648)

mypath = axlPathStart(list( 7500:5600))
axlPathArcRadius(mypath, 0., 8000:4700, nil, nil, 1000)
axlDBCreatePath( mypath, "etch/top")
```

Prints the two possible centers for the arcs going through the points (7500:5600) and (8000:4700), then adds arcs through those points using `axlPathArcRadius`, and compares the centers.

©2023 All Rights Reserved.

The arcs are shown in the following figure.

Do *Show Element* on each arc to show its center coordinate.The solid arc on the left lists: `"center-xy (8499,5566)"` which agrees with the *(8499.434 5566.352)* printed by `axlGeoArcCenterRadius`. The dotted arc on the right lists: `"center-xy (7001, 4734)"`, which agrees within rounding with `(7000.566 4733.648)` printed for the other arc.

©2023 All Rights Reserved.

Arguments 3

```
axlMKSConvert(
    nil
    [t_outUnits]
)
⇒ t/nil
```

Pre-registers *t_outUnits*, the input units string, so that subsequent calls to axlMKSConvert need not specify units.

t_outUnits	String giving the units to convert to for subsequent calls to axlMKSConvert. If there is no active drawing, function fails with this combination of arguments.

Value Returned 3

t	Conversion string acceptable.
nil	Conversion string not acceptable.

Example 3

See Example 4 below.

Arguments 4

```
axlMKSConvert(
    n_input
)
⇒ f_output/nil
```

Use this combination of arguments only after a call to axlMKSConvert as in Arguments 3. Converts the number *n_input* specifying a value using the *t_outUnits* supplied by a previous call to axlMKSConvert, and returns as *f_output*.

n_input	Number giving the input value to convert

©2023 All Rights Reserved.

Value Returned 4

f_output	Converted value of *n_input.*

Example 4

```
(axlMKSConvert .5) -> nil ;;error,if no preregistered units
    (axlMKSConvert nil "MILS) -> t
    (axlMKSConvert .5) -> 0.0005 ; remembers MILS
```

The following **Show Element** form shows the net with `MYPROP` attached:

©2023 All Rights Reserved.

axlGeoArcMidpoint

```
axlGeoArcMidpoint(
     l_arcPoint1
     l_arcPoint2
     l_arcCenter
     f_radius
     g_clockwize
     )
     ⇒ l_midPoint/nil
```

Description

Finds midpoint of an arc.

Arguments

l_arcPoint1	Start point of arc
l_arcPoint2	End point of arc
l_arcCenter	Center of circle
f_radius	Radius
g_clockwize	Clockwise flag

Value Returned

`l_midPoint`	The midpoint
`nil`	

©2023 All Rights Reserved.

axlGeoCircleCircleInt

```
axlGeoCircleCircleInt(
     l_point1
     f_radius1
     l_point2
     f_radius2
     )
     ⇒ ll_intersections/nil
```

Description

Finds the intersection(s) between two circles.

Arguments

l_point1	Center point of circle 1
f_radius1	Radius of circle 1
l_point2	Center point of circle 2
f_radius2	Radius of circle 2

Value Returned

`ll_intersections`	A list of the intersection points
`nil`	No intersection

©2023 All Rights Reserved.

axlGeoCircleLineInt

```
axlGeoCircleLineInt(
     l_point1
     l_point2
     o_arcDbid
     )
     ⇒ ll_intersections/nil
```

Description

Finds the intersection(s) between a line and a circle.

Arguments

l_point1	A point on the line
l_point2	Another point on the line
o_arcDbid	Dbid of an arc

Value Returned

`ll_intersections`	A list of the intersection points
`nil`	No intersection

See Also

axlGeoCircleLineInt2

©2023 All Rights Reserved.

axlGeoCircleLineInt2

```
axlGeoCircleLineInt2(
     l_point1
     l_point2
     l_center
     f_radius
     )
     ⇒ ll_intersections/nil
```

Description

This function finds the intersection(s) between a line and a circle.

Arguments

l_point1	A point on the line
l_point2	Another point on the line
l_center	Center of an arc
f_radius	Radius of arc

Value Returned

`ll_intersections`	A list of the intersection points
`nil`	No intersection

See Also

axlGeoCircleLineInt

©2023 All Rights Reserved.

axlGeoEqual

```
axlGeoEqual(
     f_one
     f_two
     )
     ⇒ t/nil
```

Description

Performs an equal comparison between two floating point numbers and determines if they are equal within plus or minus the current database accuracy.

Useful for comparing floating point numbers converted from strings (example - using `atof` function) with those obtained from an AXL database id. Since the conversion of these numbers takes different paths (string to float versus integer to float, in the case of the database) you can have different numbers.

Note: To understand the basis of why a simple equal (==) comparison cannot always be used with floating point numbers see David Goldberg's paper on "*What Every Computer Scientist Should Know About Floating-Point Arithmetic*."

Wikipedia also has a good article: http://en.wikipedia.org/wiki/Floating_point

Floating point numbers can be internally represented by using two different formats; `float` (4 bytes) and `double` (8 bytes). All AXL interfaces use 8 bytes. SKILL interfaces depend upon the use so:

```
sscanf( "0.2" "%g" n)           ; skill float
sscanf( "0.2" "%lg" nd)         ; skill double
```

Wherever possible, use the double representation as it has more accuracy.

Arguments

Two floating point numbers.

©2023 All Rights Reserved.

Value Returned

`t`	Given numbers are equal within the current database accuracy.
`nil`	Given numbers are not equal within the current database accuracy.

Example

```
axlGeoEqual(2.0 2.0)
```

See Also

axlGeo2Str, axlGeoPointsEqual

©2023 All Rights Reserved.

axlGeoFindAngle

```
axlGeoFindAngle(
     l_vector
     l_origin
     )
     ⇒ f_angle/nil
```

Description

Finds the angle of a given vector.

Arguments

l_vector	The end point from the origin
l_origin	The origin

Value Returned

f_angle	The angle of the vector in RADIANS
nil	Vector or origin are invalid points

Example

```
axlGeoFindAngle(list(1 1) list(0 0))
=> 0.7853982
```


©2023 All Rights Reserved.

axlGeoGetBBox

```
axlGeoGetBBox(
     l_points
     )
     ⇒ l_bbox/nil
```

Description

Finds the bounding box of the given set of points.

Arguments

l_points	The set of points

Value Returned

l_bbox	The bounding box of the set of points
nil	Empty list

©2023 All Rights Reserved.

axlGeoIsBoxOverlap

```
axlGeolsBoxOverlap(
     l_first_bbox
     l_second_bbox
     [t_orientation]
     )
     ⇒ t/nil
```

Description

Determines whether a box overlaps another box.

Arguments

l_first_bbox	The bounding box of the first box
l_second_bbox	The bounding box of the second box
t_orientation	■ "x": check for horizontal overlap only ■ "y": check for vertical overlap only ■ nil: check for physical overlap (default)

Value Returned

`t`	The two boxes overlap
`nil`	The two boxes do not overlap

©2023 All Rights Reserved.

axlGeoLineMidpoint

```
axlGeoLineMidpoint(
     l_point1
     l_point2
     )
     ⇒ l_point/nil
```

Description

Finds midpoint of a line.

Arguments

l_point1	First point
l_point2	Another point

Value Returned

`l_point`	The midpoint
`nil`	Illegal arguments

©2023 All Rights Reserved.

axlGeoRotatePt

```
axlGeoRotatePt(
     f_angle
     l_xy
     l_origin/nil
     [mirror]
     ) -> l_xyResult/nil
```

Description

Rotates *xy* about an origin by angle. Optionally applies mirror on the *x* axis.

Arguments

f_angle	Angle 0 to 360 degrees (support for 1/1000 of a degree); rotation is counter-clockwise for positive numbers.
l_xy	xy point to rotate in user units.
l_origin	Origin to rotate about; if `nil` uses (0, 0)
mirror	optional mirror flag. Normally either `nil` (no mirror) or `t` for front-to-back mirror, also accepts `'GEOMETRY` and `'LAYERS` values, which may be set on database objects as their mirror type. You do not need to convert `'GEOMETRY` to t and `'LAYERS` to `nil`.

Value Returned

`l_xyResult`	Rotated result.
`nil`	Error in arguments or rotation would result in return being outside of the database extents.

Examples

- Rotate:

```
axlGeoRotatePt(45.0 10:200 5:2) ->   (-131.4716 145.5427)
```

- Rotate and mirror:

```
axlGeoRotatePt(45.0 10:200 5:2 t) -> (-138.5427 138.4716)
```

- Rotate about 0,0:

©2023 All Rights Reserved.

```
axlGeoRotatePt(90.0, 100:0 nil) ->  (0.0 100.0)
```


©2023 All Rights Reserved.

axlGeoPointsEqual

```
axlGeoPointsEqual(
     l_point1
     l_point2
     ) -> t/nil
```

Description

This performs an equal comparison between two xy points and determines if they are equal within db accuracy.

Arguments

two xy points

Value Returned

- `t` if they are equal within current database accuracy.
- `nil` not equal

See Also

axlGeoEqual

Examples

```
pt1 = '(2.0 1.1)
pt2 = '(2.0 1.1)
axlGeoPointsEqual(pt1 pt2)
```


©2023 All Rights Reserved.

axlGeoPickShorterArc

```
axlGeoPickShorterArc(
     l_start
     l_end1
     l_end2
     l_center
     f_radius
     g_clockwize
     )
     ⇒ l_point/nil
```

Description

Picks the shorter arc from two possibilities.

Arguments

l_start	Start point
l_end1	One possible endpoint
l_end2	Other possible endpoint
l_center	Center of arc
f_radius	Radius of arc
g_clockwize	Clockwise flag of arc

Value Returned

`l_point`	The point that gives the shorter arc
`nil`	Bad arguments

©2023 All Rights Reserved.

axlGeoIsShorterArcClockwise

```
axlGeolsShorterArcClockwise(
     l_start
     l_end
     l_centerPoint
     )
     ⇒ t/nil
```

Description

Given a start point, end point and center of an arc, determines whether the clockwise or counter-clockwise arc from start to end is the shorter arc. If the arc end points are on a diameter, it returns `t` (clockwise).

Arguments

l_start	Start point of the arc
l_end	End point of the arc
l_centre	Centre point of the arc

Value Returned

f_angle	The angle between lines in RADIANS

©2023 All Rights Reserved.

axlGeoUnrotatePt

```
axlGeoUnrotatePt(
     f_angle
     l_xy
     l_origin/nil
     [mirror]
     ) -> l_xyResult/nil
```

Description

Undoes the specified rotation and mirror to return to definition of the point prior to transform. This routine should be used to be consistent with transforms done by the database.

Arguments

f_angle	Angle 0 to 360 degrees (support for 1/1000 of a degree); rotation is counter-clockwise for positive numbers.
l_xy	xy point to rotate in user units.
l_origin	Origin to rotate about; if `nil` uses (0, 0)
mirror	Optional mirror flag. Normally either `nil` (no mirror) or `t` for front-to-back mirror, also accepts `'GEOMETRY` and `'LAYERS` values, which may be set on database objects as their mirror type. You do not need to convert `'GEOMETRY` to t and `'LAYERS` to `nil`.

Value Returned

`l_xyResult`	Unrotated result.
`nil`	Error in arguments or rotation would result in return being outside of the database extents.

See Also

axlGeoRotatePt

©2023 All Rights Reserved.

axlMathSolveQuadratic

```
axlMathSolveQuadratic(
     n_a
     n_b
     n_c
     )
     ⇒ l_roots/nil
```

Description

Solves a quadratic equation in the form ax^2+bx+c=0. Does not solve equations with complex roots.

Arguments

n_a	a in ax^2+bx+c=0
n_b	b in ax^2+bx+c=0
n_c	c in ax^2+bx+c=0

Value Returned

`l_roots`	A list of the roots
`nil`	Complex roots

Example

```
axlMathSolveQuadratic(1 2 1)
=> (-1.0)
```


©2023 All Rights Reserved.

axlIsBetween

```
axlIsBetween(
     g_testNum
     g_x1, g_x2
     ) -> t/nil
```

Description

Checks if a number lies between two other given numbers. Returns `t` if a number is in a given range specified by two numbers. For example, for number n and range specified by x1 and x2, `t` will be returned if either of x1<= n <= x2 or x1<= n >= x2 is true.

Arguments

`g_testNum`	Number to test
`g_x1, g_x2`	Number range to test

Value Returned

`t` if number is in range including the end values, otherwise `nil`

See Also

axlIsPointInsideBox

©2023 All Rights Reserved.

axlIsPointInsideBox

```
axlIsPointInsideBox(
     l_point
     l_box
     )
     ⇒ t/nil
```

Description

Checks if a point is inside a bounding box. Returns `t` if a point is inside or on the edge of a bounding box. Also see axlGeoPointInShape on page 1595 for *dbid*-based tests. You may use floating point.

Arguments

l_point	A point.
l_box	A bounding box.

Value Returned

`t`	Point is inside or on the edge of box
`nil`	Point is outside of box.

Example

```
axlIsPointInsideBox(10:20 list(5:20 15:30)) = t
axlIsPointInsideBox(0:20 list(5:20 15:30)) = nil
axlIsPointInsideBox(15:20 list(5:20 15:30)) = t
```


©2023 All Rights Reserved.

axlIsPointOnLine

```
axlIsPointOnLine(
     l_point
     ll_line
     [f_nearNess]
     )
     ⇒ t/nil
```

Description

Returns `t` if point is on a given line or `nil` if not on the line.

If f_nearNess value is provided, it is used as a tolerance so if a point is within the tolerance value.

In either case, an epsilon of axlEpsilonFloat (see axlMathConstants) is applied.

Arguments

l_point	A point.
ll_line	Two end points.
[f_nearNess]	(optional) A tolerance value

Value Returned

`t`	Point is on the specified line.
`nil`	Point is not on the specified line.

Example

```
axlIsPointOnLine(10:20 list(5:20 15:30)) = nil
axlIsPointOnLine(10:30 list(5:20 15:30)) = t
axlIsPointOnLine(10:20 list(5:20 15:30) 2.5) = t
```

See Also

axlIsBetween

©2023 All Rights Reserved.

axlLineSlope

```
axlLineSlope(
     ll_line
     )
     ⇒ f_slope
```

Description

Returns the slope of a line. You may use floating point.

Arguments

ll_line	Two end points.

Value Returned

f_slope	Slope of the line.
`nil`	Line is vertical.

Example

```
axlLineSlope(list(5.0:20.10 15.4:30.2)) = 0.9711538
axlLineSlope(list(5:20 5:40)) = nil
```


©2023 All Rights Reserved.

axlLineXLine – Obsolete

This function is no longer required, but is kept for backward compatibility.

©2023 All Rights Reserved.

axlMathConstants

Provides predefined set of high accuracy math constants. They are:

- `axlPI` – PI
- `axlPI_2` – PI/2.0
- `axlPI_4` – PI/4.0
- `axlSQRT2` – sqrt(2)
- `axlSQRT1_2` – 1/sqrt(2)
- `axlEpsilonFloat` – epsilon for floating point numbers (32 bit)
- `axlEpsilonDouble` – epsilon for doubles (64 bit)
- `axlDegPerRad` – Degrees per radian
- `axlRadPerDeg` – Radians per degree

axlRad0, axlRad45, axlRad90, axlRad135, axlRad180, axlRad225, axlRad270, axlRad315, axlRad360 – radians values for popular degrees values

SKILL, by default, limits the number of decimal places printed but these constants are still stored and used at the full precision. To see the full precision of the constant you can do:

```
sstatus(fullPrecision t)
```

or

```
printf("%5.18f\n" axlPI)
```


©2023 All Rights Reserved.

axlMathDotProduct

```
axlMathDotProduct(
     l_ptA1
     l_ptA2
     l_ptB1
     l_ptB2
     ) -> f_dotProduct
```

Description

This calculates the dot or scaler product.

Dot Product:

```
(ptB1.y - ptA1.y)*(ptB2.y - ptA2.y) + (ptB1.x - ptA1.x)*(ptB2.x - ptA2.x)
```

Line are perpendicular when return is 0.0

Arguments

Four coordinates describing 2 lines.

Value Returned

Dot product result.

Example

```
axlMidPointLine(list(5:20 15:30)) = (10.0 25.0)
```

See Also

axlDistance

©2023 All Rights Reserved.

axlMidPointArc

```
axlMidPointArc(
     ll_endPoints
     l_center
     f_radius
     g_clockwise
     ) -> l_midPoint
```

Description

Returns mid-point on a arc. Note mid-point may not be on a database coordinate. All parameters may be obtained from a arc dbid.

Arguments

ll_line	arc end points
l_center	center of arc
f_radius	arc radius
g_clockwise	Is arc in clockwise (`t`) or counter clockwise direction (`nil`)

Value Returned

l_midPoint	mid-point of line
`nil`	error in arguments

See Also

axlMidPointLine

Example

- try clockwise

```
axlMidPointArc(list(20:0 0:20) 0:0 20 t) = (-14.14214 -14.14214)
```

- try counter-clockwise

```
axlMidPointArc(list(20:0 0:20) 0:0 20 nil) = (14.14214 14.14214)
```


©2023 All Rights Reserved.

axlMidPointLine

```
axlMidPointLine(
     ll_line
     ) -> l_midPoint
```

Description

Returns mid-point of line. Note mid-point might not be a database coordinate.

Arguments

ll_line	Two end points

Value Returned

l_midPoint	mid-point of line
nil	error in arguments

Example

```
axlMidPointLine(list(5:20 15:30)) = (10.0 25.0)
```

See Also

axlMidPointArc

©2023 All Rights Reserved.

axlMPythag

```
axlMPythag(
     l_pt1
     l_pt2
     ) -> f_distance/nil
```

Description

Calculates distance between two points using Pythagoras. This is faster then building this code in SKILL.

The `l_ptN` is an x:y coordinate.

Arguments

l_pt1, l_pt2	Two xy points.

Value Returned

f_distance	Distance between points.
`nil`	Arguments were not xy points.

See Also

axlMXYAdd

Example

```
axlMPythag(1263.0:1062.0 1338.0:1137.0) -> 106.066
```


©2023 All Rights Reserved.

axlMUniVector

```
axlMUniVector(
     l_pt1
     l_pt2
     [f_length]
     ) -> l_uniPt1
```

Description

This calculates a unit-vector. A unit vector allows one to calculate points additional points along that line.

It has two modes of operation:

- Without a length returns a unit vector to use in other operations like `axlMXYMult`. Use this mode if you need to calculate several points from the same unit vector.
- With a length, calculates a new `xy` location f_length from l_pt1 along the vector specified by `pt1` and `pt2`.

This provides optimized solution over the traditional trigonometric approach.

Arguments

l_pt1, l_pt2:	2 xy points
f_length:	optional length to project

Value Returned

Returns a unit-vector, xy point

nil: arguments were not xy points

Examples

Found a point 5 units along a line from 1263.0:1062.0 to 1338.0:1137.0

```
origin = 1263.0:1062.0
uniVec = axlMUniVector(origin 1338.0:1137.0)
res = axlMXYMult(uniVec, 5.0 origin)
```


©2023 All Rights Reserved.

Same as example 1 except have `uni vec` do all the work

```
res = axlMUniVector(origin 1338.0:1137.0 5.0)
```


©2023 All Rights Reserved.

axlMXYAdd

```
axlMXYAdd(
     l_pt1
     l_pt2
     ) -> l_pt/nil
```

Description

This does a `l_pt1 + lpt2` and returns the result.

The `l_ptN` is an x:y coordinate.

Arguments

l_pt1, l_pt2	Two xy points.

Value Returned

l_pt	Returns coordinate that is result of addition.
`nil`	Arguments are not coordinates.

See Also

axlMXYSub

Example

```
axlMXYAdd(1263.0:1063.0 1338.0:1137.0) -> (2601.0 2200.0)
```


©2023 All Rights Reserved.

axlMXYMult

```
axlMXYMult(
     l_uniVec
     f_factor
     [l_origin]
     ) -> l_pt/nil
```

Description

This is a convenience function that does a `l_pt.x * f_factor` and `lpt.y * factor` and returns the result. If provided an origin, it adds the origin.

```
(l_uniVec * f_factor) + l_origin
```

It is normally used in conjunction with `axlMUniVector` to project a point along a vector.

Arguments

l_uniVec	xy point
f_factor	multiplication factor
l_origin	additive point

Value Returned

l_pt	Returns resultant coordinate
nil	Arguments are not coordinates

Examples

```
axlMXYMult(1263.0:1063.0 2.0) -> (2526.0 2126.0)
```

See Also

axlMUniVector

©2023 All Rights Reserved.

axlMXYSub

```
axlMXYSub(
     l_pt1
     l_pt2
     ) -> l_pt/nil
```

Description

This does a `l_pt1 - lpt2` and returns the result.

The `l_ptN` is an x:y coordinate.

Arguments

l_pt1, l_pt2	Two xy points.

Value Returned

l_pt	Returns coordinate that is result of subtraction.
`nil`	Arguments are not coordinates.

See Also

axlMXYAdd

Example

```
axlMXYSub('(1263.0 1063.0) '(1338.0 1137.0)) -> (-75.0 -74.0)
```


©2023 All Rights Reserved.

axlRadToDeg

```
axlRadToDeg(
     n_angle
     ) => f_angle
```

Description

Converts an angle in radians to degrees.

Arguments

n_angle	The angle in radians

Value Returned

f_angle	The angle in degrees

See Also

axlDegToRad, axlMathConstants

Example

```
axlRadToDeg(0.7853982)
     => 45.0
```


©2023 All Rights Reserved.

axl_ol_ol2

```
axl_ol_ol2(
     l_seg1
     l_seg2
     )
     ⇒ l_result
```

Description

Finds the intersection point of two lines. If the lines intersect, returns the intersection point with a distance of 0. If the lines do not intersect, the distance is not zero and the function returns `t`.

Arguments

l_seg1	1st line segment (list *x1*:*y1* *x2*:*y2*)
l_seg2	2nd line segment (list *x1*:*y1* *x2*:*y2*)

Value Returned

`nil`	Error due to incorrect argument.
(*car l_result*)	Intersect or nearest point on seg1
(*cadr l_result*)	Intersect or nearest point on seg2
(*caddr l_result*)	Distance between the two intersect points.

©2023 All Rights Reserved.

Examples

Data for examples

```
a=list(1:5 5:5)
b=list(2:5 4:2)
c=list(0:0 5:0)
d=list(4:5 7:5)
```

Example 1

```
axl_ol_ol2(a b)
```

⇒ ((2.0 5.0) (2.0 5.0) 0.0)

Intersects line, returns intersection point, note distance of 0.

Example 2

```
axl_ol_ol2(a c)
```

⇒ ((3.0 5.0) (3.0 0.0) 5.0)

Lines don't intersect, returns closest point on each line and distance.

Example 3

```
axl_ol_ol2(a d)
```

⇒ ((4.5 5.0) (4.5 5.0) 0.0)

Lines overlap, distance of 0 and selects mid-point of the overlap.

©2023 All Rights Reserved.

bBoxAdd

```
bBoxAdd(
     l_bBox1
     l_bBox2
     ) -> l_bBox_result
```

Description

Adds two bounding boxes together and returns the result.

Arguments

2 bBox values

Value Returned

Resulting bounding box.

Example

Expand bounding box by 100.

```
orig = '((200 100) (400 500))
res = bBoxAdd(orig '((-100 -100) (100 100)))
-> ((100 0) (500 600))
```

Example 2

```
res = bBoxAdd('((200 100) (400 500)) '((0 0) (200 100)))
-> ((200 100) (600 600))
```


©2023 All Rights Reserved.

©2023 All Rights Reserved.

26

Database Miscellaneous Functions

Overview

This chapter describes the AXL-SKILL functions that do not fit into other sections.

©2023 All Rights Reserved.

axlAirGap

```
axlAirGap(
     o_item1DBID
     o_item2DBID/l_xy
     [t_layer]/nil
     [s_mode]
     )
     ==> l_airGapData/nil/(s_error l_airGapData/l_errorData)
```

Description

Finds the air gap and location between two given items. Gap is the same as reported by the `show measure` command. Any geometric objects; logical, group or symbols are not supported (same as show measure). Unfilled shapes are currently treated as filled but this may change in the future.

You only need to provide a layer option when measuring between two pin or vias (also called pad comparison). When doing pad comparison without the layer, the current active layer is used. The layer syntax should either be "ETCH/<subclass>" or "<subclass>".

For the following special via or pin subclasses spacing, either provide "PIN or "VIA CLASS" as the class name.

- SOLDERMASK_TOP
- SOLDERMASK_BOTTOM
- PASTEMASK_TOP
- PASTEMASK_BOTTOM
- FILMMASKTOP
- FILMMASKBOTTOM

Both of these class names work equally well with pins and vias. If you want the soldermask top spacing between a pin and via, then use "PIN/SOLDERMASK_TOP".

The second argument may be a location (in design units). Gap reports the minimum distance from the first object to this location. In enhanced mode, the location is reported as the "ETCH/TOP" layer.

Output data is returned in one of the following formats depending on the `s_mode` option:

©2023 All Rights Reserved.

Default is `s_mode (s_mode==nil)` returns the `l_airGapData` or a `nil` if there is an error. If `s_mode` is `t` then data is returned as `(s_error l_airGapData)` where `s_error` is one of the following:

`t`	`Success (t (l_airGapData))`
`'NOMATCH`	No subclass matches between pin or via and object. Returns object's layer. (`NOMATCH (t_layer)`)
`'RANGE`	No subclass match between two etch elements (one or both must be a pad element (pin or via). If common layers exist, Allegro PCB Editor returns the top and bottom layer where matches exist otherwise returns `nil`: (`ETCH (t_topMatch t_bottomMatch)`)
`'INVALID`	One or both elements are invalid. Data return format: (`INVALID nil`).

Enhanced out, `s_mode = 'enhanced` offers anyLayer air gap and returns a disembodied property list of:

airGap = <spacing between objects> (floating point)

location1 = xy location first item where air gap measured

location2 = xy location of second item where air gap measured

layer1 = layer (class subclass) of where first object measured (string)

layer2 = layer (class subclass) of where second object measured (string)

isEtch = both objects of type ETCH (boolean)

For distance between two pads, return gap based upon the active etch subclass, if `t_layer` is `nil`. Otherwise use `t_layer` to determine gap. If one or both pads do not exist on that layer:

- in anyLayer mode the distance between the closest pad layers is returned.
- it is an error in `s_mode=nil` or `s_mode=t`

For distance between a pad and non-pad element; use the layer of the pad that you want the measurement if layer is not provided, the active layer or the top layer of the padstack is used.

If performance is a concern, use `anyLayer` mode over enhanced output.

The distance, if objects do not share the same layer, does not take into account board thickness.

©2023 All Rights Reserved.

Tip

For legacy purposes, this interface does not return an air gap if the two objects do not share the same layer. If you want the air gap any layer use `s_mode = 'anyLayer` or `s_mode ='enhanced`.

©2023 All Rights Reserved.

Arguments

o_item1DBID	`dbid` of the first item.
o_item2DBID	`dbid` of the second item.
l_xy	The second item can be a xy location in design units and must be in the design extents.
t_layer	Optional layer used to resolve gap comparison between two pin or via elements. If in 'anyLayer or 'enhanced mode, this targets a particular layer for comparison. It is most useful in measuring mask layer gaps.
s_mode	Return additional info to clarify error. This may be: ■ `nil`: Default mode (objects must be on the same layer) ■ `t`: `("full mode")` return `l_airGapData` or if not share see above (objects must be on the same layer) ■ `anyLayer`: support any layer measure return just gap ■ `enhanced`: return disembodied property list of additional air gap criteria (see above) ■ `overlap`: return `-1` if two objects overlap and `0` if they only touch. Otherwise, this functions the same as default mode.

Value Returned

`l_airGapData`	List containing the following items: `(l_airGapPt1 l_airGapPt2 f_airGapDistance)` where *l_airGapPt1:* (X,Y) point on the 1st item where the gap is measured. *l_airGapPt2:* (X,Y) point on the 2nd item where the gap is measured. *f_airGapDistance:* Distance between the two points.
nil	Input data error; element 1 and 2 are the same or no air gap can be computed between the two items. If `t_layer` is used but does not specify an etch layer.

©2023 All Rights Reserved.

s_error See error symbols listed above.

Examples

- Basic input

```
axlAirGap(el1 el2)
-> ((1337.5 1100.0) (1362.5 1100.0) 25.0)
```

- Basic input layer

```
axlAirGap(el1 el2 "TOP")
-> ((1337.5 1100.0) (1362.5 1100.0) 25.0)
```

- Full output success

```
axlAirGap(el1 el2 nil t)
-> (t ((1337.5 1100.0) (1362.5 1100.0) 25.0))
```

- Any layer airgap

```
q = axlAirGap(el1 el2 nil 'anyLayer)
```

- Enhanced output

```
q = axlAirGap(el1 el2 nil 'enhanced)
```

- Obtain soldermask spacing

```
axlAirGap(el1 el2 ""PIN/SOLDERMASK_TOP" )
-> (((1337.5 1100.0) (1362.5 1100.0) 40.0))
```

- Obtain spacing to design origin

```
q = axlAirGap(el1 0:0 nil 'enhanced)
```

- Full output failure

```
axlAirGap(el3 el2 nil t)
-> (RANGE ("TOP" "GND"))
```


©2023 All Rights Reserved.

axlBackDrill – Obsolete

This interface is obsolete. Use axlBackdrillGet to retrieve actual backdrilling of pins and vias. Data returned by this interface may not match the actual backdrill results in the design.

©2023 All Rights Reserved.

axlDBGetLength

```
axlDBGetLength(
     o_dbid
     )
     ==> f_etchlength/nil
```

Description

Calculates the length of the given object which may be a NET, CLINE, SEGMENT, or RATSNEST. If RATSNEST returns the Manhattan length. If a net is partially routed, includes sum of all ratsnest Manhattan lengths.

Currently does not include VIA-Z or PIN_DELAY in its calculation.

Arguments

`o_dbid`	*dbid*

Value Returned

`nil`	Not a legal object
`f_etchLength`	Length of object

See Also

axlDBGetManhattan, axlDBPinPairLength

Example

```
Skill> p = ashOne()
Skill> axlDBGetLength(p)
-> 2676.777
```


©2023 All Rights Reserved.

axlDBGetManhattan

```
axlDBGetManhattan(
     o_dbid_net
     )
     ⇒ l_result/nil
```

Description

Given a net, calculates an etch, path, and Manhattan length. The result is the same as that used by list element.

- Etch - The current length of etch. The length is 0 when there is no etch.
- Path - The etch plus remaining length. When the net is fully connected, there is no remaining, and path is equal to etch.
- Manhattan - The estimated routing length.

Note: Path is equal to Manhattan when the net has no etch.

Arguments

o_dbid	Net *dbid*.

Value Returned

l_result	(*etchLength path manhattan*)
nil	Not a net *dbid*.
	Net is out of date.
	No ratsnest.

See Also

axlDBGetLength

Example

```
p = ashOne()
axlDBGetManhattan(p)
(2676.777 3300.0)
```


©2023 All Rights Reserved.

axlDBGetSymbolBodyExtent

```
axlDBGetSymbolBodyExtent(
     o_dbid
     )
     -> bBox/nil
```

Description

This returns the body extent of a symbol. Unlike the bBox associated with a dbid, a body extents is either one of the following.

1. the extent box created by the union of all shapes on layers PACKAGE_GEOMETRY (PLACE_BOUND_TOP, PLACE_BOUND_BOTTOM, DFA_BOUND_TOP, DFA_BOUND_BOTTOM) and EMBEDDED_GEOMETRY (PLACE_BOUND and DFA_BOUND)
2. the symbol bbox, a union of all items in symbol

The symbol instance extent box is based upon the design origin while the symdef box is based upon the symbol origin.

Arguments

o_dbid	A symbol instance or definition

Value Returned

`bBox`	body box of symbol `(minX:minY maxX:maxY)`
nil	dbid is not a symbol instance (symbol) or definition (symdef)

See Also

axlDBAltOrigin

©2023 All Rights Reserved.

axlDBPinPairLength

```
axlDBPinPairLength(
     o_pin1
     o_pin2
     )
     ==> f_etchlength/nil
```

Description

Calculate the shortest length between 2 pins. Pins must be on the same xnet. The pin can also be a VIA or RAT_T. If the distance is not fully routed, it includes a Manhattan estimate of the unrouted portion.

Includes VIA-Z or PIN_DELAY in its calculation if these options are enabled and if your license permits this capability.

Arguments

o_pin1	A pin, via or rat_t
o_pin2	A pin, via or rat_t on same xnet as o_pin1

Value Returned

`nil` – Not a legal object; unsupported dbid or items not on same xnet

`f_etchLength` – length of object

See Also

axlDBGetLength

Example

```
Skill> pin1 = ashOne()
Skill> pin2 = ashOne()
Skill> axlDBPinPairLength(pin1 pin2)
         -> 2676.777
```


©2023 All Rights Reserved.

axlDeleteByLayer

```
axlDeleteByLayer(
     t_layerName/lt_layerName
     [nil/'fixed]
     )
     ==> x_cnt/nil
```

Description

Deletes all data on one or more provided layers. The following should be noted:

- Does not delete pins or vias.
- Deletes pins escapes and other symbol data associated with symbols.
- Does not delete objects on a symbol definition. If you are using this interface as a prerequisite to deleting a layer, objects on a symbol definition may prevent you from deleting the layer.
- To delete dynamic shapes, you also need to delete data on the equivalent BOUNDARY class.
- Certain classes, such as, DRC_ERROR_CLASS, PIN, VIA_CLASS, ROUTER_PLAN and CAVITY, are ignored.

Arguments

t_layerName	layer name <class>/<subclass>
lt_layerName	list of layer names
'fixed	Optional, ignore FIXED property

Value Returned

x_cnt	number of items deleted
nil	any error

©2023 All Rights Reserved.

Example

- Delete all data on ETCH/TOP except for fixed data

```
axlDeleteByLayer("ETCH/TOP")
```

- Delete all data on ETCH/BOTTOM plus OUTLINE layers including fixed

```
axlDeleteByLayer(list("ETCH/TOP" "BOARD GEOMETRY/OUTLINE") 'fixed)
```


©2023 All Rights Reserved.

axlExtentDB

```
axlExtentDB()
     ⇒ l_bBox/nil
```

Description

Determines a design type and returns the *bBox* extent.

For a layout this function computes the layout extents and returns the smallest bounding box to be used for window-fit. Only `lines`, `linesegs`, and `shapes` are searched on selected layers in the following order:

1. `BOARD GEOMETRY/OUTLINE`
2. `PACKAGE KEEPIN/ALL`
3. `ROUTE KEEPIN/ALL`

The first layer with any elements is used to determine the layout extents. If no elements are found on these layers, the design extents are returned.

For a symbol drawing (a `.dra` file), this function computes the bounding box enclosing all objects visible for a drawing.

Arguments

None

Valued Returned

l_bBox	Returns *bBox* extent.
`nil`	Unknown drawing type.

©2023 All Rights Reserved.

axlExtentLayout – Obsolete

This function is obsolete. Use `axlExtentDB`. Kept for backward compatibility.

©2023 All Rights Reserved.

axlExtentSymbol – Obsolete

This function is obsolete. Use axlExtentDB. Kept for backward compatibility.

©2023 All Rights Reserved.

axlFindPath

```
axlFindPath(
     o_oneDbid
     o_twoDbid
     [g_altPath]
     )
     ==> lo_dbid/llo_dbid/nil
```

Description

Finds an etch path from one object to another. Items must be on the same net and must be connect type, such as, pins, vias, clines or shapes, and tee.

Restrictions:

- A partial connection between the 2 objects (ratsnest still exists) results in a nil return.
- Segments are promoted to their owning cline (path)

Return list is ordered by:

```
o_oneDbid, ... <connected items>, o_twoDbid
```

To use this for finding loops on a net, you must compare every node to every other node. This can be very time consuming for large pin count nets.

Caution

– If multiple paths exist between the two objects, returns will follow a single path but the one it uses is not defined (by this it may decide on the shortest or longest.

– Because of the high number of interconnects, VOLTAGE nets may not return correct results since the algorithm is recursive and terminates if it nests too deeply.

©2023 All Rights Reserved.

Arguments

o_oneDbid	first net item
o_twoDbid	second net item
[g_altPath]	enable alternate path

Value Returned

nil	no path exists between objects or an error
lo_dbid	path list if `g_altPath` is `nil`
llo_dbid	path list if `g_altPath` is `t`. First item is one path and second item is nil or the alternative path. (`lo_1dbid` `lo1dbid`)

Example

1. Find a path between two items

```
; ashOne is a selection utility found at <cdsroot>/pcb/examples/skill/ash-fxf/
ashone.il
one = ashOne()
two = ashOne()
; pick a line, cline or segment (set find filter)
path = axlFindPath(one two)
axlShowObject(path)
```

2. See if the two objects is a start/end point of a loop

```
path = axlFindPath(one two t)
```


©2023 All Rights Reserved.

axlGeoClosestPointOnArc

```
axlGeoClosestPointOnArc(
     l_point
     o_arcDbid
     )
     ⇒ l_closest_point/nil
```

Description

Finds the closest point from the given arc to the given point.

Arguments

l_point	A point
o_arcDbid	Dbid of an arc

Value Returned

`l_closest_point`	The closest point on the arc to the given point
`nil`	Invalid parameters

©2023 All Rights Reserved.

axlGeoClosestPointOnCircle

```
axlGeoClosestPointOnCircle(
     l_point
     l_center
     l_radius
     )
     ⇒ l_closest_point/nil
```

Description

Finds the closest point from the given circle to the given point.

Arguments

l_point	A point
l_center	Center point of circle
l_radius	Radius of circle

Value Returned

`l_closest_point`	The closest point on the arc to the given point
`nil`	Invalid parameters

See Also

axlGeoClosestPointOnArc

©2023 All Rights Reserved.

axlGeoPointInShape

```
axlGeoPointInShape(
     l_point
     o_dbid/o_polygon
     [g_include_voids]
     [t/nil]
     )
     ⇒ t/nil
```

Description

Given a point and a shape *dbid*, determines whether that point is inside or outside the shape or a polygon. For a shape with voids, a point is considered *outside* the given shape if inside a void. If shape has voids and g_include_voids is t then point is outside if inside a void.

The command does not allow hole polygons as input. When polygon holes is passed the following warning is displayed:

```
Invalid polygon id argument -<argument>
```

Arguments

l_point	Point to check.
o_dbid/o_polygon	dbid of the shape / o_polygon
[g_include_voids]	Applicable only in case the second parameter is a shape otherwise it's ignored. In case of shapes, if the parameter value is nil, voids are excluded. The default value is `t`.
[t/nil]	`t` means include voids, `nil` means use the shape outline only.

Default is t.

Value Returned

t	Point is inside the shape.
nil	Point is outside the shape, or incorrect arguments were given.

See Also: axlGeoPointShapeInfo

©2023 All Rights Reserved.

axlGeoPointShapeInfo

```
axlGeoPointShapeInfo(
     l_point
     o_dbid
     ) ==> (g_state o_dbid)/nil
```

Description

Given a point and a shape dbid returns relation of point to shape. State may be outside, inside or on. Additional dbid is returned in the second argument to indicate if void or shape is involved.

Return matrix:

G_STATE	O_DBID
outside	nil if outside shape, void dbid if inside void
inside	nil
on	shape dbid if on shape else void dbid

Caution

- Assumes that cross-hatch shapes are solid filled.
- Rounds point to database units. If database accuracy is 2 and you pass a 3 decimal place point, we will round it to 2 places before doing the test.

Arguments

`l_point`	the point
`o_dbid`	dbid of the shape

Value Returned

`nil` - if an error since as an invalid argument

`g_state/o_dbid` - see *Description*

©2023 All Rights Reserved.

axlGetImpedance

```
axlGetImpedance(
     o_dbid
     ) => (f_min f_max)/nil
```

Description

Returns minimum and maximum impedance for given item. Item can be either cline, cline segment, net or xnet. Impedance is in ohms by default.

Arguments

o_dbid	Segment cline

Value Returned

f_min f_max	Impedance in current MKS units.
nil	Segment is not a cline segment.

See Also

axlSegDelayAndZ0

©2023 All Rights Reserved.

axlGeoMirrorLayer

```
axlGeoMirrorLayer(
     t_layer
     t_mirror
     )
     ⇒ t_result/nil
```

Description

Mirrors a subclass to get the target layer. Given a layer and one of the mirror codes, the function returns the layer, which maps based on the mirroring.

Arguments

t_layer	Name of the starting layer
t_mirror	Mirror code to apply (`'GEOMETRY`, `'LAYERS`, `t`, `nil`).

Value Returned

`t_result`	Layer to put objects on after mirroring.
`nil`	Error in arguments or layer doesn't exist

Example

```
axlGeoMirrorLayer("ETCH/TOP" t) -> "ETCH/BOTTOM";
```


©2023 All Rights Reserved.

axlImpdedanceGetLayerBroadsideDPImp

```
axlImpdedanceGetLayerBroadsideDPImp(
     t_layer1/x_layerNum1
     t_layer2/x_layerNum2
     f_width
     ) ==> f_diffImpedance/nil
```

Description

Computes the differential impedance of a broadside-coupled diffpair with the given line width and two specified layers on which the signal lines will be routed. A warning message may be given if the parameters are inappropriate for the calculation.

Arguments

`t_layer1`	Layer name (example "ETCH/TOP" or "TOP")
`x_layerNum1`	Number of the etch subclass. Layers are numbered starting with 0 for the Top layer.
`t_layer2`	Layer name (example "ETCH/TOP" or "TOP")
`x_layerNum2`	Number of the etch subclass. Layers are numbered starting with 0 for the Top layer.
`f_width`	The line width in user units.

Value Returned

The line differential impedance in ohms (float) or `nil` on error.

See Also

axlImpedance2Width

©2023 All Rights Reserved.

axlImpdedanceGetLayerBroadsideDPWidth

```
axlImpdedanceGetLayerBroadsideDPWidth(
     t_layer1/x_layerNum1
     t_layer2/x_layerNum2
     f_diffImpedance
     )
     ==> f_lineWidth/nil
```

Description

Computes the differential impedance of a broadside-coupled diffpair with the given line width and two specified layers on which the signal lines will be routed. A warning message may be given if the parameters are inappropriate for the calculation.

Arguments

`t_layer1`	Layer name (example "ETCH/TOP" or "TOP")
`x_layerNum1`	Number of the etch subclass. Layers are numbered starting with 0 for the Top layer.
`t_layer2`	Layer name (example "ETCH/TOP" or "TOP")
`x_layerNum2`	Number of the etch subclass. Layers are numbered starting with 0 for the Top layer.
`diffImp`	The target differential impedance in ohms.

Values Returned

The line width in user units or `nil` on error.

See Also

axlImpedance2Width

©2023 All Rights Reserved.

axlImpdedanceGetLayerEdgeDPImp

```
axlImpdedanceGetLayerEdgeDPImp(
     t_layer/x_layerNum
     f_spacing
     f_width
     ) ==> f_diffImpedance/nil
```

Description

Computes the differential impedance of a edge-coupled diffpair with the given line width and spacing on a specified layer. A warning message may be given if the parameters are inappropriate for the calculation.

Arguments

`t_layer`	Layer name (example "ETCH/TOP" or "TOP").
`x_layerNum`	Number of the etch subclass. Layers are numbered starting with 0 for the Top layer.
`f_spacing`	Spacing between the two signal lines in use units.
`f_width`	The line width in user units.

Value Returned

The differential impedance value in ohms (float) or `nil` on error.

See Also

`axlImpedance2Width`

©2023 All Rights Reserved.

axlImpdedanceGetLayerEdgeDPSpacing

```
axlImpdedanceGetLayerEdgeDPSpacing(
     t_layer/x_layerNum
     f_width
     f_diffImp
     )
     ==> f_spacing/nil
```

Description

Given the line width of the two signal lines of an edge-coupled diffpair on the specified layer, finds the spacing such that the differential impedance is closest to the target value. A warning message may be given if the parameters are inappropriate for the calculation.

Arguments

`t_layer`	Layer name (example "ETCH/TOP" or "TOP").
`x_layerNum`	Number of the etch subclass. Layers are numbered starting with 0 for the Top layer.
`f_width`	The given line width, in user units.
`f_diffImp`	The target differential impedance in ohms.

Value Returned

The target spacing in user units or `nil` on error.

See Also

`axlImpedance2Width`

©2023 All Rights Reserved.

axlImpdedanceGetLayerEdgeDPWidth

```
axlImpdedanceGetLayerEdgeDPWidth(
     t_layer/x_layerNum
     f_spacing
     f_diffImp
     ) ==> f_width/nil
```

Description

Given the spacing of the two signal lines of an edge-coupled diffpair on the specified layer, finds the line width such that the differential impedance is closest to the target value. A warning message may be given if the parameters are inappropriate for the calculation.

Arguments

`t_layer`	Layer name (example "ETCH/TOP" or "TOP").
`x_layerNum`	Number of the etch subclass. Layers are numbered starting with 0 for the Top layer.
`f_spacing`	The spacing between the two signal lines in user units.
`f_diffImp`	The target differential impedance in ohms.

Value Returned

The line width in database units (float) or `nil` on error.

See Also

`axlImpedance2Width`

©2023 All Rights Reserved.

axlImpedance2Width

```
axlImpedance2Width(
     t_layer/x_layerNum
     f_impedance
     ) ==> f_lineWidth/nil
```

Description

Converts the given impedance on a specified layer to a line width.

Note: None of the `axlImpedance` APIs are available in Allegro PCB L.

Arguments

`t_layer`	Layer name (example "ETCH/TOP" or "TOP").
`x_layerNum`	Number of the etch subclass. Layers are numbered starting with 0 for the Top layer.
`f_impedance`	The impedance value, in ohms, that is to be converted to a line width.

Value Returned

`f_lineWidth`	The converted line width in drawing units.
`nil`	Conversion was not successful.

See Also

axlImpedance2Width

axlImpdedanceGetLayerEdgeDPImp

axlImpdedanceGetLayerEdgeDPWidth

axlImpdedanceGetLayerEdgeDPSpacing

axlImpdedanceGetLayerBroadsideDPImp

axlImpdedanceGetLayerBroadsideDPWidth

©2023 All Rights Reserved.

axlPadOnLayer

```
axlPadOnLayer(
     o_dbid
     t_layer/x_layerNumber
     [g_noPadSuppress]
     )
     ==> t/nil
```

Description

Tests if a pad is present on an etch layer. A pad is present on the layer if the padstack has a regular, anti or thermal pad and it is not suppressed by the rules of Pad Suppression.

While this does support a padstack dbid, for best operation, pass the VIA or PIN object.

Arguments

o_dbid	A via, pin or padstack
t_layer	Name of layer (for example, "TOP")
x_layerNumber	layer number (starts at 0)
g_noPadSuppress	t if ignore pad suppression, nil (default) use pad suppression

Value Returned

`t` if a pad is on layer; `nil` no pad on layer

See Also

axlPadSuppressGet

Example

- Using ashOne shareware in `<cdsroot>/share/pcb/examples/skill/ash-fxf/ashone.il`

  Assuming a design where pad suppression is enabled on etch layer GND

```
pad = ashOne(list("vias" "pins"))

res1 = axlPadOnLayer(pad "GND")
```


©2023 All Rights Reserved.

```
res2 = axlPadOnLayer(pad "GND" t)
```


©2023 All Rights Reserved.

axlPinExport

```
axlPinExport(
     g_includeTextLocation
     [t_csvfile]
     )
     --> t/nil
```

Description

This exports all pins in the symbol editor in csv format. The format of the csv file is described in axlPinImport.

Note: Function is only enabled in symbol editor.

Arguments

g_includeTextLocation	if `t`, include pin text location (offset, rotation and mirror); `nil` omits data which means pin text when loaded into a symbol will be located at pin origin.
t_csvfile	Name of csv file; default is symbol name. Assumes a csv extension.

Value Returned

t	csv file created
nil	failed to create csv file

See Also

axlPinImport

Example

See example in axlPinImport.

©2023 All Rights Reserved.

axlPinImport

```
axlPinImport(
     t_csvFile
     )
     --> l_cnt/nil
```

Description

This imports pin csv (comma separated values) file into the symbol editor. With this file you can describe the location and other characteristics of a set of pins (including mechanical) that comprise a symbol.

Note: This function is only enabled in symbol editor.

To best understand the format of this file, you should export one via axlPinExport.

Two formats are supported:

- pin only, pin text is located at pin origin
- pin with text

File format:

- A '#' indicates a comment
- (Optional) Units,*<units strings>*
- table describing pins

Pin Table (column number indicated)

1. PinNumber - Pin number, if blank then a mechanical pin.
2. Padstack - name of padstack
3. x - x location of pin (no units)
4. y - y location of pin (no units)
5. rotation - pin rotations, if blank has no rotations

If the pin text option is used then the following columns should be present.

1. x offset location from pin origin
2. y offset location from pin origin

©2023 All Rights Reserved.

3. rotation of text (absolute), if blank no rotation
4. textMirror; blank no mirror, "m" text should be mirrored

Text block used for pin text is the design active text block.

Note: Setting axlDebug() may give additional info on why pins fail to load.

Arguments

t_csvFile	csv file, assumes a .csv extension.

Value Returned

nil	Unable to open file or no pins loaded
l_cnt	A list of `(x_pinsLoaded x_pinFailed)`

See Also

axlPinExport

Example

- In the symbol editor with a `dra` file loaded. Export pins with text location, date, delete all pins and then import them:

```
axlPinExport(nil "foo")
axlDeleteObject(axlDBGetDesign()->pins nil
axlPinImport(foo")
```


©2023 All Rights Reserved.

axlReratNet

```
axlReratNet(
     t_netName/o_dbid
     )
     ==> t/nil
```

Description

Rerats a net. Normally this is not required since Allegro PCB Editor automatically updates ratsnesting as required.

Arguments

t_old_name	the existing net name.
o_dbid	Alternative is a dbid that is on a net

Value Returned

t	the net is successfully reratted.
nil	fails.

Example

```
axlReratNet("NET1")
```


©2023 All Rights Reserved.

axlText2Lines

```
axlText2Lines(
     o_textDbid
     )
     ==> llr_path/nil
```

Description

This vectorizes a text dbid into a list of lists of `r_path` objects.

The return is a list of list `r_paths` for each character:

```
llr_path = (l_rpathChar1, l_rpathChar2 ... l_lrpath_CharLast)
```

Each character can have one or more line draws and each line draw can have one or more segments. For example, an 'A' has 2 line draws; one have 2 segments and the second 1 segment.

```
l_rpathChar1 = (l_rpathLine1, ... lrpathLineN)
```

where:

```
l_rpathLineX->_width  -> thickness of line
l_rpathLineX->__pathList -> list of segments making up a line
```

Things to note:

- Vectorization returns line segments (no arcs) although this may change in the future.
- A single character may return multiple r_paths and one r_path may have multiple segments.
- The width is the same for all lines making up a single `textDbid`. This means that the width for all segments undefined since the r_path has the width.
- Characters are returned left to right.
- Whitespace is skipped.

Allegro draws all text as stroke text. This converts a text dbid into a series of line draws using `r_path` structures.

Tip

You can convert a `r_path` to an `o_polygon` by using axlPolyFromDB using its "`?line2poly t`" option.

©2023 All Rights Reserved.

Arguments

o_textDbid	A text dbid

Value Returned

llr_path	A list of list of r_paths (see above)
nil	An error (not a text dbid) or text dbid is an empty string (shown in Allegro with a small triangle).

See Also

axlPolyFromDB, Path Functions

Example

Function ashOne is a shareware utility that allows user to select one object (see `<cdsroot>/share/pcb/examples/skill/ash-fxf/ashone.il`).

- Pick a text and add converted lines on BOARD GEOMETRY/OUTLINE layer

```
text = ashOne("TEXT")
lines = axlText2Lines(text)
layer = "BOARD GEOMETRY/OUTLINE"
; flatten list
flattened = foreach( mapcan x lines x)
; create objects in database
foreach(path flattened i = axlDBCreatePath(path layer nil nil nil))
```

- Pick a text and add converted to shapes on "BOARD GEOMETRY/ASSEMBLY_DETAIL

```
text = ashOne("TEXT")
lines = axlText2Lines(text)
layer = "BOARD GEOMETRY/ASSEMBLY_DETAIL"
; flatten list
flattened = foreach( mapcan x lines x)
foreach(path flattened
; may return multiple polys
polys = axlPolyFromDB(path ?endCapType 'ROUND ?line2poly t)
; create shapes in database
foreach(poly polys i = axlDBCreateShape(poly t layer nil nil))
)
```


©2023 All Rights Reserved.

axlUnfixAll

```
axlUnfixAll(
     )
     ==> x_count
```

Description

This is a convenience API.

If removes the FIXED property from all elements in the design.

Arguments

none

Value Returned

x_count	Number of fixed properties removed.

Example

```
axlUnfixAll()
```


©2023 All Rights Reserved.

axlWidth2Impedance

```
axlWidth2Impedance(
     t_layer/x_layerNum
     f_lineWidth
     ) ==> f_impedance/nil
```

Description

Converts the given line width on a specified layer to an impedance. This uses the field solver to compute the impedance

Arguments

`t_layer`	Layer name (example "ETCH/TOP" or "TOP").
`x_layerNum`	Number of the etch subclass. Layers are numbered starting with 0 for the Top layer.
`f_lineWidth`	The line width to be converted to an impedance.

Value Returned

`f_impedance`	The converted impedance value.
`nil`	Conversion was not successful.

See Also

axlImpedance2Width

©2023 All Rights Reserved.

axlIsHighlighted

```
axlIsHighlighted(
     o_dbid
     )
     ==> x_highlightColor/nil
```

Description

If the object is permanently highlighted returns the highlight color; otherwise `nil`.

Note: Pins can be highlighted.

Only symbols, nets, pins and DRC errors can be highlighted. Cadence suggests that you do not highlight DRC objects unless they are external DRCs, since Allegro PCB Editor DRCs are frequently recreated.

Arguments

o_dbid	A `dbid` for which highlighting information is desired.

Value Returned

x_highlightColor	Highlight color; `nil` if not highlighted, or object does not support highlighting.

See Also

axlHighlightObject

Examples

See axlHighlightObject

©2023 All Rights Reserved.

axlTestPoint

```
axlTestPoint
     o_dbid
     top|bottom|nil
     )
     ⇒ t/nil/s_error
```

Description

Sets or clears a pin and/or via's test point status. Abides by the rules of the testprep parameter form in its ability to add a test point (see possible errors, below). If testprep rules prevent adding a test point, an error symbol is returned. If the command fails for other reasons, `nil` is returned. On success, a `t` is returned.

If you add a test point to a pin/via that already has a test point, the existing test point is replaced.

Uses current testprep parameter settings except (these may be relaxed in future releases):

- set to flood
- set allow SMT/Blind or Thru pad stack type

Not enabled in a symbol editor.

Adds test point text using same rules as the `testpoint manual` command.

Note: Does not delete associated test point text. This may be a future enhancement. For the present, use `axlDeleteObject` and `axlDBGetAttachedText`.

Supports `axlDebug` API to print failure to place error.

©2023 All Rights Reserved.

Arguments

o_dbid	Pin or via *dbid*
g_mode	Add test point to top or bottom, or clear one.

Value Returned

t	Object changed.
nil	Error other than test point checks.
s_error	Symbol indicating an error from testprep parameter check.

Errors

PAD_TOO_SMALL	Size does not meet parameter minimums
PAD_UNDER_COMP	Padstack under component
PIN_OFF_GRID	Pin off grid
PAD_UNDEFINED	Layer of padstack not defined on required layer
PAD_NOT_SMD	Padstack must be a SMD
PAD_NOT_THRU	Padstack must be a thru pad
PAD_IN_NO_PROBE_AREA	Testpoint pad in NO_PROBE area
PIN_IS_VIA	Pin type requires a via or any point
PIN_NOT_VIA	Pin type requires a via
PIN_NOT_OUTPUT	Pin type requires an output pin for test point
PIN_NOT_IO	Pin type requires an IOpin for test point
PIN_TOO_CLOSE	Pin too close to another test point
PAD_UNDER_PIN	Test point under another pin
PIN_NOT_NODE	Test point requires a node for testbench
FIXED_TEST_POINTS	Testpoints are fixed and cannot be removed
OTHER	Unclassified error

©2023 All Rights Reserved.

Examples

The following examples use the `ashone.il` file in `<cdsroot>/share/pcb/skill/examples` to allow you to select objects:

1) Add testpoint to top

```
axlUIWPrint(nil 'info1 "Select pin or via to add testpoint")
dbid = ashOne('(VIAS PINS))
ret = axlTestPoint(dbid 'top)
```

2) Clear a testpoint

```
axlUIWPrint(nil 'info1 "Select pin or via to clear testpoint")
dbid = ashOne('(VIAS PINS))
ret = axlTestPoint(dbid nil)
```


©2023 All Rights Reserved.

axlChangeNet

```
axlChangeNet(
     o_dbid
     t_netName/o_netdbid
     )
     ⇒ t/nil
```

Description

Changes the net an object is currently on. Restricted to shapes, filled rectangles (frectangles), pins and vias. Returns `t` when successful. Will not rip up clines or vias.

Failure can occur for the following reasons:

- Object is not supported.
- netName does not exist.

The following restrictions apply to this function:

- Pins must be assigned. Pins must have an associated component. Mechanical pins are un-assigned.
- Via net assignment is advised. The via must be able to connect to something on the provided net to remain on that net. Otherwise, it will fall back to the original net or possibly another net.
- If a via is in open space, it will be on a dummy net. This API cannot be used to force it onto a net.
- This API is useful for a via, if it touches multiple shapes but it is assigned to the wrong shape's net.

Potential side effects of this function:

- It may not properly reconnect two touching cline segments that were previously connected by the shape.
- Clines only attached to the shape will inherit the new net of the shape.
- Vias attached to the shape will not inherit the new net. This is different from the Allegro change net command.

©2023 All Rights Reserved.

Arguments

o_dbid	Shape *dbid*
t_netName/ o_netdbid	Name of a net or a netdbid (for dummy nets)

Value Returned

`t`	Object changed.
`nil`	No object changed.

©2023 All Rights Reserved.

axlSegDelayAndZ0

```
axlSegDelayAndZ0(
     o_clineSegDbid
     )
     ⇒ (f_delay f_z0)/nil
```

Description

Returns the delay and impedance of a cline segment. Returns `nil` if a segment isn't a cline segment. Normally, delay is in nanoseconds and impedance is in ohms.

This function is noisy if you pass in non-cline segments.

Arguments

o_clineSegDbid	Segment cline

Value Returned

f_delay f_z0	Delay and impedance in current MKS units.
`nil`	Segment is not a cline segment.

See Also

axlGetImpedance

©2023 All Rights Reserved.

axlSetDefaultDieInformation

```
axlSetDefaultDieInformation(comp)
     ==> t/nil
```

Description

Sets the default die information for a component.

This function will configure a newly-placed IC-class component as a die in an MCM design. Based on the placed component's information the die will be flagged as either wire bond or flip-chip.

Arguments

`comp`	dbid of the component / symbol to set default information for.

Value Returned

`t` if successful, `nil` otherwise.

©2023 All Rights Reserved.

27

Microsoft Excel Integration Functions

axlSpreadsheetClose

```
axlSpreadsheetClose()
     ==> t
```

Description

Releases the spreadsheet document in memory. All information is freed. This function should be called whenever you have completed working with the active spreadsheet document.

Once the spreadsheet information is released, you cannot access any data about it. This includes retrieving style information, cell contents, lists of worksheets, etc. Any such information that you need to reference after the spreadsheet is freed should be retrieved prior to this call.

If there is no active spreadsheet, this function does nothing.

Arguments

Nothing

Values Returned

`t`	Spreadsheet information successfully freed.

Example

The following example creates a simple spreadsheet, adds information to the first cell ("Hello"), writes the spreadsheet, and closes it.

```
axlSpreadsheetInit()
     ==> t
```


©2023 All Rights Reserved.

```
axlSpreadsheetSetWorksheet("First")
     ==> t

axlSpreadsheetDefineCell(1 1 "Default" "String" "Hello")
     ==> t

axlSpreadsheetWrite("example.xml")
     ==> t

axlSpreadsheetClose()
     ==> t
```

See Also

axlSpreadsheetInit, axlSpreadsheetRead, axlSpreadsheetWrite

©2023 All Rights Reserved.

axlSpreadsheetDefineCell

```
axlSpreadsheetDefineCell(
     x_row
     x_col
     t_style
     t_type
     t_value)
     ==> t / nil
```

Description

Completely defines a single cell in the active worksheet. This function is more efficient than calling axlSpreadsheetSetCell with multiple axlSpreadsheetSetCellProp calls afterwards.

Arguments

x_row	Row index (1-based) for the desired cell.
x_col	Column index (1-based) for the desired cell.
t_style	Style name to apply to this cell / nil for default.
t_type	Type definition for this cell / nil for default (string).
t_value	Value for cell / nil for empty.

Value Returned

t	Cell successfully defined.
nil	Cell not defined. See console for reason.

Example

The following example sets the contents of cell 1, 1 in the active worksheet to be the string "Hello" using the default style.

```
axlSpreadsheetDefineCell(1 1 "Default" "String" "Hello")
     ==> t
```

See Also

axlSpreadsheetGetCell, axlSpreadsheetSetCell, axlSpreadsheetSetCellProp

©2023 All Rights Reserved.

axlSpreadsheetDoc

Description

The axlSpreadsheet family of functions allow you to read and write Microsoft's open XML-based spreadsheet format from within SKILL. You can create a spreadsheet from data within your active Allegro tool, or you can read a spreadsheet and extract information from it to update your database.

Documentation for individual functions is separately available. This entry provides an overview, as well as a small example of how to use the API routines together.

Example

The following is a simple example which creates a small, two-worksheet spreadsheet with a few formatting style definitions and cells which use those styles to format their contents when the spreadsheet is viewed with a tool such as Microsoft's Excel.

```
procedure( spreadsheetExample() ; Initialize an empty spreadsheet.
    ; Note that you do not need to provide a name until you
    ; wish to write the spreadsheet to disk.
    axlSpreadsheetInit()

    ; Define inital, default style.
    ; Styles may be defined at any point during the spreadsheet's
    ; construction, but must be defined before they are referenced
    ; by any row, column, or cell.
    axlSpreadsheetSetStyle("Default"  nil)
    axlSpreadsheetSetStyleProp("Alignment" "Vertical"   "Top")
    axlSpreadsheetSetStyleProp("Alignment" "Horizontal" "Left")
    axlSpreadsheetSetStyleProp("Alignment" "WrapText"   "1")

    ; Define a second style, derived from the Default style, which
    ; will include a thin border outline and specifies a red
    ; background fill.
```


©2023 All Rights Reserved.

```
    axlSpreadsheetSetStyle("Red" "Red Cell")
    axlSpreadsheetSetStyleParent("Default")
    axlSpreadsheetSetStyleBorder("Left"   nil "Continuous" "2")
    axlSpreadsheetSetStyleBorder("Right"  nil "Continuous" "2")
    axlSpreadsheetSetStyleBorder("Top"    nil "Continuous" "2")
    axlSpreadsheetSetStyleBorder("Bottom" nil "Continuous" "2")
    axlSpreadsheetSetStyleProp("Fill" "Color"
axlSpreadsheetGetRGBColorString(255 0 0))
    axlSpreadsheetSetStyleProp("Fill" "Pattern" "Solid")

    ; Define the first worksheet in the spreadsheet.
    axlSpreadsheetSetWorksheet("First")
    ; With a wider first column
    axlSpreadsheetSetColumnProp(1 "Width" "500")
    axlSpreadsheetDefineCell(1 1 "Default" "String" "Default formatted cell")
    axlSpreadsheetDefineCell(1 2 "Red" "String" "Red background cell")

    ; Write the compiled spreadsheet to XML file on disk.
    axlSpreadsheetWrite("spreadsheet.xml")

    ; Close and release the compiled spreadsheet's data.
    axlSpreadsheetClose()
)
```


©2023 All Rights Reserved.

axlSpreadsheetGetCell

```
axlSpreadsheetGetCell(
     x_row
     x_col
     )==> g_cellData/ nil
```

Description

Retrieves the data from the specified cell.

Arguments

`x_row`	Row index (1-based) of cell to look up.
`x_col`	Column index (1-based) of cell to look up.

Value Returned

`g_cellData`	Structure defining the contents cell
`nil`	Cell contents are currently empty or undefined.

Example

The following example reads a spreadsheet into memory, then gets the contents of one cell from the first worksheet.

```
axlSpreadsheetRead("example.xml")
     ==> t

axlSpreadsheetSetWorksheet("First")
     ==> t

g_cell = axlSpreadsheetGetCell(1 1)

g_cell->??
     ==> (column 4
     row    1
     data   "a"
     type   "String"
     style  "Default"
     )

axlSpreadsheetClose()
     ==> t
```


©2023 All Rights Reserved.

See Also

axlSpreadsheetSetCell, axlSpreadsheetSetCellProp, axlSpreadsheetDefineCell

©2023 All Rights Reserved.

axlSpreadsheetGetRGBColorString

```
axlSpreadsheetGetRGBColorString(
     x_red
     x_green
     x_blue)
     ==> t_rgb / nil
```

Description

Given red, green, and blue color values, return an RGB string for use in spreadsheet style definitions in format required for Microsoft open spreadsheet format.

Arguments

`x_red`	Integer red value (0-255)
`x_green`	Integer green value (0-255)
`x_blue`	Integer blue value (0-255)

Value Returned

`t_rgb`	String denoting the color value for the RGB value passed in.
`nil`	Illegal values passed (outside legal range).

Example

The following example get the RGB string value associated with pure red.

```
axlSpreadsheetGetRGBColorString(255 0 0)
     ==> "#ff0000"
```

See Also

axlSpreadsheetGetRGBColorString

©2023 All Rights Reserved.

axlSpreadsheetGetRGBForNamedColor

```
axlSpreadsheetGetRGBForNamedColor(
     t_name
     )
     ==> t_rgb / nil
```

Description

Spreadsheets have a small set of known, pre-defined color values. To retrieve the RGB value for a specific named color, pass that color name to this function.

Arguments

`t_name`	Name of color to retrieve RGB value for.

Value Returned

`t_rgb`	String denoting RGB value for the color value passed in.
`nil`	Color name was not found in list of standard colors.

Example

The following example get the RGB string value associated with the predefined color name "cyan".

```
axlSpreadsheetGetRGBForNamedColor("cyan")
     ==> "#00FFFF"
```

See Also

axlSpreadsheetGetRGBColorString

©2023 All Rights Reserved.

axlSpreadsheetGetStyles

```
axlSpreadsheetGetStyles()
     ==> l_styles / nil
```

Description

Retrieves a list of all the styles defined for the active spreadsheet. If no worksheets currently exist, `nil` is returned.

Arguments

none

Value Returned

`l_styles`	List of style names and IDs as pairs (ID, name)).
`nil`	No worksheets current defined / no spreadsheet active.

EXAMPLES

The following example reads a spreadsheet into memory, then gets the list of defined styles for that spreadsheet.

```
axlSpreadsheetRead("example.xml")
     ==> t

axlSpreadsheetGetStyles()
     ==> (("Default" "DEFAULT") ("Title" "TITLE") ("Data" "DATA"))

axlSpreadsheetClose()
     ==> t
```

See Also

axlSpreadsheetSetWorksheet

©2023 All Rights Reserved.

axlSpreadsheetGetWorksheets

```
axlSpreadsheetGetWorksheets(
     )
     ==> l_worksheets / nil
```

Description

Retrieves a list of all the worksheets defined in the active spreadsheet. If no worksheets currently exists, `nil` is returned.

Arguments

none

Value Returned

`l_worksheets`	List of worksheet names (as ordered in the spreadsheet).
`nil`	No worksheets current defined / no spreadsheet active.

Example

The following example reads a spreadsheet into memory, then gets the list of defined worksheets in the file.

```
axlSpreadsheetRead("example.xml")
     ==> t

axlSpreadsheetGetWorksheets()
     ==> ("First" "Second")

axlSpreadsheetClose()
     ==> t
```

See Also

axlSpreadsheetSetWorksheet

©2023 All Rights Reserved.

axlSpreadsheetGetWorksheetSize

```
axlSpreadsheetGetWorksheetSize()
     ==> l_rowsColumns/nil
```

Description

Return the "size" of the current worksheet, in terms of the highest row and column which have data.

Arguments

none

Value Returned

`l_rowsColumns`	(maxRow, maxColumn).
`nil`	No worksheets current defined / no spreadsheet active.

Example

The following example reads a spreadsheet into memory, then gets the size of the workbook named "First" before closing the file.

```
axlSpreadsheetRead("example.xml")
     ==> t

axlSpreadsheetSetWorksheet("First")
     ==> t

axlSpreadsheetGetWorksheetSize()
     ==> (5 5)

axlSpreadsheetClose()
     ==> t
```

See Also

axlSpreadsheetSetWorksheet

©2023 All Rights Reserved.

axlSpreadsheetInit

```
axlSpreadsheetInit(
     )
     ==> t / nil
```

Description

Initializes an empty spreadsheet document to begin filling it with worksheets, styles, and cell data. A new spreadsheet, when first initialized, does not include any of this information. It is completely empty.

If there is a spreadsheet already active in memory, it will be closed. Only one spreadsheet may be active at a time.

Arguments

none

Value Returned

`t`	Spreadsheet successfully initialized.
`nil`	Unable to initialize empty spreadsheet. Reason printed to console.

Example

The following example creates a simple spreadsheet, adds information to the first cell ("Hello"), writes the spreadsheet, and closes it.

```
axlSpreadsheetInit()
     ==> t

axlSpreadsheetSetWorksheet("First")
     ==> t

axlSpreadsheetDefineCell(1 1 "Default" "String" "Hello")
     ==> t

axlSpreadsheetWrite("example.xml")
     ==> t

axlSpreadsheetClose()
     ==> t
```


©2023 All Rights Reserved.

See Also

axlSpreadsheetClose, axlSpreadsheetRead, axlSpreadsheetWrite

©2023 All Rights Reserved.

axlSpreadsheetRead

```
axlSpreadsheetRead(
     t_fileName
     )
     ==> t / nil
```

Description

Read a spreadsheet file on disk into memory for data access and manipulation. File is expected to be in Microsoft XML open spreadsheet format. For text-delimited files, use axlSpreadsheetReadDelimited.

Arguments

`t_fileName`	Name of spreadsheet file on disk to be read.

Value Returned

`t`	Spreadsheet successfully read; ready for querying.
`nil`	Unable to read spreadsheet file.

Example

The following example reads a spreadsheet into memory, after which it can be queried for cells' contents, and finally closed.

```
axlSpreadsheetRead("example.xml")
     ==> t
```

...

```
axlSpreadsheetGetCell(1 1)
```

...

```
axlSpreadsheetClose()
     ==> t
```


©2023 All Rights Reserved.

See Also

axlSpreadsheetClose, axlSpreadsheetInit, axlSpreadsheetWrite, axlSpreadsheetReadDelimited

©2023 All Rights Reserved.

axlSpreadsheetReadDelimited

```
axlSpreadsheetReadDelimited(t_fileName, t_delimiter)
     ==> t / nil
```

Description

Read a text file on disk into memory for data access and manipulation as a spreadsheet. File is expected to be a delimited text file, with cell delimiters as specified in the `t_delimiter` argument. For XML spreadsheets, use axlSpreadsheetRead.

Arguments

`t_fileName`	Name of text file on disk to be read.
`t_delimited`	Delimiter character used to separate "cells" in text file.

Value Returned

`t`	File successfully read; ready for querying.
`nil`	Unable to read spreadsheet file.

Example

The following example reads a csv file into memory, after which it can be queried for cells' contents, and finally closed.

```
axlSpreadsheetRead("example.txt", ",")
    ==> t
...
axlSpreadsheetGetCell(1 1)
...
axlSpreadsheetClose()
    ==> t
```

See Also

axlSpreadsheetRead

©2023 All Rights Reserved.

axlSpreadsheetSetCell

```
axlSpreadsheetSetCell(
     x_row
     x_col
     )
     ==> t / nil
```

Description

Make the active row/column of the current worksheet active.

Arguments

`x_row`	Row index (1-based) of cell to activate.
`x_col`	Column index (1-based) of cell to activate.

Value Returned

`t`	Cell successfully activated.
`nil`	Cell not activated. See console for reason.

Example

The following example sets the active cell to be cell 1,1 in the active worksheet.

```
axlSpreadsheetSetCell(1 1)
     ==> t

 **/

 /*INDENT ON*/

list axlSpreadsheetSetCell(list l_row, list l_col)

 {
     long status = SUCCESS;
     if(sgp_doc && sgp_worksheet)
     {
          int row = 0;
          int col = 0;
          row = ilGetInt(l_row);
          col = ilGetInt(l_col);

         if(row > 0 && col > 0)
```


©2023 All Rights Reserved.

```
        {
         excelCell* p_cell = excelCellFind(sgp_worksheet, row, col);
         if(!p_cell)
              {
                   p_cell = excelCellDefine(sgp_worksheet, row, col, "Default",
     "String", "");
              }
              if(p_cell)
              {
                   sgp_cell = p_cell;
              }
              else
              {
                   status = ICPEXCELMSG_SKILL_NOT_DEFINED_1;
                   icp_messagePrint(ICP_MESSAGE_CONSOLE, status, "cell");
              }
         }
         else
         {
              status =ICPEXCELMSG_SKILL_BAD_CELLPOS_2;
              icp_messagePrint(ICP_MESSAGE_CONSOLE, status, row, col);
         }
     }
     else
     {
          status = ICPEXCELMSG_SKILL_NOT_ACTIVE_1;
          icp_messagePrint(ICP_MESSAGE_CONSOLE, status, "worksheet");
     }
     return(SUCCESS == status ? ilcT : ilcNil);
     }

/*INDENT OFF*/

/*-

#ifdef DOC_C
```

See Also

axlSpreadsheetGetCell, axlSpreadsheetSetCellProp, axlSpreadsheetDefineCell

©2023 All Rights Reserved.

axlSpreadsheetSetCellProp

```
axlSpreadsheetSetCellProp(
     t_propName
     t_propVal
     )
     ==> t / nil
```

Description

Sets a property on the active cell in the spreadsheet.

Arguments

`t_propName`	Property to set. Allowable values are: STYLE, TYPE, FORMULA, or VALUE
`t_propVal`	Value to set this property to.

Value Returned

`t`	Cell property successfully set.
`nil`	Property not set (no active cell or invalid property). See console for further details.

Values supported for:

- STYLE – String value giving the ID of style already defined in active spreadsheet.
- TYPE – Number, DateTime, Boolean, String, or Error.
- FORMULA – Any string representing a properly-formatted spreadsheet formula for evaluation.
- Formulas are NOT VERIFIED by this interface for correctness.
- VALUE – Any string providing contents of the cell.

Example

Following example sets the contents of the active cell to the string "New Value".

©2023 All Rights Reserved.

```
axlSpreadsheetSetCell(1 1)
     ==> t

axlSpreadsheetSetCellProp("VALUE" "New Value")
     ==> t
```

See Also

axlSpreadsheetSetCell, axlSpreadsheetGetCell, axlSpreadsheetDefineCell

©2023 All Rights Reserved.

axlSpreadsheetSetColumnProp

```
axlSpreadsheetSetColumnProp(
     x_column
     t_propName
     t_propVal
     )
     ==> t / nil
```

Description

Sets a property for the given column of the active worksheet.

Arguments

`x_column`	Column index to set property for.
`t_propName`	Property to set. Allowable values are: `AUTO_WIDTH`, `WIDTH`, and `STYLE`.
`t_propVal`	Value to set this property to.

Values supported for:

- AUTO_WIDTH – Boolean value (0 or 1).
- WIDTH – Positive integer value in font points.
- STYLE – Style ID name currently defined in active document.

These statements, along with any others, are NOT evaluated by the SKILL API. They will be evaluated by the spreadsheet tool which opens the document. That tool may treat either the AUTO_WIDTH or the WIDTH tag as having priority of evaluation at its discretion, for instance. The SKILL API will NOT evaluate the AUTO_WIDTH or other instructions.

Value Returned

`t`	Property set on column.
`nil`	Property not set. Reason printed to console.

Example

The following example sets the AUTO_WIDTH attributed on column 1 of the active worksheet.

©2023 All Rights Reserved.

```
axlSpreadsheetSetRowProp(1 "AUTO_WIDTH" "1")
```

See Also

axlSpreadsheetSetRowProp

©2023 All Rights Reserved.

axlSpreadsheetSetDocProp

```
axlSpreadsheetSetDocProp(
     t_propName
     t_propVal
     )
     ==> t / nil
```

Description

Sets a property on the document (spreadsheet) itself.

Arguments

`t_propName`	Property to set. Allowable values are: AUTHOR, LAST_AUTHOR, DATE, COMPANY, or VERSION.
`t_propVal`	Value to set this property to.

Value Returned

`t`	Document property successfully set.
`nil`	Property not set (no active spreadsheet or invalid property). See console for further details.

Example

The following example sets the Author's name for this spreadsheet to be "John Doe".

```
axlSpreadsheetInit()
     ==> t

axlSpreadsheetSetDocProp("AUTHOR" "John")
     ==> t

axlSpreadsheetSetDocProp("AUTHOR" "Doe")
     ==> t

axlSpreadsheetWrite("example.xml")
     ==> t

axlSpreadsheetClose()
     ==> t
```


©2023 All Rights Reserved.

axlSpreadsheetSetRowProp

```
axlSpreadsheetSetRowProp(
     x_row
     t_propName
     t_propVal
     )
     ==> t / nil
```

Description

Sets a property for the given row of the active worksheet.

Arguments

`x_row`	Row index to set property for.
`t_propName`	Property to set. Allowable properties are, AUTO_HEIGHT, HEIGHT, and STYLE. Values supported for these properties are: AUTO_HEIGHT — Boolean value (0 or 1) HEIGHT — Positive integer value in font points STYLE — Style ID name currently defined in active document
`t_propVal`	Value to set this property to. AUTO_HEIGHT — Boolean value (0 or 1) HEIGHT — Positive integer value in font points STYLE — Style ID name currently defined in active document

These statements, along with any others, are NOT evaluated by the SKILL API. They will be evaluated by the spreadsheet tool which opens the document. That tool may treat either the AUTO_HEIGHT or the HEIGHT tag as having priority of evaluation at its discretion, for instance. The SKILL API will NOT evaluate the AUTO_HEIGHT or other instructions.

©2023 All Rights Reserved.

Value Returned

`t`	Property set on row.
`nil`	Property not set. Reason printed to console.

Example

The following example set the auto fit attributed on row 1 of the active worksheet.

```
axlSpreadsheetSetRowProp(1 "AUTO_HEIGHT" "1")
```

See Also

axlSpreadsheetSetColumnProp

©2023 All Rights Reserved.

axlSpreadsheetSetStyle

```
axlSpreadsheetSetStyle(
     t_id
     t_name
     )==> t / nil
```

Description

Defines or activates the specified style in the active spreadsheet. Styles may be referenced in any worksheet of the spreadsheet. You do not need to redefine the style for each new worksheet you create.

Arguments

`t_id`	The spreadsheet ID for this style.
`t_name`	The user "name" for this style / nil. This is the name that is displayed for this style in the Excel style editor and selection pull-down.

Value Returned

`t`	Style successfully activated / defined.
`nil`	Style not activated. Reason written to console.

Example

The following example activates the Default style in the active spreadsheet and sets its vertical alignment style to Top-justified.

```
axlSpreadsheetSetStyle("Default"  nil)
     ==> t

axlSpreadsheetSetStyleProp("Alignment" "Vertical" "Top")
     ==> t
```

See Also

axlSpreadsheetSetCell, axlSpreadsheetSetWorksheet

©2023 All Rights Reserved.

axlSpreadsheetSetStyleBorder

```
axlSpreadsheetSetStyleBorder(
     t_position
     t_color
     t_lineStyle
     t_weight
     )==> t / nil
```

Description

Sets the cell border properties for a active style definition.

Arguments

`t_position`	Position must be one of the accepted Microsoft positions (Left, Right, Top, Bottom, etc).
`t_color`	Microsoft color name or RGB value (for example, "BLACK" or #FF00AA).
`t_lineStyle`	Line style to use (normally "Continuous" for a solid line).
`t_weight`	The thickness of the line, in font points. Must be a positive integer.

Following table lists the values supported for different arguments.

Argument	Supported Values
POSITION	Left, Top, Right, Bottom, DiagonalLeft, or DiagonalRight
COLOR	RGB Value in format "#RRGGBB" or color name from pre-defined names table
LINE_STYLE	None, Continuous, Dash, Dot, DashDot, DashDotDot, SlashDashDot, or Double
WEIGHT	Positive integer value in font points

©2023 All Rights Reserved.

Value Returned

`t`	Border style successfully set.
`nil`	Border style not set (no active style or invalid parameters). See console for further details.

Example

The following example defines a new style, "Second", which inherits its settings from the "Default" style, but with a thin border defined.

```
axlSpreadsheetSetStyle("Second" "Second Style")
     ==> t

axlSpreadsheetSetStyleParent("Default")
     ==> t

axlSpreadsheetSetStyleBorder("Left"   nil "Continuous" "2")
     ==> t

axlSpreadsheetSetStyleBorder("Right"  nil "Continuous" "2")
     ==> t

axlSpreadsheetSetStyleBorder("Top"    nil "Continuous" "2")
     ==> t

axlSpreadsheetSetStyleBorder("Bottom" nil "Continuous" "2")
     ==> t
```

See Also

axlSpreadsheetSetStyle, axlSpreadsheetSetStyleProp, axlSpreadsheetSetStyleParent, axlSpreadsheetGetRGBColorString

©2023 All Rights Reserved.

axlSpreadsheetSetStyleParent

```
axlSpreadsheetSetStyleParent(
     t_parent)
     ==> t / nil
```

Description

Sets the active style's parent. Style will inherit default properties from its parent style, therefore only changes need to be specified in the child style. Parent must already be defined for spreadsheet.

Arguments

`t_parent`	Style ID of parent to link to. Note that the parent must already be defined before it can be referenced by children.

Value Returned

`t`	Style parent successfully set.
`nil`	Parent not set (no active style or parent style doesn't exist). See console for further details.

Note: PARENT value must be a style ID defined in the active spreadsheet document.

Example

The following example defines a new style, "Second", which inherits its settings from the "Default" style, but with text centered in the cell.

```
axlSpreadsheetSetStyle("Second" "Second Style")
     ==> t

axlSpreadsheetSetStyleParent("Default")
     ==> t

axlSpreadsheetSetStyleProp("Alignment" "Horizontal" "Center")
     ==> t
```

See Also

axlSpreadsheetSetStyle, axlSpreadsheetSetStyleBorder, axlSpreadsheetSetStyleProp

©2023 All Rights Reserved.

axlSpreadsheetSetStyleProp

```
axlSpreadsheetSetStyleProp(
     t_type
     t_propName
     t_propVal
     ) ==> t / nil
```

Description

Sets a specific style property in the active style definition.

Arguments

`t_type`	Type of property being set. Must be one of: ALIGNMENT, FONT, FILL, NUMBER_FORMAT, PROTECTION.
`t_propName`	Name of the property being set (varies by type).
`t_propVal`	Value to set the property to.

Value Returned

`t`	Style attribute successfully set.
`nil`	Attribute not set (no active style or invalid parameters). See console for further details.

ALIGNMENT properties and values supported are listed in the following table.

Property	**Values Supported...**
Horizontal	Automatic, Left, Center, Right, Fill, Justify, CenterAcrossSelection, JustifyDistributed, or Distributed.
Indent	Positive integer value in characters widths to indent.
`ReadingOrder`	RightToLeft, LeftToRight, or Context
`Rotate`	Rotation angle in degrees
`ShrinkToFit`	Boolean value (0 or 1).

©2023 All Rights Reserved.

Property	Values Supported...
`Vertical`	Automatic, Top, Bottom, Center, Justify, JustifyDistributed, or Distributed
`VerticalText`	Boolean value (0 or 1).
`WrapText`	Boolean value (0 or 1).

Table 27-1 FONT properties and values supported

Property	Values Supported...
Bold	Boolean value (0 or 1).
CharSet	Integer value
Color	RGB Value in format "#RRGGBB" or color name from pre-defined names table
Family	Automatic, Decorative, Modern, Roman, Swiss, or Script.
Italic	Boolean value (0 or 1).
Outline	Boolean value (0 or 1).
Shadow	Boolean value (0 or 1).
Size	Positive integer value in font size points..
StrikeThrough	Boolean value (0 or 1).
Underline	None, Single, Double, SingleAccounting, or DoubleAccounting.
VerticalAlign	None, Subscript, or SuperScript

Table 27-2 FILL properties and values supported

Property	Values Supported...
Color	RGB Value in format "#RRGGBB" or color name from pre-defined names table

©2023 All Rights Reserved.

Table 27-2 FILL properties and values supported

Property	Values Supported...
Pattern	None, Solid, Gray75, Gray50, Gray25, Gray125, Gray0625, HorzStripe, VertStripe, ReverseDiagStripe, DiagStripe, DiagCross, ThickDiagCross, ThinHorzStripe, ThinVertStripe, ThinReverseDiagStripe, ThinDiagStripe, ThinHorzCross, or ThinDiagCross.
PatternColor	RGB Value in format "#RRGGBB" or color name from pre-defined names table

Table 27-3 NUMBER_FORMAT properties and values supported

Property	Values Supported...
Format	String defining format of number in cell

Table 27-4 PROTECTION properties and values supported

Property	Values Supported...
Protected	Boolean value (0 or 1).
HideFormula	Boolean value (0 or 1).

Examples

The following example defines a new style, "Second", which inherits its settings from the "Default" style, but with text centered in the cell.

```
axlSpreadsheetSetStyle("Second" "Second Style")
     ==> t

axlSpreadsheetSetStyleParent("Default")
     ==> t

axlSpreadsheetSetStyleProp("Alignment" "Horizontal" "Center")
     ==> t
```


©2023 All Rights Reserved.

See Also

axlSpreadsheetSetStyle, axlSpreadsheetSetStyleBorder, axlSpreadsheetSetStyleParent, axlSpreadsheetGetRGBColorString

©2023 All Rights Reserved.

axlSpreadsheetSetWorksheet

```
axlSpreadsheetSetWorksheet(
     t_name)
     ==> t / nil
```

Description

Makes the specified worksheet the active one for future cell references. If the worksheet does not exist, it is created as the new last worksheet in the document.

Arguments

`t_name`	The name of the worksheet to activate.

Value Returned

`t`	Worksheet successfully activated / defined.
`nil`	Worksheet not activated. Reason written to console.

Examples

The following example activates the worksheet named "First" in the active spreadsheet, then sets the first column to have a width of 500.

```
axlSpreadsheetSetWorksheet("First")
    ==> t

axlSpreadsheetSetColumnProp(1 "Width" "500")
    ==> t
```

See Also

axlSpreadsheetSetCell, axlSpreadsheetSetStyle

©2023 All Rights Reserved.

axlSpreadsheetWrite

```
axlSpreadsheetWrite(
     t_fileName
     )==> t / nil
```

Description

Write the spreadsheet in memory to file on disk. File will be written compliant with Microsoft's open spreadsheet XML format.

Arguments

`t_fileName`	Name of file to be written to, including path if not to be written to current working directory.

Value Returned

`t`	File successfully written.

Examples

- The following example creates a simple spreadsheet, adds information to the first cell ("Hello"), writes the spreadsheet, and closes it.

```
axlSpreadsheetInit()
    ==> t
axlSpreadsheetSetWorksheet("First")
    ==> t
axlSpreadsheetDefineCell(1 1 "Default" "String" "Hello")
    ==> t
axlSpreadsheetWrite("example.xml")
    ==> t
axlSpreadsheetClose()
    ==> t
```

Note: Specifying file extension other than `*.xml` creates the file, but its format remains Microsoft's open spreadsheet XML.

©2023 All Rights Reserved.

Note:

See Also

axlSpreadsheetClose, axlSpreadsheetInit, axlSpreadsheetRead

©2023 All Rights Reserved.

©2023 All Rights Reserved.

28

Plugin Functions

Overview

This chapter describes the AXL-SKILL functions related to plugin APIs.

The axlDll family of APIs provides the ability to bind compiled DLL (shared library) packages into programs supporting the "axl" SKILL APIs. Any publicly exported functions from a DLL can be imported. The only restriction is that exported DLL functions must support the API specified below.

Any reference to 'DLL' is the equivalent to a shared library for UNIX and Linux programmers. All UNIX references apply to Linux.

Creating a plugin requires two components:

- SKILL code to import and wrap the functionality provided by the DLL.
- The DLL/shared library implementing the plugin functionality.

SKILL Programming

The SKILL programming model for plugins is:

- Locate and open a plugin via `axlDllOpen`. We suggest assigning a returned handle to a global SKILL symbol. On subsequent calls into your SKILL application, the symbol will be non-nil, so the call to `axlDllOpen` can be skipped. (See `axlDllOpen`.)
- Import the required symbols from the plugin via `axlDLLSym`. Like the handle returned by `axlDllOpen`, these handles should be assigned to global symbols.
- Use either `axlDllCall` or `axlDllCallList` to access the capability from the plugin.
- The I/O data types that are supported are documented in `axlDllCall`.

©2023 All Rights Reserved.

DLL Programming

DLL programming allows the use of external developers to utilize existing C/C++ code or develop new capabilities in C/C++ to plugin as extensions to SPB software. SPB software supporting this capability are those that incorporate the "axl" extension package to SKILL.

Implementation of a plugin DLL:

- On both Windows and Linux, all SPB applications are 64-bit applications, which means that any DLL (shared library on Linux) must be built as a 64-bit loadable library. If the DLL is built as a 32-bit library, it will not load successfully. On Windows you must build with the x64 architecture. It is also recommended to build with the release configuration on Windows, rather than the debug configuration. Also, in Visual Studio on Windows in the Project Properties, Linker section's Advanced tab, you must set the option Target Machine to MachineX64 (/MACHINE:X64 option).
- Obtain the compiler environment required by Cadence. (See the Allegro platform documentation.)
- Use the existing Cadence Makefile (UNIX) or Project file (Microsoft) which contains the required compile/link options. You can use these files to build your plugin to adapt your own software configuration environment. (See `<cdsroot>/share/pcb/examples/skill/plugin.`)
- Ensure that the exported DLL functions meet the API requirements. (See API plugin functions below). The include file, `<cdsroot>/share/pcb/include/axlplugin.h,` has the required structure definitions and defines.
- Build your plugin.
- Test it.

Required Cadence files for plugin programming:

```
<cdsroot>/share/pcb/include/axlplugin.h
```

API Plugin Functions

The C API for any plugin function is as follows:

```
long <function>(AXLPluginArgs *output, AXLPluginArgs *input)
```

The API takes identical structures for both its input and output arguments. The calling Cadence software updates the input structure with the data passed by the calling SKILL code. It also initializes the output structure.

©2023 All Rights Reserved.

The Plugin function must return a value and optionally update the output structure with return data (`argv` and `count`). The plugin return value is passed back to the calling SKILL code as follows:

`return == 0`	Returns a list of output data structure up to the count value. The length of the list is given by 'count'.If ‘count’ in output structure is 0, the returned list is empty.
`return != 0`	Return value is returned to SKILL as an integer.

AXLPluginArgs Input/Output Structure Members

`version = AXLPLUGIN_VERS_IN`	Version of input structure. If additional capability is added in the future, this version number will be bumped. It informs the plugin of the capability supported in the structure.
`flag = 0`	Future use
`maxEntries = AXLPLUGIN_MAX`	Can be ignored on input. On output, you cannot exceed this value for return arguments.
`count = <number of argv entries>`	Number of entries in `argv`. Basically, the number of arguments provided to the `axlDLLCall` APIs. Will never be more the `maxEntries`.
`argv[]`	Array of `AXLPluginEntry` arguments

AXLPluginEntry (argv) Structure Members

(See Input/Output Data Primitives.)

`type`	Indicates type of data
`data`	Union of primitive types supported

For the called DLL function to return data to calling SKILL code, both the `count` and `argv` entries should be set in the output data structure. For each `argv` entry returned, you should also set the data type to one of the primitives shown below. Under no situation should you attempt to return more then `maxEntries`.

If your exported DLL functions will be used outside your programming environment, then you should valid check the input arguments either in the SKILL wrapper or in your DLL function.

©2023 All Rights Reserved.

For example, if you expect a string argument and the calling SKILL code passes an integer, a program exception will occur if the data is not checked.

Input/Output Data Primitives

A set of I/O data primitives is supported. The `argv` entry of `AXLPluginArgs` is an array of these structures. Each array member has its data type indicated and the data itself. Both the input and output data use the `AXLPluginArgs` structure.

The data primitives that are supported are:

Type	SKILL type	C type	C struct member
AP_BOOL	t/nil	int	b_value
AP_LONG	x_value	long	l_value
AP_DOUBLE	f_value	double	d_value
AP_CONST_STRING	t_value/s_value	char *	cs_value
AP_STRING	t_value	char *	s_value (output only)
AP_XY	f_value:f_value	AXLXY	xy_value

`AP_STRING` types will not be seen on input. All strings passed from Allegro to the plugin are `AP_CONST_STRING`. To return a string, the plugin may use either `AP_CONST_STRING` or `AP_STRING`. If `AP_STRING` is used, then Allegro will free the memory associated with the string using the standard C "free" API, which means you must allocate it via `malloc`.

Other data type restrictions are:

- The plugin must not modify in place any input `AP_CONST_STRING`; corruption of SKILL will occur.
- To maintain `AP_CONST_STRING` input data across function calls, you should make a copy of them. SKILL may garbage collect the memory after your DLL function returns.
- If you use your own memory manager, do not use `AP_STRING` types for return. These require the use the standard `malloc` memory manager.
- Input arguments can be SKILL symbols (`'<symbol>`) but these are converted to `AP_CONST_STRING` types.
- The `STRING` types do not support wide character sets; use only characters in the ASCII character set.

©2023 All Rights Reserved.

- `AP_XY` represents a (x y) location and is implemented as a structure of two doubles.
- If `AP_BOOL` type is used, two defines are provided in `axlplugin.h`:
  - `AXLPLUGIN_TRUE  = 1`
  - `AXLPLUGIN_FALSE = 0`

Return value from plugin exported back to SKILL:

- If `output->count` is `0`, then the we look at the return value from the plugin function and return `x_value` to symbol.
- Else (non-zero count), we return this value to SKILL as a SKILL integer type.

Programming Restrictions, Cautions and Hints

- Cadence only supports the compiler listed in the SPB Platform documentation. Also required are any compiler and DLL linker options listed.
- If your DLL has dependencies upon other DLLs, make sure those do not conflict with DLLs used by Cadence. Typically, they need to be the same version and not built with debug options.

  To determine the DLLs used by Cadence use:

  - Windows: `depends` or `procexp` (`www.sysinternals.com`)
  - Linux: `ldd <program name>`
- On Windows, you can include UI components in your plugin. This capability is not supported on Linux.
- Wide character types are not supported in the plugin to the Allegro interface.
- On Linux, if threading is used, then you should use `POSIX` threads (`pthreads`).
- STL programming should use the default STL provided by the Cadence required compiler. Do not use a third party STL.
- On Windows, if DLL is MFC based, then do not compile it debug. MFC Classes change in size if code is built debug and are not compatible with non-debug MFC code. There are methods described on the Web on how to build MFC debuggable without requiring the MFC debug shared library. Typically on Windows, Debug DLLs are not compatible with non-Debug DLLs. Also many different versions of MFC exist which are incompatible with one another. Use one of the binary query tools (see above) to determine the version of MFC currently required by Cadence.

©2023 All Rights Reserved.

- There are currently no methods to make function calls back to Allegro from the plugin.
- Your DLL can be used across multiple Cadence releases without recompiling your plugin. Re-compiling is only required if Cadence changes the compiler in the release.
- Programming errors in your plugin can crash the host program. In rare cases, these bugs can corrupt an Allegro database. (See customer support below.)
- On Windows, to access `stdout/stderr`, set the `TELCONSOLE=1` as the OS level. This variable cannot be set via Allegro's `env` file. This is also considered a debug environment, so it should not be used during board design.

Performance Considerations

The following issues should be considered if high performance is required:

- Locating and loading a plugin. This should be done once per activation. Assign the handle return by `axlDllOpen` to a global symbol to prevent SKILL garbage collection. Do not close the plugin.
- Import symbols of a plugin once. The `axlDll` interface internally caches symbol import so subsequent lookups will be faster than the initial call.
- A plugin function should do meaningful work since there is some overhead converting input data from SKILL to native C types and doing the opposite for return data.

Cadence Customer Support

Cadence does not provide support for debugging customer-developed plugins.

An environment variable, *`allegro_noextension_plugin`*, is available to disable plugin capability. If Allegro starts crashing or databases become corrupt, you should set this variable to determine if a plugin is the cause.

Examples

An example containing SKILL, the plugin C code, Gnu Makefile (Linux) and project file (Visual Studio) is contained at `<cdsroot>/share/pcb/examples/plugin`. In addition, a pre-built plugin module is contained in the Cadence install hierarchy so you do not need to compile and link the plugin source code to run the SKILL code.

The example plugin provided has three exported symbols:

- An echo API, which returns as output any input given.

©2023 All Rights Reserved.

- A `x_value` API, which returns the number of input arguments.
- A distance implementation to calculate the distance between two points.

©2023 All Rights Reserved.

axlDllCall

```
axlDllCall(
          o_pluginFunc
          [g_arg1]
          ...
          [g_arg10]
) -> nil/x_value/lg_data
```

Description

This function calls a symbol that has been imported from a plugin. As the first argument, it requires `o_pluginFunc,` which was returned via a call to `axlDllSym`. The rest of the arguments are what the implement plugin API has defined.

The return from the call is one of the following:

- `nil`: error processing data
- `x_value`: plugin function returned a non-zero result
- `lg_data`: plugin function returned a zero and its output values are returned in a list

In turn it calls the import function from the plugin.

Arguments

`o_pluginFunc`	plugin symbol handle
`[g_arg1..10]`	up to 10 arguments

Value Returned

`nil`	Error in processing arguments or funding functions.
`x_value`	If plugin function returns a non-zero, then this is what is returned.
`lg_data`	If plugin function returns zero, then its output arguments are processed and returned as a list. If the output argument list from the plugin has 0 entries, then an empty list is returned.

©2023 All Rights Reserved.

See Also

axlDllOpen

Example

Example carried from axlDllSym

```
axlDllCall(_ashDistance 10:0 25.1:0) -> 15.1
```


©2023 All Rights Reserved.

axlDllCallList

```
axlDllCallList(
          o_pluginFunc
          l_args/nil
     ) -> nil/x_value/lg_data
```

Description

This function is identical to `axlDllCall` except it takes a list of arguments to pass to the plugin function. Unlike `axlDllCall`, which is limited to 10 arguments, this interface can take up to 512 arguments.

See `axlDllCall` for a further explanation.

Arguments

`o_pluginFunc`	Plugin symbol handle
`l_args`	A list of up to 512 arguments

Value Returned

`nil`	Error in processing arguments or funding functions.
`x_value`	If plugin function returns a non-zero, then this is what is returned.
`lg_data`	If plugin function returns zero, then its output arguments are processed and returned as a list. If the output argument list from the plugin has 0 entries, then an empty list is returned.

See Also

`axlDllCall`, `axlDllOpen`

Example

From `axlDllOpen` example

```
_ashEcho = axlDllSym(_ashTestDll "ashEcho")
axlDllCallList(_ashEcho list(-1 -2.0 nil "another string"
          -10.1:-2 0.2))
```


©2023 All Rights Reserved.

axlDllClose

```
axlDllClose(
     o_plugin
     )
     ==> t/nil
```

Description

This closes an open plugin handle. Once a handle is closed, you can no longer call functions obtained from the plugin. Also, a plugin is automatically closed when there are no active references to it via SKILL's garbage collection.

It is not advisable to close a plugin due to performance considerations.

Arguments

`o_plugin`	Plugin handle obtained from `axlDllOpen`.

Value Returned

`t` if successful to close, `nil` if handle is not a legal handle

See Also

`axlDllOpen`

Example

See example referenced by `axlDllOpen`.

©2023 All Rights Reserved.

axlDllDump

```
axlDllDump(
     )
     ==> l_dllLoad/nil
```

Description

This is a debug function that reports all plugins loaded by SKILL.

Arguments

None

Value Returned

List of plugin handles or `nil` if no loaded plugins.

See Also

axlDllOpen

Example

```
axlDllDump()
```


©2023 All Rights Reserved.

axlDllOpen

```
axlDllOpen(
     t_dllname
     )
     ==> o_plugin/nil
```

Description

This binds a DLL/shared library to the current program. While this can load any DLL, only those built to be compatible with the axl Plugin model can be utilized via SKILL (see DLL Programming on page 1662 for information on building compatible DLLs).

If the DLL name does not have a directory path component, then *AXLPLUGINPATH* environment variable is used to search for the DLL.

After a DLL is successfully loaded, you need to import one or more symbols (`axlDllSym`).

Plugin Attributes

Name	Type	Description
name	string	Name of plugin file (DLL name)
functions	l_dbid	Disembodied property list name/value pairs of imported symbols (`t_name o_pluginFunc`)
objType	string	"plugin"

Note: To access imported plugin function types do a

```
<o_plugin>->functions-><pluginFuncName>
```

Arguments

`t_dllname` Name of DLL. For platform independence, it is strongly suggested that you do not include the file extension or a directory path component.

Value Returned

`o_plugin`

`nil` Can't locate library or not a DLL.

©2023 All Rights Reserved.

See Also

DLL Programming on page 1662, axlDllSym, axlDllCall, axlDllCallList axlDllClose, axlDllDump

Example

Open Cadence test DLL

```
_ashTestDll = axlDllOpen("axlecho_plugin")
```


©2023 All Rights Reserved.

axlDllSym

```
axlDllSym(
     o_plugin
     t_symbolName
     )
     ==> o_pluginFunc/nil
```

Description

This imports a symbol from a loaded dll. A dll can have one or more exported symbols. The symbol must have been exported from the dll when the dll was compiled and linked (See `axlDllDoc`).

PluginFunc Attributes

Name	Type	Description
name	string	Name of imported symbol file
functions	nil	Always `nil`
objType	string	"pluginFunc"

Arguments

`o_plugin` dll handle from `axlDllOpen`

`t_symbolName` Name of an exported function within the dll

Value Returned

`o_pluginFunc` Symbol handle

`nil` Error; symbol not present in dll.

See Also

`axlDllOpen`

©2023 All Rights Reserved.

Example

Load the distance symbol from the axl plugin test dll

```
_ashDistance = axlDllSym(_ashTestDll "ashDistance")
```


©2023 All Rights Reserved.

29

Skill Language Extensions

axldo

```
axldo(
     g_initList
     g_terminateList
     [g_body]
     ) -> g_result


axldoStar(
     g_initList
     g_terminateList
     [g_body]
     ) -> g_result
```

Description

A do function, modeled after the CL (Common Lisp) do.

```
Public:

        (defmacro do ((var [init [step]]) ...) (end-test result result ...) @body)

         (defmacro doStar ((var [init [step]]) ...) (end-test result result ...)
```

The do macro provides a generalized iteration facility, with an arbitrary number of *index variables*. These variables are bound within the iteration and stepped in specified ways. They may be used both to generate successive values of interest or to accumulate results. When an end condition is met (as specified by end-test), the iteration terminates, the result sexps are successive evaluated, and the value of the last result sexp is returned.

The first item in the form is a list of 0 or more index-variable specifiers. Each index-variable specifier is a list of the name of the variable, `var`; an initial value, `init`; and a stepping form, `step`.

If `init` is omitted, it defaults to nil. If `step` is omitted, the `var` is not changed by the do construct between repetitions (though code within the do is free to alter the value of the variable by using `setq`).

©2023 All Rights Reserved.

An index-variable specified can also be just the name of a variable. In this case, the variable has an initial value of nil and is not changed between repetitions. This would be used much as a locally scoped variable in a let statement would be.

Before the first iteration, all the init forms are evaluated, and each var is bound to the value of its respective init. Because this is a binding, and not an assignment, when the loop terminates the old values of the variables is restored. All of the init forms are evaluated before any var is bound; hence all the init forms may refer to the old bindins of all the variables (that is, to the values visible BEFORE beginning execution of the do).

Note: All init bindings are done in parallel for `axldo`, and serially for `axldoStar`.

The second element of the loop is a list of an end-testing predicate form end-test, and zero or more result forms. This resembles a 'cond' clause. At the beginning of each iteration, after processing the variables, the end-test is evaluated. If the result is nil, execution proceeds with the body of the form. If the result is non-nil, the result forms are evaluated in order as an implicit 'progn', and then the do returns the value of the last evaluated result.

At the beginning of each iteration, the index variables are updated as follows.

➡ All the step forms are evaluated, from left to right, and the resulting values are assigned to the respective index variables. Any variable that has no step value is not assigned.

Arguments

`g_initList`	0 or more index variable specifiers
`g_termiateList`	end test predicate
`g_body`	body of procedure

Value Returned

Value resulting from evaluating last result sexp.

See Also

letStar

©2023 All Rights Reserved.

copyDeep

```
copyDeep(
                l_object
        ) -> l_newObject
```

Description

This function recursively copy a list.

The copy function makes a new list containing copies of all top level elements in the source list. But each new element contains references to the same sublist elements as the source list. Thus, if sublist items are modified in the source list they are also modified in the copy, and vice-versa. The copyDeep function makes a complete copy of the list, top to bottom. So changes in one list do not affect the other. This allocates more memory, of course.

Arguments

`l_object`	The list to be copied

Value Returned

A new list identical to the original but sharing no memory.

©2023 All Rights Reserved.

isBoxp

```
isBoxp(
                g_bBox
        )
        ==> t/nil
```

Description

Checks argument to see if it is a valid bounding box. A valid bounding box should be of the form of `((a b) (c d))` where `a`, `b`, `c`, and `d` are all numbers and `a!= c` and `b!= d`, to ensure that the bounding box encloses some area.

Arguments

`g_bBox`	input argument to be tested.

Value Returned

`t`: If g_bBox is a valid bounding box.

`nil`: If g_bBox is not a valid bounding box.

©2023 All Rights Reserved.

lastelem

```
lastelem(
          l_list
        ) -> g_elem
```

Description

The `last()` function returns the last LIST object in a list, but `lastelem()` takes the car of that to get the last ATOM.

Arguments

`l_list`	a list

Value Returned

The last atom element of a list.

Example

```
l = list(1 2 3)
last(l) -> (3)
lastelem(l) -> 3
```


©2023 All Rights Reserved.

letStar

```
letStar(
          l_bindings
          [@body]
        ) -> g_lastValue
```

Description

This is a let* implementation of CL (Common Lisp).This is a procedure function.

Arguments

`l_bindings`	list of l_varbind `l_varbind` is (<name> <value>) ■ `name:` interned as lexically-scoped symbol ■ `value:` evaluated to arrive at value
`@body`	one or more expressions to be evaluated.

Value Returned

last value of `@body`

See Also

axldo

©2023 All Rights Reserved.

listnindex

```
listnindex(
     l_theList
     g_item
     ) -> x_found/nil
```

Description

Finds the position of an item in a list. Works just like `nindex`, but finds the position of an element in a list instead of a character in a string. An integer denoting the sequence number of the first matching element is determined.

Arguments

`l_theList`	A list containing the element to be found
`g_item`	The element to be found

Value Returned

The position in the list where the element was first found, or `nil` if it is not found.

Note: x_found is 0 based so you use other SKILL functions like nth

Example

```
listnindex( '("three" "dog" 'night) "dog") -> 1
```


©2023 All Rights Reserved.

movedown

```
movedown(
          g_elem
          l_list
        ) --> l_newlist
```

Description

Find all occurrences of element within a list and moves them one item closer to the list tail. No action for other items and the last element of the list.

This destructively modifies the list.

Arguments

`g_elem`	The element to be moved, matched using (equal)
`l_list`	The list containing the element to be moved.

Value Returned

The modified list.

©2023 All Rights Reserved.

moveup

```
moveup(
          g_elem
          l_list
        ) --> l_newlist
```

Description

Moves an element one item closer to the head of a list. Finds all occurrences of the element within a list and moves them one item closer to the list head. No action for other items and the first element of the list.

This destructively modifies the list.

Arguments

`g_elem`	The element to be moved, matched using (equal)
`l_list`	The list containing the element to be moved.

Value Returned

The modified list.

©2023 All Rights Reserved.

parseFile

```
parseFile (
          t_fileName
          s_handler
          [t_breakChars]
         )
         ==> g_result
```

Description

Parse all lines of a file. Opens input file and reads it line by line. Each line is parsed using `parseQuotedString`. The result of parseQuotedString is passed to the application defined handler `s_handler`. The handler defines the return value.

©2023 All Rights Reserved.

Arguments

`t_fileName` Name of file to be read.

`s_handler` Application callback function to process parsed arguments

```
s_handler (
l_curLineInfo
l_lineArgs
g_result
)
==> g_result
```

`l_curLineInfo` List of info which describes the current line being processed.

Defined as:

`(t_fileName g_lineNo t_curString)`

- `t_fileName:` Name of file being read
- `g_lineNo:` Current line number
- `t_curString:` Unparsed file line

`l_lineArgs` List of strings that result from parsing the line.

`g_result` The application callback result. This is continually passed to s_handler so that a result can be built up from the processing of all file lines. This will be nil the first time and will be whatever s_handler last returned for subsequent calls.

`t_breakChars` Optional string containing characters that are used as break characters. The default is `"'\" "` (quote chars and space char).

Value Returned

`g_result` The application callback result from the last call to `s_handler`.

©2023 All Rights Reserved.

parseQuotedString

```
parseQuotedString(
                 t_string
                 [t_breakCharacters]
                )
                ==> l_strings
```

Description

Breaks a string into a list of words. Multiple words enclosed within quotation marks are treated as single words.

Arguments

`t_string`	String to be parsed.
`t_breakCharacters`	Optional string containing characters to be used as break characters. The default is `"'\"  "` (quote chars and space char).

Value Returned

`l_strings`	A list of strings parsed from the `t_string` argument.

Note: A word break is not created at the start of a quote unless the quote character is a break character.

Examples

- `parseQuotedString( "111 222'333 444'"  "  ")` => ("111" "222333 444")
- `parseQuotedString( "111 222'333 444'"  "'  ")` => ("111" "222" "333 444")

©2023 All Rights Reserved.

pprintln

```
pprint(
            g_item
            [p_port]
        ) -> t/nil
```

Description

Prints a newline character at the end of the line.

Arguments

`g_item`	The item to be printed.
`p_port`	The optional parameter that specifies the port to write to. Default value is stdout.

Value Returned

Returns item pretty printed plus a newline character.

©2023 All Rights Reserved.

propNames

```
propNames(
           g_propList
        ) -> lS_names/nil
```

Description

Use this command to get the names of properties in a disembodied property list. Walk each property in disembodied property list, building a list of the names of each property.

Note: Order of returned property names is unspecified.

Arguments

`g_propList`	A disembodied property list.

Value Returned

`lS_names`	A list of symbols corresponding to the names of each property found in the list.

Example

```
n = ncons(nil)
n->one = 1
n->two = 2
propNames(n) -> (one two)
```


©2023 All Rights Reserved.

30

Logic Access Functions

Overview

This chapter describes the AXL-SKILL functions related to schematic capture or the logical definition of the design.

©2023 All Rights Reserved.

axlDBAssignNet

```
axlDBAssignNet(
     o_object/lo_object
     o_net/t_net
     [g_ripup]
     )
     ⇒ t/nil
```

Description

Assigns an object or a list of objects to a new net. Supports pins, vias, and shapes. Vias may not stay on net assigned if they do not connect to an object on the new net. This is not applicable if the new net has RETAIN_NET_ON_VIAS property.

©2023 All Rights Reserved.

Arguments

o_object	*dbid*, or list of *dbids* of objects to change net.
o_net	*dbid* of destination net, or `nil` if assigning to a dummy net.
t_net	Net name can be used as an alternative to a dbid net.
g_ripup	An optional flag to ripup clines and vias connected to modified objects. possible values are: `t` = ripup clines connected to modified objects. `nil` = do not ripup clines connected to modified objects. The default is `nil`.
g_ignoreFixed	By default, won't allow net assignment if FIXED property is present on the object(s) in question. Setting this argument to *t* ignores the FIXED property. If `g_ripup` is `t`, and connected clines have the FIXED property then the clines will remain and an error message thrown.

Value Returned

`t`	At least one object changed net.
`nil`	No object changed net.

See Also

axlDBCreateNet, axlDBIgnoreFixed

Example:

- Simple re-assignment

```
pin_id->net->name => ""
net_id->name => "GND"

axlDBAssignNet(pin_id net_id t)=> t
pin_id->net->name => "GND"
```

- Interactive exploration; use the ashOne shareware provided in examples area of cdsroot.

©2023 All Rights Reserved.

```
;select an object
item = ashOne()
new net
net = "net1"

axlDBAssignNet(item net t t)
```


©2023 All Rights Reserved.

axlDBCreateConceptComponent

```
axlDBCreateConceptComponent(
     s_refdes
     s_partPath
     s_logName
     s_primName
     [s_pptRowName]

)

⇒ r_dbid/nil
```

Description

Given the Concept information needed to describe an Allegro PCB Editor device, create the Allegro PCB Editor component and return its *dbid*. If the component definition already exists, use the existing definition to create the new component. If the component definition does not exist, create a new definition and then create the component instance. Concept information comes from a `chips_prt` file and from a physical parts table (PPT). Determine the location of this information using the `cptList`*XXX* family of routines, which allow browsing through a Concept library.

©2023 All Rights Reserved.

Arguments

s_refDes	Reference designator for the new component.
s_partPath	Full path to the `chips_ptr` file containing the description of the desired logical part. Determine using the `cptListComponentLibraries` function.
s_logName	Name of the desired logical part. You can determine this using the `cptListComponentPrimitives` function.
s_primName	Name of the desired primitive. You can determine this using the `cptListComponentPrimitives` function.
s_pptRowName	Name of the desired PPT part. Concept data may not include specific device information which would be contained in a PPT. Indicates a specific row in a PPT from which to create the component. You can determine this using the `cptListComponentDevices()` function.

Value Returned

r_dbid	*dbid* of the new Allegro PCB Editor component instance.
`nil`	Unable to create component instance.

Note: The actual name of the resulting Allegro PCB Editor device is generated automatically. If using the `cptListComponentDevices()` function, then the name should have been created already and is included in the return values of that function. Name is determined by the Concept library data you use to create the part.

This function is meant to be called from SKILL.

©2023 All Rights Reserved.

axlDBCreateComponent

```
axlDBCreateComponent(
     s_refDes
     s_deviceName
     [s_package]
     [s_value]
     [s_tolerance]
     )
     ==> r_dbid/nil
```

Description

Given the information needed to describe a Allegro PCB Editor device, create the Allegro PCB Editor component and return its `dbid`. If the component definition already exists, use the existing definition to create the new component. If the component definition does not exist, create a new definition using the device file and create the new component.

Arguments

s_refDes	The reference designator for the new component.
s_deviceName	Name of Allegro PCB Editor device file.
s_package	Package name to be used for the component. This overrides the value found in the device file (can be nil).
s_value	"Value" attribute value. This will override the value found in the device file (can be nil).
s_tolerance	"Tolerance" attribute value. This will override the value found in the device file (can be nil).

Value Returned

r_dbid	`dbid` of new Allegro PCB Editor component.
`nil`	If unable to create component.

Note: If you change an existing component definition by specifying a new value for package, value, or tolerance, you need a device file.

©2023 All Rights Reserved.

Example

Create a new empty comp from an existing one, ashOne can be found at:

```
<cdsroot>/share/pcb/examples/skill/examples/ash-fxf/ashone.il
syminst = ashOne()
ci = syminst->component
nci = axlDBCreateComponent("C1_NEW" ci->deviceType ci->package
ci->compdef->prop->VALUE ci->compdef->prop->TOL)
```

If your component is not a discrete component, you do not need the fourth and fifth arguments, but the above example will work for all components.

See Also

axlComponentChangeClass

©2023 All Rights Reserved.

axlDBCreateManyModuleInstances

```
axlDBCreateManyModuleInstances(
            t_name
            t_moddefName
            x_tileStartNum
            l_origin
            l_offset
            x_num_tiles
            f_rotation
            x_logicMethod
            [l_netExcept]
              [g_mirror]
)
         ==> o_result/nil
```

Description

Creates multiple module instances in the design. By reducing the number of times the module definition file opens, this function optimizes performance when creating several instances of the same module.

©2023 All Rights Reserved.

Arguments

t_name	Prefix of the names of the module instances.
t_moddefName	Name of the module definition/
x_tileStartNum	Tile numbering start number and increment by 1 for each tile.
l_origin	First location of first module.
l_offset	List containing the offset wanted between module origins.
x_numTiles	The number of module instances to be place.
f_rotation	Angle of rotation for the module instance.
x_logicMethod	Flag to indicate where the logic for the module comes from. ■ 0: No logic. ■ 1: Logic from schematic. ■ 2: Logic from module definition.
l_netExcept	Optional list of net names to add to the net exception list.
g_mirror	Optional if modules should be mirrored

Value Returned

lo_result	If successful, returns the list of database objects that belong to the module instances created.
nil	Creation of module instance could not be completed.

See Also

axlDBCreateModuleDef, axlDBCreateModuleInstance

Example

Add five module instances based on the module definition file mod.mdd, starting at point (10,10) and offsetting by (5,0) every time:

```
modinsts = axlDBCreateManyModuleInstances(
"Num" "mod" 2 10:10 '(5 0) 5 0 2 '("GND" "+5"))
```

Creates five module instances named Num2, Num3, Num4, Num5, Num6.

©2023 All Rights Reserved.

©2023 All Rights Reserved.

axlDBCreateModuleDef

```
axlDBCreateModuleDef(
     t_name
     l_origin
     l_objects
)
⇒ t/nil
```

Description

Creates a module based on existing database objects.

Arguments

t_name	String providing the name of the module definition. File name is the module definition name appended with `.mdd`.
l_origin	Coordinate serving as the origin of the module definition.
l_objects	List of objects to add to the module.

Value Returned

`t`	Module definition successfully created.
`nil`	No module definition created.

Example

```
axlSetFindFilter(?enabled '("noall" "components") ?onButtons '("noall"
    "components"))
axlSingleSelectName("COMPONENT" "U1")
comp1 = car(axlGetSelSet())
axlSingleSelectName("COMPONENT" "U2")
comp2 = car(axlGetSelSet())
axlDBCreateModuleDef("comps" '(0 0) '(comp1 comp2))
⇒ A module definition file named comps.mdd is created.
```

Creates a module definition file containing two components.

©2023 All Rights Reserved.

axlDBCreateModuleInstance

```
axlDBCreateModuleInstance(
     t_name
     t_moddef_name
     l_origin
     r_rotation
     i_logic_method
     l_net_except
)
⇒ o_result/nil
```

Description

Allows you to use or place a previously defined module.

Arguments

t_name	String providing name of the module instance.
t_moddef_name	String providing name of the module definition to base the instance on.
l_origin	Coordinate location to place the origin of the module definition.
r_rotation	Angle of rotation for the module instance.
i_logic_method	Flag indicating where the logic for the module comes from: 0 - no logic 1 - logic from schematic 2 - logic from module definition.
l_net_except	Optional list of net names to add to net exception list.

©2023 All Rights Reserved.

Value Returned

o_result	Database object that is the group used to represent the module instance.
nil	Module instance not created.

Example

```
modinst = axlDBCreateModuleInstance("inst" "mod" '(500 1500) 2 '("GND" "+5"))
```

Adds a module instance based on the module definition file `mod.mdd`.

©2023 All Rights Reserved.

axlDBCreateNet

```
axlDBCreateNet(
     t_netName
     )
     ==> o_dbid/nil
```

Description

Creates a net in database if does not exist or returns `dbid` of net if it exists.

Arguments

`t_netName`	Net name to create, or find.

Value Returned

`nil` if not created, or a axl `dbid` of net

See Also

axlDBAssignNet

Example

```
net = axlDBNetCreate("gnd")
    => dbid:123456
net->name
    => "GND"
```


©2023 All Rights Reserved.

axlDBCreateSymDefSkeleton

```
axlDBCreateSymDefSkeleton(
     l_symbolData
     l_extents
     [l_pinData]
     )
     ==> axlDBID/nil
```

Description

Creates a “minimal” symbol definition. While the symbol name and type must be provided, the instance is created only with pins. Once this “skeleton” definition has been created, you add the rest of the symbol geometry with additional `axlDBCreate` calls. This provides the ability to create symbols that do not exist in the library.

Shape symbol:

- You may only attach a single shape to a shape symbol, no voids.
- Layer required is “ETCH/TOP”.
- Extents should be larger than the shape but there is no adverse impact if they are significantly larger.

Flash symbol:

- You may attach multiple shapes, but none may contain voids.
- Layer required is “ETCH/TOP”.
- Extents should be larger than the shape but there is no adverse impact if they are significantly larger.

©2023 All Rights Reserved.

Arguments

l_symbolData	A list of (`t_symbolName [t_symbolType]`).
	t_symbolName: Name of the symbol.
	t_symbolType: Package (default), mechanical, or format.
l_extents	The lower left and upper right corners of the symbol def extents.
l_pinData	List of `axlPinData` defstructs for the pins.

Value Returned

`axlDBCreateSymDefSkeleton`	`nil` if not created, or `axlDBID` of the symbol definition.

Examples

```
symdef = axlDBCreateSymDefSkeleton('("shape_pad" "shape") list(-100:-100 100:100))
p = axlPathStart( list(-4:10 4:10 8:0 4:-10 -4:-10 -4:10))
s = axlDBCreateShape(p t "ETCH/TOP" nil symdef)
```

Creates a shape symbol.

```
symdef = axlDBCreateSymDefSkeleton('("flash_pad" "flash") list(-100:-100 100:100))
p = axlPathStart( list(-4:10 4:10 8:0 4:-10 -4:-10 -4:10))
ps = axlPathStart( list(-4:10 4:10 4:-10 -4:-10 -4:10))
s = axlDBCreateShape(p t "ETCH/TOP" nil symdef)
s = axlDBCreateShape(ps t "ETCH/TOP" nil symdef)
```

Creates a flash symbol.

©2023 All Rights Reserved.

axlDBDummyNet

```
axlDBDummyNet (
     g_mode)
     -> lo_dbid/nil
```

Description

This command returns all dummy nets in design. Two courtesy options provided are:

- `'pin` for any dummy net that has a pin return the first pin of the dummy net
- `'shape` for any dummy net that has a shape return the first shape of the dummy net

Typically each dummy net in design will only have a single pin or shape but this may not always be the case. Clines or vias cannot, by themselves exist on a dummy. Symbols (`dra`) do not have dummy nets

Arguments

`g_mode`	Can have following two values: ■ `'pin` – returns a list of first pins on dummy nets ■ `'shape` – returns list of first shapes on dummy nets

Value Returned

- `t` - indicates success
- `nil` - failed due to incorrect arguments

See Also

axlIsDummyNet, axlDbidName

Examples

1. Print all 1st pins on dummy nets

```
foreach( mapc x axlDBDummyNet('pin) printf("%s\n" axlDbidName(x)))
```


©2023 All Rights Reserved.

2. Get all dummy nets on design

```
p = axlDBDummyNet(nil)
```


©2023 All Rights Reserved.

axlDbidName

```
axlDbidName(
                 o_dbid
        ) -> t_name/nil
```

Description

Returns the standard Allegro PCB Editor name of a database object. Many of the named Allegro PCB Editor objects (for example, nets) have their names defined in the name attribute (for example, `dbid->name`) but other objects (for example, clines and pins) either do not have the desired reporting name or are unnamed.

Arguments

o_dbid	An Allegro PCB Editor database id.

Note: Some Allegro PCB Editor database ids are pseudo ids (for example, `axlDBGetDesign()` and pads) and generate a `nil` return.

Value Returned

Allegro PCB Editor name of object, or `nil` if not a `dbid` and not a true Allegro PCB Editor database object.

Note: The return value is printed for display purposes and should not be used to connect to the database objects.

Examples

This uses the ashOne selection function found at:

```
<cdsroot>/share/pcb/examples/skill/examples/ash-fxf/ashone.il
```

Pin name:

```
pin = ashOne()
axlDbidName(pin)
-> "U1.1"
```

Cline name:

```
cline = ashOne()
```


©2023 All Rights Reserved.

```
axlDbidName(cline)
-> "Net3, Etch/Top"
```


©2023 All Rights Reserved.

axlDiffPair

- Add DiffPair

```
axlDiffPair(
     t_diffpair
     o_net1/t_net1
     o_net2/t_net2

)
```

⇒ *o_diffpair*/nil

- Modify DiffPair

```
axlDiffPair(
     o_diffpair/t_diffpair
     o_net1/t_net1
     o_net2/t_net2

)
```

⇒ *o_diffpair*/nil

- Delete DiffPair

```
axlDiffPair(
     o_diffpair/t_diffpair/lo_diffpair

)
```

⇒ t/nil

Description

Creates, modifies, or deletes a differential pair. In all cases you can pass names or a *dbid*.

Note: If the differential pair was created due to Signoise models, you cannot modify or delete it. Consequently, you cannot modify or delete the differential pair if the following is true:

```
diffpair_dbid->prop->DIFFP_ELECTRICAL == t.
```

You cannot create a differential pair if two nets belong to the same XNet.

©2023 All Rights Reserved.

Arguments

o_diffpair	Differential pair *dbid*
lo_diffpair	List of differential pair dbids (delete mode only)
t_diffpair	Differential pair name (string)
o_net1/o_net2	Net *dbid*.
t_net1/t_net2	Net name (string)
g_mode	Add to testpoint to top or bottom or clear one

Value Returned

Values returned depend on whether adding, modifying, or deleting.

o_diffpair	*dbid* of new or modified differential pair
t	Delete was successful
nil	Error due to incorrect arguments.

Example 1

```
dbid = axlDiffPair("DP" "NET1+" "NET2-")
```

Creates a differential pair and names it DP1.

Example 2

```
dbid = axlDiffPair(dbid "NET1+" "NET1-")
```

Modifies a differential pair.

Example 3

```
axlDiffPair(dbid)
```

Deletes a differential pair.

Example 4

```
axlDiffPair(axlDBGetDesign()->diffpair)
```

Delete all differential pairs in design.

©2023 All Rights Reserved.

axlDiffPairAuto

```
axlDiffPairAuto(
     t_diffPairPrefix
     t_posNetSuffix
     t_negNetSuffix
     [g_returnDiffPairList]

)

⇒ x_cnt/(xcnt lo_diffpair)/nil
```

Description

Allows automatic generation of the differential pair. Generates the set of differential pairs based on the provided positive (*t_posNetSuffix*) and negative (*t_negNetSuffix*) suffixes used in your net naming scheme.

You may optionally provide a prefix (*t_diffPairPrefix*) used in generating the differential pair names of the form: <*t_diffPairPrefix*> + *netname* - *suffix*.

If nets are part of busses and end the bit field syntax (<1>), the bit field portion is ignored when performing suffix matching. If a differential pair is created the bit number is added to the base net name used in forming a differential pair. For example, given two nets; DATA_P<1> and DATA_N<1> will result in a differential pair called DP_DATA1 with this call:

```
axlDiffPairAuto("DP_" "_P" "_N")
```

Arguments

t_diffPairPrefix	String to prefix differential pair names. Use "" if no prefix is desired.
t_posNetSuffix	Suffixes used to identify + differential pair members.
t_negNetSuffix	Suffixes used to identify – differential pair members.
g_returnDiffPairList	Controls return.

Value Returned

Returns depend on value of *g_returnDiffPairList* as shown:

©2023 All Rights Reserved.

g_returnDiffPairList	Value Returned	Description
`nil`	*x_cnt*	Number of differential pairs created.
`t`	(*x_cnt*, *lo_diffpair*)	List of differential pairs created

The default is the `nil` case.

Examples

Example nets

Two nets called `NET1+` and `NET1-` are passed to this function.

Example 1

```
axlDiffPairAuto("DP_" "+" "-")
```

Shows differential pair creation and name generation. Results in one differential pair called `DP_NET1` with members `NET1+` and `NET1-`.

Example 2

```
axlDiffPairAuto("" "+" "-")
```

Given the same inputs as the previous example, will result in a differential pair with the same members, but names the differential pair `NET1`.

©2023 All Rights Reserved.

axlDiffPairDBID

```
axlDiffPairDBID(
     t_name
     )
     ⇒ o_dbid/nil
```

Description

Returns the *dbid* of the named differential pair (*t_name*), if it exists in the database.

Arguments

t_name	Differential pair name.

Value Returned

o_dbid	*dbid* of differential pair if it exists.
nil	Differential pair does not exist.

Example

List differential pairs:

```
axlDBGetDesign()->diffpair
```


©2023 All Rights Reserved.

axlMatchGroupAdd

```
axlMatchGroupAdd(
     o_mgdbid/t_mgName
     o_dbid/lo_dbid
     )==> t/nil
```

Description

Adds members to a matched group. Eligible members are:

- nets (if a net is part of an xnet the xnet is added to the group)
- xnets
- pinpairs

See discussion in `axlDBMatchGroupCreate`.

Command fails in product tiers that do not support electrical constraints or the symbol editor.

Tip

Using `dbids` is faster than using names.

Arguments

o_mgdbid	`dbid` of a match group.
t_mgName	Name of a match group.
o_dbid	Legal database `dbid` to add to match group.
lo_dbid	List of legal database `dbids` to add to match group.

Value Returned

`t`	Added elements.
`nil`	Failed one or more element additions.

See Also

`axlMatchGroupCreate`

©2023 All Rights Reserved.

Example

Add two nets to match group created in `axlMatchGroupCreate`:

```
mg = car(axlSelectByName("MATCH_GROUP" "MG1"))
nets = axlSelectByName("NET" '("B1_OUT" "B2_OUT"))
axlMatchGroupAdd(mg  nets)
```


©2023 All Rights Reserved.

axlMatchGroupCreate

```
axlMatchGroupCreate(
     t_name
     )==> o_mgdbid
```

Description

Creates a new match group. If a match group already exists with the same name, `nil` is returned. Match groups need to be populated, or they are deleted when saving. Use the axlMatchGroupAdd command to populate the match groups.

Note: The axlMatchGroupCreate command fails in product tiers that do not support electrical constraints or the symbol editor.

If the match group was partially or completely created from an ECset, you can delete it, but it reappears when ECset flattening is required due to modifications in the design. SKILL functions do not indicate ECset-derived match groups.

You can access list of match groups in database by:

```
axlDBGetDesign()->matchgroup
```

RELATIVE_PROPAGATION_DELAY

The RELATIVE_PROPAGATION_DELAY property can be added to match groups, xnets, and pinpairs. If you add it to the match group then any match group member that does not have that property inherits it from the match group.

Match groups contain the following elements: xnets, nets, and pinpairs. If a net is part of an xnet, the xnet is added to the match group.

Xnets and pinpairs can belong to multiple match groups, so an RPD property exists on the `dbid` for nets, xnets and pinpairs. This property is a list of lists where each sub-list contains a match group `dbid` and the RELATIVE_PROPAGATION_DELAY value:

```
rpd = ( (o_mgDbid t_rpdValue) ....)
```

Thus if a pinpair belongs to 2 match groups, you see two lists that are the inherited. A pinpair in a single match group has a single list of list. For example, a pinpair in MG3 with global scope and an override of delta/tolerance of `10ns:5%` reports:

```
rpd = ((dbid:61315360 "MG3:G:::10 ns:5 %"))
```

The same pinpair without an override will report default match group value as

```
rpd = ((dbid:61315360 "MG3:G:AD:AR:0 ns:5 %"))
```


©2023 All Rights Reserved.

In both the examples, the dbid references the match group id (MG3).

The RELATIVE_PROPAGATION_DELAY syntax is discussed in the Allegro Property Reference Manual. In general the syntax is:

```
<Match group name>:<scope>:<pinpair>:<value>
```

You can add and delete properties to a member of a match group or pinpair `dbid` using axlMatchGroupProp. When creating the property value, you must include the match group name but not an explicit pinpair. For example, the following adds an RPD property to a match group named `MG2`:

```
axlMatchGroupProp(mg n1 "MG1:G:::100 ns:5 %")
```

Additional restrictions for this property are:

- Pinpairs should leave the pinpair section empty (`":::"`).

  Example: `"MG2:G:::0 ns:5 %"`

- Match groups should not reference an explicit pinpair but, if not empty, should use a pinpair type (for example, "AD:AR","D:R" etc.)

For nets and xnets, if you access the RELATIVE_PROPAGATION_DELAY property, you may see the flattened version. This implies that if nets and xnets are part of multiple Match Groups, they all appear concatenated in the RELATIVE_PROPAGATION_DELAY property.

Any pinpairs that are part of the net appear as part of the property at the net or xnet level. This is present to support legacy applications like netlisters. The RPD property that is `dbids` for pinpairs, net and xnets breaks this concatenation. Using `axlDBAddProp` and `axlDBDeleteProp` commands to modify the property may effect all match groups and pinpairs. It is recommended that axlMatchGroupProp is used for modification of the RELATIVE_PROPAGATION_DELAY property for all objects.

©2023 All Rights Reserved.

Arguments

t_name	Name of match group (changed to upper case).

Value Returned

`nil`	Error or match group with same name already exists.
o_mgdbid	`dbid` of match group.

See Also

axlPinPairSeek, axlPinsOfNet, axlMatchGroupCreate, axlMatchGroupDelete, axlMatchGroupAdd, axlMatchGroupRemove, `axlMatchGroupProp`

Example

Create a match group called `MG1`:

```
mg = axlMatchGroupCreate("mg1")
```


©2023 All Rights Reserved.

axlMatchGroupDelete

```
axlMatchGroupDelete(
                 o_mgdbid/t_mgName
         ) -> t/nil
```

Description

This deletes a match group. The command fails in product tiers that do not support electrical constraints or the symbol editor.

Tip

Using `dbids` is faster than using names.

Arguments

o_mgdbid	`dbid` of a match group.
t_mgName	Name of a match group.

Value Returned

`t`	Match group deleted.
`nil`	Failed.

See Also

axlMatchGroupCreate

Examples

Delete match group created in `axlMatchGroupCreate`:

```
mg = car(axlSelectByName("MATCH_GROUP" "MG1"))
axlMatchGroupDelete(mg)
```

or

```
axlMatchGroupDelete("MG1")
```


©2023 All Rights Reserved.

axlMatchGroupProp

```
axlMatchGroupProp(
                 o_mgdbid/t_mgName
                 o_dbid
                 t_value/nil
         )==> t/nil
```

Description

Adds or removes the RELATIVE_PROPAGATION_DELAY property from a member of a match group. Property must be a legal RPD syntax that includes the RPD name.

The command fails in product tiers that do not support electrical constraints or the symbol editor.

See discussion in `axlDBMatchGroupCreate`.

Tip

Using `dbids` is faster than using names.

Arguments

o_mgdbid	`dbid` of a match group
t_mgName	Name of a match group
o_dbid	Legal database dbid to of a member of the match group
t_value	RELATIVE_PROPAGATION_DELAY value in legal syntax. If value is `nil;` removes the property.

Value Returned

`t`	Added elements.
`nil`	Failed one or more element additions.

See Also

`axlMatchGroupCreate`

©2023 All Rights Reserved.

Examples

Add two nets to match group created in `axlMatchGroupCreate`:

```
mg = car(axlSelectByName("MATCH_GROUP" "MG1"))
nets = axlSelectByName("NET" '("B1_OUT" "B2_OUT"))
n1 = car(nets)
n2 = cadr(nets)
axlMatchGroupAdd(mg  nets)
```

Add properties:

```
axlMatchGroupProp(mg n1 "MG1:G:::100 ns:5 %")
axlMatchGroupProp(mg n2 "MG1:G:AD:AR:0 ns:5 %")
```

Remove property from `n2`:

```
axlMatchGroupProp(mg n2 nil
```


©2023 All Rights Reserved.

axlMatchGroupRemove

```
axlMatchGroupRemove(
                 o_mgdbid/t_mgName
                 o_dbid/lo_dbid
         )==> t/nil
```

Description

Removes elements from an existing match group. Elements must be members (attribute groupMembers) of the match group.

The command fails in product tiers that do not support electrical constraints or the symbol editor.

Tip

Using `dbids` is faster than using names.

Arguments

o_mgdbid	`dbid` of a match group.
t_mgName	Name of a match group.
o_dbid	Legal database `dbid` to remove from match group.
lo_dbid	List of legal database `dbids` to remove from match group.

Value Returned

`t`	Removed elements.
`nil`	Failed one or more element removals.

See Also

axlMatchGroupCreate

Example

To match group in example `axlMatchGroupAdd` remove one of the nets:

©2023 All Rights Reserved.

```
axlMatchGroupRemove(mg  car(nets))
```


©2023 All Rights Reserved.

axlNetSched

```
axlNetSched()
==> t
```

Description

This is the main routine that the command processor calls for the `net schedule` command.

Arguments

None

Value Returned

t

©2023 All Rights Reserved.

axlPinPair

Add

```
axlPinPair(
    o_pin1/t_pin1
    o_pin2/t_pin2
)==> o_pinpair
```

Delete

```
axlPinPair(
    o_pinpair/lo_pinpair
)==> t/nil
```

Description

This creates or deletes a pinpair. A pinpair consists of two unordered pins or ratTs on the same net. For example, pinpair `u1.2:r1.2` is the same pinpair as `r1.2:u1.2`. If the pinpair already exists then the existing pinpair is returned. The command fails in product tiers that do not support electrical constraints or the symbol editor.

Note: You cannot create a pinpair if both pins (or ratTs) do not belong to the same XNet.

If the pinpair was created in an ECSet, the ECsetDerived attribute will be `t` and you cannot delete it. You must find the ECSet(s) associated with a net, XNet, differential pair or bus and modify the pinpair in the associated ECset..

At database save, a pinpair must be part of a match group or have a legal electrical constraint property assigned to it, otherwise it will be deleted. Legal electrical properties are:

- PROPAGATION_DELAY
- MIN_FIRST_SWITCH
- MAX_FINAL_SETTLE
- IMPEDANCE_RULE
- TIMING_DELAY_OVERRIDE
- RELATIVE_SKEW

RELATIVE_PROPAGATION_DELAY is stored on the RPD attribute as a list of lists.The reason for this is that a pinpair can be a member of multiple matched groups.

See `axlMatchGroupCreate` for more information.

©2023 All Rights Reserved.

Tip

Using `dbids` is faster than using names.

Arguments

o_pin1/o_pin2	`dbid` of a pin or ratT
t_pin1/t_pin2	A pin name (`<refdes>.<pin#>`); ratT names are not supported.
o_pinpair	Pinpair `dbid`.
lo_pinpair	List of pinpair `dbids` (delete mode only).

Value Returned

Returns depending upon the mode.

`nil`	Error
`t`	Deletion was successful.
o_pinpair	`dbid` of added or modified differential pair.

See Also

axlPinPairSeek, axlPinsOfNet, `axlMatchGroupCreate`

Examples

Example 1: XNet having two nets; `NET1` and `NET1A`. This demonstrates that pinpairs are stored on the XNet.

Create pinpair using name:

```
pp = axlPinPair("U2.13" "R1.2")
```

Create pinpair with ratT of net `NET1A`:

```
ratTs = axlPinsOfNet("NET1A" 'ratT)
```


©2023 All Rights Reserved.

```
pp = axlPinPair("U2.13" car(ratTs))
```

Verify pinpairs are both on `NET1A`:

```
n = car(axlSelectByName("NET" "NET1A"))
n->pinpair RETURNS nil
```

Examine the XNet (`NET1`):

```
xn = car(axlSelectByName("XNET" "NET1"))
xn->pinpair RETURNS (dbid:21697512 dbid:21697232)
```

Example 2: Delete all pinpairs of Example 1:

```
axlPinPair(xn->pinpair)
```


©2023 All Rights Reserved.

axlPinPairSeek

```
axlPinPairSeek(
                o_pin1
                o_pin2
            )==> o_pinpair/nil
```

Description

Given two pins or ratTs reports if they are part of a pinpair.

Arguments

o_pin1/o_pin2	`dbid` of a pin or ratT.
t_pin1/t_pin2	A pin name (`<refdes>.<pin#>`); ratT names not supported.

Value Returned

o_pinpair	Pinpair `dbid`.
`nil`	Pinpair for given pins does not exist.

See Also

axlPinPair

Example

See if a pinpair for these two pins exists:

```
pp = axlPinPair("U2.13" "R1.2")
```


©2023 All Rights Reserved.

axlPinsOfNet

```
axlPinsOfNet(
                 o_net/t_net
                 g_mode
         ) -> lo_pins/nil
```

Description

Returns list of pins and ratTs on a net or xnet. First argument can be either a net, xnet `dbid` or a net name (xnet names are not supported). Second option, *`g_mode`*, can be *`'pin`* to return only the pins, *`'ratT`* to return list of ratTs or nil to return both pins and ratTs. There is no meaning conveyed in the list of items returned.

Arguments

`o_net`	`dbid` of a net or xnet.
`t_net`	Name of a net (does not support xnet names).
`g_mode`	`nil` return both pins and ratTs of a net.
`'pin`	Return only pins.
`'ratT`	Return only the ratT's.

Value Returned

`lo_pins`	List of pins and/or ratTs on net or xnet.
`nil`	Nothing meeting criteria (or error, `dbid` not net or xnet).

Examples

All pins on GND:

```
net = car(axlSelectByName("NET" "GND"))
lpins = axlPinsOfNet(net, 'pins)
```

All pins and ratTs on first xnet in design root (could be a net):

```
xnet = car( axlDBGetDesign()->xnet )
lpins = axlPinsOfNet(xnet, nil)
```


©2023 All Rights Reserved.

axlRemoveNet

```
axlRemoveNet(
     t_name/o_dbid
     [g_ripup]
     )
     ⇒ t/nil
```

Description

Removes a net. May either give a string with the net name to be renamed or *dbid* of an object on that net.

Caution

The net name may be used in properties. This function does not update these values.

Arguments

t_name	Net name.
o_dbid	*dbid* of a net.
g_ripup	Optional argument. Ripup associated etch when a net is deleted.

Value Returned

t	Net successfully removed.
nil	No net is removed.

Example

```
axlRemoveNet("GND")
```


©2023 All Rights Reserved.

axlRenameNet

```
axlRenameNet(
     t_old_name
     t_new_name
     )
     ⇒ t/nil
```

```
axlRenameNet(
     o_dbid
     t_new_name
     )
     ⇒ t/nil
```

Description

Renames a net. For the old object, may either give a string with the net name to be renamed, or *dbid* of an object on that net. Fails if the new net name already exists in the database.

```
dbid = axlSingleSelectName("NET" '("NET"))
```

Note: This function does not refresh any `axl` *dbids* to reflect the new net name.

Caution

The net name may be used in properties. This function does not update net names in property values.

Arguments

t_old_name	Existing net name.
o_dbid	*dbid* of an object on a net.
t_new_name	New net name (should not exist in the database.)

Value Returned

`t`	Net successfully renamed.
`nil`	Net name already exists in the database.

Example

```
axlRenameNet("GND" "NEWGND")
```


©2023 All Rights Reserved.

```
; first verify the new net name doesn’t exist
axlSetFindFilter(?enabled '("noall" "nets"))
if(axlSingleSelectName("NET" '("NEWGND") ) then
    axlRenameNet(dbid "NEWGND")
```


©2023 All Rights Reserved.

axlRenameRefdes

```
axlRenameRefdes(
     t_old_name/o_oldCompDbid
     t_new_name/o_newCompDbid

)

⇒ t/nil
```

Description

Renames a refdes. For either argument, may use a refdes name or a component instance.

If both refdes exist, a swap is done.

Arguments

t_oldName	Existing refdes name.
o_oldCompDbid	Component *dbid*.
t_newName	New refdes name.
o_newCompDbid	Component *dbid*.

Value Returned

`t`	Refdes successfully renamed or swapped.
`nil`	No refdes renamed or swapped due to incorrect arguments.

©2023 All Rights Reserved.

Example 1

```
axlRenameRefdes("U1" "X1")
```

Changes refdes by name.

Example 2

```
axlSetFindFilter(?enabled '("noall" "components") ?onButtons '(all))
axlSingleSelectName("COMPONENT" "U1")
firstComp = car(axlGetSelSet())
axlSingleSelectName("COMPONENT" "U2")
secondComp = car(axlGetSelSet())
axlRenameRefdes(firstComp secondComp)
```

Swaps with starting point of two component *dbids*.

©2023 All Rights Reserved.

axlSchedule

```
axlSchedule(
          o_net/t_net
          [g_userSchedule]
        )
        ==> t_schedule/nil
```

Description

Gets net schedule. When `g_userSchedule` is `t,` this fetches the `a` user schedule or a partial user schedule from a net. Returns nil if the net is completely algorithm scheduled. Using `t` is recommended. When `g_userSchedule` is nil, returns the schedule of the complete net even if the net is completely algorithm scheduled.

The format of `t_schedule` is a string in the $SCHEDULE netin (3rd party) format. See `netin` documentation for more info about the syntax.

Arguments

o_net	*dbid* of net
t_net	Name of net
g_userSchedule(optional)	If t returns the schedule if the net is user schedule or partial user schedule. Other nets in this netin format if nil remove

Values Returned

t_schedule	Schedule or partial user schedule.
nil	Failed or net is not user schedule or partial user schedule. Use axlDebug to obtain more data.

See Also

axlScheduleNet

©2023 All Rights Reserved.

Examples

Net2 has the following pins and rat-Ts:

```
P1.7 U1.4 U1.10 U2.6 T.1
```

It is partially user schedule such as P1.7, U1.4, and U1.10 should be connected to rat-T, T.1. Pin U2.6 is algorithm scheduled but the sub-schedule (partial) indicates it should connected to U1.10 (indicated by a star '*' in the schedule string).

Fetch partial schedule (note no U2.6)

```
q = axlSchedule("NET2" t)
==> "P1.7 T.1 U1.4 ; T.1 *U1.10 "
```

Same net but complete schedule

```
q = axlSchedule("NET2" t)
==> "P1.7 T.1 U1.4 ; T.1 *U1.10 U2.6 "
```


©2023 All Rights Reserved.

axlScheduleNet

```
axlScheduleNet(
          o_net/t_net
          t_schedule/nil
         )
==> t/nil
```

Description

This applies a user schedule or a partial user schedule to a net. Format of *t_schedule* is a string in the $SCHEDULE netin (3rd party) format.

Note: See `netin` documentation for more info about the syntax.

When *t_schedule* is *nil* it removes any user schedule or partial user schedule from the net and restores its default schedule algorithm (NET_SCHEDULE property).

Arguments

o_net	*dbid* of net
t_net	Name of net
t_schedule	Schedule or partial schedule using $SCHEDULE netin format; if *nil,* remove

Value Returned

t	Schedule applied.
nil	Failed or arguments are incorrect (use `axlDebug`) for more info.

See Also

axlSchedule

©2023 All Rights Reserved.

axlWriteDeviceFile

```
axlWriteDeviceFile(
     o_compDefDbid
     [t_output_dir]
)
⇒ t/nil
```

Description

Given a component definition, writes out a third party device file. Writes to the directory specified, or if no directory or `nil` is given, writes to the current directory.

Name of the file is compDef->deviceType in lower case with a.txt file extension. For example, if component definition (compDef) device type is `CAP1`, then the device file name is `cap1.txt`.

Also creates a `devices.map` file which is empty unless the device name has characters that are not legal as a filename.

See `netin` documentation for device file syntax.

Note: Do not use this function if you use Cadence Front-End Schematic packages.

Caution

This function overwrites existing <`device`> and `devices.map` files in the directory.

©2023 All Rights Reserved.

Arguments

o_compDefDbid	Component definition of the device file to write out.
t_output_dir	Directory in which to write the files. If not provided, the current directory is used.

Value Returned

`t`	Device file successfully written.
`nil`	Failed to write device file due to incorrect *dbid* or directory.

Example

```
axlWriteDeviceFile( car(axlDBGetDesign()->components)->compdef)
```

Writes device file of the definition for the first component instance off the design root.

©2023 All Rights Reserved.

axlWritePackageFile

```
axlWritePackageFile(
     o_symDefDbid
     [t_output_dir]
)
⇒ t/nil
```

Description

Given a symbol definition, writes out symbol `.dra`, `.psm` and associated padstack files. Works like `dump_libraries` on a single symbol definition.

The file name root is the symbol definition name. For example, if the symbol definition (symDef) name is `CAPCK05`, the output files created are named `capck05.psm` and `capck05.dra`, plus any padstacks (in lower case) that are part of the symbol.

Caution

This function overwrites existing files in the target directory.

Arguments

o_symDefDbid	Symbol definition to store on disk.
t_output_dir	Directory in which to store the files. If not provided, the current directory is used.

Value Returned

`t`	Files successfully written.
`nil`	Failed to write files due to incorrect *dbid* or directory.

Example

```
symDef = car(axlDBGetDesign()->components)->symbol->definition
axlWritePackageFile( symDef)
```

Writes symbol files of the definition for the first component instance off the design root.

©2023 All Rights Reserved.

©2023 All Rights Reserved.

31

DFM SKILL APIs

This chapter describes the AXL-SKILL functions related to design for manufacturing (DFM).

Component Lead Functions

axlCreateLeadContact

```
axlCreateLeadContact(
     t_leadType
     t_symbol
     l_pins
     r_laedParams
     )
     ⇒ t/nil
```

Description

This function creates lead contact shape for the pins belonging to a symbol definition.

Arguments

t_leadType	Type of leads to be created. The valid types are: "No lead", "Ball", "Ball-Collapsing", "Ball-Non collapsing", "Bump", "Column", "Pillar", "Rectangular end cap", "Cylindrical end cap", "Flat lead", "Flat lug", "Flat no-lead bottom", "Flat no-lead edge", "Flat thermal", "Gull wing", "Ribbon L-Inward","Ribbon L-Outward", "Under body outward L", "J-Lead", "Side lead convex","Side lead concave","Side lead flat", "Butt lead","Corner concave","Other surface","Through round","Through rectangular","Through other", "No connect", "Press fit"
t_symbol	Name of the symbol

©2023 All Rights Reserved.

l_pins	List of dbids of the pins for which the contact shapes are to be created. If this is passed as `nil` all the numbered pin will be considered for lead.
r_leadParams	Use make_axlLeadParam. Elements are: leadFigure: (text) Allowed names are "CIRCLE", "RECTANGLE", "DONUT", "N_SIDED_POLY" "OBLONG", "OCTAGON", "ROUNDED_RECT", "CHEMFERED_RECT", "SQUARE", "SHAPE"
leadShape	(text) name of the shape (valid only if 'SHAPE is specified as leadFigure) figureSize: (list) (f_width:f_height) width and height of the figure offset: (list) (x_offset:y_offset) offset of the lead contact shape with respect to pad center length: length of the actual lead width: width of the lead height: height of the lead n_sides: no of sides (valid for N_SIDED_POLY) outer_inner_dia: (outerDia innerDia) valid for Donut shape cornerRadOrChanf: specific to rounded or chamfered rectangle. They specify corner radius or corner chamfer. corner: specifies the list of corners that need to be rounded/ chamfered. Valid values of an element are: "UPPER_LEFT", "UPPER_RIGHT", "LOWER_LEFT", "LOWER_RIGHT"

Value Returned

`t`	If successful
`nil`	If failed

See Also

axlDeleteLeadContact

©2023 All Rights Reserved.

Example

```
leadParams = cons( make_axlLeadParam( ?leadFigure 'N_SIDED_POLY ?figureSize
10:10 ?offset
-1:-2 ?length 50 ?width 10 ?height 10 ?n_sides 8 ) nil )
axlCreateLeadContact("Ball" "RES" nil leadParams ) ; apply ball type lead for
all the pins in the symbol
```


©2023 All Rights Reserved.

axlDeleteLeadContact

```
axlDeleteLeadContact(
     t_symbol
     l_pins
     )
     ⇒ t/nil
```

Description

This function deletes lead contact shape for the pins belonging to a symbol definition.

Arguments

t_symbol	Name of the symbol
l_pins	List of dbids of the pins for which the contact shapes are to be deleted. If this is passed as `nil` all the numbered pin will be considered.

Value Returned

`t`	If successful
`nil`	If failed

See Also

axlCreateLeadContact

Example

```
axlDeleteLeadContact("RES" nil ) ; delete all the lead contact for the symbol
```


©2023 All Rights Reserved.

axlGetSupportedLeadTypes

```
axlGetSupportedLeadTypes(
     g_category
     )
     ⇒ list of supported lead types/nil
```

Description

This function returns all the supported lead types in the form of a list. Each element of the list is a name of the lead types supported by the lead editor and lead checks.

Arguments

g_category	Category of the lead. Valid values are: ■ ALL: Get all type of leads ■ SMD: Get lead types that are valid for surface mount devices ■ THRU: Get lead types that are valid for through hole pins ■ BALL: Get lead types that are applicable to balls

Value Returned

`list of valid lead types`	If successful
`nil`	If failed

See Also

axlCreateLeadContact, axlDeleteLeadContact

Example

```
ll = axlGetSupportedLeadTypes("ALL") ; Get all supported lead types
```


©2023 All Rights Reserved.

DFM CSet Operations

Worksheet Names

The following table lists supported worksheet names.

Table 31-1 Worksheet names

`"DFF_OUTLINE"`	Indicates that cset is going to hold constraints pertaining to OUTLINE worksheet
`"DFF_MASK"`	Indicates that cset is going to hold constraints pertaining to MASK worksheet
`"DFF_HOLE"`	Indicates that cset is going to hold constraints pertaining to HOLE worksheet
`"DFF_SILKSCREEN"`	Indicates that cset is going to hold constraints pertaining to SILKSCREEN worksheet
`"DFF_ANNULAR_RING"`	Indicates that cset is going to hold constraints pertaining to ANNULAR RING worksheet
`"DFF_COPPER_FEATURE"`	Indicates that cset is going to hold constraints pertaining to COPPER FEATURE worksheet
`"DFF_COPPER_SPACING"`	Indicates that cset is going to hold constraints pertaining to COPPER SPACING worksheet
`"DFA_OUTLINE"`	Indicates that cset is DFA cset pertaining to DFA outline worksheet
`"DFA_PKGPKG"`	Indicates that cset is DFA cset pertaining to DFA package to package worksheet
`"DFA_SPACING"`	Indicates that cset is a DFA cset pertaining to DFA spacing worksheet
`"DFA_COMPLEAD"`	Indicates that cset is a DFA cset pertaining to DFA component lead worksheet
`"DFA_MASK"`	Indicates that cset is a DFA cset pertaining to DFA mask worksheet
`"DFA_FIDUCIAL"`	Indicates that cset is a DFA cset pertaining to DFA fiducial worksheet

©2023 All Rights Reserved.

"DFT_OUTLINE"	Indicates that cset is a DFT cset pertaining to DFT outline worksheet
"DFT_MASK"	Indicates that cset is a DFT cset pertaining to DFT mask worksheet
"DFT_SPACING"	Indicates that cset is a DFT cset pertaining to DFT spacing worksheet
"DFT_PROBE"	Indicates that cset is a DFT cset pertaining to DFT probe worksheet

Subtype CSet Names

The following table lists names of supported subtype CSets.

Table 31-2 List of Subtype CSets

"DFF_OUTLINE"	Indicates that cset is going to hold constraints pertaining to OUTLINE worksheet
"DFF_MASK"	Indicates that cset is going to hold constraints pertaining to MASK worksheet
"DFF_HOLE"	Indicates that cset is going to hold constraints pertaining to HOLE worksheet
"DFF_SILKSCREEN"	Indicates that cset is going to hold constraints pertaining to SILKSCREEN worksheet
"DFF_ANNULAR_RING"	Indicates that cset is going to hold constraints pertaining to ANNULAR RING worksheet
"DFF_COPPER_FEATURE"	Indicates that cset is going to hold constraints pertaining to COPPER FEATURE worksheet
"DFF_COPPER_SPACING"	Indicates that cset is going to hold constraints pertaining to COPPER SPACING worksheet
"DFA_OUTLINE"	Indicates that cset is DFA cset pertaining to DFA outline worksheet
"DFA_PKGPKG"	Indicates that cset is DFA cset pertaining to DFA package to package worksheet
"DFA_SPACING"	Indicates that cset is a DFA cset pertaining to DFA spacing worksheet

©2023 All Rights Reserved.

`"DFA_COMPLEAD"`	Indicates that cset is a DFA cset pertaining to DFA component lead worksheet
`"DFA_MASK"`	Indicates that cset is a DFA cset pertaining to DFA mask worksheet
`"DFA_FIDUCIAL"`	Indicates that cset is a DFA cset pertaining to DFA fiducial worksheet
`"DFT_OUTLINE"`	Indicates that cset is a DFT cset pertaining to DFT outline worksheet
`"DFT_MASK"`	Indicates that cset is a DFT cset pertaining to DFT mask worksheet
`"DFT_SPACING"`	Indicates that cset is a DFT cset pertaining to DFT spacing worksheet
`"DFT_PROBE"`	Indicates that cset is a DFT cset pertaining to DFT probe worksheet

©2023 All Rights Reserved.

axlCreateDfmAssignment

```
axlCreateDfmAssignment(
     className
     worksheetName
     dfmentryType
     stackupName
     subclassGrouporGLTName
     cset_name
     subClassName
     )
     ⇒ t/nil
```

Description

This function assigns a DFM CSet to a layer, layer group, or a subclass group. With this all the constraints associated with the CSet gets assigned to the object. The DRC engine uses the CSet assignments with the objects to determine the constraints that needs to be evaluated.

©2023 All Rights Reserved.

Arguments

`className`	Name of the classes on which the constraint is applicable. This is applicable only form non etch type of rules specified through subclass group.
`worksheetName`	Name of the worksheet where the rule is applicable. Refer to Worksheet names for valid worksheet names
`dfmentryType`	Specifies the entry type in the assignment table. The valid values are: 'LAYER_BASED: Indicates that assignment is layer based and is assigned to a layer. 'CLASS_SUBCLASS: Indicates that the assignment is class subclass based. It needs the subclass group name to be filled. 'GLT_BASED: Indicates that the assignment is applicable to a generic layer type. The subclass group name argument should have a valid GLT name if this type is selected. Valid GLT names are: "TESTING LAYERS": for DFT "ASSEMBLY LAYERS": for DFA "CONDUCTOR": For DFF "PLANE" Any GLT name defined in cross-section editor 'STACKUP_BASED: Indicates that the rule is assigned to the stackup. That means that the rule will be assigned to the entire stackup (For example, Outline to Cutout rule).
`stackupName`	Specifies the name of the stackup on which the rule is applicable. The primary stackup is named as "PRIMARY"
`subclassGrouporGLTName`	Specifies that the name field in the table corresponds to a bucket name which is essentially a group of class and subclass combination. This interpretation is valid only if the entry type is CLASS_SUBCLASS. If value of entry type is GLT_BASED, this field refers to GLT name.

©2023 All Rights Reserved.

cset_name	Specifies the name of the DFF CSet that corresponds to the mapping based on other fields.
subClassName	Specifies the subclass name. This holds the name of the layer or subclass in the table.

Value Returned

`t`	If successful
`nil`	If failed

See Also

axlCreateDffCset, axlDeleteDffCset

Example

```
ll = axlCreateDFMCset("test_cset33" "DFF_OUTLINE" "ETCH")
axlCreateDfmAssignment( "ETCH" "DFF_OUTLINE" "LAYER_BASED"  "PRIMARY" "dummy"
"test_cset33" "TOP")
```


©2023 All Rights Reserved.

axlDFMIsCsetLocked

```
axlDFMIsCsetLocked(
     worksheetName
     cset_name
     )
     ⇒ t/nil
```

Description

This function Checks if a DFM cset is locked or not.

Arguments

worksheet_name	Name of the worksheet where the rule is applicable. Refer to Worksheet names for valid worksheet names
cset_name	Specifies the name of the DFM CSet that corresponds to the mapping based on other fields.

Value Returned

`t`	If locked
`nil`	If not locked

See Also

axlDFMCsetLock

Example

```
lockStatus = axlDFMIsCsetLocked( "DFF_OUTLINE"  "test_cset33" )
```


©2023 All Rights Reserved.

axlDFMCsetLock

```
axlDFMCsetLock(
     worksheetName
     cset_name
     g_mode
     )
     ⇒ t/nil
```

Description

This function locks/unlocks a DFM cset.

Arguments

worksheet_name	Name of the worksheet where the rule is applicable. Refer to Worksheet names for valid worksheet names
cset_name	Specifies the name of the DFM cset that corresponds to the mapping based on other fields.
g_mode	May either be `t` (to lock) or `nil` to unlock

Value Returned

`t`	If updated lock status
`nil`	If an error

See Also

axlDFMIsCsetLocked

Example

```
axlDFMCsetLock( "DFF_OUTLINE"  "test_cset33" t)
```


©2023 All Rights Reserved.

axlDeleteDfmAssignment

```
axlDeleteDfmAssignment(
     worksheetName
     cset_name
     )
     ⇒ t/nil
```

Description

This function deletes Design For manufacturing cset assignment.

Arguments

worksheet_name	Name of the worksheet where the rule is applicable. Refer to Worksheet names for valid worksheet names
cset_name	Specifies the name of the DFM cset that corresponds to the mapping based on other fields.

Value Returned

`t`	If successful
`nil`	If failed

See Also

axlCreateDFMCset

Example

```
axlDeleteDfmAssignment( "DFF_OUTLINE"  "test_cset33" )
```


©2023 All Rights Reserved.

axlGetDFMAssignedCsets

```
axlGetDFMAssignedCsets(
     subtype
     )
     ⇒ l_dff_cset/nil
```

Description

This function gets the Assigned Design For Manufacturing (DFM) CSets in a design.

©2023 All Rights Reserved.

Arguments

subtype Specifies the sub type of the CSet. The valid values are:

DFF_OUTLINE: Indicates that CSet is going to hold constraints pertaining to OUTLINE worksheet.

DFF_MASK: Indicates that CSet is going to hold constraints pertaining to MASK worksheet.

DFF_HOLE: Indicates that CSet is going to hold constraints pertaining to HOLE worksheet.

DFF_SILKSCREEN: Indicates that CSet is going to hold constraints pertaining to SILKSCREEN worksheet.

DFF_ANNULAR_RING: Indicates that CSet is going to hold constraints pertaining to ANNULAR RING worksheet.

DFF_COPPER_FEATURE: Indicates that CSet is going to hold constraints pertaining to COPPER FEATURE worksheet.

DFF_COPPER_SPACING: Indicates that CSet is going to hold constraints pertaining to COPPER SPACING worksheet.

DFA_OUTLINE: Indicates that CSet is a DFA CSet pertaining to DFA outline worksheet.

DFA_PKGPKG: Indicates that CSet is a DFA CSet pertaining to DFA package to package worksheet.

DFA_SPACING: Indicates that CSet is a DFA CSet pertaining to DFA spacing worksheet.

DFA_COMPLEAD: Indicates that CSet is a DFA CSet pertaining to DFA component lead worksheet.

DFA_MASK: Indicates that CSet is a DFA CSet pertaining to DFA mask worksheet.

DFA_FIDUCIAL: Indicates that CSet is a DFA CSet pertaining to DFA fiducial worksheet.

©2023 All Rights Reserved.

DFT_OUTLINE: Indicates that CSet is a DFT CSet pertaining to DFT outline worksheet.

DFT_MASK: Indicates that CSet is a DFT CSet pertaining to DFT mask worksheet.

DFT_SPACING: Indicates that CSet is a DFT CSet pertaining to DFT spacing worksheet.

DFT_PROBE: Indicates that CSet is a DFT CSet pertaining to DFT probe worksheet.

Value Returned

List of CSets and types along with the assignment details, if there is at least one assigned CSet. If there are more than one CSet on that category, it will be a list of lists.

Each list will contain the following:

1. Name of the cset
2. Subtype of the cset. The valid values are mentioned under arguments.
3. DFM entry type. The valid values are as follows:
   - LAYER_BASED: Indicates that assignment is layer based and is assigned to a layer.
   - CLASS_SUBCLASS: Indicates that the assignment is class and subclass based. It needs the subclass group name to be filled.
   - GLT_BASED: Indicates that the assignment is applied to a generic layer type.Valid GLT names are:
     - TESTING LAYERS: for DFT
     - ASSEMBLY LAYERS: for DFA
     - CONDUCTOR: For DFF
     - PLANE
     - Any GLT name defined in Cross-section Editor.
   - STACKUP_BASED: Indicates that the rule is assigned to the stackup. For example,. Outline to Cutout rule.
4. stackupName: Specifies the name of the stackup on which the rule is applied. The primary stackup is named as PRIMARY.

©2023 All Rights Reserved.

5. subclassGrouporGLTName: Specifies that the name field in the table corresponds to a subclass group name which is essentially a group of class subclass combination. This interpretation is valid only if the entry type is CLASS_SUBCLASS. If the value of entry type is GLT_BASED, this field refers to GLT name. Otherwise subclass name is returned.
6. subclass_name: Specifies the subclass name. This field holds the name of the layer or subclass in the table.
7. className: Specifies the name of the class on which the constraint is applicable. This field is allowed only for non-etch type of rules specified through subclass group. By default, it returns BOARD_GEOMETRY.

`nil` is returned if failed or if there is no CSet assigned.

See Also

axlCreateDFMCset, axlCreateDfmAssignment, axlDeleteDffCset

Example

For example, in a design that has 2 CSets with types Annular ring and 1 CSet with type Mask in DFF sub-domain:

- The function call axlGetDFMAssignedCsets("DFF_ANNULAR_RING") return the following:

```
( ("ABC1" "DFF_ANNULAR_RING" "LAYER_BASED" "PRIMARY" "SOLMPH_TOP"
"SOLMPH_TOP" "BOARD_GEOMETRY") ("TEST2" "DFF_ANNULAR_RING" "LAYER_BASED"
"PRIMARY" "SOLMPH_TOP"  "SOLMPH_BOT" "BOARD_GEOMETRY") )
```

- Function call axlGetDFMAssignedCsets("DFF_MASK") return the following:

```
("ABC2" "DFF_MASK" "CLASS_SUBCLASS" "PRIMARY" "SILK2PAD_TOP" "PLATING_BAR"
"BOARD_GEOMETRY"))
```


©2023 All Rights Reserved.

axlGetDFMCsetAssignmentStatus

```
axlGetDFMCsetAssignmentStatus(
     cset_name
     subtype

     ⇒ l_dff_cset/nil
```

Description

This function checks if a given Manufacturing (DFM) CSet is assigned in a design.

©2023 All Rights Reserved.

Arguments

cset_name Name of the CSet

subtype Specifies the sub type of the CSet. The valid values are:

DFF_OUTLINE: Indicates that CSet is going to hold constraints pertaining to OUTLINE worksheet.

DFF_MASK: Indicates that CSet is going to hold constraints pertaining to MASK worksheet.

DFF_HOLE: Indicates that CSet is going to hold constraints pertaining to HOLE worksheet.

DFF_SILKSCREEN: Indicates that CSet is going to hold constraints pertaining to SILKSCREEN worksheet.

DFF_ANNULAR_RING: Indicates that CSet is going to hold constraints pertaining to ANNULAR RING worksheet.

DFF_COPPER_FEATURE: Indicates that CSet is going to hold constraints pertaining to COPPER FEATURE worksheet.

DFF_COPPER_SPACING: Indicates that CSet is going to hold constraints pertaining to COPPER SPACING worksheet.

DFA_OUTLINE: Indicates that CSet is a DFA CSet pertaining to DFA outline worksheet.

DFA_PKGPKG: Indicates that CSet is a DFA CSet pertaining to DFA package to package worksheet.

DFA_SPACING: Indicates that CSet is a DFA CSet pertaining to DFA spacing worksheet.

DFA_COMPLEAD: Indicates that CSet is a DFA CSet pertaining to DFA component lead worksheet.

DFA_MASK: Indicates that CSet is a DFA CSet pertaining to DFA mask worksheet.

DFA_FIDUCIAL: Indicates that CSet is a DFA CSet pertaining to DFA fiducial worksheet.

©2023 All Rights Reserved.

DFT_OUTLINE: Indicates that CSet is a DFT CSet pertaining to DFT outline worksheet.

DFT_MASK: Indicates that CSet is a DFT CSet pertaining to DFT mask worksheet.

DFT_SPACING: Indicates that CSet is a DFT CSet pertaining to DFT spacing worksheet.

DFT_PROBE: Indicates that CSet is a DFT CSet pertaining to DFT probe worksheet.

Value Returned

`t`	If CSet is assigned
`nil`	Otherwise

See Also

axlCreateDFMCset, axlCreateDfmAssignment, axlDeleteDffCset, axlGetDFMAssignedCsets

Example

```
retVal = axlGetDFMCsetAssignmentStatus( "ABC" "DFF_MASK")
```


©2023 All Rights Reserved.

axlRenameDFFCset

```
axlRenameDFFCset(
     oldCsetName
     newCsetName
     csetType
     )
     ⇒ l_csetObj/nil
```

Description

This function renames an existing DFF CSet with a new name.

Arguments

oldCsetName	Name of the existing cset
newCsetName	New name of the cset
csetType	Type of the existing cset. Refer to List of Subtype CSets for valid values.

Value Returned

`l_csetObj`	New id of cset
`nil`	If failed

See Also

axlCreateDffCset, axlCreateDffAttr

Example

```
axlRenameDFFCset("test" "test_new" "DFF_OUTLINE")
 ==> "12,1,2,0,test_bucket1,TOP,test_cset1"
```


©2023 All Rights Reserved.

axlCreateDFMCset

```
axlCreateDFMCset(
     name
     subtype
     usage
     )
     ⇒ l_dff_set/nil
```

Description

This function creates a Design For Manufacturing (DFF) Cset. The DFM cset holds the constraint values for various checks to be performed on the design.

Arguments

name	Name of the cset to create
subtype	Sub type of the cset. Refer to List of Subtype CSets for valid values.
usage	Specifies the cset intent. The valid values are: "ETCH": Indicates that cset is to be used for constraints in conducting layer. This is valid for DFF, DFA and DFT subdomain "NON_ETCH": Indicates that the cset is for constraints on non-etch subclasses. Valid for all the DFM subdomains "STACKUP": Indicates that the cset captures constraints for stackup based rules. Valid for DFF "SPACING": Indicates that cset captures package to package rules. This is valid for DFA_PKGPKG worksheets. "HEIGHT": Indicates that cset captures constraints for AOI rules. This is valid for DFA_PKGPKG worksheet.

Value Returned

`l_dfm_cset`	db id of the DFM cset object, if successful
`nil`	If failed

©2023 All Rights Reserved.

See Also

axlDeleteDffCset

Example

```
axlCreateDFMCset("test_cset33" "OUTLINE")
```


©2023 All Rights Reserved.

axlDeleteDFMCset

```
axlDeleteDffCset(
     name
     subtype
     )
     ⇒ t/nil
```

Description

This function deletes a DFM CSet from the database.

Arguments

name	Name of cset to delete
subtype	Type of the DFM cset. Refer to List of Subtype CSets for valid values.

Value Returned

`t`	If successful
`nil`	If failed

See Also

axlCreateDFMCset

Example

```
axlCreateDFMCset("test_cset33" "DFF_OUTLINE")
```


©2023 All Rights Reserved.

axlGetDFMCsets

```
axlGetDFMCsets(
     subtype
     )
     ⇒ l_dff_cset/nil
```

Description

This function gets the Design For Manufacturing (DFM) Csets in the design.

Arguments

subtype	Sub type of the cset. Refer to List of Subtype CSets for valid values.

Value Returned

`l_dfm_csetlist`	List of DB ids for the DFM csets of the specified types
`nil`	Failed or if there is none

See Also

axlCreateDFMCset, axlDeleteDffCset

Example

```
axlCreateDFMCset("DFT_PROBE" )
```


©2023 All Rights Reserved.

axlGetDFMCset

```
axlGetDFMCset(
     name
     subtype
     )
     ⇒ l_dff_cset/nil
```

Description

This function gets the Design For Manufacturing (DFM) Csets in the design.

Arguments

name	Name of the cset
subtype	Sub type of the cset. Refer to List of Subtype CSets for valid values.

Value Returned

`l_dff_cset`	dbid of the cset
`nil`	Failed or if the cset does not exist

See Also

axlCreateDFMCset, axlGetDFMCsets

Example

```
axlGetDFMCset("Test_cset" "DFT_PROBE" )
```


©2023 All Rights Reserved.