SCPI Command Tree

See Also

- Example Programs
- Find commands using a simulated VNA UI
- See list of all SCPI Errors.
- See Calibrating the VNA Using SCPI
- Synchronizing the Analyzer and Controller
- IEEE- 488.2 Common Commands
- Local Lockout

ABORt	Stops all sweeps
AFR	Automatic Fixture Removal
+ CALCulate	Click to hide and show CALC branches
CORRection	Electrical Delay and Phase Offset
CUSTom	Custom measurements
DATA	Sends and queries data
DIQ	Differential IQ measurement
DTOPology	Defines topology for a balanced measurement
EQUation	Equation Editor
FILTer	Time domain gating
FORMat	Display format
FSIMulator	Balanced measurements and Fixturing
FUNCtion	Trace Statistics
GCData	Read Gain compression data
GCMeas	Gain Compression Analysis
GDELay	Group Delay Aperture setting
HOLD	Trace Hold
LIMit	Limit lines for pass / fail testing
MARKer	Marker settings
MATH	Math / Memory
MEASure	Measurement settings specific to a measurement number
BLIMit	Bandwidth threshold settings
CONVersion	Conversion parameter setting
CORRection	Electrical delay settings
DATA	Sends and queries data
FILTer	Gate filter settings
FUNCtion	Trace Statistics
GCData	Read Gain compression data
GCMeas	Gain Compression Analysis

GDELay	Group Delay Aperture settings
LIMit	Limit line settings
MARKer	Marker settings
OFFSet	Mag and Phase offset
PARameter	Balanced measurement parameter settings
RLIMit	Ripple limit settings
SA	Spectrum Analyzer markers
SMOothing	Smoothing settings
TRANsform	Time domain transform settings
UNCertainty	Uncertainty trace properties
X	X-Axis settings
MIXer	X-axis display for FCA measurements
NORMalize	Receiver power cal (Obsolete)
OFFSet	Mag and Phase offset
PARameter	Create and delete measurements
RDATa?	Queries receiver data
SMOothing	Point-to-point smoothing
TRANsform	Time domain transform
UNCertainty	Uncertainty Trace Properties
X:AXIS	X-Axis Domain
CALPod	Controls CalPod units
CONTrol	Interface control, ECal module state control, and Rear-panel connector control.
CONTrol:MULTiplexer	Control the E5092A Configurable Multiport Test Set.
CSET	Work with a Cal Set without having to select it into that channel.
DISPlay	Display settings
FORMat	Format for data transfer
HCOPy	Hardcopy printing
INITiate	Continuous or manual triggering
LXI	LXI communications
MMEMory	Saves and recalls instrument states
OUTPut	Turns RF power ON and OFF

+ SENSe Click to hide and show SENSe branches

AMPLifier	Control the M9379A
AVErage	Sweep Averaging
BANDwidth	IF Bandwidth
CLASs	Returns measurement class name
CORRection	Calibration and other correction settings
| CKIT	Manage Cal Kits and ECal modules
| COLL:CKIT	Edit Cal Kit definitions
| COLL:GUIDed	Perform Guided Cals
| COLL:SESSion	Perform SMC and VMC calibrations

| CSET	Manage Cal Sets
| EXTension	Port Extensions
| IMD	Controls IMD and IMDx calibration
COUPle	Chopped or Alternate sweep
DUTControl	Control M9341B
ECAL:CHARacterize	Ecal user characterization
FOM	Frequency Offset (opt 080)
FOM Segment	Construct a segment table
FREQuency	Frequency sweep settings
GCSetup	Gain Compression App (opt 086)
MIXer	FCA measurements (opts S93082A and S93083A)
MIXer Embed LO	Allows measurements of mixers with embedded LO
MIXer Segment	Configures mixer segments
MULTiplexer	Controls external test sets
NOISe	Noise Figure (opt 028 / 029)
PATH	Provides access to hardware configuration
POWer	Receiver attenuation and overpower protection
PULSe	Configure internal pulse generators
ROLE	Assign sources to roles
ROSCillator	Returns the source of the reference oscillator
SEGMent	Segment sweep settings
SWEep	Sweep types
SWEep Pulse	Pulse measurements
SWITch	Control the M9191D switch module
TEMPerature	Returns the temperature on the receiver board
X:VALues	Returns X-axis values for channel
SOURce	Source power to the DUT
DC	DC Source control
PHASe	Phase control (Opt S93088A)
POWer:CORR	Source power calibration
ALC:MODE:REC	Receiver Leveling
STATus	Reads the VNA status registers

+ SYSTem Click to hide and show SYSTem branches

SYSTem	VNA system setting commands
ACTive	Manage active channel/measurement
| CAL:All	Calibrate All Channels
| CAPability	Reads various capabilities of the analyzer
| CAP:HARD:MODule	PXI module capabilities
	Perform channel operations

| **CHANnels**	
| **COMMunicate**	Controls and queries PNA settings
| **CONF:EDEV**	Configure external devices
| **CONF:EDEV:DC**	Configures external SMU, DC Meter, and DC Source properties
| **CONF:EDEV:PMAR**	Configures external Power Meter as Receiver
| **CORR:INTerpolate:LINear**	Linear interpolation
| **DATA:MEMory**	Shared memory commands
| **FIFO**	Controls data in and out of FIFO data buffer
| **PREFerences**	VNA Preferences
| **SERV:PVER**	Instrument Cal dates
| **UNCertainty**	Dynamic Uncertainty
TRIGger	Trigger measurements