2024/07/30 05:27 1/4 I/O Expansion GPIO MAP


I/O Expansion GPIO MAP

• I/O Level 3.3V

IOH(Output High Current) : 3.0 mAIOL(Output Low Current) : -3.0mA

https://wiki.odroid.com/ Printed on 2024/07/30 05:27

2024/07/30 05:27 3/4 I/O Expansion GPIO MAP



NAME	PIN #	PIN #	NAME
GND	1	2	5V_RUN
USB2_P7_DP	3	4	3.3V_RUN
USB2_P7_DN	5	6	GND
USB2_P5_DP	7	8	UART0_RXD
USB2_P5_DN	9	10	UART0_TXD
GND	11	12	UART0_CTS#
I2C_1_SCL	13	14	UART0_RTS#
I2C_1_SDA	15	16	GND
PWR_BTN#	17	18	I2C_0_SCL
GND	19	20	I2C_0_SDA
USB2_P6_DP	21	22	HDMI_CEC
USB2_P6_DN	23	24	+V5P0A

Power budget on the 5Volt and 3.3Volt power rails

"+5V_RUN_H" is active only when the system runs. Its maximum output current is 1000mA. "V5P0A" is always on even when the system turns off. Its maximum output current is 600mA. "+3.3V RUN H" is active only when the system runs. Its maximum output current is 700mA.

From:

https://wiki.odroid.com/ - ODROID Wiki

Permanent link:

https://wiki.odroid.com/odroid-h4/hardware/io_expansion_gpio

Last update: 2024/04/16 14:52



https://wiki.odroid.com/ Printed on 2024/07/30 05:27