

Diagnostic Command Master List

Command	Description	Size	Data Type	Filter
0001	Latching PID Command	0	N/A	00
0002	Shock Actuator Control Command	8	BMP	08
0003	Air Suspension Control Command	16	BMP	16
0004	One-Touch and Accessory Delay Command	8	BMP	08
0005	Door Lock Command	8	BMP	08
0006	Front Windshield Wiper / Washer Control Command	8	BMP	8
0007	Memory Recall Indicator Control Command	8	BMP	8
0008	Warning Lamps and Chime Command	8	BMP	8
0009	Key Pad Backlighting Control	8	BMP	8
000A	Enter Sleep Mode	0	N/A	0
000B	Parameter Reset Command	8	SED	6
000C	Battery Saver and Courtesy Entry Command	8	BMP	8
000D	Four Wheel Drive Transfer Case & Indicator Control Command	16	BMP	16
000E	Heated Window / Mirror Control Command	8	BMP	08
000F	Rear Wiper Control	8	BMP	08
0010	Rear Window Control Command	8	BMP	08
0011	Front Window Control Command	8	BMP	08
0012	Lamps Exterior Control	8	BMP	08
0013	Door Lock/Unlock Control	8	BMP	08
0014	Rear Door Lock/Unlock Control	8	BMP	08
0015	Turn Signal and Marker Lamps Command	8	BMP	08
0016	Head - Cornering Lamp Control Command	8	BMP	08
0017	Horn Control Command	8	BMP	08
0018	Speedometer Gauge Indicator Control	8	NUM	08
0019	Fuel Gauge Indicator Control	8	NUM	08
001A	Engine Coolant Temperature Indicator Control	8	NUM	08
001B	Tachometer Gauge Indicator Control	8	NUM	08
001C	Battery Voltage Indicator Control Command	8	NUM	00
001D	PWM Output Control Command #1	8	NUM	08
001E	Variable Voltage Output #1 Control Command	TBD	TBD	00
001F	Driver's Seat Output Control	8	BMP	08
0020	Sideview Power Mirror Output Control	8	BMP	08
0021	Message Center Display Character	8	ASC	08
0022	Memory Seat Selection Control	8	BMP	08
0023	Send Signal/Request to an ECU Command #1	8	BMP	08
0024	Send Signal/Request to an ECU Command #2	8	BMP	08
0025	Powertrain Non-Injector Output Control Command	TBD	TBD	00
0026	6-bit D/A Output Control Command #1	8	NUM	08
0027	PWM Output Control Command #2	8	NUM	08
0028	ACM Access Pointer	8	SED	08
0029	6-bit D/A Output Control Command #2	8	NUM	08
002A	Starter Control Command	8	BMP	08
002B	ABS Output Control Command	16	BMP	16
002C	Security Access Command	0	N/A	00
002D	Execute ABS Rolls Test Sequence	0	N/A	00
002E	Clear Recall Last Remote Receive Data and/or TIC PID	0	N/A	00
002F	Memory Select Control Command	8	BMP	00
0030	4WD Transfer Case Control	8	BMP	00
0031	Climate Control Temperature Control Command	8	BMP	08
0032	Climate Control A/C Clutch Demand Control Command	TBD	TBD	08
0033	Climate Control Blower Motor Speed Control Command	8	NUM	08
0034	Climate Control Blower Motor (Hi) Control Command	TBD	TBD	08
0035	Cellular Phone Control Command	8	BMP	08
0036	Program TIC Code Pointer	8	SED	08
0037	VDM Goto Accurate Trim Command	TBD	TBD	00
0038	Anti-Theft Indicator Lamp Control	8	SED	08
0039	Anti-Theft Ignition Key Code Erase Command	8	SED	08
003A	Anti-Theft Battery Enable Control	8	SED	08
003B	Anti-Theft RF Enable and Transmit Command	8	SED	08

Diagnostic Command Master List

Command	Description	Size	Data Type	Filter
003C	ABS Traction Assist Valve Output Control Command	8	BMP	08
003D	Airbag Warning Lamp and Tone Generator Enable	0	N/A	00
003E	Ride Control Output Command	16	BMP	16
003F	Save Calibration or Data Values	8	SED	08
0040	Central Lock Command	8	BMP	08
0041	Double Lock Command	8	BMP	08
0042	Trunk Release Command	0	N/A	00
0043	Power Sunroof Control Command	8	BMP	08
0044	Power Window Enable Command	8	BMP	08
0045	Anti-Theft Indicator Command	8	BMP	08
0046	Alarm System Arm / Disarm Command	8	BMP	08
0047	Powertrain Output Substitution Control Enable Mask Command	TBD	TBD	00
0048	Engine Coolant Command	8	BMP	08
0049	Audio Control Command	8	BMP	08
004A	Audio Cycle Speaker Sound	8	NUM	08
004B	Clear Keep Alive Memory Command	32	BMP	
004C	Brake System Control Command	8	BMP	08
004D	VAPSII Output Pulse Control	8	NUM	08
004E	Seatbelt Control	8	BMP	08
004F	Passenger Seat Output Control	8	BMP	08
0050	Operational Strategy Control	8	SED	08
0051	Neutral in Tow	0	N/A	00
0052	Steering Column Control Command	8	BMP	08
0053	Pedal Position Control Command	16	BMP	16
0054	Indicator Lamp Control Command II	16	BMP	16
0055	Indicator Lamp Control Command	16	BMP	16
0056	Display Segment Control	8	BMP	08
0057	Sliding Door Output Control	16	BMP	08
0058	Display Segment Control Command II	32	BMP	32
0059	All Wheel Drive Transfer Case & Indicator Control	16	BMP	16
005A	PRNDL Display Control Command	8	SED	08
005B	ABS Output Control Command II	16	BMP	16
005C	Indicator Lamp Control Command III	32	BMP	16
005D	Engine Torque Reduction Control	8	NUM	22
005E	Traction Control Priming and Switching Valve Co.	16	BMP	
005F	Steering Column Control Command 2	16	BMP	
0060	Depressurize Hydraulic Power Unit	0	N/A	00
0061	Neutral in Tow II	0	N/A	00
0062	Move Clutch to Desired Position	16	NUM	16
0063	4-Wheel Drive System Control Command	32	BMP	
0064	4-Wheel Drive tried to use this one, don't use for a while	-	-	
0065	Chime Command	32	BMP	
0066	Vehicle Option Content Control	16	BMP	16
0067	Configure Part Number Suffix	32		
0068	Backlighting Intensity Control Command	8	NUM	
006A	Oil Pressure Gauge Indicator Control	8	NUM	
006B	Tachometer Gauge Calibration Control	8	NUM	
006C	Battery Voltage Gauge Calibration Control	8	NUM	
006D	Oil Pressure Gauge Calibration Control	8	NUM	
006E	Yaw Output Control Command	32	BMP	
006F	Message Center Control	32	BMP	08
0070	Mirror Electrochromatic Illumination Control Command	16	BMP	
0071	Fuel Pump Control Command	8	NUM	
0072	Lamp Control Command	16	BMP	
0073	Mirror Control Command	32	BMP	
0074	Fuel Flow Offset	8	NUM	
0075	Fuel Fired Heater Control Command	32	BMP	05
0076	Perform ACCM Calibration Function	8	SED	09
0078	Anti-Theft System Control Command	8	SED	
0079	Anti-Theft System Control Command 2	8	BMP	

Diagnostic Command Master List

Command	Description	Size	Data Type	Filter
CLIMATE CONTROL COMMANDS 0080 - 008E				
0080	Climate Control Blend Door Control Command	8	SED	08
0081	Climate Control Recirculation Door Control Command	8	SED	08
0082	Climate Control Display Control Command	8	SED	08
0083	Climate Control Floor Door Control Command	8	SED	08
0084	Climate Control Panel Door Control Command	8	SED	08
0085	Climate Control Bypass Door Control Command	8	SED	08
0086	Climate Control Defrost Door Control Command	8	SED	08
0087	Climate Control Driver Side Coolant Flow Control Command	8	NUM	08
0088	Climate Control Passenger Side Coolant Flow Control Command	8	NUM	08
0089	Radiator Fan Speed Control Command	8	SED	08
008A	Climate Control A/C Duty Cycle Control	8	NUM	08
008B	Climate Control Blower State Control	8	SED	08
008C	Climate Control Continuous Blend Door Movement Control	8	NUM	08
008D	Climate Control System Control Command	32	BMP	08
008E	Climate Control Cycle Blend Door	0	N/A	08
INSTRUMENT CLUSTER COMMANDS 008F - 00AF				
008F	Voltmeter Pointer Placement Command	16	NUM	08
0090	Run-Dry Output Control	8	BMP	08
CLIMATE CONTROL COMMANDS 00B0 - 00DF				
00B0	Climate Control Left Blend Door Control Command	8	SED	05
00B1	Climate Control Right Blend Door Control Command	8	SED	05
00B2	Flash Memory Erase (Sector Selectable)	8	SED	06
00B3	Flash Memory Program (Sector Selectable)	8	SED	06
0100 - 014F GENERIC CONTROL				
0100	Delay Time Set	16	NUM	16
0101	Security Access Switch	8	SED	
0102	Instrumentation Control Command	32	BMP	
0103	Voltage / Current Control Command	32	BMP	
0104	Function Control Command 1	32	BMP	
0105	Global Closing Windows Control Command	8	BMP	26
0106	Glow Plug Telltale	8	BMP	12
010B	Baud Rate Select	8	SED	08
010D	Dimming Control Command	8	NUM	08
010E	Display Dimming Command	8	SED	
0110	Speedometer Gauge Placement Command	16	NUM	08
0111	Tachometer Gauge Pointer Placement Command	16	NUM	08
0112	Fuel Gauge Pointer Placement Command	16	NUM	08
0113	Temperature Gauge Pointer Placement Command	16	NUM	08
0115	Oil Pressure Gauge Pointer Placement Command	8	BMP	08
0120	Generic Digital Command	8	PKT	
0121	DSC Output Control	16	BMP	22
0122	Unconditional Module Reset	0	NA	06
0123	Initiate Data Transfer Across Unsupported Data Link	0	NA	06
0124	Electronic System Calibration	0	NA	06
0125	Reset ECU	0	NA	06
0126	Restart ECU	0	NA	06
0150 - 019F VEHICLE CONFIGURATION				
0150	Personality Configuration	32	BMP	32
0151	Module Mode Command	8	SED	08
0152	Program Key Fob TIC	32	NUM	

Diagnostic Command Master List

Command Description		Size	Data Type	Filter
0155	Module Configuration Command	32		
0190	Write Vehicle Identification Number Command 1	32	NUM	
0191	Write Vehicle Identification Number Command 2	32	NUM	
0192	Write Vehicle Identification Number Command 3	32	NUM	
0193	Write Vehicle Identification Number Command 4	32	NUM	
0194	Write Vehicle Identification Number Command 5	32	NUM	
0195	Write Vehicle Identification Number Command 6	32	NUM	
019A	Store Serial Number	32	NUM	
019C	Start Timed Access	0	N/A	
019D	Incode Response	16	NUM	
019E	Security System Control Command	8	SED	
01BA	B&A Enable	8	NUM	
0218	Store Part Identification Prefix	32	NUM	
0219	Store Part Identification Suffix	16	NUM	
0290	Parking Aid Control Command	32	BMP	
02A0	Security System - Number of Keys Required	8	NUM	
02A1	Security System Spare Key Switch	8	SED	
0300 - 031F GATEWAY / ACP CONTROL				
0300	Gateway State Access Command	32	PKT	00
0301	Audio Speaker Test Cycle	8	BMP	02
0320 - 034F RESTRAINTS				
0320	Airbag Warning and Passenger Airbag Deactivation Lamps	8	NUM	17
0321	System Selectable Calibration	8	SED	17
0323	Voice Microphone Passthrough Control	8	SED	17
0400	Voice Control Command	16	BMP	16
0500 - 051F ELECTRIC VEHICLE				
0500	Battery Select Command	8	SED	EV
0501	Charging System Output Control Command	32	BMP	EV
0502	Charging Level Control Command	16	NUM	EV
0503	Thermal Regulation Output Control Command	32	BMP	EV
0504	Fan Speed Control Command	16	NUM	EV
0505	Contactor Output Control Command	32	BMP	EV
0506	Current Output Control Command	32	BMP	EV
0507	Reset Historical Data	8	SED	EV
0508	Fluid Control Command	32	BMP	EV
0509	Battery State-of-Charge Gauge Control	8	NUM	EV
050A	Economy Gauge Control	8	NUM	EV
050B	Distance-to-Empty Gauge Control	16	NUM	EV
050C	Temperature Gauge Control	8	NUM	EV
050D	Maintain SLI Voltage	8	SED	EV
050E	Maintain Vacuum	8	SED	EV
SECURITY COMMANDS 0550 - 05FF				
0550	Unlimited Transponder Security Key	32	NUM	19
0551	Clear Alarm Trigger Event History	0	NA	19
0600 - 06FF Steering Commands				
0600	Electronic Power Steering Output Control	8	BMP	21
0601	Electronic Power Steering Motor Output Control	8	BMP	21

Diagnostic Command Master List

Command	Description	Size	Data Type	Filter
BRAKE COMMANDS 0700 - 07FF				
0700	Vehicle Speed Signal Output	8	NUM	03
LIGHTING COMMANDS 0800 - 08FF				
0800	Courtesy Lighting Ramp-up Command	0	NA	13
0801	Courtesy Lighting Ramp-down Command	0	NA	13
0802	Headlamp Position	8	NA	13
0803	Axle Height Sensor Parameter Reset	8	BMP	13
0804	Calibrate Front and Rear Axle Level Sensors	0	N/A	13
8000 - 87FF POWERTRAIN				
8001	Schedule Task Just Downloaded (one byte address)	TBD	TBD	00
8002	Schedule Task Just Downloaded (two byte address)	TBD	TBD	00
8003	Schedule Task Just Downloaded (three byte address)	TBD	TBD	00
8010	Keep Alive Memory Reset	TBD	TBD	00
8011	Invoke Shadow RAM Query	TBD	TBD	00
8012	Complete Keep Alive Memory Reset	0	N/A	-
8013	Select Calibration	4	ASCII	09
8014	Prioritize Rapid Data	0	N/A	09
8033	Alternate Learning Strategy for Diagnostics	8	SED	
8101	Transfer Execution to Task Just Downloaded (one byte address)	TBD	TBD	00
8102	Transfer Execution to Task Just Downloaded (two byte address)	TBD	TBD	00
8103	Transfer Execution to Task Just Downloaded (three byte address)	TBD	TBD	00
8104	Air Conditioning Control	16	BMP	09
8105	Glow Plug Control	32	BMP	09
8106	Fuel System Control	32	BMP	09
8107	EGR Valve Actuator Control	16	NUM	09
8108	EGR Throttle Plate Actuator Control	16	NUM	09
8109	Inlet Port Deactivation Actuator Plate Control	16	NUM	09
810A	Variable Geometric Turbo Actuator Control	16	NUM	09
810B	Cooling Fan Control	32	BMP	09
810C	Cylinder Head Sensor Control	8	BMP	09
810D	Heater Control	32	BMP	09
810E	Smart Alternator Regulator Setting	16	NUM	09
810F	Engine RPM Control	16	NUM	09
8110	Fuel Injection Pump Fuel Quantity Control	16	NUM	09
8112	Fuel Injection Pump Timing Control	16	NUM	09
8113	Set Clutch Valve Current	16	NUM	25
8114	Set select valve current	16	NUM	25
8115	Set shift forward valve current	16	NUM	25
8116	Set shift reverse valve current	16	NUM	25
8117	Put transmission in desired gear	8	SED	25
8118	Perform HPU Services (Hydraulic Power Unit)	8	SED	25
8119	Buzzer configuration data to driver interface	8	PKT	08
811A	Illumination brightness data to the driver interface	8	SED	08
811B	Transmission LED Data to the driver interface	8	PKT	08
811C	Transmission display data to the driver interface	8	PKT	08
811D	TCM Output Control Command	16	BMP	25
8800 - 88FF Convenience				
8800	Right Rear Memory Seat Selection Control	16	BMP	18
8801	Left Rear Memory Seat Selection Control	16	BMP	18
8802	Right Rear Seat Output Control	16	BMP	18
8803	Left Rear Seat Output Control	16	BMP	18
8804	Driver Seat Output Control 2	16	BMP	18
8900 - 89FF Suspension / ABS				
8900	Calibrate Steering Angle Sensor	0	N/A	03

Diagnostic Command Master List

Command Description		Size	Data Type	Filter
C900	Tone Playback			
		0	N/A	23
CC3E	Air Suspension Control Command 2			
		16	BMP	16
	F001 - F01F Security			
F001	Anti-theft Outcode and Incode			
F004	Security Access Timer	32	NUM	
F010	Set Service Mode	8	NUM	
FACE	Toggles gateway mode hold timer (part 1)	8	SED	
		0	N/A	

Tait Robert (RBAU/SST)

From: Carl Evered AUS [cevered@ford.com]
Sent: Tuesday, 30 November 1999 10:20 AM
To: anocon@swsa.com.au; mhorat@swsa.com.au
Subject: Diagnostic Requirements

The attached file contains all current information relative to Diagnostic Requirements. These documents are updated on a regular basis, it is anticipated that the Global Diagnostic Spec Part 1 and Appendix may be updated in the next two months. This will not affect the direct of Diagnostics, it may provide greater detail.

As an introduction to 'what is required for diagnostics' refer to the following sections prior to reading the complete documents:

WCR.pdf

- Provides a broad overview of requirements.

Pt1_42 - Part1.doc (Global Diagnostic Spec.)

Refer to the following pages:

P2-1 section 2.4

P2-2 section 2.5, 2.6

P3-1 section 3.2.2

6-1, section 6.2.1, 1

P8-3' section 8.7

P8-11section 8.9

Pt1_42a - Part 1, Appendix A.doc

P B-1 Provides a detailed requirements checklist.

P D-1 Documentation list.

Obviously the sections identified above should not be read in isolation, however it will provide a broad understanding prior to reading all documents in detail

Please call to discuss any issues as they arise.

Regards,

Carl Evered

New Model Co-ordinator

Upstream Engineering, FCSD, Ford Australia

Ph: 61 3 9359 7573

Fax: 61 3 9359 8276