

EXLs3





KIT CONTENT

•	EXLs3 Wireless Inertial Module	n. 1
•	EXLs3 strap holder	n. 1
•	Recharging docking-station	n. 1
•	Micro-USB cable	n. 1



You can find the EXLs3's **User Manual** and the PC application **ExIlmuController** in the EXLs3's internal flash disk.

In order to retrieve them, please follow the steps below:

- 1. Place the EXLs3 unit in the docking station
- 2. Connect the docking station to a USB port of a PC by using the provided USB cable. The micro-USB socket is located on one side of the docking station.
- 3. A new drive letter will be created on the host PC.
- 4. Move the whole content of the drive to a PC's local folder





EXL IMU CONTROLLER

The EXL IMU CONTROLLER is an application which allows to control and configure the EXLs3 modules.

It can support up to 7 modules at the same time.

Minimum PC requirements:

In order to work properly *ExI Imu Controller* must be installed on a PC with the following minimum characteristics:

- Processor 1 GHz or faster
- 4 GB RAM
- Monitor resolution 1280 x 1024 pixel
- Windows Vista, 7 or 8 (Dot.Net framework 4.5 required)

Installation:

After having copied the SETUP folder on a PC's local folder, launch **setup.exe** and follow the instructions on the PC.