IH40/IH45 HANDHELD RFID READER

Accessories Guide



Honeywell

BRACKETS AND BATTERY PACKS



IH25-BR-1

Non-booted EDA51 bracket

Allows holding the mobile computer and charging it simultaneously.



IH25-BR-2

Non-booted CT40 bracket

Allows holding the mobile computer and charging it simultaneously.



IH25-BR-3

Non-booted CT60 bracket

Allows holding the mobile computer and charging it simultaneously.



IH25-BR-4

Non-booted EDA51K bracket

Allows holding the mobile computer and charging it simultaneously.



IH25-BR-5

Non-booted EDA52/EDA56 bracket

Allows holding the mobile computer and charging it simultaneously.



IH40-BR-4S

Booted CT40 bracket, 4 screws

Bracket including 4 screws, allows holding the mobile computer and charging it simultaneously.



IH40-BK-45S

Non-booted CT45/XP bracket, 4 screws

Bracket including 4 screws; allows holding the mobile computer and charging it simultaneously.



IH40-BK-45PBS

Booted CT45/XP bracket, 4 screws

Bracket including 4 screws, allows holding the mobile computer and charging it simultaneously.



CT30P-IH40-BRS

Non-booted CT30 XP bracket, 4 screws

Bracket including 4 screws; allows holding the mobile computer and charging it simultaneously.



50181029-001

IH25/IH40/IH45 standard battery pack (Li-ion, 3.8V, 4000 mAh), ROW

For use on SKU# IHxx-x-xxxxxxxXK (excluding IHxx-x- xxxxxxxUK).



3007-3012-001

IH25/IH40 standard battery pack (Li-ion, 3.8V, 4000 mAh), US/C and LATAM

For use only on SKU# IHxx-x-xxxxxxxUK.

MISCELLANEOUS



50155100-001

Wrist wrap

Wrist wrap for holding.



IH40-ADP-SLV

Adapter sleeve

For booted CT40 standard charger.

CHARGERS



CT40-HB-UVN-0

Standard CT40 non-booted home base

For recharging computer and one spare battery. Kit includes home base and power supply. Power cord must be ordered separately. Supports USB client via USB Type B connector.



CT40-CB-UVN-0

Standard CT40 non-booted charge base

For recharging up to four computers only. Kit includes 4-bay charger and power supply. Power cord must be ordered separately.

COMPATIBLE CT40 CHARGERS

IH40 / IH45 can be charged with any charge dock that a non-booted CT40 / CT45 can be charged with. Other than the above two specimen chargers, IH40 / IH45 are compatible with the following list of existing CT40 chargers.

CT40-CB-UVN-0

CT40 non-booted charger

Kit includes four bay charger and power supply. Must order power cord separately. For recharging up to four computers only. One for US power cord, two for EU power cord, three for UK power cord.

CT40-EB-UVN-0

CT40 non-booted charger

Kit includes ethernet home base and power supply. Power cord must be ordered separately. Supports USB client via USB Type B connector. One for US power cord, two for EU power cord, three for UK power cord.

CT40-HB-UVN-0

CT40 non-booted home base

Kit includes homebase and power supply. Must order power cord separately. For recharging computer and a spare battery. Support USB client via USB Type B connector. One for US power cord, two for EU power cord, three for UK power cord.

CT40-NB-UVN-0

CT40 non-booted 4 bay Net Base

Kit includes dock and power supply, must order power cord separately. For ethernet comms and recharging up to four computers only. One for US power cord, two for EU power cord, three for UK power cord.

CT40-DB-UVN-0

CT40 non-booted display dock

Kit includes display base and power supply. Must order power cord separately. For charging CT40 only, connection with an external display, and extending I/O for HDMI, ethernet comm and three USB ports. One for US power cord, two for EU power cord, three for UK power cord.

For more information
sps.honeywell.com

Honeywell Safety and Productivity Solutions
855 S Mint St
Charlotte, NC 28202
800-582-4263
www.honeywell.com

IH40/IH45 RFID Reader Accessories Guide A4 | Rev A | 07/23
© 2023 Honeywell International Inc.

Honeywell