

1. Connection lidar



2. enable block "save trajectoire"



3. Changing the data storage path



Start driving and you'll get the appropriate data.

After got the data, you disable block "save trajectory" and read "HowToUseData"