

Retiring Calibration Gas Cylinders

To retire a calibration gas cylinder, perform the following steps.

- 1. Select the relevant calibration gas cylinder in the *Bottle Inventory* section.
- 2. Click on Retire.
- 3. A pop-up window will appear with the question, Are you sure you want to retire this bottle?
- 4. Click on Retire.