

STANDARD OPERATING PROCEDURE FOR ROLL GRINDING

- According to the quality check department find the rolls which are to be grinded.
- Lift the rolls using EOT crane and place it on the grinding machine fixing one end of the roll to head stock chuck and the another end to the tail stock firmly.
- Select the grinding wheel according to the quality instructions.
- Closely place the grinding wheel to the roll such that the surface of the roll and the grinding wheel should meet.
- Ensure coolant is supplied continuously while grinding.
- Because of the grinding the diameter of the roll reduces at the range between 0.01 to 0.05mm and tolerance up to 0.03mm.
- After the grinding operation the coolant on the roll is wiped using the cloth.
- After cleaning cover is wrapped around the roll.
- Before removing the roll from the tailstock and head stock Grease is applied on the either ends of the roll.
- Place the sticker on the roll mentioning its final diameter, camber and finish.
- Then using EOT the roll is placed on the storage cell.