Page 1: Fasteners and Alignment Overview

Loose fasteners and misaligned shafts or conveyor belts cause vibration and premature wear. Check torque marks and belt tracking during every weekly round.

Page 2: Loose Bolt Re-tightening

Defect Type: Loose Bolt.

Symptom: Broken torque stripe, rattling, visible gap under the bolt head or fretting dust around a flange.

Action Required: Re-tighten to the specified torque in a cross pattern; for M16 bolts the value is 210 Nm. Replace any bolt that is stretched or has damaged threads and issue an immediate tightening work order. Priority: Medium.

Page 3: Shaft and Conveyor Misalignment

Defect Type: Misalignment.

Symptom: Belt drifting to one side, uneven wear, high axial vibration or coupling heat.

Action Required: Isolate the drive, align shafts with a laser alignment tool to within 0.05 mm offset and re-track the belt. If misalignment recurs more than twice in 24 hours call a maintenance technician. Priority: Medium.